


SPECIFICATION CONTROL DRAWING	Revisions			
	Rev.	Date	Description	ECO No.
	A	7/13/12	Production Release	----

Dimensions and drawings for reference only. Drawings are not to scale.



Specifications

1. Description Product documentation, Alpha TT Owner's Mnual (EN)
2. Size Trimmed: Width = 9.5" Height = 4.75". Finished, Folded: Width = 4.75", Height = 4.75".
3. Tolerance ±0.0787" (±2 mm)
4. Pagination 70 pages
5. Material Cover: 200-lb coated ivory board. Text: 100-lb matte-finish offset. Approved Equivalents Allowed
6. Finish Cover: High gloss. Text: Matte. Approved Equivalents Allowed.
7. Color Cover: 4-color process. Text: Black and white
8. Bindery Saddle-stitched (72 pages maximum), Perfect-bound. Approved Equivalents Allowed.
9. Folds N/A
10. Electronic Artwork Shall conform to Garmin Archive 190-01500-00_0A.zip
11. Languages
12. Notes This part shall comply with Garmin Banned & Restricted Substances (GPN 001-00211-00).

Files

The following files have been archived under the above ARCHIVE FILENAME.

File Name	File Contents
190-01500-00_0A.indd	InDesign CS4 for PC, Formatted manual
190-01500-00_0A_Spec.indd	InDesign CS4 for PC, Document specification sheet
190-01500-00_0A.pdf	Portable Document Format, Manual and specification sheet for printing
Links	Graphic files (eps, bmp, etc.)
Fonts	Font files
Alpha-TT_OM_EN.pdf	Portable Document Format, for online

<p style="text-align: center;">CONFIDENTIAL</p> <p>This drawing and the specifications contained herein are the property of Garmin Ltd. or its subsidiaries and may not be reproduced or used in whole or in part as the basis for manufacture or sale of products without written permission.</p>					<p>Garmin Ltd. or its subsidiaries C/O Garmin International, Inc. 1200 E. 151st Street Olathe, Kansas 66062 U.S.A.</p>	
			TITLE Alpha TT Owner's Manual (EN)			
Drawn By: KEG		Date: 7/13/12	SIZE: A	PART NO: 190-01500-00		REV: A
Checked By:						
Project Manager:			SCALE: N/A		Sheet Of 1 72	
Approved By:						

GARMIN

Alpha™ 100 and TT™ 10 Owner's Manual



July 2012

190-01500-00_01

Printed in Taiwan

All rights reserved. Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of Garmin. Garmin reserves the right to change or improve its products and to make changes in the content of this manual without obligation to notify any person or organization of such changes or improvements. Go to www.garmin.com for current updates and supplemental information concerning the use of this product.

Garmin®, the Garmin logo, BlueChart®, and City Navigator® are trademarks of Garmin Ltd. or its subsidiaries, registered in the USA and other countries. Alpha™, ANT+™, BaseCamp™, and TT™ are trademarks of Garmin Ltd. or its subsidiaries. These trademarks may not be used without the express permission of Garmin.

microSD™ is a trademark of SD-3C, LLC. Windows® and Windows NT® are registered trademarks of Microsoft Corporation in the United States and other countries. Mac® is a trademark of Apple Computer, Inc., registered in the U.S. and other countries.

DRAFT

Table of Contents

Getting Started	1
Setting Up the Alpha System	1
Device Overviews	1
Alpha 100 Handheld Device	1
TT 10 Dog Collar Device	2
Getting More Information	2
Registering Your Device	2
Installing the Battery in the Handheld Device	2
Charging the Handheld Device	3
Charging the Dog Collar Device	4
Turning On the Devices	4
Turning Off the Devices	4
Acquiring Satellite Signals	5
Using the Touchscreen	5
Locking the Touchscreen	5
Unlocking the Touchscreen	5
Profiles	5
Changing Profiles	5
Creating a Custom Profile	6
Editing a Profile Name	6
Dog Collar Device Setup	6
Methods to Add a Dog to a Handheld Device	6

Adding a Dog Over MURS/VHF	7
Adding a Dog Using the Track and Train Codes	7
Finding the Dog ID and Track and Train Codes	8
Sharing a Dog Wirelessly Over ANT+	8
Editing Dog Information	9
Resetting a Dog's Statistics and Track	9
Changing the Length of the Dog's Track	9
Changing the Dog Name	9
Changing the Color of the Dog's Track	9
Changing the Dog Type	9
Changing the Dog ID	9
Setting Dog Alerts	10
Removing a Dog	10
Attaching the Collar on Your Dog	10
Communication with the Collar	11
Dog Tracking	12
Tracking Your Dog on the Map	13
Dog Status Icons	13
Dog Tracking Compass	14
Navigating to Your Dog	14

Tracking with BaseCamp™	Adding a Contact Over MURS/VHF	23
BaseStation	Adding a Contact Using the ID	24
Pausing Dog Tracking	Sending a Message to Your Contacts ..	24
Pausing All Dog Tracking	Tracking a Contact	25
Location Alerts	Finding Your Contact ID	25
Setting a Geofence Alert	Changing Your Contact ID	25
Setting a Radius Alert	Updating a Contact's ID	25
Editing Location Alerts		
Dog Training	Hunting with the Alpha System ..	26
Selecting and Installing the Contact	Marking Your Truck Location	26
Points	Marking a Covey	26
Removing the Contact Points	Turning On the Collar Beacon	26
Setting the Training Keys for One Dog ..	Turning On Rescue Mode	27
More Than One Dog	Waypoints, Routes, and Tracks .	27
Basic Training Commands	Waypoints	27
Training to Heel	Marking Your Current Location	27
Training to Sit and Stay	Marking a Waypoint Using the	
Training to Come Here	Map	27
Collar Training	Editing a Waypoint	27
Training Intensities and Types ..	Repositioning a Waypoint to Your	
Teaching the Dog to Heel and Sit	Current Location	27
with the Collar	Moving a Waypoint on the Map	28
Training the Dog to Come Here	Increasing the Accuracy of a Waypoint	
with the Collar	Location	28
	Projecting a Waypoint	28
	Deleting a Waypoint	28
Contact Tracking	Routes	29

Creating a Route	29	Calibrating the Compass	33
Editing the Name of a Route	29	Navigating with the Bearing Pointer	33
Navigating a Saved Route	29	Course Pointer	33
Editing a Route	29	Where To? Menu	34
Reversing a Route	29	Finding a Waypoint by Name	34
Viewing a Route on the Map	30	Finding a Waypoint Near Another Waypoint	34
Viewing the Active Route	30	Navigating with Sight 'N Go	34
Deleting a Route	30	Elevation Plot	34
Tracks	30	Calibrating the Barometric Altimeter	35
Recording Track Logs	30	Navigating to a Point on the Plot	35
Viewing Details about the Track	31	Changing the Plot Type	35
Viewing the Elevation Plot of a Track	31	Resetting the Elevation Plot	35
Navigating to the Start of a Track	31	Trip Computer	35
Changing the Track Color	31	Resetting the Trip Computer	35
Saving the Current Track	31	Applications	36
Saving a Location on a Track	31	Setting a Proximity Alarm	36
Clearing the Current Track	32	Calculating the Size of an Area	36
Deleting a Track	32	Viewing the Calendar and Almanacs	36
Archiving a Saved Track	32	Setting an Alarm	36
Archiving Tracks Automatically	32	Starting the Countdown Timer	37
Sending and Receiving Data Wirelessly	32	Opening the Stopwatch	37
Navigation	32	Satellite Page	37
Map	32	Changing the Satellite View	37
Compass	33		

Turning Off GPS	37	Device Care	44
Simulating a Location	37	Cleaning the Device	44
Customizing Your Device	37	Cleaning the Screen	44
Customizing the Main Menu	37	Specifications	44
Customizing the Data Fields	38	Alpha 100 Handheld Device	
Enabling the Map Data Fields	38	Specifications	44
System Settings	38	TT 10 Dog Collar Device	
Dog Settings	38	Specifications	45
Contact Settings	39	Battery Information	45
Display Settings	39	Long-Term Storage	45
Calibrating the Touchscreen	39	Maximizing the Battery Life	46
Appearance Settings	39	Adjusting the Backlight	
Setting the Device Tones	40	Brightness	46
Map Settings	40	Adjusting the Backlight	
Advanced Map Settings	40	Timeout	46
Track Settings	41	Changing the Dog Collar Device	
Routing Settings	41	Update Rate	47
Changing the Units of Measure	41	Changing Your Handheld Update	
Time Settings	42	Rate	47
Position Format Settings	42	Turning On the Handheld Battery	
Heading Settings	42	Save Mode	47
Altimeter Settings	42	Adjusting the Map Drawing	
Marine Map Settings	43	Speed	47
Device Information	43	About Data Management	47
Viewing Device Information	43	File Types	47
Updating the Software	44	Installing a Memory Card	48

Connecting the Handheld Device to a Computer	48
Connecting the Collar to a Computer	49
Deleting Files	49
Disconnecting the USB Cable	49
Appendix	50
Accessories and Replacement Parts	50
Purchasing Accessories	50
Optional Maps	50
About Memory Cards	50
Optional Fitness Accessories	50
TT 10 Battery Replacement Instructions	51
TT 10 Components	51
Removing the Old Battery	51
Installing the New Battery	52
Replacing the Collar Strap	52
Replacing the VHF Antenna in the Dog Collar Device	53
Changing the Fuse in the Vehicle Power Cable	54
Data Field Options	54
Index	58

DRAFT

Getting Started

WARNING

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

Setting Up the Alpha System

Before you can use the Alpha handheld device and the TT dog collar device, you must set up the devices.

- 1 Install the battery in the handheld device (page 2).
- 2 Charge the handheld device (page 3).
- 3 Charge the collar (page 4).
- 4 Turn on the devices (page 4).
- 5 If necessary, add the collar to the handheld device (page 7).
- 6 Acquire satellite signals (page 5).

Device Overviews

Alpha 100 Handheld Device



①	GPS antenna
②	VHF radio antenna
③	Training keys
④	Power key
⑤	Mounting spine
⑥	microSD™ memory card slot (under battery)
⑦	Battery cover D-ring
⑧	Mini-USB port (under weather cap)

TT 10 Dog Collar Device



①	VHF antenna
②	GPS antenna
③	⏻ Power key
④	Contact points
⑤	Status LED and flashing beacon LEDs

Getting More Information

You can find more information about this product on the Garmin® website.

- Go to www.garmin.com/alpha.
- Go to www.garmin.com/outdoor.

- Go to www.garmin.com/learningcenter.
- Go to <http://buy.garmin.com>, or contact your Garmin dealer for information about optional accessories and replacement parts.

Registering Your Device

Help us better support you by completing our online registration today.

- Go to <http://my.garmin.com>.
- Keep the original sales receipt, or a photocopy, in a safe place.

Installing the Battery in the Handheld Device

WARNING

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, store the device out of direct sunlight.

- 1 Turn the D-ring counter-clockwise, and pull up to remove the cover.

- 2 Locate the metal contacts on the end of the lithium-ion battery.
- 3 Insert the battery into the compartment, contacts first.



- 4 Press the battery into place.
- 5 Replace the battery cover, and turn the D-ring clockwise.

Charging the Handheld Device

NOTICE

To prevent corrosion, thoroughly dry the mini-USB port, the weather cap, and the surrounding area before charging or connecting to a computer.

You should fully charge the handheld device completely before using it on a

hunt. Charging a depleted battery takes 4½ hours.

NOTE: The device will not charge when it is outside the temperature range of 32°F to 113°F (0°C to 45°C).

- 1 Lift the weather cap ①.



- 2 Plug the small end of the power cable into the mini-USB port ② on the device.
- 3 Plug the other end of the power cable into an appropriate power source.

Charging the Dog Collar Device

NOTICE

To prevent corrosion, thoroughly dry the contacts on the collar and the surrounding area before connecting the charging clip.

You should fully charge the collar completely before using it on a hunt. Charging a depleted battery takes 4½ hours.

- 1 Snap the charging clip ① onto the collar.



- 2 Plug the small end of the power cable into the mini-USB port ② on the charging clip.
- 3 Plug the other end of the power cable into an appropriate power source.
The LED is solid red when the collar is charging.
- 4 Remove the charging clip from the collar after the LED turns solid green.
If you do not remove the clip, it may become detached from the collar and become lost.

Turning On the Devices

- On the handheld device, select ⏻.
- On the collar, select the ⏻ Power key.
The collar beeps and the LED blinks green when the collar is turned on.

Turning Off the Devices

- On the handheld device, hold ⏻.
- On the collar, hold the ⏻ Power key until the LED turns red.









Acquiring Satellite Signals

Before you can track your dog with the track and train system, both the collar and handheld device must acquire satellite signals. Acquiring satellites can take a few minutes.

- 1 Go outdoors to an open area.
- 2 Turn on both devices (page 4).



The green LED blinks in intervals of 2 or 3 when the collar has acquired satellite signals.

Using the Touchscreen

- Select  to open the application drawer.
- Select  to open a menu.
- Select  to close the page and return to the previous page.
- Select  to return to the previous page.
- Select  to save changes and close the page.
- Select  and  to scroll.
- Select  to search by name.

Locking the Touchscreen

You can lock the screen to prevent inadvertent screen touches.

- 1 Select .
- 2 Select .

Unlocking the Touchscreen

- 1 Select .
- 2 Select .

Profiles

Profiles are a collection of settings that optimize your device based on how you are using it. For example, the settings and views are different when you are using the device with for hunting than when geocaching.

When you are using a profile and you change settings such as data fields or units of measurement, the changes are saved automatically as part of the profile.

Changing Profiles

When you change activities, you can change the setup of the handheld device to suit the activity by changing the profile.

- 1 Select  > **Profile Change**.

- 2 Select a profile.

Creating a Custom Profile

You can customize your settings and data fields for a particular activity or trip.

- 1 Select **Setup > Profiles**.
- 2 Select **Create New Profile > OK**.
The new profile is created with a default name, and the profile is now the active profile.
- 3 Customize the settings as necessary (page 37).
- 4 Customize the data fields as necessary (page 38).

Any changes you make to the settings, dashboards, and data fields are automatically saved to the active profile.

Editing a Profile Name

- 1 Select **Setup > Profiles**.
- 2 Select a profile.
- 3 Select **Edit Name**.
- 4 Enter the new name, and select ✓.

Dog Collar Device Setup

Methods to Add a Dog to a Handheld Device

If you purchased the collar and the handheld device separately, you must add the collar to the handheld device. You can add up to 20 collars to one handheld device.

There are three different methods to add (or pair) the collar to the handheld device: using MURS/VHF, using the track/train code, or using ANT+™.

Adding over MURS/VHF : Allows you to pair after you have placed the collar into pairing mode by pressing the power key.

This method is helpful when you are adding a new accessory collar to the system prior to leaving for the hunt.

See page 7.

Entering the track and train codes :

Allows you to add a dog that you do not own and that is not in the area. The dog's owner must determine if people can only track the dog or can

track and train the dog. This method requires the dog's owner to find and communicate the codes to the person adding the dog.

This method is helpful when you would like to add a dog before a hunt, but you are not near the dog. For example, you are adding another member of your hunting party's dog to your handheld device, but you do not own the dog.

See page 7.



Sharing wirelessly over ANT+ : Allows you to add a dog that you do not own and that is not in the area. The dog's owner must determine if people can only track the dog or can track and train the dog. This method does not require the dog's owner to find and communicate the codes to the person adding the dog. The two handheld devices must be within range (10 feet) to share data wirelessly.

This method is helpful when you would like to add a dog during a hunt, and you are not near the dog. For example, the dogs have already been let loose, but you are near the dog


owner, who can share the dog wirelessly.

See page 8.

Adding a Dog Over MURS/VHF

- 1 If necessary, turn off the collar by holding  until the LED turns red.
- 2 Hold the  Power key until the collar emits two series of beeps, about 2 seconds.

The LED begins blinking rapidly. The collar is now ready to be linked, or paired, with a handheld device.

- 3 On the handheld device, select **Dog List > Add Dog**.
- 4 Bring the collar near the handheld device, and select **Yes**.
- 5 Enter the name of the dog, and select  > **OK**.

Adding a Dog Using the Track and Train Codes

Before you can add a dog using the track and train codes, you must have the dog owner find the track and train codes (page 8) and tell them to you.

If you are not nearby the dog you want to add or you cannot put the collar into pairing mode, you can add the dog using the track and train codes.

- 1 Select **Add Dog**.
- 2 When asked if you are near the collar, and select **No**.
- 3 When asked if you know the track and train codes, and select **Yes**.
- 4 Enter the track or train code for the collar, and select **✓**.

The dog's track code allows you to view the dog's location with the map and dog tracking compass. The dog's train code allows you to track and train the dog.

- 5 Enter the name of the contact, and select **✓ > OK**.

Finding the Dog ID and Track and Train Codes

You can share a dog's track code so the other person can view your dog's location with the map and dog tracking compass. Also, you can share a dog's train code so the other person can track your dog and train (correct) your dog.

- 1 Select **Dog List**.
- 2 Select a dog.
- 3 Select **Show Info**.

Sharing a Dog Wirelessly Over ANT+

Before you can share data wirelessly, the two handheld devices must be within range (10 feet).

- 1 Select **Dog List**.
- 2 Select the dog to share.
- 3 Select **Share Wirelessly**.
- 4 Select an option:
 - To allow the other person to only track your dog's location with the map and dog tracking compass, select **Track Only**.
 - To allow the other person to track your dog and correct your dog's behavior, select **Track and Train**.
- 5 On the other handheld device, select **Dog List > ≡ > Receive Wirelessly**.

Editing Dog Information

Resetting a Dog's Statistics and Track

You might want to clear the dog statistics and track before a new hunt.

- 1 Select **Dog List**.
- 2 Select a dog.
- 3 Select **Show Info > Reset > Yes**.

Changing the Length of the Dog's Track

You can adjust the length of the tracks that are shown on the map.

- 1 Select **Setup > Dogs > Dog Track On Map**.
- 2 Select an option to show more or less of the tracks on the map.

Changing the Dog Name

- 1 Select **Dog List**.
- 2 Select a dog.
- 3 Select **Show Info**.
- 4 Select the dog's name.
- 5 Enter the name, and select **✓ > OK**.

Changing the Color of the Dog's Track

You can change the track color of the dog. It is helpful to have the track color match the color of the collar strap, if possible.

- 1 Select **Dog List**.
- 2 Select a dog.
- 3 Select **Show Info**.
- 4 Select the colored square next to the dog's name.
- 5 Select a color.


Changing the Dog Type

- 1 Select **Dog List**.
- 2 Select a dog.
- 3 Select **Show Info > ≡ > Change Dog Type**.
- 4 Select a dog type.

Changing the Dog ID

If you are experiencing interference from other collars or handheld devices in the area, you might need to change the ID for the dog.

- 1 Select **Dog List**.

- 2 Select a dog.
- 3 Select **Show Info**.
- 4 Select  > **Change ID**.
- 5 Select an ID that is not yet assigned to another device in the area.

If you select an ID that interferes with devices in the area, you should select a new ID.

If another handheld device is tracking this dog, for best results, remove the dog from the device and add again through the **Dog List** (page 7) or share the track and train codes to add the dog (page 7).

Setting Dog Alerts

You can adjust how the handheld device alerts you to certain actions of the dog.

- 1 Select **Setup > Dogs > Dog Alerts**.
- 2 Select an alert.
- 3 Select the handheld device action for the specific alert.
- 4 Repeat steps 3 and 4 as needed.

Removing a Dog

- 1 Select **Dog List**.
- 2 Select a dog.

- 3 Select **Remove**.

Attaching the Collar on Your Dog

CAUTION

To prevent irritation from the contact points, remove the collar for at least 8 hours out of every 24-hour period.

NOTICE

Remove the charging clip before putting the collar on the dog. If you do not remove the clip, it may become detached from the collar and become lost.


Before you put the collar on the dog, pair the handheld device and collar (page 7), and acquire satellite signals (page 5).

- 1 Select an option:
 - If you are training your dog with the collar, select and install the appropriate contact points (page 17).
 - If you are not training your dog with the collar, install the cap over the contact point locations (page 17).

- 2 Place the collar in the middle of the dog's neck, directly behind the dog's ears.
- 3 Position the collar with the VHF whip antenna pointing up, the GPS antenna facing up, and the LEDs facing forward.

When using the contact points, they can be positioned anywhere along the dog's neck. The best location for the contact points is in the front of the neck.

- 4 Tighten the strap so that it is snug around the dog's neck.



- 5 If the strap is too long, cut off the excess, leaving at least 3 inches to spare.


Communication with the Collar

If the collar and handheld device came in the same packaging, they were paired at the factory. If you are using a collar or handheld device that you purchased separately, add the collar to the handheld device to establish a communication link between the collar and handheld device (page 6).

The collar and handheld device must be within range to communicate with each other. The MURS/VHF radio communication range is up to 9 miles.

The collar and handheld device use radio signals to communicate. Objects in the path of radio signals degrade the quality of the signals. Keeping an unobstructed line of sight between the collar and handheld device produces the best communication signal. Obstructed radio waves result in a poor signal. To achieve the best line-of-sight

conditions, move to the highest elevation point in your area (for example, on the top of a hill).



Dog Tracking

The Alpha system allows you to track your dog, up to 9 miles away, using the dog

tracking compass or map. The map displays your location and your dog's location and tracks. The pointer acts like a

compass, pointing in the direction of the dog's current location.

One Alpha handheld device can track up to 20 devices (TT dog collar devices and Alpha handheld devices).

NOTE: Both the collar and the handheld device must have acquired satellites before you can track the dog on the handheld device.



Tracking Your Dog on the Map


Before you can track a dog or contact on the map, you must add them to the handheld device (page 7 and page 23).

You can view the dog's location and other contacts' locations on the map.






1 Select .



2 If necessary select  and  to zoom in and out of the map.

TIP: If necessary, select  to track the dog using the dog tracking compass (page 14).

Dog Status Icons

	Sitting
	Running
	On point
	Treed
	Unknown*

*The unknown status icon indicates that the collar has not acquired a satellite signal and that the handheld device cannot determine the location of the dog.

Dog Tracking Compass


To open the dog tracking compass, select



The dog tracking compass to view the direction and distance to your dog. The dog tracking compass also shows the dog's status, such as running or on point (page 13). The color of the pointer corresponds to the color of the dog track.


The dog tracking compass is most accurate when the dog is more than 30 feet (9.1) meters away. When the dog is less than 30 feet (9.1) away, "Near" appears.

Navigating to Your Dog

- 1 Select **Dog List**.
- 2 Select the dog.
- 3 Select **Show Info > Go**.
The map opens.
- 4 Follow the magenta line to the dog.
- 5 If necessary, select  to track the dog using the dog tracking compass (page 14).

Tracking with BaseCamp™ BaseStation

The BaseStation feature of BaseCamp allows you to track your dogs and contacts in real-time on a computer. For more information on using BaseCamp, see the help file in the application.

- 1 Select **Setup > System > BaseCamp Basestation > Prompted**.
- 2 Lift the weather cap .



- 3 Plug the small end of the USB cable into the mini-USB connector ② on the device.
- 4 Plug the other end of the USB cable into an available USB port on the computer.
- 5 Open BaseCamp .
- 6 Follow the on-screen instructions.

Pausing Dog Tracking

You can pause the tracking of a single dog during a hunt. This can be helpful if the dog is taking a break.

- 1 Select **Dog List**.
- 2 Select a dog.
- 3 Select **Show Info** ≡ **Stop Tracking**.

TIP: To resume tracking, select ≡ > **Stop Tracking**.

Pausing All Dog Tracking

If you are moving the dogs during a hunt and you do not want to record the transportation of the dogs, you can pause the tracking of all of the dogs.

- 1 Select Ⓞ.
- 2 Select ≡ > **Stop Tracking**.

Location Alerts

Location alerts notify you when your dogs or contacts enter or leave a particular location. You can create a custom geofence or use a radius around your current location.

A geofence is a virtual boundary that you can create using points on the map. The virtual boundaries of your geofences are accurate up to approximately 6 ft. (6 m)

Setting a Geofence Alert

You can set up an invisible fence around an area and receive an alert when a dog or contact leaves or enters that area.

- 1 Select **Setup > Location Alerts > Add Alert > Geofence**.
 - 2 Select a point on the map, and select **Use**.
 - 3 Repeat step 2 to define a geofence with up to 5 points.
 - 4 Select **↩**.
- Select **Set Alert Type** to set the way the device notifies you for this alert.
 - Select **Set Alert Mode** to set the notification to sound on exit, entrance, or both.
 - Select **Delete** to remove the alert.

Setting a Radius Alert

You can receive an alert when a dog or contact gets within or away from a certain distance away from you.

- 1 Select **Setup > Location Alerts > Add Alert > Radius**.
- 2 Select the units of measurement.
- 3 Enter the radius distance, and select **✓**.

Editing Location Alerts

- 1 Select **Setup > Location Alerts**.
- 2 Select an alert.
- 3 Select an option:
 - Select **Disable** to turn off notifications for this alert.

Dog Training

In addition to tracking your dog, the Alpha system can help train your dog as well. The Alpha system can both train and track your dog from up to 9 miles away. One Alpha handheld device can track up to 20 devices (TT dog collar devices and Alpha handheld devices).

Training information is available at www.garmin.com/alpha. Research and investigate the training methods best suited for you, your dog, and your needs. This manual will provide some basics about training, but you are encouraged to research more.

When used properly, the collar is a very effective training tool to aid your dog in reaching its full potential. The use of the

collar should be used as part of an overall training program.

Begin training your dog on a leash, without the collar. Train your dog how to heel, sit and stay and come to you. After the dog shows a grasp of the concepts of these three basic commands, you begin training with the collar and the leash. Finally, when the dog consistently obeys commands using the leash and collar, you can remove the leash to train with only the collar.

Selecting and Installing the Contact Points

For best results, select the correct contact points based on your dog's coat.

- 1 Select the correct contact point length for your dog's coat type:
 - For dogs with thicker coats, use the longer contact points.
 - For dogs with shorter coats, use the shorter contact points.
- 2 If necessary, use the included wrench to remove the contact points.
- 3 Twist the contact points into the collar.

- 4 Tighten with the included wrench, but do not over tighten.

When you put the collar on the dog, make sure that the contact points are tight against the neck (page 10).

Removing the Contact Points

When you are not training the dog using the training keys, remove the contact points.

- 1 Use the included wrench to remove both contact points.
- 2 Place the cap over the contact point holes.

Setting the Training Keys for One Dog

Before you can assign the training keys to a dog, you must add the dog to the handheld device (page 7).

By default, the training keys are set to the lowest stimulation setting, with momentary (M), continuous (C), and tone (T) for each key. This mode is best for when you are training just on dog. When you train more than one dog, it is helpful to use the multi-dog training mode (page 18).

- 1 Select **Setup > Training**.
- 2 Select the top of the screen.
- 3 Select the intensity level for the keys.
- 4 Select ↩.

In this mode, the left key provides momentary simulation. The center key provides continuous stimulations. The right key provides a tone.

Setting the Training Keys for Training More Than One Dog

Before you can assign the training keys to a dog, you must add the more than one dog to the handheld device (page 7).

You can change the mode of the training keys to customize each key for a specific level and also better train multiple dogs. If you are training one dog, it is helpful to use the single-dog training mode (page 17).

- 1 Select **Setup > Training > Training Buttons > Change Mode**.
- 2 Select the top of the screen directly under the key you are customizing.
- 3 Select the dog you want to train with this key.

- 4 Select an intensity level for the key.
- 5 Select momentary (**M**), continuous (**C**), or tone (**Tone**).
- 6 Repeat with all three keys.
- 7 If you need to train with more than three keys, select **Insert Page**, and program the additional keys.
- 8 Select ↩.

Basic Training Commands

You should begin training your dog with a few basic commands using a leash only.

You should train the three basic commands in the following order: "heel," "sit" and "stay," and "here."

Initially, you should keep the training sessions short and only train one command during a session. This way, the dog is less likely to become confused and training should progress more quickly. Pay close attention while training the dog, so you can begin to learn when to go faster or slower, and when to take a break.

With plenty of repetition, consistency, patience, and a lot of praise, the dog should begin to obey these commands in

just a few short training sessions. Once the dog demonstrates a grasp of the concepts of these commands while on a leash, training with collar stimulations can be introduced, while keeping the dog on the leash.

Training to Heel

Before you begin training, put a leash on the dog, and select an area with minimal distractions.

The first command that you will teach the dog is the "heel" command.

- 1 With the dog at your side on a leash, command the dog to "heel" and begin walking forward while gently pulling on the leash.
- 2 If the dog gets in front of you, repeat the command "heel," and move in another direction or pull back on the leash.
- 3 If the dog starts to lag behind you, lightly tug on the leash to bring the dog back to your side.

Reward the dog with praise when the dog obeys the command.

Training to Sit and Stay

Before you begin training, put a leash on the dog, and select an area with minimal distractions. Before you train to sit and stay, you should first train to "heel."

The actual command is "sit," and the "stay" is implied. When you command the dog to sit, the dog should stay until you indicate otherwise.

- 1 Begin training this command walking the dog on a leash in the heel position.
- 2 Stop walking, pull up on the leash, and command the dog to "sit."
- 3 Maintain steady pressure on the leash until the dog obeys the command.
- 4 If the dog does not obey and seems confused, gently push down on the dog's back above the flank, to make the dog sit.

Reward the dog with praise when the dog sits and stays.

Training to Come Here

Before you begin training, put a leash on the dog, and select an area with minimal distractions. Before you begin training the

dog to come here, you should first train the dog to "heel" and "sit."

Teaching your dog to come here is the most important command. The "here" command allows you to maintain control of your dog and can be used to call your dog away from a potentially dangerous situation. This command must be taught properly.

- 1 With the dog in a sitting position, move away to the end of the leash. You may need to use a long leash to effectively train "here."
- 2 Command the dog to come "here" while gently tugging on the leash.

The dog might resist this command. With repetition and patience, the dog will learn to obey the command.

Reward the dog with praise when the dog obeys the command.

Collar Training

Begin training your dog on a leash, without the dog collar device. After the dog shows a grasp of the concepts of "heel," "sit" and "stay," and "here," you

can begin training with the collar and the leash.

During the initial stage of collar introduction, the dog learns that collar stimulation means the same thing as a tug on the leash. At first, the dog may be alarmed by the electronic stimulation. The key is to be patient and consistent and to not start off at too high of an intensity. Be fair and consistent, use repetition and praise when using the collar as a training tool.

If the dog does not respond to the stimulation level you have selected (page 22), increase the stimulation one level at a time until you achieve the appropriate response. Once you achieve the desired response, you can lower the stimulation level as long as the dog maintains consistency.

As the dog becomes more responsive to the training, you should begin to stimulate intermittently, giving the dog a "freebie." This will help keep the dog's attitude upbeat, and let you know that the dog is responding to the command rather than just the collar. As the dog becomes more proficient with the commands, you can

begin to introduce distractions, such as rolling a ball in front of the dog or walking him in the presence of others.

After the dog begins to respond consistently to the command during collar training, typically after about 5 or 6 training sessions using the collar, you can remove the leash and train with just the collar. Eventually in most training circumstances, your commands will not require stimulation when given with the command. You should only use stimulation when you need to repeat a command because the dog did not obey the first one.

As the dog becomes better trained, you should decrease the use of collar training. Continue to have the dog wear the collar until you feel certain that it is no longer needed to reinforce known commands. Abandoning the collar too early can lead to problems in the future.

Training Intensities and Types

The Alpha system provides two styles of training stimulation intensity levels. The default intensity style, **Linear**, contains 18 stimulation levels. The lowest level of

simulation is 1, and the levels increase sequentially to 18.

The second style, **Traditional**, contains 6 numbered levels that each have a high (**Hi**), medium (**Med**), and low (**Lo**) setting. Level 1 **Lo** is going to produce a very slight stimulation that is hardly perceived. Level 6 on **Hi** produces a very strong stimulation. You should find the correct training intensity level and then use **Lo**, **Med**, **Hi** levels as needed for the situation.

The Alpha system uses momentary (**M**) and continuous (**C**) types of stimulations. Momentary applies a brief stimulation when you press the key, regardless of how long the key is depressed. Continuous applies stimulation to the dog the entire time you press the key, for a maximum of 8 seconds. Your stimulations should typically be far shorter than 8 seconds. Continuous can be helpful when first beginning training with your dog.

You can also train using a tone (T). When you select **T** for a key, the key press activates an audible tone instead of stimulation. Using the tone can be a helpful training tool.

Choosing the Correct Intensity Level

- 1** Set the training keys to the lowest level (page 17).
- 2** Press a training key.
- 3** Observe the dog for a reaction, such as a head shake, neck movement, or just a change in expression.

Sometimes dogs will vocalize due to the surprise of the electrical stimulation. If the dog vocalizes more than once, the intensity level is too high for beginning training.

- 4** If there is no reaction, increase the intensity level by one level until the dog has a slight but discernible reaction to the stimulation.

The intensity level that causes a slight but discernible reaction is your dog's baseline level for beginning collar training. You do not need to, and should not, apply this intensity selection test again.

After you begin training, the dog's performance guides your intensity selection. As the dog advances in training, you may need to change the level depending upon circumstances.

Teaching the Dog to Heel and Sit with the Collar

Before you begin training your dog using the collar, your dog must show a grasp of the "heel," "sit," and "come" while on the leash, you must put on the collar (page 10), and you must find the correct intensity level (page 22).

When beginning collar training, start with the "heel" and "sit" commands.

- 1** With the dog at your side on a leash, pull up on the leash, and command the dog to "sit," and also press a training key briefly.

After the dog begins associating the collar stimulation with the command, move on to the "heel" command. Many dogs indicate that it is time to make this transition by trying to sit before being commanded, in an effort to avoid the stimulation associated with the command.

- 2** With the dog at your side on a leash and with the collar on, command "heel" and begin walking forward while gently pulling on the leash.

- 3 If the dog gets in front of you, press a training key briefly, repeat the command "heel", and move in another direction or pull back on the leash.

Reward the dog with praise when the dog obeys commands.

Training the Dog to Come Here with the Collar

Before you begin training your dog to "come" using the collar, your dog must a strong grasp of the "heel" and "sit" commands using the collar, you must put on the collar (page 10), and you must find the correct intensity level (page 22).

Teaching your dog to come here is the most important command. The "here" command allows you to maintain control of your dog and can be used to call your dog away from a potentially dangerous situation. This command must be taught properly.

- 1 With the dog in a sitting position, move away to the end of the leash.
You may need to use a long leash to effectively train "here."

- 2 Command the dog to come "here," gently tug on the leash, and press a training key briefly.

The dog might resist this command. With repetition and patience, the dog will learn to obey the command.

Reward the dog with praise when the dog comes when called.

Contact Tracking

You can track other hunters so you know where they are at all times. You can also send messages to your contacts. One Alpha handheld device can track up to 20 devices (TT dog collar devices and Alpha handheld devices).

Adding a Contact Over MURS/VHF

Before you can add a contact over MURS/VHF, you should be within 9 miles of the contact.

You can add fellow hunters to your handheld device so you can track them on the map (page 25) and send messages to them (page 24).

- 1 On your handheld device, select **^** > **Contacts** > **Add**.
- 2 Bring the two handheld devices near each other, and select **Yes** on your handheld device.
- 3 On the contact's handheld device, select **^** > **Contacts** > **Pair**.
- 4 On your handheld device, enter the name of the contact, and select **✓** > **OK**.

The contact is added to your handheld device.

If you would like to be added to another hunter's handheld device using your contact ID, repeat this procedure using the hunter's handheld device.

Adding a Contact Using the ID

Before you can add a hunter using the contact ID, you must have the hunter find the contact ID (page 25) and send it to you.

If you are not nearby the hunter you want to add, you can add the hunter using the contact ID.

- 1 On your handheld device, select **^** > **Contacts** > **Add**.
- 2 When asked if you are near the other handheld device, and select **No**.
- 3 When asked if you know the ID, select **Yes**.
- 4 Select the correct ID for the contact you are adding.
- 5 Enter the name of the contact, and select **✓** > **OK**.

The contact is added to your handheld device.

If you would like to be added to another hunter's handheld device using your contact ID, repeat this procedure using the hunter's handheld device.

Sending a Message to Your Contacts

- 1 Select **^** > **Contacts** > **Message**.
- 2 Select a message.

The message is sent to your contacts with your name before the message. Anyone tracking your handheld device receives the message.

Tracking a Contact

You can keep track of contacts' locations using the map.

- 1 Select **▲** > **Contacts**.
- 2 Select the contact.
- 3 Select **Show Info**.
- 4 Select an option:
 - To navigate to the contact, select **Go**, and follow the magenta line to the contact.
 - To view the contact's location on the map, select **Map**.

Finding Your Contact ID

Select **Setup** > **Contacts** > **Pairing Setup**.

The contact ID for your handheld device is listed under **ID**.

Changing Your Contact ID

If you are experiencing interference from other collars or handheld devices in the area, you might need to change the contact ID for your handheld device.

- 1 Select **Setup** > **Contacts** > **Pairing Setup** > **ID**.

- 2 Select a contact ID that is not yet assigned to another device in the area.

If you select a contact ID that interferes with devices in the area, you should select a new contact ID.

Each time a contact changes their contact ID, you must update the contact ID in your handheld device. (page 25).

Updating a Contact's ID

If a contact has changed their contact ID (page 25), you can quickly update the contact ID in your handheld device.

- 1 Select **▲** > **Contacts**.

- 2 Select the contact.

- 3 Select **Show Info**.

- 4 Select **≡** > **Change ID**.

- 5 Select the contact ID that matches the contact's new contact ID.

Hunting with the Alpha System

You can perform many tasks that are very helpful when you are hunting with the Alpha system.

- Mark your truck's location (page 26).
- Track your dogs (page 13).
- Track your fellow hunters (page 25).
- Mark the location of a covey (page 26).
- Send messages to your fellow hunters (page 24).
- Turn on the beacon light on the collar (page 26).
- Put the collar into rescue mode to save battery power (page 27).
- Pause tracking while you move the dogs (page 15).

Marking Your Truck Location

You can mark the location of the truck, so you can navigate back to your truck after the hunt.

- 1 Select **New Hunt**.

- 2 Follow the on-screen instructions.

Marking a Covey

You can mark a covey location and enter the estimated number of birds flushed and the number of birds taken.

- 1 Select **Mark**.
- 2 Select **Covey**.
- 3 Enter the number of birds flushed.
- 4 Enter the number of birds taken.
- 5 Select **OK**.


Turning On the Collar Beacon

You can turn on the LED on the collar at night to help locate a dog or to warn drivers if a dog wanders near a road. The light is visible for up to 100 yards.

- 1 Select **Dog List**.
- 2 Select a dog.
- 3 Select **Show Info**.
- 4 Select **≡ > Adjust Collar Light**.
- 5 Select **.**

Turning On Rescue Mode

You conserve battery power at the end of a long hunt, or if your dog might get out of range.

- 1 Select **Dog List**.
- 2 Select a dog.
- 3 Select **Show Info** >  > **Rescue Mode**.

When the collar battery life reaches below 10%, the collar update rate is automatically changed to once every 2 minutes.

Waypoints, Routes, and Tracks

Waypoints

Waypoints are locations you record and store in the device.



Marking Your Current Location

- 1 Select **Mark**.
- 2 Select an option:
 - Select **New**.

- Select a default location name, such as **Truck** or **Camp**.



- 3 Select **Save**.

Marking a Waypoint Using the Map

- 1 Select .
- 2 Select the location on the map.
- 3 Select the information bar along the top of the screen.
- 4 Select  > **OK**.



Editing a Waypoint

Before you can edit a waypoint, you must create a waypoint.

- 1 Select  > **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select an item to edit, such as the name.
- 4 Enter the new information.
- 5 Select .



Repositioning a Waypoint to Your Current Location

You can change the position of a waypoint. For example, if you move your vehicle, you can change the location to your current position.

- 1 Select  > **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Reposition Here**.



The waypoint location changes to your current location.

Moving a Waypoint on the Map

- 1 Select  > **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Move Waypoint**.
- 4 Select the new location on the map.
- 5 Select **Move**.

Increasing the Accuracy of a Waypoint Location

You can refine a waypoint location for more accuracy. When averaging, the device takes several readings at the same location and uses the average value to provide more accuracy.





- 1 Select  > **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Average Location**.
- 4 Move to the waypoint location.
- 5 Select **Start**.

- 6 Follow the on-screen instructions.
- 7 When the confidence status bar reaches 100%, select **Save**.

For best results, collect 4 to 8 samples for the waypoint, waiting at least 90 minutes between samples.

Projecting a Waypoint

You can create a new location by projecting the distance and bearing from a marked location to a new location.

- 1 Select  > **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Project Waypoint**.
- 4 Enter the bearing, and select .
- 5 Select a unit of measure.
- 6 Enter the distance, and select .
- 7 Select **Save**.

Deleting a Waypoint

- 1 Select  > **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select  > **Delete** > **Yes**.

Routes

A route is a sequence of waypoints or locations that leads you to your final destination.

Creating a Route

- 1 Select **▲** > **Route Planner** > **Create Route** > **Select First Point**.
- 2 Select a category.
- 3 Select the first point on the route.
- 4 Select **Use** > **Select Next Point**.
- 5 Select and repeat steps 3 through 5 to add all the points in the route.
- 6 Select **↪**.

Editing the Name of a Route

- 1 Select **▲** > **Route Planner**.
- 2 Select a route.
- 3 Select **Change Name**.
- 4 Enter the new name, and select **✓**.

Navigating a Saved Route

- 1 Select **▲** > **Route Planner**.
- 2 Select a route.
- 3 Select **View Map** > **Go**.

- 4 Navigate using the compass (page 33) or map (page 32).

Editing a Route

- 1 Select **▲** > **Route Planner**.
- 2 Select a route.
- 3 Select **Edit Route**.
- 4 Select a point.
- 5 Select an option:
 - To view the point on the map, select **View Map**.
 - To change the order of the points on the route, select **Move Up** or **Move Down**.
 - To insert an additional point on the route, select **Insert**.
The additional point is inserted before to point you are editing.
 - To remove the point from the route, select **Remove**.


Reversing a Route

- 1 Select **▲** > **Route Planner**.
- 2 Select a route.
- 3 Select **Reverse Route**.


Viewing a Route on the Map

- 1 Select  > **Route Planner**.
- 2 Select a route.
- 3 Select **View Map**.

Viewing the Active Route

- 1 Select  > **Active Route**.
- 2 Select a point in the route to view additional details.


Deleting a Route

- 1 Select  > **Route Planner**.
- 2 Select a route.
- 3 Select **Delete Route** > **Yes**.

Tracks

A track is a recording of your path. The track log contains information about points along the recorded path, including time, location, and elevation for each point.

Recording Track Logs

- 1 Select  > **Setup** > **Tracks** > **Track Log**.
- 2 Select **Record, Do Not Show** or **Record, Show On Map**.

If you select **Record, Show On Map**, a line on the map indicates your track.

- 3 Select **Record Method**.
- 4 Select an option:
 - To record tracks at a variable rate that create an optimum representation of your tracks, select **Auto**.
 - To record tracks at a specified distance, select **Distance**.
 - To record tracks at a specified time, select **Time**.
- 5 Select **Interval**.
- 6 Complete an action:
 - If you selected **Auto** for the **Record Method**, select an option to record tracks more or less often.

NOTE: Using the **Most Often** interval provides the most track detail, but fills up the device memory quicker.

- If you selected **Distance** or **Time** for the **Record Method**, enter a value, and select .

As you move with the device turned on, a track log is created.

Viewing Details about the Track

- 1 Select **▲** > **Track Manager**.
- 2 Select a track.
- 3 Select **View Map**.
The beginning and the end of the track are marked by flags.
- 4 Select the information bar along the top of the screen.
Information about the track is listed.

Viewing the Elevation Plot of a Track

- 1 Select **▲** > **Track Manager**.
- 2 Select a track.
- 3 Select **Elevation Plot**.

Navigating to the Start of a Track

You can navigate back to the beginning of a track. This can be helpful when finding your way back to camp or the trail head.

- 1 Select **▲** > **Track Manager** > **Current Track** > **View Map**.
- 2 Select **TracBack**.
The map page opens with your route marked with a magenta line.

- 3 Navigate using the map (page 32) or the compass (page 33).

Changing the Track Color

- 1 Select **▲** > **Track Manager**.
- 2 Select a track.
- 3 Select **Set Color**.
- 4 Select a color.

Saving the Current Track

- 1 Select **▲** > **Track Manager**.
- 2 Select a track.
- 3 Select an option:
 - To save the entire track, select **Save Track**.
 - To save part of the track, select **Save Portion**, and select the part to save.

Saving a Location on a Track

- 1 Select **▲** > **Track Manager**.
- 2 Select a track.
- 3 Select **View Map**.
- 4 Select a location along the track.
- 5 Select the information bar along the top of the screen.

- 6 Select **▶**.
- 7 Select **OK**.

Clearing the Current Track

Select **▲** > **Track Manager** > **Current Track** > **Clear Current Track**.

Deleting a Track

- 1 Select **▲** > **Track Manager**.
- 2 Select a track.
- 3 Select **Delete** > **Yes**.

Archiving a Saved Track

You can archive saved tracks to save memory space.

- 1 Select **▲** > **Track Manager**.
- 2 Select a saved track.
- 3 Select **Archive**.

Archiving Tracks Automatically

- 1 Select **Setup** > **Tracks** > **Auto Archive**.
- 2 Select an option.

Sending and Receiving Data Wirelessly

Before you can share data wirelessly, you must be within 10 feet (3 m) of a compatible Garmin device.

You can share waypoints, geocaches, routes, and tracks wirelessly. For information on sharing dog track and train codes wirelessly, see page 8.

- 1 Select **▲** > **Share Wirelessly**.
- 2 Select **Send** or **Receive**.
- 3 Follow the on-screen instructions.

Navigation

You can navigate a route, a track, to a waypoint, to a geocache, photo, or any saved location in the device. You can use the map or the compass to navigate to your destination.

Map

The **▲** blue triangle represents your location on the map. As you travel, the icon moves and leaves a track log (trail). Waypoint names and symbols appear on

the map. When you are navigating to a destination, your route is marked with a magenta line on the map.

When the map orientation is **Track Up**, objects on the map appear to rotate around your position. As you travel, the entire map reorients in the direction you are facing. You can stabilize the objects by setting the orientation to **North Up** (page 40).

To open the map, select .

Compass

The handheld device has a 3-axis compass. You can use a bearing pointer or a course pointer to navigate to your destination.

Calibrating the Compass

NOTICE


Calibrate the electronic compass outdoors. To improve heading accuracy, do not stand near objects that influence magnetic fields, such as vehicles, buildings, and overhead power lines.



You should calibrate the compass after moving long distances, experiencing

temperature changes, or removing the battery.

- 1 Select  > **Compass** >  > **Calibrate Compass** > **Start**.
- 2 Follow the on-screen instructions.


Navigating with the Bearing Pointer

When navigating to a destination, the  bearing pointer points to your destination, regardless of the direction you are moving.

- 1 While navigating to a destination, select  > **Compass**.
- 2 Turn until  points toward the top of the compass, and continue moving in that direction to the destination.

Course Pointer

The course pointer is most useful if you are navigating on water or where there are no major obstacles in your path. It also helps you avoid hazards to either side of the course, such as shoals or submerged rocks.

To enable the course pointer, from the compass, select  > **Setup Heading** > **Go To Line/Pointer** > **Bearing**.



The course pointer ① indicates your relationship to the course line leading to the destination. The course deviation indicator (CDI) ② provides the indication of drift (right or left) from the course. The scale ③ refers to the distance between dots ④ on the course deviation indicator, which tell you how far off course you are.

Where To? Menu

You can use the **Where To?** menu to find a destination to navigate to. Not all **Where To?** categories are available in all areas and maps.

Finding a Waypoint by Name

- 1 Select **▲** > **Where To?** > **Waypoints** > **☰** > **Spell Search**.
- 2 Enter the name.
- 3 Select **✓**.

Finding a Waypoint Near Another Waypoint

- 1 Select **▲** > **Waypoint Manager**.
- 2 Select a waypoint.
- 3 Select **☰** > **Find Near Here**.
- 4 Select a category.

The list displays waypoints near the original waypoint.

Navigating with Sight 'N Go

You can point the device at an object in the distance, lock in the direction, and then navigate to the object.

- 1 Select **▲** > **Sight 'N Go**.
- 2 Point the device at an object.
- 3 Select **Lock Direction** > **Set Course**.
- 4 Navigate using the compass (page 33) or map (page 32).

Elevation Plot

By default, the elevation plot displays the elevation for an elapsed time. You can customize the plot (page 35) and the data fields (page 38).

To open the elevation plot, select **▲** > **Elevation Plot**.

Calibrating the Barometric Altimeter

You can manually calibrate the barometric altimeter if you know the correct elevation or the correct barometric pressure.

- 1 Go to a location where the elevation or barometric pressure is known.
- 2 Select **▲** > **Elevation Plot** > **☰** > **Calibrate Altimeter**.
- 3 Follow the on-screen instructions.

Navigating to a Point on the Plot

- 1 Select **▲** > **Elevation Plot**.
- 2 Select an individual point on the plot.
Details about the point appear in the upper-left corner of the plot.
- 3 Select **☰** > **View Map**.
- 4 Select the information bar along the top of the screen.
- 5 Select **Go**.
- 6 Navigate using the compass (page 33) or map (page 32).

Changing the Plot Type

You can change the elevation plot to display pressure and elevation over time or distance.

- 1 Select **▲** > **Elevation Plot** > **☰** > **Change Plot Type**.
- 2 Select an option.

Resetting the Elevation Plot

Select **▲** > **Elevation Plot** > **☰** > **Reset** > **Clear Current Track** > **Yes**.

Trip Computer

The trip computer displays your current speed, average speed, maximum speed, trip odometer, and other helpful statistics. You can customize the trip computer layout, dashboard, and data fields (page 38).

To open the trip computer, select **▲** > **Trip Computer**.

Resetting the Trip Computer



For accurate trip information, reset the trip information before beginning a trip.

Select **▲** > **Trip Computer** > **☰** > **Reset** > **Reset Trip Data** > **Yes**.

Applications


Setting a Proximity Alarm

Proximity alarms alert you when you are within a specified range of a particular location.

- 1 Select  > **Proximity Alarms**.
- 2 Select **Create Alarm**.
- 3 Select a category.
- 4 Select a location.
- 5 Select **Use**.
- 6 Enter a radius.
- 7 Select 




When you enter an area with a proximity alarm, the device will sound a tone.

Calculating the Size of an Area




- 1 Select  > **Area Calculation** > **Start**.
- 2 Walk around the perimeter of the area you want to calculate.
- 3 Select **Calculate** when finished.

Viewing the Calendar and Almanacs

You can view device activity, such as a waypoint was saved, and almanac information for the sun and moon, and hunting and fishing.

- 1 Select .
- 2 Select an option:
 - To view device activity for specific days, select **Calendar**.
 - To view the sunrise, sunset, moonrise, and moonset times, select **Sun and Moon**.
 - To view the predicted best times for hunting and fishing, select **Hunt and Fish**.
- 3 If necessary, select  or  to view a different day.

Setting an Alarm


- 1 Select  > **Alarm Clock**.
- 2 Select  and  to set the time.
- 3 Select **Turn Alarm On**.
- 4 Select an option.

The alarm sounds at the selected time. If the device is off at the alarm time, the device turns on and sounds the alarm.

Starting the Countdown Timer

- 1 Select  > **Alarm Clock** >  > **Timer**.
- 2 Select  and  to set the time.
- 3 Select **Start Timer**.



Opening the Stopwatch

Select  > **Stopwatch**.

Satellite Page

The satellite page shows your current location, GPS accuracy, satellite locations, and signal strength.

Changing the Satellite View

- 1 Select  > **Satellite** > .
- 2 Select **Track Up** to change the view of the satellites to be oriented with your current track toward the top of the screen.

Turning Off GPS

Select  > **Satellite** >  > **Use With GPS Off**.

Simulating a Location

- 1 Select  > **Satellite** >  > **Use With GPS Off**.
- 2 Select  > **Set Location On Map**.
- 3 Select a location.
- 4 Select **Use**.

Customizing Your Device

Customizing the Main Menu

You can move, add, or delete items in the main menu.

- 1 From the main menu, select **Setup** > **Main Menu**.
- 2 Select a menu item.
- 3 Select an option.
 - Select **Move Up** or **Move Down** to change the location of the item in the list.

- Select **Remove** to delete an item from the list.

TIP: Select  > **Restore Defaults** to reset the menu order.

Customizing the Data Fields

Before you can customize the data fields on the map, you must enable the data fields (page 38).

You can customize the data fields and dashboards of the map, compass, elevation plot, and trip computer.

- 1 Open the page for which you will change the data fields.
- 2 Select a data field to customize.
- 3 Select the new data field.

For data field descriptions, see page 54.

Enabling the Map Data Fields

- 1 Select  >  > **Setup Map > Dashboard**.
- 2 Select **Large Data Fields** or **Small Data Fields**.

System Settings

Select **Setup > System**.

GPS: Sets the GPS to **Normal**, **WAAS/EGNOS** (Wide Area Augmentation System/European Geostationary Navigation Overlay Service, or **Demo Mode** (GPS off). For more information about WAAS, go to www.garmin.com/aboutGPS/waas.html.

BaseCamp Basestation: Sets how the device connects to BaseCamp when the device is connected to the computer.

Dog Settings

Select **Setup > Dogs**.

Dog Track On Map: Sets the length (duration in minutes or hours) of the dog track on the map. Reducing the duration of the track shown can reduce the clutter on the map.

Zoom Map To Dogs: Automatically zooms the map to show all of the dogs' locations and your location unless you manually pan the map. This feature is very helpful because it

automatically zooms the map to the level it is most helpful.

Dog Alerts: Sets how you are alerted to certain actions (page 10).

Contact Settings

Select **Setup > Contacts**.

Contact Track On Map: Sets the length of time of the contact track on the map.

Zoom Map To Contacts: Automatically zooms out the map to show all of the contacts' locations and your location unless you manually pan the map.

Message Alerts: Sets message alerts to **Tone, Vibrate, Tone and Vibrate**, or **Message Only**.

Pairing Setup: Sets the options your device uses to track and communicate with other devices.

Display Settings

Select **Setup > Display**.

Backlight Timeout: Adjusts the length of time before the backlight turns off.

Screen Capture: Allows you to save the image on the device screen.

Battery Save: Saves the battery power and prolongs the battery life by turning off the screen when the backlight times out (page 47).

Calibrate Screen: Aligns the screen to properly respond to touches (page 39).

Calibrating the Touchscreen

The screen does not normally require calibration. However, if the screen does not seem to be responding properly, calibrate the touchscreen.

- 1 Select **Setup > Display > Calibrate Screen**.
- 2 Follow the on-screen instructions.

Appearance Settings

Select **Setup > Appearance**.

Mode: Sets a light background, a dark background, or automatically switches between the two based on the sunrise and sunset time for your current location.

Background: Sets the background image.

Day Highlight Color: Sets the color for selections made when in day mode.

Night Highlight Color: Sets the color for selections made when in night mode.

Setting the Device Tones

You can customize tones for messages, keys, warnings, and alarms.

- 1 Select **Setup > Tones**.
- 2 Select a tone for each audible type.

Map Settings

Select **Setup > Map**.

Orientation: Adjusts how the map is shown on the page. **North Up** shows North at the top of the page. **Track Up** shows your current direction of travel toward the top of the page.

Automotive Mode shows an automotive perspective with the direction of travel at the top.

Guidance Text: Sets when the guidance text on the map is shown.

Dashboard: Selects a dashboard to display on the map. Each dashboard shows different information about your route or your location.

Map Information: Enables or disables the maps currently loaded on the device.

Map Speed: Adjusts the speed at which the map is drawn. A faster map drawing speed decreases the battery life.

Advanced Map Settings

Select **Setup > Map**.

Auto Zoom: Automatically selects the appropriate zoom level for optimal use on your map. When **Off** is selected, you must zoom in or out manually.

Detail: Selects the amount of detail shown on the map. Showing more detail may cause the map to redraw more slowly.

Shaded Relief: Shows detail relief on the map (if available) or turns off shading.

Vehicle: Selects the position icon, which represents your position on the map.

Zoom Levels: Adjusts the zoom level at which map items will appear. The map

items will not appear when the map zoom level is higher than the selected level.

Text Size: Selects the text size for map items.

Track Settings

Select **Setup > Tracks**.

Track Log: Turns track recording on or off.

Record Method: Selects a track recording method. **Auto** records the tracks at a variable rate to create an optimum representation of your tracks.

Interval: Selects a track log recording rate. Recording points more frequently creates a more-detailed track, but fills the track log faster.

Auto Archive: Selects an automatic archive method to organize your tracks. Tracks are saved and cleared automatically based on the user setting.

Color: Changes the color of the track line on the map.

Routing Settings

The device calculates routes optimized for the type of activity you are doing. The routing settings available vary based on the activity selected.

Select **Setup > Routing**.

Activity: Selects an activity for routing.

The device calculates routes optimized for the type of activity you are doing.

Route Transitions: Sets how the device routes from one point on the route to the next. Available only for some activities. **Distance** routes you to the next point on the route when you are within a specified distance of your current point.

Lock On Road: Locks the position icon, which represents your position on the map, onto the nearest road.

Changing the Units of Measure

You can customize units of measure for distance and speed, elevation, depth, temperature, and pressure.

- 1 Select **Setup > Units**.
- 2 Select a measurement type.
- 3 Select a unit of measure for the setting.

Time Settings

Select **Setup > Time**.

Time Format: Sets the device to show time in a 12-hour or 24-hour format.

Time Zone: Sets the time zone for the device. **Automatic** sets the time zone automatically based on your GPS position.

Position Format Settings

NOTE: Do not change the position format or the map datum coordinate system unless you are using a map or chart that specifies a different position format.

Select **Setup > Position Format**.

Position Format: Sets the position format in which a given location reading appears.

Map Datum: Sets the coordinate system on which the map is structured.

Map Spheroid: Shows the coordinate system the device is using. The default coordinate system is WGS 84.

Heading Settings

You can customize the compass settings.

Select **Setup > Heading**.

Display: Sets the type of directional heading on the compass.

North Reference: Sets the north reference of the compass.

Go To Line/Pointer: Allows you to use the **Bearing** pointer that points in the direction of your destination, or use the **Bearing** that shows your relationship to the course line leading to the destination.

Compass: Automatically switches from an electronic compass to a GPS compass when you are traveling at a higher rate of speed for a period of time.

Calibrate Compass: See page 33.

Altimeter Settings

Select **Setup > Altimeter**.

Auto Calibration: Self-calibrates the altimeter each time the device is turned on.

Barometer Mode: Variable Elevation allows the barometer to measure changes in elevation while you are moving. **Fixed Elevation** assumes the device is stationary at a fixed elevation. Therefore, the barometric pressure should only change due to weather.

Pressure Trending:
Sets how the device records pressure data. **Save Always** can be useful when you are watching for pressure fronts.

Plot Type: Records elevation changes over a period of time or distance, records barometric pressure over a period of time, or records ambient pressure changes over a period of time.

Calibrate Altimeter: See page 35.

Marine Map Settings

Select **Setup** > **Marine**.

Marine Chart Mode: Selects a nautical chart or a fishing chart. **Nautical** displays various map features in different colors so that the marine POIs are more readable and so the map reflects the drawing scheme of paper charts. **Fishing** (requires marine maps) displays a detailed view of bottom contours and depth soundings and simplifies map presentation for optimal use while fishing.

Appearance: Sets the appearance of marine navigation aids on the map.

Marine Alarm Setup: Sets alarms for when you exceed a specified drift distance while anchored, when you are off course by a specified distance, and when you enter water of a specific depth.

Device Information

Viewing Device Information

You can view the unit ID, software version, and license agreement.

Select **Setup** > **About**.

Updating the Software

Before you can update the handheld device or collar software, you must first connect the handheld device (page 48) or the collar (page 49) to the computer.

You must update the software on the handheld device and collar individually.

NOTE: Updating the software does not erase any of your data or settings.

- 1 Go to www.garmin.com/products/webupdater.
- 2 Follow the on-screen instructions.

Device Care

NOTICE

Do not store the device where prolonged exposure to extreme temperatures can occur, because it can cause permanent damage.

Never use a hard or sharp object to operate the touch screen, or damage may result.

Avoid chemical cleaners and solvents that can damage plastic components.

Cleaning the Device

- 1 Wipe the device with a cloth dampened with a mild detergent solution.
- 2 Wipe it dry.

Cleaning the Screen

Before you can clean the screen, you should have a soft, clean, lint-free cloth and water, isopropyl alcohol, or eyeglass lens cleaner.

Apply the liquid to the cloth, and gently wipe the screen with the cloth.

Specifications

Alpha 100 Handheld Device Specifications

Battery type	Rechargeable, replaceable lithium-ion
Battery life	Up to 20 hours
Operating temperature range	From -4°F to 140°F (from -20°C to 60°C)
Charging temperature range	From 32°F to 113°F (from 0°C to 45°C)
Long-term storage temperature range	From 32°F to 77°F (from 0°C to 25°C)

Water resistance	IEC 60529 IPX7
VHF wireless range	Up to 9 miles
ANT+ Low power wireless range	About 10 ft. (3 m.)

Water Resistance	Up to 10 m
------------------	------------

TT 10 Dog Collar Device Specifications

Battery Type	Rechargeable, replaceable lithium-ion
Battery Life	20 hours with a 2.5-second update rate; 40 hours with a 2-minute update rate
Operating Temperature Range	From -4°F to 140°F (from -20°C to 60°C)
Charging Temperature Range	From 32°F to 113°F (from 0°C to 45°C)
Short-Term Storage Temperature Range	From -4°F to 104°F (from -20°C to 40°C)
Long-Term Storage Temperature Range	From -4°F to 77°F (from -20°C to 25°C)

Battery Information

WARNING

This product contains a lithium-ion battery. To prevent the possibility of personal injury or product damage caused by battery exposure to extreme heat, store the device out of direct sunlight.

Do not use a sharp object to remove batteries.

CAUTION

Contact your local waste disposal department to properly recycle the batteries.

Long-Term Storage

NOTICE

The normal long-term decrease in the charging capacity of lithium-ion batteries can be accelerated by exposure to elevated temperatures. Storing fully charged devices in a location with a temperature outside the long-term storage

temperature range can significantly reduce its recharging capacity.

When you do not plan to use the handheld device for several months, the battery should be removed. Stored data is not lost when the battery is removed.

When you do not plan to use the collar for several months, the battery should be charged to about 50%. The device should be stored in a cool, dry place with temperatures are around the typical household level. After storage, the collar should be fully recharge before use.

Maximizing the Battery Life

You can do several things to extend the life of the batteries in the handheld device and collar.


- Reduce the backlight brightness (page 46).
- Reduce the backlight timeout (page 46).
- Extend the duration for the collar update rate (page 47).
- Extend the duration for your handheld update rate (page 47).

- Put the dog collar device into rescue mode (page 27).
- Use battery save mode (page 47).
- Decrease the map drawing speed (page 47).

Adjusting the Backlight Brightness

Extensive use of screen backlighting can significantly reduce battery life. You can adjust the backlight brightness to maximize the battery life.

NOTE: The backlight brightness may be limited when the battery is low.

- 1 Select .
- 2 Use the slider to adjust the backlight level.

The device may feel warm when the backlight setting is high.


Adjusting the Backlight Timeout

You can decrease the backlight timeout to maximize the battery life.

- 1 Select **Setup > Display > Backlight Timeout**.
- 2 Select an option.

Changing the Dog Collar Device Update Rate

You can select a longer duration for the update rate to conserve battery power.

- 1 Select **Dog List**.
- 2 Select a dog.
- 3 Select **Show Info** >  > **Change Update Rate**.

Changing Your Handheld Update Rate

You can select a longer duration for the update rate to conserve battery power.

- 1 Select **Setup** > **Contacts** > **Pairing Setup** > **Update Rate**.
- 2 Select a new update rate.

Turning On the Handheld Battery Save Mode

You can use battery save mode to prolong the battery life.

Select **Setup** > **Display** > **Battery Save** > **On**.

When in battery save mode, the screen shuts off when the backlight times out.

Adjusting the Map Drawing Speed

Reduce the map drawing speed to conserve battery power.

Select **Setup** > **Map** > **Map Speed** > **Normal**.

About Data Management

You can store files, such as JPEG image files, on your device. The device has a memory card slot for additional data storage.

NOTE: The device is not compatible with Windows® 95, 98, Me, Windows NT®, and Mac® OS 10.3 and earlier.

File Types

The handheld device supports the following file types:

- Files from BaseCamp. Go to www.garmin.com/trip_planning.
- JPEG photo files.
- GPX geocache files. Go to www.opencaching.com.
- GPI custom POI files from the Garmin POI Loader. Go to www.garmin.com/products/poiloader.

Installing a Memory Card

WARNING

Do not use a sharp object to remove the battery.

You can install a microSD memory card in the handheld device for additional storage or pre-loaded maps.

- 1 Turn the D-ring counter-clockwise, and pull up to remove the cover.
- 2 Remove the battery.
- 3 Slide the card holder left and lift up, as shown in the battery compartment.



- 4 Place the memory card with the gold contacts facing down.
- 5 Close the card holder.

- 6 Slide the card holder right to lock it.
- 7 Replace the battery and cover (page 2).

Connecting the Handheld Device to a Computer

NOTICE

To prevent corrosion, thoroughly dry the mini-USB port, the weather cap, and the surrounding area before charging or connecting to a computer.

- 1 Connect the USB cable to a USB port on your computer.
- 2 Pull up the weather cap from the mini-USB port.
- 3 Plug the small end of the USB cable into the mini-USB port.

Your device and memory card (optional) appear as removable drives in My Computer on Windows computers and as mounted volumes on Mac computers.

Connecting the Collar to a Computer

NOTICE

To prevent corrosion, thoroughly dry the contacts on the collar and the surrounding area before connecting the charging clip.

- 1 Connect the USB cable to a USB port on your computer.
- 2 Snap the charging clip onto the collar.
- 3 Plug the small end of the USB cable into the mini-USB port.

The collar appears as a removable drive in My Computer on Windows computers and as a mounted volume on Mac computers.

Remove the charging clip from the collar when you are done. If you do not remove the clip, it may become detached from the collar and become lost.

Deleting Files

NOTICE

If you do not know the purpose of a file, do not delete it. Your device memory

contains important system files that should not be deleted.

- 1 Open the **Garmin** drive or volume.
- 2 If necessary, open a folder or volume.
- 3 Select a file.
- 4 Press the **Delete** key on your keyboard.

Disconnecting the USB Cable

If your device is connected to your computer as a removable drive or volume, you must safely disconnect your device from your computer to avoid data loss. If your device is connected to your Windows® computer as a portable device, it is not necessary to safely disconnect.

- 1 Complete an action:
 - For Windows computers, select the **Safely Remove Hardware** icon in the system tray, and select your device.
 - For Mac® computers, drag the volume icon to the **Trash**.
- 2 Disconnect the cable from your computer.

Appendix

Accessories and Replacement Parts

Purchasing Accessories

Go to <http://buy.garmin.com>.

Optional Maps

You can use additional maps with the device, such as BirdsEye satellite imagery, BlueChart® g2, and City Navigator® detailed maps. Detailed maps may contain additional points of interest, such as restaurants or marine services. For more information, go to <http://buy.garmin.com> or contact your Garmin dealer.

About Memory Cards

You can purchase memory cards from an electronics supplier, or purchase pre-loaded Garmin mapping software (http://www.garmin.com/trip_planning). In addition to map and data storage, the memory card can be used to store files such as maps, images, geocaches, routes, waypoints, and custom POIs.

Optional Fitness Accessories

You can use optional fitness accessories including a heart rate monitor or a cadence sensor with your device. These accessories use ANT+ wireless technology to send data to the device.

Before you can use the fitness accessory with your device, you must install the accessory according to the instructions included with the accessory.

Using Optional Fitness Accessories

- 1 Bring the device within range (3 m) of the ANT+ accessory.
- 2 Select **▲** > **Setup** > **Fitness**.
- 3 Select **Heart Rate Monitor** or **Bike Cadence Sensor**.
- 4 Select **Search for New**.
- 5 Customize the data fields to view the heart rate or cadence data (xref).

Tips for Pairing ANT+ Accessories with Your Garmin Device


- Verify that the ANT+ accessory is compatible with your Garmin device.
- Before you pair the ANT+ accessory with your Garmin device, move 10 m

(32.9 feet) away from other ANT+ accessories.

- Bring the Garmin device within range 3 m (10 feet) of the ANT+ accessory.
- After you pair the first time, your Garmin device automatically recognizes the ANT+ accessory each time it is activated. This process occurs automatically when you turn on the Garmin device and only takes a few seconds when the accessories are activated and functioning correctly.
- When paired, your Garmin device receives data from only your accessory, and you can go near other accessories.

TT 10 Battery Replacement Instructions

TT 10 Components



①	Back plate
②	⏻ Power key
③	Connectors
④	Battery cover
⑤	Battery

Removing the Old Battery

Before you replace the battery, you need a small Phillips screwdriver.

- 1 Remove the six screws from the outer edges of the back plate.


- 2 Pry off the back plate.
- 3 Disconnect the four-pin and five-pin connectors.
- 4 Remove the three screws that secure the battery cover.
- 5 Remove the battery cover and the battery.

Remember the orientation of the battery. You must install the new battery the same way.

After you remove the old battery, contact your local waste disposal department to properly recycle the battery.

Installing the New Battery

Before you replace the battery, you must remove the old battery (page 51). You also need a small Phillips screwdriver. You may need a small flat screwdriver to connect the connectors.

- 1 Install the new battery with the connector on the end nearest the  Power key.
- 2 Replace the battery cover.
- 3 Replace the three small screws to secure the battery cover.

- 4 Connect the five-pin and four-pin connectors.

You may need to use a flat screwdriver to help connect the connectors.

- 5 Select the  Power key to test the connections.

When properly connected, a tone is emitted and the green LED begins to blink.

TIP: You can turn off the device before proceeding.

- 6 Make sure the gasket located inside the bottom cover is fully seated.
- 7 Replace the back plate.
- 8 Replace the six screws to secure to back plate.

After you install the new battery, charge the collar completely.

Replacing the Collar Strap

Before you replace the collar strap, you need a small Phillips screwdriver.


- 1 Remove the four screws from the back of the GPS antenna case.

- 2 Pull the collar strap out of the VHF antenna guide and the dog device.
You may need to push and pull the collar strap to properly move it through all of the loops in the case.
- 3 Thread the new collar strap through the dog device and VHF antenna guide.
- 4 Place the collar strap in between the two sides of the GPS antenna.
- 5 Replace the four screws that secure the GPS antenna case.

Replacing the VHF Antenna in the Dog Collar Device

Before you replace the VHF antenna in the collar, you need a small Phillips screwdriver.

- 1 Remove the 4 screws ① from the L-shaped cover over the VHF antenna.
- 2 Pry off the L-shaped cover.



- 3 Remove the screw ② securing the VHF antenna to the back plate.
- 4 Pull the length of the antenna from the antenna guide to remove the old antenna.
- 5 Loop the antenna guide around the collar strap, and thread the new VHF antenna through the guide.
This helps to point the antenna up.
- 6 Replace the screw securing the VHF antenna to the back plate.
- 7 Replace the L-shaped cover over the VHF antenna.
- 8 Replace the 4 screws on the L-shaped cover.

Changing the Fuse in the Vehicle Power Cable

NOTICE

When replacing the fuse, do not lose any of the small pieces and make sure they are put back in the proper position. The vehicle power cable does not work unless it is assembled correctly.

If your device does not charge in your vehicle, you may need to replace the fuse located at the tip of the vehicle adapter.

- 1 Unscrew the end piece ①.



TIP: You may need to use a coin to remove the end piece.

- 2 Remove the end piece, the silver tip ②, and the fuse ③.
- 3 Install a 2 A fast-blow fuse.
- 4 Place the silver tip in the end piece.
- 5 Screw the end piece back into the vehicle power cable ④.

Data Field Options

Accuracy of GPS: The margin of error for your exact location. For example, your GPS location is accurate to within +/- 12 feet (3.65 m).

Ambient Pressure: The uncalibrated environmental pressure.

Ascent - Average: The average vertical distance of ascent since the last reset.

Ascent - Maximum: The maximum rate of ascent in feet per minute or meters per minute since the last reset.

Ascent - Total: The total elevation distance ascended since the last reset.

Barometer: The calibrated current pressure.

Battery Level: The remaining battery power.

Bearing: The direction from your current location to a destination. You must be navigating for this data to appear.

Cadence: Revolutions of the crank arm or strides per minute. Your device must be connected to a cadence accessory.

Course: The direction from your starting location to a destination. Course can be viewed as a planned or set route. You must be navigating for this data to appear.

Depth: The depth of the water. Your device must be connected to a NMEA 0183 device capable of acquiring the water depth.

Descent - Average: The average vertical distance of descent since the last reset.

Descent - Maximum: The maximum rate of descent in feet per minute or meters per minute since the last reset.

Descent - Total: The total elevation distance descended since the last reset.

Distance to Destination: The remaining distance to the final destination. You must be navigating for this data to appear.

Distance to Next: The remaining distance to the next waypoint on the route. You must be navigating for this data to appear.

Elevation: The altitude of your current location above or below sea level.

Elevation - Maximum: The highest elevation reached since the last reset.

Elevation - Minimum: The lowest elevation reached since the last reset.

ETA at Destination: The estimated time of day you will reach the final destination (adjusted to the local time of the destination). You must be navigating for this data to appear.

ETA at Next: The estimated time of day you will reach the next waypoint on the route (adjusted to the local time of the waypoint). You must be navigating for this data to appear.

Glide Ratio: The ratio of horizontal distance traveled to the change in vertical distance.

Glide Ratio to Dest: The glide ratio required to descend from your current position to the destination elevation. You must be navigating for this data to appear.

GPS Signal Strength: The strength of the GPS satellite signal.

Heading: The direction you are moving.

Heart Rate: Your heart rate in beats per minute (bpm). Your device must be connected to a compatible heart rate monitor.

Location (lat/lon): Displays the current position in the default position format regardless of the selected settings.

Location (selected): Displays the current position in the selected position format.

Odometer: A running tally of distance traveled for all trips. This total does not clear when resetting the trip data.

Off Course: The distance to the left or right by which you have strayed from the original path of travel. You must be navigating for this data to appear.

Pointer: An arrow points in the direction of the next waypoint or turn. You must be navigating for this data to appear.

Speed: The current rate of travel.

Speed Limit: The reported speed limit for the road. Not available in all maps and in all areas. Always rely on posted road signs for actual speed limits.

Speed - Maximum: The highest speed reached since the last reset.

Speed - Moving Avg.: The average speed while moving since the last reset.

Speed - Overall Avg.: The average speed while moving and stopped since the last reset.

Sunrise: The time of sunrise based on your GPS position.

Sunset: The time of sunset based on your GPS position.

Temperature - Water: The temperature of the water. Your device must be connected to a NMEA 0183 device capable of acquiring the water temperature.

Time of Day: The current time of day based on your current location and time settings (format, time zone, daylight saving time).

Time to Destination: The estimated time remaining before you reach the destination. You must be navigating for this data to appear.

Time to Next: The estimated time remaining before you reach the next waypoint in the route. You must be navigating for this data to appear.

To Course: The direction in which you must move to get back on the route. You must be navigating for this data to appear.

Trip Odometer: A running tally of the distance traveled since the last reset.

Trip Time - Moving : A running tally of the time spent moving since the last reset.

Trip Time - Stopped: A running tally of the time spent not moving since the last reset.

Trip Time - Total: A running tally of the total time spent moving and not moving since the last reset.

Turn: The angle of difference (in degrees) between the bearing to your destination and your current course. L means turn left. R means turn right. You must be navigating for this data to appear.

Velocity Made Good: The speed at which you are closing on a destination along a route. You must be navigating for this data to appear.

Vertical Speed: The rate of ascent or descent over time.

Vertical Speed to Dest: The rate of ascent or descent to a predetermined altitude. You must be navigating for this data to appear.

Waypoint at Dest: The last point on the route to the destination. You must be navigating for this data to appear.

Waypoint at Next: The next point on the route. You must be navigating for this data to appear.

Index

A

- accessories 2, 50
- alarm, proximity 36
- alarms
 - clock 36
 - marine 43
 - tones 40
- alerts
 - dog 10
 - location 15, 16
- altimeter, calibrating 35
- area calculation 36

B

- backlight 39, 46, 47
- BaseCamp 14, 38
- battery
 - charging 3
 - installing 2
 - life 40
 - maximize 47
 - maximizing 39, 46, 47
 - replacing 51, 52
 - saving 27, 47
 - storage 45
- beacon 26
- bearing pointer 33

C

- calendar 36

- calibrating
 - altimeter 35
 - screen 39
- charging
 - collar 4
 - handheld 3
- cleaning the device 44
- collar
 - battery replacement 51, 52
 - charging 4
 - contact points 2, 17
 - replacing strap 52
 - VHF antenna 2
- collar light 26
- compass
 - calibrating 33
 - navigating 33
 - settings 42
- computer, connecting 48, 49
- contact
 - adding 23, 24
 - ID 25
 - navigating to 25
 - settings 39
 - update rate 47
 - viewing on map 25
- contact points 17
- course, pointer 33
- covey, marking 26

D

- data, sharing 32
- data fields 38
- deleting, all user data 49
- device
 - care 44
 - registration 2
- dog
 - adding 6–8
 - alerts 10
 - collar 27
 - ID 8, 9
 - information 9
 - navigating to 14
 - settings 38
 - statistics 9
 - track and train codes 7, 8
 - tracking 12–15
 - tracks 9
 - training 17, 18
 - training basics 16, 18–20, 22, 23
 - training intensity levels 21, 22
 - type 9
 - update rate 47

E

- elevation, plot 34, 35

F

- fuse, changing 54

G

geofences 15, 16
GPS, settings 38

H

hunter. See contact

I

icons 13

K

keys, training 17, 18

L

line-of-sight radio
communication 11

M

main menu, customizing 37

maps

- data fields 38
- navigating 32
- optional 50
- orientation 32, 40
- settings 40, 42, 43, 47
- zoom 40

marine, alarms setup 43

memory card 1, 48, 50

messages 24

microSD. See memory card

microSD card. See memory
card

N

navigation, altimeter 35

O

on-screen buttons 5

P

pausing dog tracking 15

power cables, changing the
fuse 54

power key 1, 2

product registration 2

profiles 5, 6

proximity alarm 36

R

radio communication 11

registering the device 2

replacement parts 50–53

rescue mode 27

routes

- creating 29

- deleting 30

- editing 29

- navigating 29

- settings 41

S

satellite signals, acquiring 5
screen

- cleaning 44

- locking, screen 5

- settings 39

settings 38–43

sharing data 32

Sight N' Go 34

software, updating 44

specifications 44, 45

stopwatch 37

T

time settings 42

tones 40

TracBack 31

tracks, settings 38, 39, 41

trip computer, resetting 35

trip information

- resetting information 35

- viewing 35

trip planner. See routes

troubleshooting 2

U

units of measure 41

updates, software 44

USB

- connector 1

- disconnecting 49

- mass storage mode 47

- transferring 47

user data, deleting 49

V

VHF antenna 1, 53

W
waypoints

deleting 28
editing 27, 28

projecting 28
saving 26, 27

DRAFT

DRAFT

DRAFT

DRAFT

www.garmin.com/support



913-397-8200
1-800-800-1020



0808 2380000
+44 870 850 1242



1-866-429-9296



43 (0) 3133 3181 0



00 32 2 672 52 54



00 45 4810 5050



00 358 9 6937 9758



00 331 55 69 33 99



0180 5 / 42 76 46 - 880



00 39 02 3669 9699



0800-0233937



815 69 555



00800 4412 454
+44 2380 662 915



00 35 1214 447 460



00 34 902 007 097



00 46 7744 52020

Garmin International, Inc.
1200 East 151st Street
Olathe, Kansas 66062, USA

Garmin (Europe) Ltd.
Liberty House, Hounsdown Business Park
Southampton, Hampshire, SO40 9LR UK

Garmin Corporation
No. 68, Zangshu 2nd Road, Xizhi Dist.
New Taipei City, 221, Taiwan (R.O.C.)



© 2012 Garmin Ltd. or its subsidiaries