




Quick-start guide  
Guide de  
démarriage rapide

**2.4GHz Cordless Mouse & Transceiver  
M-R0011 & C-U0006**



## Srpski

### Pointer does not move at all?

1. Make sure the power slider is in the **ON** position.
2. Ensure that the battery polarity is correct. Check battery power by turning the mouse OFF and then ON. If the battery indicator light glows red or does not glow at all, replace the batteries.
3. Try plugging the Unifying receiver into a different USB port.
4. Try reconnecting the mouse and Unifying receiver using the Logitech Unifying software (refer to the Unifying section of this guide).

### Erratic pointer movement or missed button clicks?

1. Remove metallic objects between the mouse and Unifying receiver.
2. If the Unifying receiver is plugged into a USB hub, try plugging it directly into your computer.
3. Move the Unifying receiver to a USB port closer to the mouse, or go to [www.logitech.com/usbextender](http://www.logitech.com/usbextender) for a USB extension stand that will allow the Unifying receiver to be placed closer to the mouse.

If these tips fail, contact Logitech Customer Support at [www.logitech.com/support](http://www.logitech.com/support), or call using the phone numbers listed in this guide.

## Română

### Pointer does not move at all?

1. Make sure the power slider is in the **ON** position.
2. Ensure that the battery polarity is correct. Check battery power by turning the mouse OFF and then ON. If the battery indicator light glows red or does not glow at all, replace the batteries.
3. Try plugging the Unifying receiver into a different USB port.
4. Try reconnecting the mouse and Unifying receiver using the Logitech Unifying software (refer to the Unifying section of this guide).

### Erratic pointer movement or missed button clicks?

1. Remove metallic objects between the mouse and Unifying receiver.
2. If the Unifying receiver is plugged into a USB hub, try plugging it directly into your computer.
3. Move the Unifying receiver to a USB port closer to the mouse, or go to [www.logitech.com/usbextender](http://www.logitech.com/usbextender) for a USB extension stand that will allow the Unifying receiver to be placed closer to the mouse.

If these tips fail, contact Logitech Customer Support at [www.logitech.com/support](http://www.logitech.com/support), or call using the phone numbers listed in this guide.

## Slovenščina

### Pointer does not move at all?

1. Make sure the power slider is in the **ON** position.
2. Ensure that the battery polarity is correct. Check battery power by turning the mouse OFF and then ON. If the battery indicator light glows red or does not glow at all, replace the batteries.
3. Try plugging the Unifying receiver into a different USB port.
4. Try reconnecting the mouse and Unifying receiver using the Logitech Unifying software (refer to the Unifying section of this guide).

### Erratic pointer movement or missed button clicks?

1. Remove metallic objects between the mouse and Unifying receiver.
2. If the Unifying receiver is plugged into a USB hub, try plugging it directly into your computer.
3. Move the Unifying receiver to a USB port closer to the mouse, or go to [www.logitech.com/usbextender](http://www.logitech.com/usbextender) for a USB extension stand that will allow the Unifying receiver to be placed closer to the mouse.

If these tips fail, contact Logitech Customer Support at [www.logitech.com/support](http://www.logitech.com/support), or call using the phone numbers listed in this guide.

## Hrvatski


### Pointer does not move at all?

1. Make sure the power slider is in the **ON** position.
2. Ensure that the battery polarity is correct. Check battery power by turning the mouse OFF and then ON. If the battery indicator light glows red or does not glow at all, replace the batteries.
3. Try plugging the Unifying receiver into a different USB port.
4. Try reconnecting the mouse and Unifying receiver using the Logitech Unifying software (refer to the Unifying section of this guide).

### Erratic pointer movement or missed button clicks?

1. Remove metallic objects between the mouse and Unifying receiver.
2. If the Unifying receiver is plugged into a USB hub, try plugging it directly into your computer.
3. Move the Unifying receiver to a USB port closer to the mouse, or go to [www.logitech.com/usbextender](http://www.logitech.com/usbextender) for a USB extension stand that will allow the Unifying receiver to be placed closer to the mouse.

If these tips fail, contact Logitech Customer Support at [www.logitech.com/support](http://www.logitech.com/support), or call using the phone numbers listed in this guide.



**Plug it. Forget it. Add to it.**  
You've got a Logitech® Unifying receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse.

It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\*PC: go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
MAC: go to Applications / Utilities / Logitech Unifying Software

## Deutsch

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
Mac: Go to Applications / Utilities / Logitech Unifying Software

## Français

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
Mac: Go to Applications / Utilities / Logitech Unifying Software

## По-русски

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
Mac: Go to Applications / Utilities / Logitech Unifying Software

## Magyar

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
Mac: Go to Applications / Utilities / Logitech Unifying Software

## Slovenčina

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
Mac: Go to Applications / Utilities / Logitech Unifying Software

## Български

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
Mac: Go to Applications / Utilities / Logitech Unifying Software

## Srpski

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
Mac: Go to Applications / Utilities / Logitech Unifying Software

## Slovenščina

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
Mac: Go to Applications / Utilities / Logitech Unifying Software

## Eesti

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

\* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software  
Mac: Go to Applications / Utilities / Logitech Unifying Software

## Italiano

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

- \* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software
- Mac: Go to Applications / Utilities / Logitech Unifying Software

## Česká verze

### Plug it. Forget it. Add to it.

You've got a Logitech® Unifying Receiver. Now add a compatible wireless keyboard that uses the same receiver as your mouse. It's easy. Just start the Logitech® Unifying software\* and follow the onscreen instructions.

- \* PC: Go to Start / All Programs / Logitech / Unifying / Logitech Unifying Software
- Mac: Go to Applications / Utilities / Logitech Unifying Software

#### Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### Industry Canada Statement

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device

申請NCC使用手冊必須包含之資訊:

經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前項合法通信，指依電信法規定作業之無線電通信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。