

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T9580		Test voltage: 4.2Vdc	
A. PCB LEVEL (Test Condition: under CH15)			
NO	ITEM	ALIGNMENT METHOD	REMARK
1.	LCD display (Should enter test mode)	1. Press and hold the '+' key and 'Menu' key together. 2. Turn on the radio power until a good key chirp is heard, and the backlight is on for about 500 ms . finally, the LCD should be display '1 ^{CH} '. 3. Press 'DOWN' key , then all LCD segments should be anticlockwise displayed. 4. Finally, all the LCD segments should be shown for about 500ms as follows: 18⁸⁸ .	
2.	Standby current	1. Set A-METER, and RX mode. 2. Check the standby current <45mA.	
3.	Talk on current	1. Set A-METER, and TX mode @50ohm load. 2. Check the TX current <1300mA@4.2Vdc. 3. Set channel to 14. 4. Check the TX current <600mA@4.2Vdc.	
4.	VCO	1. Set RX or TX mode 2. Check TP103 to provide 0.6 ~ 2.0VDC. 3. Adjust L603 to provide 1.8 ± 0.1Vdc at TP103 if VCO level are more than 2.0Vdc on CH14. 4. Press "+" key to enter weather mode. Check Weather receiver VCO voltage should be within 0.6~2.2V	
5.	TX Power	1. Set TX mode CH15. 2. Check transmit power to provide 0.75W ERP 3. Set TX mode channel 14. 4. Adjust VR 1 to provide 0.29W ERP.	Test voltage is 4.5V DC.
6.	CTCSS Tone Frequency	1.set CH1/CODE1. 2.Set Tx mode. 3.Check the code signal should be within 66.8Hz to 67.2Hz.	FILTER SET: 1. 20Hz~300Hz
7.	TX Frequency	Adjust C159 to provide 462.5625MHz +300Hz (± 50Hz).	
8.	CTCSS Tone Dev.	1. Set CH1/CODE1、 AF input level to off, check DEV to be 350Hz~ 600Hz. 2. Set CH14/CODE38、 AF input level to off, check DEV to be 350Hz~ 600Hz.	FILTER SET: 1. 20Hz~300Hz 2. 750µs De-emp ON 3. PK+/- Max 4. FM DEV. AVG ON
9.	CDCSS TX	1. Set TX mode 2. Set CH15/CODE121 3. Check the detector (HP8920B with decoder) display 754 Octal Code 4. Set CH15/CODE39, check Octal Code to be 023	FILTER SET: 1. 20Hz~300Hz 2. 750µs De-emp ON 3. PK+/- Max 4. Input Level: 0.6KHz
10.	TX Modulation & distortion	1.Set AF level at 50mV;1KHz,Adjust VR101 to provide Max TX deviation 2.1KHz to 2.2KHz. 2. Check the max deviation with code1(or code38), it should be ≤2.5KHz 3. Without code. check input Mic level (TP116) in 3~15 mV to provide normal deviation 1.5KHz. 4.Check the demodulation distortion <5% 5. Audio Frequency Response. a) Input a 2.0mV 1KHz audio frequency to TP116 and press 'PTT' switch. b) Check the response compare to 1KHz tone. i) 500Hz : -9.0 dB to -3.0 dB. ii) 2.5KHz : 3.0 dB to +9.0 dB .	Item1, 2, 3&5 set : 1. HPF 50Hz 2. LPF 15KHz 3. PK+/- Max 4. 2.750µs De-emp ON Item 4 set: 1. HPF 300Hz 2. LPF 3KHz 3. PK+/- Max 4. 2.750µs De-emp ON

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT. LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE,MAINTENANCE AND USE OF THE GIANT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT LTD. ALL RIGHTS RESERVED.

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T9580			
A. PCB LEVEL (Test Condition: under CH15)			
NO	ITEM	ALIGNMENT METHOD	REMARK
11.	VOX Detector	Input and test 1KHz AF signal at TP116. 1. Set VOX level at 1. Unit start to transmit : 10mV~16mV Unit stop transmit: 8mV~12mV 2. Set VOX level at 2. Unit start to transmit : 6mV~10mV Unit stop transmit : 5mV~10mV 3. Set VOX level at 3. Unit start to transmit : 3mV~6mV Unit stop transmit : 2mV~5mV	
12.	Rx Audio test	1. Set RX mode CH7. 2. Set SG RF level to -50dBm with 1.5KHz deviation 1KHz modulation Signal. 3. Rotate the volume switch to the position, which give a Max audio output at TP117. 4. Check Max audio output level >1300mVrms. 5. Check Rx current <250mA. 6. Check the 1KHz distortion <= 5%. 7. Set SG RF level to -118dBm with 1.5kHz deviation at 1KHz audio frequency. a). Check SINAD sensitivity <= -118dBm. @12dB SINAD at TP117. 8. Audio frequency response. a) Set SG RF level to -50dBm with 1.5kHz deviation at 1KHz audio frequency. b) Rotate the volume switch to the position, which give an output 300mV±5mV at TP117. c) Vary the audio frequency from 300Hz to 3KHz. d) Check the RX response compare to 1KHz tone. i) 500Hz : 2.0 dB to 8.0 dB. ii) 2.5KHz : -23.0 dB to -17.0 dB. 9. Maximum and Minimum Audio Output Power. a) Set SG RF level to -50dBm with 1.5kHz deviation at 1KHz audio frequency. b) Rotate the volume switch to the position, which give a maximum output . c) Check the voltage at TP117 >1300mVrms. d) Set maximum audio output to 0dB, rotate the volume switch to the position, which give a minimum output. e) Check the minimum voltage -23dB to -40dB at TP117	
13.	Weather/S.A.M.E Receiver sensitivity	1. Set SG RF level to -50dBm with 3.0KHz deviation 1KHz modulation Signal and the frequency is 162.55MHz. 2. Press “+” key until the unit enter weather mode. Rotate the volume switch to the position, which give out 700mVrms output at TP117 3. Check the 1KHz distortion <= 10%. 4. Check 12dBSINAD sensitivity <= -118dBm. 5. Turn on S.A.M.E mode, RF SG level set to -113dBm with 4KHz external S.A.M.E modulation. Check the unit display the correct S.A.M.E message	

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT. LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT LTD. ALL RIGHTS RESERVED.

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T9580			
A. PCB LEVEL (Test Condition: under CH15)			
NO	ITEM	ALIGNMENT METHOD	REMARK
14.	Weather/S.A.M.E Auto Detection	1. Set SG RF frequency is 162.55MHz with 3.0KHz deviation 1050Hz modulation Signal, RF level set to -47dBm and turn off. 2. Setting weather mode is “on”, Push “+” key, the unit will return to “two-way radio”mode. 3. Turn on the SG RF level , check the unit will auto-enter “weather receiver”mode and there’s 1050KHz AF signal output at TP117. 4. Turn off SG RF level and change to ext modulation with S.A.M.E signal generator, the deviation set to 4KHz 5. Turn on the “S.A.M.E” mode then push “+” key to return two-way radio mode. Turn on RF SG and S.A.M.E signal generator, Check the unit will auto-enter “S.A.M.E” mode and the unit display a correct S.A.M.E message.	
15.	Noise- Detector	1. Push “+”key to return “two way radios” mode 2. Set SG to -120dBm with 1.5KHz deviation., 1KHz AF on CH7. 3. Adjust VR502 for transient state @ 8dB SINAD. 4. Check high state @ 6 to 14dB SINAD.	
16.	CTCSS tone Detect	1. Set CH15/CODE1and SG to -120dBm with Modul1: 67Hz tone / 300Hz deviation. Modul2: 1KHz tone / 1.5KHz deviation 2. Check the unit can switch on speaker and heard 1KHz sound. 3. Repeat item 1 and 2 for code38(250.3Hz). 4. Repeat item 1 to 3 for CH14.	
17.	Quiet tone det	1.Set unit to quiet tone ON mode. 2.Set CH15 and SG to -60dBm with 1KHz frequency, 500Hz deviation and 55Hz tone,400Hz DEV. 5. Check 1KHz signal will appear on TP 117.	
18.	CDCSS Tone Detect	1. Set CH15/CODE121 and SG to -60dBm with 1KHz/1.5K Dev, 754 Octal encoder/400Hz Dev. 2. Check the speaker output (1KHz signal) should be continued . 3. Repeat item 1 and 2 for code39(023 Octal Code). 4. Repeat item 1 ~ 3 for CH14.	
19.	Normal Batter level Detect	1. Battery level : 2. level 1: 3.90+/-0.15V, 3. level 2: 3.55+/-0.15V, 4. level 3: 3.25+/-0.15V, 5. power off: 3.20+/-0.15V, 6. Power on: 3.25+/-0.15V.	
20.	SCAN	1. Set SG RF 467.5875MHz / -50dBm with 500Hz deviation, 100Hz modulation. 2. Press "Mon" key. 3. Unit shows channels 9 and code 13.	
21.	Battery charging current	1. Switch to charger unit ,check the battery and the unit charging current @3.6V battery:(coordinate 100 Ohm load) 2. Adaptor input voltage 120V: 45±8mA. 3. Adaptor input voltage 108V: 40±8mA. 4. Adaptor input voltage 132V: 50±8mA.	

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT. LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT LTD. ALL RIGHTS RESERVED.

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T9580			
B. CASING LEVEL			
NO	ITEM	ALIGNMENT METHOD	REMARK
1.	Current Consumption	1. Set A-METER. With volume switch OFF, check the OFF current <100 μ A. 2. With volume switch ON, check the standby current <45mA. 3. Press 'PTT' switches and check the TX current <1300mA @ Ch15 and <600mA @Ch14.	Battery Voltage” 4.2Vdc
2.	TX Frequency	TE Check: 1. Check CH1=462.5625MHz+ (-200Hz ~ +500Hz); Remark: QA approved spec is 1. Check CH14 =467.7125MHz+ (-300Hz ~ +600Hz).	
3.	Noise- Detector	1. Set the distance between antennas of SG and checked unit to 0.3M ~ 0.5M . 2. The antennas of SG and checked unit should be parallel to make the electromagnetic field of SG . 3. radiate equably to the antenna of checked unit . 4. Set SG to -90dBm with 1.5KHz deviation, 1KHz tone on CH7 . 5. Adjust VR502 for HIGH state : 6~14dB SINAD .	When adjusting Noise-Det. , Should reduce any interference from other Instruments and body.
4.	Weather and S.A.M.E Auto-detection	1. Switch off RF SG with weather frequency 162.55MHz /level -50dBm and AF 1050Hz/Dev 3Khz modulation. 2. Press “+”key until the unit enter weather/S.A.M.E mode. 3. Turn on weather mode and off S.A.M.E mode, press”+” key to return to two-way radio mode. 4. Turn on RF SG, Check the unit auto-enter weather mode and you can hear 1050Hz sound from the speaker. 5. Switch off RF SG, and use 4KHz deviation external S.A.M.E modulation 6. Switch off weather mode and on S.A.M.E mode, press”+” key to return to two-way radio mode. 7. Turn on RF SG, Check the unit auto-enter S.A.M.E mode and the unit will display the correct S.A.M.E message.	

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT. LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT LTD. ALL RIGHTS RESERVED.

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T9580			
B. CASING LEVEL			
NO	ITEM	ALIGNMENT METHOD	REMARK
4.	Audio RX Path CH7	<div>1. Set SG RF level to -50dBm with 1.5kHz Dev.;1kHz AF , Rotate the volume switch to the position, which give an Max output.</div> <div>2. Check speaker O/P level >85dBspL (30cm distance).</div> <div>3. Set SG RF level to -60dBm with 1.5kHz Dev.;1kHz AF.</div> <div>4. Plug the dummy speaker and dummy microphone into audio jet.</div> <div>5. Rotate the volume switch to the position, which give an output 700+/-50mv.</div> <div>6. Set SG RF level to -90dBm with 1.5kHz Dev.;1kHz AF.</div> <div>7. Check the radiated sensitivity correlate to the golden sample.</div> <div>8. Audio frequency response.</div> <div> a) Set SG RF level to -60dBm with 1.5kHz deviation at 1KHz audio frequency.</div> <div> b) Rotate the volume switch to the position, which give an output 300mV ±5mV (voltage difference of dummy speaker).</div> <div> c) Vary the audio frequency from 300Hz to 3KHz.</div> <div> d) Check the RX response compare to 1KHz tone.</div> <div> i. 500Hz : 2.0 dB to 8.0 dB.</div> <div> ii. 2.5KHz : -23.0 dB to -17.0 dB.</div> <div>9. Maximum and Minimum Audio Output Power.</div> <div> a) Set SG RF level to -60dBm with 1.5kHz deviation at 1KHz audio frequency.</div> <div> b) Rotate the volume switch to the position, which give a maximum output with distortion <5%.</div> <div> c) Check the voltage difference of dummy speaker >/=900mV.</div> <div> d) Set maximum audio output to 0dB, rotate the volume switch to the position, which give a minimum output.</div> <div> e) Check the voltage difference between of dummy speaker -23dB to -40dB.</div>	
5.	Audio TX Path CH15	<div>1. Check the radiated power correlate to golden sample.</div> <div>2. Plug the dummy speaker and dummy microphone into audio jet.</div> <div>3. Standard TX Deviation.</div> <div> a) Input mic level to dummy microphone and press ‘PTT’ switch.</div> <div> b) Check max. Dev. 2.0KHz < max. Dev. < 2.5KHz.</div> <div> c) Check input level in 3~15mV to provide normal deviation 1.5KHz.</div> <div>4. Audio Frequency Response.</div> <div> a) Input a 2.0mv@1KHz audio frequency to dummy microphone and press ‘PTT’ switch.</div> <div> b) Check the response.</div> <div> 500Hz : -9.0 dB to -3.0 dB.</div> <div> 2.5KHz : 3.0 dB to +9.0 dB .</div> <div>5. Repeat CH14.</div>	<div>Fliter set :</div> <div>1.HPF 50Hz</div> <div>2.LPF 15HHz</div> <div>3. PK +/- Max</div>

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT. LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE, MAINTENANCE AND USE OF THE GIANT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT LTD. ALL RIGHTS RESERVED.

GIANT ELECTRONICS LTD.			
Title: Alignment Procedure			
Model: T9580			
B. CASING LEVEL			
NO	ITEM	ALIGNMENT METHOD	REMARK
6.	Function check and Intercom function (between sample and production unit)	<div>1. Turn on the radio power , the back-light should be on For a while and a good key chirp should be heard at the same time.</div> <div>2. The LCD display should be clear , not miss the segment when pressing ‘+’ and ‘-’ or ‘-’ key , the key tone should also be heard clearly.</div> <div>3. Set channel of the sample and production unit CH=11.</div> <div>4. Press ‘PTT’ switch to intercom between sample and Production unit , the LED should be light.</div> <div>5. The sound quality between both should be clear and no metal sound .</div> <div>6. Press ‘CALL’ key , the call tone should be heard clearly each other .</div> <div>7. Change channel of the unit to CH=12 , then Press ‘PTT’ switch of sample.</div> <div>8. Any noise should not be heard from the speaker of Production unit.</div> <div>9. Press any key , the dead problem should not occur .</div> <div>10. Set CH1/code5,SG to be CH1/code4 and code6,check the speaker mute.</div> <div>11. Set CH1/code37,SG to be CH1/code36 and code38, check the speaker mute.</div> <div>12. Repeat item 10 and 11 for CH14.</div> <div>13. Push ‘PTT’ Key and then turn on the radio, check the Ivox function.</div>	

* Remark:

TX mode : Press and hold PTT button

RX mode : Release PTT button

Power supply: Min DC 3.2v;Normal DC3.6v; Max DC4.5v

附录：SAME 信息的显示

THE CONTENT OF THIS DOCUMENT IS GIANT ELCT. LTD. INTELLECTUAL PROPERTY AND IS THE PROPERTY OF GIANT, IT IS TO BE TREATED AS STRICTLY AND IS NOT BE DISCLOSED, REPRODUCED, OR USED EXCEPT AS AUTHORIZED IN WRITING BY GIANT ELECTRONIC LTD. IN CONNECTION WITH THE MANUFACTURE,MAINTENANCE AND USE OF THE GIANT WHICH IT PERTAINS. COPYRIGHT @GIANT ELECT LTD. ALL RIGHTS RESERVED.