



SONY.

3-xxx-xxx-11 (1)

Portable PCS Telephone

Operating Instructions

CM-Z100SPR

©1997 Sony Electronics Incorporated

Before operating the CM-Z100SPR portable telephone, please read this manual thoroughly and retain it for future reference.

If your usage includes in-vehicle operation, it is recommended that you refer to the Installation/Connections/Operation manual for the optional accessory kits.

DISPOSAL OF LITHIUM ION BATTERY

LITHIUM ION BATTERY.
DISPOSE OF PROPERLY.

You can return your unwanted lithium ion batteries to your nearest Sony Service Center or Factory Service Center.

Note: In some areas the disposal of lithium ion batteries in household or business trash may be prohibited.

For the Sony Service Center nearest you call 1-800-222-SONY (United States only).
For the Sony Factory Service Center nearest you call 416-499-SONY (Canada only).

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

FCC CAUTION STATEMENT

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

Owner's record

The model number, regulatory number, and serial number are located on a nameplate inside the battery compartment. Record the serial number in the space provided below. Refer to these numbers whenever you call your dealer regarding this product.

Model No.: CM-Z100SPR

Serial No.: _____



"Digital by QUALCOMM" is a registered trademark of QUALCOMM Incorporated.

Rules and regulations

The U.S. Federal Communications Commission and the Industry Canada regulate PCS telephone service in their respective countries. It is important for you, the PCS telephone user, to observe the applicable regulations when operating your PCS telephone in either country. In addition to these U.S. and Canadian federal regulations, you may be bound also by certain state, provincial, territorial, and local rules and regulations, as well as by your PCS carrier's tariff (the rates, terms, and conditions of its service). If you wish to use your PCS telephone in both the U.S. and Canada, please consult with your System Operator.

Furthermore, you should remember that your PCS telephone is a *radiotelephone*, — i.e., it combines both wireline technology, as used in your home or office telephone system, and radio technology — and that the scope of regulations and precautions is therefore broader than the scope of regulations and precautions relating to wireline-only telephone usage.

Some of the major points of consideration are set out below. Please note, however, that these "Rules and Regulations" and "Safety Precautions" sections do not constitute legal advice; and are intended merely for general information purposes. If you have any specific questions, please contact your PCS carrier (System Operator).

License — If your home system is in the U.S., you do not require a separate license to operate your PCS telephone; obtaining a PCS telephone access number is sufficient to register you as a user. If your home system is in Canada, a separate license is required; your carrier will assist you in the licensing

process. If you wish to use your PCS telephone on both sides of the border, please contact your PCS carrier (System Operator).

Equipment modifications — The U.S. Federal Communications Commission has type-approved the model of PCS telephone which you have purchased, and has allocated a specific frequency range for PCS service. No changes or adjustments are to be made to your PCS telephone.

The radio equipment shall be made available for inspection upon request by representatives of the FCC or licensees.

Denial of service — A PCS carrier may deny service temporarily or terminate service for violation of any government regulations or violation of its tariff.

Privacy — As a telephone user, you have come to assume a certain standard of privacy when you place or receive a telephone call via the traditional wireline systems. However, because PCS telephones utilize radio transmissions to effect calls, the same standard cannot always be assured. While it is unlawful for any unauthorized person to divulge or use any information obtained from intercepting or "listening in on" conversations intended for others, you should not assume that your conversation is completely secure. Commercially available scanning equipment can permit a third party to monitor the radio channels used for PCS telephone calls.

Interference — No person shall interfere with, or cause interference to, any radio communication or signal.

Safety precautions

IMPORTANT

For safe and efficient operation of your phone, observe these guidelines. Your hand-held portable PCS telephone uses digital Code Division Multiple Access (CDMA) technology. CDMA is a newer radio frequency (RF) technology than the FM technology that has been used for radio communications for decades.

Your portable PCS telephone is a radio transmitter and receiver. When the phone is ON, it receives and sends out radio frequency (RF) energy. The phone operates in the frequency range of 1851 MHz to 1989 MHz. When you use your phone, the PCS system handling your call controls the mode of operation and the power level at which your phone transmits. The power is transmitted as a digitally coded waveform at a rate varying from 100 Hz to 800 Hz. The average power can range from about 0.01 μ W to about 300 mW.

Exposure to radio frequency energy

Research on health effects from RF energy has focused for many years on FM radio technology. That research and studies regarding newer radio technologies, such as CDMA, have found no credible scientific evidence that adverse health effects result from the use of PCS telephones.

The Institute of Electrical and Electronics Engineers (IEEE) in 1991, and The American National Standards Institute (ANSI) in 1992, updated the 1982 ANSI Standard for safety levels with respect to human exposure to RF energy. Over 120 scientists, engineers,

and physicians from universities, government health agencies, and industry, reviewed the available research and developed this updated Standard. In March 1993, the U.S. Federal Communications Commission (FCC) proposed the adoption of this updated Standard.

The design of your phone complies with this updated Standard. Of course, if you want to limit RF exposure even further than the updated ANSI Standard, you may choose to control the duration of your calls and operate your phone in the most power efficient manner.

Efficient phone operation

For your phone to operate at the lowest power level consistent with satisfactory call quality, please observe the following guidelines:

Your phone has an extendable antenna; extend it fully whenever possible for maximum efficiency.

Hold the phone as you would any other telephone. While speaking directly into the mouthpiece, position the antenna up and over your shoulder.

Do not hold the antenna when the phone is in use. Holding the antenna affects call quality and may cause the phone to operate at a higher power level than needed.

Antenna care and replacement

Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Replace a damaged antenna immediately. Take your phone to an authorized service center for repair.

Use only the supplied or approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the phone, and violate FCC regulations.

Driving

Check the laws and regulations on the use of PCS telephones in the areas where you drive. Always obey them. Also, when using your phone while driving, please:

- pay full attention to driving;
- use hands-free operation, if available;
- pull off the road and park before making or answering a call, if driving conditions so require.

Electronic devices

Most modern electronic equipment is shielded from RF energy. However, RF energy from PCS telephones may affect some electronic equipment.

RF energy may affect improperly installed or inadequately shielded electronic operating and entertainment systems in motor vehicles. Check with the manufacturer or its representative to determine if these systems are adequately shielded from external RF energy. You should also check with the manufacturer of any equipment that has been added to your vehicle.

Medical devices

Consult the manufacturer of any personal medical devices (such as pacemakers, hearing aids, etc.) to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Turn your phone OFF in health care facilities when regulations posted in the areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Aircraft

Turn your phone OFF before boarding any aircraft.

- Use it on the ground only with crew permission.
- Do not use in the air.

To prevent possible interference with aircraft systems, U.S. Federal Aviation Administration (FAA) regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent interference with PCS systems, FCC regulations prohibit using your phone while the plane is in the air.

Children

Do not allow children to play with your phone. It is not a toy. Children could hurt themselves or others (by poking themselves or others in the eye with the antenna, for example). Children also could damage the phone or make calls that increase your telephone bills.

Blasting areas

To avoid interfering with blasting operations, turn your unit OFF when in a "blasting area" or in areas posted: "Turn off two-way radio." Construction crews often use remote control RF devices to set off explosives.

Potentially explosive atmospheres

Turn your phone OFF when in any area with a potentially explosive atmosphere. It is rare, but your phone or its accessories could generate sparks. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always, clearly marked. They include fueling areas such as gas stations; below deck on boats; fuel or chemical transfer or storage facilities; areas where the air contains chemicals or particles, such as grain, dust, or metal powders; and any other area where you would normally be advised to turn off your vehicle's engine.

Do not transport or store flammable gas, liquid, or explosives in the compartment of your vehicle which contains your phone or accessories.

Vehicles using liquefied petroleum gas (such as propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269, Attn: Publication Sales Division.


Table of contents

	Rules and regulations	3	
	Safety precautions	4	
Getting Started	Unpacking your phone	8	Getting Started
	Looking at your phone	9	
	Charging the battery pack	11	
	Turning the phone on	14	
	Using the Jog Dial™ navigator	15	
Basic Operations	Making calls	16	Basic Operations
	Receiving calls	18	
Quick Ways to Make Calls	Storing phone numbers in the Phone Book	20	Quick Ways to Make Calls
	Calling from the Phone Book	26	
	Searching the Phone Book	28	
	Calling from the Calls List	31	
	Sending DTMF signals from the Phone Book	33	
Advanced Features	About the Features menus	34	Advanced Features
	Using the Short Messaging Service	36	
	Adjusting the volume	44	
	Message ring	48	
	Checking and setting the timers	49	
	Using the Directory	51	
	Miscellaneous extra features	57	
	Setting security options	59	
	Setting display options	64	
	Adjusting network settings	68	
Additional Information	Troubleshooting	71	Additional Information
	List of menu items	72	
	Specifications	74	
	Glossary	75	
	Index	78	

Unpacking your phone

Carefully unpack your phone and check the contents using this list.
If there is something missing, please contact your nearest Sony dealer.


CM-Z100SPR Portable PCS
Telephone (1)




QN-029BPLH Hi-Capacity
Li-Ion Battery (1)




Hand Strap (1)



QN-001AC AC Adapter (1)



Attaching the hand strap




8

Looking at your phone

For further information, refer to the page numbers indicated in parentheses ().

Telephone



1 Call alert indicator (14)
Lights when there is an incoming call.

2 Earpiece

3 Display
See "Display" on page 10 for a general explanation of the items that appear on the display.

4 Number buttons, 0 to 9, and ***** and **#** buttons (16, 20)
Use the number buttons to enter letters and numbers. Press and hold a number button, 0 to 9, for touch dialing (see page 27). Use the ***** and **#** buttons to move the cursor when you are entering letters.

5 Arm microphone
Open to make/receive a call. Close to end a call.

6 **TALK** button (16 to 20)
Press to make outgoing calls and to receive incoming calls when the arm microphone is open.

7 **END** button (16, 18, 19)
Press to end calls. Also cancels operations and returns the phone to standby mode.

8 **CLR** (clear) button (20)
Press to clear the last or all entered digits on the display, or to exit the current mode of operation.


9 **PWR** (power) button (14)
Press to turn the phone on or off.

10 Hand strap attachment (8)

11 Battery cover release tab (11)
Slide up to remove the battery cover.

12 Battery cover (11)

13 Antenna (14)


14 Jog Dial™ navigator (15)
Push and turn for menu navigation and for changing settings on menus. In this manual, the  icon indicates that you should push the Jog Dial™ navigator in towards the center of the phone.

15 Ringer (44)

16 Connector (12)
Use to connect the phone to either the AC adapter, a cigarette lighter adapter, a desktop charger, or a hands-free car kit.

Display

The top row of the display contains icons that inform you of the current status of your phone. The bottom four rows of the display are for text such as phone numbers, names, and operational prompts. Each row displays a maximum of 12 characters.



1 Short character display

Shows settings such as the number of the currently displayed Features menu, as well as Phone Book and Calls List memory locations.

2 (in-use) / (out-of-service) icon (14, 16, 18)

The in-use icon appears during a call. A slash through the in-use icon appears when no signal is received. You cannot make or receive calls when the out-of-service icon is visible.

3 D (digital) icon

Appears when your phone is receiving a signal.

4 Y III (signal strength) icon (14)

Tells you the approximate strength of the signal being received.

5 R (roam) icon (68)

Appears when you are roaming outside your home service area.

6 M (message) icon (36)

Appears when you have new text or voice mail messages pending. The icon flashes if the new message is urgent.

7 [Battery Icon] (battery) icon (12, 13)

Shows the approximate amount of charge power remaining in the battery. Recharge the battery before it is fully discharged.

8 Character display

Prompts various actions, and then displays the results. It also shows phone numbers and names.

Charging the battery

Make sure to charge the battery before using the phone. To charge the battery, attach the battery to the handset, then connect the supplied AC adapter.


Getting Started

Inserting the battery

- 1 Slide up the battery cover release tab ① and remove the cover ②.



- 2 Align the battery terminals with those on the phone and insert the battery. Make sure the battery is inserted with the ⊕ ⊖ facing down.




- 3 Align the tabs at the bottom of the cover with the tabs in the phone ① and push the cover until it clicks ②.



To remove the battery


Open the cover and tap the phone lightly to remove the battery.




Charging the battery

Connect the AC adapter to the phone and the other end to a standard 120V AC outlet as illustrated below. The charging time is about 3 hours.

In addition, you can charge the battery with the phone turned on. Charging will take longer with the phone turned on.





When the power is turned on

As the battery charges, the battery icon () indicates the power status. The blocks in the battery icon gradually stop flashing. This indicates the level of power restoration.


When all of the blocks in the battery icon have stopped flashing, the battery is fully charged.

When the power is turned off

The message "Battery is Charging" is displayed, and  flashes.



When the battery is fully charged, the message "Charging is Complete" is displayed, and  stops flashing.



Notes

- If you make or receive a call when the battery is not charged sufficiently, the call will be cut off. In that case, you will hear an alarm, indicating that the battery is low.
- You can turn on the phone without the battery, but you cannot make or receive a call, even if you connect the AC adapter to an AC outlet.

Notes on charging

- When you charge the battery, avoid:
 - charging in temperatures below 32°F (0°C) or over 104°F (40°C).
 - charging the battery in direct sunlight or in places with high humidity (such as a bathroom).
- Do not use any battery other than the one specified in these instructions.
- It is normal for the battery to become warm during charging or after use.
- The supplied AC adapter is not intended to be serviced. In the event of a malfunction, it should be replaced.

Notes on the battery

- Do not try to disassemble the battery.
- Do not expose battery to high temperatures or fire.
- Never short circuit the battery. Do not allow battery contacts to touch metal materials.


Checking the battery

Battery duration

In standby mode, the battery lasts approximately 20 hours. When used continuously, it lasts approximately 2 hours.

Battery condition

The battery icon indicates the battery level as follows (when the power is on):



Note that the battery icon displays the approximate charge level and that the consumption may differ depending on conditions of use, such as ambient temperature, network coverage, and usage patterns.

When the battery is empty

The battery icon flashes. A beep sounds, indicating that the battery is low. Shortly thereafter, the phone turns off. Make sure to recharge the battery as soon as possible.

Turning the phone on

To use your phone, the power must be turned on. It is preferable to extend the antenna, as this maximizes signal strength and minimizes interference.

Extending the antenna

Hold the end of the antenna and pull up until fully extended.

To retract the antenna

Push the antenna down until it is fully retracted.




Turning the power on

Hold down **PWR** for about one second. The call alert indicator lights up, the phone beeps (if keybeep volume is not turned off), and the phone starts searching for a signal.



When the phone has found a service signal, the standby display appears and the call alert indicator goes off. Now the phone is ready to use.



To check the signal strength

The signal strength icon indicates various levels of signal strength. It is best to make calls when the signal is strong, although calls can be made when the signal strength is weak.




If you are out of the service area

The out-of-service icon (⌘) appears, and the phone searches for a service signal.




If a signal cannot be found, the phone enters power save mode. It will "wake up" automatically at intervals (based on carrier network settings) to search for a service signal.




Turning the power off

Hold down **PWR** for about one second. The following display appears briefly, then the phone turns off.



Using the Jog Dial™ navigator

The Jog Dial™ navigator makes it easy to navigate from one menu to another.




Getting Started

Choosing a menu item

To choose a menu item, push the Jog Dial™ navigator. The flashing arrow (⇨) on the display indicates the item you can select by pushing ○. If you push ○ on the standby display, for example, you will go to the Features menu. If you push ○ again, you will go to the Message menu.



If you enter digits on the standby display, the word "Options" appears at the bottom of the display, preceded by ⇨. Push ○ to access the Options menu.




To go back

If you want to go back to the previous display, press CLR. If you want to return to the standby display, either press END or hold down CLR.

Scrolling through menu items


To scroll through menu items, turn the Jog Dial™ navigator when the ○ icon appears. The up (⌈) and down (⌋) arrows on the display indicate the available scrollable direction. For example, if you turn ○ within the Sounds menu, you will scroll through the submenu items.



On the leftmost display, ⌈ is not shown. This indicates that you cannot scroll up.

Making calls


You can call any number up to 32 digits from within a service area. The out-of-service icon (K) indicates that you are outside the service area.



In this example, the phone number to be called is 123-456-7890.


1 Use the number buttons and * / # to enter the number.

The following display appears. If you enter the wrong digit, press CLR to back up. To clear all entered digits, press END or hold down CLR to return to the standby display.




2 If the arm microphone is closed, open it to dial. If the arm microphone is open, press TALK to dial.

The phone dials the number you have entered. The icon appears.




When the call is connected, the call timer appears and displays the elapsed time.




4 Press END or close the arm microphone to end the call when you are finished.

The icon disappears and the final elapsed call time flashes for 10 seconds.



The standby display automatically reappears.




Tips

- When dialing, you can insert a pause to attach a DTMF (Dual Tone Multiple Frequency) number to the number you are calling (see page 33 for a description of DTMF).
- If Auto-Hyphen is turned on, the phone number is hyphenated automatically as you enter the digits (see page 65).
- If Minute Alert is turned on, a beep sounds 10 seconds before every full minute throughout the call (see page 50).
- Enhanced voice privacy is indicated by the message “-P-” displayed in the upper left corner of the LCD (see page 70). This feature is carrier-dependent.

To adjust the earpiece volume during a call


Turn  up to increase the volume.

Turn  down to decrease the volume.

Tip

In addition, you can adjust the volume using the Sounds menu (see page 44).



To mute/unmute the microphone during a call

Push and hold .

Tip

In addition, you can mute the microphone using the Sounds menu (see page 45).


To redial the last number

On the standby display, press  when the arm microphone is open. Then press  again and the number you dialed last is redialed automatically.



Receiving calls


You can receive calls as long as the out-of-service icon (⌘) is not displayed. The ⌘ icon indicates that you are outside the service area.



When you receive a call, the ringer sounds or the phone vibrates. "Incoming Call" flashes, and the call alert indicator lights.


Note

If you turn off the ringer volume (see page 44), you will not hear the ringer sound. The message "-Ringer Off-" is displayed on the standby display.





- 1 If the arm microphone is closed, open it.
If the arm microphone is open, press **TALK** to answer the call.

When the call is connected, the call timer appears and displays the elapsed time.



- 2 Press **END** or close the arm microphone to end the call when you are finished.
The ⌘ icon disappears, and the final elapsed call time flashes for 10 seconds.

The standby display automatically reappears.



Tips

- Using the Jog Dial™ navigator, you can adjust the earpiece volume or mute the microphone during a call (see page 44).
- Enhanced voice privacy is indicated by the message "-P-" displayed in the upper left corner of the LCD (see page 70). This feature is carrier-dependent.

If the caller has caller ID

The caller's phone number appears on the display when you receive a call if both the caller and the carrier support this feature.




If the caller has caller ID and the number matches a Phone Book entry, the name that you stored with the number (if any) is displayed also.



If you miss a call


If you miss an incoming call, a message appears similar to the following display. To return to the standby display, either press **CLR**, **END**, or **OK**. If the caller had caller ID, the caller's number is stored in the Calls List (see page 31).



Storing phone numbers in the Phone Book

Your phone features a built-in Phone Book memory, in which you can store up to 99 (01-99) phone numbers with names. You can dial stored numbers quickly by recalling them from the Phone Book (see page 26).

Each phone number can contain up to 32 digits, and each name up to 12 characters. This section shows how to store, edit, and erase Phone Book numbers quickly.




In this example, the phone number to be stored is 123-456-7890, and the name is SONY.

- 1** On the standby display, use the number buttons and *->/->* to enter the number.


The number appears on the display.



In addition, you can store hyphens, pauses, and links with your Phone Book entries (see page 22).




- 2** Push .

The Options menu appears.




- 3** Turn  to select "Save," then push .

The following display appears, prompting you for a name to accompany the number.





- 4** Use the number buttons to enter the name.


If you press the same button in quick succession, the letter you just entered changes. (See the "Alphanumeric table" on page 21.) For the next entry, wait until the cursor moves one step to the right or use *->/->* or Jog Dial™ navigator to move the cursor. Use *->/->* to insert spaces between characters. If you enter the wrong character, press CLR to clear the character highlighted by the cursor.





To enter "SONY"

Press  four times to enter an "S."

Press  three times to enter an "O." Wait until the cursor moves one step to the right for the next entry.

Press  twice to enter an "N."

Press  three times to enter a "Y."



5 When you are finished, push to store the phone number and name.

A display appears similar to the following, indicating the first available memory location.

```

  BTd 0228
  Save in
  Location 15?
  #: Save
  ( : Other Loc
  
```

6 Push to store the new number in the first available memory location.

If you want to store it in another location, turn to select the desired location or enter the location number, then push . A confirmation message appears, followed by the status of the Phone Book.

```

  L 15 BTd 0228
  SONY
  has been
  saved in
  Location 15.
  
```



```

  BTd 0228
  PHONE BOOK
  LOCATIONS:
  21 used
  78 empty
  
```

Tip

In addition, you can use the Directory menu to store Phone Book numbers (see page 50).

Quick Ways
to Make Calls

Alphanumeric table

Each time you press a number button, it cycles through the letters as follows:


Button	Sequence
	- " . ' , & () : 1
	A B C a b c 2
	D E F d e f 3
	G H I g h i 4
	J K L j k l 5
	M N O m n o 6
	P Q R S p q r s 7
	T U V t u v 8
	W X Y Z w x y z 9
	0

To enter a hyphen, pause, or link

You can enter hyphens, pauses, or links, as well as digits into a number entry. When you store a foreign number, turn off the phone's autohyphenation feature. If you enter a hyphen manually, autohyphenation will turn off for that number. Pauses are helpful when you want to send DTMF signals (see page 33). Use links when you want to join and dial two or more Phone Book entries. After inserting a link, enter the number of the memory location that you want to attach.


1 While entering digits, push .




The Options menu appears.



2 Turn to select which information to enter, then push .


After inserting a hyphen, pause, or link, the display returns to number entry mode.



To enter	Select	The display shows
a hyphen	Enter Hyphen	-
a hard pause	Hard Pause	
a time pause	Time Pause	
a link	Enter Link	


If the Phone Book is full

If there are no memory locations available, the following display appears.




After entering a name, the following display appears, prompting you to specify a memory slot to overwrite.


To cancel, hold down .





Editing stored information


You can edit the name, phone number, and memory location of specific entries stored in the Phone Book.


- 1 On the standby display, turn  once.
The Phone List display appears.





- 2 Turn  down to select "Phone Book."
The first entry in the Phone Book appears.






- 3 Turn  to select the entry that contains the information you want to edit.
The contents of the selected memory location are displayed.






- 4 Push .
The Options menu appears.



- 5 Turn  to select "Edit," then push .
The Edit menu appears.




- 6 Turn  to select the item you want to edit, then push .
The stored information that corresponds to the selected item appears.



To change	Select
the name	Name
the phone number	Phone #
the memory location	Location #


- 7 Enter the new information.
Enter new information the same way you stored original information (see page 20). The old information is overwritten.





Quick Ways
to Make Calls


8 When you are finished, push .

The Options menu reappears when you edit the name, phone number, or the memory location. New information is saved immediately.



9 Turn  to select "Save," then push .

A display appears similar to the following, confirming that your changes have been saved.



Tip


In addition, you can use the Directory menu to edit Phone Book numbers (see page 52).

Erasing a phone number

You can erase stored Phone Book entries. If the selected entry is restricted, you must enter the four-digit lock code before you can erase it (see page 60).


1 On the standby display, turn  down twice to select "Phone Book."

The first Phone Book entry is displayed.




2 Turn  to find the Phone Book entry you want to erase.


The contents of the selected memory location are displayed.




3 Push .

The Options menu appears.




4 Turn  to select "Erase," then push .

A display appears similar to the following, prompting you to confirm the erasure.



5 Push  again.

The selected entry is erased. After a few seconds, the standby display reappears.





Tips



- You also can use the Directory menu to erase one Phone Book entry at a time (see page 51).
- Use the Security menu to erase all Phone Book entries at once (see page 62).


Restricting Phone Book entries


You can restrict individual Phone Book entries or the entire Phone Book so that access can be gained only by entering a lock code (see page 60). The phone numbers of restricted entries will not be displayed.


- 1 Select the Phone Book entry that you want to restrict, then push . The Options menu appears.



- 2 Turn  to select "Restriction," then push . A display similar to the following appears.




- 3 Push  to restrict the selected entry. Now the selected entry is restricted. After a few seconds, the standby display reappears.




Quick Ways
to Make Calls



To unrestrict an entry


- 1 Select the Phone Book entry that you want to unrestrict. The following display indicates a restricted entry.




- 2 Push . The Options menu appears.



- 3 Turn  to select "Restriction," then push . The following display appears, prompting you to enter the lock code.




- 4 Use the number buttons to enter the lock code. Now the selected entry is unrestricted. After a few seconds, the standby display reappears.



Tip
You also can use the Security menu to restrict/unrestrict Phone Book entries (see page 61).


Calling from the Phone Book

You can dial frequently used numbers quickly from the Phone Book using the Jog Dial™ navigator. Alternatively, by using speed/touch dialing, you only need to press a few buttons to dial these numbers.




1 On the standby display, turn once.

The Phone List display appears.




2 Turn down to select "Phone Book."

The first entry in the Phone Book appears.





3 Turn to select the desired Phone Book entry.

The contents of the selected entry are displayed.





4 Open the arm microphone if it is closed.

If the arm microphone is open, push  to see the Options menu.





Push  again to make a call.

The phone dials the number stored in the selected Phone Book entry. The  icon appears.




Tips

- You can search for a phone number by name or memory location (see pages 28-30).
- Whenever the phone number is displayed, you can call it by pushing  or  or by opening the arm microphone.
- If the phone number of a selected Phone Book entry is too long to fit on the screen, you can still view the overflow digits by selecting "View Number" on the Options menu.

To release a pause or link during a call


If a Phone Book entry contains hard pauses or links, only the digits up to the first hard pause or link are displayed. To dial the rest of the selected entry (and release the pause or link), push . For a time pause, wait two seconds. The phone dials the rest of the entry automatically.



Speed dialing


To dial quickly, you can enter the Phone Book memory location numbers. The phone calls the number stored in the corresponding location.

1 Use the number buttons to enter the memory location number.



2 To dial the number, open the arm microphone. If the arm microphone is already open, press .

The name and memory location number appear. The phone dials the number stored in the entered memory location.



Quick Ways
to Make Calls

Note


You cannot use speed dialing to call the phone number in location 1. If the arm microphone is open and you press , then , the phone dials voice mail center.

Touch dialing

You can dial a phone number stored in the Phone Book without pressing . Before using this feature, make sure that Touch Dial on the Extras menu is set to "on" (see page 57).

1 Use the number buttons to enter the memory location number, and hold down the last digit of the memory location number for about two seconds when the arm microphone is already open.

The name and number of the memory location appear. The phone dials the number stored in the entered memory location.




Note

You cannot use touch dialing to call the phone number in location 1. If the arm microphone is open and you press , then , the phone dials voice mail center.


Searching the Phone Book


To locate a desired Phone Book entry, you can search by name, phone number, or memory location. You can search the Phone Book either alphabetically or for a string of characters.





Searching alphabetically

When you enter only one character, the phone lists all entries that begin with the entered character.


- 1 From the standby display, turn  once.
The Phone List display appears.





- 2 Push .
- The Search display appears.



- 3 Enter only one character.



- 4 Push .
- All Phone Book entries display alphabetically that begin with the entered character.




- 5 Turn  to view the next entry.


Tip


In addition, you can use the Directory menu to search the Phone Book by name (see page 53).


Searching for a string of characters

When you enter two or more characters, the phone searches for entries that contain those characters. The results are listed starting from the lowest memory location number.


- 1 From the standby display, turn  once.
The Phone List display appears.






- 2 Push .
The Search display appears.



- 3 Enter at least two characters.



- 4 Push .
The entries containing the selected string are listed starting from the lowest memory location number.
Turn  to view the next search string entry.



Quick Ways
to Make Calls


Note


If the search string does not contain punctuation or a space, the phone scans only the first characters of the words in the matching entries.


Searching by memory location

The phone searches for a memory location that matches the entered digit(s), and displays a list of options.

- 1 On the standby display, enter the memory location (a maximum of two digits).



- 2 Push .
The Options menu appears.



- 3 Turn \odot up to select "Recall Loc#," then push \odot .**
The Phone Book entry stored in the selected memory location is displayed.

```
L 15 BTM 022
SONY
123-456-7890
☛:Options
```

If the entered location is empty, a message similar to the following appears. After a few seconds, the standby display reappears.

```
L 15 BTM 022
Phone Book
storage
location 15
is empty.
```

Tip

In addition, you can use the Directory menu to search the Phone Book by memory location (see page 54).

Searching for a phone number

The phone lists all entries that contain the entered digit(s).

- 1 On the standby display, enter at least three digits.**

```
BTM 022
456
☛:Options
```

- 2 Push \odot .**
The Options menu appears.

```
BTM 022
OPTIONS CC
Find Number
Talk
Save
```

- 3 Turn \odot up to select "Find Number," then push \odot .**
The Phone Book lists and displays all entries matching the entered digits. Depending on the Sort Book setting (see page 66), the entries are listed either alphabetically or by memory location.

```
L 15 BTM 022
SONY
123-456-7890
☛:Options
```


- 4 Turn \odot to view the next entry that contains the search string.**

If a matching Phone Book entry is not found, a message similar to the following is displayed. After a few seconds, the standby display reappears.


```
L 01 BTM 022
"645"
wasn't found
in any Phone
Book entries
```

Calling from the Calls List


Information on the ten most recent outgoing calls, incoming calls, scratch pad entries, and missed calls are stored in the phone's Calls List. If you call the same number twice in a row, only the most recent call is stored in the Calls List.




- 1 On the standby display, turn **⌂** once.
The Phone List display appears.




- 2 Turn **⌂** up to go to "Calls List."
Information on the most recent call appears.
"Calls List is empty" displays if there are no entries.



- 3 Turn **⌂** to select the entry you want.
The contents of the selected entry displays.




- 4 Open the arm microphone if it is closed.
If the arm microphone is open, push **⌂**.



The Options menu appears.

- Push **⌂** again.
The phone dials the selected Calls List entry.
The **⌂** icon appears.



Quick Ways
to Make Calls

Tips

- To dial, you also can press **(MAX)** (when the arm microphone is open) after selecting the entry in step 3 on the previous page.
- If the selected entry contains a pause or a link, only the digits up to the pause or link are dialed. To release pauses and links, see page 27.
- In addition, you can use the Directory menu to view the Calls List (see page 55).

To view detailed information of Calls List entries

Using the Options menu in step 4 on the previous page, In addition, you can view the digits of a phone number that do not fit on the screen, the duration of the call, or the time and date of the call.


To view	Select
digits that do not fit on the screen	View Number
the duration of the call	Duration
the time and date of the call	Time/Date

To save the number to the Phone Book

Select "Save" from the Options menu in step 4 on the previous page by pushing the Jog Dial™ navigator.


Sending DTMF signals from the Phone Book

You can send DTMF (Dual Tone Multiple Frequency) signals to access electronic services (such as telephone banking) when dialing numbers from the Phone Book. Dual Tone Multiple Frequency is also known as "touch-tone." Tones are generated when you press a telephone button (number, #, or *). It can be used to access answering machines, pagers, telephone banking services, data services, and other electronic services.




- 1 During a call, search for the Phone Book entry that contains the numbers you want to send.

The selected entry is displayed. Use the Directory menu to search for the Phone Book entry (see pages 53 and 54).



- 2 Push .


The Options menu appears.



- 3 Turn to select "Send Tones," then push .

A DTMF signal, containing the entered digits, is sent in a burst.

If you try to send a DTMF signal in standby mode
The following message is displayed. You can send a DTMF signal only during a call.




Notes

- To enter and send numbers one by one during a call, use the number buttons and / to send the DTMF number.
- To change the length of the DTMF transmission, see "Setting the keybeep length" on page 47.

Quick Ways
to Make Calls


About the Features menus

You can use the Features menu to customize the special features of your phone.



Menu structure

The phone uses a hierarchical on-screen menu structure for setting and editing parameters. For a comprehensive list of submenus and corresponding settings, see "List of menu items" on pages 72 and 73.



Viewing and selecting menu options

The Jog Dial™ navigator makes it easy to navigate the phone's menus. The procedure to view and select menu options is common to most of the Features menus (see page 72). These menus are also accessible during a call. The following example shows how to set the backlight.

1 On the standby display, push **END** to select "Features."

If the standby display is not shown, press **END** or hold down **CLR**, then push **END** to display the Features menu. The arrow and the menu number flash, indicating which menu will be selected by pushing **END** (in this case the Message menu [F-1]).



2 Turn **END** to select "Display," then push **END**.

The Display menu appears. The arrow and the last digit of the submenu number flash, indicating which submenu will be selected by pushing **END** (in this case the Banner menu [F71]).



3 Turn \odot to select "Backlight," then push \odot .
 The Backlight menu appears. The current setting is indicated by a check mark (\checkmark) and is displayed in capital letters. (See page 65 for an additional description on setting the backlight.)

```

F 12 B Y M 0221
BACKLIGHT
✓FOR 7 SECS
(←: Choices
→: To Set
  
```

4 Turn \odot to select the setting.
 The available options appear in a cyclic manner as you turn \odot .

```

F 12 B Y M 0221
BACKLIGHT
off
(←: Choices
→: To Set
  
```

5 Push \odot to enter the new setting.
 The standby display reappears.

```

B Y M 0221
My Phone
12:34P 12/25
(←: Phone List
→: Features
  
```

To exit from the Features menu

Press END or hold down CLR to return to the standby display.

To return to the previous display

Press CLR . To go back further, press CLR again.

Notes

- If you reach the last menu item and try to turn \odot further, a beep indicates that you have reached the end of the menu. To view other menu items, turn \odot in the opposite direction.
- The standby display automatically reappears after 30 seconds of inactivity, except in the Phone List.

Tip


Each menu item can be accessed quickly from the standby display by pushing \odot and then pushing the number of the menu item. The item number then appears in the upper left corner of the display in step 3. For example, you can access the backlight setting by pushing \odot followed by 7 and 2 .

Advanced Features

Using the Short Messaging Service

This section contains information on the Short Messaging Service (SMS). This feature lets you receive "text" messages, which are stored in your phone as long as there are enough memory locations available.

Contact your service provider to see if this service is available in your area.




Receiving messages

To receive messages, the phone must be turned on. The phone supports three types of messages: "TEXT" indicates a text message; "PAGE" typically contains only digits; "VOICE" is a voice mail notification, and indicates the number of new voice mail messages stored in your voice mailbox.

When you receive a message

The message icon (☐) appears on the display and the call alert indicator flashes, accompanied by audible alerts. The following display appears. The first line indicates message type and priority. If the message is urgent, the message type is preceded by the word URGENT. If you press any key, this display disappears. The message icon (☐) remains displayed as long as there are unread messages.



Tip


If you receive duplicate messages, the phone deletes the older one and stores the new one with the indication "DUPLICATE."

Notes


- When you receive a new message and your phone does not have enough memory to store it, the phone automatically erases old messages that are not locked.
- If the ringer volume is set to "vibration," the phone emits a vibration instead of an audible ring when you receive a message.

If the memory becomes full

The phone issues a warning when the memory is 75% full. At this point, you should erase expendable messages (see page 43).



If the memory becomes completely full or your phone does not have enough memory to receive an incoming message, new messages are rejected and the following display appears.




Accessing messages

1 Push **○** twice from the standby display.

The Message menu appears, indicating the number of the following types of messages, respectively:

- Voice mail messages (see the section below).
- Unread text messages and pagings (see page 39).
- Text messages and pagings that you have already read, but are still stored in memory (see page 40).



Reading voice mail notification messages [F11]


1 Push **○** to select "Voice" from the Message menu.

The Voice display appears, indicating the number of voice messages stored in your voice mailbox. Press **CLR** to go back to the Message menu.



2 Turn **○** to scroll through the message.

A hollow box (□) indicates the end of the message.



Options




Accessing voice mail

You can access voice mail center easily.

1 Press and hold **○** for about two seconds.

or


Press **○**, then press **TALK**.



To erase a voice message


- 1 After reading a voice mail notification message, push .

The Options menu appears.



- 2 Turn  to select "Erase Msg," then push .


The voice mail notification message is erased. The Message menu reappears, indicating that there are currently no voice mail notification messages stored in memory.




To dial a callback number


- 1 After reading a voice mail notification message, open the arm microphone if it is closed.

The phone dials the callback phone number which is attached to the message.




If the arm microphone is open, push  to see the Options menu.

Then push  again to dial the callback phone number.



Tip

In addition, you can dial the callback number by pressing  when reading a voice mail notification message if the arm microphone is open.

Reading new text messages [F12]

You can read both new and old messages stored in memory. Urgent messages are listed above non-urgent ones, with the most recent entries first. After reading messages, you can protect or erase them.


- 1 Turn **⊙** to select "New Text" from the Message menu, then push **⊙**.

The first message is displayed.



URGENT TEXT
from SONY
123-456-7890


If there are no new messages, the following display appears. Push **⊙** to return to the Message menu.



There are no
new text
messages.
⇒:OK

- 2 Turn **⊙** to scroll through the message.


If you do not scroll, the display automatically scrolls down. A hollow box (□) indicates the end of the message.



Thanks□
12:25P 12/25
=====

- 3 To proceed to the next message, push **⊙**.


The Options menu appears. To return to the standby display, press **END**.



OPTIONS
TALK
Next Msg
Lock Msg

- 4 Turn **⊙** to select "Next Msg," then push **⊙**.

The next message is displayed. If there are no more messages, the Message menu reappears.



TEXT from
619-658-5100

To return to the previous message

In step 4 above, select "Prev Msg" from the Options menu.

Note


Once you reach the end of the message and go to the next message, previous message is stored as old message.




Reading old text messages [F13]

The most recent messages are listed first.


- 1 Turn **⊙** to select "Old Text" from the Message menu, then push **⊙**.
A list of old messages is displayed. A dot (•) indicates the beginning of each message. A lock icon (🔒) indicates that the message is locked (see page 41). If a number is too long to fit, an ellipsis (...) is used.
- 2 Turn **⊙** to scroll through the list of old messages.
- 3 To read the selected message, push **⊙**.
The selected message is displayed.
- 4 Turn **⊙** to scroll through the message.
If you do not scroll, the display automatically scrolls down to the end of the message, which is indicated with a hollow box (□).
- 5 When you have read the message, press **CLR** to return to the list of old messages.
To read the next message, push **⊙** to go to the Options menu, then select "Next Msg."
To read the previous message, push **⊙** to go to the Options menu, then select "Prev Msg."




```
BTM [lock] [options]
OLD TEXT (
• Bob, flig...
  619-658-54
  658-5272
```



```
BTM [lock] [options]
OLD TEXT (
• Bob, flig...
  619-658-54
  658-5272
```




```
BTM [lock] [options]
Bob, flight
comes in at
1:30. Please
pick me up!
```



↓

```
BTM [lock] [options]
Thanks□
12:25P 12/25
=====
⇒Options
```



```
BTM [lock] [options]
OLD TEXT (
• Bob, flig...
  619-658-54
  658-5272
```



To protect a text message

You can lock a message to protect it from being erased.

- 1 After reading a message, push .
The Options menu appears.



- 2 Turn to select "Lock Msg," then push .
The following display appears, and the message is now locked.




Note

The phone does not erase locked messages automatically. When there is not enough memory for incoming messages, you must erase the locked messages manually.


To respond to a text message

- 1 After reading a text message, open the arm microphone if it is closed.




- 2 If the arm microphone is open, push to see the Options menu. Then, turn to select "Talk," then push .

The phone dials the callback phone number which is attached to the message.



If the callback number is not attached to the message, no call is made and the following message is displayed.



Tip


In addition, when viewing a text message or the list of old messages, you can dial the callback phone number simply by opening the arm microphone, or pressing when the arm microphone is already open.

To save the callback number


- 1 After reading a message, push .
The Options menu appears.




- 2 Turn to select "Save Number," then push .
The following display appears, prompting you for a name to accompany the number.




- 3 Use the number buttons to enter the name.
If you press the same button in quick succession, the letter you just entered changes. (See the "Alphanumeric table" on page 21.) Use / or Jog Dial™ navigator to move the cursor or to insert spaces between characters. If you enter the wrong character, press to clear the character highlighted by the cursor.




- 4 When you are finished, push to store the phone number and name.
A display similar to the following appears.



- 5 Push to store the new number in the first available memory location.
If you want to store it in another location, turn to select the desired location, then push .




A confirmation message appears, followed by the status of the Phone Book.



Adjusting the volume

You can adjust the volume of the ringer, keybeep, and earpiece on the Sounds menu. In addition, you can select the type of sounds heard when the phone rings (see page 46) and when you press buttons (see page 47).




Sounds menu

Adjusting the ringer volume [F21]


- 1 Push to select "Ringer Vol" from the Sounds menu.

The Ringer Vol menu appears.



- 2 Turn up to raise the ringer volume, and down to lower it.

You can select from six ringer volume settings: "off," "low," "med. (medium)," "high," "escalate," and "vibration."




- 3 Push to enter the new setting.

The standby display reappears.

If you turn off the ringer volume

The message "-Ringer Off-" is displayed at the top of the screen when the standby display appears.



Tips

- If you set the ringer volume to "escalate," the telephone rings twice at a low volume, then once at medium volume, and thereafter at a high volume.
- If you set the ringer volume to "vibration," the telephone emits a vibration instead of an audible ring.
- If the telephone is used in conjunction with a hands-free car kit or a portable hands-free car kit, the "vibration" setting is not available.
- If the telephone is connected to a wall outlet and the ringer volume is set to "vibration," the telephone emits an audible ring at the "high" setting instead.

Muting/unmuting the microphone [F22]


You can mute/unmute the phone during a call directly, without using the Sounds menu by pushing and holding .

In addition, you can mute/unmute the microphone during a call using the Sounds menu as follows. This feature is disabled in standby mode.


- 1 During a call, turn **⊙** to select "Sounds" from the Features menu, then push **⊙**.
The Sounds menu appears.




- 2 Turn **⊙** to select "Mute/UnMute" then push **⊙**.
The following display appears. Now the microphone is muted.



- 3 To unmute the microphone, turn **⊙** to select "Sounds" from the Features menu, then push **⊙**.
The Sounds menu reappears.




- 4 Turn **⊙** to select "Mute/UnMute" then push **⊙**.
The following display appears. Now the microphone is unmuted.




Adjusting the keybeep volume [F23]

You can adjust the volume of the beep that sounds when you press a button.

- 1 Turn **⊙** to select "Keybeep Vol" from the Sounds menu, then push **⊙**.
The Keybeep Vol menu appears.



- 2 Turn **⊙** up to raise the keybeep volume, and down to lower it.
You can select from four keybeep volume settings: "off," "low," "med. (medium)," and "high."



- 3 Push **⊙** to enter the new setting.
The standby display reappears.


Adjusting the earpiece volume [F24]

You can adjust the speaker volume.

- 1 Turn  to select "Earpiece Vol" from the Sounds menu, then push .

The Earpiece Vol menu appears.

```
F24 07M 022
EARPIECE VOL
  7 -■■■■■
⌂: Choices
⇨: To Set
```

- 2 Turn  up to raise the earpiece volume, and down to lower it.

There are seven earpiece volume settings ranging from "1" to "7." A higher number indicates higher volume.

```
F24 07M 022
EARPIECE VOL
  4 -■■■
⌂: Choices
⇨: To Set
```

- 3 Push  to enter the new setting.

The standby display reappears.

Tip

You can adjust the earpiece volume during a call by turning .

Setting the ringer type [F25]


You can set the type of beep that sounds for an incoming call.

- 1 Turn  to select "Ringer Type" from the Sounds menu, then push .

The Ringer Type menu appears.

```
F25 07M 022
RINGER TYPE
  STANDARD
⌂: Choices
⇨: To Set
```

- 2 Turn  to select the ringer type.

You can select from five different ringer settings. The ringer sounds every time you turn .

```
F25 07M 022
RINGER TYPE
  option 2
⌂: Choices
⇨: To Set
```

- 3 Push  to enter the new setting.

The standby display reappears.

Setting the keybeep type [F26]

You can set the beep that sounds when you press a button to either a tone or a click. Tones sound similar to DTMF tones. Clicks are indicated by single beeps.

- 1 Turn to select "Key Sound" from the Sounds menu, then push .

The Key Sound menu appears.

```
F26 B.Y.M. 
KEY SOUND
      ^TONES
(C: Choices
^: To Set
```

- 2 Turn to select the keybeep type.

You can select "tones" or "clicks."

```
F26 B.Y.M. 
KEY SOUND
      clicks
(C: Choices
^: To Set
```

- 3 Push to enter the new setting.

The standby display reappears.

Note

DTMF tones are played to the other party during a call even if you set the keybeep type to "clicks."

Setting the keybeep length [F27]

You can set the length of the beep that sounds when you press a button. This setting affects both the keybeep feedback and DTMF transmission tones. The phone sends a short DTMF burst (default) or plays every tone of the DTMF signal as long as the key is held down.

- 1 Turn to select "Beep Length" from the Sounds menu, then push .

The Beep Length menu appears.

```
F27 B.Y.M. 
BEEP LENGTH
      ^STANDARD
(C: Choices
^: To Set
```


- 2 Turn to select the keybeep length.

You can select "standard" or "long."

```
F27 B.Y.M. 
BEEP LENGTH
      long
(C: Choices
^: To Set
```



- 3 Push to enter the new setting.


The standby display reappears.




Message ring

Setting the message ring [F28]

- 1 Turn  to select "Message Ring" from the Sounds menu, then push .
The Message Ring menu appears.




- 2 Turn  to select the setting.
If you select "on," beeps sound when you receive a new message. In addition, a beep will sound every 3 minutes to remind you that you have unread message(s) if you select "+ reminder."

If you select "off," beeps will not sound when you receive new message(s).

- 3 Push  to enter the new setting.

Checking and setting the timers

You can check call durations on the Timers menu. In addition, you can set the phone to alert you every minute of a call, and make the phone turn itself off automatically.




Timers menu

Checking the duration of all calls [F31]

You can view the total duration of all calls. This information cannot be reset.

- 1 Turn **⊙** to select "All Calls" from the Timers menu, then push **⊙**.
The All Calls display appears.




- 2 Push **⊙** to go back to the standby display.


Checking and resetting the duration of recent calls [F32]

You can view the total duration of the most recent calls.

- 1 Turn **⊙** to select "Recent Calls" from the Timers menu, then push **⊙**.
The Recent Calls display appears.





- 2 Press **1** to reset, or hold down **CLR** to go back to the standby display.
If you choose to reset, the counter of recent calls and the corresponding durations are reset.



Setting the minute alert [F33]


You can set the phone to alert you ten seconds before every full minute.

- 1 Turn  to select "Minute Alert" from the Timers menu, then push .
The Minute Alert menu appears.

```
F33 BTM 0222
MINUTE ALERT
      OFF
((): Choices
(): To Set
```



- 2 Turn  to select "on" or "off."

```
F33 BTM 0222
MINUTE ALERT
      on
((): Choices
(): To Set
```


- 3 Push  to enter the new setting.
The standby display reappears.

Setting the phone to automatically turn off [F34]


You can set the phone to automatically turn itself off after a specified duration.

- 1 Turn  to select "Auto-Off" from the Timers menu, then push .
The Auto-Off menu appears.

```
F34 BTM 0222
AUTO-OFF
      NEVER
((): Choices
(): To Set
```

- 2 Turn  to select the duration before the phone powers off automatically.
You can select from five settings: "never," "in 3 hours," "in 2 hours," "in 1 hour," and "in 30 mins." If you select "never," the phone does not turn itself off automatically.

```
F34 BTM 0222
AUTO-OFF
      in 30 mins
((): Choices
(): To Set
```

- 3 Push  to enter the new setting.
If you set the phone to power off in 30 minutes, for example, the following display appears.

```
F34 BTM 0222
Phone will
turn off in
30 minutes.
```

Notes

- If you press any button or operate the Jog Dial™ navigator, the timer is reset and the countdown starts over.
- The phone does not turn itself off automatically during a call.
- If the Auto-Off timer is set, the phone turns off after a user-specified duration and the countdown "Off:xxxxxx" is displayed.
- Once the phone turns off, the setting will revert to "never."

50

Using the Directory

You can use the Directory menu to check your phone number, as well as store, erase, and edit phone numbers and names in the Phone Book. In addition, you can use this menu to view the Calls List.




Directory menu

Checking your phone number [F41]

- 1 Push **○** to select "My Number" from the Directory menu.

The My Phone # display appears, showing your phone's number.




- 2 Push **○** to exit this feature.
The standby display reappears.


Storing phone numbers [F42]

For quick and easy dialing, the Phone Book allows you to store up to 99 phone numbers.


- 1 Turn **○** to select "Save" from the Directory menu, then push **○**.
The following display appears.




- 2 Use the number buttons and **(#→)/(←*)** to enter the phone number, then push **○**.
The Options menu appears. (See the "Alphanumeric table" on page 21.)



- 3 Turn **○** to select "Save," then push **○**.
The following display appears, prompting you for a name to accompany the number.




- 4 Use the number buttons to enter the name.
Use **(#→)/(←*)** or Jog Dial™ navigator to move the cursor or to insert spaces between characters. If you enter the wrong character, press **(CLR)** to clear the character highlighted by the cursor. (See the "Alphanumeric table" on page 21.)



5 When you are finished, push \odot to store the phone number and name.



A display similar to the following appears.



6 Push \odot to store the new number in the first available memory location.

If you want to store it in another location, turn \odot to select the desired location, then push \odot .

A confirmation message appears, followed by the status of the Phone Book.



Tip


In addition, you can use the Options menu to store Phone Book numbers (see page 20).

Erasing a phone number [F43]

You can erase stored Phone Book entries. If the selected entry is restricted, you must enter the four-digit lock code to erase it (see page 60).


1 Turn \odot to select "Erase" from the Directory menu, then push \odot .

The following display appears, prompting you for the Phone Book entry to be erased.




2 Turn \odot to select the entry you want to erase, then push \odot .

A display similar to the following appears, prompting you to confirm that the selected Phone Book entry should be erased. In addition, you can use the number buttons to select the entry to be erased.



3 Push \odot again.

The selected entry is erased. After a few seconds, the standby display reappears.



Tips

- In addition, you can use the Options menu to erase one Phone Book entry at a time (see page 24).
- Use the Security menu to erase all Phone Book entries at once (see page 62).

Editing stored information [F44]

You can edit the name, phone number, and memory location of specific entries stored in the Phone Book. If the selected entry is restricted, you must enter the four-digit lock code to edit it (see page 60).

- 1 Turn **⊙** to select "Edit" from the Directory menu, then push **⊙**.

The following display appears, prompting you for the Phone Book entry to be edited.

```
F44 BTM 0221
((to find
entry to
edit then
⇒to select
```

- 2 Turn **⊙** to select the entry that contains the information you want to edit.

In addition, you can use the number buttons to select the entry to be edited.

```
L15 BTM 0221
My Phone
123-456-7890
⇒:Edit
```

A display similar to the following appears, prompting you to confirm that the selected Phone Book entry should be edited.

```
L15 0221
Edit PhBook
Location 15?
SONY
⇒:Edit
```

- 3 Push **⊙** again.

The Edit menu appears.

- 4 Turn **⊙** to select the item you want to change, then push **⊙**.

You can change the name, phone number, or memory location by selecting "Name," "Phone #," or "Location #," respectively. The stored information that corresponds to the selected item appears.

```
L15 BTM 0221
EDIT THE
Name
*Phone #
*Location #
```

- 5 Enter the new information.

The old information is overwritten.

```
L15 BTM 0221
Edit Number
456-123-7890
⇒:Options
```

- 6 When you are finished, push **⊙**.

The Options menu appears when you edit the name, phone number, or the memory location. New information is stored immediately.

```
BTM 0221
OPTIONS ((
Enter Pause
*Save
*Enter Link
```



-
- 7 Turn \odot to select "Save," then push \ominus .**
A display similar to the following appears, confirming that your changes have been saved.

```
L 15 07:14 0222
SONY
has been
saved in
location 15.
```

Tip

In addition, you can use the Options menu to edit Phone Book entries (see page 23).

Searching the Phone Book by name [F45]

You can find name entries in the Phone Book by searching alphabetically or for a string of characters.

Tip

In addition, you can use the Options menu to search the Phone Book by names (see pages 28 and 29).

To search alphabetically

When you enter only one character, the phone lists all entries that begin with the entered character.

- 1 Turn \odot to select "Find Name" from the Directory menu, then push \ominus .**
The Search display appears, prompting you for a search string.

```
F45 07:14 0222
SEARCH FOR
SEARCH FOR
(Enter Name)
Find
```

- 2 Enter only one character.**

```
F45 07:14 0222
SEARCH FOR
S
(Enter Name)
Find
```

- 3 Push \ominus .**
All Phone Book entries are listed that begin with the entered character.

```
L 15 07:14 0222
SONY
123-456-7890
Options
```

- 4 Turn \odot to view the next entry.**

To search for a string of characters

When you enter two or more characters, the phone searches for entries that contain the entered string. The results are listed starting from the lowest memory location number.

- 1 Turn **⊙** to select "Find Name" from the Directory menu, then push **⊙**.

The Search display appears, prompting you for a search string.

```
F45 [Y] [Z]
SEARCH FOR
[ ]
(Enter Name)
⤵:Find
```

- 2 Enter at least two characters.

```
F45 [Y] [Z]
SEARCH FOR
NY[ ]
(Enter Name)
⤵:Find
```

- 3 Push **⊙**.

The entries containing the selected string are listed starting from the lowest memory location number.

```
L 15 [Y] [Z]
SONY
123-456-7890
⤵:Options
```

- 4 Turn **⊙** to view the next entry.

Searching the Phone Book by memory location [F46]

You can find memory locations easily.

- 1 Turn **⊙** to select "Phone Book" from the Directory menu, then push **⊙**.

The following display appears, prompting you for a search string.

```
F46 [Y] [Z]
(( for all
book entries
or enter the
location #.
```

- 2 Use the number buttons to enter the memory location number.

The Phone Book entry that matches the search string is displayed.


```
L 15 [Y] [Z]
SONY
123-456-7890
⤵:Options
```

If the selected entry is empty, the display shows the message "Phone Book storage location XX is empty." After a few seconds, the standby display reappears.

```
L 15 [Y] [Z]
Phone Book
storage
location 15
is empty.
```





Tips

- In addition, you can use the Options menu to recall Phone Book memory locations (see page 29).
- In addition, you can turn  to scroll through the entire Phone Book instead of entering the memory location number in step 2.


Viewing the Calls List [F47]




You can view Calls List entries easily.


- 1 Turn  to select "Calls List" from the Directory menu, then push .


The following display appears, allowing you to view the Calls List.


If the Calls List is empty, the display shows the message "Calls List is empty."






F47   
← for calls list. Then →
to get each call's time

- 2 Turn  to view the Calls List entries.

The most recent entry is displayed first. To view the rest of the ten most recent entries, turn .






C06   
CALL TO
SONY
123-456-7890
⇒Options


Tip

In addition, you can view the Calls List from the standby display (see page 31).

To place a call


Press  in step 2. You also can push  to go to the Options menu, then select "Talk" and push .



C06   
Connecting..
SONY
123-456-7890


Miscellaneous extra features


On the Extras menu, you can set the phone to enable touch dialing, redial automatically, and answer incoming calls automatically or at the press of any button. In addition, you can use this menu to lock the keypad and to jot down phone numbers.




Extras menu

Preventing accidental operation [F51]


When the microphone is closed, you can lock the keypad by pushing and holding  from the standby display. Locking the keypad offers low-level security. For example, it disables accidental dialing when you keep the phone in your pocket. In addition, you can lock the keypad as follows.

- 1 Turn  to select "Key Guard" from the Extras menu, then push .

The following message appears.



After a few seconds, the standby display reappears. The text "Keyguard On" indicates that the keypad is locked.



To unlock the keypad

Open the arm microphone or press ,  and  in quick succession.

To answer an incoming call when the keypad is locked

Just open the arm microphone. You do not need to unlock the keypad.

Tips


- You can lock the keypad even when the phone itself is locked (see page 59).
- The backlight and keybeeps are turned off when the keypad is locked.

Activating touch dialing [F52]

If you want to use the touch dialing feature (see page 27), set to "on."

- 1 Turn  to select "Touch Dial" from the Extras menu, then push .


The Touch Dial menu appears.



- 2 Turn  to select "on" or "off."



- 3 Push  to enter the new setting.

The standby display reappears.




Setting the phone to redial automatically [F53]

You can set the interval for redialing. If a number is not dialed successfully, the phone tries to redial it up to five times every three seconds.


- 1 Turn  to select "Auto-Retry" from the Extras menu, then push .

The Auto-Retry menu appears.



- 2 Turn  to select "on" or "off."

If you select "off," the phone does not try to redial automatically.





- 2 Push  to enter the new setting.

The standby display reappears.



Using the scratch pad [F54]


Your phone has a scratch pad feature, which is useful for writing down phone numbers temporarily.

- 1 Turn  to select "Scratch Pad" from the Extras menu, then push .

The Scratch Pad display appears, prompting you to enter a phone number.




- 2 Use the number buttons and  /  to enter the digits.



- 3 Push .

The Options menu appears. Besides storing digits, you can enter hyphens, pauses, and links (see page 22).



- 4 Turn  to select "Store&Exit," then push .

The information is stored as a scratch pad entry in the Calls List. When the Calls List reaches more than 10 list items, the oldest entries will be deleted as needed to make room for new entries.

58

Setting security options

You can restrict unauthorized access to your phone and the information it holds. Additionally, on the Security menu, you can reset menu settings to default and store emergency numbers. Unlike other items on the Features menu, accessing the Security menu requires a lock code when you select it from the Features menu.

```
F-5 BTM 022
SECURITY
Enter code
for access.
CODE: ----
```



```
F6 BTM 022
SECURITY (
Lock Phone
New Code
Restrict #
```

Security menu

Preventing others from using your phone [F61]

This option lets you set when the phone will be locked. When the phone is locked, carrying out most operations requires entering the lock code; you still can answer incoming calls and dial 911, *911, #911, *611, *2, or the other stored emergency numbers.

1 Push to select "Lock Phone" from the Security menu.

The Lock Phone menu appears.

```
F61 BTM 022
LOCK PHONE
      OFF
(C: Choices
(=: To Set
```

2 Turn to select when the phone will be locked.

You can select "off," "on power-up," or "right now." If you select "off," the phone is available for use without a lock code. If you select "on power-up," the phone is locked every time you turn it on.

```
F61 BTM 022
LOCK PHONE
on power-up
(C: Choices
(=: To Set
```



3 Push to enter the new setting.

The standby display reappears. The message "(=:Unlock" indicates that the phone is locked.

```
BTM 022
My Phone
12:34P 12/25
(=:Unlock
```

To unlock the phone

On the standby display, push . When prompted, enter the lock code.

Setting a new lock code [F62]

The lock code must be entered every time you want to unlock the phone, and also when you want to access restricted numbers.

- 1 Turn **⊙** to select "New Code" from the Security menu, then push **⊙**.

The Enter New Code display appears, prompting you to enter a new lock code.

```
F62 B Y M 0222
ENTER NEW
CODE:
----
⇨: Save Code
```

- 2 Use the number buttons to enter a lock code.

The lock code must be exactly four digits long.

```
F62 B Y M 0222
ENTER NEW
CODE:
 2345
⇨: Save Code
```

- 3 Push **⊙** to store the new lock code in memory.

A confirmation display appears.

```
F62 B Y M 0222
New Lock
code is
 2345
```

Note

Keep a record of your lock code. If you forget it, contact your service provider.

Restricting a Phone Book entry [F63]

You can restrict access to individual Phone Book entries.

- 1 Turn **⊙** to select "Restrict #" from the Security menu, then push **⊙**.

The following display appears, prompting you to specify the Phone Book entry to be restricted.

```
F63 B Y M 0222
⊙ for all
book entries
or enter the
location #.
```

- 2 Turn **⊙** to select the Phone Book entry that you want to restrict.

```
L 15 B Y M 0222
My Phone
123-456-7890
⇨: Restrict
```


- 3 Push **⊙** to restrict the selected entry.

Now the selected entry is restricted.

```
L 15 B Y M 0222
Entry is now
Restricted
```

To unrestrict an entry

Follow the procedure for restricting an entry on the previous page to select the entry you want to unrestrict.



Notes

- The phone number of a restricted entry is not displayed when you view the Phone Book and make a call.
- Restricted entries are not listed or displayed after a digit string search (see pages 29 and 30).
- Calling, editing, and erasing a restricted entry requires the four-digit lock code.


Tip

In addition, you can use the Options menu to restrict/unrestrict Phone Book entries (see page 25).


Restricting all Phone Book entries [F64]

You can restrict access to all Phone Book entries. All operations that involve Phone Book entries require the four-digit lock code (see page 60).

- 1 Turn to select "Restrict All" from the Security menu, then push . The Restrict All menu appears.





- 2 Turn to set restriction of all Phone Book entries on or off.





- 3 Push to enter the new setting.

Reverting to default settings [F65]

You can reset all menu settings to the defaults. This does not affect Phone Book or Calls List entries.

- 1 Turn  to select "Master Reset" from the Security menu, then push .
The Master Reset display appears.



```
F65 07M 022
MASTER RESET
1:To Reset
All Settings
+:Quit
```

- 2 Press  to revert to the factory defaults, or push  to keep the current settings.
If you revert to the factory defaults, all your custom menu settings are erased.



```
F65 07M 022
-reset-
```

Erasing all Phone Book entries [F66]

You can erase all Phone Book entries at once.

- 1 Turn  to select "Erase Book" from the Security menu, then push .
The Erase Book display appears.



```
F66 07M 022
ERASE BOOK
1:To Erase
Phone Book
+:Quit
```

- 2 Press  to erase all Phone Book entries, or push  to quit without erasing.
If you erase all entries, the following display appears.



```
F66 07M 022
-erased-
```

Erasing all Calls List entries [F67]

You can erase all Calls List entries at once.

- 1 Turn  to select "Erase Calls" from the Security menu, then push .
The Erase Calls display appears.

```
F67 07M 022
ERASE CALLS
1:To Erase
Calls List
+:Quit
```

- 2 Press  to erase all Calls List entries, or push  to quit without erasing.
If you erase all entries, the following display appears.


```
F67 07M 022
-erased-
```

Storing emergency numbers [F68]

You can use the Security menu to store up to three emergency numbers other than 911, *911, #911, *611, and *2 (which you cannot erase). You can call these numbers even when the phone is locked.

- 1 Turn **⊙** to select "Emergency #" from the Security menu, then push **⊙**.


The first Emergency # display appears.



F68 **⊙** **⊙** **⊙**
EMERGENCY #1
(empty)
⊙:Other #'s
⊙:Edit #


- 2 Turn **⊙** to select the emergency memory location, then push **⊙**.

The following display appears, prompting you to enter the phone number for the emergency entry.



F68 **⊙** **⊙** **⊙**
Enter phone
number for
emergency
entry #1

- 3 Use the number buttons and **⊙**/**⊙** to enter the number.



F68 **⊙** **⊙** **⊙**
098-765-4321
⊙:Store #

- 4 Push **⊙** to store the emergency number.
The entered emergency number is stored in memory. To store other emergency numbers, repeat the above procedure. To go back to the standby display, hold down **⊙**.



Setting display options

You can use the features on the Display menu to change the appearance of the on-screen display.




Display menu

Setting the banner [F71]

You can change what the banner reads.


- 1 Push to select "Banner" from the Display menu.

The Banner display appears. The current banner text is displayed.




- 2 Push again to start editing.

The following message appears, prompting you to enter a new banner.




- 3 Use the number buttons and / to enter the new banner text.

The banner can be up to 12 characters long.
For details on character entry, see the "Alphanumeric table" on page 21.



- 4 Push to enter the new setting.

The standby display reappears. Your new banner is displayed.



Setting the backlight [F72]

You can adjust the duration of the backlight on the display and keypad.

- 1 Turn **⊙** to select "Backlight" from the Display menu, then push **⊙**.

The Backlight menu appears.

```
F72 07d 022
BACKLIGHT
✓FOR 7 SECS
⌈⌋: Choices
⇨: To Set
```

- 2 Turn **⊙** to select how long the backlight is on after the last press of a button.

You can select "for 30 secs," "for 15 secs," "for 7 secs," or "off." If the phone is used in conjunction with a hands-free car kit, a cigarette lighter adapter, or a single- or dual-slot battery charger, you have the added option of "always on," which leaves the backlight on permanently.

```
F72 07d 022
BACKLIGHT
for 15 secs
⌈⌋: Choices
⇨: To Set
```

- 3 Push **⊙** to enter the new setting.

The standby display reappears.

Setting autohyphenation [F73]

You can turn the autohyphenation feature on and off. If you turn it on, entered numbers are hyphenated according to the North American Numbering Plan (eleven digits which include a long distance identifier, an area code, a three-digit community code, and a four-digit location code e.g., 9-999-999-9999).

- 1 Turn **⊙** to select "Auto-Hyphen" from the Display menu, then push **⊙**.

The Auto-Hyphen menu appears.

```
F73 07d 022
AUTO-HYPHEN
✓ON
⌈⌋: Choices
⇨: To Set
```

- 2 Turn **⊙** to select "on" or "off."

```
F73 07d 022
AUTO-HYPHEN
off
⌈⌋: Choices
⇨: To Set
```

- 3 Push **⊙** to enter the new setting.

The standby display reappears.



Note

Autohyphenation is not fully deactivated when a pause or link is entered. All entered hyphens up to the pause/link will remain.




Sorting the Phone Book [F74]

You can determine how the Phone Book will be displayed, and also set the phone to sort the entries either alphabetically or by memory location.

- 1 Turn  to select "Sort Book" from the Display menu, then push .


The Sort Book menu appears.



```
F74 BYM 0000
SORT BOOK
  BY LOC. #
←:Choices
→:To Set
```

- 2 Turn  to set the sorting preferences.

You can choose to sort the Phone Book "by Loc. #" (by location) or "alphabetic" (alphabetically).





```
F74 BYM 0000
SORT BOOK
  alphabetic
←:Choices
→:To Set
```

- 3 Push  to enter the new setting.


The standby display reappears.

Setting the menu length [F75]

You can set the menu length (long or short). The short menu displays only the most common items on the Features menu; the long menu displays all items.

- 1 Turn  to select "Menu Length" from the Display menu, then push .
The Menu Length menu appears.

```
F75 BTM 0222
MENU LENGTH
  LONG
←: Choices
→: To Set
```

- 2 Turn  to set the menu length.
You can select "short" or "long."

```
F75 BTM 0222
MENU LENGTH
  short
←: Choices
→: To Set
```

- 3 Push  to enter the new setting.
The standby display reappears.

Items on the short menu

The short menu contains the following items:

- Message (see page 36)
- Ringer Vol (see page 44)
- My Number (see page 51)
- Phone List (see pages 28, 23, 31)
- Lock Phone (see page 59)
- Long Menu

Note


The item "Phone List" contains the items "Find Name" (see page 28), "Phone Book" (see page 23), and "Calls List" (see page 31).

To return to the long menu

On the short menu, turn  to select "Long Menu," then push .

Adjusting network settings

On the Network menu, you can set the phone to alert you when the roaming status changes, when a call is dropped, or when enhanced voice privacy is lost. You can set how NAM's (Number Assignment Modules) are switched, and also activate new services. NAM's are phone identifier numbers associated specifically with your phone. For example, you may have both a business phone number and also a personal phone number associated with your phone.




Network menu

Setting the roaming alert [F81]


Your phone is roaming when you use it outside of the home area. Roaming access to a different carrier and the types of calls you can make varies with the agreement between your "home" carrier and the currently serving carrier. Check with your service provider for details about roaming in a specific area.

- 1 Push to select "Roam Alert" from the Network menu.

The Roam Alert menu appears.



- 2 Turn to select "on" or "off."



- 3 Push to enter the new setting.

The standby display reappears.

When you enter another service area

The roaming icon () appears on the display. A beep accompanies the icon if you have turned the roam alert on.





If you leave any valid service area


The following display appears, indicating that you are outside the area serviced by your "home" carrier or other valid service areas. The out-of-service icon () also appears.





Setting the drop alert [F82]


If the signal fades, your phone may drop the ongoing call. You can choose to be alerted by an audible alarm when a call is dropped.



- 1 Turn  to select "Drop Alert" from the Network menu, then push .
The Drop Alert menu appears.




F82  
DROP ALERT
✓OFF
⏪: Choices
⏩: To Set

- 2 Turn  to select "on" or "off."






F82  
DROP ALERT
on
⏪: Choices
⏩: To Set

- 3 Push  to enter the new setting.
The standby display reappears.

When a call is dropped

The following display appears accompanied by a beep if drop alert has been turned on.





 
Time: 1:30
SIGNAL FADED
Your call
was lost.




Setting the voice privacy alert [F83]

A display appears to indicate if enhanced voice privacy is lost during a call. You can choose to have an audible alarm accompany this display.


- 1 Turn  to select "Priv. Alert" from the Network menu, then push .

The Priv. Alert menu appears.



```
F83 874 022
PRIV. ALERT
      ^OFF
(():Choices
+:To Set
```

- 2 Turn  to select "on" or "off."




```
F83 874 022
PRIV. ALERT
      on
(():Choices
+:To Set
```

- 3 Push  to enter the new setting.

The standby display reappears.

If enhanced voice privacy is lost


The following display appears accompanied by a beep if the voice privacy alert has been turned on.



```
874 022
Time: 1:30
Enhanced
Privacy was
just lost.
```

When enhanced voice privacy is regained

The following display appears accompanied by a beep if the voice privacy alert has been turned on.



```
-P-874 022
Time: 1:30
Enhanced
Privacy is
regained
```

Note

The network automatically turns on enhanced voice privacy if it is available. You do not have to change your phone settings. For details, contact your service provider.

Troubleshooting

Problem	Cause/Remedy	Page
Nothing appears on the display.	• The phone is off. Turn the phone on.	14
	• Battery is fully discharged. Recharge the battery.	12
The out-of-service icon (K) appears.	• The phone is outside the service area, or the signal is too weak. Extend the antenna fully.	14
	• Check NAM settings on the Network menu. If you set "Auto-NAM" to "off" and you are using two NAM's, the phone may be ignoring an available service.	68
Nothing happens when you press the buttons.	• The buttons may be locked.	57
	• The phone may be locked. Enter the lock code to unlock the phone.	59
The call does not go through.	• Check the signal strength.	14
	• If the out-of-service icon (K) is displayed, there is no service. See above.	14
	• Check the number.	16
	• Press (END).	16
	• Listen for a busy signal.	—
You can hear the other party, but the other party cannot hear you.	• The microphone may be muted. Unmute the microphone.	17, 45
You hear the other party only faintly.	• Adjust the earpiece volume. If possible, also reduce the noise around you.	17, 44
The call is cut off ("dropped").	• You are possibly out of the coverage area. Redial the number. If the problem continues, contact your carrier. Also see "The out-of-service icon (K) appears" above.	69
You hear an alternate high/low tone.	• You are attempting to use the phone in an area without service.	14
	• Extend the antenna fully.	14
	• Wait for the out-of-service icon to disappear, then try to dial.	14
You forgot the lock code.	• Try 0000, 1234 (commonly used as defaults), or the last four digits of your own number. • See your authorized dealer or service provider.	60 —
You hear a fast busy tone.	• The fast busy tone can result from any one of the following problems:	
	– The phone is improperly programmed.	—
	– The phone is out of range.	14
	– All channels are busy.	—
	– The antenna is broken or damaged.	14
You cannot place or receive calls.	• Make sure that the phone is turned on, and that the out-of-service icon is not displayed.	14
	• Check the system settings. If you are roaming, consult your service provider concerning roaming agreements.	—

Additional Information

List of menu items

This section lists the Features menu and its submenus. Use these to set the various parameters that pertain to the operation of the phone. For details on how to navigate from one menu to another, see "About the Features menus" on page 34.

Submenu	Menu Item	Settings	Page
F-1 Message	F11 Voice	—	37
	F12 New Text	—	39
	F13 Old Text	—	40
	F14 Erase Old	—	43
F-2 Sounds	F21 Ringer Vol	off / low / medium / high / escalating / vibration	44
	F22 Mute/UnMute	mutes or unmutes the microphone	45
	F23 Keybeep Vol	off / low / medium / high	47
	F24 Earpiece Vol	1 / 2 / 3 / 4 / 5 / 6 / 7	46
	F25 Ringer Type	standard / option 1 to 4	46
	F26 Key Sound	tones / clicks	47
	F27 Beep Length	standard / long	47
	F28 Message Ring	on / + reminder / off	48
F-3 Timers	F31 All Calls	total call time, number of calls	49
	F32 Recent Calls	total call time, number of calls 0 m 0 s 0 call	49
	F33 Minute Alert	on / off	50
	F34 Auto-Off	never / in 3 hours / in 2 hours / in 1 hour / in 30 mins	50
F-4 Directory	F41 My Number	—	51
	F42 Save	—	51
	F43 Erase	—	52
	F44 Edit	—	53
	F45 Find Name	—	54
	F46 Phone Book	No default entries	55
	F47 Calls List	No default entries	56
F-5 Extras	F51 Key Guard	—	57
	F52 Touch Dial	on / off	57
	F53 Auto-Retry	on / off	58
	F54 Scratch Pad	—	59

Submenu	Menu Item	Settings	Page
F-6 Security	F61 Lock Phone	never / on power-up / right now	59
	F62 New Code	0000	60
	F63 Restrict #	No default restricted numbers	60
	F64 Restrict All	on / off	61
	F65 Master Reset	—	62
	F66 Erase Book	—	62
	F67 Erase Calls	—	62
	F68 Emergency #	No default numbers for #1 to #3	63
F-7 Display	F71 Banner	No default banner	64
	F72 Backlight	off / for 7 secs / for 15 secs / for 30 secs / always on	65
	F73 Auto-hyphen	on / off	65
	F74 Sort Book	by loc. # / alphabetic	66
	F75 Menu Length	long / short	67
F-8 Network	F81 Roam Alert	on / off	68
	F82 Drop Alert	on / off	69
	F83 Priv. Alert	on / off	70

Additional
information

Specifications

Frequency range	Transmit: 1851.25 to 1908.75 MHz Receive: 1931.25 to 1988.75 MHz
Dimensions	XXX x XXX x XXX inches (h/w/d) (not including antenna) (100 x 50 x 25 mm)
Mass (weight)	Approx. XXX oz (160 g) (including battery)
RF power output	0.01 μ W to 300 mW
Operational temperature	-22°F to +140°F (-30°C to +60°C) (excluding battery pack)
Supplied Accessories	QN-029BPLH Hi-Cap Li-Ion Battery (1) QN-001AC AC Adapter (1) Hand strap (1)
Optional Accessories	TBD

Design and specifications are subject to change without notice.

Glossary

A

Automatic NAM

Feature that automatically selects an available NAM that matches the current serving system (carrier).

Automatic retry

Feature that automatically redials a call when a "System Busy" indication is received.

B

Banner

Message at the top of the standby display.

C

Calls List

See "Phone Book."

Carrier

A company that provides cellular and PCS telephone service.

CDMA

Code Division Multiple Access. A spread-spectrum approach to digital transmission. With CDMA, each conversation is digitized, and then tagged with a code. The mobile phone receives only the signal with the appropriate code.

Coverage area

The geographic area covered by one carrier. If you travel outside a carrier's area, you cannot receive service from that carrier. Also see "Roam."

D

Dropped call

A call terminated because of a deep, long fade or because the user left the coverage area.

DTMF

Dual Tone Multiple Frequency, also known as "touch-tone." Tone generated when you press a telephone button (number, #, or *). Can be used to access answering machines, pagers, telephone banking services, data services, and other electronic services.

E

ESN

Electronic Serial Number. The unique identification number of your telephone. The telephone transmits this number to the base station every time a call is placed.

Emergency number

In addition to the general emergency number (911 for the U.S.A. and Canada), three phone numbers can be stored as emergency numbers in your telephone. You can dial these numbers and 911 even when the phone is locked.

H

Home area

The area of the home system to which you subscribe.

I

Incoming call

A call received by your telephone.

L

Lock

Prevents unauthorized calls by requiring the user to enter a code to use the phone. Even if the phone is locked, you can call any of the emergency numbers or answer incoming calls.

Additional
Information

M

Memory

A storage area for names and phone numbers. Also see "Phone Book."

Menu

The menu allows you to change or see the settings of your phone. You can access it from the standby display or during a call. See "List of menu items" on pages 72 and 73 for an overview of this feature.

Minute alert

This alert beeps periodically during a call to help you keep track of the length of the call.

N

NAM

Number Assignment Module. Portion of your telephone's memory programmed to contain information about your subscription to the carrier. Your telephone can have up to two NAM's.

P

Pause

You can enter pause codes in the phone number memory data. Use this feature when accessing an answering machine, voice mail system, electronic banking system, etc. When a pause is inserted between two groups of digits, the phone will pause before dialing the next set of digits, allowing you to wait until your counterpart is ready to accept the string.

Phone Book

You can store up to 99 numbers in Phone Book memory, location number 01 to number 99. An additional recent number memory (Calls List) stores the last ten used phone numbers.

R

Roam

Your phone is roaming when you use it outside of the home area. Availability of roaming access to a different carrier and types of calls you can make varies with the agreement between your home carrier and serving carrier. Check with your carrier for details about roaming in a specific area.

S

Scratch pad

Allows you to enter a number and store it in the Calls List.

Service area

Region covered by a cellular/PCS service. Also see "Coverage area."

SMS

Short Messaging Service. An extended service offered by carriers that allows you to receive text messages on your phone. Check with your carrier for details.

Speed dialing

Making a call using Phone Book memory locations. Also see "Phone Book."



T

Touch dialing

A quick way of making a call using a number stored in a Phone Book memory location. Also see "Speed dialing."

Touch-tone

See "DTMF."

V

Voice mail

An extended service, offered by carriers, that allows you to retrieve voice mail messages stored in your voice mailbox. Check with your carrier for details.

Volume

You can adjust the volume of keybeep, ringer, and earpiece.



Additional
Information



Index

A

- AC adapter 8, 12
- Antenna 14
- Arm microphone 9
- Automatic
 - Hyphenation 65
 - Retry 58
 - Redial 58

B

- Backlight 65
- Banner 64
- Battery pack
 - Charging 11
 - Checking 13
 - Attaching/removing 11
- Battery charge contacts 11
- Battery pack release tab 11
- Battery icon 10, 12, 13

C

- Calling
 - Calls List 31, 56
 - Dropped call 69
 - Ending calls 16, 18
 - Making calls 16
 - Receiving calls 18
 - Recent number 31
 - Redialing 17, 58
 - Restrictions 25, 60
 - Roaming 68
 - Speed dialing 27
 - Touch dialing 27, 57
- Carrier 68,
- CDMA (Code Division Multiple Access) 4
- Character display 10
- Clearing. *See* Deleting
- Coverage area 68
- Cursor 20, 51

D

- Dialing. *See* Calling
- Deleting
 - Calls List entries 62
 - Characters 20, 51
 - Message 43
 - Phone Book entries 24, 52
 - Phone numbers 24, 52
 - Voice mail 37, 38
- Digital icon 10
- Display 10
- Display settings
 - Accessing 34
 - Autohyphenation 65
 - Backlight 65
 - Banner 64
 - Time 49
- Displays
 - Calling 16
 - Features menu 34
 - Menu setting 67
 - Hyphens/pauses/links 22
 - Security 59
 - Standby 14
- Dropped call 69
- DTMF (Dual Tone Multiple Frequency) 33

E

- Earpiece 17, 46
- Editing
 - Emergency numbers 63
 - Phone numbers 23, 53
- Emergency numbers 63
- Enabling
 - Lock 57
 - Touch dialing 27, 57
- Ending a call 16, 18
- Entering
 - Hyphens 22
 - Links 22
 - Pauses 22
- Erasing. *See* Deleting
- ESN (Electronic Serial Number) 75

F

Finding. *See* Searching

H

Hand strap
 Attaching 8
Hyphens
 Autohyphenation 65
 Entering manually 22

I

Incoming call 18
In-use icon 10, 16, 18

K

Keybeep 47

L

Laws
 Rules and regulations 3
Lock code 60

M

Making calls 16
Manual
 Answer 18
 Call 16
 Hyphenation 22
 Redial 17
Memory
 Deleting 24, 52
 Editing 24, 53
 Number searching 29, 30, 55
 Storing 20, 51

Menus

 Accessing 34
 Message button 10, 36
 Message icon 10, 37
 Messages
 Calling back 38
 Displaying 38, 39
 Erasing 38, 43
 Locking 41
 Message list 36
 Receiving 36
 Microphone 17, 44
 Minute alert 50
 Muting the microphone 17, 45

N

NAM (Number Assignment
Module) 68
Number buttons 16, 20

O

Out-of-service icon 14, 68
Overflow digits
 Viewing 26

P

Pause 22
Phone Book 20, 26, 28, 51
Power
 Turning off 14
 Turning on 14

Q

Quitting. *See* Power

Additional
Information

R

- Receiving
 - Calls 18
 - Messages 36
 - Voice mail 37
- Recent number memory
 - Calling recent numbers 31
 - Clearing call memory 62
- Redialing
 - Auto retry 58
 - Last dialed number 17
- Restriction 25, 60
- Ringer
 - Volume 44
- Roam 68
- Roam icon 68
- Roaming agreement 68
- Rules and regulations 3

S

- Safety precautions 4
- Scratch pad 58
- Scrolling
 - Menus 15
 - Message 37, 39
 - Message list 40
- Searching
 - For a name 28, 29, 54
 - For a number 29, 30
 - For a message 40
- Security code. *See* Security functions
- Security functions
 - Accessing 59
 - Clearing call memory 62
 - Emergency numbers 63
 - Lock mode 59
 - New lock code 60
 - Restriction 60

- Sending. *See* Calling
- Service area 68
- Signal strength icon 14
- Special characters 21
- Special features
 - Accessing 57
 - Changing DTMF transmission 47
 - Enabling touch dialing 27, 57
 - Muting the microphone 44, 45
 - Using the scratch pad 58
 - Setting auto-retry 58
- Standby display 14
- System settings
 - Accessing 68

T

- Text Message. *See* Messages
- Touch dialing
 - Enabling 27, 57
- Troubleshooting 71
- Turning phone on 14

V

- Voice mail notification
 - Accessing 37
 - Receiving 36
- Voice Privacy 70
- Volume
 - Adjusting 44



Additional
Information





SONY Wireless Hotline Number (USA only)

If you have any questions or comments, please call:
SONY WIRELESS HOTLINE
1-800-578-SONY (7669)

© 1997 Sony Electronics Incorporated

Printed in U.S.A.



