



















Technical Information

Micropilot FMR56, FMR57

Level radar Level measurement in bulk solids



Application

Continuous, non-contact level measurement in powdery to granular bulk solids

Features FMR56:

- Attractively-priced basic device for standard process conditions, as for example in bulk cargo silos and storage tanks
- PP-cladded horn antenna
- Maximum measuring range: 30 m (98 ft)
- Process connection: Mounting bracket or slip-on flange with variable flange seal for alignment
- Temperature range: -40 to +80 °C (-40 to 176 °F)
- Pressure range: -1 to +3 bar (-14.5 to +43.5 psi)
- Accuracy: ± 3 mm

Features FMR57:

- Premium device for highly demanding solid applications; ideally suited for measurements in high silos, bunkers and stockpiles
- Horn or parabolic antenna
- Air purge connection integrated
- Maximum measuring range: 70 m (230 ft)
- Process connection: 1½" thread or flange
- Temperature range: -40 to +400 °C (-40 to 752 °F)
- Pressure range: -1 to +16 bar (-14.5 to +232 psi)
- Accuracy: ± 3 mm

Your benefits

- Reliable measurement even for changing product and process conditions
- Integrated data memory (HistoROM) for high availability
- Intuitive operating menu in national languages for easy commissioning
- Simple integration into control or asset management systems
- Exact diagnostic and process information to assist fast decisions
- International approvals for use in hazardous areas
- 5-point linearity protocol
- SIL2 according to IEC 61508, SIL3 in case of homogeneous or heterogeneous redundancy
- System integration via HART/PROFIBUS PA (Profile 3.02)/FOUNDATION Fieldbus



Table of contents

| Important document information 3 Document conventions 3 | P r Pr Pr |
|---|---|
| Function and system design5Measuring principle5 | D: |
| Input7Measured variable7Measuring range7Operating frequency8Transmitting power8 | Di W M |
| Output9Output signal9Signal on alarm10Linearization10Galvanic isolation10Protocol-specific data10 | Lo Og Re Sy C |
| Power supply14Terminal assignment14Device plug connectors21Supply voltage22Power consumption24Current consumption24Power supply failure25Potential equalization25Terminals25Cable entries25Cable specification25Overvoltage protection26 | C- Ex D' Fu Al Pr M Ra Ra FO C! Tr |
| Performance characteristics27Reference operating conditions27Maximum measured error27Measured value resolution27Reaction time28Influence of ambient temperature28Installation29Installation conditions29Measuring conditions36Installation in vessel (free space)37Vessels with heat insulation46 | OOD OOD SECOND OOD OOD OOD OOD OOD OOD OOD OOD OOD |
| Environment47Ambient temperature range47Ambient temperature limits47Storage temperature51Climate class51Geometric height according to IEC61010-1 Ed.351Degree of protection51Vibration resistance51Cleaning the antenna51Electromagnetic compatibility (EMC)52 | St Su Sa Ro |

| Process Process temperature range Process pressure range Dielectric constant | 53 53 53 53 |
|--|--|
| Mechanical construction Dimensions | 54 54 61 62 |
| Operability | 67 67 68 68 72 |
| Certificates and approvals CE mark C-Tick symbol Ex approval Dual seal according to ANSI/ISA 12.27.01 Functional Safety AD2000 Pressure Equipment Directive Marine certificate (in preparation) Radio standard EN302729-1/2 Radio standard EN302372-1/2 FCC / Industry Canada CRN approval Track record Other standards and guidelines | 73 73 73 73 73 73 73 73 73 74 74 75 75 |
| Ordering information | 76 76 76 77 |
| Accessories Device-specific accessories Communication-specific accessories Service-specific accessories System components | 78 78 81 82 83 |
| Documentation Standard documentation Supplementary documentation Safety Instructions (XA) | 84 84 84 84 |
| Registered trademarks | 86 |
| Patents | 86 |

Important document information

Document conventions

Safety symbols

| Symbol | Meaning | |
|-----------------------|---|--|
| A0011189-EN | DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury. | |
| WARNING A0011190-EN | WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. | |
| CAUTION A0011191-EN | CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury. | |
| NOTICE A0011192-EN | NOTICE! This symbol contains information on procedures and other facts which do not result in personal injury. | |

Electrical symbols

| Symbol | Meaning | | |
|--|---|--|--|
| Direct current A terminal to which DC voltage is applied or through which direct current flows. | | | |
| A0011198 | Alternating current A terminal to which alternating voltage is applied or through which alternating current flows. | | |
| Direct current and alternating current A terminal to which alternating voltage or DC voltage is applied. A terminal through which alternating current or direct current flows. | | | |
| | Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system. | | |
| A0011199 | Protective ground connection A terminal which must be connected to ground prior to establishing any other connections. | | |
| A0011201 | Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice. | | |

Symbols for certain types of information

| | Symbol | Meaning | |
|--|--|--|--|
| Allowed Indicates procedures, processes or actions that are allowed. | | 1 | |
| | Preferred Indicates procedures, processes or actions that are preferred. | | |
| | A0011184 | Forbidden Indicates procedures, processes or actions that are forbidden. | |
| | A0011193 | Tip Indicates additional information. | |
| | A0011194 | Reference to documentation Refers to the corresponding device documentation. | |

| Symbol | Meaning |
|----------|--|
| A0011195 | Reference to page Refers to the corresponding page number. |
| A0011196 | Reference to graphic Refers to the corresponding graphic number and page number. |

Symbols in graphics

| Symbol | Meaning |
|----------------|--|
| 1, 2, 3 | Item numbers |
| 1. , 2. , 3 | Series of steps |
| A, B, C, | Views |
| A-A, B-B, C-C, | Sections |
| A0011187 | Hazardous area Indicates a hazardous area. |
| A0011188 | Safe area (non-hazardous area) Indicates a non-hazardous location. |

Symbols at the device


| Symbol | Meaning |
|---------------------|---|
| ↑ → 1 | Safety instructions Observe the safety instructions contained in the associated Operating Instructions. |
| | Temperature resistance of the connection cables Specifies the minimum value of the temperature resistance of the connection cables. |



Function and system design

Measuring principle

The Micropilot is a "downward-looking" measuring system, operating based on the time-of-flight method (ToF). It measures the distance from the reference point (process connection) to the product surface. Radar impulses are emitted by an antenna, reflected off the product surface and received again by the radar system.



Δ001787

- Setup parameters of the Micropilot
- R Reference point of the measurement (lower edge of the flange or threaded connection)
- E Empty calibration (= zero)
- F Full calibration (= span)
- D Measured distance
- L Level (L = E D)

Input

The reflected radar impulses are received by the antenna and transmitted into the electronics. A microprocessor evaluates the signal and identifies the level echo caused by the reflection of the radar impulse at the product surface. The unambiguous signal identification is accomplished by the PulseMaster® eXact software together with the Multi–echo tracking algorithms, based on many years of experience with time–of-flight technology.

The distance D to the product surface is proportional to the time of flight t of the impulse:

$$D = c \cdot t/2$$

with c being the speed of light.

Based on the known empty distance E, the level L is calculated:

$$L = E - D$$

The reference point R of the measurement is located at the process connection. For details see the dimensional drawing:

- FMR56: (→ 🖹 55)
- FMR57: (→ 🖹 58)

The Micropilot is equipped with functions to suppress interference echoes. The user can activate these functions. Together with the multi-echo tracking algorithms they ensure that interference echoes (i.e. from edges and weld seams) are not interpreted as level echo.


Endress+Hauser V. 1, Rev. 6, 19-10-2012 5

Output

The Micropilot is commissioned by entering an empty distance "E" (=zero), a full distance "F" (=span) and application parameters. The application parameters are automatically adapt into the instrument to the process conditions. For models with a current output, the factory adjustment for zero point "E" and span "F" is 4 mA and 20 mA. For digital outputs and the display module, the factory adjustment for zero point "E" and span "F" is 0 ma and 0 ma.

A linearization with max. 32 points, based on a table entered either manually or semi-automatically, can be activated locally or remotely. This function provides a measurement in engineering units and a linear output signal for spheres, horizontal cylindrical tanks and vessels with conical outlet.

Life cycle of the product



2 Life cycle

Engineering

- Universal measuring principle
- Measurement unaffected by medium properties
- Hardware and software developed according to SIL IEC 61508

Procurement

- Endress+Hauser being the world market leader in level measurement guarantees asset protection
- lacktriangle Worldwide support and service

Installation

- Special tools are not required
- Reverse polarity protection
- Modern, detachable terminals
- $\ \blacksquare$ Main electronics protected by a separate connection compartment

Commissioning

- Fast, menu-guided commissioning in only a few steps on site or from the control room
- Plain text display in national languages reduces the risk of error or confusion
- Direct local access of all parameters
- Short instruction manual at the device

Operation

- Multi-echo tracking: Reliable measurement through self-learning echo-search algorithms taking into
 account the short-term and long-term history in order to check the found echoes for plausibility and to
 suppress interference echoes.
- Diagnostics in accordance with NAMUR NE107

Maintenance

- HistoROM: Data backup for instrument settings and measured values
- Exact instrument and process diagnosis to assist fast decisions with clear details concerning remedies
- Intuitive, menu-guided operating concept in national languages saves costs for training, maintenance and operation
- Cover of the electronics compartment can be opened in hazardous areas

Retirement

- Order code translation for subsequent models
- RoHS-conforming (Restriction of certain Hazardous Substances), unleaded soldering of electronic components
- Environmentally sound recycling concept

Input

Measured variable

The measured variable is the distance between the reference point and the product surface.

Subject to the empty distance entered "E" the level is calculated.

Alternatively, the level can be converted into other variables (volume, mass) by means of linearization (32 points).

Measuring range

Maximum measuring range

| Device | Maximum measuring range | |
|--------|-------------------------|--|
| FMR56 | 30 m (98 ft) | |
| FMR57 | 70 m (230 ft) | |

Usable measuring range

Reduction of the max. possible measuring range through:

- Media with poor reflection properties (= small DC). For examples refer to table below.
- Angle of repose
- Extremely loose surfaces of bulk solids, e.g. bulk solids with low bulk weight for pneumatic filling.
- Build-up, above all of moist products.

| Media group | DK (ε _r) | Examples | Signal attenuation |
|-------------|----------------------|--|--------------------|
| A | 1.6 to 1.9 | Plastic granulateWhite lime, special cementSugar | 19 to 16 dB |
| В | 1.9 to 2.5 | Portland cement, plaster | 16 to 13 dB |
| С | 2.5 to 4 | Grain, seedsGround stonesSand | 13 to 10 dB |
| D | 4 to 7 | Naturally moist (ground) stones, oreSalt | 10 to 7 dB |
| E | >7 | Metallic powderCarbon blackCoal | < 7 dB |

The respective lower group applies for very loose or loosened bulk solids.



Operating frequency

K-band (~ 26 GHz)

Up to 8 Micropilot transmitters can be installed in the same tank because the transmitter pulses are statistically coded.

Transmitting power

8

| Distance | Average energy density in beam direction | |
|--------------|--|--|
| 1 m (3.3 ft) | < 64 nW/cm ² | |
| 5 m (16 ft) | < 2.5 nW/cm ² | |



Output

Output signal

HART

| Signal coding | FSK ±0.5 mA over current signal |
|------------------------|---------------------------------|
| Data transmission rate | 1 200 Bit/s |
| Galvanic isolation | Yes |

PROFIBUS PA (in preparation)

| Signal coding | Manchester Bus Powered (MBP) |
|------------------------|------------------------------|
| Data transmission rate | 31.25 kBit/s, voltage mode |
| Galvanic isolation | Yes |

FOUNDATION Fieldbus (in preparation)

| Signal coding | Manchester Bus Powered (MBP) | | |
|------------------------|------------------------------|--|--|
| Data transmission rate | 31.25 kBit/s, voltage mode | | |
| Galvanic isolation | Yes | | |

Switch output



For HART devices, the switch output is available as an option. See product structure, feature 20: "Power Supply, Output", option B: "2-wire; 4-20mA HART, switch output"

Devices with PROFIBUS PA and FOUNDATION Fieldbus always have a switch output.

| Switch output | | |
|-----------------------------------|--|--|
| Function | Open collector switching output | |
| Switching behavior | Binary (conductive or non-conductive), switches when the programmable switch point reached | |
| Failure mode | non-conductive | |
| Eectrical connection values | U = 10.4 to 35 V _{DC} , I = 0 to 40 mA | |
| Internal resistance | $R_{l} < 880\;\Omega$ The voltage drop at this internal resistance has to be taken into account on planning the configuration. For example, the resulting voltage at a connected relay must be sufficient to switch the relay. | |
| Insulation voltage | floating, Insulation voltage 1 350 V_{DC} to power supply aund 500 V_{AC} to ground | |
| Switch point | freely programmable, separately for switch-on and switch-off point | |
| Switching delay | freely programmable from 0 to 100 sec. , separately for switch-on and switch-off point | |
| Number of switching cycles | corresponds to the measuring cycle | |
| Signal source device variables | Level linearized Distance Terminal voltage Electronic temperature Relative echo amplitude Diagnostic values, Advanced diagnostics | |
| Number of switching cycles | unlimited | |

Endress+Hauser V. 1, Rev. 6, 19-10-2012 9

Signal on alarm

Depending on the interface, failure information is displayed as follows:

- Current output (for HART devices)
 - Failsafe mode selectable (in accordance with NAMUR Recommendation NE 43):
 Minimum alarm: 3.6 mA
 - Maximum alarm (= factory setting): 22 mA
 - Failsafe mode with user-selectable value: 3.59 to 22.5 mA
- Local display
 - Status signal (in accordance with NAMUR Recommendation NE 107)
 - Plain text display
- Operating tool via digital communication (HART, PROFIBUS PA, FOUNDATION Fieldbus) or service interface (CDI)
 - Status signal (in accordance with NAMUR Recommendation NE 107)
 - Plain text display

Linearization

The linearization function of the device allows the conversion of the measured value into any unit of length or volume. Linearization tables for calculating the volume in cylindrical tanks are pre-programmed. Other tables of up to 32 value pairs can be entered manually or semi-automatically.

Galvanic isolation

All circuits for the outputs are galvanically isolated from each other.

Protocol-specific data

HART

| Manufacturer ID | 17 (0x11) | |
|------------------------------------|--|--|
| Device type ID | 41 (0x28) | |
| HART specification | 6.0 | |
| Device description files (DTM, DD) | Information and files under: ■ www.endress.com ■ www.hartcomm.org | |
| HART load | Min. 250 Ω | |
| HART device variables | The measured values can be freely assigned to the device variables. | |
| | Measured values for PV (primary variable) ■ Level linearized ■ Distance ■ Electronic temperature ■ Relative echo amplitude ■ Analog output adv. diagnostics | |
| | Measured values for SV, TV, FV (second, third and fourth variable) Level linearized Distance Terminal voltage Electronic temperature Absolute echo amplitude Relative echo amplitude Area of incoupling | |
| Supported functions | Burst modeAdditional transmitter status | |

PROFIBUS PA (in preparation)

| Manufacturer ID | 17 (0x11) | |
|------------------|--|--|
| Ident number | 0x1559 | |
| Profile version | 3.02 | |
| GSD file | Information and files under: | |
| GSD file version | www.endress.comwww.profibus.org | |

| Output values | Analog Input: Level linearized Distance Terminal voltage Electronic temperature Absolute echo amplitude Relative echo amplitude Digital Input: | | |
|---------------------|---|--|--|
| | Extended diagnostic blocksStatus output PFS Block | | |
| Input values | Analog Output: ■ Analog value from PLC (for sensor block external pressure and temperature) ■ Analog value from PLC to be indicated on the display | | |
| | Digital Output: Extended diagnostic block Level limiter Sensor block measurement on Sensor block save history on Status output | | |
| Supported functions | Identification & Maintenance Einfachste Geräteidentifizierung seitens des Leitsystems und des Typenschildes Automatic Ident Number Adoption GSD compatibility mode with respect to the preceding product Micropilot M FMR2xx Physical Layer Diagnostics Installation check of the PRFIBUS segment and the Micropilot FMR5x via the terminal voltage and telegram surveillance. PROFIBUS Up-/Download Up to 10 times faster writing and reading of parameters via PROFIBUS up-/ download Condensed Status Simple and self-explanatory diagnostic information by categorization of occurring diagnostic messages. | | |

FOUNDATION Fieldbus (in preparation)

| 0x452B48 | |
|--|--|
| 0x1028 | |
| 0x01 | |
| Information and files can be found: | |
| www.endress.comwww.fieldbus.org | |
| 6.0.1 | |
| IT085300 | |
| yes | |
| yes; default: Basic Device | |
| Default: 247 (0xF7) | |
| Following methods are supported: Restart ENP Restart Setup Linearization Self Check | |
| nships (VCRs) | |
| 44 | |
| 50 | |
| | |

| Permanent entries | 1 |
|--------------------------|----|
| Client VCRs | 0 |
| Server VCRs | 10 |
| Source VCRs | 43 |
| Sink VCRs | 0 |
| Subscriber VCRs | 43 |
| Publisher VCRs | 43 |
| Device Link Capabilities | |
| Slot time | 4 |
| Min. inter PDU delay | 8 |
| Max. response delay | 20 |

Transducer Blocks

| Block | Content | Output values | |
|--|---|--|--|
| Setup Transducer Block | Contains all parameters for a standard commissioning procedure | ■ Level or volume ¹⁾ (Channel 1) ■ Distance (Channel 2) | |
| Advanced Setup Transducer Block | Contains all parameters for a more detailed configuration of the device | no output values | |
| Display Transducer Block | Contains all parameters for the configuration of the display module | no output values | |
| Diagnostic Transducer Block | Contains diagnostic information | no output values | |
| Expert Configuration Transducer Block | Contains parameters which require detailed knowledge of the functionalities of the device | no output values | |
| Expert Information Transducer Block | Contains information about the state of the device | no output values | |
| Service Sensor Transducer Contains parameters which can only be operated by Endress+Hauser service personnel | | no output values | |
| Service Information Transducer Block | Contains information on the state of device which is relevant for service operations | no output values | |
| Data Transfer Transducer Block | Contains parameters which allow to Sacrap are device | | |

1) depending on the configuration of the block

Function Blocks

12

| Block | Content | Number of permanent blocks | Number of instantiable blocks | Execution time | Functionality |
|-----------------------------------|---|----------------------------|-------------------------------|----------------|---------------|
| Resource Block | The Resource Block contains all the data that uniquely identifies the field device. It is an electronic version of a nameplate of the device. | 1 | 0 | - | enhanced |
| Multiple Analog Input Block | The AI block takes the manufacturer's input data, selected by channel number, and makes it available to other function blocks at its output. | 2 | 3 | 25 ms | enhanced |
| Discrete Input Block | The DI block takes a discrete input value (e.g. indication of an level limit), and makes it available to other function blocks at its output. | 1 | 2 | 20 ms | standard |

| Block | Content | Number of permanent blocks | Number of instantiable blocks | Execution time | Functionality |
|----------------------------------|--|----------------------------|-------------------------------|----------------|---------------|
| PID Block | The PID block serves as proportional-integralderivative controller and is used almost universally to do closed-loop-control in the field including cascade and feedforward. | 1 | 1 | 25 ms | standard |
| Arithmetic Block | This block is designed to permit simple use of popular measurement math functions. The user does not have to know how to write equations. The math algorithm is selected by name, chosen by the user for the function to be done. | 1 | 1 | 25 ms | standard |
| Signal Characterizer Block | The signal characterizer block has two sections, each with an output that is a non-linear function of the respective input. The non-linear function is determined by a single look-up table with 21 arbitrary x-y pairs. | 1 | 1 | 25 ms | standard |
| Input Selector Block | The input selector block provides selection of up to four inputs and generates an output based on the configured action. This block normally receives its inputs from AI blocks. The block performs maximum, minimum, middle, average and 'first good' signal selection. | 1 | 1 | 25 ms | standard |
| Integrator Block | The Integrator Function Block integrates a variable as a function of the time or accumulates the counts from a Pulse Input block. The block may be used as a totalizer that counts up until reset or as a batch totalizer that has a setpoint, where the integrated or accumulated value is compared to pre-trip and trip settings, generating discrete signals when these settings are reached. | 1 | 1 | 25 ms | standard |
| Analog Alarm Block | | 1 | 1 | 25 ms | standard |

Up to 20 blocks can be instantiated in the device altogether, including the blocks already instantiated on delivery.


Endress+Hauser V. 1, Rev. 6, 19-10-2012 13

Power supply

Terminal assignment


14

2-wire: 4-20mA HART



- ☐ 3 Terminal assignment 2-wire; 4-20mA HART
- A Without integrated overvoltage protection
- B With integrated overvoltage protection
- 1 Active barrier with power supply (e.g. RN221N): Observe terminal voltage ($\rightarrow \stackrel{ }{=} 22$)
- HART communication resistor (\geq 250 Ω): Observe maximum load (\rightarrow $\stackrel{\triangle}{=}$ 22)
- 3 Connection for Commubox FXA195 or FieldXpert SFX100 (via VIATOR Bluetooth modem)
- Analog display device: Observe maximum load ($\rightarrow \stackrel{\triangle}{=} 22$)
- *Cable screen; observe cable specification* ($\rightarrow \stackrel{\triangle}{=} 25$)
- 6 Terminals for 4-20mA HART (passive)
- 7 Overvoltage protection module
- 8 Terminal for potential equalization line
- 9 Cable entry

2-wire: 4-20mA HART, switch output




Terminal assignment 2-wire; 4-20mA HART, switch output

- A Without integrated overvoltage protection
- B With integrated overvoltage protection
- 1 Active barrier with power supply (e.g. RN221N): Observe terminal voltage ($\rightarrow \stackrel{\square}{=} 22$)
- 2 HART communication resistor (\geq 250 Ω): Observe maximum load (\rightarrow $\stackrel{\triangle}{=}$ 22)
- 3 Connection for Commubox FXA195 or FieldXpert SFX100 (via VIATOR Bluetooth modem)
- Analog display device: Observe maximum load ($\rightarrow \stackrel{\triangle}{=} 22$)
- Cable screen; observe cable specification ($\rightarrow \stackrel{\triangle}{=} 25$)
- 6 Terminals for 4–20mA HART (passive)
- 7 Terminals for switch output (open collector)
- 8 Terminal for potential equalization line
- 9 Cable entry for 4-20mA HART line
- 10 Cable entry for switch output line
- 11 Overvoltage protection module

Endress+Hauser V. 1, Rev. 6, 19-10-2012 15

2-wire: 4-20mA HART, 4-20mA




☑ 5 Terminal assignment 2-wire, 4-20 mA HART, 4...20mA

- A Without integrated overvoltage protection
- B With integrated overvoltage protection
- 1 Connection current output 2
- 2 Connection current output 1
- 3 Supply voltage for current output 1 (e.g. RN221N); Observe terminal voltage ($\rightarrow \stackrel{\triangle}{=} 23$)
- 4 Cable screen; observe cable specification ($\rightarrow \stackrel{\triangle}{=} 25$)
- 5 HART communication resistor ($\geq 250 \,\Omega$): Observe maximum load ($\rightarrow \stackrel{\triangle}{=} 23$)
- 6 Connection for Commubox FXA195 or FieldXpert SFX100 (via VIATOR Bluetooth modem)
- 7 Analog display device ; observe maximum load (→ 🖹 23)
- 8 Analog display device; observe maximum load ($\rightarrow \stackrel{\triangle}{=} 23$)
- 9 Supply voltage for current output 2 (e.g. RN221N); Obesrve terminal voltage ($\rightarrow \stackrel{\square}{=} 23$)
- 10 Overvoltage protection module
- 11 Terminals for current output 2
- 12 Terminal for the potential equalization line
- 13 Cable entry for current output 1
- 14 Cable entry for current output 2

This version is also suited for single-channel operation. In this case, current output 1 (terminals 1 and 2) must be used.

4-wire: 4-20mA HART (10.4 to 48 V_{DC})



- 6 Terminal assignment 4-wire; 4-20mA HART (10.4 to 48 VDC)
- 1 Evaluation unit, e.g. PLC
- *2* HART communication resistor (\geq 250 Ω): Observe maximum load (\rightarrow $\stackrel{\triangle}{=}$ 24)
- 3 Connection for Commubox FXA195 or FieldXpert SFX100 (via VIATOR Bluetooth modem)
- 4 Analog display device: Observe maximum load ($\rightarrow 24$)
- Signal cable including screening (if required), observe cable specification ($\rightarrow \stackrel{\triangle}{=} 25$)
- 6 Protective connection; do not disconnect!
- Protective earth, observe cable specification (\rightarrow $\stackrel{ }{=}$ 25)
- 8 Terminals for 4...20mA HART (active)
- 9 Terminals for supply voltage
- 10 Supply voltage: Observe terminal voltage (\rightarrow $\stackrel{\triangle}{=}$ 24), observe cable specification (\rightarrow $\stackrel{\triangle}{=}$ 25)
- 11 Terminal for potential equalization
- 12 Cable entry for signal line
- 13 Cable entry for power supply


ACAUTION

To ensure electrical safety:

- ▶ Do not disconnect the protective connection (7).
- ▶ Disconnect the supply voltage before disconnecting the protective earth (8).
- Connect protective earth to the internal ground terminal (8) before connecting the supply voltage. If necessary, connect the potential matching line to the external ground terminal (12).
- In order to ensure electromagnetic compatibility (EMC): Do not only ground the device via the protective earth conductor of the supply cable. Instead, the functional grounding must also be connected to the process connection (flange or threaded connection) or to the external ground terminal.
- An easily accessible power switch must be installed in the proximity of the device. The power switch must be marked as a disconnector for the device (IEC/EN61010).

Endress+Hauser V. 1, Rev. 6, 19-10-2012 17

4-wire: 4-20mA HART (90 to 253 V_{AC})



7 Terminal assignment 4-wire; 4-20mA HART (90 to 253 VAC)

- 1 Evaluation unit, e.g. PLC
- 2 HART communication resistor ($\geq 250 \,\Omega$): Observe maximum load ($\rightarrow \stackrel{\triangleright}{=} 24$)
- 3 Connection for Commubox FXA195 or FieldXpert SFX100 (via VIATOR Bluetooth modem)
- *Analog display device: Observe maximum load* ($\rightarrow \stackrel{\triangle}{=} 24$)
- Signal cable including screening (if required), observe cable specification ($\rightarrow \stackrel{\triangle}{=} 25$)
- 6 Protective connection; do not disconnect!
- 7 Protective earth, observe cable specification ($\rightarrow \stackrel{\triangle}{=} 25$)
- 8 Terminals for 4...20mA HART (active)
- 9 Terminals for supply voltage
- 11 Terminal for potential equalization
- 12 Cable entry for signal line
- 13 Cable entry for power supply


ACAUTION

18

To ensure electrical safety:

- ▶ Do not disconnect the protective connection (7).
- ▶ Disconnect the supply voltage before disconnecting the protective earth (8).
- Connect protective earth to the internal ground terminal (8) before connecting the supply voltage. If necessary, connect the potential matching line to the external ground terminal (12).
- In order to ensure electromagnetic compatibility (EMC): Do not only ground the device via the protective earth conductor of the supply cable. Instead, the functional grounding must also be connected to the process connection (flange or threaded connection) or to the external ground terminal.
- An easily accessible power switch must be installed in the proximity of the device. The power switch must be marked as a disconnector for the device (IEC/EN61010).

PROFIBUS PA / FOUNDATION Fieldbus (in preparation)



- Terminal assignment PROFIBUS PA / FOUNDATION Fieldbus
- Without integrated overvoltage protection
- With integrated overvoltage protection
- Cable screen: Observe cable specifications ($\rightarrow 25$)
- Terminals for switch output (open collector)
 Terminals PROFIBUS PA / FOUNDATION Fieldbus
- Terminal for potential equalization line
- Cable entries
- Overvoltage protection module

Endress+Hauser V. 1, Rev. 6, 19-10-2012 19


Connection examples for the switch output

i

20

For HART devices, the switch output is available as an option. See product structure, feature 20: "Power Supply, Output", option B: "2-wire; 4-20mA HART, switch output"

Devices with PROFIBUS PA and FOUNDATION Fieldbus always have a switch output.




Device plug connectors



For the versions with fieldbus plug connector (M12 or 7/8"), the signal line can be connected without opening the housing.

Pin assignment of the M12 plug connector



Pin assignment of the 7/8" plug connector





Supply voltage

An external power supply is required.



Various supply units can be ordered from Endress+Hauser: see "Accessories" section ($\rightarrow \blacksquare 83$)

2-wire, 4-20mA HART, passive

| "Power Supply, Output" 1) | "Approval" 2) | Terminal voltage U at the device | Maximum load R, depending on the supply voltage \mathbf{U}_0 at the supply unit | |
|---|---|----------------------------------|---|--|
| A: 2-wire; 4-20mA HART | Non-ExEx nAEx icCSA GP | 10.4 to 35 V ³⁾ | R [Ω] 500 | |
| | Ex ia / IS | 10.4 to 30 V ³⁾ | 0 10 10.4 20 21.4 30 35 U ₀ [V] | |
| ■ Ex d(ia) / XP ■ Ex ic(ia) ■ Ex nA(ia) ■ Ex ta / DIP | | | | |
| | Ex ia + Ex d(ia) / IS + XP | 12 to 30 V ⁴⁾ | 0 10 20 30 35 U ₀ [V] | |

- 1) Feature 020 of the product structure
- 2) Feature 010 of the product structure
- For ambient temperatures $T_a \le -20$ °C (-4 °F) a minimum voltage of 15 V is required for the sartup of the device at the MIN error current (3,6 mA). The startup current can be parametrized. If the device is operated with a fixed current $I \ge 5,5$ mA (HART multidrop mode), a voltage of $U \ge 10,4$ V is sufficient throughout the entire range of ambient temperatures.
- 4) For ambient temperatures $T_a \le -20$ °C (-4 °F) a minimum voltage of 16 V is required for the satrtup of the device at the MIN error current (3.6 mA).

| "Power Supply, Output" 1) | "Approval" 2) | Terminal voltage U at the device | $\label{eq:maximum load R} \mbox{Maximum load R, depending on the supply voltage U_0 at the supply unit}$ |
|---|--|----------------------------------|---|
| B: 2-wire; 4-20 mA HART, switch output | Non-Ex Ex nA Ex nA(ia) Ex ic Ex ic(ia) Ex d(ia) / XP Ex ta / DIP CSA GP | 12 to 35 V ³⁾ | R [Ω] 500 |
| | ■ Ex ia / IS ■ Ex ia + Ex d(ia) / IS + XP | 12 to 30 V ³ | 0 10 20 30 35 U ₀ [V] 12 23 A0019136 |

- 1) Feature 020 of the product structure
- 2) Feature 010 of the product structure
- For ambient temperatures $T_a \le -30$ °C (-22 °F) a minimum voltage of 16 V is required for the satrtup of the device at the MIN error current (3.6 mA).

| "Power Supply, Output" 1) | "Approval" 2) | Terminal voltage U at the device | Maximum load R, depending on the supply voltage U_0 at the supply unit |
|--------------------------------|---------------|----------------------------------|--|
| C: 2-wire; 4-20mA HART, 4-20mA | any | 12 to 30 V ³⁾ | R [Ω] 500 10 20 30 U ₀ [V] A0017055 |

- 1) Feature 020 of the product structure
- 2) Feature 010 of the product structure
- 3) For ambient temperatures $T_a \le -30$ °C (-22 °F) a minimum voltage of 16 V is required for the satrtup of the device at the MIN error current (3.6 mA).

| Polarity reversal protection | Yes |
|---|--------------------------|
| Admissible residual ripple at f = 0 to 100 Hz | $U_{SS} < 1 \text{ V}$ |
| Admissible residual ripple at f = 100 to 10000 Hz | $U_{SS} < 10 \text{ mV}$ |



4-wire, 4-20mA HART, active

| "Power supply; Output" 1) | Terminal voltage | $Maximum \ load \ R_{max}$ |
|---|--|----------------------------|
| K: 4-wire 90-253VAC; 4-20mA HART | 90 to 253 V _{AC} (50 to 60 Hz), overvoltage category II | 500 Ω |
| L: 4-wire 10,4-48VDC; 4-20mA HART | 10.4 to 48 V _{DC} | |

Feature 020 of the product structure

PROFIBUS PA, FOUNDATION Fieldbus (in preparation)

| "Power supply; Output" 1) | "Approval" 2) | Terminal voltage |
|---|---|-------------------------|
| E: 2-wire; FOUNDATION Fieldbus, switch output G: 2-wire; PROFIBUS PA, switch output | ■ Non-Ex ■ Ex nA ■ Ex nA(ia) ■ Ex ic ■ Ex ic(ia) ■ Ex d(ia) / XP ■ Ex ta / DIP ■ CSA GP | 9 to 32 V ³⁾ |
| | ■ Ex ia / IS ■ Ex ia + Ex d(ia) / IS + XP | 9 to 30 V ³⁾ |

- 1) Feature 020 of the product structure
- 2)
- Feature 010 of the product structure Input voltages up to 35 V will not spoil the device.

| Polarity sensitive | No |
|---|-----|
| FISCO/FNICO compliant according to IEC 60079-27 | Yes |

Power consumption

| "Power supply; Output" 1) | Power consumption |
|---|-------------------|
| A: 2-wire; 4-20mA HART | < 0.9 W |
| B: 2-wire; 4-20mA HART, switch output | < 0.9 W |
| C: 2-wire; 4-20mA HART, 4-20mA | < 2 x 0.7 W |
| K: 4-wire 90-253VAC; 4-20mA HART | 6 VA |
| L: 4-wire 10,4-48VDC; 4-20mA HART | 1.3 W |

Feature 020 of the product structure

Current consumption

HART

| Nominal current | $3.6\ to\ 22\ mA,$ the start-up current for multidrop mode can be parametrized (is set to $3.6\ mA$ on delivery) | |
|----------------------------------|--|--|
| Breakdown signal (NAMUR NE43) | adjustable: 3.59 to 22.5 mA | |

PROFIBUS PA (in preparation)

| Nominal current | 14 mA |
|--|-------|
| Error current FDE (Fault Disconnection Electronic) | 0 mA |

FOUNDATION Fieldbus (in preparation)

| Device basic current | 14 mA |
|--|-------|
| Error current FDE (Fault Disconnection Electronic) | 0 mA |

FISCO (in preparation)


| U _i | 17.5 V | |
|----------------|--------|--|
| I _i | 550 mA | |
| P _i | 5.5 W | |
| C _i | 5 nF | |
| L _i | 10 µН | |

Power supply failure

- Configuration is retained in the HistoROM (EEPROM).
- Error messages (incl. value of operated hours counter) are stored.

Potential equalization

No special measures for potential equalization are required.



Terminals

■ Without integrated overvoltage protection

Plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

■ With integrated overvoltage protection

Screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG)

Cable entries

- Cable gland (not for Ex d):
 - Plastics M20x1.5 for cable Ø 5 to 10 mm (0.2 to 0.39 in): non-Ex, ATEX/IECEx/NEPSI Ex ia/ic
 - Metal M20x1.5 for cable \varnothing 7 to 10 $\,$ mm (0.28 to 0.39 $\,$ in): dust-Ex, FM IS, CSA IS, CSA GP, Ex nA
- Thread for cable entry:
 - ½" NPT
 - G ½"
 - $M20 \times 1.5$
- Connector (only for non-Ex, Ex ic, Ex ia): M12 or 7/8"

Cable specification

- Standard device cable is sufficient for the power supply of the device.
- Minimum cross-section: (→ \(\bigsip 25 \))
- For ambient temperature $T_U \ge 60$ °C (140 °F): use cable for temperature $T_U + 20$ K.

HART

- A normal device cable suffices if only the analog signal is used.
- A shielded cable is recommended if using the HART protocol. Observe grounding concept of the plant.

PROFIBUS (in preparation)

Use a twisted, screened two-wire cable, preferably cable type A.



For further information on the cable specifications, see Operating Instructions BA00034S "Guidelines for planning and commissioning PROFIBUS DP/PA", PNO Guideline 2.092 "PROFIBUS PA User and Installation Guideline" and IEC61158-2 (MBP).

FOUNDATION Fieldbus (in preparation)

Endress+Hauser recommends using twisted, shielded two-wire cables.

For further information on the cable specifications, see Operating Instructions BA00013S "FOUNDATION Fieldbus Overview", FOUNDATION Fieldbus Guideline and IEC 61158-2 (MBP).

Endress+Hauser V. 1, Rev. 6, 19–10–2012 25

Overvoltage protection

26

If the measuring device is used for level measurement in flammable liquids which requires the use of overvoltage protection according to DIN EN 60079-14, standard for test procedures 60060-1 (10 kA, pulse $8/20~\mu s$), overvoltage protection has to be ensured by an integrated or external overvoltage protection module.

Integrated overvoltage protection

An integrated overvoltage protection module is available for 2-wire HART as well as PROFIBUS PA and FOUNDATION Fieldbus devices.

Product structure: Feature 610 "Accessory mounted", option NA "Overvoltage protection".

| Technical data | | |
|--|---------------|--|
| Resistance per channel | 2 * 0.5 Ω max | |
| Threshold DC voltage | 400 to 700 V | |
| Threshold impulse voltage | < 800 V | |
| Capacitance at 1 MHz | < 1.5 pF | |
| Nominal arrest impulse voltage (8/20 µs) | 10 kA | |

External overvoltage protection

HAW562 or HAW569 from Endress+Hauser are suited as external overvoltage protection.

For detailed information please refer to the following documents:

HAW562: TI01012KHAW569: TI01013K



Performance characteristics

Reference operating conditions

- Temperature = +24 °C (+75 °F) ± 5 °C (± 9 °F)
- Pressure = 960 mbar abs. (14 psia) \pm 100 mbar (\pm 1.45 psi)
- Humidity = $60 \% \pm 15 \%$
- Reflector: metal plate with a minimum diameter of 1 m (40 in)
- No major interference reflections inside the signal beam


Maximum measured error

Typical data under reference operating conditions: DIN EN 61298-2, percentage values in relation to the span.

| Device | Value | Output | |
|-------------|---|------------------|-----------|
| | | digital | analog 1) |
| FMR56/FMR57 | Sum of non-linearity, nonrepeatability and hysteresis | ± 3 mm (0.12 in) | ± 0.02 % |
| | Offset/Zero | ± 4 mm (0.2 in) | ± 0.03 % |

1) Add error of the analogous value to the digital value.

Differing values in near-range applications



11 Maximum measured error in near-range applications

- Δ Maximum measured error
- D Distance from the reference point R
- A Lower edge of the antenna

Measured value resolution

Dead band according to EN61298-2:

- digital: 1 mm
- analog: 1 µA

Endress+Hauser V. 1, Rev. 6, 19-10-2012 27

Reaction time

The reaction time can be parametrized. The following step response times (as per DIN EN 61298-2) $^{1)}$ are valid if the damping is switched off:

| Tank height | Sampling rate | Step response time |
|-----------------|-----------------------|--------------------|
| < 10 m (33 ft) | ≥ 3.6 s ⁻¹ | < 0.8 s |
| < 70 m (230 ft) | ≥ 2.2 s ⁻¹ | < 1 s |

Influence of ambient temperature

The measurements are carried out in accordance with EN 61298-3

- Digital (HART, PROFIBUS PA): average $T_K = 5 \text{ mm}/10 \text{ K}$; maximum 15 mm
- Analog (current output):


 zero point (4 mA): average $T_K = 0.02 \%/10 \text{ K}$ span (20 mA): average $T_K = 0.05 \%/10 \text{ K}$

According to DIN EN 61298-2 the response time is the time which passes after a sudden change of the input signal until the output signal for the first time assumes 90% of the steady-state value. 1)

Installation

Installation conditions


Mounting position



- Recommended distance **A** from wall to outer edge of nozzle: ~ 1/6 of vessel diameter. Nevertheless the device should not be installed closer than 20 cm (7.87 in) to the vessel wall. If the wall of the vessel is not smooth (corrugated metal, welding seams, irregularities etc.) the distance from the wall should be kept as large as possible. If necessary, use an alignment device to prevent interference reflections from the wall(→ ≜ 44).
- Not in the center (2), as interference can cause signal loss.
- Not above the fill stream (3).
- It is recommended to us a weather protection cover (1) in order to protect the device from direct sun or rain.
- In extremely dusty applications, the integrated air purge connection can prevent clogging of the antenna (\rightarrow $\stackrel{\triangle}{=}$ 45).




Vessel installations



Avoid any installations (limit switches, temperature sensors, braces etc.) inside the signal beam. Take into account the beam angle (\rightarrow $\stackrel{\square}{=}$ 34):


Reduction of interference echoes




Metallic screens mounted at a slope spread the radar signal and can, therefore, reduce interference echoes.


Measurement in a plastic vessel

If the outer wall of the vessel is made of a non-conductive material (e.g. GRP), microwaves can also be reflected off interfering installations outside the signal beam (e.g. metallic pipes (1), ladders (2), grates (3), ...). Therefore, there should be no such interfering installations in the signal beam. Please contact Endress+Hauser for further information.





A0017125




Optimization options

- Antenna size
 - The bigger the antenna, the smaller the beam angle α and the fewer interference echoes ($\rightarrow \stackrel{\triangle}{=} 34$).
- Mapping
 - The measurement can be optimized by means of electronic suppression of interference echoes.
- Antenna alignment
 - Take into account the marker on the flange or threaded connection ($\rightarrow \stackrel{\triangle}{=} 39$).
- Metallic screens mounted at a slope (3)
 - They spread the radar signals and can, therefore, reduce interference echoes.
- Variable flange seal (FMR56)
 - Using the variable flange seal, the device can be aligned in the direction of the product surface. For details refer to Operating Instructions BA01048F, chapter "Accessories".
- Alignment device for FMR57
 - In FMR57 with alignment device, the sensor can be optimally aimed within the vessel and thus interference echoes can be avoided. The maximum angle β is $\pm 15^{\circ}$.
 - In particular, sensor alignment serves to:
 - prevent interference reflections
 - extend the maximum possible measuring range in conical outlets.



Beam angle



 \blacksquare 12 Relationship between beam angle α , distance D and beamwidth diameter W

The beam angle is defined as the angle α where the energy density of the radar waves reaches half the value of the maximum energy density (3-dB-width). Microwaves are also emitted outside the signal beam and can be reflected off interfering installations.

Beam diameter W as a function of beam angle α and measuring distance D:

| FMR56 | | |
|---|---|--|
| 80 mm (3 in) | 100 mm (4 in) | |
| 10° | 8° | |
| Measuring distance (D) Beamwidth diameter (W) | | |
| 0.53 m (1.7 ft) | 0.42 m (1.4 ft) | |
| 1.05 m (3.4 ft) | 0.84 m (2.8 ft) | |
| 1.58 m (5.2 ft) | 1.26 m (4.1 ft) | |
| 2.1 m (6.9 ft) | 1.68 m (5.5 ft) | |
| 2.63 m (8.6 ft) | 2.10 m (6.9 ft) | |
| 3.50 m (11 ft) | 2.80 m (9.2 ft) | |
| 4.37 m (14 ft) | 3.50 m (11 ft) | |
| 5.25 m (17 ft) | 4.20 m (14 ft) | |
| | 80 mm (3 in) 10° Beamwidth 0.53 m (1.7 ft) 1.05 m (3.4 ft) 1.58 m (5.2 ft) 2.1 m (6.9 ft) 2.63 m (8.6 ft) 3.50 m (11 ft) 4.37 m (14 ft) | |


| FM | FMR57 - Horn antenna | | |
|------------------------|---|-----------------|--|
| Antenna size | 80 mm (3 in) | 100 mm (4 in) | |
| Beam angle α | 10° | 8° | |
| Measuring distance (D) | Measuring distance (D) Beamwidth diameter W | | |
| 5 m (16 ft) | 0.87 m (2.9 ft) | 0.7 m (2.3 ft) | |
| 10 m (33 ft) | 1.75 m (5.7 ft) | 1.4 m (4.6 ft) | |
| 15 m (49 ft) | 2.62 m (8.6 ft) | 2.1 m (6.9 ft) | |
| 20 m (66 ft) | 3.50 m (11 ft) | 2.80 m (9.2 ft) | |
| 30 m (98 ft) | 5.25 m (17 ft) | 4.20 m (14 ft) | |
| 40 m (131 ft) | 7.00 m (23 ft) | 5.59 m (18 ft) | |
| 50 m (164 ft) | 8.75 m (29 ft) | 6.99 m (23 ft) | |

| FMR57 - Parabolic antenna | | |
|---------------------------|----------------------|----------------|
| Antenna size | 200 mm (8 in) | 250 mm (10 in) |
| Beam angle α | 4° | 3,5° |
| Measuring distance (D) | Beamwidth diameter W | |
| 5 m (16 ft) | 0.35 m (1.1 ft) | 0.30 m (1 ft) |
| 10 m (33 ft) | 0.70 m (2.3 ft) | 0.61 m (2 ft) |
| 15 m (49 ft) | 1.05 m (3.4 ft) | 0.92 m (3 ft) |
| 20 m (66 ft) | 1.40 m (4.6 ft) | 1.22 m (4 ft) |
| 30 m (98 ft) | 2.10 m (6.9 ft) | 1.83 m (6 ft) |
| 40 m (131 ft) | 2.79 m (9.2 ft) | 2.44 m (8 ft) |
| 50 m (164 ft) | 3.50 m (11 ft) | 3.06 m (10 ft) |
| 60 m (197 ft) | 4.19 m (14 ft) | 3.70 m (12 ft) |
| 70 m (230 ft) | 4.90 m (16 ft) | 4.28 m (14 ft) |



Measuring conditions

- The measuring range begins, where the beam hits the bottom. Particularly with conical outlets the level cannot be detected below this point. The maximum measuring range can be increased in such applications by using an alignment device ($\rightarrow \triangleq 44$).
- In case of media with a low dielectric constant $(\varepsilon_r = 1.5 \text{ to } 2.5)^2$, the bottom can be visible through the medium at low levels. In order to guarantee the required accuracy in these cases, it is recommended to position the zero-point at a distance \mathbf{C} above the bottom (see figure).
- In principle it is possible to measure up to the tip of the antenna with Micropilot. However, due to considerations regarding abrasion and build-up and depending on the orientation of the product surface (angle of repose), the end of the measuring range should be at a distance of **A** (see figure) from the tip of the antenna. If required, and if some conditions (high DC value, flat angle of repose) are met, shorter distances can be achieved.



A001071

| Device | A [mm (in)] | C [mm (in)] |
|--------|-------------|-------------------------|
| FMR56 | 400(15.7) | 50 to 150(1.97 to 5.91) |
| FMR57 | 400(13.7) | 30 (0 130(1.97 (0 3.91) |


²⁾ Dielectric constants of important media commonly used in the industry are summarized in the document SD106F, which can be downloaded from the Endress+Hauser web page (www.endress.com).

Installation in vessel (free space)


Horn antenna with slip-on flange (FMR56)

Alignment

- When using the Micropilot with a slip-on flange in explosion-hazardous areas, strictly observe all specifications in the relevant Safety Instructions (XA).
- Align the antenna vertically to the product surface. Optionally, a variable flange seal, which is available as an accessory, can be used for alignment (see Technical Information BA01048F, chapter "Accessories").
- A marking at the boss enables axial alignment of the antenna. This marking must be aligned towards the tank wall.



Nozzle mounting




Nozzle height and diameter for horn antenna with slip-on flange (FMR50/FMR56)

| Antenna size | | 80 mm (3 in) | 100 mm (3.94 in) | | | |
|-----------------|--------------------|--------------------|--------------------|--------------------|--------------------|--|
| D | 80 mm (3.15 in) | 100 mm (3.94 in) | 150 mm (5.91 in) | 100 mm (3.94 in) | 150 mm (5.91 in) | |
| Н | < 500 mm (19.7 in) | |

37 Endress+Hauser V. 1, Rev. 6, 19-10-2012

Horn antenna with mounting bracket (FMR56)



☐ 14 Installation of the horn antenna with mounting bracket (FMR50/FMR56)

Align the antenna vertically to the product surface using the mounting bracket.

NOTICE


The mounting bracket has no conductive connection to the transmitter housing. Danger of electrostatic charge

► Connect the mounting bracket to the local potential equalization system.

Horn antenna (FMR57)


Alignment

- Ideally, the horn antenna should be installed vertically. To avoid interference reflections or for optimum alignment within the vessel, the Micropilot with optional alignment device can be inclined by 15° in all directions ($\rightarrow \stackrel{\triangle}{=} 45$).
- A marking at the boss enables axial alignment of the antenna. This marking must be aligned towards the tank wall.



Nozzle mounting

The horn antenna should protrude from the nozzle. If this is not possible for mechanical reasons, larger nozzle heights can be accepted.



15 Nozzle height and diameter for the horn antenna (FMR57)

| Antenna size | 80 mm (3 in) | 100 mm (4 in) |
|------------------------------------|--------------------|--------------------|
| D | 75 mm (2.95 in) | 95 mm (3.74 in) |
| H without antenna extension | < 260 mm (10.2 in) | < 480 mm (18.9 in) |

Please contact Endress+Hauser for applications with higher nozzle.

Endress+Hauser V. 1, Rev. 6, 19–10–2012 39

Threaded connection

- Tighten with the hexagonal nut only.
 Tool: Hexagonal wrench 60 mm
 Maximum permissible torque: 60 Nm (44 lbf ft)



V. 1, Rev. 6, 19-10-2012 Endress+Hauser

40

Parabolic antenna (FMR57)


Alignment

Ideally, the parabolic antenna should be installed vertically. To avoid interference reflections or for optimum alignment within the vessel, the Micropilot with optional alignment device can be swiveled by 15° in all directions ($\rightarrow \stackrel{\triangle}{=} 44$).

Nozzle mounting

- Ideally, the parabolic antenna should protrude from the nozzle (1). Particularly when using the alignment device, please ensure that the parabolic reflector is protruding from the nozzle/roof so as not to inhibit alignment.
- For applications with higher nozzle it may be necessary to install the parabolic antenna completely in the nozzle (2).

The maximum height of the nozzle (H_{max}) to the parabolic mirror should not exceed 500 mm (19.7 in). Interfering edges within the nozzle should be avoided.



Nozzle mounting of Micropilot FMR57 with parabolic antenna

- 1 Antenna protrudes from the nozzle
- 2 Antenna completely within the nozzle

| Antenna size | 200 mm (8 in) | 250 mm (10 in) |
|------------------------------------|-------------------|-------------------|
| D | 173 mm (6.81 in) | 236 mm (9.29 in) |
| H without antenna extension | < 50 mm (1.97 in) | < 50 mm (1.97 in) |


Endress+Hauser V. 1, Rev. 6, 19–10–2012 41

Examples for installation with small flange

If the flange is smaller than the parabolic reflector, the device can be mounted in one of the following ways:

- Standard installation (\rightarrow 🖹 42)
- Dismantling the parabolic reflector (\rightarrow 🖹 42)
- Installation with hinged flange (\rightarrow 🖹 43)

Standard installation



1 Nozzle


42

| Antenna size | ØD | H 1) |
|----------------|------------------|-------------------|
| 200 mm (8 in) | 173 mm (6.81 in) | < 50 mm (1.96 in) |
| 250 mm (10 in) | 236 mm (9.29 in) | < 50 mm (1.96 in) |

1) without antenna extension

Dismantling the parabolic reflector


For installation in a nozzle, the parabolic reflector can be dismantled:



- Parabolic reflector 4 bolts

Installation with hinged flange


At hinged flanges, the length of the antenna must be taken into account.



Alignment device for FMR57

Using the alignment device it is possible to tilt the antenna axis by up to 15° in all directions. The alignment device is used for the optimum alignment of the radar beam with the bulk solids surface.

Product structure: Feature 100 "Process connection", options XCJ, XEJ, XFJ




☐ 17 Micropilot FMR57 with alignment device





Integrated air purge connection for FMR57

In extremely dusty applications, the integrated air purge connection can prevent clogging of the antenna. Pulsed operation is recommended.



18 Micropilot FMR57 with air purge connection

1 Air purge connection NPT1/4 or G1/4


Torque for air purge connection: 6 Nm (4.4 lbf ft)

- **Pulsed operation**max. pressure of purge air: 6 bar (87 psi)
- **Permanent operation** recommended pressure range of the purge air: 200 to 500 mbar (3 to 7.25 psi)
- Make sure to use dry purge air.
- In general, air purging should only be used as much as necessary, since too much air purging may cause mechanical damage.



Endress+Hauser V. 1, Rev. 6, 19-10-2012 45

Vessels with heat insulation



A0019142

If process temperatures are high, the device must be included in normal tank insulation to prevent the electronics heating up as a result of heat radiation or convection. The insulation may not exceed beyond the neck of the housing.

Environment


Ambient temperature range

| Measuring device | -40 to $+80$ °C (-40 to $+176$ °F); -50 °C (-58 °F) with manufacturer declaration on request |
|------------------|---|
| Local display | -20 to $+70$ °C (-4 to $+158$ °F), the readability of the display may be impaired at temperatures outside the temperature range. |

When operating the device in the open with strong sunlight:

- Mount the device in a shady position.
- Avoid direct sunlight, especially in warmer regions.
- Use a weather protection cover (see accessories).


Ambient temperature limits




With a temperature (T_p) at the process connection the admissible ambient temperature (T_a) is reduced according to the following diagram (temperature derating):


Information concerning the derating tables

| Option | Meaning |
|--------|-------------------------------------|
| A | 2-wire; 4-20 mA HART |
| В | 2-wire; 4-20 mA HART, switch output |
| С | 2-wire; 4-20 mA HART, 4-20 mA |
| Е | 2-wire; FF, switch output |
| G | 2-wire; PA, switch output |
| K | 4-wire 90-253VAC; 4-20 mA HART |
| L | 4-wire 10, 4-48VDC; 4-20 mA HART |



Endress+Hauser V. 1, Rev. 6, 19-10-2012 47






V. 1, Rev. 6, 19-10-2012 Endress+Hauser

48

FMR57


Seal: Viton GLT Housing: GT19 (Plastics PBT) Temperature unit: °C (°F)




| Power Supply; Output (Pos. 2 of | P | 1 | P | 2 | P | 3 | P | 4 | F | 25 | P | 6 |
|---------------------------------|----------------|-------------|----------------|-------------|----------------|-------------|----------------|--------------|----------------|--------------|----------------|----|
| the product structure) | T _p | Ta | T _p | Ta | T _p | Ta |
| A | -40 (-40) | 80 (176) | 80 (176) | 80 (176) | 200 (392) | 53 (127) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| B Switch output not used | -40 (-40) | 76 (169) | 76 (169) | 76 (169) | 200 (392) | 53 (127) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| B Switch output used | -40 (-40) | 60 (140) | 60 (140) | 60 (140) | 200 (392) | 37 (99) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| C Channel 2 not used | -40 (-40) | 82 (180) | 82 (180) | 82 (180) | 200 (392) | 53 (127) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| C Channel 2 used | -40 (-40) | 74 (165) | 74 (165) | 74 (165) | 200 (392) | 53 (127) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| E, G Switch output not used) | -40 (-40) | 79 (174) | 79 (174) | 79 (174) | 200 (392) | 53 (127) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| E, G Switch output used | -40 (-40) | 63 (145) | 63 (145) | 63 (145) | 200 (392) | 40 (104) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |

FMR57

Seal: Viton GLT Housing: GT20 (Alu, coated) Temperature unit: °C (°F)



| | | | | | | | | | | | | A0019331 |
|---------------------------------|----------------|-------------|----------------|-------------|----------------|-------------|----------------|--------------|----------------|--------------|----------------|----------|
| Power Supply; Output (Pos. 2 of | P1 | | P2 | | Р3 | | P4 | | P5 | | P6 | |
| the product structure) | T _p | Ta | T _p | Ta | T _p | Ta |
| A | -40 (-40) | 81 (178) | 81 (178) | 81 (178) | 200 (392) | 70 (158) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| B Switch output not used | -40 (-40) | 82 (180) | 82 (180) | 82 (180) | 200 (392) | 70 (158) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| B Switch output used | -40 (-40) | 77 (171) | 77 (171) | 77 (171) | 200 (392) | 65 (149) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| C Channel 2 not used | -40 (-40) | 82 (180) | 82 (180) | 82 (180) | 200 (392) | 71 (160) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| C Channel 2 used | -40 (-40) | 79 (174) | 79 (174) | 79 (174) | 200 (392) | 67 (153) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| E, G Switch output not used | -40 (-40) | 83 (181) | 83 (181) | 83 (181) | 200 (392) | 71 (160) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| E, G Schaltausgang verwende) | -40 (-40) | 78 (172) | 78 (172) | 78 (172) | 200 (392) | 66 (151) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| K, L | -40 (-40) | 77 (171) | 77 (171) | 77 (171) | 200 (392) | 66 (151) | 200 (392) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |



K, L

-40

77

(171)

77

(171)

77

(171)

400

(752)

48

(118)

400

(752)

-40


(-40)

-40

(-40)

-40


(-40)



FMR57

Seal: Graphite

Housing: GT20 (Alu, coated) Temperature unit: °C (°F)



| Power Supply; Output (Pos. 2 of | P1 | | P2 | | Р3 | | P4 | | P5 | | P6 | |
|---------------------------------|--------------|----------------|----------------|-------------|--------------|-------------|----------------|--------------|----------------|--------------|-------|----|
| the product structure) | $T_{\rm p}$ | T _a | T _p | Ta | T_{p} | Ta | T _p | Ta | T _p | Ta | T_p | Ta |
| A | -40 (-40) | 81 (178) | 81 (178) | 81 (178) | 400 (752) | 58 (136) | 400 (752) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| B Switch output not used | -40 (-40) | 82 (180) | 82 (180) | 82 (180) | 400 (752) | 59 (138) | 400 (752) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| B Switch output used | -40 (-40) | 77 (171) | 77 (171) | 77 (171) | 400 (752) | 53 (127) | 400 (752) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| C Channel 2 not used | -40 (-40) | 82 (180) | 82 (180) | 82 (180) | 400 (752) | 59 (138) | 400 (752) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| C Channel 2 used | -40 (-40) | 79 (174) | 79 (174) | 79 (174) | 400 (752) | 56 (133) | 400 (752) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| E, G Switch output not used | -40 (-40) | 83 (181) | 83 (181) | 83 (181) | 400 (752) | 59 (138) | 400 (752) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| E, G Switch output used | -40 (-40) | 78 (172) | 78 (172) | 78 (172) | 400 (752) | 55 (131) | 400 (752) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |
| K, L | -40 (-40) | 77 (171) | 77 (171) | 77 (171) | 400 (752) | 54 (129) | 400 (752) | -40 (-40) | -40 (-40) | -40 (-40) | - | - |

Storage temperature

-40 to +80 °C (-40 to +176 °F)

Climate class

DIN EN 60068-2-38 (test Z/AD)

Geometric height according to IEC61010-1 Ed.3

Up to 2000 m (6600 ft) above MSL.

Can be expanded to $3\,000\,\mathrm{m}$ ($9\,800\,\mathrm{ft}$) above MSL by application of an overvoltage protection, e.g. HAW562 or HAW569.

Degree of protection

- With closed housing tested according to:
 - IP68, NEMA6P (24 h at 1.83 m under water surface)
 - For plastic housing with transparent cover (display module): IP68 (24 h at 1.00 m under water surface) $^{3)}$
 - IP66, NEMA4X
- With open housing: IP20, NEMA1 (also ingress protection of the display)

Degree of protection IP68 NEMA6P applies for M12 PROFIBUS PA plugs only when the PROFIBUS cable is plugged in and is also rated IP68 NEMA6P.

Vibration resistance

DIN EN 60068-2-64 / IEC 68-2-64: 20 to 2000 Hz, 1 $(m/s^2)^2/Hz$

Cleaning the antenna

The antenna can get contaminated, depending on the application. The emission and reception of microwaves can thus eventually be hindered. The degree of contamination leading to an error depends on the medium and the reflectivity, mainly determined by the dielectric constant ε_r .

If the medium tends to cause contamination and deposits, cleaning on a regular basis is recommended. In the case of FRM57, the integrated air purge connection can be used for this ($\rightarrow \stackrel{\boxtimes}{=} 45$). Care has to be taken not to damage the antenna in the process of a mechanical or hose-down cleaning. The material compatibility has to be considered if cleaning agents are used! The maximum permitted temperature at the flange should not be exceeded.

Endress+Hauser V. 1, Rev. 6, 19-10-2012 51

This restriction is valid if the following options of the product structure have been selected at the same time: 030("Display, Operation") = C("SD02") or E("SD03"); 040("Housing") = A("GT19").

Air purge connection

in preparation

Electromagnetic compatibility (EMC)

Electromagnetic compatibility to all relevant requirements of the EN 61326- series and NAMUR recommendation EMC (NE21). For details see declaration of conformity. ⁴⁾.

If only the analogue signal is used, unshielded interconnection lines are sufficient for the installation. In case of using the digital signal (HART/PA/FF) use shielded interconnection lines. Use a shielded cable when working with a digital communications signal.

Max. fluctuations during EMC- tests: < 0.5~% of the span. As an exception to this, the maximum fluctuations may amount to 2~% of the span for devices with plastic housing and see-through lid (integrated display and operating module SD02 or SD03) if strong electromagnetic interferences in the frequenency range of 1~ to 2~ GHz are present.

⁴⁾ Can be downloaded from www.endress.com.

Process

Process temperature range

| Sensor | Seal | Process temperature range |
|--------|-----------|---------------------------------|
| FMR56 | _ | -40 to +80 °C (-40 to +176 °F) |
| FMR57 | Viton GLT | -40 to +200 °C (-40 to +392 °F) |
| | Graphite | -40 to +400 °C (-40 to +752 °F) |

Process pressure range

| Sensor | Process pressure range |
|--------|---|
| | $p_{rel} = -1 \text{ to } 3 \text{ bar } (-14.5 \text{ to } 43.5 \text{ psi})$ $p_{abs} < 4 \text{ bar } (58 \text{ psi})$ |
| FMR57 | $p_{rel} = -1$ to 16 bar (-14.5 to 232 psi) |



This range may be reduced by the selected process connection. The pressure rating (PN) specified on the flanges refers to a reference temperature of 20 $^{\circ}$ C, for ASME flanges 100 $^{\circ}$ F. Pay attention to pressure-temperature dependencies.

Please refer to the following standards for the pressure values permitted for higher temperatures:

- EN 1092-1: 2001 Tab. 18 With regard to their temperature stability properties, the materials 1.4435 and 1.4404 are grouped under 13E0 in EN 1092-1 Tab. 18. The chemical composition of the two materials can be identical.
- ASME B 16.5a 1998 Tab. 2-2.2 F316
- ASME B 16.5a 1998 Tab. 2.3.8 N10276
- JIS B 2220

Dielectric constant

■ For liquids

- $\epsilon_r \ge 1.9$ in free-field applications
- $-\epsilon_{\rm r} \ge 1.4$ in stilling well
- For bulk solids


 $\varepsilon_{\rm r} \ge 1.6$



Mechanical construction


Dimensions

Dimensions of the electronics housing




19 Housing GT18 (316L); Dimensions in mm (in)

*This measure is valid for devices with integrated overvoltage protection.



20 Housing GT19 (Plastics PBT); Dimensions in mm (in)


^{*}This measure is valid for devices with integrated overvoltage protection.



21 Housing GT20 (Alu coated); Dimensions in mm (in)

^{*}This measure is valid for devices with integrated overvoltage protection.


Dimensions FMR56 (process connection/antenna)



- Horn DN80 (3")/DN100 (4") standard version Reference point of the measurement

| Dimension | DN80 | DN100 |
|-----------|--------------------|--------------------|
| a | 137.9 mm (5.43 in) | 150.5 mm (5.93 in) |
| b | 15 mm (0.59 in) | 20 mm (0.79 in) |
| ØC | 107 mm (4.21 in) | 127 mm (5 in) |
| ød | 115 mm (4.53 in) | 135 mm (5.31 in) |






A001774


- A Horn DN80 (3")/DN100 (4"); flange DN80/DN100 (with slotted hole) with slip-on flange suitable for DN80 PN16 / ANSI 3" 150 lbs / 10K 80 suitable for DN100 PN16 / ANSI 4" 150 lbs / 10K 100
- B Horn DN80; flange DN100/DN150 with adapter ring suitable for DN100 PN16 / ANSI 4" 150 lbs / 10K 100 suitable for DN150 PN16 / ANSI 6" 150 lbs / 10K 150
- C Horn DN100 (4"); flange DN150 with adapter ring suitable for DN150 PN16 / ANSI 6" 150 lbs / 10K 150
- R Reference point of the measurement

| Dimension | DN80 | DN100 | DN150 |
|-----------|----------------------|---------------------|---------------------|
| a | ø75 mm (2.95 in) | ø95 mm (3.74 in) | - |
| b | ø115.6 mm (4.55 in) | ø135.6 mm (5.34 in) | - |
| С | ø156.2 mm (6.15 in) | - | - |
| d | ∞200 mm (7.87 in) | ø228.6 mm (9 in) | - |
| e | 15.5 mm (0.61 in) | 20.5 mm (0.81 in) | - |
| f | 119 mm (4.69 in) | 131.5 mm (5.18 in) | - |
| g | 8 x ø21 mm (0.83 in) | 8 x 19 mm (0.75 in) | 8 x 23 mm (0.91 in) |
| h | ø143 mm (5.63 in) | ø163 mm (6.42 in) | - |
| i | - | ø175 mm (6.89 in) | ø240 mm (9.45 in) |
| j | - | ø190.5 mm (7.5 in) | ø241.3 mm (9.5 in) |
| k | - | ø228.6 mm (9 in) | ø285 mm (11.2 in) |
| n | 129.5 mm (5.1 in) | 142 mm (5.59 in) | - |
| р | 30.5 mm (1.2 in) | 35.5 mm (1.4 in) | - |



- Mounting bracket with alignment for roof mounting Mounting bracket with alignment for wall mounting

Dimensions FMR57 (process connection/antenna)



- A Horn antenna, standard version with alignment device and UNI flange
- B Horn antenna, standard version with UNI flange
- C Horn antenna, standard version with standard flange
- D Horn antenna, standard version with threaded connection
- E Parabolic antenna with alignment device and UNI flange
- F Parabolic antenna with UNI flange
- G Parabolic antenna, standard version with standard flange
- H Horn antenna, high temperature version with alignment device and UNI flange

I Horn antenna, high temperature version with standard flange

- Horn antenna, high temperature version with UNI flange Horn antenna, high temperature version with threaded connection
- Reference point of the measurement

Horn antenna

| Dimension | 80 mm (3") | 100 mm (4") |
|-----------|------------------|------------------|
| L | 211 mm (8.37 in) | 430 mm (16.9 in) |
| ød | ø75 mm (2.95 in) | ø95 mm (3.74 in) |

Parabolic antenna

| Dimension | 200 mm (8") | 250 mm (10") |
|-----------|-----------------------------------|----------------------------|
| L1 | 60.6 mm (2.39 in) | 88.4 mm (3.48 in) |
| øF | ø173 mm (6.81 in) | ∞236 mm (9.29 in) |
| L2 | 50 mm (1.97 in) | 37 mm (1.46 in) |
| | für version with 250 mm | (10 in) antenna extension: |
| | 300 mm (11.8 in) 287 mm (11.3 in) | |
| | for version with 450 mm | (18 in) antenna extension: |
| | 500 mm (19.7 in) | 487 mm (19.2 in) |

Flanges according to EN1092-1 (suitable for DIN2527)

| Dimension | Version | DN80 | DN100 |
|-----------|---------|-------------------|-------------------|
| b | 16 bar | 20 mm (0.79 in) | 20 mm (0.79 in) |
| øD | 10 Dai | ∞200 mm (7.87 in) | ∞220 mm (8.66 in) |

Flanges according to ANSI B16.5


| Dimension | Version | 3" | 4" |
|-----------|---------|--------------------|-------------------|
| b | 150 lbs | 23.9 mm (0.94 in) | 23.9 mm (0.94 in) |
| øD | 130 105 | ∅190.5 mm (7.5 in) | Ø228.6 mm (9 in) |

Flanges according to JIS B2220

| Dimension | Version | DN80 | DN100 |
|-----------|---------|-------------------|-------------------|
| b | 10 K | 18 mm (0.71 in) | 18 mm (0.71 in) |
| øD | 10 K | ∞185 mm (7.28 in) | ∞210 mm (8.27 in) |

Endress+Hauser V. 1, Rev. 6, 19-10-2012 59


Endress+Hauser UNI flange



| Pos. | Flange | Suitable for | Material |
|------|-------------------|---|---------------|
| 1: | UNI flange DN100 | 4" 150lbsDN100 PN1610K 100 | 316L (1.4404) |
| 2: | UNI- flange DN200 | 8" 150lbsDN200 PN1610K 200 | 316L (1.4404) |
| 3: | UNI flange DN250 | 10" 150lbsDN250 PN1610K 250 | 316L (1.4404) |

The number of bolts has sometimes been reduced. The bolt-holes have been enlarged for adaption of dimensions, therefore, the flange needs to be properly aligned to the counterflange before the bolts are tightened.

Alignment device with Endress+Hauser UNI flange



- Viton seal
- Endress+Hauser UNI flange DN100/200/250 Clamping screw 3 x M8, shifty at 120°
- For the high temperature version of the FMR57 (sales option 090: "Seal", option D4 "Graphite, -40...400°C /-40...752°F"), there is no Viton seal (1) at the alignment device.

Weight

Housing

| Part | Weight |
|--------------------------------|--------------------------|
| Housing GT18 - stainless steel | approx. 4.5 kg (9.9 lbs) |
| Housing GT19 - plastic | approx. 1.2 kg (2.7 lbs) |
| Housing GT20 – aluminium | approx. 1.9 kg (4.2 lbs) |


Antenna and process connection

| Device | Weight of antenna and process connection | |
|--------|---|--|
| FMR56 | max. 1.5 kg (3.3 lbs) + weight of flange 1) | |
| FMR57 | MR57 max. 5.5 kg (12.1 lbs) + weight of flange 1) | |

For the weight of the flange refer to Technical Information TI00426F.

Endress+Hauser V. 1, Rev. 6, 19-10-2012 61

Materials Housing



A001378


| | Housing GT18 - stainless steel, corrosion-resistant | | | | |
|-----|--|-----|---|--|--|
| No. | Part: material | No. | Part: material | | |
| 1 | Housing: 316L (CF-3M, 1.4404) | 5 | Cable entry | | |
| 2.1 | 2.1 Cover of the electronics compartment Cover: 316L (CF-3M, 1.4404) Window: glass Cover seal: EPDM | | Sealing: EMPB Cable gland: 316L (1.4404) Adapter: 316L (1.4435) | | |
| 2.2 | Cover of the terminal compartment Cover: 316L (CF-3M, 1.4404) Cover seal: EPDM | 6 | Dummy plug: 316L (1.4404) | | |
| | | 7 | Pressure relief stopper: 316L (1.4404) | | |
| 3 | Cover lock Screw: A4 Clamp: 316L (1.4404) | 8 | Ground terminal Screw: A4 Spring washer: A4 Clamp: 316L (1.4404) Holder: 316L (1.4404) | | |
| 4 | Turn housing ■ Screw: A4-70 ■ Clamp: 316L (1.4404) | 9 | Identification Nameplate: 304 (1.4301) Groove pin: A2 | | |

| | Housing GT19 - plastic | | | |
|---|------------------------|---|-----|--|
| | No. | Part: material | No. | Part: material |
| Ī | 1 | Housing: PBT | 5 | Cable entry |
| | 2.1 | Cover of the electronics compartment Cover: PA (see-through cover) PBT (non-transparent cover) Cover seal: EPDM | | Sealing: EMPB Cable gland: polyamide (PA), nickel-plated brass (CuZn) Adapter: 316L (1.4435) |
| | 2.2 | Cover of the terminal compartment | 6 | Dummy plug: nickel-plated brass (CuZn) |
| | | Cover: PBTCover seal: EPDM | 7 | Pressure relief stopper: nickel-plated brass (CuZn) |
| | 4 | Turn housing ■ Screw: A4-70 ■ Clamp: 316L (1.4404) | 8 | Ground terminal Screw: A2 Spring washer: A4 Clamp: 304 (1.4301) Holder: 304 (1.4301) |
| | | | 9 | Identification Nameplate: sticker |

| | Housing GT20 - die-cast aluminum, powder-coated, seawater-resistant | | | | |
|-----|--|-----|--|--|--|
| No. | Part: material | No. | Part: material | | |
| 1 | Housing: AlSi10Mg(<0.1% Cu) Coating: polyester | 5 | Cable entry Sealing: EMPB | | |
| 2.1 | Cover of the electronics compartment Cover: AlSi10Mg(<0.1% Cu) Window: glass Cover seal: EPDM | | Cable gland: polyamide (PA), nickel-plated brass (CuZr Adapter: 316L (1.4435) | | |
| 2.2 | Cover of the terminal compartment | | Dummy plug: nickel-plated brass (CuZn) | | |
| | ■ Cover: AlSi10Mg(<0.1% Cu) ■ Cover seal: EPDM | 7 | Pressure relief stopper: nickel-plated brass (CuZn) | | |
| 3 | Cover lock Screw: A4 Clamp: 316L (1.4404) | 8 | Ground terminal Screw: A2 Spring washer: A2 Clamp: 304 (1.4301) Holder: 304 (1.4301) | | |
| 4 | Turn housing Screw: A4-70 Clamp: 316L (1.4404) | 9 | Identification Nameplate: sticker | | |

Antenna and process connection


FMR56



- Standard version with mounting bracket Horn antenna with slip-on flange Horn antenna with flange and adapter ring

| Pos. | Part | Material |
|------|-------------------------|--------------|
| 1 | Mounting bracket | 304 (1.4301) |
| | Screw | A2 |
| | Nordlock washer | A4 |
| 2 | Housing adapter | 304 (1.4301) |
| 3 | Horn | PBT |
| 4 | Slip-on flange | PP |
| 5 | Flange and adapter ring | PP |
| | Screw | A2 |
| | Seal | FKM |
| 6 | Focusing lense | PP |
| | Seal | VMQ |

FMR57



- Α Horn standard version with alignment device and UNI flange
- Horn standard version with UNI flange В
- C
- Horn standard version with standard flange Horn standard version with screw-in adapter D
- Parabolid version with alignment device and UNI flange Parabolid version with UNI flange Е


64

- G Horn high temperature version with alignment device and UNI flange
- Horn high temperature version with standard flange
- Horn high temperature version with UNI flange
- Horn high temperature version with threaded connection

| Pos. | Part | Material | | |
|-----------------------------|-----------------------|---------------|---------------|--|
| 1 | Housing adapter | 316L (1.4404) | | |
| | Temperature reduction | 316L (1.4404) | | |
| | Intermediate adapter | 316L (1.4404) | | |
| | Purge-air connection | 316L (1.4404) | | |
| | Plug | A4 | 316L (1.4404) | |
| | Adapter (G→NPT) | 316L (1.4404) | | |
| 2 Housing adapter 316L (1.4 | | 316L (1.4404) | . (1.4404) | |
| | Plug | A4 | 316L (1.4404) | |
| | Adapter (G→NPT) | 316L (1.4404) | | |
| | Dichtung | FKM | PTFE (tape) | |

| Pos. | Part | Material | | | |
|------|-------------------------------|--|--|--|--|
| 3 | Flange | 316L (1.4404) | | | |
| | Ball | 316L (1.4404) | | | |
| | Screws | A2 | | | |
| | Spring-lock washer | 1.4310 | | | |
| | Clamping flange | 316L (1.4404) | | | |
| | Adapter | 316L (1.4404) | | | |
| | Seal (except for version "G") | FKM | | | |
| 4 | Flange | 316L (1.4404/1.4435) | | | |
| | Adapter | 316L (1.4404) | | | |
| 5 | Process connection | 316L (1.4404) | | | |
| 6 | Process separating parts | 316L (1.4404) | | | |
| | Adapter Horn/Parabolic | 316L (1.4404) | | | |
| 7 | Tube | 316L (1.4404) | | | |
| 8 | Horn | 316L (1.4404) | | | |
| | Screws | A4 | | | |
| | Process separating cone | Standard: PEEK High temperature: PI | | | |
| | Seal | Standard: FKM High temperature: Graphite | | | |
| 9 | Parabolic reflector | 316L (1.4404) | | | |
| | Screws | A4 | | | |
| | Feed | PTFE | | | |
| | Seal | FKM | | | |

Weather protection cover



| Weather protection cover | | | | | | |
|--------------------------|--------------------------------|-----|--------------------------|--|--|--|
| Nr. | Part: material | Nr. | Part: material | | | |
| 1 | Protection cover: 304 (1.4301) | 4 | Bracket: 304 (1.4301) | | | |
| 2.1 | Washer: A2 | 5.1 | Cheese head screw: A2-70 | | | |
| 2.2 | Cheese head screw: A4-70 | 5.2 | Nut: A2 | | | |

| | Weather protection cover | | | | | | |
|-----|--------------------------------|-----|---|--|--|--|--|
| Nr. | Part: material | Nr. | Part: material | | | | |
| 3.1 | Washer: A2 | 6 | Ground terminal | | | | |
| 3.2 | Tightening screw: 304 (1.4301) | | Screw: A4 Spring washer: A4 Clamp: 316L (1.4404) Holder: 316L (1.4404) | | | | |



Operability

Operating concept

Operator-oriented menu structure for user-specific tasks

- Commissioning
- Operation
- Diagnostics
- Expert level

Quick and safe commissioning

- Guided menus ("Make-it-run" wizards) for applications
- Menu guidance with brief explanations of the individual parameter functions


Reliable operation

- Local operation in different languages (see product structure, feature "Additional Operation Language")
- Standardized operation at the device and in the operating tools
- Data storage device (HistoROM) for process and measuring device data with event logbook available at all times - even if electronics modules are replaced

Efficient diagnostics increase measurement reliability

- Remedy information is integrated in plain text
- Diverse simulation options and line recorder functions

Local operation



Display elements

- 4-line display
- In the case of order code for "Display; Operation", option **E**: white background lighting; switches to red in event of device errors (in preparation)
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F)
 The readability of the display may be impaired at temperatures outside the temperature range.

Operating elements


- In the case of order code "Display; Operation", Option **C**: local operation with 3 push buttons (⑤, ⑥, ⑥), ⑥)
- In the case of order code for "Display; Operation", option **E**: external operation via touch control; 3 optical keys: ⑤, ⑥, ⑥ (in preparation)
- Operating elements also accessible in various hazardous areas

Additional functionality

- Data backup function
 - The device configuration can be saved in the display module.
- Data comparison function
 - The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function
 - The transmitter configuration can be transmitted to another device using the display module.

Endress+Hauser V. 1, Rev. 6, 19-10-2012 67

Operation with remote display and operating module FHX50




22 FHX50 operating options

- 1 Housing of the remote display and operating module FHX50
- 2 Display and operating module SD02, push buttons; cover must be removed
- 3 Display and operating module SD03, optical keys; can be operated through the glass of the cover (in preparation)

Remote operation

68

Via HART protocol




A00137

23 Options for remote operation via HART protocol

- 1 PLC (programmable logic controller)
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- 3 Connection for Commubox FXA191, FXA195 and Field Communicator 375, 475
- 4 Field Communicator 375, 475
- 5 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 6 Commubox FXA191 (RS232) or FXA195 (USB)
- 7 Field Xpert SFX100
- 8 VIATOR Bluetooth modem with connecting cable
- 9 Transmitter


Via PROFIBUS PA protocol (in preparation)



- Segment coupler Computer with Profiboard/Proficard and operating tool (e.g. FieldCare) PLC (Progrommable Logic Controller)
- Transmitter
- Additional functions (valves etc.)

Endress+Hauser V. 1, Rev. 6, 19-10-2012 69

Via FOUNDATION Fieldbus (in preparation)



24 FOUNDATION Fieldbus system architecture with associated components

IN Industrial network

FF- High Speed Ethernet

HSE

FF- FOUNDATION Fieldbus-H1

H1

LD Linking Device FF-HSE/FF-H1
PS Bus Power Supply

SB

Safety Barrier Bus Terminator BT


FFblue Bluetooth modem

Field Xpert SFX100

3 FieldCare

NI-FF interface card

Via service interface (CDI)



- Service interface (CDI) of the measuring device (= Endress+Hauser Common Data Interface) Commubox FXA291 Computer with "FieldCare" operating tool

71 Endress+Hauser V. 1, Rev. 6, 19-10-2012


System integration via Fieldgate

Vendor Managed Inventory

By using Fieldgates to interrogate tank or silo levels remotely, suppliers of raw materials can provide their regular customers with information about the current supplies at any time and, for example, account for them in their own production planning. For their part, the Fieldgates monitor the configured level limits and, if required, automatically activate the next supply. The spectrum of options here ranges from a simple purchasing requisition via e-mail through to fully automatic order administration by coupling XML data into the planning systems on both sides.

Remote maintenance of measuring equipment

Fieldgates not only transfer the current measured values, they also alert the responsible standby personnel, if required, via e-mail or SMS. In the event of an alarm or also when performing routine checks, service technicians can diagnose and configure connected HART devices remotely. All that is required for this is the corresponding HART operating tool (e.g. FieldCare, ...) for the connected device. Fieldgate passes on the information transparently, so that all options for the respective operating software are available remotely. Some on-site service operations can be avoided by using remote diagnosis and remote configuration and all others can at least be better planned and prepared.



A001127

- 25 The complete measuring system consists of devices and:
- 1 Fieldgate FXA520
- 2 Multidrop Connector FXN520
- The number of instruments which can be connected in mutidrop mode can be calculated by the "FieldNetCalc" program. A description of this program can be found in Technical Information TI 400F (Multidrop Connector FXN520). The program is available form your Endress+Hauser sales organisation or in the internet at: www.de.endress.com/Download (text search = "Fieldnetcalc").

Certificates and approvals

CE mark The measuring system meets the legal requirements of the applicable EC guidelines. These are listed in the corresponding EC Declaration of Conformity together with the standards applied. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

C-Tick symbol

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

Ex approval

- ATEX
- IEC Ex
- CSA (in Vorbereitung)
- FM (in Vorbereitung)
- NEPSI (in Vorbereitung)
- TIIS (in Vorbereitung)

Additional safety instructions must be observed for applications in hazardous areas. They are contained in the separate "Safety Instructions" (XA) document, which is included in the scope of delivery. Reference is made to the XA on the nameplate of the device.



Details on the available certificats as well as the associated XAs can be found in the **Associated documentation** chapter in the **Safety instructions** section: $(\rightarrow \stackrel{\triangle}{=} 84)$.

Dual seal according to ANSI/ISA 12.27.01

The devices Micropilot FMR5x have been designed according to ANSI/ISA 12.27.01 as dual seal devices, allowing the user to waive the use and save the cost of installing external secondary process seals in the conduit as required by the process sealing sections of ANSI/NFPA 70 (NEC) and CSA 22.1 (CEC). These instruments comply with the North-American installation practice and provide a very safe and cost-saving installation for pressurized applications with hazardous fluids.

Further information can be found in the control drawings of the relevant devices.

Functional Safety

Used for level monitoring (MIN, MAX, range) up to SIL 3 (homogeneous or inhomogeneous redundancy), independently assessed by $T\ddot{U}V$ Rhineland as per IEC 61508. Other information see documentation SD01087F: "Functional Safety Manual".

AD2000

The pressure retaining material 316L (1.4435/1.4404) corresponds to AD2000 - W2/W10.

Pressure Equipment Directive

The Micropilot is not subject to the scope of the Pressure Equipment Directive 97/23/EC, as it does not have a pressure-bearing housing according to article 1, section 2.1.4 of the directive.

Marine certificate (in preparation)

in preparation

Radio standard EN302729-1/2

The devices Micropilot FMR50, FMR51, FMR52, FMR56 and FMR57 are conform with the LPR (Level Probing Radar) standard EN302729–1/2. The devices are allowed to be used inside or outside of closed bins or tanks in countries of th EU and the EFTA. Precondition is that the country itself already has implemented the directive.

At present, the following countries have already implemented the directive:

Belgium, Bulgaria, Germany, Denmark, Estonia, France, Greece, Great Britain, Ireland, Iceland, Italy, Liechtenstein, Lithuania, Latvia, Malta, Netherland, Norway, Austria, Poland, Romania, Sweden, Switzerland, Slovakia, Spain, Czech Republic and Cyprus.

All countries not mentioned above are at present in the implementation phase.

For the use of the devices outside of closed bins or tanks, the following has to be observed:

- 1. The installation has to be done by trained personnel.
- 2. The antenna of the device has to be mounted on a fixed place and vertically to the bottom.
- 3. The mounting place has to be in a distance of at least 4 km to the mentioned astronomical stations or an appropriate permission has to be issued by the national authority. If the device is mounted at a

Endress+Hauser V. 1, Rev. 6, 19–10–2012 73

distance of 4 to 40 km from the stations mentioned, the maximum mounting height is restricted to $15\ m$ (49 ft).

Astronomical stations

| Country | Name of the station | Geographical latitude | Geographical longitude |
|----------------|---------------------|-----------------------|------------------------|
| Germany | Effelsberg | 50°31'32" N | 06°53'00" E |
| Finland | Metsähovi | 60°13'04" N | 24°23'37" E |
| | Tuorla | 60°24'56" N | 24°26'31" E |
| France | Plateau de Bure | 44°38'01" N | 05°54'26" E |
| | Floirac | 44°50'10" N | 00°31'37" W |
| United Kingdom | Cambridge | 52°09'59" N | 00°02'20" E |
| | Damhall | 53°09'22" N | 02°32'03" W |
| | Jodrell Bank | 53°14'10" N | 02°18'26" W |
| | Knockin | 52°47'24" N | 02°59'45" W |
| | Pickmere | 53°17'18" N | 02°26'38" W |
| Italy | Medicina | 44°31'14" N | 11°38'49" E |
| | Noto | 36°52'34" N | 14°59'21" E |
| | Sardinia | 39°29'50" N | 09°14'40" E |
| Poland | Krakow Fort Skala | 50°03'18" N | 19°49'36" E |
| Russia | Dmitrov | 56°26'00" N | 37°27'00" E |
| | Kalyazin | 57°13'22" N | 37°54'01" E |
| | Pushchino | 54°49'00" N | 37°40'00" E |
| | Zelenchukskaya | 43°49'53" N | 41°35'32" E |
| Sweden | Onsala | 57°23'45" N | 11°55'35" E |
| Switzerland | Bleien | 47°20'26" N | 08°06'44" E |
| Spain | Yebes | 40°31'27" N | 03°05'22" W |
| | Robledo | 40°25'38" N | 04°14'57" W |
| Hungary | Penc | 47°47'22" N | 19°16'53" E |



In general the requirements of EN 302729-1/2 has to be taken in consideration.

Radio standard EN302372-1/2

The devices Micropilot FMR50, FMR51, FMR52, FMR53, FMR54, FMR56 and FMR57 are conform with the TLPR (Tanks Level Probing Radar) standard EN302372-1/2 and can always be used in closed tanks or bins. For installation, points a to f in Annex B of EN302372-1 have to be taken into account.

FCC / Industry Canada

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canada CNR-Gen Section 7.1.3

This device complies with Industry Canada licence–exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

[Any] changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

| CRN approval | in preparation |
|--------------------------------|---|
| Track record | FMR5x is the upgrade model of the corresponding FMR2xx series. |
| Other standards and guidelines | ■ EN 60529 Degrees of protection by housing (IP code) ■ EN 61010-1 Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures. ■ IEC/EN 61326 "Emission in accordance with Class A requirements". Electromagnetic compatibility (EMC requirements) ■ NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment. ■ NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. ■ NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics ■ NAMUR NE 107 Status classification as per NE107 ■ NAMUR NE 131 Requirements for field devices for standard applications ■ IEC61508 Functional safety of electrical/electronic/programmable electronic safety-related systems |

Endress+Hauser V. 1, Rev. 6, 19-10-2012 75

Ordering information

Ordering information

Detailed ordering information is available from the following sources:

- In the Product Configurator on the Endress+Hauser website: www.endress.com → Select country → Instruments → Select device → Product page function: Configure this product
- From your Endress+Hauser Sales Center: www.endress.com/worldwide

Product Configurator - the tool for individual product configuration


- Up-to-the-minute configuration data
- Depending on the device: Direct input of measuring point-specific information such as measuring range or operating language
- Automatic verification of exclusion criteria
- Automatic creation of the order code and its breakdown in PDF or Excel output format
- Ability to order directly in the Endress+Hauser Online Shop

5-point linearity protocol (in preparation)

The following notes must be taken into account if option F4 ("5 point linearity protocol") has been selected in feature 550 ("Calibration").

The five points of the linearity protocol are evenly distributed across the measuring range (0% to 100%). In order to define the measuring range, **Empty calibration** (E) and **Full calibration** (F) have to be specified $^{5)}$.

The following restrictions have to be taken into account when defining E and F:



A0017983

| | Minimum distance between reference point (R) and 100% level | Minimum span | Maximum value for "empty calibration" |
|-----|--|--------------------|---------------------------------------|
| - 1 | $A \ge Length \ of antenna + 200 \ mm \ (8 \ in)$ Minimum value: 400 mm (16 in) | F ≥ 400 mm (16 in) | E ≤ 24 m (79 ft) |

- The linearity is checked under reference conditions.
- The selected values of **Empty calibration** and **Full calibration** are only used to record the linearity protocol and are reset to their antenna specific default values thereafter. If values different from the default are required, they must be ordered as a customized parametrization ($\rightarrow \boxed{2}$ 77).

If E and F are not specified, antenna dependent default values will be used instead.


Customized parametrization


If the option IJ "Customized parametrization HART", IK "Customized parametrization PA" or IL "Customized parametrization FF" has been selected in feature 570 "Service", customer specific presettings can be selected for the following parameters:


| Parameter | Communication | Selection list / range of values |
|--|------------------------|--|
| $Setup \rightarrow Distance \ unit$ | ■ HART ■ PA ■ FF | ■ in ■ mm |
| $Setup \rightarrow Empty \ calibration$ | ■ HART ■ PA ■ FF | 0 to 70 m (0 to 230 ft) |
| $Setup \to Full \ calibration$ | ■ HART ■ PA ■ FF | 0 to 70 m (0 to 230 ft) |
| Setup \rightarrow Adv. Setup \rightarrow Current output 1/2 \rightarrow Damping | HART | 0 to 999,9 s |
| Setup \rightarrow Adv. Setup \rightarrow Current output 1/2 \rightarrow Failure mode | HART | MinMaxLast valid value |
| | HART | Off On |





Accessories














Communication-specific accessories

| Accessory | Description |
|----------------------|---|
| Commubox FXA195 HART | For intrinsically safe HART communication with FieldCare via the USB interface. |
| | For details refer to Technical Information TI00404F |

| Accessory | Description |
|-----------------|---|
| Commubox FXA291 | Connects Endress+Hauser field devices with CDI interface (= Endress+Hauser Common Data Interface) to the USB interface of a computer. |
| | For details refer to Technical Information TI00405C |

| Accessory | Description |
|------------------------------|---|
| HART Loop Converter HMX50 | Evaluates the dynamic HART variables and converts them to analog current signals or limit values. |
| | For details refer to Technical Information TI00429F and Operating Instructions BA00371F |

| Accessory | Description |
|-------------------------------|---|
| WirelessHART Adapter SWA70 | Connects field devices to a WirelessHART network. The WirelessHART adapter can be mounted directly at a HART device and is easly integrated into an existing HART network. It ensures safe data transmission and can be operated in parallel with other wireless networks. For details refer to Operating Instructions BA00061S |

| Accessory | Description |
|------------------|---|
| Fieldgate FXA320 | Gateway for remote monitoring of connected 4-20mA measuring devices via web browser. |
| | For details refer to Technical Information T100025S and Operating Instructions BA00053S |

| Accessory | Description | |
|------------------|---|--|
| Fieldgate FXA520 | Gateway for remote diagnosis and parametrization of connected HART measuring devices via web browser. | |
| | For details refer to Technical Information TI00025S and Operating Instructions BA00051S | |

| Accessory | Description |
|--------------------|---|
| Field Xpert SFX100 | Compact, flexible and robust industry handheld terminal for remote parametrization and measured value inspection via the HART output or via FOUNDATION Fieldbus . |
| | For details refer to Operating Instructions BA00060S |

Service-specific accessories

| Accessory | Description | |
|-----------|---|--|
| FieldCare | Endress+Hauser's FDT-based Plant Asset Management tool. Helps to configure and maintain all field devices of your plant. By supplying status information it also supports the diagnosis of the devices. | |
| | For details refer to Operating Instructions BA00027S and BA00059S. | |

System components

| Accessory | Description |
|-------------------------------------|--|
| Graphic Data Manager Memograph M | The graphic data manager Memograph M provides information on all the relevant process variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on an SD card or USB stick. For details refer to Technical Information TI00133R and Operating Instructions BA00247R |
| RN221N | Active barrier with power supply for safe separation of 4 to 20 mA current circuits. |
| | Provides bi-directional HART transmission. |
| | For details refer to Technical Information TI00073R and Operating Instructions BA00202R |
| RNS221 | Transmitter supply for 2-wire sensors or transmitters exclusively for non-Ex areas. Provides bi-directional communication using the HART communication sockets. |
| | For details refer to Technical Information TI00081R and Operating Instructions KA00110R |



Documentation



The following document types are available: ■ On the CD supplied with the device

- lacktriangledown In the Download Area of the Endress+Hauser Internet site: www.endress.com ightarrow Download

Standard documentation

Micropilot FMR56, FMR57

Correlation of documentations to the device:

| Device | Power supply, output | Communikation | Document type | Document code |
|-----------------|--|----------------------------------|----------------------------------|----------------|
| FMP56, FMP57 | A, B, C, K, L | HART | Operating Instructions | BA01048F/00/EN |
| | | | Brief Operating Instructions | KA01102F/00/EN |
| | | | Description of Device Parameters | GP01014F/00/EN |
| | G | PROFIBUS PA (in preparation) | Operating Instructions | BA01127F/00/EN |
| | | | Brief Operating Instructions | KA01131F/00/EN |
| | | | Description of Device Parameters | GP01018F/00/EN |
| | E FOUNDATION Fieldbus (in preparation) | | Operating Instructions | BA01123F/00/EN |
| | | | Brief Operating Instructions | KA01127F/00/EN |
| | | Description of Device Parameters | GP01017F/00/EN | |

Supplementary documentation

| Device | Document type | Document code |
|--------------------------|----------------------------------|---------------|
| Fieldgate FXA520 | Technical Information | TI369F/00/EN |
| Tank Side Monitor NRF590 | Technical Information | TI402F/00/EN |
| | Operating Instructions | BA256F/00/EN |
| | Description of Device Parameters | BA257F/00/EN |

Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.

| Feature 010 | Approval | Available for | Safety Instructions HART | Safety Instructions PROFIBUS FOUNDATION Fieldbus |
|-------------|---|--------------------|--------------------------|--|
| BA | ATEX: II 1 G Ex ia IIC T6 Ga | ■ FMR56 ■ FMR57 | XA00677F | XA00685F |
| ВВ | ATEX: II 1/2 G Ex ia IIC T6-T1 Ga/Gb | ■ FMR56 ■ FMR57 | XA00677F | XA00685F |
| ВС | ATEX: II 1/2 G Ex d [ia] IIC T6-T1 Ga/Gb | ■ FMR56 ■ FMR57 | XA00680F | XA00688F |
| BD | ATEX: II 1/2/3 G Ex ic [ia Ga] IIC T6-T1 Ga/Gb/Gc | FMR57 | XA00678F | XA00686F |
| BE | ATEX: II 1 D Ex ta IIIC T500 xx°C Da | ■ FMR56 ■ FMR57 | XA00682F | XA00690F |
| BF | ATEX: II 1/2 D Ex ta IIIC Txx°C Da/Db | ■ FMR56 ■ FMR57 | XA00682F | XA00690F |
| BG | ATEX: II 3 G Ex nA IIC T6-T1 Gc | ■ FMR56 ■ FMR57 | XA00679F | XA00687F |
| ВН | ATEX: II 3 G Ex ic IIC T6-T1 Gc | ■ FMR56 ■ FMR57 | XA00679F | XA00687F |
| BL | ATEX: II 1/2/3 G Ex nA [ia Ga] IIC T6-T1 Ga/Gb/Gc | FMR57 | XA00678F | XA00686F |
| B2 | ATEX: II 1/2 G Ex ia IIC T6-T1 Ga/Gb ATEX: II 1/2 D Ex ia IIIC Txx°C Da/Db | ■ FMR56 ■ FMR57 | XA00683F | XA00691F |

| Feature 010 | Approval | Available for | Safety Instructions HART | Safety Instructions PROFIBUS FOUNDATION Fieldbus |
|-------------|---|--------------------|--------------------------|--|
| В3 | ATEX: II 1/2 G Ex d [ia] IIC T6-T1 Ga/Gb ATEX: II 1/2 D Ex ta IIIC Txx°C Da/Db | ■ FMR56 ■ FMR57 | XA00684F | XA00692F |
| IA | IECEx: Ex ia IIC T6-T1 Ga | ■ FMR56 ■ FMR57 | XA00677F | XA00685F |
| IB | IECEx: Ex ia IIC T6-T1 Ga/Gb | ■ FMR56 ■ FMR57 | XA00677F | XA00685F |
| IC | IECEx: Ex d [ia] IIC T6-T1 Ga/Gb | ■ FMR56 ■ FMR57 | XA00680F | XA00688F |
| ID | IECEx: Ex ic [ia Ga] IIC T6-T1 Ga/Gb/Gc | FMR57 | XA00678F | XA00686F |
| IE | IECEx: Ex ta IIIC T ₅₀₀ xx°C Da | ■ FMR56 ■ FMR57 | XA00682F | XA00690F |
| IF | IECEx: Ex ta IIIC Txx°C Da/Db | ■ FMR56 ■ FMR57 | XA00682F | XA00690F |
| IG | IECEx: Ex nA IIC T6-T1 Gc | ■ FMR56 ■ FMR57 | XA00679F | XA00687F |
| IH | IECEx: Ex ic IIC T6-T1 Gc | ■ FMR56 ■ FMR57 | XA00679F | XA00687F |
| IL | IECEx: Ex nA [ia Ga] IIC T6-T1 Ga/Gb/Gc | FMR57 | XA00678F | XA00686F |
| I2 | IECEx: Ex ia IIC T6-T1 Ga/Gb IECEx: Ex ia IIIC Txx°C Da/Db | ■ FMR56 ■ FMR57 | XA00683F | XA00691F |
| I3 | IECEx: Ex d [ia] IIC T6-T1 Ga/Gb IEXEx: Ex ta IIIC Txx°C Da/Db | ■ FMR56 ■ FMR57 | XA00684F | XA00692F |

For certified devices the relevant Safety Instructions (XA) are indicated on the nameplate.

If the device is prepared for the remote display FHX50 (product structure: feature 030: Display, Operation", option L or M), the Ex marking of some certificates changes according to the following table 6 :

| Feature 010 ("Approval") | Feature 030 ("Display, Operation") | Ex marking |
|--------------------------|------------------------------------|---|
| BE | L oder M | ATEX II 1D Ex ta [ia] IIIC T ₅₀₀ xx°C Da |
| BF | L oder M | ATEX II 1/2 D Ex ta [ia Db] IIIC Txx°C Da/Db |
| BG | L oder M | ATEX II 3G Ex nA [ia Ga] IIC T6 Gc |
| ВН | L oder M | ATEX II 3G Ex ic [ia Ga] IIC T6 Gc |
| B3 | L oder M | ATEX II 1/2G Ex d [ia] IIC T6 Ga/Gb, ATEX II 1/2D Ex ta [ia Db] IIIC Txx°C Da/Db |
| IE | L oder M | IECEx Ex ta [ia] IIIC T500 xx°C Da |
| IF | L oder M | IECEx ta [ia Db] IIIC Txx°C Da/Db |
| IG | L oder M | IECEx Ex nA [ia Ga] IIC Tó Gc |
| IH | L oder M | IECEx Ex ic [ia Ga] IIC T6 Gc |
| I3 | L oder M | IECEx Ex d [ia] IIC T6 Ga/Gb, IECEx Ex ta [ia Db] IIIC Txx°C Da/Db |

Endress+Hauser V. 1, Rev. 6, 19-10-2012 85

⁶⁾ The marking of certificates not mentioned in this table are not affected by the FHX50.

Registered trademarks

HART®

Registered trademark of the HART Communication Foundation, Austin, USA

PROFIBUS®

Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany

FOUNDATIONTM Fieldbus

Registered trademark of the Fieldbus Foundation, Austin, Texas, USA

KALREZ®, VITON®

Registered trademark of DuPont Performance Elastomers L.L.C., Wilmington, USA

TFFI ON®

Registered trademark of E.I. DuPont de Nemours & Co., Wilmington, USA

TRI CLAMP®

Registered trademark of Alfa Laval Inc., Kenosha, USA

Patents

This product may be protected by at least one of the following patents.

Further patents are pending.

| US Patents | EP Patents |
|------------|------------|
| 5.948.979 | 882 957 |
| 6.087.978 | 955 527 |
| 6.140.940 | - |
| 6.155.112 | 834 722 |
| - | 882 955 |
| 6.266.022 | 1 083 413 |
| 6.295.874 | 210 567 |
| 6.512.358 | 1 301 914 |
| 6.606.904 | - |
| 6.640.628 | - |
| 6.679.115 | 1 360 523 |
| - | 1 389 337 |
| 6.779.397 | - |
| 7.201.050 | - |
| 7.412.337 | - |
| 7.552.634 | - |
| 7.730.760 | - |
| 7.819.002 | - |
| - | 1 774 616 |
| 7.966.141 | - |
| 8.040.274 | - |
| 8.049.371 | - |





Instruments International

Endress+Hauser Instruments International AG Kaegenstrasse 2 4153 Reinach Switzerland

Tel.+41 61 715 81 00 Fax+41 61 715 25 00 www.endress.com info@ii.endress.com



People for Process Automation