

---

<b>Display</b>	SlotNo.	:<value>
<b>Format</b>	ReservedParameter1	:<value>
(for each	ReservedParameter2	:<value>
existing AU	ReservedParameter3	:<value>
object if	ReservedParameter4	:<value>
requested	ReservedParameter5	:<value>
for all AUs)	ReservedParameter6	:<value>
	ReservedParameter7	:<value>
	ReservedParameter8	:<value>
	ReservedParameter9	:<value>

---

**Command Modes** Global command mode

## 4.6 Managing ODUs

Up to 28 ODU objects can be created and configured, corresponding to up to 28 ODUs that can be installed. Up to four ODU Ports, numbered 1 to 4, can be created and configured for each ODU. However, for a 1by1 ODU only port number 1 is meaningful. For a 2by1 ODU only ports 1 and 2 are meaningful.

This section include:

- “Configuring ODUs”, Section 4.6.1
- “Configuring ODU Ports”, Section 4.6.2

### 4.6.1 Configuring ODUs



**To configure an ODU:**

- 1 Enable the ODU configuration mode for the selected ODU (refer to [Section 4.6.1.1](#))
- 2 You can now execute any of the following tasks:
  - » Configure one or more of the parameters tables of the ODU (refer to [Section 4.6.1.2](#))
  - » Restore the default values of parameters in one or more of the parameters tables of the ODU (refer to [Section 4.6.1.3](#))
- 3 Terminate the ODU configuration mode (refer to [Section 4.6.1.4](#))

In addition, you can, at any time, display configuration and status information for each of the parameters tables of the ODU (refer to [Section 4.6.1.6](#)) or delete an existing ODU object (refer to [Section 4.6.1.5](#)).

#### 4.6.1.1 Enabling the ODU Parameters Configuration Mode\Creating an ODU Object

To configure the parameters of an ODU, first enable the ODU parameters configuration mode for the specific ODU. Run the following command to enable the ODU parameters configuration mode for an existing ODU object:

```
npu (config)# odu-params <(1 to 28 StepSize 1)>
```

To create a new ODU object, the mandatory required-odu-type parameter must be specified. Run the following command to create a new ODU object and enable the parameters configuration mode for this ODU:

```
npu (config)# odu-params <(1 to 28 StepSize 1)> required-odu-type
{oDU23002360000N361by1N0 | oDU24962602000N361by1N0 |
oDU25902690000N361by1N0 | oDU24962602000N382by1N0 |
oDU25902690000N382by1N0 | oDU34003455000N341by1N0 |
oDU34453500000N341by1N0 | oDU35003555000N341by1N0 |
oDU35453600000N341by1N0 | oDU24962602000N384by2N0 |
oDU25902690000N384by2N0 | oDU34003600000N372by1N0 |
oDU36003800000N372by1N0 | oDU34003600000N374by2N0 |
oDU36003800000N374by2N0 | oDU23052360000N361by1Y0 |
oDU24962602000N392by1N0 | oDU25902690000N392by1N0 |
oDU24962602000N394by2N0 | oDU25902690000N394by2N0}
```

A new ODU object is created with default values for all parameters except to the mandatory required-odu-type parameter.



#### IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

For example, to create an ODU 1 object and enable the parameters configuration mode for this ODU, where the required odu type is oDU23002360000N361by1N0, run the following command:

```
npu (config)# odu-params 1 required-odu-type oDU23002360000N361by1N0
```

After enabling the parameters configuration mode for an ODU you can execute any of the following tasks:

- Configure one or more of the parameters tables of the ODU (refer to [Section 4.6.1.2](#))
- Restore the default values of parameters in one or more of the parameters tables of the ODU (refer to [Section 4.6.1.3](#))

After executing the above tasks, you can terminate the ODU parameters configuration mode (refer to [Section 4.6.1.4](#)) and return to the global configuration mode.

**Command**    **npu (config)# odu-params** <(1 to 28 StepSize 1)> [**required-odu-type**  
**Syntax**       {oDU23002360000N361by1N0 | oDU24962602000N361by1N0 | oDU25902690000N361by1N0 |  
oDU24962602000N382by1N0 | oDU25902690000N382by1N0 | oDU34003455000N341by1N0 |  
oDU34453500000N341by1N0 | oDU35003555000N341by1N0 | oDU35453600000N341by1N0 |  
oDU24962602000N384by2N0 | oDU25902690000N384by2N0 | oDU34003600000N372by1N0 |  
oDU36003800000N372by1N0 | oDU34003600000N374by2N0 | oDU36003800000N374by2N0 |  
oDU23052360000N361by1Y0 | oDU24962602000N392by1N0 | oDU25902690000N392by1N0 |  
oDU24962602000N394by2N0 | oDU25902690000N394by2N0}

**Privilege**    10  
**Level**

**Syntax**  
**Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 28 StepSize 1)>	The ODU number	Mandatory	N/A	1-28

	required-odu-type {oDU2300236000 0N361by1N0   oDU2496260200 0N361by1N0   oDU2590269000 0N361by1N0   oDU2496260200 0N382by1N0   oDU2590269000 0N382by1N0   oDU3400345500 0N341by1N0   oDU3445350000 0N341by1N0   oDU3500355500 0N341by1N0   oDU3545360000 0N341by1N0   oDU2496260200 0N384by2N0   oDU2590269000 0N384by2N0   oDU3400360000 0N372by1N0   oDU3600380000 0N372by1N0   oDU3400360000 0N374by2N0   oDU3600380000 0N374by2N0   oDU2305236000 0N361by1Y0   oDU2496260200 0N392by1N0   oDU2590269000 0N392by1N0   oDU2496260200 0N394by2N0   oDU2590269000 0N394by2N0}	The required ODU type (see details below).	Mandatory for a new ODU object	N/A	<ul style="list-style-type: none"> <li>■ oDU23002360000N361by1N0</li> <li>■ oDU24962602000N361by1N0</li> <li>■ oDU25902690000N361by1N0</li> <li>■ oDU24962602000N382by1N0</li> <li>■ oDU25902690000N382by1N0</li> <li>■ oDU34003455000N341by1N0</li> <li>■ oDU34453500000N341by1N0</li> <li>■ oDU35003555000N341by1N0</li> <li>■ oDU35453600000N341by1N0</li> <li>■ oDU24962602000N384by2N0</li> <li>■ oDU25902690000N384by2N0</li> <li>■ oDU34003600000N372by1N0</li> <li>■ oDU36003800000N372by1N0</li> <li>■ oDU34003600000N374by2N0</li> <li>■ oDU36003800000N374by2N0</li> <li>■ oDU23052360000N361by1Y0</li> <li>■ oDU24962602000N392by1N0</li> <li>■ oDU25902690000N392by1N0</li> <li>■ oDU24962602000N394by2N0</li> <li>■ oDU25902690000N394by2N0</li> </ul>
--	---	---	--------------------------------------	-----	--

**Command  
Modes**

Global configuration mode

ODU Type = oDUAAAABBBBZZZWPPRbyTCS, where:

AAAA = Lower bound of frequency band in MHz, rounded up to the nearest integer.

BBBB = Upper bound of frequency band in MHz, rounded down.

ZZZ = 000 in TDD systems.

W = N in TDD systems.

PP = maximum transmit power in dBm, rounded down.

R = number of receive channels.

T = number of transmit channels.

C = Y if cavity filter is present, N if not.

S = Reserved (0).

The currently available ODUs are:

**Table 4-27: Currently Available Single Port ODU Types**

ODU Type in CLI	ODU Marketing Name	Frequency Band (MHz)	Max Tx Power (dBm)
oDU23002360000N361by1N0	BMAX-AU-ODU-HP-2.3	2300-2360	36
oDU24962602000N361by1N0	BMAX-AU-ODU-HP-2.5A	2496-2602	36
oDU25902690000N361by1N0	BMAX-AU-ODU-HP-2.5B	2590-2690	36
oDU34003455000N341by1N0	BMAX-AU-ODU-HP-TDD-3.4a	3400-3455	34
oDU34453500000N341by1N0	BMAX-AU-ODU-HP-TDD-3.4b	3445-3500	34
oDU35003555000N341by1N0	BMAX-AU-ODU-HP-TDD-3.5a	3500-3555	34
oDU35453600000N341by1N0	BMAX-AU-ODU-HP-TDD-3.5b	3545-3600	34

**Table 4-28: Currently Available 4Rx x 2Tx ODU Types**

ODU Type in CLI	ODU Marketing Name	Frequency Band (MHz)	Max Tx Power (dBm)
oDU24962602000N384by2N0	ODU-2496-2602-000N-38-4x2-N-0	2496-2602	38
oDU25902690000N384by2N0	ODU-2590-2690-000N-38-4x2-N-0	2590-2690	38
oDU34003600000N374by2N0	ODU-3400-3600-000N-37-4x2-N-0	3400-3600	37
oDU36003800000N374by2N0	ODU-3600-3800-000N-37-4x2-N-0	3600-3800	37



**NOTE**

The following examples are for odu-1 parameters configuration mode.

### 4.6.1.2 Configuring ODU Parameters

After enabling the ODU parameters configuration mode you can configure the following parameters tables:

- General (refer to [Section 4.6.1.2.1](#))

- Reserved (refer to [Section 4.6.1.2.2](#))

### 4.6.1.2.1 Configuring General ODU Parameters

The general table enables configuring the main properties of the required ODU.

To configure the general ODU parameters, run the following command:

```
npu(config-odu-params-1)# odu-general [heater-existence {TRUE | FALSE} ]
[external-cavity-filter-existence {TRUE | FALSE} ] [required-odu-type
{oDU23002360000N361by1N0 | oDU24962602000N361by1N0 |
oDU25902690000N361by1N0 | oDU24962602000N382by1N0 |
oDU25902690000N382by1N0 | oDU34003455000N341by1N0 |
oDU34453500000N341by1N0 | oDU35003555000N341by1N0 |
oDU35453600000N341by1N0 | oDU24962602000N384by2N0 |
oDU25902690000N384by2N0 | oDU34003600000N372by1N0 |
oDU36003800000N372by1N0 | oDU34003600000N374by2N0 |
oDU36003800000N374by2N0 | oDU23052360000N361by1Y0 |
oDU24962602000N392by1N0 | oDU25902690000N392by1N0 |
oDU24962602000N394by2N0 | oDU25902690000N394by2N0} ]
```



#### NOTE

You can display configuration information for the ODU general parameters. For details, refer to [Section 4.6.1.6.1](#).



#### IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

<b>Command Syntax</b>	<pre>npu(config-odu-params-1)# odu-general [heater-existence {TRUE   FALSE} ] [external-cavity-filter-existence {TRUE   FALSE} ] [required-odu-type {oDU23002360000N361by1N0   oDU24962602000N361by1N0   oDU25902690000N361by1N0   oDU24962602000N382by1N0   oDU25902690000N382by1N0   oDU34003455000N341by1N0   oDU34453500000N341by1N0   oDU35003555000N341by1N0   oDU35453600000N341by1N0   oDU24962602000N384by2N0   oDU25902690000N384by2N0   oDU34003600000N372by1N0   oDU36003800000N372by1N0   oDU34003600000N374by2N0   oDU36003800000N374by2N0   oDU23052360000N361by1Y0   oDU24962602000N392by1N0   oDU25902690000N392by1N0   oDU24962602000N394by2N0   oDU25902690000N394by2N0} ]</pre>
-----------------------	---

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[heater-existence {TRUE   FALSE}]	Informational parameter indicating whether a heater for the ODU exists.	Optional	FALSE	<input type="checkbox"/> TRUE <input type="checkbox"/> FALSE
[external-cavity-filter-existence {TRUE   FALSE}]	Informational parameter indicating whether an external cavity filter for the ODU exists.	Optional	FALSE	<input type="checkbox"/> TRUE <input type="checkbox"/> FALSE
[required-odu-type {...}]	The required ODU type. For more details refer to <a href="#">Section 4.6.1.1</a>	Optional	The previously configured value	For details refer to <a href="#">Section 4.6.1.1</a>

**Command Modes** odu-params configuration mode

#### 4.6.1.2.2 Configuring ODU Reserved Parameters

As the name implies, the reserved parameters table enables configuring up to 9 parameters that are reserved for possible future use. In the current release none of the reserved parameters is being used.

To configure the ODU reserved parameters, run the following command:

```
npu(config-odu-params-1)# odu-reserved [reserved-1 <string (32)>]
[reserved-2 <string (32)>] [reserved-3 <string (32)>] [reserved-4
<string (32)>] [reserved-5 <string (32)>] [reserved-6 <string
(32)>] [reserved-7 <string (32)>] [reserved-8 <string (32)>]
[reserved-9 <string (32)>].
```

**Command Syntax** npu (config-odu-params-1)# odu-reserved [reserved-1 <string (32)>] [reserved-2 <string (32)>] [reserved-3 <string (32)>] [reserved-4 <string (32)>] [reserved-5 <string (32)>] [reserved-6 <string (32)>] [reserved-7 <string (32)>] [reserved-8 <string (32)>] [reserved-9 <string (32)>]



**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[reserved-N <string (32)>] (N=1-9)	Reserved parameter number N	Optional	null (an empty string)	A string of 32 printable characters.

**Command Modes** odu-params configuration mode

### 4.6.1.3 Restoring Default Values for ODU Configuration Parameters

After enabling the ODU parameters configuration mode you can restore the default values for parameters in the following parameters tables:

- General (refer to [Section 4.6.1.3.1](#))
- Reserved (refer to [Section 4.6.1.3.2](#))

#### 4.6.1.3.1 Restoring the Default Values of General Parameters

To restore one or all of the general parameters to their default value (excluding the mandatory required-odu-type parameter), run the following command:

```
npu(config-odu-params-1)# no odu-general [heater-existence]
[external-cavity-filter-existence]
```

You can restore only one parameter to its default value by specifying only that parameter. For example, to restore only the heater-existence to the default value (FALSE), run the following command:

```
npu(config-odu-params-1)# no odu-general heater-existence
```

The parameter will be restored to its default value, while the other parameters will remain unchanged.

To restore all general parameters to their default value, run the following command:

```
npu(config-odu-params-1)# no odu-general
```

**NOTE**

Refer to [Section 4.6.1.2.1](#) for a description and default values of these parameters.

---

**Command Syntax** `npu(config-odu-params-1)# no odu-general [heater-existence] [external-cavity-filter-existence]`

---

**Privilege Level** 10

---

**Command Modes** odu-params configuration mode

### 4.6.1.3.2 Restoring the Default Values of ODU Reserved Parameters

To restore the ODU Reserved parameters to their default value, run the following command:

```
npu(config-odu-params-1)# no odu-reserved [reserved-1] [reserved-2]
[reserved-3] [reserved-4] [reserved-5] [reserved-6] [reserved-7]
[reserved-8] [reserved-9]
```

You can restore only selected parameters to their default value by specifying only those parameter. For example, to restore only the reserved-1 parameter to its default values, run the following command:

```
npu(config-odu-params-1)# no odu-reserved reserved-1
```

This parameter will be restored to the default value, while the other parameters will remain unchanged.

To restore all parameters to their default value, run the following command:

```
npu(config-odu-params-1)# no odu-reserved
```

**NOTE**

Refer to [Section 4.6.1.2.2](#) for a description and default values of these parameters.

---

**Command Syntax** `npu(config-odu-params-1)# no odu-reserved [reserved-1] [reserved-2] [reserved-3] [reserved-4] [reserved-5] [reserved-6] [reserved-7] [reserved-8] [reserved-9]`

---

**Privilege Level** 10

---

**Command Modes** odu-params configuration mode

#### 4.6.1.4 Terminating the ODU Parameters Configuration Mode

Run the following command to terminate the ODU Parameters configuration mode:

**npu(config-odu-params-1)# exit**

---

**Command Syntax** npu(config-odu-params-1)# exit

---

**Privilege Level** 10

---

**Command Modes** odu-params configuration mode

#### 4.6.1.5 Deleting an ODU Object

Run the following command to delete an ODU object:

**npu(config)# no odu-params <(1 to 28 StepSize 1)>**



#### IMPORTANT

An associated ODU (specified in a Sector Association) cannot be deleted.

---

**Command Syntax** npu(config)# no odu-params <(1 to 28 StepSize 1)>

---

**Privilege Level** 10

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 28 StepSize 1)>	The ODU number	Mandatory	N/A	1-28

**Command**

Global configuration mode

**Modes**

### 4.6.1.6 Displaying Configuration and Status Information for ODU Parameters

You can display the current configuration and (where applicable) additional status information for the following parameters tables:

- General (refer to [Section 4.6.1.6.1](#))
- Reserved (refer to [Section 4.6.1.6.2](#))

#### 4.6.1.6.1 Displaying Configuration and Status Information for ODU General Parameters

To display configuration and status information for the general parameters of a specific or all ODU objects, run the following command:

```
npu# show odu-general [odu-no <(1 to 28 StepSize 1)>]
```

Specify the ODU number (1-28) if you want to display configuration and status information for a particular ODU. Do not specify a value for this parameter if you want to view configuration and status information for all existing ODU objects.

**Command****npu# show odu-general** [odu-no <(1 to 28 StepSize 1)> ]**Syntax****Privilege**

1

**Level**

**Syntax**

**Description**

Parameter	Description	Presence	Default Value	Possible Values
[odu-no <(1 to 28 StepSize 1)> ]	The number of the ODU  Specify a value for this parameter if you want to display the general parameters of a specific ODU. Do not specify a value for this parameter if you want to display the general parameters of all ODUs.	Optional	N/A	1-28

**Display Format**

(for each existing ODU object if requested for all ODUs)

ODUNo.	:<value>
HeaterExistence	:<value> or (0) if object does not exist
ExternalCavityFilterExistence	:<value> or (0) if object does not exist
RequiredODUType	:<value> or (0) if object does not exist
InstalledODUType	:<value> or (0) if ODU is not installed
SerialNumber	:<value> or null if ODU is not installed

**Command Modes**

Global command mode

In addition to the configurable parameters, the following status parameters are also displayed:

Parameter	Description	Possible Values
InstalledODUType	The installed ODU Type.	<ul style="list-style-type: none"> <li>■ oDU23002360000N361by1N0 (1)</li> <li>■ oDU24962602000N361by1N0 (2)</li> <li>■ oDU25902690000N361by1N0 (3)</li> <li>■ oDU24962602000N382by1N0 (4)</li> <li>■ oDU25902690000N382by1N0 (5)</li> <li>■ oDU34003455000N341by1N0 (6)</li> <li>■ oDU34453500000N341by1N0 (7)</li> <li>■ oDU35003555000N341by1N0 (8)</li> <li>■ oDU35453600000N341by1N0 (9)</li> <li>■ oDU24962602000N384by2N0 (10)</li> <li>■ oDU25902690000N384by2N0 (11)</li> <li>■ oDU34003600000N372by1N0 (12)</li> <li>■ oDU36003800000N372by1N0 (13)</li> <li>■ oDU34003600000N374by2N0 (14)</li> <li>■ oDU36003800000N374by2N0 (15)</li> <li>■ oDU23052360000N361by1Y0 (16)</li> <li>■ oDU24962602000N392by1N0 (17)</li> <li>■ oDU25902690000N392by1N0 (18)</li> <li>■ oDU24962602000N394by2N0 (19)</li> <li>■ oDU25902690000N394by2N0 (20)</li> <li>■ odunotDetected (97)</li> <li>■ odutypeUnknown (98)</li> <li>■ odunotAssociated to sector (0)</li> </ul>
SerialNumber	The ODU serial number	<number>

### 4.6.1.6.2 Displaying Configuration Information for ODU Reserved Parameters

To display configuration information for the reserved parameters of a specific or all ODU objects, run the following command:

```
npu# show odu-reserved [odu-no <(1 to 28 StepSize 1)>]
```

Specify the ODU number (1-28) if you want to display configuration for a particular ODU. Do not specify a value for this parameter if you want to view configuration for all existing ODU objects.

---

**Command Syntax**     **npu# show odu-reserved** [odu-no <(1 to 28 StepSize 1)> ]

---

**Privilege Level**     1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[odu-no <(1 to 28 StepSize 1)> ]	The number of the ODU  Specify a value for this parameter if you want to display the reserved parameters of a specific ODU. Do not specify a value for this parameter if you want to display the reserved parameters of all ODUs.	Optional	N/A	1-28

<b>Display</b>	ODUNo.	: <value>
<b>Format</b>	ReservedParameter1	: <value>
(for each existing ODU object if requested for all ODUs)	ReservedParameter2	: <value>
	ReservedParameter3	: <value>
	ReservedParameter4	: <value>
	ReservedParameter5	: <value>
	ReservedParameter6	: <value>
	ReservedParameter7	: <value>
	ReservedParameter8	: <value>
	ReservedParameter9	: <value>

**Command Modes** Global command mode

## 4.6.2 Configuring ODU Ports

Up to four ODU Ports, numbered 1 to 4, can be created and configured for each ODU. However, for a 1by1 ODU only port number 1 is meaningful. For a 2by1 ODU only ports 1 and 2 are meaningful.



### To configure an ODU Port:

- 1 Enable the ODU Port configuration mode for the selected ODU Port (refer to [Section 4.6.2.1](#))
- 2 You can now execute any of the following tasks:
  - » Configure one or more of the ODU Port parameters (refer to [Section 4.6.2.2](#))
  - » Restore the default value of the txpower-onoff parameter (refer to [Section 4.6.2.3](#))
- 3 Terminate the ODU Port configuration mode (refer to [Section 4.6.2.4](#))

In addition, you can, at any time, display configuration and status information for each or all of the ODU Ports (refer to [Section 4.6.2.6](#)) or delete an existing ODU Port (refer to [Section 4.6.2.5](#)).



### 4.6.2.1 Enabling the ODU Port Configuration Mode\Creating an ODU Port

To configure the parameters of an ODU Port, first enable the ODU Port configuration mode for the specific ODU Port. Run the following command to enable the ODU Port configuration mode for an existing ODU Port:

```
npu (config)# odu-port <(1 to 28 StepSize 1)> <(1 to 4 StepSize 1)>
```

To create a new ODU Port, the mandatory txpower parameter must be specified. Run the following command to create a new ODU Port and enable the configuration mode for this ODU Port:

```
npu (config)# odu-port <(1 to 28 StepSize 1)> <(1 to 4 StepSize 1)> txpower  
<(0 to 46 StepSize 0.1)>
```

A new ODU Port is created with default values for the txpower-onoff parameter. For example, to create Port 1 in ODU 1 with a configured Tx Power of 34 dBm, and enable the parameters configuration mode for this ODU Port run the following command:

```
npu (config)# odu-port 1 1 txpower 34
```

After enabling the configuration mode for an ODU Port you can execute any of the following tasks:

- Configure one or more of the parameters of the ODU Port (refer to [Section 4.6.2.2](#))
- Restore the default value of the txpower-onoff parameter (refer to [Section 4.6.2.3](#))

After executing the above tasks, you can terminate the ODU Port configuration mode (refer to [Section 4.6.2.4](#)) and return to the global configuration mode.

<b>Command Syntax</b>	<b>npu (config)# odu-port</b> <(1 to 28 StepSize 1)> <(1 to 4 StepSize 1)> [ <b>txpower</b> <(0 to 46 StepSize 0.1)>]
-----------------------	---

<b>Privilege Level</b>	10
------------------------	----

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 28 StepSize 1)>	The ODU number	Mandatory	N/A	1-28
<(1 to 4 StepSize 1)>	The Port number.	Mandatory	N/A	1-4
[txpower <(0 to 46 StepSize 0.1)>]	The required tx power at the specified ODU Port, in dBm.  The actually available range depends on ODU Type: The upper limit is set by the Maximum Tx Power supported by the ODU (see <a href="#">“Currently Available Single Port ODU Types” on page 487</a> ). The control range for all ODUs is 10dBm, except to the following ODUs whose control range is 6dBm: oDU23002360000N361by1N0, oDU24962602000N361by1N0, oDU25902690000N361by1N0, oDU23052360000N361by1Y0	Mandatory for a new ODU Port	N/A	0 to 46 in increments of 0.1

**Command Modes**

Global configuration mode

**NOTE**

The following examples are for odu-1, port-1 configuration mode.

### 4.6.2.2 Configuring ODU Port Parameters

After enabling the ODU Port configuration mode you can configure the transmit power parameters of the port.

To configure the ODU Port parameters, run the following command:

```
npu(config-odu-port-1-1)# params [txpower <(0 to 46 StepSize 0.1)> ]
[txpower-onoff {on | off} ]
```

**NOTE**

You can display configuration information for the ODU Port parameters. For details, refer to [Section 4.6.2.6](#).

**IMPORTANT**

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

**Command Syntax** `npu(config-odu-port-1-1)# params [txpower <(0 to 46 StepSize 0.1)>] [txpower-onoff {on | off} ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[txpower <(0 to 46 StepSize 0.1)>]	The transmit power at the ODU Port, in dBm.	Optional	As configured previously	0 to 46 in increments of 0.1  Actual range depends on ODU type.
[txpower-onoff {on   off} ]	Enables or disables transmissions on this port.	Optional	on	<input type="checkbox"/> on  <input type="checkbox"/> off

**Command Modes** odu-port configuration mode

**IMPORTANT**

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

### 4.6.2.3 Restoring Default Values for ODU Port Parameters

After enabling the ODU Port configuration mode you can restore the default values for the txpower-onoff parameter:

To restore the default values for the txpower-onoff parameter, run the following command:

```
npu(config-odu-port-1-1)# no params
```

The txpower-onoff parameter will be restored to its default value (on), while the mandatory txpower parameter will remain unchanged.

---

**Command Syntax**    `npu(config-odu-port-1-1)# no params`

---

**Privilege Level**    10

---

**Command Modes**    odu-port configuration mode

#### 4.6.2.4 Terminating the ODU Port Configuration Mode

Run the following command to terminate the ODU Port configuration mode:

**`npu(config-odu-port-1-1)# exit`**

---

**Command Syntax**    `npu(config-odu-port-1-1)# exit`

---

**Privilege Level**    10

---

**Command Modes**    odu-port configuration mode

#### 4.6.2.5 Deleting an ODU Port

Run the following command to delete an ODU Port:

**`npu(config)# no odu-port` <(1 to 28 StepSize 1)> <(1 to 4 StepSize 1)>**



#### IMPORTANT

An associated ODU Port (specified in a Sector Association) cannot be deleted.

---

**Command Syntax**    `npu(config)# no odu-params` <(1 to 28 StepSize 1)> <(1 to 4 StepSize 1)>

---

**Privilege Level** 10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 28 StepSize 1)>	The ODU number	Mandatory	N/A	1-28
<(1 to 4 StepSize 1)>	The Port number	Mandatory	N/A	1-4

---

**Command Modes** Global configuration mode

### 4.6.2.6 Displaying Configuration and Status Information for ODU Ports

To display configuration and status information of a specific or all ODU Ports, run the following command:

**npu# show odu-port** [odu-no <(1 to 28 StepSize 1)> port-no <(1 to 4 StepSize 1)>]

Specify the ODU number (1-28) and Port number (1-4) if you want to display configuration and status information for a particular ODU Port. Do not specify values for these parameters if you want to view configuration and status information for all existing ODU Ports.

---

**Command Syntax** **npu# show odu-port** [odu-no <(1 to 28 StepSize 1)> port-no <(1 to 4 StepSize 1)> ]

---

**Privilege Level** 1

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
[odu-no <(1 to 28 StepSize 1)> ]	The number of the ODU  Specify a value for this parameter if you want to display the parameters of a specific ODU Port. Do not specify a value for this parameter if you want to display the general parameters of all ODU Ports.	Optional	N/A	1-28
[port-no <(1 to 4 StepSize 1)> ]	The number of the Port  Specify a value for this parameter if you want to display the parameters of a specific ODU Port. Do not specify a value for this parameter if you want to display the general parameters of all ODU Portss.	Optional	N/A	1-4

**Display****Format**

(for each existing

ODU Port if requested for all ODU Ports)

ODUNo .	:<value>
ODUPortNo	:<value>
TxPower (dBm)	:<value>
TxEnable	:<value>
HWVersion	:<value>
HWRevision	:<value>
HPACard	:<value>
HPAHWVersion	:<value>
HC08SWVersion	:<value>
CPLDSWVersion	:<value>
SerialNumber	:<value>
txpower-status	:<value>

**Command Modes**

Global command mode

In addition to the configurable parameters, the following status parameters are also displayed:

Parameter	Description	Possible Values
HWVersion	HW version no. of ODU basic card connected to this port	<number>
HWRevision	HW revision no. of ODU basic card connected to this port	<number>
HPACard	Indicates whether the port is connected to an HPA card	<input checked="" type="checkbox"/> installed (1) <input type="checkbox"/> notInstalled (0)
HPAHWVersion	HW version no. of HPA connected to this port (relevant only if HPACard is installed)	<number>
HC08SWVersion	SW version of HC08 controlling card connected to this port	<string>
CPLDSWVersion	SW version of CPLD controlling card connected to this port	<string>
SerialNumber	Serial number of ODU basic card connected to this port	<number>
txpower-status	The operation status of the port	<enabled/disabled>

## 4.7 Managing Antennas

Up to 28 Antenna objects, identified by the Antenna number (1-28), can be created and configured.



### To configure an Antenna:

- 1 Enable the Antenna configuration mode for the selected Antenna (refer to [Section 4.7.1](#))
- 2 You can now execute any of the following tasks:
  - » Configure one or more of the Antenna parameters ([Section 4.7.2](#))
  - » Restore the default value of some or all of the Antenna parameters (refer to [Section 4.7.3](#))
- 3 Terminate the Antenna configuration mode (refer to [Section 4.7.4](#))

In addition, you can, at any time, display configuration information for one or all of the Antennas (refer to [Section 4.7.6](#)) or delete an existing Antenna (refer to [Section 4.7.5](#)).

### 4.7.1 Enabling the Antenna Configuration Mode\Creating an Antenna

To configure the parameters of an Antenna, first enable the Antenna configuration mode for the specific Antenna. Run the following command to enable the Antenna configuration mode for an existing Antenna:

```
npu (config)# antenna <(1 to 28 StepSize 1)>
```

To create a new Antenna, the mandatory heading parameter must be specified. Run the following command to create a new Antenna and enable the configuration mode for this Antenna:

```
npu (config)# antenna <(1 to 28 StepSize 1)> heading <(0 to 359 StepSize 1)>
```

A new Antenna is created with default values for all other parameters.



**IMPORTANT**

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

For example, to create Antenna 1 with a configured heading of 90 degrees and enable the parameters configuration mode for this Antenna, run the following command:

```
npu (config)# antenna 1 heading 90
```

**CAUTION**

When an antenna is associated to a sector, the antenna heading must be the same as the sector heading for every antenna associated to the sector.

After enabling the configuration mode for an Antenna you can execute any of the following tasks:

- Configure one or more of the parameters of the Antenna (refer to [Section 4.7.2](#))
- Restore the default value of the non-mandatory parameters parameter (refer to [Section 4.7.3](#))

After executing the above tasks, you can terminate the Antenna configuration mode (refer to [Section 4.7.4](#)) and return to the global configuration mode.

**Command Syntax**

```
npu (config)# antenna <(1 to 28 StepSize 1)> [heading <(0 to 359 StepSize 1)>]
```

**Privilege Level**

10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 28 StepSize 1)>	The ODU number	Mandatory	N/A	1-28

[heading <(0 to 359 StepSize 1)>]	Indicates the azimuth angle (in degrees) between the center of the horizontal antenna beamwidth and the true north; counting clockwise.	Mandatory for a new Antenna	N/A	0 to 359
-----------------------------------	---	-----------------------------	-----	----------

**Command Modes** Global configuration mode



#### NOTE

The following examples are for antenna-1 configuration mode.

## 4.7.2 Configuring Antenna Parameters

After enabling the Antenna configuration mode you can configure the Antenna parameters.

To configure the Antenna parameters, run the following command:

```
npu(config-antenna-1)# params [antenna-type <string (32)>] [no-of-ports <(1 to 8 StepSize 1)>] [gain <(0 to 60 StepSize 0.1)>] [mechanical-downtilt <(-90 to 90 StepSize 0.1)>] [electrical-downtilt <(-90 to 90 StepSize 0.2)>] [electrical-azimuth-adjustment <(-90 to 90 StepSize 0.3)>] [longitude <longitude>] [latitude <latitude>] [tower-height <(0 to 500 StepSize 1)>] [altitude <(-500 to 10000 StepSize 1)>] [heading <(0 to 359 StepSize 1)>] [beamwidth <(0 to 359 StepSize 1)>] [cable-loss <(0 to 20 StepSize 0.1)>]
```

**Command Syntax** **npu(config-antenna-1)# params** [antenna-type <string (32)> ] [no-of-ports <(1 to 8 StepSize 1)> ] [gain <(0 to 60 StepSize 0.1)> ] [mechanical-downtilt <(-90 to 90 StepSize 0.1)> ] [electrical-downtilt <(-90 to 90 StepSize 0.2)> ] [electrical-azimuth-adjustment <(-90 to 90 StepSize 0.3)> ] [longitude <longitude> ] [latitude <latitude> ] [tower-height <(0 to 500 StepSize 1)> ] [altitude <(-500 to 10000 StepSize 1)> ] [heading <(0 to 359 StepSize 1)> ] [beamwidth <(0 to 359 StepSize 1)> ] [cable-loss <(0 to 20 StepSize 0.1)> ]

**Privilege Level** 10

**Syntax****Description**

<b>Parameter</b>	<b>Description</b>	<b>Presence</b>	<b>Default Value</b>	<b>Possible Values</b>
[antenna-type <string (32)> ]	Antenna type to be populated manually for inventory information only	Optional	N/A	String (up to 32 printable characters)
[no-of-ports <(1 to 8 StepSize 1)> ]	The number of antenna ports	Optional	1	1-8
[gain <(0 to 60 StepSize 0.1)> ]	Antenna Gain (in dB)	Optional	17	0-60 in steps of 0.1
[mechanical-downtilt <(-90 to 90 StepSize 0.1)> ]	Downwards mechanical tilt of the antenna (in degrees) as opposed to the electrical tilt already integrated in the antenna (and thus taken as reference; instead of the horizontal plane)	Optional	0	-90.0 to 90.0 in steps of 0.1
[electrical-downtilt <(-90 to 90 StepSize 0.1)> ]	Downwards electrical tilt of the antenna, in degrees	Optional	0	-90.0 to 90.0 in steps of 0.1
[electrical-azimuth-adjustment <(-90 to 90 StepSize 0.1)> ]	Electrical azimuth adjustment of the antenna, in degrees (in a clockwise direction)	Optional	0	-90.0 to 90.0 in steps of 0.1
[longitude <longitude> ]	The longitude of the antenna. The recommended format is III.mmm.a where III.mmm is the longitude in degrees (III - between 000 and 180, mmm - between 000 and 999), a is E (East) or W (West).	Optional	000.000; E	String
[latitude <latitude> ]	The latitude of the antenna. The recommended format is III.mmm.a where III.mmm is the longitude in degrees (III - between 000 and 90, mmm - between 000 and 999), a is N (North) or S (South).	Optional	000.000; E	String
[tower-height <(0 to 500 StepSize 1)> ]	Defines the height of the antenna above the ground in meters.	Optional	0	0-500

[altitude <(-500 to 10000 StepSize 1)> ]	Absolute altitude of the sector (above sea level) in meters.	Optional		-500 to 10000
[heading <(0 to 359 StepSize 1)> ]	Indicates the azimuth angle (in degrees) between the center of the horizontal antenna beamwidth and the true north; counting clockwise.	Optional		0-359
[beamwidth <(0 to 359 StepSize 1)> ]	Beamwidth of the antenna in degrees	Optional	60	0-359
[cable-loss <(0 to 20 StepSize 0.1)> ]	The attenuation (in dB) of the cable between the ODU port and antenna port (informative only)	Optional	0.5	0-20 in steps of 0.1

**Command Modes** antenna configuration mode



#### NOTE

You can display configuration information for the Antenna parameters. For details, refer to [Section 4.7.6](#).



#### IMPORTANT

An error may occur if you provide an invalid value for any of these parameters. Refer the syntax description for more information about the appropriate values and format for configuring these parameters.

### 4.7.3 Restoring Default Values for Antenna Parameters

After enabling the Antenna configuration mode you can restore the default values for some or all of the parameters (excluding the mandatory heading parameter).

To restore one or several Antenna parameters do their default value, run the following command:

```

npu(config-antenna-1)# no params [antenna-type] [no-of-ports]
[ gain] [mechanical-downtilt] [electrical-downtilt]
[electrical-azimuth-adjustment] [longitude] [latitude]
[tower-height] [altitude] [beamwidth] [cable-loss]

```

You can restore one or several parameters to the default value(s) by specifying only those parameter. For example, to restore only the mechanical-downtilt and electrical-downtilt to their default values, run the following command:

```
npu(config-antenna-1)# no params mechanical-downtilt
electrical-downtilt
```

The mechanical-downtilt and electrical-downtilt will be restored to their default values, while all other parameters will remain unchanged.

To restore all parameters to their default value, run the following command:

```
npu(config-antenna-1)# no params
```



#### NOTE

Refer to [Section 4.7.2](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<b>npu(config-antenna-1)# no params</b> [antenna-type] [no-of-ports] [gain] [mechanical-downtilt] [electrical-downtilt] [electrical-azimuth-adjustment] [longitude] [latitude] [tower-height] [altitude] [beamwidth] [cable-loss]
-----------------------	---

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	antenna configuration mode
----------------------	----------------------------

## 4.7.4 Terminating the Antenna Configuration Mode

Run the following command to terminate the Antenna configuration mode:

```
npu(config-antenna-1)# exit
```

<b>Command Syntax</b>	<b>npu(config-antenna-1)# exit</b>
-----------------------	------------------------------------

<b>Privilege Level</b>	10
------------------------	----

**Command** antenna configuration mode  
**Modes**

## 4.7.5 Deleting an Antenna

Run the following command to delete an Antenna:

**npu(config)# no antenna** <(1 to 28 StepSize 1)>



### IMPORTANT

An associated Antenna (specified in a Sector Association) cannot be deleted.

**Command Syntax** npu(config)# no antenna <(1 to 28 StepSize 1)>

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 28 StepSize 1)>	The Antenna number	Mandatory	N/A	1-28

**Command Modes** Global configuration mode

## 4.7.6 Displaying Configuration Information for Antennas

To display configuration information of a specific or all Antennas, run the following command:

**npu# show antenna** [antenna-no <(1 to 28 StepSize 1)>]

Specify the Antenna number (1-28) if you want to display configuration information for a particular Antenna. Do not specify values for this parameter if you want to view configuration information for all existing Antennas.

**Command Syntax**     **npu# show antenna** [antenna-no <(1 to 28 StepSize 1)>]

**Privilege Level**     1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[antenna-no <(1 to 28 StepSize 1)> ]	The number of the Antenna  Specify a value for this parameter if you want to display the parameters of a specific Antenna. Do not specify a value for this parameter if you want to display the parameters of all Antennas.	Optional	N/A	1-28

**Display Format**

(for each existing Antenna if requested for all Antennas)

AntennaNo .	: <value>
AntennaType	: <value>
No.ofPorts	: <value>
Gain(dB)	: <value>
MechanicalDownTilt(degrees)	: <value>
ElectricalDownTilt(degrees)	: <value>
ElectricalAzimuthAdjustment(degrees)	: <value>
Longitude	: <value>
Latitude	: <value>
TowerHeight(meters)	: <value>
Altitude(meters)	: <value>
AntennaHeading(degrees)	: <value>
AntennaBeamWidth(degrees)	: <value>
CableLoss(dB)	: <value>

**Command**    Global command mode  
**Modes**



## 4.8 Managing BSs

Up to 28 different BSs can be defined.

The full configuration of each BS includes multiple components (tables). Many of these tables include one or more mandatory parameters (parameters with no default value). The creation of a new BS is not completed until all mandatory parameters have been configured.

For each table that has only optional (non-mandatory) parameters, at least one parameter must be configured explicitly (even if not changed from the default value) when creating a new BS.

Due to the complicated structure of the BS object and the high number of mandatory parameters in different tables, a special **apply** command must be executed for properly completing the configuration of certain tables. The **apply** command must be executed before exiting the applicable configuration mode. Failure to execute the **apply** command will result in loss of the newly configured parameters. Wherever required, the need to use the **apply** command will be indicated in the manual.

The following table lists the tasks for configuring a BS, indicating the applicable mandatory parameters and the need to execute the **apply** command where applicable. When configuring a new BS, verify that all mandatory parameters have been configured (otherwise a trial to associate the BS to a Sector will fail):

**Table 4-29: Tasks for Configuring a BS**

Task	Mandatory Parameters	apply required
<a href="#">“Enabling the BS Configuration Mode\Creating a BS Object” on page 518</a>	bs id	No
<a href="#">“Managing BS General Parameters” on page 520</a>		No
<a href="#">“Managing BS Services” on page 523</a>	service name (type)	Yes

**Table 4-29: Tasks for Configuring a BS**

<b>Task</b>	<b>Mandatory Parameters</b>	<b>apply required</b>
<a href="#">“Managing Service Mapping Rules” on page 529</a>	service mapping rule index srvc (service-name) order r1 profile parameters: <ul style="list-style-type: none"> <li>■ datadelivery-type</li> <li>■ priority</li> <li>■ mir</li> <li>■ cir</li> <li>■ jitter</li> <li>■ latency</li> <li>■ sdu-size</li> <li>■ grant-interval</li> </ul>	Yes
<a href="#">“Managing Power Control Levels and Policies” on page 548</a>		Yes
<a href="#">“Managing BS Feedback Allocation Parameters” on page 580</a>	max-cqi	No
<a href="#">“Managing Neighbor Advertisement Parameters” on page 584</a>		No
<a href="#">“Managing Triggers Parameters” on page 587</a>		No
<a href="#">“Managing Trigger Setup Parameters” on page 591</a>		No
<a href="#">“Managing Scan Negotiation Parameters” on page 595</a>		No
<a href="#">“Managing Handover Negotiation at SBS Parameters” on page 599</a>		No

**Table 4-29: Tasks for Configuring a BS**

Task	Mandatory Parameters	apply required
<a href="#">“Managing Neighbor BSs” on page 606</a>	General Parameters: <ul style="list-style-type: none"> <li>■ eirp</li> <li>■ bw</li> <li>■ feedbackzone-permbase</li> <li>■ ucd-configchangecount</li> <li>■ dcd-configchangecount</li> <li>■ frequency</li> <li>■ restartcount</li> <li>■ preamble-idx</li> </ul>	Yes
<a href="#">“Managing UCD Parameters” on page 629</a>		No
<a href="#">“Managing DCD Parameters” on page 633</a>		No
<a href="#">“Managing the RF Frequency Parameter” on page 637</a>	frequency	No
<a href="#">“Managing the Baseband Bandwidth Parameter” on page 640</a>	bandwidth	No

**Table 4-29: Tasks for Configuring a BS**

Task	Mandatory Parameters	apply required
“Managing Airframe Structure Parameters” on page 642	General Parameters: <ul style="list-style-type: none"> <li>■ cell-id</li> <li>■ segment</li> <li>■ frame-offset</li> <li>■ ul-dl-allocation</li> </ul> Map Zone Parameters: <ul style="list-style-type: none"> <li>■ majorgrps</li> </ul> Uplink Feedback Zone Parameters: <ul style="list-style-type: none"> <li>■ permbase</li> </ul> Downlink Data Zone: <ul style="list-style-type: none"> <li>■ subchannels</li> <li>■ permbase</li> </ul> Uplink Data Zone: <ul style="list-style-type: none"> <li>■ subchannels</li> </ul>	Yes
“Managing Rate Adaptation Parameters” on page 683		No
“Managing BS Bearer Interface Parameters” on page 692	ip-address ip-subnetmask dflt-gw	No
“Managing Authentication Relay Parameters” on page 695	dflt-auth-ip-address	No
“Managing Handover Control Parameters” on page 700		No
“Managing Bearer Traffic QoS Marking Rules” on page 704	enable-srvclow-mediaflowtype srvclow-mediaflowtype (if enable-srvclow-mediaflowtype is set to True)	Yes
“Managing Control Traffic QoS Marking Rules” on page 712		Yes

Table 4-29: Tasks for Configuring a BS

Task	Mandatory Parameters	apply required
<a href="#">“Managing BS Management Alarm Thresholds Parameters” on page 721</a>		No
<a href="#">“Managing ID-IP Mapping Parameters” on page 724</a>	nw-node-id (Next Hop BS ID) nw-node-ip	No
<a href="#">“Managing Ranging Parameters” on page 728</a>		Yes
<a href="#">“Managing Alarm Threshold Parameters” on page 750</a>		No
<a href="#">“Managing BS Reserved Parameters” on page 756</a>		No
<a href="#">“Managing the BS Keep-Alive Functionality” on page 760</a>		No

### 4.8.1 Enabling the BS Configuration Mode\Creating a BS Object

To configure the parameters of a BU, first enable the BS configuration mode for the specific BS. Run the following command to enable the BS configuration mode. You can also use this command to create a new BS object. Note that for a new object this command only defines the BS ID, and that the BS is not fully created until completing configuration of all mandatory parameters.

The BS ID is the unique identifier of the BS in the access network. The BS ID used in the system is in the format A.B.C where A, B, C are from 0 to 255. The BS ID used in the CLI is an integer that is calculated by the formula  $A*65536+B*256+C$ . For example, a BS ID of 1.2.5 is translated to  $1*65536+2*256+5=66053$ .

```
npu(config)# bs <(1 to 16777215 StepSize 1)>
```

For example, to configure BS 66053, run the following command:

```
npu (config)# bs 66053
```



#### IMPORTANT

An error occurs if you specify BS ID that is not in the range, 1-16777215.

If you use this command to create a new BS, the configuration mode for this BS is automatically enabled, after which you can execute any of the following tasks:

- Configure one or more of the parameters tables of the BS

- Restore the default values for the non-mandatory parameters of one or more of the parameters tables of the BS

After executing the above tasks, you can terminate the BS configuration mode (refer to [Section 4.5.4](#)) and return to the global configuration mode. From the global configuration mode you can delete an existing BS (refer to). You can display configuration information for selected tables from the global command mode.

---

**Command Syntax**    `npu(config)# bs <(1 to 16777215 StepSize 1)>`

---

**Privilege Level**    10

---

**Syntax**

**Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The unique ID (BSIDLSB) of the BS. Must be unique in the radio access network. A number in the range from 1 to 16,777,215 (a 24-bit value that can be represented as A.B.C where A, B, C are from 0 to 255).	Mandatory	N/A	1 to 16777215

---

**Command Modes**    Global configuration mode



**NOTE**

The following examples are for bs configuration mode for bs-66053 .

## 4.8.2 Deleting a BS

Run the following command to delete a BS:

**npu(config)# no bs <(1 to 16777215 StepSize 1)>**



**IMPORTANT**

An associated bs (specified in an associated sector) cannot be deleted.

---

**Command Syntax**    npu(config)# no bs <(1 to 16777215 StepSize 1)>

---

**Privilege Level**    10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The unique ID (BSIDLSB) of the BS.	Mandatory	N/A	1 to 16777215

---

**Command Modes**    Global configuration mode

### 4.8.3 Managing BS General Parameters

The general parameters of a BS include the Operator ID and the BS Name.

After enabling the BS configuration mode, you can execute the following tasks:

- Configure one or more of the general parameters (refer to [Section 4.8.3.1](#)).
- Restore the default values of one or all of the general parameters (refer to [Section 4.8.3.2](#)).

You can display configuration information for the general parameters of a selected or all existing BSs (refer to [Section 4.8.3.3](#)).

#### 4.8.3.1 Configuring BS General Parameters



**To configure the BS General Parameters:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# general [operator-id <(1 to 16777215 StepSize 1)>]
[bs-name <string (32)>]
```

**IMPORTANT**

When creating a new BS, at least one of the BS General parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** `npu(config-bs-66053)# general [operator-id <(1 to 16777215 StepSize 1)> ] [bs-name <string (32)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[operator-id <(1 to 16777215 StepSize 1)>]	A unique operator identifier. The same Operator ID must be used throughout the radio access network. (a 24-bit value that can be represented as A.B.C where A, B, C are from 0 to 255)	Optional	16773929	1 to 16777215
[bs-name <string (32)>]	BS name	Optional	empty string	A string of up to 32 printable characters.

**Command Modes** bs configuration mode

### 4.8.3.2 Restoring Default Values for BS General Parameters

After enabling the BS configuration mode you can restore the default values for one or all of the general BS parameters.

To restore one or all general BS parameters do their default value, run the following command:

```
npu(config-bs-66053)# no general [operator-id] [bs-name]
```

You can restore one parameter to its default value by specifying only that parameter. For example, to restore only the operator-id to its default value, run the following command:



```
npu(config-bs-66053)# no general operator-id
```

The operator-id will be restored to its default value, while the bs-name parameter will remain unchanged.

To restore all parameters to their default value, run the following command:

```
npu(config-bs-66053)# no general
```



#### NOTE

Refer to [Section 4.8.3.1](#) for a description and default values of these parameters.

---

<b>Command Syntax</b>	<code>npu(config-bs-66053)# no general [operator-id] [bs-name]</code>
-----------------------	---

---

<b>Privilege Level</b>	10
------------------------	----

---

<b>Command Modes</b>	bs configuration mode
----------------------	-----------------------

### 4.8.3.3 Displaying Configuration Information for BS General Parameters

To display configuration information of the general parameters of a specific or all BSs, run the following command:

```
npu# show general bs [<(1 to 16777215 StepSize 1)>]
```

Specify the BS ID (1-16777215) of an existing BS if you want to display configuration information for a particular BS. Do not specify values for this parameter if you want to view configuration information for all existing BSs.

---

<b>Command Syntax</b>	<code>npu# show general bs [&lt;(1 to 16777215 StepSize 1)&gt; ]</code>
-----------------------	---

---

<b>Privilege Level</b>	1
------------------------	---

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
[<(1 to 16777215 StepSize 1)> ]	The BS ID  Specify a value for this parameter if you want to display the general parameters of a specific BS. Do not specify a value for this parameter if you want to display the general parameters of all BSs.	Optional	N/A	1-16777215

**Display****Format**

(for each existing BS if requested for all BSs)

```
BSIDLSB                :<value>
OperatorID             :<value>
BSName                 :<value>
```

**Command Modes**

Global command mode

## 4.8.4 Managing BS Services

The BS Service parameters affect the properties of the HARQ mechanism for each Service.

### 4.8.4.1 Enabling the BS Service Configuration Mode\Creating a BS Service

To configure the parameters of a BS Service, first enable the BS service configuration mode for the specific service. Run the following command to enable the BS service configuration mode. You can also use this command to create a new service with default values.

```
npu(config-bs-66053)# service <(string (32))>
```

For example, to define a new service named video, or to enable the configuration mode for an existing service named video, run the following command:

```
npu(config-bs-66053)# service video
```

If you use this command to create a new service, the configuration mode for this service is automatically enabled, after which you can execute any of the following tasks:

- Configure the parameters of the service (refer to [Section 4.8.4.2](#))
- Restore the default values for the non-mandatory parameters of the service (refer to [Section 4.8.4.3](#))

After executing the above tasks, you can terminate the BS Service configuration mode (refer to [Section 4.8.4.4](#)) and return to the BS configuration mode. From the BS configuration mode you can delete an existing service (refer to [Section 4.8.4.5](#)). You can display configuration information for BS services from the global command mode (refer to [Section 4.8.4.6](#)).

Note that for properly completing the configuration of a service the **apply** command must be executed prior to exiting the BS Service configuration mode.

---

**Command Syntax**     `npu(config-bs-66053)# service <(string (32))>`

---

**Privilege Level**     10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(string (32))>	The Service name (type).	Mandatory	N/A	A string of 1 to 32 characters.

---

**Command Modes**     bs configuration mode

## 4.8.4.2 Configuring Service Parameters



**To configure the BS Service Parameters:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053-service-video)# def [max-dl-rtx <(0 to 15 StepSize1)> ] [max-ul-rtx <(0 to 15 StepSize 1)> ] [max-subburst
```

```
<(0 to 1500 StepSize 1)> ] [trgt-err-rate <(0.1 to 10 StepSize 0.1)> ]
```

**IMPORTANT**

When creating a new Service, at least one of the Service parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** `npu(config-bs-66053-service-video)# def [max-dl-rtx <(0 to 15 StepSize1)> ] [max-ul-rtx <(0 to 15 StepSize 1)> ] [max-subburst <(0 to 1500 StepSize 1)> ] [trgt-err-rate <(0.1 to 10 StepSize 0.1)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[max-dl-rtx <(0 to 15 StepSize1)> ]	The maximal number of downlink retransmissions of an HARQ sub-burst for this service	Optional	5	0 -15i
[max-ul-rtx <(0 to 15 StepSize 1)> ]	The maximal number of uplink retransmissions of an HARQ sub-burst for this service	Optional	5	0 - 15
[max-subburst <(0 to 1500 StepSize 1)> ]	The maximal size of a sub-burst in bytes for this service	Optional	600	0 - 1500
[trgt-err-rate <(0.1 to 10 StepSize 0.1)> ]	The target sub-burst error rate for this service	Optional	1	0.1 to 10 in steps of 0.1

**Command Modes** bs service configuration mode

#### 4.8.4.3 Restoring Default Values for BS Service Parameters

After enabling the BS Service configuration mode you can restore the default values for some or all of the non-mandatory parameters.

To restore one or several BS Service parameters to their default value, run the following command:

```
npu(config-bs-66053-service-video)# no def [max-dl-rtx ]
[max-ul-rtx ] [max-subburst ] [trgt-err-rate ]
```

You can restore one or several parameters to the default value(s) by specifying only those parameter. For example, to restore only the max-dl-rtx and max-ul-rtx parameters to their default values, run the following command:

```
npu(config-bs-66053-service-video)# no def max-dl-rtx max-ul-rtx
```

The max-dl-rtx and max-ul-rtx parameters will be restored to their default values, while all other parameters will remain unchanged.

To restore all parameters to their default value, run the following command:

```
npu(config-bs-66053-service-video)# no def
```



#### NOTE

Refer to [Section 4.8.4.2](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<code>npu(config-bs-66053-service-video)# no def [max-dl-rtx ] [max-ul-rtx ] [max-subburst ] [trgt-err-rate ]</code>
-----------------------	--

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs service configuration mode
----------------------	-------------------------------

### 4.8.4.4 Terminating the BS Service Configuration Mode

Run the following command to terminate the BS Service configuration mode:

```
npu(config-bs-66053-service-video)# exit
```



#### IMPORTANT

Do not forget to execute the apply command before terminating the BS Service configuration mode:

```
npu(config-bs-66053-service-video)# apply
```

---

**Command Syntax**     **npu(config-bs-66053-service-video)# exit**

---

**Privilege Level**     10

---

**Command Modes**     bs service configuration mode

#### 4.8.4.5 Deleting a BS Service

Run the following command from the BS configuration mode to delete a BS Service:

**npu(config-bs 66053)# no service <string (32)>**

---

**Command Syntax**     **npu(config-bs 66053)# no service <string (32)>**

---

**Privilege Level**     10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<string (32)>	The Service name	Mandatory	N/A	String

---

**Command Modes**     bs service configuration mode

#### 4.8.4.6 Displaying Configuration Information for BS Service

To display configuration information of a specific or all BS Services, run the following command:

**npu# show service bs** [(1 to 16777215 StepSize 1)> service-name <string (32)>]

Specify the BS ID and Service name if you want to display configuration information for a particular Service. Do not specify values for these parameter if you want to view configuration information for all existing BS Services.

**Command Syntax**    `npu# show service bs [<(1 to 16777215 StepSize 1)> service-name <string (32)>]`

**Privilege Level**    1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the parameters of a specific BS Service. Do not specify a value for this parameter if you want to display the parameters of all BS Services.	Optional	N/A	1-16777215
<string (32)>	The Service name  Specify a value for this parameter if you want to display the parameters of a specific BS Service. Do not specify a value for this parameter if you want to display the parameters of all BS Services.	Optional	N/A	String

**Display Format**

BSIDLSB	:<value>
ServiceName	:<value>
(for each existing Antenna if requested for all Antennas)	
MaximumDownlinkRetransmissions	:<value>
MaximumUplinkRetransmissions	:<value>
MaximumSub-BurstSize(bytes)	:<value>
TargetPacketErrorRate(%)	:<value>

**Command Modes**    Global command mode

## 4.8.5 Managing Service Mapping Rules

Up to 255 Service Mapping Rule may be defined.



### To configure a Service Mapping Rule:

- 1 Enable the BS Service Mapping Rule configuration mode for the selected Service Mapping Rule (refer to [Section 4.8.5.1](#))
- 2 You can now execute any of the following tasks:
  - » Configure one or more of the parameters tables of the Service Mapping Rule (refer to [Section 4.8.5.2](#))
  - » Restore the default values of parameters in one or more of the parameters tables of the Service Mapping Rule (refer to [Section 4.8.5.3](#))
  - » Terminate the Service Mapping Rule configuration mode (refer to [Section 4.8.5.4](#))

In addition, you can, at any time, display configuration information for each of the parameters tables of the Service Mapping Rule (refer to [Section 4.8.5.6](#)) or delete an existing Service Mapping Rule (refer to [Section 4.8.5.5](#)).

### 4.8.5.1 Enabling the Service Mapping Rule Configuration Mode\Creating a Service Mapping Rule

To configure the parameters of a Service Mapping Rule, first enable the BS Service Mapping Rule configuration mode for the specific Service Mapping Rule. Run the following command to enable the BS Service Mapping Rule configuration mode. You can also use this command to create a new Service Mapping Rule.

Note that for a new Service Mapping Rule this command only defines the Service Mapping Rule index, and that the Service Mapping Rule is not fully created until completing configuration of all mandatory parameters and executing the **apply** command (must be executed before exiting the BS Service Mapping Rule configuration mode). Also when updating an existing Service Mapping Rule, the **apply** command must be executing prior to termination the Service Mapping Rule configuration mode.

```
npu(config-bs-66053)# srvcmaprule <(1 to 255 StepSize 1)
```

For example, to define a new Service Mapping Rule index 1, or to enable the configuration mode for Service Mapping Rule 1, run the following command:



```
npu(config-bs-66053)# srvcmaprule 1
```

If you use this command to create a new Service Mapping Rule, the configuration mode for this Service Mapping Rule is automatically enabled, after which you can execute any of the following tasks:

- Configure one or more of the parameters tables of the Service Mapping Rule (refer to [Section 4.8.5.2](#))
- Restore the default values of parameters in one or more of the parameters tables of the Service Mapping Rule (refer to [Section 4.8.5.3](#))

After executing the above tasks, you can terminate the Service Mapping Rule configuration mode (refer to [Section 4.8.5.4](#)) and return to the BS configuration mode.

Note that for properly completing the configuration of a Service Mapping Rule the **apply** command must be executed prior to exiting the BS Service Mapping Rule configuration mode.

---

**Command Syntax**      `npu(config-bs-66053)# srvcmaprule <(1 to 255 StepSize 1)>`

---

**Privilege Level**      10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<code>srvcmaprule &lt;(1 to 255 StepSize 1)&gt;</code>	The Service Mapping Rule index	Mandatory		1 - 255

---

**Command Modes**      BS configuration mode

For example, to define Service Mapping Rule 1 for BS 66053, run the following command:

```
npu(config-bs-66053)# srvcmaprule 1
```

**NOTE**

The following examples are for BS Service Mapping Rule configuration mode for bs-66053, service mapping rule (srvcmaprule)-1.

## 4.8.5.2 Configuring Service Mapping Rule Parameters

After enabling the Service Mapping Rule configuration mode you can configure the following parameters tables:

- General (refer to [Section 4.8.5.2.1](#))
- Order (refer to [Section 4.8.5.2.2](#))
- R1 Profile (refer to [Section 4.8.5.2.3](#))
- R6 Profile (refer to [Section 4.8.5.2.4](#))

**IMPORTANT**

After completing the Service Mapping Rule configuration, do not forget to execute the apply command before exiting the BS Service Mapping Rule configuration mode:

**npu(config-bs-66053-srvcmaprule-1)# apply**

### 4.8.5.2.1 Configuring General Service Mapping Rule Parameters

The General Service Mapping Parameters table enables associating the Service Mapping Rule to a specific Service.

To configure the General Service Mapping Rule parameters, run the following command:

```
npu(config-bs-66053-srvcmaprule-1)# general srvc <string (32)>
```

**IMPORTANT**

When creating a new Service Mapping Rule, the mandatory srvc parameters must be configured.

---

**Command Syntax**

```
npu(config-bs-66053-srvcmaprule-1)# general srvc <string (32)>
```

---

**Privilege Level**

10

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
[ <code>svc &lt;string (32)&gt;</code> ]	<p>The service type to which the connection will be mapped.</p> <p>Must be the same as the name (type) configured for the relevant service (refer to <a href="#">Section 4.8.4</a>).</p> <p>All service a certain data delivery type (see <a href="#">Section 4.8.5.2.3</a>) must use the same service type (same HARQ properties).</p>	Mandatory		A string of 1 to 32 printable characters.

**Command**

`bs service mapping rule configuration mode`

**Modes**

### 4.8.5.2.2 Configuring the Order Parameters

The Order Parameters table enables configuring the look-up-order parameter that defines the order in which conceptual rows of the table are checked to find a match.

To configure the Order parameters, run the following command:

```
npu(config-bs-66053-srvcmaprul-1)# order look-up-order <(1 to 255 StepSize 1)>
```

**IMPORTANT**

When creating a new Service Mapping Rule, the mandatory order parameter must be configured.

**Command**

```
npu(config-bs-66053-srvcmaprul-1)# order [look-up-order <(1 to 255 StepSize 1)> ]
```

**Syntax****Privilege**

10

**Level**

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
[look-up-order <(1 to 255 StepSize 1)> ]	Defines the order in which the conceptual rows of the table are checked to find a match.  <b>Note:</b> The value of this parameter must be different for each conceptual row instance	Mandatory		1 to 255

**Command**

bs service mapping rule configuration mode

**Modes****4.8.5.2.3 Configuring R1 Profile Parameters**

To configure mapping rules to R1 Profile parameters, run the following command:

```
npu(config-bs-66053-srvcmaprul-1)# rlprof [modify-serviceqos
{TRUE | FALSE} ] [dfltpriority <(0 to 7 StepSize 1)> ]
[datadeliverytype {uGS | rTVR | nRTVR | bE | eRTVR} ] [priority <(0
to 7 StepSize 1)> ] [mir <(0 to 20000 StepSize 1)> ] [cir <(0 to
20000 StepSize 1)> ] [jitter <(0 to 5000 StepSize 1)> ] [latency
<(0 to 5000 StepSize 1)> ] [sdu-length {fixed | variable} ]
[sdu-size <(1 to 255 StepSize 1)> ] [grant-interval <(0 to 5000
StepSize 1)> ]
```

**IMPORTANT**

When creating a new Service Mapping Rule, all mandatory parameters must be configured.

**Command****Syntax**

```
npu(config-bs-66053-srvcmaprul-1)# rlprof [modify-serviceqos
{TRUE | FALSE} ] [dfltpriority <(0 to 7 StepSize 1)> ]
[datadeliverytype {uGS | rTVR | nRTVR | bE | eRTVR} ] [priority
<(0 to 7 StepSize 1)> ] [mir <(0 to 20000 StepSize 1)> ] [cir <(0
to 20000 StepSize 1)> ] [jitter <(0 to 5000 StepSize 1)> ]
[latency <(0 to 5000 StepSize 1)> ] [sdu-length{fixed | variable}
] [sdu-size <(1 to 255 StepSize 1)> ] [grant-interval <(0 to 5000
StepSize 1)> ]
```

**Privilege**

10

**Level**

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
[modify-serviceqos {TRUE   FALSE} ]	Indicates whether to modify service QoS parameters using internal R1 profile parameters.	Optional	FALSE	<input type="checkbox"/> TRUE <input type="checkbox"/> FALSE
[dfllpriority <(0 to 7 StepSize 1)> ]	Relevant only if modify-serviceqos is FALSE. Indicates the traffic priority to be used when it is missing in R6 request.	Optional	0	0 to 7
[datadeliverytype {uGS   rTVR   nRTVR   bE   eRTVR} ]	Relevant only if modify-serviceqos is TRUE. An internal R1 profile parameter, specifying the type of data delivery (service type).  (RTVR and NRTVR are not applicable for current release)	Mandatory when creating a new Service Mapping Rule.	N/A	<input type="checkbox"/> uGS <input type="checkbox"/> rTVR <input type="checkbox"/> nRTVR <input type="checkbox"/> bE <input type="checkbox"/> eRTVR
[priority <(0 to 7 StepSize 1)> ]	Relevant only if modify-serviceqos is TRUE and the datadeliverytype is rTVR, nRTVR, eRTVR or bE. An internal R1 profile parameter specifying the traffic priority.	Mandatory when creating a new Service Mapping Rule.	N/A	0 to 7
[mir <(0 to 20000 StepSize 1)> ]	Relevant only if modify-serviceqos is TRUE and the datadeliverytype is bE or eRTVR. An internal R1 profile parameter specifying the maximum sustained traffic rate in Kbps.	Mandatory when creating a new Service Mapping Rule.	N/A	0 - 20000
[cir <(0 to 20000 StepSize 1)> ]	Relevant only if modify-serviceqos is TRUE and the datadeliverytype is uGS or eRTVR. An internal R1 profile parameter specifying the minimum reserved traffic rate in Kbps.	Mandatory when creating a new Service Mapping Rule.	N/A	0 - 20000

[jitter <(0 to 5000 StepSize 1)> ]	Relevant only if modify-serviceqos is TRUE and the datadeliverytype is uGS or eRTVR. An internal R1 profile parameter specifying maximum tolerated jitter in milliseconds.	Mandatory when creating a new Service Mapping Rule.	N/A	0 - 5000
[latency <(0 to 5000 StepSize 1)> ]	Relevant only if modify-serviceqos is TRUE and the datadeliverytype is uGS or eRTVR. An internal R1 profile parameter specifying maximum latency in milliseconds.	Mandatory when creating a new Service Mapping Rule.	N/A	0 - 5000
[sdu-length{fixed   variable} ]	Relevant only if modify-serviceqos is TRUE and the datadeliverytype is uGS. An internal R1 profile parameter specifying whether SDU length is fixed or variable. In the current release only fixed length is supported.	Optional	fixed	<input checked="" type="checkbox"/> fixed  <input checked="" type="checkbox"/> variable (not supported in current release)
[sdu-size <(1 to 255 StepSize 1)> ]	Relevant only if modify-serviceqos is TRUE, the datadeliverytype is uGS and the sdu-length is fixed. An internal R1 profile parameter specifying the SDU size in bytes.	Mandatory when creating a new Service Mapping Rule.	N/A	1 - 255
[grant-interval <(0 to 5000 StepSize 1)> ]	Relevant only if modify-serviceqos is TRUE and the datadeliverytype is uGS or eRTVR. An internal R1 profile parameter specifying the grant interval in milliseconds.	Mandatory when creating a new Service Mapping Rule.	N/A	0 - 5000

**Command Modes** bs service mapping rule configuration mode



**IMPORTANT**

Note that when creating a new Service Mapping Rule all mandatory parameters must be configured, including those that may not be relevant for the Service Mapping Rule.

**4.8.5.2.4 Configuring R6 Profile Parameters**

To configure mapping rules to R6 Profile parameters, run the following command:

```
npu(config-bs-66053-srvcmaprul-1)# r6prof [datadeliverytype {uGS | rTVR | nRTVR | bE | eRTVR | any} ] [priority <(-1 to -1 StepSize 1) | (0 to 7 StepSize 1)> ] [mediaflowtype <string (32)> ] [use-mediaflowtype {TRUE | FALSE} ] [mir <(-1 to -1 StepSize 1) | (0 to 20000 StepSize 1)> ] [cir <(-1 to -1 StepSize 1) | (0 to 20000 StepSize 1)> ] [latency <(-1 to -1 StepSize 1) | (0 to 5000 StepSize 1)>].
```



**IMPORTANT**

When creating a new Service Mapping Rule, at least one of the R6 Profile parameters must be configured explicitly (even if configured to the default value).

**Command Syntax**

```
npu(config-bs-66053-srvcmaprul-2)# r6prof [datadeliverytype {uGS | rTVR | nRTVR | bE | eRTVR | any} ] [priority <(-1 to -1 StepSize 1) | (0 to 7 StepSize 1)> ] [mediaflowtype <string (32)> ] [use-mediaflowtype {TRUE | FALSE} ] [mir <(-1 to -1 StepSize 1) | (0 to 20000 StepSize 1)> ] [cir <(-1 to -1 StepSize 1) | (0 to 20000 StepSize 1)> ] [latency <(-1 to -1 StepSize 1) | (0 to 5000 StepSize 1)> ]
```

**Privilege Level**

10

**Syntax**

**Description**

Parameter	Description	Presence	Default Value	Possible Values
-----------	-------------	----------	---------------	-----------------

[datadeliverytype {uGS   rTVR   nRTVR   bE   eRTVR   any} ]	An R6 parameter entry in the lookup table specifying the data delivery type (service type).	Optional	any	<ul style="list-style-type: none"> <li>■ uGS</li> <li>■ rTVR</li> <li>■ nRTVR</li> <li>■ bE</li> <li>■ eRTVR</li> <li>■ any</li> </ul>
[priority <(-1 to -1 StepSize 1)   (0 to 7 StepSize 1)> ]	An R6 parameter entry in the lookup table specifying the traffic priority. A value of -1 means any.	Optional	-1	<ul style="list-style-type: none"> <li>■ -1</li> <li>■ 0 - 7</li> </ul>
[mediaflowtype <string (32)> ]	An R6 parameter entry in the lookup table that is relevant only if the use-mediaflowtype parameter is defined as TRUE	Optional	blank string	A string of 32 printable characters.
[use-mediaflowtype {TRUE   FALSE} ]	<p>If this parameter has a value TRUE, the service lookup function will try to match the R6 media flow type with the mediaFlowType entry in the table.</p> <p>If FALSE the service lookup function will ignore the R6 media flow type.</p>	Optional	FALSE	<ul style="list-style-type: none"> <li>■ TRUE</li> <li>■ FALSE</li> </ul>
[mir <(-1 to -1 StepSize 1)   (0 to 20000 StepSize 1)> ]	An R6 parameter entry in the lookup table specifying the maximum sustained traffic rate in Kbps. A value of -1 means any.	Optional	-1	<ul style="list-style-type: none"> <li>■ -1</li> <li>■ 0 - 20000</li> </ul>
[cir <(-1 to -1 StepSize 1)   (0 to 20000 StepSize 1)> ]	An R6 parameter entry in the lookup table specifying the minimum reserved traffic rate in Kbps. A value of -1 means any.	Optional	-1	<ul style="list-style-type: none"> <li>■ -1</li> <li>■ 0 - 20000</li> </ul>
[latency <(-1 to -1 StepSize 1)   (0 to 5000 StepSize 1)> ]	An R6 parameter entry in the lookup table specifying tolerated latency in milliseconds. A value of -1 means any.	Optional	-1	<ul style="list-style-type: none"> <li>■ -1</li> <li>■ 0 - 5000</li> </ul>



---

**Command Modes**    bs service mapping rule configuration mode

### 4.8.5.3 Restoring Default Values for Service Mapping Rule Configuration Parameters

After enabling the Service Mapping Rule configuration mode you can restore the default values for non-mandatory parameters in the following parameters tables:

- R1 Profile (refer to [Section 4.8.5.3.1](#))
- R6 Profile (refer to [Section 4.8.5.3.2](#))

#### 4.8.5.3.1 Restoring the Default Values of R1 Profile Parameters

To restore some or all of R1 Profile non-mandatory parameters to their default values, run the following command:

```
npu(config-bs-66053-srvcmaprul-1)# no rlprof [modify-serviceqos ]
[dfltpriority ]
```

You can restore only one or several parameters to the default values by specifying only those parameters. For example, to restore only the dfltpriority to the default value, run the following command:

```
npu(config-bs-66053-srvcmaprul-1)# no rlprof dfltpriority
```

The parameter will be restored to its default value, while the other parameters will remain unchanged.

To restore all R1 Profile non-mandatory parameters to their default value, run the following command:

```
npu(config-bs-66053-srvcmaprul-1)# no rlprof
```



#### NOTE

Refer to [Section 4.8.5.2.3](#) for a description and default values of these parameters.

---

**Command Syntax**    npu(config-bs-66053-srvcmaprul-1)# no rlprof [modify-serviceqos ]  
[dfltpriority ]

---

**Privilege Level**    10

---

**Command Modes**    bs service mapping rule configuration mode

#### 4.8.5.3.2 Restoring the Default Values of R6 Profile Parameters

To restore some or all of R6 Profile parameters to their default values, run the following command:

```
npu(config-bs-66053-srvcmaprul-1)# no r6prof [datadeliverytype ]
[priority ] [mediaflowtype ] [use-mediaflowtype] [mir ] [cir ]
[latency ]
```

You can restore only one or several parameters to the default values by specifying only those parameters. For example, to restore only the mir and cir to the default values, run the following command:

```
npu(config-bs-66053-srvcmaprul-1)# no r6prof mir cir
```

These parameter will be restored to their default values, while all other parameters will remain unchanged.

To restore all R6 Profile parameters to their default value, run the following command:

```
npu(config-bs-66053-srvcmaprul-1)# no r6prof
```



#### NOTE

Refer to [Section 4.8.5.2.4](#) for a description and default values of these parameters.

---

**Command Syntax**    npu(config-bs-66053-srvcmaprul-1)# no r6prof [datadeliverytype ]  
[priority ] [mediaflowtype ] [use-mediaflowtype] [mir ] [cir ]  
[latency ]

---

**Privilege Level**    10

---

**Command Modes**    bs service mapping rule configuration mode

#### 4.8.5.4 Terminating the Service Mapping Rule Configuration Mode

Run the following command to terminate the Service Mapping Rule configuration mode:

**npu(config-bs-66053-srvcmaprul-1)# exit**



#### IMPORTANT

Do not forget to execute the apply command before terminating the BS Service Mapping Rule configuration mode:

**npu(config-bs-66053-srvcmaprul-1)# apply**

**Command Syntax** npu(config-bs-66053-srvmaprule-1)# exit

**Privilege Level** 10

**Command Modes** bs service mapping rule configuration mode

### 4.8.5.5 Deleting a Service Mapping Rule

Run the following command from the BS configuration mode to delete a Service Mapping Rule:

**npu(config-bs 66053)# no srvcmaprul <(1 to 255 StepSize 1)>**

**Command Syntax** npu(config-bs 66053)# no srvcmaprul <(1 to 255 StepSize 1)>

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 255 StepSize 1)>	The Service Mapping Rule index	Mandatory	N/A	1-255

**Command Modes** bs configuration mode

## 4.8.5.6 Displaying Configuration Information for Service Mapping Rules

You can display the current configuration information for the following parameters tables:

- General (refer to [Section 4.8.5.6.1](#))
- Order (refer to [Section 4.8.5.6.2](#))
- R1 Profile (refer to [Section 4.8.5.6.3](#))
- R6 Profile (refer to [Section 4.8.5.6.4](#))
- All (refer to [Section 4.8.5.6.5](#))

### 4.8.5.6.1 Displaying Configuration Information for General Service Mapping Rule Parameters

To display configuration for the general parameters of a specific or all Service Mapping Rules, run the following command:

```
npu# show srvcmaprule-general bs [(1 to 16777215 StepSize 1)> rule-index (1 to 255 StepSize 1)>]
```

Specify the BS ID and Service Mapping Rule index if you want to display configuration for a particular Service Mapping Rule. For example, to display the General parameters of Service Mapping Rule 1 in BS 66053, run the following command:

```
npu# show srvcmaprule-general bs 66053 rule-index 1
```

Do not specify these parameters if you want to view configuration information for all existing Service Mapping Rules. To display information for all Service Mapping Rules, run the following command:

```
npu# show srvcmaprule-general bs
```

---

<b>Command Syntax</b>	<b>npu# show srvcmaprule-general bs</b> [(1 to 16777215 StepSize 1)> rule-index (1 to 255 StepSize 1)> ]
-----------------------	--

---

<b>Privilege Level</b>	1
------------------------	---

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the general parameters of a specific Service Mapping Rule. Do not specify a value for this parameter if you want to display the general parameters of all Service Mapping Rules.	Optional	N/A	1-16777215
rule-index <(1 to 255 StepSize 1)> ]	The Service Mapping Rule index. To be used only if you want to display the general parameters of a specific Service Mapping Rule.	Optional	N/A	1-255

**Display Format**

(for each existing Service Mapping Rule if requested for all Service Mapping Rules)

```

BSIDLSB                : <value>
MappingRuleIndex       : <value>
ServiceName            : <value>

```

**Command Modes**

Global command mode

#### 4.8.5.6.2 Displaying Configuration Information for Service Mapping Rule Order Parameters

To display configuration for the order parameters of a specific or all Service Mapping Rules, run the following command:

```
npu# show srvcmaprule-order bs [(1 to 16777215 StepSize 1)> rule-index (1 to 255 StepSize 1)>]
```

Specify the BS ID and Service Mapping Rule index if you want to display configuration for a particular Service Mapping Rule. For example, to display the order parameters of Service Mapping Rule 1 in BS 66053, run the following command:

**npu# show srvcmaprule-order bs 66053 rule-index 1**

Do not specify these parameters if you want to view configuration information for all existing Service Mapping Rules. To display information for all Service Mapping Rules, run the following command:

**npu# show srvcmaprule-order bs**

**Command Syntax** **npu# show srvcmaprule-order bs** [(1 to 16777215 StepSize 1)> rule-index (1 to 255 StepSize 1)> ]

**Privilege Level** 1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the order parameters of a specific Service Mapping Rule. Do not specify a value for this parameter if you want to display the order parameters of all Service Mapping Rules.	Optional	N/A	1-16777215
rule-index <(1 to 255 StepSize 1)>]	The Service Mapping Rule index. To be used only if you want to display the order parameters of a specific Service Mapping Rule.	Optional	N/A	1-255

<b>Display</b>	BSIDLSB	: <value>
<b>Format</b>	MappingRuleIndex	: <value>
(for each existing Service Mapping Rule if requested for all Service Mapping Rules)	LookUpOrder	: <value>
<b>Command Modes</b>	Global command mode	

#### 4.8.5.6.3 Displaying Configuration Information for Service Mapping Rule R1 Profile Parameters

To display configuration for the R1 Profile parameters of a specific or all Service Mapping Rules, run the following command:

```
npu# show srvcmaprule-r1prof bs [<(1 to 16777215 StepSize 1)> rule-index <(1 to 255 StepSize 1)>]
```

Specify the BS ID and Service Mapping Rule index if you want to display configuration for a particular Service Mapping Rule. For example, to display the R1 Profile parameters of Service Mapping Rule 1 in BS 66053, run the following command:

```
npu# show srvcmaprule-r1prof bs 66053 rule-index 1
```

Do not specify these parameters if you want to view configuration information for all existing Service Mapping Rules. To display information for all Service Mapping Rules, run the following command:

```
npu# show srvcmaprule-r1prof bs
```

<b>Command Syntax</b>	<b>npu# show srvcmaprule-r1prof bs</b> [<(1 to 16777215 StepSize 1)> rule-index <(1 to 255 StepSize 1)> ]	
<b>Privilege Level</b>	1	

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the R1 Profile parameters of a specific Service Mapping Rule. Do not specify a value for this parameter if you want to display the R1 Profile parameters of all Service Mapping Rules.	Optional	N/A	1-16777215
rule-index <(1 to 255 StepSize 1)>]	The Service Mapping Rule index. To be used only if you want to display the R1 Profile parameters of a specific Service Mapping Rule.	Optional	N/A	1-255

**Display Format**

(for each existing Service Mapping Rule if requested for all Service Mapping Rules)

BSIDLSB	: <value>
MappingRuleIndex	: <value>
ModifyServiceQoSParameters	: <value>
DefaultPriority	: <value>
DataDeliveryTypeR1Profile	: <value>
PriorityR1Profile	: <value>
MIRR1Profile	: <value>
CIRR1Profile	: <value>
Jitter	: <value>
LatencyR1Profile	: <value>
SDULength	: <value>
SDUSize	: <value>

**Command Modes**

Global command mode



#### 4.8.5.6.4 Displaying Configuration Information for Service Mapping Rule R6 Profile Parameters

To display configuration for the R6 Profile parameters of a specific or all Service Mapping Rules, run the following command:

```
npu# show srvcmaprule-r6prof bs [<(1 to 16777215 StepSize 1)> rule-index <(1 to 255 StepSize 1)>]
```

Specify the BS ID and Service Mapping Rule index if you want to display configuration for a particular Service Mapping Rule. For example, to display the R6 Profile parameters of Service Mapping Rule 1 in BS 66053, run the following command:

```
npu# show srvcmaprule-r6prof bs 66053 rule-index 1
```

Do not specify these parameters if you want to view configuration information for all existing Service Mapping Rules. To display information for all Service Mapping Rules, run the following command:

```
npu# show srvcmaprule-r6prof bs
```

---

**Command Syntax**     **npu# show srvcmaprule-r6prof bs** [<(1 to 16777215 StepSize 1)> rule-index <(1 to 255 StepSize 1)> ]

---

**Privilege Level**     1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the R6 Profile parameters of a specific Service Mapping Rule. Do not specify a value for this parameter if you want to display the general parameters of all Service Mapping Rules.	Optional	N/A	1-16777215

rule-index <(1 to 255 StepSize 1)>]	The Service Mapping Rule index. To be used only if you want to display the R6 Profile parameters of a specific Service Mapping Rule.	Optional	N/A	1-255
-------------------------------------	--	----------	-----	-------

<b>Display Format</b> (for each existing Service Mapping Rule if requested for all Service Mapping Rules)	BSIDLSB	: <value>
	MappingRuleIndex	: <value>
	DataDeliveryTypeR6Profile	: <value>
	PriorityR6Profile	: <value>
	MediaFlowType	: <value>
	UseMediaFlowType	: <value>
	CIRR6Profile	: <value>
MIRR6Profile	: <value>	
LatencyR6Profile	: <value>	

<b>Command Modes</b>	Global command mode
----------------------	---------------------

#### 4.8.5.6.5 Displaying Configuration Information for All Service Mapping Profile Parameters

To display all configuration parameters of a specific or all Service Mapping Rules, run the following command:

```
np# show srvcmaprule-all bs [(1 to 16777215 StepSize 1)> rule-index <(1 to 255 StepSize 1)>]
```

Specify the BS ID and Service Mapping Rule index if you want to display configuration for a particular Service Mapping Rule. For example, to display all parameters of Service Mapping Rule 1 in BS 66053, run the following command:

```
np# show srvcmaprule-all bs 66053 rule-index 1
```

Do not specify these parameters if you want to view configuration information for all existing Service Mapping Rules. To display information for all Service Mapping Rules, run the following command:

```
np# show srvcmaprule-all bs
```

**Command Syntax**     `npu# show srvcmaprule-all bs [<(1 to 16777215 StepSize 1)> rule-index <(1 to 255 StepSize 1)>]`

**Privilege Level**     10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display all parameters of a specific Service Mapping Rule. Do not specify a value for this parameter if you want to display all parameters of all Service Mapping Rules.	Optional	N/A	1-16777215
rule-index <(1 to 255 StepSize 1)>]	The Service Mapping Rule index. To be used only if you want to display all parameters of a specific Service Mapping Rule.	Optional	N/A	1-255

**Command Modes**     Global command mode

## 4.8.6 Managing Power Control Levels and Policies



**To configure a the Power Control Levels and Policies:**

- 1 Enable the Power Control configuration mode (refer to [Section 4.8.6.1](#))

- 2 You can now execute any of the following tasks:
  - » Configure one or more of the Power Control parameters tables (refer to [Section 4.8.6.2](#))
  - » Restore the default values of parameters in one or more of the Power Control parameters tables (refer to [Section 4.8.6.3](#))
  - » Terminate the Power Control configuration mode (refer to [Section 4.8.6.4](#))

In addition, you can, at any time, display configuration information for each of the parameters tables (refer to [Section 4.8.6.5](#)).

### 4.8.6.1 Enabling the Power Control Configuration Mode

To configure the Power Control parameters, first enable the Power Control configuration mode. Run the following command to enable the Power Control configuration mode.

Note that for properly completing the configuration the **apply** command must be executed prior to exiting the Power Control configuration mode.

```
npu(config-bs-66053)# pwrctrl
```

The Power Control configuration mode is enabled, after which you can execute any of the following tasks:

- Configure one or more of the Power Control parameters tables (refer to [Section 4.8.6.2](#))
- Restore the default values of parameters in one or more of the parameters tables (refer to [Section 4.8.6.3](#))

After executing the above tasks, you can terminate the Power Control configuration mode (refer to [Section 4.8.6.4](#)) and return to the BS configuration mode.

Note that for properly completing the Power Control configuration the **apply** command must be executed prior to exiting the Power Control configuration mode.

---

<b>Command</b>	npu(config-bs-66053)# pwrctrl
<b>Syntax</b>	

---

**Privilege Level** 10

---

**Command Modes** bs configuration mode

## 4.8.6.2 Configuring Power Control Parameters

After enabling the Power Control configuration mode you can configure the following parameters tables:

- Target Noise and Interference Level (refer to [Section 4.8.6.2.1](#))
- Maximum EIRP (refer to [Section 4.8.6.2.2](#))
- Required C/N Level (refer to [Section 4.8.6.2.3](#))
- Open Loop Correction Policy (refer to [Section 4.8.6.2.4](#))
- Open Loop Correction Range (refer to [Section 4.8.6.2.5](#))
- Closed Loop - Unstable MS (refer to [Section 4.8.6.2.6](#))
- Closed Loop - MS in Network Entry (refer to [Section 4.8.6.2.7](#))
- Closed Loop Correction Range (refer to [Section 4.8.6.2.8](#))



### IMPORTANT

After completing the Power Control configuration, do not forget to execute the apply command before exiting the Power Control configuration mode:

**npu(config-bs-66053-pwrctrl)# apply**

### 4.8.6.2.1 Configuring Power Control Target Noise and Interference Level Parameters

The Target Noise and Interference Level table enables defining the target limits for various noise and interference levels.

To configure the Target Noise and Interference Levels, run the following command:

**npu(config-bs-66053-pwrctrl)# nilevels** [cqi-ack-ranging <(-150 to -22.5 StepSize 0.5)>] [pusc <(-150 to -22.5 StepSize 0.5)>]

**IMPORTANT**

When creating a new BS, at least one of the Power Control Target Noise and Interference Level parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** `npu(config-bs-66053-pwrctrl)# nilevels [cqi-ack-ranging <(-150 to -22.5 StepSize 0.5)> ] [pusc <(-150 to -22.5 StepSize 0.5)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[cqi-ack-ranging <(-150 to -22.5 StepSize 0.5)> ]>	Target Noise and interference level for the CQI, ACK and periodic ranging regions, in dBm.	Optional	-128	-150 to -22.5 in steps of 0.5
[pusc <(-150 to -22.5 StepSize 0.5)> ]	Target Noise and interference level for the PUSC zone, in dBm	Optional	-128	-150 to -22.5 in steps of 0.5

**Command Modes** bs power control configuration mode

#### 4.8.6.2.2 Configuring the Power Control Maximum EIRP

The maxeirxp parameter enables defining the maximum effective isotropic received power at the BS for Initial ranging.

To configure the maxeirxp, run the following command:

**npu(config-bs-66053-pwrctrl)# maxeirxp <(-140 to -40 StepSize 1)>**

**IMPORTANT**

When creating a new BS, the maxeirxp parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** `npu(config-bs-66053-pwrctrl)# maxeirxp <(-140 to -40 StepSize 1)>`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
maxeirxp <(-140 to -40 StepSize 1)>	The maximum effective isotropic received power at the BS for Initial ranging, in dBm.	Optional	-124	-140 to -40

**Command Modes** bs power control configuration mode

#### 4.8.6.2.3 Configuring the Power Control Required C/N Level Parameters

The Required C/N Levels table enables defining the Carrier to Noise Ratios required for various types of transmissions.

To configure the Required C/N Levels, run the following command:

```
npu(config-bs-66053-pwrctrl)# requiredcnr [ack <(-20 to 50 StepSize 1)>] [cqi <(-20 to 50 StepSize 1)>] [cdma <(-20 to 50 StepSize 1)>] [qpsk-1by2 <(-20 to 50 StepSize 1)>] [qpsk-3by4 <(-20 to 50 StepSize 1)>] [qam16-1by2 <(-20 to 50 StepSize 1)>] [qam16-3by4 <(-20 to 50 StepSize 1)>] [qam64-1by2 <(-20 to 50 StepSize 1)>] [qam64-2by3 <(-20 to 50 StepSize 1)>] [qam64-3by4 <(-20 to 50 StepSize 1)>] [qam64-5by6 <(-20 to 50 StepSize 1)>]
```



#### IMPORTANT

When creating a new BS, at least one of the Power Control Required C/N Level parameters must be configured explicitly (even if configured to the default value).

**Command** `npu(config-bs-66053-pwrctrl)# requiredcnr [ack <(-20 to 50 StepSize 1)> ] [cqi <(-20 to 50 StepSize 1)> ] [cdma <(-20 to 50 StepSize 1)> ] [qpsk-1by2 <(-20 to 50 StepSize 1)> ] [qpsk-3by4 <(-20 to 50 StepSize 1)> ] [qam16-1by2 <(-20 to 50 StepSize 1)> ] [qam16-3by4 <(-20 to 50 StepSize 1)> ] [qam64-1by2 <(-20 to 50 StepSize 1)> ] [qam64-2by3 <(-20 to 50 StepSize 1)> ] [qam64-3by4 <(-20 to 50 StepSize 1)> ] [qam64-5by6 <(-20 to 50 StepSize 1)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[ack <(-20 to 50 StepSize 1)> ]	The C/N in dB required for sending ACK, reported to the MS for power control purposes.	Optional	7	-20 to 50
[cqi <(-20 to 50 StepSize 1)> ]	The C/N in dB required for sending CQI, reported to the MS for power control purposes.  Must be in the range from requiredcnr-ack - 8 to requiredcnr-ack + 7 (see ack parameter above)	Optional	0	-20 to 50
[cdma <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting CDMA, reported to the MS for power control purposes.  Must be in the range from requiredcnr-cqi - 8 to requiredcnr-cqi + 7 (see cqi parameter above)	Optional	0	-20 to 50
[qpsk-1by2 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using QPSK 1/2, reported to the MS for power control purposes.  Must be in the range from requiredcnr-cdma - 16 to requiredcnr-cdma + 14 (see cdma parameter above)	Optional	14	-20 to 50



[qpsk-3by4<(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using QPSK 3/4, reported to the MS for power control purposes.  Must be in the range from requiredcnr-qpsk-1by2 - 16 to requiredcnr-qpsk-1by2 + 14 (see qpsk-1by2 parameter above)	Optional	16	-20 to 50
[qam16-1by2 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 16QAM 1/2, reported to the MS for power control purposes.  Must be in the range from requiredcnr-qpsk-3by4 - 8 to requiredcnr-qpsk-3by4 + 7 (see qpsk-3by4 parameter above)	Optional	18	-20 to 50
[qam16-3by4 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 16QAM 3/4, reported to the MS for power control purposes.  Must be in the range from requiredcnr-qam16-1by2 - 16 to requiredcnr-qam16-1by2 + 14 (see qam16-1by2 parameter above)	Optional	22	-20 to 50
qam64-1by2 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 64QAM 1/2, reported to the MS for power control purposes.  Must be in the range from requiredcnr-qam16-3by4 - 16 to requiredcnr-qam16-3by4 + 14 (see qam16-3by4 parameter above)	Optional	23	-20 to 50
[qam64-2by3 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 64QAM 2/3, reported to the MS for power control purposes.  Must be in the range from requiredcnr-qam64-1by2 - 8 to requiredcnr-qam64-1by2 + 7 (see qam64-1by2 parameter above)	Optional	23	-20 to 50

[qam64-3by4 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 64QAM 3/4, reported to the MS for power control purposes.  Must be in the range from requiredcnr-qam64-2by3 - 8 to requiredcnr-qam54-2by3 + 7 (see qam54-2by3 parameter above)	Optional	23	-20 to 50
[qam64-5by6 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 64QAM 5/6, reported to the MS for power control purposes.  Must be in the range from requiredcnr-qam64-3by4 - 8 to requiredcnr-qam64-3by4 + 7 (see qam64-3by4 parameter above)	Optional	23	-20 to 50

**Command Modes** bs power control configuration mode

#### 4.8.6.2.4 Configuring the Power Control Open Loop Correction Policy Parameters

To configure the Open Loop Correction Policy parameters, run the following command:

```
npu(config-bs-66053-pwrctrl)# olpolicy [positivecoefficient <(0 to 1 StepSize 0.05)>] [negativecoefficient<(0 to 1 StepSize 0.05)>] [max-positivecorrection <(0 to 20 StepSize 0.1)>] [max-negativecorrection <(0 to 20 StepSize 0.1)>]
```



#### IMPORTANT

When creating a new BS, at least one of the Power Control Open Loop Correction Policy parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** **npu(config-bs-66053-pwrctrl)# olpolicy** [positivecoefficient <(0 to 1 StepSize 0.05)> ] [negativecoefficient<(0 to 1 StepSize 0.05)> ] [max-positivecorrection <(0 to 20 StepSize 0.1)> ] [max-negativecorrection <(0 to 20 StepSize 0.1)> ]

**Privilege Level** 10

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
[positivecoefficient <(0 to 1 StepSize 0.05)> ]	Correction coefficient for open loop when giving positive corrections	Optional	0.7	0 to 1 in steps of 0.05
[negativecoefficient <(0 to 1 StepSize 0.05)> ]	Correction coefficient for open loop when giving negative corrections	Optional	0.7	0 to 1 in steps of 0.05
[max-positivecorrection <(0 to 20 StepSize 0.1)> ]	Maximum positive power correction (in dB) for open loop	Optional	8	0 to 20 in steps of 0.1
[max-negativecorrection <(0 to 20 StepSize 0.1)> ]	Maximum negative power correction (in dB) for open loop	Optional	8	0 to 20 in steps of 0.1

**Command**

bs power control configuration mode

**Modes**

#### 4.8.6.2.5 Configuring the Power Control Open Loop Correction Range Parameters

To configure the Open Loop Correction Range parameters, run the following command:

```
npu(config-bs-66053-pwrctrl)# olrange [lowthrshld-linear <(-20 to 0 StepSize 0.1)>] [lowthrshld-constant <(-20 to 0 StepSize 0.1)>] [highthrshld-linear <(0 to 20 StepSize 0.1)>] [highthrshld-constant <(0 to 20 StepSize 0.1)>]
```

**IMPORTANT**

When creating a new BS, at least one of the Power Control Open Loop Correction Range parameters must be configured explicitly (even if configured to the default value).

**Command Syntax**

```
npu(config-bs-66053-pwrctrl)# olrange [lowthrshld-linear <(-20 to 0 StepSize 0.1)> ] [lowthrshld-constant <(-20 to 0 StepSize 0.1)> ] [highthrshld-linear <(0 to 20 StepSize 0.1)> ] [highthrshld-constant <(0 to 20 StepSize 0.1)> ]
```

**Privilege Level**

10

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
[lowthrshld-linear <(-20 to 0 StepSize 0.1)> ]	The open loop correction range threshold (in dB) below which linear corrections are made.  Cannot be lower than orange-lowthrshld-constant (see below)	Optional	-18	-20 to 0 in steps of 0.1
[lowthrshld-constant <(-20 to 0 StepSize 0.1)> ]	The open loop correction range threshold (in dB) below which constant corrections are made.	Optional	-19	-20 to 0 in steps of 0.1
[highthrshld-linear <(0 to 20 StepSize 0.1)> ]	The open loop correction range threshold (in dB) above which linear corrections are made.	Optional	18	0 to 20 in steps of 0.1
[highthrshld-constant <(0 to 20 StepSize 0.1)> ]	The open loop correction range threshold (in dB) above which constant corrections are made.  Cannot be lower than orange-highthrshld-linear (see above)	Optional	19	0 to 20 in steps of 0.1

**Command**

bs power control configuration mode

**Modes**

#### 4.8.6.2.6 **Configuring the Power Control Closed Loop - Unstable MS Correction Policy Parameters**

To configure the Closed Loop - Unstable MS Correction Policy parameters, run the following command:

```
npu(config-bs-66053-pwrctrl)# clunstable [positivecoefficient <(0 to 1 StepSize 0.05)>] [negativecoefficient <(0 to 1 StepSize 0.05)>] [max-positivecorrection <(0 to 20 StepSize 0.1)>][max-negativecorrection <(0 to 20 StepSize 0.1)>]
```

**IMPORTANT**

When creating a new BS, at least one of the Power Control Closed Loop - Unstable MS parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** `npu(config-bs-66053-pwrctrl)# clunstable [positivecoefficient <(0 to 1 StepSize 0.05)> ] [negativecoefficient <(0 to 1 StepSize 0.05)> ] [max-positivecorrection <(0 to 20 StepSize 0.1)> ] [max-negativecorrection <(0 to 20 StepSize 0.1)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[positivecoefficient <(0 to 1 StepSize 0.05)> ]	Correction coefficient for problematic MS in a closed loop when giving positive corrections	Optional	0.8	0 to 1 in steps of 0.05
[negativecoefficient <(0 to 1 StepSize 0.05)> ]	Correction coefficient for problematic MS in a closed loop when giving negative corrections	Optional	0.7	0 to 1 in steps of 0.05
[max-positivecorrection <(0 to 20 StepSize 0.1)> ]	Maximum positive power correction (in dB) for problematic MS in a closed loop	Optional	3	0 to 20 in steps of 0.1
[max-negativecorrection <(0 to 20 StepSize 0.1)> ]	Maximum negative power correction (in dB) for problematic MS in a closed loop	Optional	8	0 to 20 in steps of 0.1

**Command Modes** bs power control configuration mode

#### 4.8.6.2.7 Configuring the Power Control Closed Loop - MS in Network Entry Correction Policy Parameters

To configure the Closed Loop - MS in Network Entry Correction Policy parameters, run the following command:

**npu(config-bs-66053-pwrctrl)# clne** [positivecoefficient <(0 to 1 StepSize 0.05)>] [negativecoefficient <(0 to 1 StepSize 0.05)>] [max-positivecorrection <(0 to 20 StepSize 0.1)>] [max-negativecorrection <(0 to 20 StepSize 0.1)>]

**IMPORTANT**

When creating a new BS, at least one of the Power Control Closed Loop - MS in Network Entry parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** `npu(config-bs-66053-pwrctrl)# clne [positivecoefficient <(0 to 1 StepSize 0.05)> ] [negativecoefficient <(0 to 1 StepSize 0.05)> ] [max-positivecorrection <(0 to 20 StepSize 0.1)> ] [max-negativecorrection <(0 to 20 StepSize 0.1)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[positivecoefficient <(0 to 1 StepSize 0.05)> ]	Correction coefficient for network entry in closed loop when giving positive corrections	Optional	0.7	0 to 1 dB in steps of 0.05
[negativecoefficient <(0 to 1 StepSize 0.05)> ]	Correction coefficient for network entry in closed loop when giving negative corrections	Optional	0.7	0 to 1 dB in steps of 0.05
[max-positivecorrection <(0 to 20 StepSize 0.1)> ]	Maximum positive power correction (in dB) for network entry in closed loop	Optional	8	0 to 20 in steps of 0.1
[max-negativecorrection <(0 to 20 StepSize 0.1)> ]	Maximum negative power correction (in dB) for network entry in closed loop	Optional	8	0 to 20 in steps of 0.1

**Command Modes** bs power control configuration mode

#### 4.8.6.2.8 **Configuring the Power Control Closed Loop Correction Range Parameters**

To configure the Closed Loop Correction Range parameters, run the following command:

**npu(config-bs-66053-pwrctrl)# clrange** [lowthrshld-linear <(-20 to 0 StepSize 0.1)>] [lowthrshld-constant <(-20 to 0 StepSize 0.1)>] [highthrshld-linear <(0 to 20 StepSize 0.1)>] [highthrshld-constant <(0 to 20 StepSize 0.1)>]



### IMPORTANT

When creating a new BS, at least one of the Power Control Closed Loop Correction Range parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** **npu(config-bs-66053-pwrctrl)# clrange** [lowthrshld-linear <(-20 to 0 StepSize 0.1)> ] [lowthrshld-constant <(-20 to 0 StepSize 0.1)> ] [highthrshld-linear <(0 to 20 StepSize 0.1)> ] [highthrshld-constant <(0 to 20 StepSize 0.1)> ]

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[lowthrshld-linear <(-20 to 0 StepSize 0.1)> ]	Closed loop correction range threshold (in dB) below which linear corrections are made.  Cannot be lower than clrange-lowthrshld-constant (see below)	Optional	-2	-20 to 0 in steps of 0.1
lowthrshld-constant <(-20 to 0 StepSize 0.1)> ]	Closed loop correction range threshold (in dB) below which constant corrections are made.	Optional	-8	-20 to 0 in steps of 0.1
[highthrshld-linear <(0 to 20 StepSize 0.1)> ]	Closed loop correction range threshold (in dB) above which linear corrections are made.	Optional	2	-20 to 0 in steps of 0.1
[highthrshld-constant <(0 to 20 StepSize 0.1)> ]	Closed loop correction range threshold (in dB) above which constant corrections are made.  Cannot be lower than clrange-highthrshld-linear (see above)	Optional	8	-20 to 0 in steps of 0.1

**Command**    bs power control configuration mode  
**Modes**

### 4.8.6.3 Restoring Default Values for Power Control Configuration Parameters

After enabling the Power Control configuration mode you can restore the default values for parameters in the following parameters tables:

- Noise and Interference Level (refer to [Section 4.8.6.3.1](#))
- Maximum EIRP (refer to [Section 4.8.6.3.2](#))
- Required C/N Level (refer to [Section 4.8.6.3.3](#))
- Open Loop Correction Policy (refer to [Section 4.8.6.3.4](#))
- Open Loop Correction Range (refer to [Section 4.8.6.3.5](#))
- Closed Loop - Unstable MS (refer to [Section 4.8.6.3.6](#))
- Closed Loop - MS in Network Entry (refer to [Section 4.8.6.3.7](#))
- Closed Loop Correction Range (refer to [Section 4.8.6.3.8](#))

#### 4.8.6.3.1 Restoring the Default Values of Power Control Target Noise and Interference Level Parameters

To restore one or all of the Target Noise and Interference Level parameters to their default values, run the following command:

```
npu(config-bs-66053-pwrctrl)# no nilevels [cqi-ack-ranging] [pusc]
```

You can restore only one parameter to its default values by specifying only that parameter. For example, to restore only the pusc to the default value, run the following command:

```
npu(config-bs-66053-pwrctrl)# no nilevels pusc
```

The parameter will be restored to its default value, while the other parameter will remain unchanged.

To restore all Target Noise and Interference Level parameters to their default value, run the following command:

```
npu(config-bs-66053-pwrctrl)# no nilevels
```



**NOTE**

Refer to [Section 4.8.6.2.1](#) for a description and default values of these parameters.

---

**Command Syntax**    `npu(config-bs-66053-pwrctrl)# no nilevels [cqi-ack-ranging ] [pusc]`

---

**Privilege Level**    10

---

**Command Modes**    bs power control configuration mode

### 4.8.6.3.2 Restoring the Default Values of the Power Control Maximum EIRP Parameter

To restore the `maxeirxp` parameter to its default value, run the following command:

**`npu(config-bs-66053-pwrctrl)# no maxeirxp`**

**NOTE**

Refer to [Section 4.8.6.2.2](#) for a description and default value of this parameter.

---

**Command Syntax**    `npu(config-bs-66053-pwrctrl)# no maxeirxp`

---

**Privilege Level**    10

---

**Command Modes**    bs power control configuration mode

### 4.8.6.3.3 Restoring the Default Values of Power Control Required C/N Level Parameters

To restore some or all of the Required C/N Levels parameters to their default values, run the following command:

```
npu(config-bs-66053-pwrctrl)# no requiredcnr [ack] [cqi] [cdma] [qpsk-1by2]
[qpsk-3by4] [qam16-1by2] [qam16-3by4] [qam64-1by2] [qam64-2by3]
[qam64-3by4] [qam64-5by6]
```

You can restore only some parameters to their default values by specifying only those parameter. For example, to restore only the ack and cqi parameters to the default values, run the following command:

```
npu(config-bs-66053-pwrctrl)# no requiredcnr ack cqi
```

These parameters will be restored to their default value, while the other parameters will remain unchanged.

To restore all Required C/N Levels parameters to their default value, run the following command:

```
npu(config-bs-66053-pwrctrl)# no requiredcnr
```



#### NOTE

Refer to [Section 4.8.6.2.3](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<pre><b>npu(config-bs-66053-pwrctrl)# no requiredcnr</b> [ack ] [cqi ] [cdma ] [qpsk-1by2 ] [qpsk-3by4 ] [qam16-1by2 ] [qam16-3by4 ] [qam64-1by2 ] [qam64-2by3 ] [qam64-3by4 ] [qam64-5by6 ]</pre>
-----------------------	--

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs power control configuration mode
----------------------	-------------------------------------

#### 4.8.6.3.4 Restoring the Default Values of Power Control Open Loop Correction Policy Parameters

To restore some or all of the Open Loop Correction Policy parameters to their default values, run the following command:

```
npu(config-bs-66053-pwrctrl)# no olpolicy [positivecoefficient]
[negativecoefficient] [max-positivecorrection] [max-negativecorrection]
```

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the positivecoefficient and negativecoefficient parameters to the default values, run the following command:

**npu(config-bs-66053-pwrctrl)# no olpolicy positivecoefficient  
negativecoefficient**

These parameters will be restored to their default value, while the other parameters will remain unchanged.

To restore all Open Loop Correction Policy parameters to their default value, run the following command:

**npu(config-bs-66053-pwrctrl)# no olpolicy**



#### NOTE

Refer to [Section 4.8.6.2.4](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<b>npu(config-bs-66053-pwrctrl)# no olpolicy</b> [positivecoefficient ] [negativecoefficient ] [max-positivecorrection ] [max-negativecorrection ]
-----------------------	--

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs power control configuration mode
----------------------	-------------------------------------

#### 4.8.6.3.5 Restoring the Default Values of Power Control Open Loop Correction Range Parameters

To restore some or all of the Open Loop Correction Range parameters to their default values, run the following command:

**npu(config-bs-66053-pwrctrl)# no orange** [lowthrshld-linear]  
[lowthrshld-constant] [highthrshld-linear] [highthrshld-constant]

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the highthrshld-linear and highthrshld-constant parameters to the default values, run the following command:

**npu(config-bs-66053-pwrctrl)# no orange highthrshld-linear  
highthrshld-constant**

These parameters will be restored to their default value, while the other parameters will remain unchanged.

To restore all Open Loop Correction Range parameters to their default value, run the following command:

**npu(config-bs-66053-pwrctrl)# no olrange**



#### NOTE

Refer to [Section 4.8.6.2.5](#) for a description and default values of these parameters.

<b>Command Syntax</b>	npu(config-bs-66053-pwrctrl)# no olrange [lowthrshld-linear ] [lowthrshld-constant ] [highthrshld-linear ] [highthrshld-constant ]
-----------------------	--

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs power control configuration mode
----------------------	-------------------------------------

### 4.8.6.3.6 Restoring the Default Values of Power Control Closed Loop - Unstable MS Correction Policy Parameters

To restore some or all of the Open Loop - Unstable MS Correction Policy parameters to their default values, run the following command:

**npu(config-bs-66053-pwrctrl)# no clunstable** [positivecoefficient]  
[negativecoefficient] [max-positivecorrection] [max-negativecorrection]

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the positivecoefficient and negativecoefficient parameters to the default values, run the following command:

**npu(config-bs-66053-pwrctrl)# no clunstable positivecoefficient  
negativecoefficient**

These parameters will be restored to their default value, while the other parameters will remain unchanged.

To restore all Open Loop - Unstable MS parameters to their default value, run the following command:

**npu(config-bs-66053-pwrctrl)# no clunstable**



#### NOTE

Refer to [Section 4.8.6.2.6](#) for a description and default values of these parameters.

---

**Command Syntax**    `npu(config-bs-66053-pwrctrl)# no clunstable [positivecoefficient ] [negativecoefficient ] [max-positivecorrection ] [max-negativecorrection ]`

---

**Privilege Level**    10

---

**Command Modes**    bs power control configuration mode

#### 4.8.6.3.7 Restoring the Default Values of Power Control Closed Loop - MS in Network Entry Correction Policy Parameters

To restore some or all of the Open Loop - MS in Network Entry Correction Policy parameters to their default values, run the following command:

```
npu(config-bs-66053-pwrctrl)# no clne [positivecoefficient] [negativecoefficient] [max-positivecorrection] [max-negativecorrection]
```

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the positivecoefficient and negativecoefficient parameters to the default values, run the following command:

```
npu(config-bs-66053-pwrctrl)# no clne positivecoefficient negativecoefficient
```

These parameters will be restored to their default value, while the other parameters will remain unchanged.

To restore all Open Loop - MS in Network Entry parameters to their default value, run the following command:

```
npu(config-bs-66053-pwrctrl)# no clne
```



#### NOTE

Refer to [Section 4.8.6.2.7](#) for a description and default values of these parameters.

---

**Command Syntax**    `npu(config-bs-66053-pwrctrl)# no clne [positivecoefficient ] [negativecoefficient ] [max-positivecorrection ] [max-negativecorrection ]`

---

**Privilege Level** 10

---

**Command Modes** bs power control configuration mode

#### 4.8.6.3.8 Restoring the Default Values of Power Control Closed Loop Correction Range Parameters

To restore some or all of the Closed Loop Correction Range parameters to their default values, run the following command:

```
npu(config-bs-66053-pwrctrl)# no clrange [lowthrshld-linear]
[lowthrshld-constant] [highthrshld-linear] [highthrshld-constant]
```

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the highthrshld-linear and highthrshld-constant parameters to the default values, run the following command:

```
npu(config-bs-66053-pwrctrl)# no clrange highthrshld-linear
highthrshld-constant
```

These parameters will be restored to their default value, while the other parameters will remain unchanged.

To restore all Closed Loop Correction Range parameters to their default value, run the following command:

```
npu(config-bs-66053-pwrctrl)# no clrange
```



#### NOTE

Refer to [Section 4.8.6.2.8](#) for a description and default values of these parameters.

---

**Command Syntax** npu(config-bs-66053-pwrctrl)# no clrange [lowthrshld-linear ]  
[lowthrshld-constant ] [highthrshld-linear ]  
[highthrshld-constant ]

---

**Privilege Level** 10

---

**Command Modes** bs power control configuration mode

### 4.8.6.4 Terminating the Power Control Configuration Mode

Run the following command to terminate the Power Control configuration mode:

```
npu(config-bs-66053-pwrctrl)# exit
```



#### IMPORTANT

Do not forget to execute the apply command before terminating the Power Control configuration mode: **npu(config-bs-66053-pwrctrl)# apply**

<b>Command Syntax</b>	<b>npu(config-bs-66053-pwrctrl)# exit</b>
-----------------------	---

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs power control configuration mode
----------------------	-------------------------------------

### 4.8.6.5 Displaying Configuration Information for Power Control Parameters

You can display the current configuration information for the following parameters tables:

- Noise and Interference Level (refer to [Section 4.8.6.5.1](#))
- Maximum EIRP (refer to [Section 4.8.6.5.2](#))
- Required C/N Level (refer to [Section 4.8.6.5.3](#))
- Open Loop Correction Policy (refer to [Section 4.8.6.5.4](#))
- Open Loop Correction Range (refer to [Section 4.8.6.5.5](#))
- Closed Loop - Unstable MS (refer to [Section 4.8.6.5.6](#))
- Closed Loop - MS in Network Entry (refer to [Section 4.8.6.5.7](#))
- Closed Loop Correction Range (refer to [Section 4.8.6.5.8](#))
- All (refer to [Section 4.8.6.5.9](#))

#### 4.8.6.5.1 Displaying Configuration Information for Power Control Target Noise and Interference Level Parameters

To display configuration for the Power Control Target Noise and Interference Level parameters, run the following command:

```
npu# show pwrctrl-nilevels bs [<(1 to 16777215 StepSize 1)
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Power Control Target Noise and Interference Level parameters of BS 66053, run the following command:

```
npu# show pwrctrl-nilevels bs 66053
```

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show pwrctrl-nilevels bs
```

---

**Command Syntax**     **npu# show pwrctrl-nilevels bs** [<(1 to 16777215 StepSize 1)

---

**Privilege Level**     1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Target Noise and Interference Level parameters of a specific BS. Do not specify a value for this parameter if you want to display the Target Noise and Interference Level parameters of all BSs.	Optional	N/A	1-16777215



<b>Display</b>	BSIDLSB	: <value>
<b>Format</b>	NoiseandInterferenceLevelforCQI&ACKRegion	: <value>
(for each existing BS if requested for all BSs)	NoiseandInterferenceLevelforPUSCZone	: <value>

<b>Command Modes</b>	Global command mode
----------------------	---------------------

#### 4.8.6.5.2 Displaying Configuration Information for Power Control Maximum EIRP

To display configuration for the Power Control Maximum EIRP parameter, run the following command:

```
npu# show pwrctrl-maxeirxp bs [<(1 to 16777215 StepSize 1)
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Power Control Maximum EIRP parameter of BS 66053, run the following command:

```
npu# show pwrctrl-maxeirxp bs 66053
```

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show pwrctrl-maxeirxp bs
```

<b>Command Syntax</b>	<b>npu# show pwrctrl-maxeirxp bs</b> [<(1 to 16777215 StepSize 1)
-----------------------	---

<b>Privilege Level</b>	1
------------------------	---

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Maximum EIRP parameter of a specific BS. Do not specify a value for this parameter if you want to display the Maximum EIRP parameter of all BSs.	Optional	N/A	1-16777215

**Display****Format**

BSIDLBS

:&lt;value&gt;

MaxEIRxP

:&lt;value&gt;

(for each existing BS if requested for all BSs)

**Command Modes**

Global command mode

### 4.8.6.5.3 Displaying Configuration Information for Power Control Required C/N Level Parameters

To display configuration for the Power Control Required C/N Level parameters, run the following command:

```
npu# show pwrctrl-requiredcnr bs [(1 to 16777215 StepSize 1)]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Power Control Required C/N Level parameters of BS 66053, run the following command:

```
npu# show pwrctrl-requiredcnr bs 66053
```

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show pwrctrl-requiredcnr bs
```

**Command Syntax**     `npu# show pwrctrl-requiredcnr bs [<(1 to 16777215 StepSize 1)`

**Privilege Level**     1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Required C/N Level parameters of a specific BS. Do not specify a value for this parameter if you want to display the Required C/N Level parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

```

BSIDLSB                               : <value>
RequiredCNRforACK                      : <value>
(for each existing BS                    : <value>
if requested for all BSs)
RequiredCNRforCQI                      : <value>
RequiredCNRforCDMA                     : <value>
RequiredCNRforQPSK1/2                  : <value>
RequiredCNRforQPSK3/4                  : <value>
RequiredCNRfor16QAM1/2                 : <value>
RequiredCNRfor16QAM3/4                 : <value>
RequiredCNRfor64QAM1/2                 : <value>
RequiredCNRfor64QAM2/3                 : <value>
RequiredCNRfor64QAM3/4                 : <value>
RequiredCNRfor64QAM5/6                 : <value>

```

**Command Modes**     Global command mode

#### 4.8.6.5.4 Displaying Configuration Information for Power Control Open Loop Correction Policy Parameters

To display configuration for the Power Control Open Loop Correction Policy parameters, run the following command:

```
npu# show pwrctrl-olpolicy bs [<(1 to 16777215 StepSize 1)
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Power Control Open Loop Correction Policy parameters of BS 66053, run the following command:

```
npu# show pwrctrl-olpolicy bs 66053
```

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show pwrctrl-olpolicy bs
```

---

**Command Syntax**     **npu# show pwrctrl-olpolicy bs** [<(1 to 16777215 StepSize 1)

---

**Privilege Level**     1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Open Loop Correction Policy parameters of a specific BS. Do not specify a value for this parameter if you want to display the Open Loop Correction Policy parameters of all BSs.	Optional	N/A	1-16777215

<b>Display</b>	BSIDLSB	: <value>
<b>Format</b>	OpenLoopPositiveCorrectionCoefficient	: <value>
(for each existing BS if requested for all BSs)	OpenLoopNegativeCorrectionCoefficient	: <value>
	OpenLoopMaximumPositivePowerCorrection(dB)	: <value>
	OpenLoopMaximumNegativePowerCorrection(dB)	: <value>

<b>Command Modes</b>	Global command mode
----------------------	---------------------

#### 4.8.6.5.5 Displaying Configuration Information for Power Control Open Loop Correction Range Parameters

To display configuration for the Power Control Open Loop Correction Range parameters, run the following command:

```
npu# show pwrctrl-orange bs [(1 to 16777215 StepSize 1)]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Power Control Open Loop Correction Range parameters of BS 66053, run the following command:

```
npu# show pwrctrl-orange bs 66053
```

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show pwrctrl-orange bs
```

<b>Command Syntax</b>	<b>npu# show pwrctrl-orange bs</b> [(1 to 16777215 StepSize 1)]
-----------------------	---

<b>Privilege Level</b>	1
------------------------	---

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Open Loop Correction Range parameters of a specific BS. Do not specify a value for this parameter if you want to display the Open Loop Correction Range parameters of all BSs.	Optional	N/A	1-16777215

**Display****Format**

(for each existing BS if requested for all BSs)

BSIDLBS	: <value>
OpenLoopLowerThresholdforLinearCorrection(dB)	: <value>
OpenLoopLowerThresholdforConstantCorrection(dB)	: <value>
OpenLoopHigherThresholdforLinearCorrection(dB)	: <value>
OpenLoopHigherThresholdforConstantCorrection(dB)	: <value>

**Command Modes**

Global command mode

#### 4.8.6.5.6 Displaying Configuration Information for Power Control Closed Loop - Unstable MS Correction Policy Parameters

To display configuration for the Power Control Closed Loop - Unstable MS Correction Policy parameters, run the following command:

```
npu# show pwrctrl-clunstable bs [(1 to 16777215 StepSize 1)]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Power Control Closed Loop - Unstable MS parameters of BS 66053, run the following command:

```
npu# show pwrctrl-clunstable bs 66053
```

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show pwrctrl-clunstable bs
```

**Command Syntax**     **npu# show pwrctrl-clunstable bs** [<(1 to 16777215 StepSize 1)>

**Privilege Level**     1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Closed Loop - Unstable MS parameters of a specific BS. Do not specify a value for this parameter if you want to display the Closed Loop - Unstable MS parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

```

BSIDLBSB                               :<value>
ClosedLoopUnstableMSPositiveCorrectionCoefficient :<value>
ClosedLoopUnstableMSNegativeCorrectionCoefficient :<value>
ClosedLoopUnstableMSMaximumPositivePowerCorrection(dB) :<value>
ClosedLoopUnstableMSMaximumNegativePowerCorrection(dB) :<value>

```

(for each existing BS if requested for all BSs)

**Command Modes**     Global command mode

#### 4.8.6.5.7 **Displaying Configuration Information for Power Control Closed Loop - MS in Network Entry Correction Policy Parameters**

To display configuration for the Power Control Closed Loop - MS in Network Entry Correction Policy parameters, run the following command:

**npu# show pwrctrl-clne bs** [<(1 to 16777215 StepSize 1)>

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Power Control Closed Loop - MS in Network Entry parameters of BS 66053, run the following command:

**npu# show pwrctrl-clne bs 66053**

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show pwrctrl-clne bs**

**Command Syntax**      **npu# show pwrctrl-clne bs** [(1 to 16777215 StepSize 1)]

**Privilege Level**      1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Closed Loop - MS in Network Entry parameters of a specific BS. Do not specify a value for this parameter if you want to display the Closed Loop - MS in Network Entry parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

```

BSIDLBS                               :<value>
ClosedLoopNetworkEntryPositiveCorrectionCoefficient:<value>
(for each existing BS
if requested
for all BSs)
ClosedLoopNetworkEntryNegativeCorrectionCoefficient:<value>
ClosedLoopNetworkEntryMaximumPositivePowerCorrection(dB):<value>
ClosedLoopNetworkEntryMaximumNegativePowerCorrection(dB):<value>
    
```

**Command Modes**      Global command mode



#### 4.8.6.5.8 Displaying Configuration Information for Power Control Closed Loop Correction Range Parameters

To display configuration for the Power Control Closed Loop Correction Range parameters, run the following command:

```
npu# show pwrctrl-clrange bs [(1 to 16777215 StepSize 1)]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Power Control Closed Loop Correction Range parameters of BS 66053, run the following command:

```
npu# show pwrctrl-clrange bs 66053
```

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show pwrctrl-clrange bs
```

---

**Command Syntax**     **npu# show pwrctrl-clrange bs** [(1 to 16777215 StepSize 1)]

---

**Privilege Level**     1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Closed Loop Correction Range parameters of a specific BS. Do not specify a value for this parameter if you want to display the Closed Loop Correction Range parameters of all BSs.	Optional	N/A	1-16777215

<b>Display</b>	BSIDLSB	:<value>
<b>Format</b>	ClosedLoopLowerThresholdforLinearCorrection(dB)	:<value>
(for each existing BS if requested for all BSs)	ClosedLoopLowerThresholdforConstantCorrection(dB)	:<value>
	ClosedLoopHigherThresholdforLinearCorrection(dB)	:<value>
	ClosedLoopHigherThresholdforConstantCorrection(dB)	:<value>

<b>Command Modes</b>	Global command mode
----------------------	---------------------

#### 4.8.6.5.9 Displaying Configuration Information for All Power Control Parameters

To display configuration for all Power Control parameters, run the following command:

```
npu# show pwrctrl-all bs [<(1 to 16777215 StepSize 1)>
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display all Power Control parameters of BS 66053, run the following command:

```
npu# show pwrctrl-all bs 66053
```

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show pwrctrl-all bs
```

<b>Command Syntax</b>	<b>npu# show pwrctrl-all bs</b> [<(1 to 16777215 StepSize 1)>
-----------------------	---

<b>Privilege Level</b>	10
------------------------	----

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display all Power Control parameters of a specific BS. Do not specify a value for this parameter if you want to display all Power Control parameters of all BSs.	Optional	N/A	1-16777215

**Command**

Global command mode

**Modes**

## 4.8.7 Managing BS Feedback Allocation Parameters

After enabling the BS configuration mode, you can execute the following tasks:

- Configure one or more of the Feedback Allocation parameters (refer to [Section 4.8.7.1](#)).
- Restore the default values of one or all of the Feedback Allocation parameters (refer to [Section 4.8.7.2](#)).

You can display configuration information for the Feedback Allocation parameters of a selected or all existing BSs (refer to [Section 4.8.7.3](#)).

### 4.8.7.1 Configuring Feedback Allocation Parameters



#### To configure the Feedback Allocation Parameters:

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# feedbackalloc [pr-cdma <(0 to 12000 StepSize 1)> ] [ir-cdma <(0 to 12000 StepSize 1)> ] [max-cqi <(0 to 29 StepSize 1)> ] [ert-poll-enable {true | false} ]
```

**IMPORTANT**

When creating a new BS, the mandatory max-cqi parameter must be configured. Typically it should be configured to 7 for bandwidth=5MHz and 19 for bandwidth=7 or 10 MHz.

**Command Syntax** `npu(config-bs-66053)# feedbackalloc [pr-cdma <(0 to 12000 StepSize 1)> ] [ir-cdma <(0 to 12000 StepSize 1)> ] [max-cqi <(0 to 29 StepSize 1)> ] [ert-poll-enable {true | false} ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[pr-cdma <(0 to 12000 StepSize 1)> ]	The period of PR CDMA allocations, in frames.  Cannot be higher than ir-cdma (see below)	Optional	5	0 - 12000
[ir-cdma <(0 to 12000 StepSize 1)> ]	The period of IR CDMA allocations, in frames	Optional	20	0 - 12000
[max-cqi <(0 to 29 StepSize 1)> ]	The maximum size allowed for the CQI region, in subchannels.	Mandatory when creating a new BS.	N/A*	<ul style="list-style-type: none"> <li>■ 0-11 for bw=5MHz</li> <li>■ 0-29 for bw=7 or 10 MHz</li> </ul>
[ert-poll-enable {true   false} ]	Defines the BS's behavior (whether polling is enabled or not) upon reception of zero size BW requests.	Optional	true	<ul style="list-style-type: none"> <li>■ true</li> <li>■ False</li> </ul>

**Command Modes** bs configuration mode

\* The default value for the mandatory max-cqi parameter is be 7 for bw=5MHz and 19 for bw=7 or 10 MHz.

### 4.8.7.2 Restoring the Default Values of Feedback Allocation Parameters

To restore one or all of the Feedback Allocation non-mandatory parameters to their default values, run the following command:

```
npu(config-bs-66053)# no feedbackalloc [pr-cdma] [ir-cdma] [ert-poll-enable]
```

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the pr-cdma and ir-cdma parameters to the default values, run the following command:

```
npu(config-bs-66053)# no feedbackalloc pr-cdma ir-cdma
```

These parameters will be restored to their default value, while the other parameters will remain unchanged.

To restore all Feedback Allocation non-mandatory parameters to their default value, run the following command:

```
npu(config-bs-66053)# no feedbackalloc
```



#### NOTE

Refer to [Section 4.8.7.1](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<b>npu(config-bs-66053)# no feedbackalloc</b> [pr-cdma ] [ir-cdma ] [ert-poll-enable]
-----------------------	---

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs configuration mode
----------------------	-----------------------

### 4.8.7.3 Displaying Configuration Information for Feedback Allocation Parameters

To display configuration information for Feedback Allocation parameters, run the following command:

```
npu# show feedbackalloc bs [<(1 to 16777215 StepSize 1)
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Feedback Allocation parameters of BS 66053, run the following command:

**npu# show feedbackalloc bs 66053**

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show feedbackalloc bs**

**Command Syntax**     **npu# show feedbackalloc bs** [<(1 to 16777215 StepSize 1)>]

**Privilege Level**     1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display Feedback Allocation parameters of a specific BS. Do not specify a value for this parameter if you want to display Feedback Allocation parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

BSIDLSB	: <value>	
PRCDMAAllocationsPeriod(frames)	: <value>	
(for each existing BS	IRCDMAAllocationsPeriod(frames)	: <value>
if requested for all BSs)	MaximumCQIRegionSize(subchannels)	: <value>

**Command Modes**     Global command mode

## 4.8.8 Managing Neighbor Advertisement Parameters

After enabling the BS configuration mode, you can execute the following tasks:

- Configure one or more of the Neighbor Advertisement parameters (refer to [Section 4.8.8.1](#)).
- Restore the default values of one or all of the Neighbor Advertisement parameters (refer to [Section 4.8.8.2](#)).

You can display configuration information for the Neighbor Advertisement parameters of a selected or all existing BSs (refer to [Section 4.8.8.3](#)).

### 4.8.8.1 Configuring Neighbor Advertisement Parameters



**To configure the Neighbor Advertisement Parameters:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# nbradvertise [mininterval-normalload <(0 to 100 StepSize 0.1)>] [mininterval-highload <(0 to 100 StepSize 0.1)>] [triggersetup <(0 to 100 StepSize 0.1)>]
```



#### IMPORTANT

When creating a new BS, at least one of the Neighbour Advertisement parameters must be configured explicitly (even if configured to the default value).

<b>Command Syntax</b>	<code>npu(config-bs-66053)# nbradvertise [mininterval-normalload &lt;(0 to 100 StepSize 0.1)&gt; ] [mininterval-highload &lt;(0 to 100 StepSize 0.1)&gt; ] [triggersetup &lt;(0 to 100 StepSize 0.1)&gt; ]</code>
-----------------------	---

<b>Privilege Level</b>	10
------------------------	----

<b>Syntax Description</b>	
---------------------------	--

Parameter	Description	Presence	Default Value	Possible Values

[mininterval-normalload <(0 to 100 StepSize 0.1)> ]	The minimum interval (in seconds) between NBRADV transmissions in normal load state.	Optional	0.5	0 -100 in steps of 0.1
[mininterval-highload <(0 to 100 StepSize 0.1)> ]	The minimum interval (in seconds) between NBRADV transmissions in high load state.	Optional	4	0 -100 in steps of 0.1
[triggersetup <(0 to 100 StepSize 0.1)> ]	The periodic NBRADV transmission interval, in seconds	Optional	10	0 - 100 in steps of 0.1

**Command Modes** bs configuration mode

### 4.8.8.2 Restoring the Default Values of Neighbor Advertisement Parameters

To restore one or all of the Neighbor Advertisement parameters to their default values, run the following command:

```
npu(config-bs-66053)# no nbradvertise [mininterval-normalload]
[mininterval-highload] [triggersetup]
```

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the mininterval-normalload parameters to the default values, run the following command:

```
npu(config-bs-66053)# no nbradvertise mininterval-normalload
```

This parameter will be restored to its default value, while the other parameters will remain unchanged.

To restore all Neighbor Advertisement parameters to their default value, run the following command:

```
npu(config-bs-66053)# no nbradvertise
```



#### NOTE

Refer to [Section 4.8.8.1](#) for a description and default values of these parameters.

**Command Syntax** `npu(config-bs-66053)# no nbradvertise [mininterval-normalload] [mininterval-highload] [triggersetup]`



---

**Privilege Level** 10

---

**Command Modes** bs configuration mode

### 4.8.8.3 Displaying Configuration Information for Neighbor Advertisement Parameters

To display configuration information for Neighbor Advertisement parameters, run the following command:

**npu# show nbradvertise bs** [<(1 to 16777215 StepSize 1)]

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Neighbor Advertisement parameters of BS 66053, run the following command:

**npu# show nbradvertise bs 66053**

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show nbradvertise bs**

---

**Command Syntax** npu# show nbradvertise bs [<(1 to 16777215 StepSize 1)]

---

**Privilege Level** 1

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display Neighbour Advertisement parameters of a specific BS. Do not specify a value for this parameter if you want to display Neighbour Advertisement parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

(for each existing BS if requested for all BSs)

BSIDLSB	: <value>
MinimumInterval-NormalLoad	: <value>
MinimumInterval-HighLoad	: <value>
PeriodicInterval	: <value>

**Command Modes**

Global command mode

## 4.8.9 Managing Triggers Parameters

After enabling the BS configuration mode, you can configure one or more of the Triggers parameters (refer to [Section 4.8.9.1](#)).

You can display configuration information for the Triggers parameters of a selected or all existing BSs (refer to [Section 4.8.9.2](#)).

### 4.8.9.1 Configuring Triggers Parameters



**To configure the Triggers Parameters:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# triggers-<trigger-name> <trigger-range>
```

Each Trigger is configured separately. This is the general structure of the command.



**IMPORTANT**

When creating a new BS, at least one of the Triggers parameters must be configured explicitly.

**Command Syntax**     **npu(config-bs-66053)# triggers-*<trigger-name>* *<trigger-range>***

**Privilege Level**     10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<i>&lt;trigger-name&gt;</i>	The Trigger name.	Mandatory	N/A	See <a href="#">Table 4-3</a> 0 below
<i>&lt;trigger-value&gt;</i>	Defines the threshold value for the Trigger.	Mandatory	N/A	See <a href="#">Table 4-3</a> 0 below

**Command Modes**     bs configuration mode

**Table 4-30: Trigger Names and Possible Value Ranges**

Trigger Name	Trigger Condition	Action	Possible Values
triggers-scnreq-cinr-min	The C/N at the Serving BS is below the Trigger threshold (in dB)	Scan Request	-64 to 63.5 in steps of 0.5
triggers-scnreq-rssi-min	The RSSI at the Serving BS is below the Trigger thresholdd (in Bm)		-103.75 to -40 in steps of 0.25
triggers-scnreq-rtd-max	The Serving BS distance from the MS (calculated by measuring the round trip delay) is above the Trigger threshold (in meter)		0-3400 in steps of 50 if BS BW is 10 MHz, 0-6800 in steps of 50 if BS BW is 5 MHz, 0-4800 in steps of 50 if BS BW is 7 MHz

**Table 4-30: Trigger Names and Possible Value Ranges**

Trigger Name	Trigger Condition	Action	Possible Values
triggers-horeq-cinr-margin	The C/N at the Neighbour BS minus the C/N at the Serving BS is above the Trigger threshold (in dB)	Handover Request	-64 to 63.5 in steps of 0.5
triggers-horeq-cinr-max	The C/N at the Neighbour BS is above the Trigger threshold (in dB)		-64 to 63.5 in steps of 0.5
triggers-horeq-cinr-min	The C/N at the Serving BS is below the Trigger threshold (in dB)		-64 to 63.5 in steps of 0.5
triggers-horeq-rssi-margin	The RSSI at the Neighbour BS minus the RSSI at the Serving BS is above the Trigger threshold (in dBm)		-32 to 31.75 in steps of 0.25
triggers-horeq-rssi-max	The RSSI at the Neighbour BS is above the Trigger threshold (in dBm)		-103.75 to -40 in steps of 0.25
triggers-horeq-rssi-min	The RSSI at the Serving BS is below the Trigger threshold (in dBm)		-103.75 to -40 in steps of 0.25
triggers-horeq-rtd-max	The Serving BS distance from the MS (calculated by measuring the round trip delay) is above the Trigger threshold (in meter)		0-3400 in steps of 50 if BS BW is 10 MHz, 0-6800 in steps of 50 if BS BW is 5 MHz, 0-4800 in steps of 50 if BS BW is 7 MHz

### 4.8.9.2 Displaying Configuration Information for Triggers Parameters

To display configuration information for Triggers parameters, run the following command:

```
npu# show triggers bs [(1 to 16777215 StepSize 1)> TrigName {scnReqCinrMin | scnReqRssiMin | scnReqRtdMax | hoReqCinrMaxNbs | hoReqRssiMaxNbs | hoReqCinrMargin | hoReqRssiMargin | hoReqRtdMax | hoReqCinrMinSbs | hoReqRssiMinSbs}]
```

Specify the BS ID and Trigger name if you want to display configuration for a particular Trigger. For example, to display the scnReqCinrMin parameters of BS 66053, run the following command:

```
npu# show triggers bs 66053 TrigName scnReqCinrMin
```

Do not specify these parameters if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show triggers bs**

**Command Syntax** **npu# show triggers bs** [(1 to 16777215 StepSize 1)> TrigName {scnReqCinrMin | scnReqRssiMin | scnReqRtdMax | hoReqCinrMaxNbs | hoReqRssiMaxNbs | hoReqCinrMargin | hoReqRssiMargin | hoReqRtdMax | hoReqCinrMinSbs | hoReqRssiMinSbs} ]

**Privilege Level** 1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display a specific Trigger of a specific BS. Do not specify a value for this parameter if you want to display all Triggers parameters of all BSs.	Optional	N/A	1-16777215
TrigName {scnReqCinrMin   scnReqRssiMin   scnReqRtdMax   hoReqCinrMaxNbs   hoReqRssiMaxNbs   hoReqCinrMargin   hoReqRssiMargin   hoReqRtdMax   hoReqCinrMinSbs   hoReqRssiMinSbs} ]	The Trigger name  Specify only if you want to display a specific Trigger of a specific BS. Do not specify if you want to display all Triggers parameters of all BSs			<ul style="list-style-type: none"> <li>■ scnReqCinrMin</li> <li>■ scnReqRssiMin</li> <li>■ scnReqRtdMax</li> <li>■ hoReqCinrMaxNbs</li> <li>■ hoReqRssiMaxNbs</li> <li>■ hoReqCinrMargin</li> <li>■ hoReqRssiMargin</li> <li>■ hoReqRtdMax</li> <li>■ hoReqCinrMinSbs</li> <li>■ hoReqRssiMinSbs}</li> </ul>

<b>Display</b>	BSIDLSB	:<value>
<b>Format</b>	scnReqRssiMin	:<value>
(for a selected Trigger)		

**Command Modes** Global command mode

## 4.8.10 Managing Trigger Setup Parameters

After enabling the BS configuration mode, you can execute the following tasks:

- Configure one or more of the Trigger Setup parameters (refer to [Section 4.8.10.1](#)).
- Restore the default values of one or all of the Trigger Setup parameters (refer to [Section 4.8.10.2](#)).

You can display configuration information for the Trigger Setup parameters of a selected or all existing BSs (refer to [Section 4.8.10.3](#)).

### 4.8.10.1 Configuring Trigger Setup Parameters



**To configure the Trigger Setup Parameters:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# triggersetup [hysteresismargin <(0 to 255 StepSize 1)>]
[timetotrigger <(0 to 255 StepSize 1)>] [avgduration-rssi <(0 to 255 StepSize 1)>]
[avgduration-cinr <(0 to 255 StepSize 1)>] [avgduration-rttd <(0 to 255 StepSize 1)>]
```



#### IMPORTANT

When creating a new BS, at least one of the Trigger Setup parameters must be configured explicitly (even if configured to the default value).

**Command** `npu(config-bs-66053)# triggersetup [hysteresismargin <(0 to 255 StepSize 1)> ] [timetotrigger <(0 to 255 StepSize 1)> ] [avgduration-rssi <(0 to 255 StepSize 1)> ] [avgduration-cinr <(0 to 255 StepSize 1)> ] [avgduration-rtd <(0 to 255 StepSize 1)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[hysteresismargin <(0 to 255 StepSize 1)> ]	The CINR hysteresis in dB for adding or deleting neighbors. The hysteresis margin is used by the MS in the decision whether to include a neighbor BS in a list of possible target BSs.	Optional	5	0 - 255
[timetotrigger <(0 to 255 StepSize 1)> ]	The minimum time in milliseconds between adding or deleting a neighbor. It is the time that the MS takes to decide whether to select a neighbor BS as a possible target BS and is applicable only for HHO.	Optional	50	0 - 255
[avgduration-rssi <(0 to 255 StepSize 1)> ]	The default RSSI average duration for triggers, in milliseconds	Optional	50	0 - 255
[avgduration-cinr <(0 to 255 StepSize 1)> ]	The default CINR average duration for triggers, in milliseconds	Optional	50	0 - 255
[avgduration-rtd <(0 to 255 StepSize 1)> ]	The default RTD average duration for triggers, in milliseconds	Optional	50	0 - 255

**Command Modes** bs configuration mode

### 4.8.10.2 Restoring the Default Values of Trigger Setup Parameters

To restore one or all of the Trigger Setup parameters to their default values, run the following command:

```
npu(config-bs-66053)# no triggersetup [hysteresismargin] [timetotrigger]
[avgduration-rssi] [avgduration-cinr] [avgduration-rtd]
```

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the hysteresismargin parameter to the default value, run the following command:

```
npu(config-bs-66053)# no triggersetup hysteresismargin
```

This parameter will be restored to its default value, while the other parameters will remain unchanged.

To restore all Trigger Setup parameters to their default value, run the following command:

```
npu(config-bs-66053)# no triggersetup
```



#### NOTE

Refer to [Section 4.8.10.1](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<b>npu(config-bs-66053)# no triggersetup</b> [hysteresismargin ] [timetotrigger ] [avgduration-rssi] [avgduration-cinr] [avgduration-rtd ]
-----------------------	--

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs configuration mode
----------------------	-----------------------

### 4.8.10.3 Displaying Configuration Information for Trigger Setup Parameters

To display configuration information for Trigger Setup parameters, run the following command:

```
npu# show triggersetup bs [<(1 to 16777215 StepSize 1)
```



Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Trigger Setup parameters of BS 66053, run the following command:

**npu# show triggersetup bs 66053**

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show triggersetup bs**

**Command Syntax**      **npu# show triggersetup bs** [<(1 to 16777215 StepSize 1)>]

**Privilege Level**      1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display Trigger Setup parameters of a specific BS. Do not specify a value for this parameter if you want to display Trigger Setup parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

```

BSIDLSB                               : <value>
HysteresisMargin(dB)                   : <value>
(for each existing BS
if requested for all BSs)
TimetoTrigger(msec)                    : <value>
AverageDurationofDefaultRSSI(msec)     : <value>
AverageDurationofDefaultCINR(msec)     : <value>
AverageDurationofDefaultRTD(msec)     : <value>
    
```

**Command Modes**      Global command mode

## 4.8.11 Managing Scan Negotiation Parameters

After enabling the BS configuration mode, you can execute the following tasks:

- Configure one or more of the Scan Negotiation parameters (refer to [Section 4.8.11.1](#)).
- Restore the default values of some or all of the Scan Negotiation parameters (refer to [Section 4.8.11.2](#)).

You can display configuration information for the Scan Negotiation parameters of a selected or all existing BSs (refer to [Section 4.8.11.3](#)).

### 4.8.11.1 Configuring Scan Negotiation Parameters



**To configure the Scan Negotiation Parameters:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# scanning [max-attempts <(0 to 255 StepSize 1)>] [interval <(0 to 100 StepSize 0.1)>] [enable-autoaccept {TRUE | FALSE}] [enable-modify {TRUE | FALSE}] [min-interval <(2 to 255 StepSize 1)>] [max-duration <(0 to 255 StepSize 1)>] [min-degradationfactor <(0 to 1 StepSize 0.1)>] [honegotiation-sbs <(0 to 255 StepSize 1)>]
```



#### IMPORTANT

When creating a new BS, at least one of the Scan Negotiation parameters must be configured explicitly (even if configured to the default value).

<b>Command Syntax</b>	<pre><b>npu(config-bs-66053)# scanning</b> [max-attempts &lt;(0 to 255 StepSize 1)&gt; ] [interval &lt;(0 to 100 StepSize 0.1)&gt; ] [enable-autoaccept {TRUE   FALSE} ] [enable-modify {TRUE   FALSE} ] [min-interval &lt;(2 to 255 StepSize 1)&gt; ] [max-duration &lt;(0 to 255 StepSize 1)&gt; ] [min-degradationfactor &lt;(0 to 1 StepSize 0.1)&gt; ] [honegotiation-sbs &lt;(0 to 255 StepSize 1)&gt; ]</pre>
-----------------------	--

<b>Privilege Level</b>	10
------------------------	----

**Syntax  
Description**

Parameter	Description	Presence	Default Value	Possible Values
[max-attempts <(0 to 255 StepSize 1)> ]	The maximum allowed number of consecutive MOB_SCN-REQs .	Optional	10	0 - 255
[interval <(0 to 100 StepSize 0.1)> ]	The measuring interval for counting MOB_SCN-REQs abuse.	Optional	1	0 to 100 secs in steps of 0.1
[enable-autoaccept {TRUE   FALSE} ]	Determine whether all scan profiles requested by MSs will be accepted automatically.  <b>Note:</b> If TRUE all scan request will be automatically accepted.	Optional	TRUE	<input checked="" type="checkbox"/> TRUE <input checked="" type="checkbox"/> FALSE
[enable-modify {TRUE   FALSE} ]	Determines whether the BS will modify unfeasible scan profiles requested by MSs.  <b>Note:</b> If TRUE the BS will modify unfeasible scan profile requests and if FALSE the BS will deny the requests.	Optional	TRUE	<input checked="" type="checkbox"/> TRUE <input checked="" type="checkbox"/> FALSE
[min-interval <(2 to 255 StepSize 1)> ]	The minimum interleaving interval permitted to the MS in the scan profile (in frames)	Optional	2	0 - 255
[max-duration <(0 to 255 StepSize 1)> ]	The maximum duration of a scan permitted to the MS in the scan profile (in frames).	Optional	255	0 - 255
[min-degradationfactor <(0 to 1 StepSize 0.1)> ]	The minimum bandwidth degradation factor allowed in the scan profile	Optional	0	0 to 1 in steps of 0.1
[honegotiation-sbs <(0 to 255 StepSize 1)> ]	The minimum value (in frames) for the start frame in the scan profile.	Optional	0	0 - 255

**Command Modes** bs configuration mode

### 4.8.11.2 Restoring the Default Values of Scan Negotiation Parameters

To restore some or all of the Scan Negotiation parameters to their default values, run the following command:

```
npu(config-bs-66053)# no scanning [max-attempts] [interval]
[enable-autoaccept] [enable-modify][min-interval] [max-duration]
[min-degradationfactor] [honegotiation-sbs]
```

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the max-attempts parameter to the default value, run the following command:

```
npu(config-bs-66053)# no scanning max-attempts
```

This parameter will be restored to its default value, while the other parameters will remain unchanged.

To restore all Scan Negotiation parameters to their default value, run the following command:

```
npu(config-bs-66053)# no scanning
```



#### NOTE

Refer to [Section 4.8.11.1](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<pre><b>npu(config-bs-66053)# no scanning</b> [max-attempts ] [interval ] [enable-autoaccept ] [enable-modify ] [min-interval ] [max-duration ] [min-degradationfactor ] [honegotiation-sbs ]</pre>
-----------------------	---

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs configuration mode
----------------------	-----------------------

### 4.8.11.3 Displaying Configuration Information for Scan Negotiation Parameters

To display configuration information for Scan Negotiation parameters, run the following command:

```
npu# show scanning bs [<(1 to 16777215 StepSize 1)
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Scan Negotiation parameters of BS 66053, run the following command:

**npu# show scanning bs 66053**

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show scanning bs**

**Command Syntax**     **npu# show scanning bs** [<(1 to 16777215 StepSize 1)>]

**Privilege Level**     1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display Scan Negotiation parameters of a specific BS. Do not specify a value for this parameter if you want to display Scan Negotiation parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

```

BSIDLSB                               : <value>
MaximumAttempts                        : <value>
(for each existing BS
if requested for all BSs)
MeasuringInterval(sec)                 : <value>
EnableAutoAcceptProfile                 : <value>
EnableModifyProfile                     : <value>
MinimumInterleavingInterval(frames)    : <value>
MaximumScanDuration(frames)            : <value>
MinimumBandwidthDegradationFactor      : <value>
MinimumStartFrame(frames)              : <value>

```

**Command** Global command mode  
**Modes**

## 4.8.12 Managing Handover Negotiation at SBS Parameters

After enabling the BS configuration mode, you can execute the following tasks:

- Configure one or more of the Handover Negotiation at SBS parameters (refer to [Section 4.8.12.1](#)).
- Restore the default values of some or all of the Handover Negotiation at SBS parameters (refer to [Section 4.8.12.2](#)).

You can display configuration information for the Handover Negotiation at SBS parameters of a selected or all existing BSs (refer to [Section 4.8.12.3](#)).

### 4.8.12.1 Configuring Handover Negotiation at SBS Parameters



**To configure the Handover Negotiation at SBS Parameters:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# honegotiation-sbs [selectcoefficient <(0 to 10 StepSize 0.1)> ] [max-tbs <(0 to 255 StepSize 1)>] [min-actiontime <(0 to 255 StepSize 1)>] [max-actiontime <(0 to 255 StepSize 1)>]
```



#### IMPORTANT

When creating a new BS, at least one of the Handover Negotiation at SBS parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** `npu(config-bs-66053)# honegotiation-sbs` [selectcoefficient <(0 to 10 StepSize 0.1)> ] [max-tbs <(0 to 255 StepSize 1)> ] [min-actiontime <(0 to 255 StepSize 1)> ] [max-actiontime <(0 to 255 StepSize 1)> ]

**Privilege Level** 10

---

**Syntax  
Description**

Parameter	Description	Presence	Default Value	Possible Values
[selectcoefficient <(0 to 10 StepSize 0.1)> ]	The coefficient for selection of Target BSs for MOB_BSHO-RSP	Optional	0.3	0 to 10 in steps of 0.1
[max-tbs <(0 to 255 StepSize 1)> ]	The maximum number of Target BSs to which to send HO-REQ message through the backbone.	Optional	255	0 - 255
[min-actiontime <(0 to 255 StepSize 1)> ]	The minimum acceptable action time in the Serving BS (in frames)	Optional	1	0 - 255
[max-actiontime <(0 to 255 StepSize 1)> ]	The maximum acceptable action time in the Serving BS (in frames)	Optional	255	0 - 255

---

**Command Modes**    bs configuration mode

### 4.8.12.2 Restoring the Default Values of Handover Negotiation at SBS Parameters

To restore some or all of the Handover Negotiation at SBS parameters to their default values, run the following command:

```
npu(config-bs-66053)# no honegotiation-sbs [selectcoefficient] [max-tbs]
[min-actiontime] [max-actiontime]
```

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the max-tbs parameter to the default value, run the following command:

```
npu(config-bs-66053)# no honegotiation-sbs max-tbs
```

This parameter will be restored to its default value, while the other parameters will remain unchanged.

To restore all Handover Negotiation at SBS parameters to their default value, run the following command:

```
npu(config-bs-66053)# no honegotiation-sbs
```

**NOTE**

Refer to [Section 4.8.12.1](#) for a description and default values of these parameters.

---

**Command Syntax**     **npu(config-bs-66053)# no honegotiation-sbs** [selectcoefficient ]  
 [max-tbs ] [min-actiontime ] [max-actiontime ]

---

**Privilege Level**     10

---

**Command Modes**     bs configuration mode

### 4.8.12.3 Displaying Configuration Information for Handover Negotiation at SBS Parameters

To display configuration information for Handover Negotiation at SBS parameters, run the following command:

**npu# show honegotiation-sbs bs** [<(1 to 16777215 StepSize 1)

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Handover Negotiation at SBS parameters of BS 66053, run the following command:

**npu# show honegotiation-sbs bs 66053**

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show honegotiation-sbs bs**

---

**Command Syntax**     **npu# show honegotiation-sbs bs** [<(1 to 16777215 StepSize 1)

---

**Privilege Level**     1



**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display Handover Negotiation at SBS parameters of a specific BS. Do not specify a value for this parameter if you want to display Handover Negotiation at SBS parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

BSIDLSB

:&lt;value&gt;

(for each existing BS if requested for all BSs)

**Command Modes**

Global command mode

## 4.8.13 Managing Handover Negotiation at TBS Parameters

After enabling the BS configuration mode, you can execute the following tasks:

- Configure one or more of the Handover Negotiation at TBS parameters (refer to [Section 4.8.13.1](#)).
- Restore the default values of some or all of the Handover Negotiation at TBS parameters (refer to [Section 4.8.13.2](#)).

You can display configuration information for the Handover Negotiation at TBS parameters of a selected or all existing BSs (refer to [Section 4.8.13.3](#)).

### 4.8.13.1 Configuring Handover Negotiation at TBS Parameters



To configure the Handover Negotiation at TBS Parameters:

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# honegotiation-tbs [defaultactiontime <(0 to 255 StepSize 1)>] [fastrangingalloc <(0 to 255 StepSize 1)>]
```



#### IMPORTANT

When creating a new BS, at least one of the Handover Negotiation at TBS parameters must be configured explicitly (even if configured to the default value).

---

**Command Syntax**    **npu(config-bs-66053)# honegotiation-tbs** [defaultactiontime <(0 to 255 StepSize 1)> ] [fastrangingalloc <(0 to 255 StepSize 1)> ]

---

**Privilege Level**    10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
defaultactiontime <(0 to 255 StepSize 1)>	The number of frames until allocation of non-contention based ranging opportunity at target BS.	Optional	3	0 - 255
fastrangingalloc <(0 to 255 StepSize 1)>	The number of consecutive fast ranging opportunities the target BS will allocate to an incoming HO MS.	Optional	2	0 - 255

---

**Command Modes**    bs configuration mode

### 4.8.13.2 Restoring the Default Values of Handover Negotiation at TBS Parameters

To restore some or all of the Handover Negotiation at TBS parameters to their default values, run the following command:

```
npu(config-bs-66053)# no honegotiation-tbs [defaultactiontime]
[fastrangingalloc]
```

You can restore only one parameter to the default values by specifying only that parameters. For example, to restore only the fastrangingalloc parameter to the default value, run the following command:

```
npu(config-bs-66053)# no honegotiation-tbs fastrangingalloc
```

This parameter will be restored to its default value, while the other parameter will remain unchanged.

To restore all Handover Negotiation at TBS parameters to their default value, run the following command:

```
npu(config-bs-66053)# no honegotiation-tbs
```



#### NOTE

Refer to [Section 4.8.13.1](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<b>npu(config-bs-66053)# no honegotiation-stbs</b> [defaultactiontime ] [fastrangingalloc ]
-----------------------	--

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs configuration mode
----------------------	-----------------------

### 4.8.13.3 Displaying Configuration Information for Handover Negotiation at TBS Parameters

To display configuration information for Handover Negotiation at TBS parameters, run the following command:

```
npu# show honegotiation-tbs bs [(1 to 16777215 StepSize 1)]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Handover Negotiation at TBS parameters of BS 66053, run the following command:

**npu# show honegotiation-tbs bs 66053**

Do not specify this parameter if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show honegotiation-tbs bs**

**Command Syntax**     **npu# show honegotiation-tbs bs** [<(1 to 16777215 StepSize 1)>]

**Privilege Level**     1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display Handover Negotiation at TBS parameters of a specific BS. Do not specify a value for this parameter if you want to display Handover Negotiation at TBS parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

BSIDLSB	:<value>
DefaultActionTime(frames)	:<value>
(for each existing BS if requested for all BSs)	FastRangingallocations :<value>

**Command Modes**     Global command mode

## 4.8.14 Managing Neighbor BSs



### To configure a Neighbor BS:

- 1 Enable the Neighbour BS configuration mode for the selected Neighbour BS (refer to [Section 4.8.14.1](#))
- 2 You can now execute any of the following tasks:
  - » Configure one or more of the parameters tables of the Neighbor BS (refer to [Section 4.8.14.2](#))
  - » Restore the default values of parameters in one or more of the parameters tables of the Neighbor BS (refer to [Section 4.8.14.3](#))
  - » Terminate the Neighbor BS configuration mode (refer to [Section 4.8.14.4](#))

In addition, you can, at any time, display configuration information for each of the parameters tables of the Neighbour BS (refer to [Section 4.8.14.6](#)) or delete an existing Neighbor BS (refer to [Section 4.8.14.5](#)).

### 4.8.14.1 Enabling the Neighbor BS Configuration Mode\Creating a Neighbor BS

To configure the parameters of a Neighbour BS, first enable the Neighbour BS configuration mode for the specific Neighbour BS. Run the following command to enable the Neighbour BS configuration mode. You can also use this command to create a new Neighbour BS.

```
npu(config-bs-66053)# nbr <(1 to 16777215 StepSize 1)>
```

Note that for a new Neighbour BS this command only defines the Neighbour BS ID, and that the Neighbour BS is not fully created until completing configuration of all mandatory parameters and executing the **apply** command (must be executed before exiting the Neighbour BS configuration mode). Also when updating an existing Neighbour BS, the **apply** command must be executing prior to termination the Neighbour BS configuration mode.

For example, to define a new Neighbour BS with a BS ID 66055, or to enable the configuration mode for Neighbour BS 66055, run the following command:

```
npu(config-bs-66053)# nbr 66055
```

If you use this command to create a new Neighbour BS, the configuration mode for this Neighbour BS is automatically enabled, after which you can execute any of the following tasks:

- Configure one or more of the parameters tables of the Neighbour BS (refer to [Section 4.8.14.2](#))
- Restore the default values of parameters in one or more of the parameters tables of the Neighbour BS (refer to [Section 4.8.14.3](#))

After executing the above tasks, you can terminate the Neighbour BS configuration mode (refer to [Section 4.8.14.4](#)) and return to the BS configuration mode.

Note that for properly completing the configuration of a Neighbour BS the **apply** command must be executed prior to exiting the Neighbour BS configuration mode.

---

**Command Syntax**    `npu(config-bs-66053)# nbr <(1 to 16777215 StepSize 1)>`

---

**Privilege Level**    10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<code>nbr &lt;(1 to 16777215 StepSize 1)&gt;</code>	The BS ID (BSIDLSB) of the Neighbour BS	Mandatory		1 - 16777215

---

**Command Modes**    bs configuration mode

For example, to define Neighbor BS 66055 for bs-68000, run the following command:

```
npu(config-bs-66053)# nbr 68000
```



#### NOTE

The following examples are for Neighbour BS configuration mode for bs-66053, neighbour bs (nbr) 68000.

### 4.8.14.2 Configuring Neighbor BS Parameters

After enabling the Neighbor BS configuration mode you can configure the following parameters tables:

- General (refer to [Section 4.8.14.2.1](#))
- Required C/N Level (refer to [Section 4.8.14.2.2](#))
- Trigger Setup (refer to [Section 4.8.14.2.3](#))
- Triggers (refer to [Section 4.8.14.2.4](#))



#### IMPORTANT

After completing the Neighbour BS configuration, do not forget to execute the apply command before exiting the Neighbour BS configuration mode:

```
npu(config-bs-66053-nbr-68000)# apply
```

#### 4.8.14.2.1 Configuring General Neighbor BS Parameters

The General Neighbor BS Parameters table enables defining the general parameters of the Neighbor BS.

To configure the General Neighbor BS parameters, run the following command:

```
npu(config-bs-66053-nbr-68000)# general [syncind {unsynchronized |
timeSynchronized | timeAndFrequencySynchronized}] [eirp <(-128 to 127
StepSize 1)>] [srvcsupport <hex-string>] [bw {fiveMHz | tenMHz | sevenMHz}]
[feedbackzone-permbase <(0 to 69 StepSize 1)>] [ucd-configchangecount <(0 to
255 StepSize 1)>] [dcd-configchangecount <(0 to 255 StepSize 1)>] [eirx-pir-max
<(-140 to -40 StepSize 1)>] [frequency <(2302.5 to 2357.5 StepSize 0.125) |
(2498.5 to 2687.5 StepSize 0.125) | (3402.5 to 3597.5 StepSize 0.125) | (3602.5
to 3797.5 StepSize 0.125)>] [restartcount <(0 to 255 StepSize 1)>] [preamble-idx
<(0 to 113 StepSize 1)>]
```



#### IMPORTANT

When creating a new Neighbour BS, all mandatory Neighbour BS General parameters must be configured.

**Command** `npn(config-bs-66053-nbr-68000)# general [syncind {unsynchronized | timeSynchronized | timeAndFrequencySynchronized} ] [eirp <(-128 to 127 StepSize 1)> ] [srvcsupport <hex-string>] [bw {fiveMHz | tenMHz | sevenMHz} ] [feedbackzone-permbase <(0 to 69 StepSize 1)> ] [ucd-configchangeount <(0 to 255 StepSize 1)>] [dcd-configchangeount <(0 to 255 StepSize 1)> ] [eirx-pir-max <(-140 to -40 StepSize 1)> ] [frequency <(2302.5 to 2357.5 StepSize 0.125) | (2498.5 to 2687.5 StepSize 0.125) | (3402.5 to 3597.5 StepSize 0.125) | (3602.5 to 3797.5 StepSize 0.125)> ] [restartcount <(0 to 255 StepSize 1)>] [preamble-idx <(0 to 113 StepSize 1)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[syncind {unsynchronized   timeSynchronized   timeAndFrequencySynchronized} ]	Time/Frequency synchronization indicator.  In the current release should always be set to timeAndFrequencySynchronized.	Optional	timeAndFrequencySynchronized	<ul style="list-style-type: none"> <li><input checked="" type="checkbox"/> unsynchronized</li> <li><input checked="" type="checkbox"/> timeSynchronized</li> <li><input checked="" type="checkbox"/> timeAndFrequencySynchronized</li> </ul>
[eirp <(-128 to 127 StepSize 1)> ]	Neighbour BS EIRP	Mandatory When creating a new Neighbour BS.	N/A	-128 to 127



[srvcsupport <hex-string>]	<p>Scheduling Service Support. Two hexadecimal digits that can be presented as 8 bits where tbits 5-7 are always 0. Bits 0-4 indicate whether specific services are supported, where a value of 1 means that the service is supported: UGS (0), RT-PS(1), NRT-PS(2), BE(3), ERT-PS(4).</p> <p>Should be taken from the displayed information for Handover Control (hoctrl) in the relevant BS (see <a href="#">Section 4.8.23.3</a>).</p>	Optional	c8  (11001000, meaning that the BS supports UGS, RT-PS and ERT-PS scheduling services).	Two hexadecimal digits.
[bw {fiveMHz   tenMHz   sevenMHz} ]	<p>The bandwidth of neighbour BS.</p> <p>Should be taken from Baseband bandwidth parameter of the relevant BS (see <a href="#">Section 4.8.18.2</a>)</p>	Mandatory When creating a new Neighbour BS.	N/A	<ul style="list-style-type: none"> <li>■ fiveMHz</li> <li>■ tenMHz</li> <li>■ sevenMHz</li> </ul>
[feedbackzone-permbase <(0 to 69 StepSize 1)> ]	<p>The first uplink zone permutation base of the neighbor BS.</p> <p>In current release this equals the feedback zone permutation base (see <a href="#">Section 4.8.19.5.8</a>)</p>	Mandatory When creating a new Neighbour BS.	N/A	0 - 69
[ucd-configchange count <(0 to 255 StepSize 1)>]	<p>UCD configuration change count of neighbor BS</p> <p>Should be taken from displayed UCD information for the relevant BS (see <a href="#">Section 4.8.15.3</a>)</p>	Mandatory When creating a new Neighbour BS.	N/A	0 - 255

[dcd-configchange count <(0 to 255 StepSize 1)> ]	DCD configuration change count of neighbor BS  Should be taken from displayed DCD information for the relevant BS (see <a href="#">Section 4.8.16.3</a> )	Mandatory When creating a new Neighbour BS.	N/A	0 - 255
eirx-pir-max <(-140 to -40 StepSize 1)>	The required effective isotropic received power at the Neighbor BS for Initial ranging, in dBm.  Should be taken from Power Control maxeirxp (see <a href="#">Section 4.8.6.2.2</a> )	Optional	-124	-140 to -40
[frequency <(2302.5 to 2357.5 StepSize 0.125)   (2498.5 to 2687.5 StepSize 0.125)   (3402.5 to 3597.5 StepSize 0.125)   (3602.5 to 3797.5 StepSize 0.125)> ]	Downlink center frequency of neighbor BS.  Should be taken from RF frequency parameter of the relevant BS (see <a href="#">Section 4.8.17.2</a> )	Mandatory When creating a new Neighbour BS.	N/A	<ul style="list-style-type: none"> <li>■ 2302.5 to 2357.5 in steps of 0.125)</li> <li>■ 2498.5 to 2687.5 in steps of 0.125</li> <li>■ 3402.5 to 3597.5 in steps of 0.125</li> <li>■ 3602.5 to 3797.5 in steps of 0.125</li> </ul>
restartcount <(0 to 255 StepSize 1)> ]	This value is incremented by one whenever the neighbor BS restarts.  Should be taken from displayed DCD information for the relevant BS (see <a href="#">Section 4.8.16.3</a> )	Mandatory When creating a new Neighbour BS.	N/A	0 - 255

[preamble-idx <(0 to 113 StepSize 1)> ]	Neighbour BS Preamble Index.  Should be the same as preamble-idx in displayed information of Airframe General parameters of the relevant BS (see <a href="#">Section 4.8.19.5.1</a> )	Mandatory When creating a new Neighbour BS.	N/A	0 - 113
---	---	---	-----	---------

**Command**    bs neighbour bs configuration mode  
**Modes**

#### 4.8.14.2.2 Configuring the Neighbor BS Required C/N Level Parameters

The Neighbor BS Required C/N Levels table enables defining the Carrier to Noise Ratios required for various types of transmissions.

The configured values should be the same as those defined for the applicable Power Control Required C/N Level parameters (see [Section 4.8.6.5.3](#)) in the neighbor BS.

To configure the Neighbor BS Required C/N Levels, run the following command:

```
npu(config-bs-66053-nbr-68000)# requiredcnr [ack <(-20 to 50 StepSize 1)>]
[cqi <(-20 to 50 StepSize 1)>] [cdma <(-20 to 50 StepSize 1)>] [qpsk-1by2 <(-20 to 50 StepSize 1)>]
[qpsk-3by4 <(-20 to 50 StepSize 1)>] [qam16-1by2 <(-20 to 50 StepSize 1)>]
[qam16-3by4 <(-20 to 50 StepSize 1)>] [qam64-1by2 <(-20 to 50 StepSize 1)>]
[qam64-2by3 <(-20 to 50 StepSize 1)>] [qam64-3by4 <(-20 to 50 StepSize 1)>]
[qam64-5by6 <(-20 to 50 StepSize 1)>]
```



#### IMPORTANT

When creating a new Neighbour BS, at least one of the Neighbour BS Required C/N Level parameters must be configured explicitly (even if configured to the default value).

**Command Syntax**    **npu(config-bs-66053-nbr-68000)# requiredcnr** [ack <(-20 to 50 StepSize 1)> ] [cqi <(-20 to 50 StepSize 1)> ] [cdma <(-20 to 50 StepSize 1)> ] [qpsk-1by2 <(-20 to 50 StepSize 1)> ] [qpsk-3by4 <(-20 to 50 StepSize 1)> ] [qam16-1by2 <(-20 to 50 StepSize 1)> ] [qam16-3by4 <(-20 to 50 StepSize 1)> ] [qam64-1by2 <(-20 to 50 StepSize 1)> ] [qam64-2by3 <(-20 to 50 StepSize 1)> ] [qam64-3by4 <(-20 to 50 StepSize 1)> ] [qam64-5by6 <(-20 to 50 StepSize 1)> ]

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[ack <(-20 to 50 StepSize 1)> ]	The C/N in dB required for sending ACK, reported by the Neighbour BS to the MS for power control purposes.	Optional	7	-20 to 50
[cqi <(-20 to 50 StepSize 1)> ]	The C/N in dB required for sending CQI, reported by the Neighbour BS to the MS for power control purposes.	Optional	0	-20 to 50
[cdma <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting CDMA, reported by the Neighbour BS to the MS for power control purposes.	Optional	0	-20 to 50
[qpsk-1by2 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using QPSK 1/2, reported by the Neighbour BS to the MS for power control purposes.	Optional	14	-20 to 50
[qpsk-3by4 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using QPSK 3/4, reported by the Neighbour BS to the MS for power control purposes.	Optional	16	-20 to 50
[qam16-1by2 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 16QAM 1/2, reported by the Neighbour BS to the MS for power control purposes.	Optional	18	-20 to 50
[qam16-3by4 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 16QAM 3/4, reported by the Neighbour BS to the MS for power control purposes.	Optional	22	-20 to 50

qam64-1by2 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 64QAM 1/2, reported by the Neighbour BS to the MS for power control purposes.	Optional	23	-20 to 50
[qam64-2by3 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 64QAM 2/3, reported by the Neighbour BS to the MS for power control purposes.	Optional	23	-20 to 50
[qam64-3by4 <(-20 to 50 StepSize 1)> ]	The C/N in dB required for transmitting using 64QAM 3/4, reported by the Neighbour BS to the MS for power control purposes.	Optional	23	-20 to 50
[qam64-5by6 <(-20 to 50 StepSize 1)> ]	he C/N in dB required for transmitting using 64QAM 5/6, reported by the Neighbour BS to the MS for power control purposes.	Optional	23	-20 to 50

**Command**    bs neighbour bs configuration mode  
**Modes**

#### 4.8.14.2.3 Configuring Trigger Setup Parameters

To configure the Neighbor BS Trigger Setup parameters, run the following command:

```
npu(config-bs-66053-nbr-68000)# triggersetup [hysteresismargin <(0 to 255 StepSize 1)>] [timetotriggger <(0 to 255 StepSize 1)>] [avgduration-rssi <(0 to 255 StepSize 1)>] [avgduration-cinr <(0 to 255 StepSize 1)>] [avgduration-rtd <(0 to 255 StepSize 1)>]
```

The configured values should be the same as those defined for the applicable Trigger Setup parameters (see [Section 4.8.10.3](#)) in the neighbor BS.



#### IMPORTANT

When creating a new Neighbour BS, at least one of the Neighbour BS Trigger Setup parameters must be configured explicitly (even if configured to the default value).

---

**Command**    `npu(config-bs-66053-nbr-68000)# triggersetup [hysteresismargin <(0 to 255 StepSize 1)> ] [timetotrigger <(0 to 255 StepSize 1)> ] [avgduration-rssi <(0 to 255 StepSize 1)> ] [avgduration-cinr <(0 to 255 StepSize 1)> ] [avgduration-rtd <(0 to 255 StepSize 1)> ]`

---

**Privilege Level**    10

---

**Syntax Description**    Refer to [Section 4.8.10.1](#)

---

**Command Modes**    bs neighbour bs configuration mode

#### 4.8.14.2.4 Configuring Neighbor BS Triggers Parameters

To configure the Neighbor BS Triggers parameters, run the following command:

**`npu(config-bs-66053-nbr-68000)# triggers-<trigger-name> <trigger-range>`**

Each Trigger is configured separately. This is the general structure of the command.

The configured trigger names and values should be the same as those defined for the applicable Triggers parameters (see [Section 4.8.9.2](#)) in the neighbor BS.



#### IMPORTANT

When creating a new Neighbour BS, at least one of the Neighbour BS Triggers parameters must be configured.

---

**Command Syntax**    `npu(config-bs-66053-nbr-68000)# triggers-<trigger-name> <trigger-range>`

---

**Privilege Level**    10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values

<trigger-name>	The Trigger name.	Mandatory	N/A	See <a href="#">Table 4-30</a>
<trigger-value>	Defines the threshold value for the Trigger.	Mandatory	N/A	See <a href="#">Table 4-30</a>

**Command Modes** bs neighbour bs configuration mode

### 4.8.14.3 Restoring Default Values for Neighbor BS Configuration Parameters

After enabling the Neighbor BS configuration mode you can restore the default values for non-mandatory parameters in the following parameters tables:

- General (refer to [Section 4.8.14.3.1](#))
- Required C/N Level (refer to [Section 4.8.14.3.2](#))
- Trigger Setup (refer to [Section 4.8.14.3.3](#))

#### 4.8.14.3.1 Restoring the Default Values of Neighbor BS General Parameters

To restore one or all of the Neighbor BS non-mandatory General parameters to their default values, run the following command:

```
npu(config-bs-66053-nbr-68000)# no general [syncind] [srvcsupport] [eirx-pir-max]
```

You can restore only some parameters to the default values by specifying only those parameters. For example, to restore only the syncind to the default value, run the following command:

```
npu(config-bs-66053-nbr-68000)# no general syncind
```

The parameter will be restored to its default value, while the other parameters will remain unchanged.

To restore all non-mandatory parameters to their default value, run the following command:

```
npu(config-bs-66053-nbr-68000)# no general
```

**NOTE**

Refer to [Section 4.8.14.2.1](#) for a description and default values of these parameters.

**Command Syntax** `npu(config-bs-66053-nbr-68000)# no general [syncind ] [srvcsupport][eirx-pir-max ]`

**Privilege Level** 10

**Command Modes** bs neighbour bs configuration mode

### 4.8.14.3.2 Restoring the Default Values of Neighbor BS Required C/N Level Parameters

To restore some or all of the Neighbor BS Required C/N Levels parameters to their default values, run the following command:

```
npu(config-bs-66053-bs-68000)# no requiredcnr [ack] [cqi] [cdma] [qpsk-1by2]
[qpsk-3by4] [qam16-1by2] [qam16-3by4] [qam64-1by2] [qam64-2by3]
[qam64-3by4] [qam64-5by6]
```

You can restore only some parameters to their default values by specifying only those parameter. For example, to restore only the ack and cqi parameters to the default values, run the following command:

```
npu(config-bs-66053-nbr-68000)# no requiredcnr ack cqi
```

These parameters will be restored to their default value, while the other parameters will remain unchanged.

To restore all Neighbor BS Required C/N Levels parameters to their default value, run the following command:

```
npu(config-bs-66053-nbr-68000)# no requiredcnr
```

**NOTE**

Refer to [Section 4.8.14.2.2](#) for a description and default values of these parameters.

**Command Syntax** `npu(config-bs-66053-nbr-68000)# no requiredcnr [ack ] [cqi ] [cdma ] [qpsk-1by2 ] [qpsk-3by4 ] [qam16-1by2 ] [qam16-3by4 ] [qam64-1by2 ] [qam64-2by3 ] [qam64-3by4 ] [qam64-5by6 ]`



---

**Privilege Level** 10

---

**Command Modes** bs neighbour bs configuration mode

#### 4.8.14.3.3 Restoring the Default Values of Neighbor BS Trigger Setup Parameters

To restore some or all of the Neighbor BS Trigger Setup parameters to their default values, run the following command:

```
npu(config-bs-66053-nbr-68000)# no triggersetup [hysteresismargin]
[timetotrigger] [avgduration-rssi] [avgduration-cinr] [avgduration-rtd]
```

You can restore only some parameters to their default values by specifying only those parameters. For example, to restore only the hysteresismargin parameter to the default value, run the following command:

```
npu(config-bs-66053-nbr-68000)# no triggersetup hysteresismargin
```

This parameter will be restored to its default value, while the other parameters will remain unchanged.

To restore all Neighbor BS Trigger Setup parameters to their default value, run the following command:

```
npu(config-bs-66053-nbr-68000)# no triggersetup
```



#### NOTE

Refer to [Section 4.8.14.2.3](#) for a description and default values of these parameters.

---

**Command Syntax** **npu(config-bs-66053-nbr-68000)# no triggersetup** [hysteresismargin ]  
[timetotrigger ] [avgduration-rssi] [avgduration-cinr]  
[avgduration-rtd ]

---

**Privilege Level** 10

---

**Command Modes** bs neighbour bs configuration mode

### 4.8.14.4 Terminating the Neighbor BS Configuration Mode

Run the following command to terminate the Neighbor BS configuration mode:

```
npu(config-bs-66053-nbr-68000)# exit
```



#### IMPORTANT

Do not forget to execute the apply command before terminating the Neighbour BS configuration mode: **npu(config-bs-66053-nbr-68000)# apply**

---

**Command Syntax**      **npu(config-bs-66053-nbr-68000)# exit**

---

**Privilege Level**      10

---

**Command Modes**      bs neighbour bs configuration mode

### 4.8.14.5 Deleting a Neighbor BS

Run the following command from the BS configuration mode to delete a Neighbor BS:

```
npu(config-bs 66053)# no nbr <(1 to 16777215 StepSize 1)>
```

---

**Command Syntax**      **npu(config-bs 66053)# no nbr <(1 to 16777215 StepSize 1)>**

---

**Privilege Level**      10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The Neighbour BS ID (bs-id-lsb)	Mandatory	N/A	1-16777215

---

**Command**    bs configuration mode  
**Modes**

### 4.8.14.6 Displaying Configuration Information for Neighbor BS Parameters

You can display the current configuration information for the following Neighbor BS parameters tables:

- General (refer to [Section 4.8.14.6.1](#))
- Required C/N Level (refer to [Section 4.8.14.6.2](#))
- Trigger Setup (refer to [Section 4.8.14.6.3](#))
- Triggers (refer to [Section 4.8.14.6.4](#))
- All (refer to [Section 4.8.14.6.5](#))

#### 4.8.14.6.1 Displaying Configuration Information for Neighbor BS General Parameters

To display configuration for the Neighbor BS General parameters, run the following command:

```
npu# show nbr-general bs [<(1 to 16777215 StepSize 1)> bs-id-lsb <(1 to 16777215 StepSize 1)>]
```

Specify the BS ID and the Neighbor BS ID (bs-id-lsb) if you want to display configuration for a particular Neighbor BS in a particular BS. For example, to display the General parameters of Neighbor BS 68000 in BS 66503, run the following command:

```
npu# show nbr-general bs 66503 bs-id-lsb 68000
```

Do not specify these parameters if you want to view configuration information for all existing Neighbor BSs in all existing BSs. To display information for all Neighbor BSs in all BSs, run the following command:

```
npu# show nbr-general bs
```

---

**Command Syntax**    **npu# show nbr-general bs** [<(1 to 16777215 StepSize 1)> bs-id-lsb <(1 to 16777215 StepSize 1)> ]

**Privilege Level** 1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the General parameters of a specific Neighbour BS in a specific BS. Do not specify a value for this parameter if you want to display the General parameters of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215
bs-id-lsb <(1 to 16777215 StepSize 1)>	The Neighbour BS ID.  Specify a value for this parameter if you want to display the General parameters of a specific Neighbour BS in a specific BS. Do not specify a value for this parameter if you want to display the General parameters of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215

<b>Display</b>	BSIDLSB	: <value>
<b>Format</b>	NeighborBSIDLSB	: <value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	SynchronizationIndicator	: <value>
	EIRP	: <value>
	SchedulingServiceSupport	: <value>
	Bandwidth(MHz)	: <value>
	UplinkFeedbackZonePermutationBase	: <value>
	UplinkDataZoneSub-ChannelsAllocated	: <value>
	UCDConfigurationChangeCount	: <value>
	DCDConfigurationChangeCount	: <value>
	IsotropicRecPwrForInitialRanging	: <value>
	CenterFrequency(MHz)	: <value>
	RestartCount	: <value>
	PreambleIndex	: <value>

<b>Command Modes</b>	Global command mode
----------------------	---------------------

#### 4.8.14.6.2 Displaying Configuration Information for Neighbor BS Required C/N Level Parameters

To display configuration for the Neighbor BS Required C/N Level parameters, run the following command:

```
npu# show nbr-requiredcnr bs [(1 to 16777215 StepSize 1)> bs-id-lsb [(1 to 16777215 StepSize 1)>]
```

Specify the BS ID and the Neighbor BS ID (bs-id-lsb) if you want to display configuration for a particular Neighbor BS in a particular BS. For example, to display the Required C/N Level parameters of Neighbor BS 68000 in BS 66503, run the following command:

```
npu# show nbr-requiredcnr bs 66053 bs-id-lsb 68000
```

Do not specify these parameters if you want to view configuration information for all existing Neighbor BSs in all existing BSs. To display information for all Neighbor BSs in all BSs, run the following command:

```
npu# show nbr-requiredcnr bs
```

**Command**    **npu# show nbr-requiredcnr bs** [(1 to 16777215 StepSize 1)> bs-id-lsb (1 to 16777215 StepSize 1)> ]

**Privilege Level**    1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Required C/N Level parameters of a specific Neighbour BS in a specific BS. Do not specify a value for this parameter if you want to display the Required C/N Level parameters of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215
bs-id-lsb <(1 to 16777215 StepSize 1)>	The Neighbour BS ID.  Specify a value for this parameter if you want to display the Required C/N Level parameters of a specific Neighbour BS in a specific BS. Do not specify a value for this parameter if you want to display the Required C/N Level parameters of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215

<b>Display</b>	BSIDLSB	: <value>
<b>Format</b>	NeighborBSIDLSB	: <value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	RequiredCNRforACK	: <value>
	RequiredCNRforCQI	: <value>
	RequiredCNRforCDMA	: <value>
	RequiredCNRforQPSK1/2	: <value>
	RequiredCNRforQPSK3/4	: <value>
	RequiredCNRfor16QAM1/2	: <value>
	RequiredCNRfor16QAM3/4	: <value>
	RequiredCNRfor64QAM1/2	: <value>
	RequiredCNRfor64QAM2/3	: <value>
	RequiredCNRfor64QAM3/4	: <value>
	RequiredCNRfor64QAM5/6	: <value>

<b>Command Modes</b>	Global command mode
----------------------	---------------------

#### 4.8.14.6.3 Displaying Configuration Information for Neighbor BS Trigger Setup Parameters

To display configuration for the Neighbor BS Trigger Setup parameters, run the following command:

```
npu# show nbr-triggersetup bs [<(1 to 16777215 StepSize 1)> bs-id-lsb <(1 to 16777215 StepSize 1)>]
```

Specify the BS ID and the Neighbor BS ID (bs-id-lsb) if you want to display configuration for a particular Neighbor BS in a particular BS. For example, to display the Trigger Setup parameters of Neighbor BS 68000 in BS 66503, run the following command:

```
npu# show nbr-triggersetup bs 66053 bs-id-lsb 68000
```

Do not specify these parameters if you want to view configuration information for all existing Neighbor BSs in all existing BSs. To display information for all Neighbor BSs in all BSs, run the following command:

```
npu# show nbr-triggersetup bs
```

**Command**    **npu# show nbr-triggersetup bs** [<(1 to 16777215 StepSize 1)> bs-id-lsb <(1 to 16777215 StepSize 1)> ]

**Privilege Level**    1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Trigger Setup parameters of a specific Neighbour BS in a specific BS. Do not specify a value for this parameter if you want to display the Trigger Setup parameters of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215
bs-id-lsb <(1 to 16777215 StepSize 1)>	The Neighbour BS ID.  Specify a value for this parameter if you want to display the Trigger Setup parameters of a specific Neighbour BS in a specific BS. Do not specify a value for this parameter if you want to display the Trigger Setup parameters of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215



<b>Display</b>	BSIDLsb	: <value>
<b>Format</b>	NeighborBSIDLsb	: <value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	HysteresisMargin(dB)	: <value>
	TimetoTrigger(msec)	: <value>
	AverageDurationofDefaultRSSI(msec)	: <value>
	AverageDurationofDefaultCINR(msec)	: <value>
	AverageDurationofDefaultRTD(msec)	: <value>
<b>Command Modes</b>	Global command mode	

#### 4.8.14.6.4 Displaying Configuration Information for Neighbor BS Triggers Parameters

To display configuration information for Neighbor BS Triggers parameters, run the following command:

```
npu# show nbr-triggers bs [<(1 to 16777215 StepSize 1)> bs-id-lsb <(1 to 16777215 StepSize 1)> TrigName {scnReqCinrMin | scnReqRssiMin | scnReqRtdMax | scnRepCinrMaxNbs | scnRepRssiMaxNbs | scnRepCinrMargin | scnRepRssiMargin | scnRepRtdMax | scnRepCinrMinSbs | scnRepRssiMinSbs | hoReqCinrMaxNbs | hoReqRssiMaxNbs | hoReqCinrMargin | hoReqRssiMargin | hoReqRtdMax | hoReqCinrMinSbs | hoReqRssiMinSbs}]
```

Specify the BS ID, Neighbour BS ID (bs-id-lsb) and Trigger name if you want to display configuration for a particular Trigger. For example, to display the scnReqCinrMin parameters of BS Neighbour 68000 in BS 66053, run the following command:

```
npu# show nbr-triggers bs 66053 bs-id-lsb 68000 TrigName scnReqCinrMin
```

Do not specify these parameters if you want to view configuration information for all existing Neighbour BSs in all BSs. To display information for all Neighbour BSs in all BSs, run the following command:

```
npu# show nbr-triggers bs
```

<b>Command Syntax</b>	<b>npu# show nbr-triggers bs</b> [<(1 to 16777215 StepSize 1)> bs-id-lsb <(1 to 16777215 StepSize 1)> TrigName {scnReqCinrMin   scnReqRssiMin   scnReqRtdMax   hoReqCinrMaxNbs   hoReqRssiMaxNbs   hoReqCinrMargin   hoReqRssiMargin   hoReqRtdMax   hoReqCinrMinSbs   hoReqRssiMinSbs} ]
-----------------------	---

**Privilege Level** 1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display a specific Trigger in a specific Neighbour BS of a specific BS. Do not specify a value for this parameter if you want to display the Triggers of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215
bs-id-lsb <(1 to 16777215 StepSize 1)>	The Neighbour BS ID.  Specify a value for this parameter if you want to display a specific Trigger in a specific Neighbour BS of a specific BS. Do not specify a value for this parameter if you want to display the Triggers of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215

TrigName {scnReqCinrMin   scnReqRssiMin   scnReqRtdMax   hoReqCinrMaxNbs   hoReqRssiMaxNbs   hoReqCinrMargin   hoReqRssiMargin   hoReqRtdMax   hoReqCinrMinSbs   hoReqRssiMinSbs} ]	The Trigger name  Specify only if you want to display a specific Trigger of a specific Neighbour BS in a specific BS. Do not specify if you want to display all Triggers parameters of all Neighbour BSs in all BSs		<ul style="list-style-type: none"> <li>■ scnReqCinrMin</li> <li>■ scnReqRssiMin</li> <li>■ scnReqRtdMax</li> <li>■ hoReqCinrMaxNbs</li> <li>■ hoReqRssiMaxNbs</li> <li>■ hoReqCinrMargin</li> <li>■ hoReqRssiMargin</li> <li>■ hoReqRtdMax</li> <li>■ hoReqCinrMinSbs</li> <li>■ hoReqRssiMinSbs}</li> </ul>
---	---	--	--

<b>Display Format</b>	BSIDLSB	:<value>
(for a selected Trigger)	BSIDLSB	:value>
	scnReqCinrMin	:value>

**Command Modes** Global command mode

#### 4.8.14.6.5 Displaying Configuration Information for All Neighbour BS Parameters

To display configuration for the all Neighbour BS parameters, run the following command:

**npu# show nbr-all bs** [(1 to 16777215 StepSize 1)> bs-id-lsb (1 to 16777215 StepSize 1)>]

Specify the BS ID and the Neighbour BS ID (bs-id-lsb) if you want to display configuration for a particular Neighbour BS in a particular BS. For example, to display all parameters of Neighbour BS 68000 in BS 66503, run the following command:

**npu# show nbr-all bs 66053 bs-id-lsb 68000**

Do not specify these parameters if you want to view configuration information for all existing Neighbour BSs in all existing BSs. To display information for all Neighbour BSs in all BSs, run the following command:

**npu# show nbr-all bs**


---

**Command Syntax**     **npu# show nbr-all bs** [<(1 to 16777215 StepSize 1)> bs-id-lsb <(1 to 16777215 StepSize 1)> ]

---

**Privilege Level**     10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Trigger Setup parameters of a specific Neighbour BS in a specific BS. Do not specify a value for this parameter if you want to display the Trigger Setup parameters of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215
bs-id-lsb <(1 to 16777215 StepSize 1)>	The Neighbour BS ID.  Specify a value for this parameter if you want to display the Trigger Setup parameters of a specific Neighbour BS in a specific BS. Do not specify a value for this parameter if you want to display the Trigger Setup parameters of all Neighbour BSs in all BSs.	Optional	N/A	1-16777215

---

**Command Modes**     Global command mode

## 4.8.15 Managing UCD Parameters

After enabling the BS configuration mode, you can execute the following tasks:

- Configure one or more of the UCD parameters (refer to [Section 4.8.15.1](#)).
- Restore the default values of some or all of the UCD parameters (refer to [Section 4.8.15.2](#)).

You can display configuration and status information for the UCD parameters of a selected or all existing BSs (refer to [Section 4.8.15.3](#)).

### 4.8.15.1 Configuring UCD Parameters



**To configure the UCD Parameters:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# ucd [interval <(1 to 10000 StepSize 1)>] [transition <(20 to 1000 StepSize 1)>]
```

---

**Command Syntax**     **npu(config-bs-66053)# ucd** [interval <(1 to 10000 StepSize 1)> ] [transition <(20 to 1000 StepSize 1)> ]

---

**Privilege Level**     10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[interval <(1 to 10000 StepSize 1)> ]	The time in milliseconds between transmission of Uplink Channel Descriptor messages.	Optional	1000	1 - 10000

[transition <(20 to 1000 StepSize 1)> ]	The number of frames from the end of the frame carrying the Uplink Channel Descriptor message that the BS should wait after repeating an Uplink Channel Descriptor message with an increment of the configuration change count before issuing a UL-MAP message referring to Uplink_Burst_Profiles	Optional	100	20 - 1000
---	---	----------	-----	-----------

**Command Modes** bs configuration mode



#### IMPORTANT

When creating a new BS, at least one of the UCD parameters must be configured explicitly (even if configured to the default value).

### 4.8.15.2 Restoring the Default Values of UCD Parameters

To restore the default values of some or all of the UCD parameters, run the following command:

```
npu(config-bs-66053)# no ucd [interval] [transition]
```

You can restore only one parameter to the default values by specifying only that parameters. For example, to restore only the interval parameter to the default value, run the following command:

```
npu(config-bs-66053)# no ucd interval
```

This parameter will be restored to its default value, while the other parameter will remain unchanged.

To restore all UCD parameters to their default value, run the following command:

```
npu(config-bs-66053)# no ucd
```



#### NOTE

Refer to [Section 4.8.15.1](#) for a description and default values of these parameters.

---

**Command Syntax**     **npu(config-bs-66053)# no ucd** [interval ] [transition ]

---

**Privilege Level**     10

---

**Command Modes**     bs configuration mode

### 4.8.15.3 Displaying Configuration and Status Information for UCD Parameters

To display configuration and status information of UCD parameters, run the following command:

**npu# show ucd bs** [<(1 to 16777215 StepSize 1)

Specify the BS ID if you want to display information for a particular BS. For example, to display the UCD parameters of BS 66053, run the following command:

**npu# show ucd bs 66053**

Do not specify this parameter if you want to view information for all existing BSs. To display information for all BSs, run the following command:

**npu# show ucd bs**

---

**Command Syntax**     **npu# show ucd bs** [<(1 to 16777215 StepSize 1)

---

**Privilege Level**     1

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display UCD parameters of a specific BS. Do not specify a value for this parameter if you want to display UCD parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

(for each existing BS if requested for all BSs)

BSIDLBS	:<value>
UCDConfigurationChangeCount	:<value>
UCDInterval(msec)	:<value>
UCDTransition(frames)	:<value>

**Command Modes**

Global command mode

In addition to the configurable parameters, the following status parameter is also displayed:

Parameter	Description	Possible Values
UCDConfigurationChangeCount	Incremented by one (modulo 256) by the BS whenever any of the values of the Uplink Channel Descriptor changes.	0-255

## 4.8.16 Managing DCD Parameters

After enabling the BS configuration mode, you can execute the following tasks:

- Configure one or more of the DCD parameters (refer to [Section 4.8.16.1](#)).
- Restore the default values of some or all of the DCD parameters (refer to [Section 4.8.16.2](#)).



You can display configuration and status information for the DCD parameters of a selected or all existing BSs (refer to [Section 4.8.16.3](#)).

### 4.8.16.1 Configuring DCD Parameters



**To configure the DCD Parameters:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# dcd [interval <(1 to 10000 StepSize 1)>] [transition <(20 to 1000 StepSize 1)>]
```

---

**Command Syntax**     **npu(config-bs-66053)# dcd** [interval <(1 to 10000 StepSize 1)> ]  
[transition <(20 to 1000 StepSize 1)> ]

---

**Privilege Level**     10

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[interval <(1 to 10000 StepSize 1)> ]	The time in milliseconds between transmission of Downlink Channel Descriptor messages.	Optional	1000	1 - 10000
[transition <(20 to 1000 StepSize 1)> ]	The number of frames from the end of the frame carrying the Downlink Channel Descriptor message that the BS should wait after repeating a Downlink Channel Descriptor message with an increment of the configuration change count before issuing a DL-MAP message referring to Downlink_Burst_Profiles	Optional	100	20 - 1000

---

**Command**    bs configuration mode  
**Modes**



### IMPORTANT

When creating a new BS, at least one of the DCD parameters must be configured explicitly (even if configured to the default value).

## 4.8.16.2 Restoring the Default Values of DCD Parameters

To restore the default values of some or all of the DCD parameters, run the following command:

```
npu(config-bs-66053)# no dcd [interval] [transition]
```

You can restore only one parameter to the default values by specifying only that parameter. For example, to restore only the interval parameter to the default value, run the following command:

```
npu(config-bs-66053)# no dcd interval
```

This parameter will be restored to its default value, while the other parameter will remain unchanged.

To restore all DCD parameters to their default value, run the following command:

```
npu(config-bs-66053)# no dcd
```



### NOTE

Refer to [Section 4.8.16.1](#) for a description and default values of these parameters.

---

**Command Syntax**    **npu(config-bs-66053)# no dcd [interval ] [transition ]**

---

**Privilege Level**    10

---

**Command Modes**    bs configuration mode

### 4.8.16.3 Displaying Configuration and Status Information for DCD Parameters

To display configuration and status information of DCD parameters, run the following command:

```
npu# show dcd bs [<(1 to 16777215 StepSize 1)
```

Specify the BS ID if you want to display information for a particular BS. For example, to display the DCD parameters of BS 66053, run the following command:

```
npu# show dcd bs 66053
```

Do not specify this parameter if you want to view information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show dcd bs
```

---

**Command Syntax**     **npu# show dcd bs** [<(1 to 16777215 StepSize 1)

---

**Privilege Level**     1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display DCD parameters of a specific BS. Do not specify a value for this parameter if you want to display DCD parameters of all BSs.	Optional	N/A	1-16777215

<b>Display</b>	BSIDL5B	: <value>
<b>Format</b>	DCDConfigurationChangeCount	: <value>
(for each existing BS if requested for all BSs)	RestartCount	: <value>
	DCDInterval(msec)	: <value>
	DCDTransition(frames)	: <value>

**Command Modes** Global command mode

In addition to the configurable parameters, the following status parameters are also displayed:

Parameter	Description	Possible Values
DCDConfigurationChangeCount	Incremented by one (modulo 256) by the BS whenever any of the values of the Downlink Channel Descriptor changes.	0-255
RestartCount	Incremented by one (modulo 256) whenever BS restarts. The value is needed to populate neighbouring BSs neighbour tables.	0-255

## 4.8.17 Managing the RF Frequency Parameter

After enabling the BS configuration mode, you can configure the RF frequency parameter (refer to [Section 4.8.17.1](#)).

You can display configuration information for the RF frequency parameter of a selected or all existing BSs (refer to [Section 4.8.17.2](#)).

### 4.8.17.1 Configuring the RF Frequency Parameter



**To configure the RF frequency parameter:**

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# rf [frequency <(2302.5 to 2357.5 StepSize 0.125) | (2498.5 to 2687.5 StepSize0.125) | (3402.5 to 3597.5 StepSize 0.125) | (3602.5 to 3797.5 StepSize 0.125)>]
```

**Command** `npu(config-bs-66053)# rf [frequency <(2302.5 to 2357.5 StepSize 0.125) | (2498.5 to 2687.5 StepSize0.125) | (3402.5 to 3597.5 StepSize 0.125) | (3602.5 to 3797.5 StepSize 0.125)>]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[frequency <(2302.5 to 2357.5 StepSize 0.125)   (2498.5 to 2687.5 StepSize0.125)   (3402.5 to 3597.5 StepSize 0.125)   (3602.5 to 3797.5 StepSize 0.125)>]	<p>The center of the frequency band in which the BS will transmit, in MHz.</p> <p>Must be within the valid range of the relevant ODU.</p> <p>The indicated Possible Values are for a bandwidth of fiveMhz. For a different bandwidth, the actually valid values are from <math>f1+1/2BW</math> to <math>f2-1/2BW</math>, where <math>f1</math> is the lowest frequency of the ODU's radio band (see <a href="#">“Currently Available Single Port ODU Types” on page 487</a>. Note that oDU23052360000N361by1Y0 (16) includes two bands: 2305-2320, 2345-2360 MHz.), <math>f2</math> is the highest frequency of the ODU's band, and BW is the configured bandwidth (see <a href="#">“Configuring the Baseband Bandwidth Parameter” on page 640</a>).</p>	Mandatory	N/A	<ul style="list-style-type: none"> <li>■ 2302.5 to 2357.5 in steps of 0.125</li> <li>■ 2498.5 to 2687.5 in steps of 0.125</li> <li>■ 3402.5 to 3597.5 in steps of 0.125</li> <li>■ 3602.5 to 3797.5 in steps of 0.125</li> </ul>

**Command Modes** bs configuration mode



**IMPORTANT**  
When creating a new BS, the mandatory frequency parameter must be configured.

## 4.8.17.2 Displaying Configuration Information for the RF Frequency Parameter

To display configuration information of the RF frequency parameter, run the following command:

```
npu# show rf bs [<(1 to 16777215 StepSize 1)
```

Specify the BS ID if you want to display information for a particular BS. For example, to display the RF frequency of BS 66053, run the following command:

```
npu# show rf bs 66053
```

Do not specify this parameter if you want to view information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show rf bs
```

---

**Command Syntax**     **npu# show rf bs** [<(1 to 16777215 StepSize 1)

---

**Privilege Level**     1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the RF frequency parameter of a specific BS. Do not specify a value for this parameter if you want to display the RF frequency parameter of all BSs.	Optional	N/A	1-16777215

---

**Display Format**     BSIDLSB     :<value>  
 Frequency     :<value>

(for each existing BS if requested for all BSs)

**Command** Global command mode  
**Modes**

## 4.8.18 Managing the Baseband Bandwidth Parameter

After enabling the BS configuration mode, you can configure the Baseband bandwidth parameter (refer to [Section 4.8.18.1](#)).

You can display configuration information for the Baseband bandwidth parameter of a selected or all existing BSs (refer to [Section 4.8.18.2](#)).

### 4.8.18.1 Configuring the Baseband Bandwidth Parameter



To configure the Baseband bandwidth parameter:

From the BS configuration mode, run the following command:

```
npu(config-bs-66053)# baseband [bandwidth {fiveMHz | tenMHz | sevenMHz}]
```

**Command Syntax** **npu(config-bs-66053)# baseband** [bandwidth {fiveMHz | tenMHz | sevenMHz} ]

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[bandwidth {fiveMHz   tenMHz   sevenMHz} ]	BS channel bandwidth	Mandatory	N/A	<ul style="list-style-type: none"> <li>■ fiveMHz</li> <li>■ tenMHz</li> <li>■ sevenMHz</li> </ul>

**Command Modes** bs configuration mode



#### IMPORTANT

When creating a new BS, the mandatory frequency parameter must be configured.

Note that the valid value ranges (and in some cases also default value) of certain parameters are affected by the value configured for the bandwidth parameter. If you change the bandwidth, verify that these parameters are configured properly:

Table	Parameters
RF (see <a href="#">Section 4.8.17.1</a> )	frequency
Airframe Structure, General (see <a href="#">Section 4.8.19.2.1</a> )	ul-dl-allocation
Airframe Structure, Map Zone (see <a href="#">Section 4.8.19.2.2</a> )	majorgrps
Airframe Structure, Uplink Feedback Zone (see <a href="#">Section 4.8.19.2.8</a> )	subchannels
Airframe Structure, Downlink Data Zone (see <a href="#">Section 4.8.19.2.9</a> )	subchannels
Airframe Structure, Uplink Data Zone (see <a href="#">Section 4.8.19.2.10</a> )	subchannels subchannels-number
Feedback Allocation (see <a href="#">Section 4.8.7.1</a> )	max-cqi
Triggers (see <a href="#">Section 4.8.9.1</a> )	triggers-scnreq-rtd-max triggers-horeq-rtd-max

## 4.8.18.2 Displaying Configuration Information for the Baseband Bandwidth Parameter

To display configuration information of the Baseband bandwidth parameter, run the following command:

```
npu# show baseband bs [<(1 to 16777215 StepSize 1)
```

Specify the BS ID if you want to display information for a particular BS. For example, to display the Baseband bandwidth of BS 66053, run the following command:

```
npu# show baseband bs 66053
```

Do not specify this parameter if you want to view information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show baseband bs
```

---

**Command Syntax**     **npu# show baseband bs** [<(1 to 16777215 StepSize 1)



**Privilege Level** 1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Baseband bandwidth parameter of a specific BS. Do not specify a value for this parameter if you want to display the Baseband bandwidth parameter of all BSs.	Optional	N/A	1-16777215

**Display Format**

BSIDLSB	:<value>
Bandwidth	:<value>

(for each existing BS if requested for all BSs)

**Command Modes** Global command mode

## 4.8.19 Managing Airframe Structure Parameters



**To configure Airframe Structure parameters:**

- 1 Enable the Airframe configuration mode (refer to [Section 4.8.19.1](#))

- 2 You can now execute any of the following tasks:
- » Configure one or more of the Airframe parameters tables (refer to [Section 4.8.19.2](#))
  - » Restore the default values of parameters in one or more of the Airframe parameters tables (refer to [Section 4.8.19.3](#))
  - » Terminate the Airframe configuration mode (refer to [Section 4.8.19.4](#))

In addition, you can, at any time, display configuration information for each of the Airframe parameters tables (refer to [Section 4.8.19.5](#)).

### 4.8.19.1 Enabling the Airframe Configuration Mode

To configure the Airframe parameters, first enable the Airframe configuration mode. Run the following command to enable the Airframe configuration mode.

```
npu(config-bs-66053)# airframe
```

After enabling the Airframe configuration mode, you can execute any of the following tasks:

- Configure one or more of the Airframe parameters tables (refer to [Section 4.8.19.2](#))
- Restore the default values of parameters in one or more of the Airframe parameters tables (refer to [Section 4.8.19.3](#))

After executing the above tasks, you can terminate the Airframe configuration mode (refer to [Section 4.8.19.4](#)) and return to the BS configuration mode.

Note that for properly completing the Airframe configuration the **apply** command must be executed prior to exiting the Airframe configuration mode.

---

<b>Command Syntax</b>	npu(config-bs-66053)# airframe
-----------------------	--------------------------------

---

<b>Privilege Level</b>	10
------------------------	----

---

<b>Command Modes</b>	bs configuration mode
----------------------	-----------------------

## 4.8.19.2 Configuring Airframe Parameters

After enabling the Airframe configuration mode you can configure the following parameters tables:

- General (refer to [Section 4.8.19.2.1](#))
- Map Zone (refer to [Section 4.8.19.2.2](#))
- Downlink Diversity (refer to [Section 4.8.19.2.3](#))
- Cyclic Delay (refer to [Section 4.8.19.2.4](#))
- Linear Delay (refer to [Section 4.8.19.2.5](#))
- Mapping (refer to [Section 4.8.19.2.6](#))
- Receive (refer to [Section 4.8.19.2.7](#))
- Uplink Feedback Zone (refer to [Section 4.8.19.2.8](#))
- Downlink Data Zone (refer to [Section 4.8.19.2.9](#))
- Uplink Data Zone (refer to [Section 4.8.19.2.10](#))
- Dynamic Permutation (refer to [Section 4.8.19.2.11](#))



### IMPORTANT

After completing the Airframe configuration, do not forget to execute the apply command before exiting the Airframe configuration mode:

```
npu(config-bs-66053-airframe)# apply
```

### 4.8.19.2.1 Configuring Airframe General Parameters

To configure the Airframe General parameters, run the following command:

```
npu(config-bs-66053-airframe)# general [cell-id <(0 to 31 StepSize 1)>]  
[preamble-grp <(1 to 2 StepSize 1)>] [segment <(0 to 2 StepSize 1)>] [frame-offset  
<(0 to 15 StepSize 1)>] [enable-ul-scrotation {TRUE | FALSE}] [ul-dl-allocation <(3  
to 7 StepSize 1)>]
```



**IMPORTANT**

When creating a new BS, all mandatory Neighbor BS General parameters must be configured.

**Command Syntax** `npu(config-bs-66053-airframe)# general [cell-id <(0 to 31 StepSize 1)> ] [preamble-grp <(1 to 2 StepSize 1)>] [segment <(0 to 2 StepSize 1)> ] [frame-offset <(0 to 15 StepSize 1)> ] [enable-ul-scrotation {TRUE | FALSE} ] [ul-dl-allocation <(3 to 7 StepSize 1)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[cell-id <(0 to 31 StepSize 1)> ]	The Cell ID (IDCell) used for preamble selection.	Mandatory when creating a new BS.	N/A	0 - 31
[preamble-grp <(1 to 2 StepSize 1)>]	The preamble group. A value of 2 is available only for the following combinations of segment and cell-id values:  segment=0, cell-id=0, 3, 6, 9, 12, 15.  segment=1, cell-id=1, 4, 7, 10, 13, 16.  segment=2, cell-id=2, 5, 8, 11, 14, 17.	Optional	1	1 - 2

[segment <(0 to 2 StepSize 1)> ]	The segment (BS) number in a three sector BS (0-2). This number influences the preamble selection and the major group used for the FDC transmission.	Mandatory when creating a new BS.	N/A	0 - 2
[frame-offset <(0 to 15 StepSize 1)> ]	Controls the offset applied between the internal frame count and the reported frame number	Mandatory when creating a new BS.	N/A	0 - 15
[enable-ul-srotation {TRUE   FALSE} ]	Controls the uplink sub channel rotation functionality.  If TRUE uplink sub channel rotation is enabled.	Optional	FALSE	<input checked="" type="checkbox"/> TRUE <input type="checkbox"/> FALSE
[ul-dl-allocation <(3 to 7 StepSize 1)> ]	The total duration of the uplink in a frame, in slots. (one slot equals 3 symbols).  The range is 4-7 for bandwidth = 5 or 10MHz, 3-5 for bandwidth = 7MHz. To avoid BS-BS interference, the ul-dl-allocation must be identical in all BSs in a geographical region.	Mandatory when creating a new BS.	N/A	3 - 7

**Command**    bs airframe configuration mode  
**Modes**

#### 4.8.19.2.2 Configuring Airframe Map Zone Parameters

To configure the Airframe Map Zone parameters, run the following command:

```
npu(config-bs-66053-airframe)# mapzone [size <(-1 to -1 StepSize 1) | (2 to 16 StepSize 2)>] [majorgrps <hex-string>] [repetition <(1 to 1 StepSize 1) | (2 to 6 StepSize 2)>]
```



**IMPORTANT**

When creating a new BS, the mandatory Airframe Map Zone majorgrps parameter must be configured.

**Command Syntax** `npu(config-bs-66053-airframe)# mapzone [size <(-1 to -1 StepSize 1) | (2 to 16 StepSize 2)> ] [majorgrps <hex-string>] [repetition <(1 to 1 StepSize 1) | (2 to 6 StepSize 2)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
size <(-1 to -1 StepSize 1)   (2 to 16 StepSize 2)>	The map zone size in symbols. A value of "-1" means the map zone size will be dynamic.	Optional	6	-1, 2, 4, 6, 8, 10, 12, 14, 16.

majorgrps <hex-string>	<p>The Major groups allocated to the BS for maps transmission.</p> <p>Two hexadecimal numbers representing 8 bits numbered 0 to 7 (left to right). Bits 0 to 5 indicate whether Subchannel Groups 0 to 5 (respectively) are allocated. Bit 6 and 7 are set to 0.</p> <p>If BW=5 MHz, bits 1, 3 and 5 are not relevant ("don't care").</p> <p>If segment (see <a href="#">Section 4.8.19.2.1</a>) = 0, then bit #0 should be set. If segment = 1, then bit #2 should be set. If segment = 2, then bit #4 should be set.</p>	Mandatory when creating a new BS.	N/A	a string of two hexadecimal numbers.
repetition <(1 to 1 StepSize 1)   (2 to 6 StepSize 2)>	The basic repetition used in the transmission of the maps	Optional	6	1, 2, 4, 6

**Command Modes** bs airframe configuration mode

### 4.8.19.2.3 Configuring the Airframe Downlink Diversity Mode Parameter

To configure the Airframe Downlink Diversity mode parameter, run the following command:

```
npu(config-bs-66053-airframe)# dldiversity [mode <{none | matrixA}>]
```



#### IMPORTANT

When creating a new BS, the Airframe Downlink Diversity mode parameter must be configured (even if configured to the default value).

**Command Syntax** **npu(config-bs-66053-airframe)# dldiversity** [mode <{none | matrixA }>]

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
mode <{none   matrixA }>	The diversity mode used in downlink transmissions: None or MIMO Matrix A.  Note that the value configured for the dldiversity mode affects the valid options for Cyclic Delay (see <a href="#">Section 4.8.19.2.4</a> ), Linear Delay (see <a href="#">Section 4.8.19.2.5</a> ) and Mapping (see <a href="#">Section 4.8.19.2.6</a> ) parameters.	Optional	none	<ul style="list-style-type: none"> <li>■ none</li> <li>■ matrixA</li> </ul>

**Command Modes** bs airframe configuration mode

#### 4.8.19.2.4 Configuring Airframe Cyclic Delay Parameters

To configure the Airframe Cyclic Delay parameters, run the following command:

```
npu(config-bs-66053-airframe)# cyclicdelay [channel-1 <(0 to 4 StepSize 0.01)>]
[channel-2 <(0 to 4 StepSize 0.01)>] [channel-3 <(0 to 4 StepSize 0.01)>]
[channel-4 <(0 to 4 StepSize 0.01)>]
```



#### IMPORTANT

When creating a new BS, at least one of the Airframe Cyclic Delay parameters must be configured explicitly (even if configured to the default value).

**Command Syntax** **npu(config-bs-66053-airframe)# cyclicdelay** [channel-1 <(0 to 4 StepSize 0.01)> ] [channel-2 <(0 to 4 StepSize 0.01)> ] [channel-3 <(0 to 4 StepSize 0.01)> ] [channel-4 <(0 to 4 StepSize 0.01)> ]



**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[channel-1 <(0 to 4 StepSize 0.01)> ]	Controls the cyclic delay (in microseconds) applied to PHY physical channel #1 of the Downlink Data Zone.  Not relevant if dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none")	Optional	0	0 to 4 in steps of 0.01
[channel-2 <(0 to 4 StepSize 0.01)> ]	Controls the cyclic delay (in microseconds) applied to PHY physical channel #2 of the Downlink Data Zone.  Not relevant if dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none")	Optional	0	0 to 4 in steps of 0.01
[channel-3 <(0 to 4 StepSize 0.01)> ]	Controls the cyclic delay (in microseconds) applied to PHY physical channel #3 of the Downlink Data Zone.  Not relevant if dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none")	Optional	0	0 to 4 in steps of 0.01
[channel-4 <(0 to 4 StepSize 0.01)> ]	Controls the cyclic delay (in microseconds) applied to PHY physical channel #4 of the Downlink Data Zone.  Not relevant if dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none")	Optional	0	0 to 4 in steps of 0.01

**Command Modes** bs airframe configuration mode

#### 4.8.19.2.5 Configuring Airframe Linear Delay Parameters

To configure the Airframe Linear Delay parameters, run the following command:

```
npu(config-bs-66053-airframe)# lineardelay [channel-1 <(0 to 4 StepSize 0.01)>]
[channel-2 <(0 to 4 StepSize 0.01)>] [channel-3 <(0 to 4 StepSize 0.01)>]
[channel-4 <(0 to 4 StepSize 0.01)>]
```

**IMPORTANT**

When creating a new BS, at least one of the Airframe Linear Delay parameters must be configured explicitly (even if configured to the default value). configured.

**Command Syntax** **npu(config-bs-66053-airframe)# lineardelay** [channel-1 <(0 to 4 StepSize 0.01)> ] [channel-2 <(0 to 4 StepSize 0.01)> ] [channel-3 <(0 to 4 StepSize 0.01)> ] [channel-4 <(0 to 4 StepSize 0.01)> ]

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[channel-1 <(0 to 4 StepSize 0.01)> ]	Controls the linear delay (in microseconds) applied to PHY physical channel #1 of the Downlink Data Zone.  Not relevant if dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none")	Optional	0	0 to 4 in steps of 0.01
[channel-2 <(0 to 4 StepSize 0.01)> ]	Controls the linear delay (in microseconds) applied to PHY physical channel #2 of the Downlink Data Zone.  Not relevant if dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none")	Optional	0	0 to 4 in steps of 0.01
[channel-3 <(0 to 4 StepSize 0.01)> ]	Controls the linear delay (in microseconds) applied to PHY physical channel #3 of the Downlink Data Zone.  Not relevant if dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none")	Optional	0	0 to 4 in steps of 0.01

[channel-4 <(0 to 4 StepSize 0.01)> ]	Controls the linear delay (in microseconds) applied to PHY physical channel #4 of the Downlink Data Zone.  Not relevant if dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none")	Optional	0	0 to 4 in steps of 0.01
---------------------------------------	--	----------	---	-------------------------

**Command Modes** bs airframe configuration mode

### 4.8.19.2.6 Configuring Airframe Mapping Parameters

To configure the Airframe Mapping parameters, run the following command:

```
npu(config-bs-66053-airframe)# mapping [channel-1 {11 | 11slashL2 | Silence}]
[channel-2 {11 | 11slashL2 | Silence}] [channel-3 {11 | 11slashL2 | Silence}]
[channel-4 {11 | 11slashL2 | Silence}]
```



#### IMPORTANT

When creating a new BS, at least one of the Airframe Mapping parameters must be configured explicitly (even if configured to the default value). configured.

**Command Syntax** **npu(config-bs-66053-airframe)# mapping** [channel-1 {11 | 11slashL2 | Silence} ] [channel-2 {11 | 11slashL2 | Silence} ] [channel-3 {11 | 11slashL2 | Silence} ] [channel-4 {11 | 11slashL2 | Silence} ]

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
-----------	-------------	----------	---------------	-----------------

<p>[channel-1 {I1   I1slashL2   Silence} ]</p>	<p>Defines which logical stream is mapped to physical channel #1:                      I1: Logical Stream 1.                      I1slashL2: Logical Streams 1 and 2.                      Silence: None</p> <p>If the ODU port associated to port 1 of the AU associated to this BS is "rx only" (port-2 or port-4), the only valid value is Silence.</p> <p>If dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none"), valid options are I1 and Silence.</p>	<p>Optional</p>	<p>I1</p>	<ul style="list-style-type: none"> <li>■ I1</li> <li>■ I1slashL2</li> <li>■ Silence</li> </ul>
<p>[channel-2 {I1   I1slashL2   Silence} ]</p>	<p>Defines which logical stream is mapped to physical channel #2.                      I1: Logical Stream 1.                      I1slashL2: Logical Streams 1 and 2.                      Silence: None</p> <p>If the ODU port associated to port 2 of the AU associated to this BS is "rx only" (port-2 or port-4), the only valid value is Silence.</p> <p>If dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none"), valid options are I1 and Silence.</p>	<p>Optional</p>	<p>I1</p>	<ul style="list-style-type: none"> <li>■ I1</li> <li>■ I1slashL2</li> <li>■ Silence</li> </ul>

[channel-3 {I1   I1slashL2   Silence} ]	<p>Defines which logical stream is mapped to physical channel #3.</p> <p>I1: Logical Stream 1.</p> <p>I1slashL2: Logical Streams 1 and 2.</p> <p>Silence: None</p> <p>If the ODU port associated to port 3 of the AU associated to this BS is "rx only" (port-2 or port-4), the only valid value is Silence.</p> <p>If dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none"), valid options are I1 and Silence.</p>	Optional	I1	<ul style="list-style-type: none"> <li>■ I1</li> <li>■ I1slashL2</li> <li>■ Silence</li> </ul>
[channel-4 {I1   I1slashL2   Silence} ]	<p>Defines which logical stream is mapped to physical channel #4.</p> <p>I1: Logical Stream 1.</p> <p>I1slashL2: Logical Streams 1 and 2.</p> <p>Silence: None</p> <p>If the ODU port associated to port 4 of the AU associated to this BS is "rx only" (port-2 or port-4), the only valid value is Silence.</p> <p>If dldiversity mode (see <a href="#">Section 4.8.19.2.3</a> is "none"), valid options are I1 and Silence.</p>	Optional	I1	<ul style="list-style-type: none"> <li>■ I1</li> <li>■ I1slashL2</li> <li>■ Silence</li> </ul>

**Command**    bs airframe configuration mode  
**Modes**

#### 4.8.19.2.7 Configuring Airframe Receive Parameters

To configure the Airframe Receive parameters, run the following command:

```
npu(config-bs-66053-airframe)# rx [adminchannel-1 {TRUE | FALSE}]
[adminchannel-2 {TRUE | FALSE}] [adminchannel-3 {TRUE | FALSE}]
[adminchannel-4 {TRUE | FALSE}]
```

**IMPORTANT**

When creating a new BS, at least one of the Airframe Receive parameters must be configured explicitly (even if configured to the default value). configured.

**Command Syntax** **npu(config-bs-66053-airframe)# rx** [adminchannel-1 {TRUE | FALSE} ]  
 [adminchannel-2 {TRUE | FALSE} ] [adminchannel-3 {TRUE | FALSE} ]  
 [adminchannel-4 {TRUE | FALSE} ]

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[adminchannel-1 {TRUE   FALSE} ]	The desired status of channel 1 in the modem receiver. A value of TRUE means enabled.	Optional	TRUE	<input type="checkbox"/> TRUE <input type="checkbox"/> FALSE
[adminchannel-2 {TRUE   FALSE} ]	The desired status of channel 2 in the modem receiver. A value of TRUE means enabled.	Optional	FALSE	<input type="checkbox"/> TRUE <input type="checkbox"/> FALSE
[adminchannel-3 {TRUE   FALSE} ]	The desired status of channel 3 in the modem receiver. A value of TRUE means enabled.	Optional	FALSE	<input type="checkbox"/> TRUE <input type="checkbox"/> FALSE
[adminchannel-4 {TRUE   FALSE} ]	The desired status of channel 4 in the modem receiver. A value of TRUE means enabled.	Optional	FALSE	<input type="checkbox"/> TRUE <input type="checkbox"/> FALSE

**Command Modes** bs airframe configuration mode

#### 4.8.19.2.8 Configuring Airframe Uplink Feedback Zone Parameters

To configure the Airframe Uplink Feedback Zone parameters, run the following command:

**npu(config-bs-66053-airframe)# ulfeedbackzone** [subchannels <(1 to 35 StepSize 1)>] [permbase <(0 to 69 StepSize 1)>]

**IMPORTANT**

When creating a new BS, the Airframe Structure Uplink Feedback Zone mandatory permbase parameter must be configured.

**Command Syntax** `npu(config-bs-66053-airframe)# ulfeedbackzone [subchannels <(11 to 35 StepSize 1)> ] [permbase <(0 to 69 StepSize 1)> ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[subchannels <(1 to 35 StepSize 1)> ]	The number of subchannels used in the uplink feedback zone.  If bandwidth=7MHz or 10MHz, valid range is 11-35. If bandwidth=5MHz, valid range is 11-17. The default for bandwidth=5MHz should be 17.  Must be higher than or equal to the value of max-cqi (see <a href="#">Section 4.8.7.1</a> )	Optional	35	11-35
[permbase <(0 to 69 StepSize 1)> ]	The permutation base used in the feedback zone	Mandatory when creating a new BS.	N/A	0 - 69

**Command Modes** bs airframe configuration mode

#### 4.8.19.2.9 Configuring Airframe Downlink Data Zone Parameters

To configure the Airframe Downlink Data Zone parameters, run the following command:

```
npu(config-bs-66053-airframe)# dldatazone [subchannels <(1 to 30 StepSize 1)>] [permbase <(0 to 31 StepSize 1)>]
```

**IMPORTANT**

When creating a new BS, the Airframe Uplink Feedback Zone mandatory parameters must be configured.

**Command Syntax** **npu(config-bs-66053-airframe)# dldatazone** [subchannels <(1 to 30 StepSize 1)> ] [permbase <(0 to 31 StepSize 1)> ]

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[subchannels <(1 to 30 StepSize 1)> ]	The number of subchannels used in the downlink data zone.  If bandwidth=7MHz or 10MHz, valid range is 1-30. If bandwidth=5MHz, valid range is 1-15.	Mandatory when creating a new BS.	N/A	1-30
[permbase <(0 to 31 StepSize 1)> ]	The permutation base used in the downlink data zone	Mandatory when creating a new BS.	N/A	0 - 31

**Command Modes** bs airframe configuration mode

#### 4.8.19.2.10 Configuring Airframe Uplink Data Zone Parameters

To configure the Airframe Uplink Data Zone parameters, run the following command:

```
npu(config-bs-66053-airframe)# ulldatazone [permbase <(0 to 69 StepSize 1)>] [startallocation <(0 to 209 StepSize 1)>] [subchannels-number <(1 to 35 StepSize 1)>]
```



**IMPORTANT**

When creating a new BS, the Airframe Structure Uplink Data Zone mandatory permbase parameter must be configured.

**Command Syntax** **npu(config-bs-66053-airframe)# uldatazone** [permbase <(0 to 69 StepSize 1)> ] [startallocation <(0 to 209 StepSize 1)> ] [subchannels-number <(1 to 35 StepSize 1)> ]

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
[permbase <(0 to 69 StepSize 1)> ]	The permutation base used in the uplink datazone	Optional		0 to 69 in steps of 1
[startallocation <(0 to 209 StepSize 1)> ]	The start allocation for the uplink datazone in slots	Optional	0	0 to 209 in steps of 1
[subchannels-number <(1 to 35 StepSize 1)> ]	The number of subchannels used in the uplink datazone.  If bandwidth=7MHz or 10MHz, valid range is 1-35. If bandwidth=5MHz, valid range is 1-17. The default for bandwidth=5MHz should be 17.	Optional	35  default value=35 (7 , 10 MHz) or 17 (5MHz)	1- 35

**Command Modes** bs airframe configuration mode

#### 4.8.19.2.11 Configuring Airframe Dynamic Permutation Parameters

To configure the Airframe Dynamic Permutation parameters, run the following command:

**npu(config-bs-66053-airframe)# dynamicperm** [dl-permbase {TRUE | FALSE}] [ul-permbase {TRUE | FALSE}]]

**IMPORTANT**

When creating a new BS, the Airframe Dynamic Permutation mandatory permbase parameter must be configured.

**Command Syntax** `npu(config-bs-66053-airframe)# dynamicperm [dl-permbase {TRUE | FALSE} ] [ul-permbase {TRUE | FALSE} ]`

**Privilege Level** 10

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
dl-permbase {TRUE   FALSE}	The Downlink Permutation Base. If TRUE we use the same Permutation Base over all frames (Static). If FALSE the Permutation Base changes from frame to frame (Dynamic).	Optional	True	<ul style="list-style-type: none"> <li>■ TRUE</li> <li>■ FALSE</li> </ul>
ul-permbase {TRUE   FALSE}	The Uplink Permutation Base. If TRUE we use the same Permutation Base over all frames. If FALSE the Permutation Base changes from frame to frame.	Optional	True	<ul style="list-style-type: none"> <li>■ TRUE</li> <li>■ FALSE</li> </ul>

**Command Modes** bs airframe configuration mode

### 4.8.19.3 Restoring Default Values for Airframe Configuration Parameters

After enabling the Airframe configuration mode you can restore the default values for non-mandatory parameters in the following parameters tables:

- General (refer to [Section 4.8.19.3.1](#))
- Map Zone (refer to [Section 4.8.19.3.2](#))

- Downlink Diversity (refer to [Section 4.8.19.3.3](#))
- Cyclic Delay (refer to [Section 4.8.19.3.4](#))
- Linear Delay (refer to [Section 4.8.19.3.5](#))
- Mapping (refer to [Section 4.8.19.3.6](#))
- Receive (refer to [Section 4.8.19.3.7](#))
- Uplink Feedback Zone (refer to [Section 4.8.19.3.8](#))
- Uplink Data Zone (refer to [Section 4.8.19.3.9](#))
- Dynamic Permutation (refer to [Section 4.8.19.3.10](#))

#### 4.8.19.3.1 Restoring the Default Values of Airframe General Parameters

To restore one or all of the Airframe non-mandatory General parameters to their default values, run the following command:

```
npu(config-bs-66053-airframe)# no general [preamble-grp]
[enable-ul-scrotation]
```

You can restore only one parameter to the default value by specifying only that parameter. For example, to restore only the preamble-grp to the default value, run the following command:

```
npu(config-bs-66053-airframe)# no general preamble-grp
```

The parameter will be restored to its default value, while the other parameter will remain unchanged.

To restore all non-mandatory parameters to their default value, run the following command:

```
npu(config-bs-66053-airframe)# no general
```



#### NOTE

Refer to [Section 4.8.19.2.1](#) for a description and default values of these parameters.

#### Command Syntax

```
npu(config-bs-66053-airframe)# no general [preamble-grp ]
[enable-ul-scrotation ]
```

---

**Privilege Level** 10

---

**Command Modes** bs airframe configuration mode

#### 4.8.19.3.2 Restoring the Default Values of Airframe Map Zone Parameters

To restore one or all of the Airframe Map Zone non-mandatory parameters to their default values, run the following command:

```
npu(config-bs-66053-airframe)# no mapzone [size] [repetition]
```

You can restore only one parameter to the default value by specifying only that parameter. For example, to restore only the size parameter to the default value, run the following command:

```
npu(config-bs-66053-airframe)# no mapzone size
```

The parameter will be restored to its default value, while the other parameter will remain unchanged.

To restore all non-mandatory parameters to their default value, run the following command:

```
npu(config-bs-66053-airframe)# no mapzone
```



#### NOTE

Refer to [Section 4.8.19.2.2](#) for a description and default values of these parameters.

---

**Command Syntax** **npu(config-bs-66053-airframe)# no mapzone** [size ] [repetition ]

---

**Privilege Level** 10

---

**Command Modes** bs airframe configuration mode

### 4.8.19.3.3 Restoring the Default Value of Airframe Downlink Diversity Mode Parameter

To restore the Airframe Downlink Diversity mode parameter to its default value, run the following command:

```
npu(config-bs-66053-airframe)# no dldiversity mode
```

Since the Downlink Diversity table contains a single parameter, it is sufficient to run the following command:

```
npu(config-bs-66053-airframe)# no dldiversity
```



#### NOTE

Refer to [Section 4.8.19.2.3](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<b>npu(config-bs-66053-airframe)# no dldiversity</b> [mode ]
-----------------------	--

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs airframe configuration mode
----------------------	--------------------------------

### 4.8.19.3.4 Restoring the Default Values of Airframe Cyclic Delay Parameters

To restore one or all of the Airframe Cyclic Delay parameters to their default values, run the following command:

```
npu(config-bs-66053-airframe)# no cyclicdelay [channel-1] [channel-2]  
[channel-3] [channel-4]
```

You can restore only one or several parameters to the default values by specifying only those parameters. For example, to restore only the channel-1 and channel-2 parameters to the default value, run the following command:

```
npu(config-bs-66053-airframe)# no cyclicdelay channel-1 channel-2
```

These parameters will be restored to their default values, while the other parameters will remain unchanged.

To restore all parameters to their default value, run the following command:

```
npu(config-bs-66053-airframe)# no cyclicdelay
```

**NOTE**

Refer to [Section 4.8.19.2.4](#) for a description and default values of these parameters.

---

**Command Syntax**     **npu(config-bs-66053-airframe)# no cyclicdelay** [channel-1 ] [channel-2 ] [channel-3 ] [channel-4 ]

---

**Privilege Level**     10

---

**Command Modes**     bs airframe configuration mode

### 4.8.19.3.5 Restoring the Default Values of Airframe Linear Delay Parameters

To restore one or all of the Airframe Linear Delay parameters to their default values, run the following command:

```
npu(config-bs-66053-airframe)# no lineardelay [channel-1] [channel-2]
[channel-3] [channel-4]
```

You can restore only one or several parameters to the default values by specifying only those parameters. For example, to restore only the channel-1 and channel-2 parameters to the default value, run the following command:

```
npu(config-bs-66053-airframe)# no lineardelay channel-1 channel-2
```

These parameters will be restored to their default values, while the other parameters will remain unchanged.

To restore all parameters to their default value, run the following command:

```
npu(config-bs-66053-airframe)# no lineardelay
```

**NOTE**

Refer to [Section 4.8.19.2.5](#) for a description and default values of these parameters.

---

**Command Syntax**     **npu(config-bs-66053-airframe)# no lineardelay** [channel-1 ] [channel-2 ] [channel-3 ] [channel-4 ]

---

**Privilege Level**     10

---

**Command**    bs airframe configuration mode  
**Modes**

#### 4.8.19.3.6 Restoring the Default Values of Airframe Mapping Parameters

To restore one or all of the Airframe Mapping parameters to their default values, run the following command:

```
npu(config-bs-66053-airframe)# no mapping [channel-1] [channel-2]
[channel-3] [channel-4]
```

You can restore only one or several parameters to the default values by specifying only those parameters. For example, to restore only the channel-1 and channel-2 parameters to the default value, run the following command:

```
npu(config-bs-66053-airframe)# no mapping channel-1 channel-2
```

These parameters will be restored to their default values, while the other parameters will remain unchanged.

To restore all parameters to their default value, run the following command:

```
npu(config-bs-66053-airframe)# no mapping
```



#### NOTE

Refer to [Section 4.8.19.2.6](#) for a description and default values of these parameters.

---

**Command Syntax**    **npu(config-bs-66053-airframe)# no mapping** [channel-1 ] [channel-2 ]  
[channel-3 ] [channel-4 ]

---

**Privilege Level**    10

---

**Command Modes**    bs airframe configuration mode

#### 4.8.19.3.7 Restoring the Default Values of Airframe Receive Parameters

To restore one or all of the Airframe Receive parameters to their default values, run the following command:

```
npu(config-bs-66053-airframe)# no rx [adminchannel-1] [adminchannel-2]
[adminchannel-3] [adminchannel-4]
```

You can restore only one or several parameters to the default values by specifying only those parameters. For example, to restore only the `adminchannel-1` and `adminchannel-2` parameters to the default value, run the following command:

```
npu(config-bs-66053-airframe)# no rx adminchannel-1 adminchannel-2
```

These parameters will be restored to their default values, while the other parameters will remain unchanged.

To restore all parameters to their default value, run the following command:

```
npu(config-bs-66053-airframe)# no rx
```



#### NOTE

Refer to [Section 4.8.19.2.7](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<b>npu(config-bs-66053-airframe)# no rx</b> [adminchannel-1 ] [adminchannel-2 ] [adminchannel-3 ] [adminchannel-4 ]
-----------------------	--

<b>Privilege Level</b>	10
------------------------	----

<b>Command Modes</b>	bs airframe configuration mode
----------------------	--------------------------------

### 4.8.19.3.8 Restoring the Default Value of Airframe Uplink Feedback Zone Subchannels Parameter

To restore the Airframe Uplink Feedback Zone non-mandatory subchannels parameter to its default value, run the following command:

```
npu(config-bs-66053-airframe)# no ulfeedbackzone subchannels
```

Since the Downlink Diversity table contains a single non-mandatory parameter, it is sufficient to run the following command:

```
npu(config-bs-66053-airframe)# no ulfeedbackzone
```



#### NOTE

Refer to [Section 4.8.19.2.8](#) for a description and default values of these parameters.

<b>Command Syntax</b>	<b>npu(config-bs-66053-airframe)# no ulfeedbackzone</b> [subchannels ]
-----------------------	--



---

**Privilege Level** 10

---

**Command Modes** bs airframe configuration mode

#### 4.8.19.3.9 Restoring the Default Values of Airframe Uplink Data Zone Parameters

To restore one or all of the Airframe Uplink Data Zone parameters to their default values, run the following command:

```
npu(config-bs-66053-airframe)# no uldatazone [startallocation]
[subchannels-number]
```

You can restore only one or several parameters to the default values by specifying only those parameters. For example, to restore only the startallocation parameters to the default value, run the following command:

```
npu(config-bs-66053-airframe)# no uldatazone startallocation
```

This parameter will be restored to the default values, while the other parameters will remain unchanged.

To restore all parameters to their default value, run the following command:

```
npu(config-bs-66053-airframe)# no uldatazone
```



#### NOTE

Refer to [Section 4.8.19.2.10](#) for a description and default values of these parameters.

---

**Command Syntax** **npu(config-bs-66053-airframe)# no uldatazone** [startallocation ]  
[subchannels-number ]

---

**Privilege Level** 10

---

**Command Modes** bs airframe configuration mode

#### 4.8.19.3.10 Restoring the Default Values of Airframe Dynamic Permutation Parameters

To restore one or all of the Airframe Dynamic Permutation parameters to their default values, run the following command:

```
npu(config-bs-66053-airframe)# no dynamicperm [dl-permbase] [ul-permbase]
```

You can restore only one parameter to the default value by specifying only that parameter. For example, to restore only the dl-permbase to the default value, run the following command:

```
npu(config-bs-66053-airframe)# no dynamicperm dl-permbase
```

The parameter will be restored to its default value, while the other parameter will remain unchanged.

To restore all non-mandatory parameters to their default value, run the following command:

```
npu(config-bs-66053-airframe)# no dynamicperm
```



#### NOTE

Refer to [Section 4.8.19.2.11](#) for a description and default values of these parameters.

#### Command Syntax

```
npu(config-bs-66053-airframe)# no dynamicperm [dl-permbase ]  
[ul-permbase ]
```

#### Privilege Level

10

#### Command Modes

bs airframe configuration mode

### 4.8.19.4 Terminating the Airframe Configuration Mode

Run the following command to terminate the Airframe configuration mode:

```
npu(config-bs-66053-airframe)# exit
```



#### IMPORTANT

Do not forget to execute the apply command before terminating the Airframe configuration mode:

```
npu(config-bs-66053-airframe)# apply
```

#### Command Syntax

```
npu(config-bs-66053-airframe)# exit
```

---

**Privilege Level** 10

---

**Command Modes** bs airframe configuration mode

### 4.8.19.5 Displaying Configuration Information for Airframe Parameters

You can display the current configuration information for the following Airframe parameters tables:

- General (refer to [Section 4.8.19.5.1](#))
- Map Zone (refer to [Section 4.8.19.5.2](#))
- Downlink Diversity (refer to [Section 4.8.19.5.3](#))
- Cyclic Delay (refer to [Section 4.8.19.5.4](#))
- Linear Delay (refer to [Section 4.8.19.5.5](#))
- Mapping (refer to [Section 4.8.19.5.6](#))
- Receive (refer to [Section 4.8.19.5.7](#))
- Uplink Feedback Zone (refer to [Section 4.8.19.5.8](#))
- Downlink Data Zone (refer to [Section 4.8.19.5.9](#))
- Uplink Data Zone (refer to [Section 4.8.19.5.10](#))
- Dynamic Permutation (refer to [Section 4.8.19.5.11](#))
- All (refer to [Section 4.8.19.5.12](#))

#### 4.8.19.5.1 Displaying Configuration Information for Airframe General Parameters

To display configuration for the Airframe General parameters, run the following command:

```
npu# show airframe-general bs [<(1 to 16777215 StepSize 1)>]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe General parameters of BS 66503, run the following command:

**npu# show airframe-general bs 66053**

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show airframe-general bs**

**Command Syntax**     **npu# show airframe-general bs** [<(1 to 16777215 StepSize 1)> ]

**Privilege Level**     1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe General parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe General parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

BSIDLSB	: <value>
CellID	: <value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	
PreambleGroup	: <value>
SegmentNumber	: <value>
FrameNumberOffset	: <value>
EnableUplinkSubchannelRotation	: <value>
Uplink-DownlinkAllocation(%)	: <value>

---

**Command** Global command mode  
**Modes**

#### 4.8.19.5.2 Displaying Configuration Information for Airframe Map Zone Parameters

To display configuration for the Airframe Map Zone parameters, run the following command:

**npu# show airframe-mapzone bs** [(1 to 16777215 StepSize 1)>]

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Map Zone parameters of BS 66503, run the following command:

**npu# show airframe-mapzone bs 66053**

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show airframe-mapzone bs**

---

**Command Syntax** **npu# show airframe-mapzone bs** [(1 to 16777215 StepSize 1)> ]

---

**Privilege Level** 1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe Map Zone parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe Map Zone parameters of all BSs.	Optional	N/A	1-16777215

<b>Display</b>	BSIDLSB	: <value>
<b>Format</b>	MapZoneSize (symbols)	: <value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	MapMajorGroups	: <value>
	BasicMapRepetitions	: <value>
<b>Command Modes</b>	Global command mode	

#### 4.8.19.5.3 Displaying Configuration Information for Airframe Downlink Diversity Parameters

To display configuration for the Airframe Downlink Diversity parameters, run the following command:

```
npu# show airframe-dldiversity bs [<(1 to 16777215 StepSize 1)>]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Downlink Diversity parameters of BS 66503, run the following command:

```
npu# show airframe-dldiversity bs 66053
```

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show airframe-dldiversity bs
```

<b>Command Syntax</b>	<b>npu# show airframe-mapzone bs</b> [<(1 to 16777215 StepSize 1)> ]
<b>Privilege Level</b>	1

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe Downlink Diversity parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe Downlink Diversity parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

BSIDLSB : <value>  
DownlinkDataDiversityMode : <value>

(for each existing Neighbour BS in each of the existing BSs if requested for all)

**Command Modes**

Global command mode

#### 4.8.19.5.4 **Displaying Configuration Information for Airframe Cyclic Delay Parameters**

To display configuration for the Airframe Cyclic Delay parameters, run the following command:

```
np# show airframe-cyclicdelay bs [(1 to 16777215 StepSize 1)>]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Cyclic Delay parameters of BS 66503, run the following command:

```
np# show airframe-cyclicdelay bs 66053
```

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show airframe-cyclicdelay bs**


---

**Command Syntax**     **npu# show airframe-cyclicdelay bs** [(1 to 16777215 StepSize 1)> ]

---

**Privilege Level**     1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe Cyclic Delay parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe Cyclic Delay parameters of all BSs.	Optional	N/A	1-16777215

---

**Display Format**

BSIDLSB	:<value>
CyclicDelayChannel1 (microseconds)	:<value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	
CyclicDelayChannel2 (microseconds)	:<value>
CyclicDelayChannel3 (microseconds)	:<value>
CyclicDelayChannel4 (microseconds)	:<value>

---

**Command Modes**     Global command mode

#### 4.8.19.5.5 Displaying Configuration Information for Airframe Linear Delay Parameters

To display configuration for the Airframe Linear Delay parameters, run the following command:



**npu# show airframe-lineardelay bs** [<(1 to 16777215 StepSize 1)>]

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Linear Delay parameters of BS 66503, run the following command:

**npu# show airframe-lineardelay bs 66053**

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show airframe-lineardelay bs**

**Command Syntax**     **npu# show airframe-lineardelay bs** [<(1 to 16777215 StepSize 1)> ]

**Privilege Level**     1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe Linear Delay parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe Linear Delay parameters of all BSs.	Optional	N/A	1-16777215

**Display Format**

BSIDLSB	: <value>
LinearDelayChannel1(microseconds)	: <value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	
LinearDelayChannel2(microseconds)	: <value>
LinearDelayChannel3(microseconds)	: <value>
LinearDelayChannel4(microseconds)	: <value>

---

**Command** Global command mode  
**Modes**

#### 4.8.19.5.6 Displaying Configuration Information for Airframe Mapping Parameters

To display configuration for the Airframe Mapping parameters, run the following command:

**npu# show airframe-mapping bs** [<(1 to 16777215 StepSize 1)>]

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Mapping parameters of BS 66503, run the following command:

**npu# show airframe-mapping bs 66053**

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show airframe-mapping bs**

---

**Command Syntax** **npu# show airframe-mapping bs** [<(1 to 16777215 StepSize 1)> ]

---

**Privilege Level** 1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe Mapping parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe Mapping parameters of all BSs.	Optional	N/A	1-16777215

<b>Display</b>	BSIDLSB	: <value>
<b>Format</b>	LogicalStramMappingChannel1	: <value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	LogicalStramMappingChannel2	: <value>
	LogicalStramMappingChannel3	: <value>
	LogicalStramMappingChannel4	: <value>

<b>Command Modes</b>	Global command mode
----------------------	---------------------

#### 4.8.19.5.7 Displaying Configuration Information for Airframe Receive Parameters

To display configuration for the Airframe Receive parameters, run the following command:

```
npu# show airframe-rx bs [<(1 to 16777215 StepSize 1)>]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Receive parameters of BS 66503, run the following command:

```
npu# show airframe-rx bs 66053
```

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show airframe-rx bs
```

<b>Command Syntax</b>	<b>npu# show airframe-rx bs</b> [<(1 to 16777215 StepSize 1)> ]
-----------------------	---

<b>Privilege Level</b>	1
------------------------	---

**Syntax****Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe Receive parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe Receive parameters of all BSs.	Optional	N/A	1-16777215

**Display****Format**

(for each existing Neighbour BS in each of the existing BSs if requested for all)

```

BSIDLBS                               : <value>
AdminStatusChannel1                   : <value>
AdminStatusChannel2                   : <value>
AdminStatusChannel3                   : <value>
AdminStatusChannel4                   : <value>

```

**Command Modes**

Global command mode

#### 4.8.19.5.8 Displaying Configuration Information for Airframe Uplink Feedback Zone Parameters

To display configuration for the Airframe Uplink Feedback Zone parameters, run the following command:

```
npu# show airframe-ulfeedbackzone bs [(1 to 16777215 StepSize 1)>]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Uplink Feedback Zone parameters of BS 66503, run the following command:

```
npu# show airframe-ulfeedbackzone bs 66053
```

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show airframe-ulfeedbackzone bs
```

**Command Syntax** `npu# show airframe-ulfeedbackzone bs [<(1 to 16777215 StepSize 1)> ]`

**Privilege Level** 1

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe Uplink Feedback Zone parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe Uplink Feedback Zone parameters of all BSs.	Optional	N/A	1-16777215

**Display Format** BSIDLSB : <value>  
 ULFeedbackZoneNumberOfSub-Channels : <value>  
 (for each existing Neighbour BS in each of the existing BSs if requested for all) ULFeedbackZonePermutationBase : <value>

**Command Modes** Global command mode

### 4.8.19.5.9 Displaying Configuration Information for Airframe Downlink Data Zone Parameters

To display configuration for the Airframe Downlink Data Zone parameters, run the following command:

`npu# show airframe-dldatazone bs [<(1 to 16777215 StepSize 1)>]`

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Downlink Data Zone parameters of BS 66503, run the following command:

```
npu# show airframe-dldatazone bs 66053
```

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show airframe-dldatazone bs
```

---

**Command Syntax**     **npu# show airframe-dldatazone bs** [<(1 to 16777215 StepSize 1)> ]

---

**Privilege Level**     1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe Downlink Data Zone parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe Downlink Data Zone parameters of all BSs.	Optional	N/A	1-16777215

---

**Display Format**

BSIDLSB	:<value>
DLDATAZoneNumberOfSub-Channels	:<value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	DLDATAZonePermutationBase :<value>

---

**Command** Global command mode  
**Modes**

#### 4.8.19.5.10 Displaying Configuration Information for Airframe Uplink Data Zone Parameters

To display configuration for the Airframe Uplink Data Zone parameters, run the following command:

**npu# show airframe-uldatazone bs** [<(1 to 16777215 StepSize 1)>]

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Uplink Data Zone parameters of BS 66503, run the following command:

**npu# show airframe-uldatazone bs 66053**

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

**npu# show airframe-uldatazone bs**

---

**Command Syntax** **npu# show airframe-uldatazone bs** [<(1 to 16777215 StepSize 1)> ]

---

**Privilege Level** 1

---

**Syntax Description**

Parameter	Description	Presence	Default Value	Possible Values
<(1 to 16777215 StepSize 1)>	The BS ID  Specify a value for this parameter if you want to display the Airframe Uplink Data Zone parameters of a specific BS. Do not specify a value for this parameter if you want to display the Airframe Uplink Data Zone parameters of all BSs.	Optional	N/A	1-16777215

<b>Display</b>	BSIDLSB	: <value>
<b>Format</b>	ULDATAPermutationBase	: <value>
(for each existing Neighbour BS in each of the existing BSs if requested for all)	StartAllocation(Slots)	: <value>
	ULDATAZoneNumberOfSub-Channels	: <value>
<b>Command Modes</b>	Global command mode	

#### 4.8.19.5.11 Displaying Configuration Information for Airframe Dynamic Permutation Parameters

To display configuration for the Airframe Dynamic Permutation parameters, run the following command:

```
npu# show airframe-dynamicperm bs [<(1 to 16777215 StepSize 1)>]
```

Specify the BS ID if you want to display configuration for a particular BS. For example, to display the Airframe Dynamic Permutation parameters of BS 66503, run the following command:

```
npu# show airframe-dynamicperm bs 66053
```

Do not specify the BS ID if you want to view configuration information for all existing BSs. To display information for all BSs, run the following command:

```
npu# show airframe-dynamicperm bs
```

<b>Command Syntax</b>	<b>npu# show airframe-dynamicperm bs</b> [<(1 to 16777215 StepSize 1)> ]
<b>Privilege Level</b>	1