

70-1494 Alignment Procedure

SETUP

- 1 Remove the ten securing screws from the bottom cover , and the cover itself.
- 2 Connect a resistive 50 Ω RF load and wattmeter to Antenna Connector J501.
- 3 Connect 13.4V DC power to transceiver J505.
- 4 Connect a 3.2 Ω , 20W resistor to pins 4 and 6 of the Accessory Plug. The jumper between pins 5 and 6 must be temporarily removed to make this connection. The resistor serves as a constant load to replace the speaker's inconsistencies.

CAUTION: Both speaker terminals are LIVE. Never ground either one. Connect grounded receive-audio measuring-equipment to only one side of the speaker, and chassis ground. Normally, voltage measurement will be half of true values.

- 5 Turn the radio on (Push on and Push off switch), set the VOLUME control to a mid-position.

Connect the Programmer to Programming Port Mic Jack J302.

Upload the radio programming Data-Packet into the Programmer and initiate its Remote Control Mode. Refer to the appropriate manual for details.

SYNTHESIZER ALIGNMENT

•VCO Resonance

- 1 Select the Remote Control Mode of the Programmer and enter the following test frequencies:

	B-Band
RX Frequency	150.00
TX Frequency	150.00

- 2 Adjust Channel RX Tank L713 for 1.5V DC at VC (VCO Steering) .
- 3 Active transmit mode (using the programmer) and adjust TX Tank L702 for 1.5V DC at VC (VCO Steering) .

•Reference Oscillator

- 4 Initiate transmit on any channel. Measure transmitted RF carrier frequency without modulation and, if necessary, adjust REFERENCE OSCILLATOR X701 for carrier frequency to within $\pm 300\text{Hz}$ of channel frequency.

110-WATT PA MODULE ALIGNMENT

The 70-1494 should be adjusted to have a 24 MHz channel spread at 110W. To do so :

- 1 Remove the four screws on the PA cover.
- 2 Remove a cable from J501.
- 3 Adjust RV501, RV502 and RV503 counter-clockwise just until stop.
- 4 Activate transmit mode, measure current.
- 5 Adjust RV503 clockwise just until currents increase 0.5A.
- 6 Adjust RV501 clockwise just until currents increase 0.5A more.
- 7 Adjust RV502 clockwise just until currents increase 0.5A more.
- 8 Stop transmit mode. Change the TX test frequency to the desired frequency.
- 9 Connect the removed cable to J501.
- 10 Activate transmit mode, then adjust CV503 to obtain maxim RF power at Antenna Connector J502.
- 11 Set RF output power to 110W at J502 using the programmer.

MODULATOR ALIGNMENT

•Modulation Limiting

- 1 Disconnect the hand microphone from its front panel Mic Jack J302. Apply 3Vrms of 1000Hz signal to pin 1 of Mic Jack J302, then initiate transmit.

2 Measure total carrier deviation and, if needed adjust modulation limiting to obtain $\pm 5\text{KHz}$ (wide) or $\pm 2.5\text{KHz}$ (narrow) using the programmer.

•Microphone Gain

3 No alignment for Microphone gain is required.

•CTCSS/DCS

4 Remove the 1KHz audio signal from Mic Jack J302.

5 Add 250.3Hz CTCSS tone to the transmit test by testing frequency using the programmer.

6 Adjust CTCSS deviation to $\pm 750\text{ Hz} \pm 10\text{ Hz}$ (wide) or $\pm 375\text{ Hz} \pm 10\text{ Hz}$ (narrow) deviation using the programmer.

7 Change 67.0 Hz CTCSS tone to the transmit test by testing frequency using in the programmer.

8 Adjust RV401 for $\pm 750\text{ Hz} \pm 10\text{ Hz}$ (wide) or $\pm 375\text{ Hz} \pm 10\text{ Hz}$ (narrow) deviation.

9 Change the transmit DCS code +023 to the transmit test by testing frequency using the programmer.

10 Adjust RV401 so that modulation waveform from modulation analyzer matches the correct waveform shown in Figure 2-1.

11 Change 250.3 Hz CTCSS tone to the transmit test by testing frequency using the programmer. Carefully adjust RV401 for $\pm 750\text{ Hz} \pm 10\text{ Hz}$ (wide) or $\pm 375\text{ Hz} \pm 10\text{ Hz}$ (narrow) deviation.




Figure 2-1 Modulation Waveforms

- DTMF

12 Clear the CTCSS tone, then initiate transmit test by testing frequency using the programmer.

13 Adjust DTMF deviation to $\pm 3.0\text{KHz} \pm 10 \text{ Hz}$ (wide) or $\pm 1.5\text{KHz} \pm 10 \text{ Hz}$ (narrow) deviation using the programmer.

RECEIVER ALIGNMENT

1 Change the RX test frequency to 162.3MHz for B-Band.

- First Injection

2 No adjustment for first injection is required.

- Preselector Alignment

3 No adjustment for the preselector (L201, L202, L204, L205, L206 and L207) is required.

- Quadrature Detector

4 No adjustment for the quadrature is required.

- First IF

5 Apply enough modulated (by 1KHz tone at ± 3 KHz (wide) or ± 1.5 KHz (narrow) deviation) on-channel carrier to maintain 12 to 15 dB SINAD. Adjust L215, L216, and L217.

- Tight Squelch

6 Squelch level set maximum (80). by using the front UP / DN switch

7 Apply 0.95 uV of modulated standard deviation on-channel RF signal to the 50 Ω antenna connector.

Adjust Squelch range RV402 counter-clockwise just until squelch opens (audio on).




Figure 2-2 Adjustment Map (TR-1529)




Figure 2-3 Adjustment Map (PA- -X0002)

Complete realignment is only needed when a component that affects alignment has been replaced. RADIO REPROGRAMMING WITH TEST FREQUENCIES IS REQUIRED.

TEST EQUIPMENT REQUIRED

TEST INSTRUMENT	INSTRUMENT CAPABILITIES	USE
Regulated DC Power supply	13.4 V DC, 30 A	Radio power source
RF Wattmeter for 70-1491	150 W, 136 - 174MHz, 50 ohm circuit	Transmitter power measurements
RF Load Resistor	50 ohm, 150 W	Antenna dummy load
Frequency Modulation Meter	136 - 174 MHz, peak-responding, +/- 5KHz range	Modulation level measurements
Frequency Meter or Frequency Counter	136 - 174 MHz, 1.0 ppm accuracy	Carrier frequency measurements
Audio Generator	1,000KHz sine-wave 0-4 Vrms output	Modulation level measurements
RF Signal Generator	136 - 174 MHz range, 0.1 - 1 KuV output, 3KHz FM mod. With 1 KHz tone	All receiver measurements
Distortion Analyzer	1 KHz notch, 1% measuring range	Receiver performance test and IF alignment
Load Resistor (audio)	3.2 ohms, 20 W	Speaker load for all receiver measurements
AC Voltmeter	10mV to 10 Vrms	Audio level adjustments
Oscilloscope	DC to 500KHz bandwidth	
Digital Multimeter	0.1 to 20 V DC	Test point measurements and power supply setup
Programmer	PC Programming Software	Manual radio control