

LTE IDU

Quick installation Guide



WLTFGT-145ACN

LTE Indoor CPE

Copyright

This DOCUMENT is copyrighted with all rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form by any means without the written permission of Gemtek Technology Co. Ltd.

Notice

Gemtek reserves the right to change specifications without prior notice.

While the information in this document has been compiled with great care, it may not be deemed an assurance of product characteristics. Gemtek shall be liable only to the degree specified in the terms of sale and delivery.

The reproduction and distribution of the documentation and software supplied with this product and the use of its contents is subject to written authorization from Gemtek.

Contents

Copyright

Notice

Contents1

1. About this Guide2

2. What's in the box?2

3. LED Indicators

錯誤! 尚未定義書籤。

4. Connectors.....5

5. Installation.....6

6. Easy Setup.....7

7. Wi-Fi Setting 錯誤! 尚未定義書籤。





1. About this Guide

This document provides information and procedures on installation and configuration of LTE Indoor CPE. You could utilize the theoretical information in this guide to setup your device. This Quick Installation Guide covers the basic installation of the LTE Indoor Gateway.


2. What's in the box?










Here's a quick checklist of everything inside your box.

Before installing the CPE, verify that you have all the items listed in the package checklist. If any of the items are missing or damaged, contact your LTE service provider.


	The LTE Indoor CPE
	Quick installation Guide
	Power Adapter
	CAT5e 8-wire Ethernet cable for connecting IDU and computer

3. LED Indicators



	LED Indication	Icon	Status	Description
1	Power		ON	Power ON
			OFF	Power OFF
2	2.4 WiFi		ON	Wi-Fi ON
			Blinking	Transmitting data
			OFF	Wi-Fi OFF
3	5 WiFi		ON	Wi-Fi ON
			Blinking	Transmitting data
			OFF	Wi-Fi OFF
4	WPS		Blinking	Searching for Connection
			ON	Connection confirm (will be off after 5 seconds)
5	Signal Strength	Display signal strength		
			ON	SINR < 7dB (Blinking: No SIM Card)
				1 LED: 7dB ≤ SINR < 11dB
				2 LED: 11dB ≤ SINR < 18dB
				3 LED: 18dB ≤ SINR < 23dB
				4 LED: 23dB < SINR
		OFF		LTE OFF
6	Firmware Upgrade	Electronic scrolling marquee		
7	Reset	All LEDs are blinking		

4. Connectors




	Connector	Description
1	Power (DC-12V Port)	The power port is where you connect the power adapter.
2	Power On/Off Switch	The on/off switch support to turn on device
3	LAN – RJ -45	The LAN port allows you to connect Modem to your PC or Hub using a Cat.5/6 Ethernet network cable.
4	USB Type A Host	Support USB 2.0 Host
5	WPS	Holds down the button for 5 seconds to enable WPS function.
6	USIM Slot	Support 2FF size ; 1.8V/3.3V USIM for LTE Mode
7	Reset	Press the button for 5 seconds to reset the setting back to factory default.

5. Installation

Please follow the steps below to install the device:

- Step1:** Insert SIM card into the device with right direction.
- Step2:** Connect the device **LAN** port to your PC with a RJ-45 Ethernet cable that is supplied.
- Step3:** Insert the power cord into the LTE Indoor CPE's **DC-12V** power jack; and insert the plug into power outlet.
- Step4:** Switch ON the power. The device will start the booting process. After a few seconds, the LED lights will start blinking.



6. Easy Setup


Please follow the steps below to configure your device through the web interface:

Step1: Open the Web browser (Internet Explorer) and enter the default IP address of the IDU CPE : <http://192.168.15.1>

Step2: Enter username/password to access the web management interface.

Username : admin


Password : admin



The screenshot shows a login page with a teal header containing a leaf icon and the word "LOGIN". Below the header, there are two input fields: "USERNAME" with the text "gointernet" and "PASSWORD" with masked characters ".....". At the bottom, there is a grey "Apply" button and a red "Language" dropdown menu.

Step3: The page displays in your browser after login; you can simply configure the device settings.

Signal strength indicator on the upper-left corner of webpage.



7. WiFi Setting

Select WiFi from main menu. Then screen will display the default setting of SSID, radio channel, working mode, and SSID broadcast.

WiFi Status:

The screenshot shows the 'Status' page for WiFi. The left sidebar has 'WiFi' selected, with 'Status' and 'Settings' as sub-options. The main content area is titled 'Status' and contains two panels: 'WiFi 2.4GHz' and 'WiFi 5GHz'. Each panel displays a table of settings.

WiFi 2.4GHz	
Status	ON
Radio Channel	1
Working Mode	802.11b/g/n mixed
WiFi MAC	80:02:9c:0a:9b:1f
Network Name(SSID)	GOINTERNET2.4G_0A9B1E
SSID Broadcast	Enable

WiFi 5GHz	
Status	ON
Radio Channel	44
Working Mode	802.11a/n/ac mixed
WiFi MAC	80:02:9c:0a:9b:20
Network Name(SSID)	GOINTERNET5G_0A9B1E
SSID Broadcast	Enable

WiFi 2.4G Settings:

The screenshot shows the 'Settings' page for WiFi 2.4G. The left sidebar has 'WiFi' selected, with 'Status' and 'Settings' as sub-options. The 'Settings' sub-option is selected. The main content area is titled 'Settings' and contains two panels: 'Wireless Settings' and 'Security'. The 'Wireless Settings' panel has a table of settings, and the 'Security' panel has a table of security settings.

Wireless Settings	
Interface Status	<input checked="" type="checkbox"/> Enable <input type="checkbox"/> Disable
Network Name(SSID)	GOINTERNET2.4G_0A9B1E
Radio Channel	Auto
Working Mode	802.11b/g/n
Bandwidth (only 11n)	20M/40M
RTS Threshold	2347 (range:1~2347)
CTS Protection Mode	Auto
Preamble Length	Short Preamble
SSID Broadcast	Enable

Security	
Security Types Setup	
Authentication	WPA/WPA2-Personal Mi
Encryption	AES
Pre-shared Settings	
Rekey Interval	3600
Key Pass Phrase	9lsjce0j
Wi-Fi Protected Setup(WPS)	
Enable WPS	<input type="checkbox"/> WPS Button

WiFi 5G Settings:

LTE 2.4G 5G

Superuser Language Settings

LTE Network

WiFi

WiFi Settings

WiFi 2.4GHz

WiFi 5GHz

Network

Firewall

Management

Monitoring

About

Settings

Wireless Settings

Interface Status

Enable

Disable

Network Name(SSID)

GOINTERNET5G_0A9B1E

Region

Europe

Radio Channel

Auto

Working Mode

802.11a/n/ac

Bandwidth (only 11n)

20M/40M/80M

RTS Threshold

2347

(range:1~2347)

Preamble Length

Long Preamble

SSID Broadcast

Enable

Security

Security Types Setup

Authentication

WPA/WPA2-Personal Mi

Encryption

AES

Pre-shared Settings

Rekey Interval

3600

Key Pass Phrase

9lsjce0j

Wi-Fi Protected Setup(WPS)

Enable WPS

WPS Button

Access Control List

Cancel

Apply

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance **20cm** between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.