


# Directory

Welcome to TOUCH-BOLT System.....	
Introduction.....	
System Requirement.....	
Minimum Requirement.....	
Recommended Specification.....	
Supported input/output Device.....	
Start and Close the Application.....	
User Guide.....	
Project Management.....	
Construction Key.....	
Create a Programming Key.....	





# Project Management



The screenshot displays a software window titled "Project Management System". It features a menu bar with "Project Management", "Construction Key", and "Programming Key". Below the menu bar is a toolbar with icons for "Add", "Edit", "Delete", and "Report". The main area contains a table with the following data:

	Customer Name	Project Name	Project Code
▶	TFH	TFH R&D	72662432
	ABC	ABC-1	07842582

03 Please refer to the user guide for more details.


# Project Management

The screenshot shows a window titled "Edit Project" with a standard Windows-style title bar (minimize, maximize, close buttons). The window contains a form with the following fields:

- Save**: A button with a floppy disk icon.
- Customer Name**: A text input field containing "DEF".
- Project Name**: A text input field containing "DEF-1".
- Invoice**: A text input field.
- Contact**: A text input field.
- TEL**: A text input field containing "1234567".
- Address**: A text input field containing "88 TF".
- Project Code**: A text input field containing "25178469".
- Barcode**: A large text area containing the alphanumeric string "Oo5+e9RFZuqe+CaVHGOSL3yZKhAFaUDzy1mxjaHMeY=".

Please refer to the user guide for more details.

# Project Management



The screenshot displays a software window titled "Project Management System". Below the title bar is a menu bar with "Project Management", "Construction Key", and "Programming Key". A toolbar contains icons for "Add", "Edit", "Delete", and "Report". The main area features a table with the following data:

	Customer Name	Project Name	Project Code
▶	TFH	TFH R&D	72662432
	ABC	ABC-1	07842582
	DEF	DEF-1	25178469

05 Please refer to the user guide for more details.

# Construction Key

Project Management System

Project Management Construction Key Programming Key

Create Key

UID  
1297461883 R

The key is assigned to project:

ABC-1  
DEF-1  
TFH R&D  
2015/09/14


Ending date  
2015/09/14

Search  
Customer name: Project name: 🔍

Customer Name	Project Name	Project Code	UID
TFH	TFH R&D	72662432	1297462907

Please refer to the user guide for more details.

## Construction Key



07 Please refer to the user guide for more details.



# Table of Content

- Welcome to Touch-Bolt Centra.....
- Introduction.....
- System Requirement.....
  - Minimum Requirement.....
  - Recommended Specification.....
  - Supported input/output Device.....
- Start and Close the Application.....
- User Guide.....
- Home .....
- Floor Plan .....
- Property management .....
- Public Area .....
- Public Area Group .....
- Public Area Locks .....
- General Area .....
- Zone .....

- Suite .....
- Unit .....
- Calendar and Timetable settings .....
- Time Table .....
- Holiday .....
- DST .....
- Operation .....
- Resident management .....
- Staff management .....
- Vendor management .....
- Vendor .....
- Employee .....
- Work order type .....
- Keys .....
- Create Key .....
- Resident Key .....
- Zone Key .....
- Master Key .....
- Tmporary Key .....

Latch On/Off Key .....	
Emergency Key .....	
Duplicate Key .....	
Black List .....	
Read Key .....	
Locks .....	
Lock Setting .....	
RetrieveLock information .....	
Reports .....	
Key History .....	
Lock History .....	
Lock Events .....	
Activity logs .....	
System Settings .....	
System Account Management .....	
Account Type Settings .....	
IM-1000&dongle Setup .....	
Database .....	


---

01 Please refer to the user guide for more details.

Please refer to the user guide for more details. 02


Home

# Floor Plan



Please refer to the user guide for more details.


## Floor Plan > Property management



05 Please refer to the user guide for more details.



## Floor Plan > Property management




The image shows a screenshot of a software dialog box titled "Property management". The dialog has a standard Windows-style title bar and a close button. Below the title bar, there is a tab labeled "General" which is currently selected. The dialog contains four input fields:

- Property Name:** TFH R&D
- Property code:** 72662432
- Address:** (empty field)
- Registry Key:** tJuZk3L4KxPnlq+cbtP6fOIsdQ84jNeSJdnbB33v5FAr5tIC5LuORA==

Please refer to the user guide for more details.

Floor Plan > Public Area > Public Area Group



07 Please refer to the user guide for more details.

## Floor Plan > Public Area > Public Area Locks


The screenshot shows a software interface with a blue header bar containing the text 'Public Area' and 'Calendar and Timetable'. Below the header, there are two side-by-side panels. The left panel is titled 'Public Area Group' and contains a table with two rows: '1 Pool' and '2 Garage'. The right panel is titled 'Public Area Locks' and contains a table with two rows: '1 P. Front' and '2 P. Back'. Both panels have a toolbar above them with 'Add', 'Edit', and 'Delete' buttons.

	Name
1	Pool
2	Garage


	Name
1	P. Front
2	P. Back

Please refer to the user guide for more details.

Floor Plan > Public Area > Public Area Locks




Floor Plan > Public Area > General Area




Please refer to the user guide for more details.

## Floor Plan > Public Area > Zone / Suite / Unit



## Floor Plan > Calendar and Timetable Settings



Please refer to the user guide for more details.

## Floor Plan > Calendar and Timetable Settings > Time Table

The screenshot shows the 'Calendar and Timetable settings' window. At the top, there are tabs for 'Time Table', 'Holiday', and 'DST'. Below the tabs are three buttons: 'Add', 'Edit', and 'Delete'. The main area is divided into two sections: 'Group' and 'Time'.

The 'Group' section contains a table with the following data:

TimeTable Name
Weekday 0000-1700
Weekend ALL
T1
T2
T3

The 'Time' section contains a grid for setting time slots. The grid has columns for hours (00 to 23) and rows for days of the week (Mon, Tue, Wed, Thu, Fri, Sat, Sun, Holiday). The 'Set' button is checked, and the 'Erase' button is unchecked. The grid shows a blue shaded area for the time slot 00:00 to 16:00 on Monday through Friday.

Time	00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23
Mon	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set							
Tue	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set							
Wed	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set							
Thu	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set							
Fri	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set	Set							
Sat																								
Sun																								
Holiday																								

13 Please refer to the user guide for more details.






## Floor Plan > Calendar and Timetable Settings > Holiday

Calendar and Timetable settings

Time Table | **Holiday** | DST

Holiday Name

Holiday Date 2015/ 9/14 

	Name	Holiday Date	Delete
▶	9/15 test holiday	2015/9/15	
	New Year	2015/9/14	

Please refer to the user guide for more details.

## Floor Plan > Calendar and Timetable Settings > DST

Calendar and Timetable settings

Time Table Holiday DST

✓  
OK

DST Type  
LOCAL STANDARD

Remind DST

DST Start

Month  
September

Occurs  
2nd

Day of the Week  
Fri

Hour Of Day(1-22)  
0

Time adjustment  
0

2015/ 9/11

DST End

Month  
September

Occurs  
2nd


Day of the Week  
Fri

Hour Of Day(1-22)  
0

2015/ 9/11


15 Please refer to the user guide for more details.

# Operation



Please refer to the user guide for more details.

## Operation > Resident management



17 Please refer to the user guide for more details.

## Operation > Staff management

The screenshot displays the Touch-bolt Central software interface. The top navigation bar includes icons for Home, Floor Plan, Operation, Keys, Locks, Reports, and System Settings. Below the navigation bar are five main management buttons: Resident management, Staff management, Vendor management, and Work order type. The Staff management window is open, displaying a table with columns for Staff ID, Name, Position, and Login ID. A modal dialog titled 'Edit Staff' is overlaid on the table, showing fields for Staff ID (JFH001), Position (Manager), First Name (Iss), Middle Name, and Last Name (Wu).

Staff ID	Name	Position	Login ID
3129628	J L	Indboy	
JFH001	Issi Wu	Manager	

**Edit Staff**

OK


Staff ID: JFH001      Position: Manager

First Name: Iss      Middle Name:      Last Name: Wu


Notes:

Please refer to the user guide for more details.

## Operation > Vendor management > Vendor



# Operation > Vendor management > Employee



Please refer to the user guide for more details.

## Operation > Vendor manggement > Work order type

The screenshot displays a software application window titled "Work order type". At the top, there is a toolbar with icons for "Add", "Edit", "Delete", and "Report". Below the toolbar is a "Search Condition" section with a dropdown menu for "Work Order Type" set to "Unit", radio buttons for "Unit" (selected) and "Property", and checkboxes for "Pending", "Open", and "Close". There are "Search" and "Reset" buttons. Below the search section is a table with the following columns: "rowid", "Work Order No.", "Unit/Property", "Status", and "Assigned To".

An "Add Work order" dialog box is overlaid on the table. It contains the following fields and controls:

- Work Order Number: 201509150002
- Work Order Type: Unit (selected), Property
- Priority: [Dropdown]
- Status: [Dropdown]
- Requested By: [Text field]
- Assigned To: [Text field]
- Job Description: [Text area]
- Special Circumstances: [Text area]

21 Please refer to the user guide for more details.



Operation > Vendor manggement > Work order type

**Add Work order**

OK

Work Order Number  
201509150002

Work Order Type  
 Unit  Property  
A10001

Priority  
High  
Normal  
Low

Requested By  
Assigned To

Job Description

Please refer to the user guide for more details.

Operation > Vendor manggement > Work order type

The screenshot shows a software window titled "Add Work order". At the top left, there is a blue header bar with a small icon and the text "Add Work order". Below the header, on the left side, there is a vertical stack of icons, with a blue checkmark icon and the text "OK" below it. The main area of the form contains several input fields and controls:

- Work Order Number:** A text input field containing the value "201509150002".
- Work Order Type:** A section containing two radio buttons: "Unit" (which is selected) and "Property". Below the radio buttons is a dropdown menu showing the value "A10001".
- Priority:** A dropdown menu that is currently empty.
- Status:** A dropdown menu with a blue highlight, showing a list of options: "Pending", "Open", and "Closed".
- Requested By:** A text input field with a greyed-out appearance and a small "..." button to its right.
- A:** A text input field with a greyed-out appearance and a small "..." button to its right.
- Job Description:** A text input field at the bottom of the form, partially visible.

23 Please refer to the user guide for more details.

## Operation > Vendor manggement > Work order type

The image shows two overlapping windows from a software application. The background window is titled "Add Work order" and contains the following fields and controls:

- Work Order Number:** 201509150002
- Work Order Type:** Unit (selected), Property
- Priority:** [Dropdown menu]
- Status:** [Dropdown menu]
- Requested By:** [Text field]
- Assigned To:** [Text field]
- Job Description:** [Text area]
- Special Circumstances:** [Text area]

The foreground window is titled "Select user" and contains the following fields and controls:

- User Type:** STAFF (selected), RESIDENT, VENDOR
- User List:** A table with two rows: "J L" and "Iriss Wu". The "J L" row is highlighted.

Name
J L
Iriss Wu

Please refer to the user guide for more details.

## Operation > Vendor manggement > Work order type

The image shows two overlapping windows from a software application. The background window is titled "Add Work order" and contains the following fields and controls:


- Work Order Number:** 201509150002
- Work Order Type:** Unit (selected), Property
- Priority:** (dropdown menu)
- Status:** (dropdown menu)
- Requested By:** (text field)
- Assigned To:** (text field with a selection button)
- Job Description:** (text area)
- Special Circumstances:** (text area)

The foreground window is titled "Select user" and contains the following controls:

- User Type:** STAFF (selected), RESIDENT, VENDOR
- User List:** A table with two rows: "J L" (highlighted) and "Iris Wu".


Name
J L
Iris Wu

# Keys




Please refer to the user guide for more details.

Keys > Create Key > Resident Key / Zone Key / Master Key /  
Temporary Key / Latch on/off Key / Emergency Key




## Keys > Duplicate Key / Black List / Read Key




Please refer to the user guide for more details.

## Locks > Lock Setting / Retrieve Lock information






# Reports > Key History / Lock History / Lock Events / Activity Logs



Please refer to the user guide for more details.

# System Settings



## System Settings > System Account Management

The screenshot displays the 'Touch-bolt Central' software interface. The main window is titled 'System Account Management' and contains a table with the following data:


Login ID	Authorization	Staff
admin	Administrator	
admin1	Administrator	

An 'Edit Account' dialog box is open over the 'admin' row. The dialog contains the following fields and options:

- Buttons: OK
- Fields: Login ID (admin), Password(Max 10) (admin)
- Dropdown: Staff (empty)
- Authorization options: Administrator (selected), Staff, Custom1, Custom2, Custom3


Please refer to the user guide for more details.

## System Settings > Account Type Settings




33 Please refer to the user guide for more details.

## System Settings > Account Type Settings




Please refer to the user guide for more details.

## System Settings > Account Type Settings




35 Please refer to the user guide for more details.

## System Settings > IM-1000&dongle Setup



Please refer to the user guide for more details.

## System Settings > Database



37 Please refer to the user guide for more details.



Please refer to the user guide for more details.

# DECLARATIONS AND SAFETY STATEMENTS

## FEDERAL COMMUNICATIONS COMMISSION STATEMENT

---

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0.5 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 0.5 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

## IC REGULATIONS RÈGLEMENTS D'IC

---

This device complies with Industry Canada licence-exempt RSS-210, RSS-247 standard. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.