



If the headset still doesn't work, delete the existing partnership and create a new one. To delete the partnership:

- 1 Press **Start** , and then select **Settings**.
- 2 Select the **Connections** tab, and then select **Bluetooth**.
- 3 Highlight the headset device name.
- 4 Press and hold **Center**  to open the shortcut menu, and then select **Delete**.
- 5 Create a new partnership (see [Connecting to devices with Bluetooth® wireless technology](#)).

Synchronization

Synchronization enables you to back up the information on your smartphone onto your computer or your server. If you ever need to perform a hard reset or otherwise erase all your information on your smartphone, you can synchronize your smartphone with your computer to restore the info. To make sure you always have an up-to-date backup of your info, synchronize frequently.

You can synchronize email and other information directly with Microsoft Exchange Server 2003 with Service Pack 2 using Microsoft Exchange ActiveSync®, or you can synchronize your smartphone with your computer, using the ActiveSync desktop synchronization software from the *Windows Mobile Getting Started Disc*.

DID YOU KNOW? You can go to the Windows website for more information at www.windowsmobile.com.

DID YOU KNOW? A common cause of sync problems is the presence of protective software, such as VPNs or firewalls, on your computer or network.

Exchange ActiveSync (wireless synchronization)

This section covers issues with direct wireless synchronization with an Exchange Server. See [ActiveSync desktop software](#) for help with synchronizing using ActiveSync desktop software.

TIP If you are synchronizing with an Exchange Server and you're unable to change your lock settings, check with your system administrator to find out if a systemwide locking policy is in place.

An alert tells me that the server could not be reached

Your smartphone had to wait too long to connect to the Exchange Server. The connection may have been lost, the server may be temporarily overloaded, or the server may have encountered an internal error. Check your Exchange Server name and proxy server settings (see [Setting up wireless synchronization](#)), and try again later.

An alert tells me that my account information could not be detected

When you set up the Exchange Server sync options, the credentials page was left blank. Correct the credentials (see [Setting up wireless synchronization](#)), or set up your smartphone to sync only with a computer, and try to sync again.

An alert tells me the device timed out while waiting for credentials


The Exchange Server credentials screen was left open too long. Re-enter the Exchange Server credentials, and try to sync again.


ActiveSync desktop software



This section covers issues with synchronizing using ActiveSync desktop software. See [Exchange ActiveSync \(wireless synchronization\)](#) for help with direct wireless synchronization with an Exchange Server.

ActiveSync desktop software does not respond to sync attempt


As you complete the following steps, synchronize after each step. If the synchronization is successful, you do not need to complete the remaining steps.

- 1 Verify that the USB sync cable is securely connected at all points (see [Setting up your computer for synchronization](#)).
- 2 Look for the ActiveSync icon  at the top of your smartphone's screen and


the ActiveSync icon  in the taskbar on your computer to make sure ActiveSync desktop software is running on your computer. If one or both icons if not displayed, do the following:

Smartphone: Press **Start** , select **Programs**, and then select **ActiveSync**. Select **Menu**  (right action key), and then select **Connections**. Make sure the **Synchronize all PCs using this connection** box is checked, and that **USB** is selected from the list.

Computer: Click **Start**, navigate to **Programs**, and then select **Microsoft ActiveSync**.

- 3 Double-click the **ActiveSync icon**  in your taskbar. From the File menu, select **Connection Settings**. Make sure the **Allow USB connections box** is checked, and then click **Connect**.
- 4 Perform a soft reset (see [Performing a soft reset](#)).
- 5 Restart your computer and make sure ActiveSync desktop software is running.
- 6 If problems persist and you're synchronizing through a USB hub, try connecting the sync cable to a different

USB port or directly to your computer's built-in USB port.

- 7 If you're already synchronizing through a built-in USB port on the front of your computer, move the sync cable to a USB on the back of your computer (if your computer has USB ports in both places).
- 8 Uninstall the desktop software that came with your smartphone, and then insert the *Windows Mobile Getting Started Disc*, which came with your smartphone, and repeat the installation process (see [Reinstalling the desktop software](#)).
- 9 Delete the existing partnership between your smartphone and your computer and create a new one by doing the following:
 - Disconnect your smartphone and your computer from the sync cable.
 - Right-click the gray **ActiveSync icon**  in the taskbar in the lower-right corner of your computer screen, and then select **Open Microsoft ActiveSync**.

- Click **File**, and then click **Delete Mobile Device**. When asked to confirm, click **Yes**.
 - Connect your smartphone and your computer to the sync cable.
 - When the Synchronization Setup Wizard appears, follow the steps to establish a sync relationship between your smartphone and your computer.
- 10** If your organization uses a firewall or a VPN connection, synchronizing with ActiveSync may not work. Go to www.microsoft.com and search for the following topics to help with specific firewall setup situations:
- ActiveSync USB Connection Troubleshooting Guide
 - ActiveSync with Sygate Personal Firewall
 - ActiveSync with TrendMicro PC-cillin Internet Security
 - ActiveSync with Norton Personal Firewall
 - ActiveSync with Zone Alarm Security Suite
 - ActiveSync with McAfee Personal Firewall
 - ActiveSync with Windows Firewall
- 11** Verify with your computer hardware vendor that your operating system supports your internal USB controller.
- Synchronization finishes but info doesn't appear where it should**
- With the included software, your smartphone can synchronize with the root folders of Contacts, Calendar, Tasks, and Notes. If you want to synchronize with a global Exchange Address Book, you must copy the addresses to your local Contacts list in Microsoft Office Outlook (right-click the addresses and select Add to Personal Address Book).
 - Microsoft Office Outlook subfolders and public folders are not accessible with the included software. You may want to use a third-party solution instead.
 - If you're trying to sync offline, be sure to set your Microsoft Office Outlook Calendar, Contacts, Notes, and Tasks to be available offline.

- If you're still having problems, try the following:
- 1 Make sure you're synchronizing with the intended desktop personal information manager (PIM). The *Windows Mobile Getting Started Disc* lets you synchronize with Microsoft Office Outlook for Windows. If you use a different PIM, you need to install third-party software to synchronize. For more information, consult the company that makes the PIM.
- 2 Open ActiveSync desktop software on your computer, and make sure the necessary synchronization settings are set to synchronize the files.
- 3 Uninstall ActiveSync desktop software, reboot your computer, and then insert the *Windows Mobile Getting Started Disc*, which came with your smartphone, and repeat the installation process (see [Reinstalling the desktop software](#)).

Synchronization starts but doesn't finish

Make sure that you installed the desktop software that came with your smartphone. If you're not sure whether this software is

installed, reinstall it (see [Reinstalling the desktop software](#)).

My video and music files won't sync

- 1 Make sure you have Windows Media Player 10 installed on your computer.
- 2 Reinstall your synchronization software from the *Windows Mobile Getting Started Disc*, which came with your smartphone (see [Reinstalling the desktop software](#)). Media file synchronization fails if you installed the synchronization software before you installed Windows Media Player 10.

My appointments show up in the wrong time slot after I sync





- 1 Make sure that you installed the desktop software that came with your smartphone. If you're not sure whether this software is installed, reinstall it (see [Reinstalling the desktop software](#)).
- 2 Open Microsoft Office Outlook and correct the wrong entries.
- 3 Manually enter any information you added to your smartphone since the last time you synchronized.

- 4** Synchronize your phone and your computer.

You should now be able to assign time zones to your events without encountering this problem.

My scheduled sync doesn't work

By default, a scheduled sync does not work while you are roaming. This is to prevent roaming charges on your account. If roaming charges are not a concern, follow these steps to continue your sync schedule while roaming:

- 1** Press **Start**  and select **Programs**.
- 2** Select **ActiveSync** .
- 3** Press **Menu**  (right action key) and select **Schedule**.
- 4** Check the **Use above setting when roaming** box.
- 5** Press **OK** .

An alert tells me that ActiveSync encountered a problem on the server

There is a temporary problem with the server or the server may be temporarily overloaded. Try again later, and if the

problem persists, contact your system administrator.

An alert tells me that there is not enough free memory to sync my info

ActiveSync ran out of storage space. Try the following:

- 1** Go to Memory Settings and close all running programs. See [Closing applications](#) for details.
- 2** If the problem persists, see [Making room on your smartphone](#) for suggestions on other ways to free up space on your smartphone.

An alert tells me that ActiveSync encountered a problem with [item type] [item name]

An error occurred during the sync of a single item. This error can usually be corrected only by removing the item that caused the error. If you sync again to see if the error persists, be aware that items causing this type of error are skipped and do not show up again.

My Today screen settings are not restored after a hard reset

Settings such as the background image and plug-in choices are not backed up during synchronization, so they can't be restored after a hard reset. If you use a backup utility, you may be able to restore a backup to recover your Today screen setting and other additional info.

Email

I have problems using my account

Occasionally you may experience problems using an email account after you set it up. If you followed the account setup procedure and are experiencing problems in using the account, verify that the account complies with your email provider's requirements by following these steps:

- Verify both your password and your username for your email account.
- Some email service providers require you to be on their network to use your email account. If this is the case, be

sure to use your provider's network as the connection type for the account.




- Some email service providers have other requirements specific to their service. For example, Yahoo! requires you to set up POP mail forwarding for your Yahoo! account to download email messages to your smartphone. Check with your service provider to see if any provider-specific requirements exist.
- Service provider settings frequently change. If your email account was working but you are currently experiencing problems, check with your service provider to see if any of the account settings have changed.

I have problems sending and receiving email

Short periods of time when email is unavailable are common due to server problems or poor wireless coverage. If you have problems sending or receiving mail for an extended period of time, check with your ISP or email service provider to verify that the service is working properly.

Scheduled email synchronization is not working

If email synchronization is occurring and you turn your smartphone off or the connection to your email service provider is disconnected, the synchronization fails.




- Check the synchronization schedule to make sure that email sync is set to occur at the expected day and time. See [Setting the synchronization schedule](#) for details.
- Press **Start** , select **Programs**, and then select **ActiveSync** . Press **Menu**  (right action key) and select **Configure Server**. Make sure the verify password setting is on. This is required for over-the-air synchronization.

I have problems sending email

If you are able to receive email messages but cannot send them, try these steps, in turn:

- Make sure your ISP or email provider allows you to access email on a smartphone. Some providers do not offer this option at all; other providers

require an upgrade for accessing email on a smartphone.

- Turn on ESMTP. Many services require authenticated access, or ESMTP, to use their SMTP servers.
- Press **Start** , select **Programs**, and then select **ActiveSync** . Press **Menu**  (right action key) and select **Configure Server**. Make sure the **SSL** box is checked.
- Enter the name of a different outgoing mail server for sending mail. Many ISPs, such as cable companies, require that you have an Internet connection to their network to send email through their servers. In this case, you can almost always receive email from these accounts, but if you want to send email, you must send it through another server.

My vCard or vCal email attachment isn't forwarding correctly

Microsoft Office Outlook provides several features that work with email client software on a Windows computer. For these features to work correctly, the email




client software must be properly set up. Follow these steps to check the settings:

- 1 Click **Start** on your computer, and then select **Settings**.
- 2 Select **Control Panel**.
- 3 Select **Internet Options**, and then click the **Programs** tab.
- 4 Make sure that the email field is set to the correct email client software.
- 5 Click **OK**.
- 6 Start the email client software and make sure it is configured as the default MAPI client. Consult the documentation for your desktop email application for more information.

When I sync with my Exchange Server my info is not downloading to my smartphone



Check with your system administrator to obtain the name of the mail server that offers you wireless access to the corporate mail system. If you cannot obtain the name of this server (some companies do not give it out, because they do not want wireless access to their servers), you cannot use Exchange ActiveSync to synchronize with

the Exchange Server. You can also check the following setting:

- 1 Press **Start**  and select **Programs**.
- 2 Select **ActiveSync** .
- 3 Press **Menu**  (right action key) and select **Configure Server**.
- 4 Make sure the **SSL** box is checked.

Web

I can't access a page

First, make sure you have Internet access: Open Internet Explorer Mobile and try to view a web page you've loaded before. To ensure that you're viewing the page directly from the Internet, press **Menu**  (right action key) and select **Refresh**. After confirming your Internet connection, try to view the page in question again. If it comes up blank, press **Menu**  (right action key) and select **Refresh**.

If you're still having trouble, the page may contain elements that are not supported by Internet Explorer Mobile, such as Flash,

Shockwave, VBScript, WML script, and other plug-ins.

Some websites use a redirector to their true home page (for example, if you enter the address <http://www.palm.com/support> it may resolve to <http://www.palm.com/us/support>). If Internet Explorer Mobile can't follow the redirect, try using a desktop browser to see the landing page of the redirector, and enter that address in Internet Explorer Mobile.

TIP Your smartphone can open your email application when you select an email address on a web page. If nothing happens when you select the link, try setting up your email application first.

An image or map is too small on my smartphone screen

Internet Explorer Mobile has several viewing modes: One Column, Default, Desktop, and Full Screen. Switch to Desktop to see the full-size image (see [Viewing a web page](#)).

A secure site refuses to permit a transaction

Some websites don't support certain browsers for transactions. Please contact the site's webmaster to make sure the site allows transactions using Internet Explorer Mobile.

Camera

Here are some tips for taking good pictures with the built-in camera:

DID YOU KNOW? Pictures are 16-bit color. Resolution settings range from 1280 x 1024 to 160 x 120 pixels (1.3 megapixels to VGA). Video resolution settings range from 352 x 288 to 176 x 144 pixels. You can change the resolution setting by pressing **Menu** (right action key) and selecting **Resolution** (still images) or **Quality** (video).

- Clean the camera's lens with a soft, lint-free cloth.
- Take pictures in bright lighting conditions. Low-light images may be

grainy, due to the sensitivity of the camera.

- Hold the camera as still as possible. Try supporting your picture-taking arm against your body or a stationary object (such as a wall).
- Keep the subject of the pictures still. Exposure time is longer with lower light levels, so you may see a blur.
- For best results, verify that you have the brightest light source coming from behind you, lighting the subject's face. Avoid taking indoor pictures with the subject in front of a window or light.
- Make sure the subject is at least 0.5 meters (18 inches) away from the camera to ensure good focus.

Remember that when you synchronize, your Camera images are stored in the C:\Documents and Settings\<Username>\My Documents\Tree\My Documents folder on your hard drive (see [Camera](#)).

The Camera preview image looks strange

Some third-party applications overwrite your smartphone's color settings with their own 8-bit color settings. This can affect the Camera Preview Mode. Delete third-party applications one by one until the preview image improves.

Third-party applications

Sometimes third-party applications can cause conflicts on your smartphone. Third-party applications that modify wireless features may affect your smartphone's performance and may require extra troubleshooting. Use caution when installing the following types of applications:

- Ringtone managers
- Caller ID applications
- Instant messaging
- Applications that modify when your phone or data connections turn on or off and how your phone behaves

If you recently installed an application and your smartphone seems to be stuck, try the following:

- 1 Perform a soft reset (see [Performing a soft reset](#)).
- 2 Make sure the third-party application is compatible with the Windows Mobile version 5.2 operating system on your smartphone.
- 3 Delete the most recently installed application from your smartphone (see [Removing applications](#)).
- 4 If the problem persists, perform another soft reset.
- 5 If possible, synchronize or use a backup utility to back up your most recent info.
- 6 Perform a hard reset (see [Performing a hard reset](#)).
- 7 Synchronize or restore your backup to restore the info in your built-in applications.
- 8 If the problem is resolved, begin reinstalling your third-party applications one at a time.

- 9 If the problem recurs, delete the last application you installed and report the problem to its developer.

Getting more help

Contact the vendor of any third-party software if you require further assistance.

TIP Remember that not all third-party applications were written with the Treo 750v smartphone keyboard and 5-way navigator in mind. You may encounter strange behavior or errors in these applications if you use the keyboard and the 5-way navigator.

Making room on your smartphone

If you store a large number of records, or install many third-party applications, the internal memory on your smartphone may fill up. Here are some common ways to clear space on your smartphone:

- **Camera:** Large images or videos take up a lot of memory. Move images to an expansion card or delete images from

your smartphone (see [Pictures & Videos](#)).

- **Messaging:** Multimedia content and email attachments can consume excessive memory. Move multimedia content and attachments to an expansion card, or delete large files from your smartphone (see [Message status icons](#)). You may also want to empty the deleted items folder.
- **Internet:** If you save links to pages you've visited in Internet Explorer Mobile, you may want to clear all recent pages (see [Customizing your Internet Explorer Mobile settings](#)).
- **Third-party applications:** You can delete infrequently used applications or move them to an expansion card (see [Copying or moving applications and files between your smartphone and an expansion card](#)).

Also, remember that your smartphone includes an expansion card slot, and that you can store applications and information on expansion cards. However, you still need free memory on the smartphone itself to run applications from an expansion card.

Voice quality

Is the other person hearing an echo?

- Try decreasing the volume on your smartphone to avoid coupling or feedback on the other person's end. This applies to both the speakerphone and to the handset earpiece.
- Position the smartphone closer to your ear to prevent sound leaking back to the microphone. Keep your hand away from the microphone hole, which is on the lower-right side of your smartphone.
- If you're using Speakerphone mode with your smartphone lying on a flat surface, try turning the smartphone "face down" (screen facing the surface).

Are you hearing your own voice echo?

Ask the other person to turn down their volume or to hold the smartphone closer to their ear.



Is your voice too quiet on the other end?

Be sure to hold the bottom of the smartphone, or the hands-free microphone, close to your mouth.

Check the signal strength indicator. If the signal is weak, try to find an area with better coverage.

Where to learn more


For a quick introduction

- **Quick Tour:** The Quick Tour introduces you to many of your Palm® Treo™ 750v smartphone's features. It is already installed on your smartphone, and you can open it any time. Press **Start** , select **Programs**, and then select **Quick Tour** .

To register your smartphone

- **Online registration:** Visit www.palm.com/register to register your smartphone and obtain benefits such as discounts on software and accessories, faster technical support, and special promotions, and important product updates including notifications on software updates, bug fixes, and more.

While using your Treo 750v smartphone


- **On-device User Guide:** A copy of this guide is included on your smartphone. The on-device guide is specially formatted for your smartphone screen. To view the on-device guide, press **Start**  and select **Help**.
- **Online support from Palm:** For up-to-date downloads, troubleshooting, and support information, go to www.palm.com/treo750v-support.

If you need more information


- **Online forums:** Consult online Treo 750v device user discussion groups to swap information and learn about topics you may find nowhere else. Visit www.palm.com/treo750v-support for details.
- Customer service from your network operator: For questions about your mobile account or features, contact your network operator's technical support or customer service department.

Terms

ActiveSync®

The technology that exchanges and updates the information on your smartphone with the information on your computer. To open ActiveSync on your computer, double-click the ActiveSync icon  in the taskbar in the lower-right corner of your screen. If the icon does not appear, click Start, click All Programs (or navigate to the Programs group), and then select Microsoft ActiveSync. See [Installing the desktop synchronization software](#).

Alt (alternative)

The key that you use to enter accented characters and symbols that do not appear on your keyboard. Press Alt , and then press a key on the keyboard to view the alternative characters available for that key. See [Entering other symbols and accented characters](#).

auto-off interval

The time of inactivity that passes before the screen on your smartphone turns off. The wireless features on your smartphone

are unaffected by this setting. See [Optimizing power settings](#).

beam

The process of sending or receiving an entry or application using the infrared port on your smartphone or using Bluetooth® wireless technology. See [Beaming information](#).

Bluetooth® wireless technology

Technology that enables devices such as smartphones, mobile phones, and computers to connect wirelessly to each other so that they can exchange information over short distances. For more info, visit www.bluetooth.com. See [Connecting to devices with Bluetooth® - wireless technology](#).

desktop software

A PIM application for computers, such as Microsoft Outlook®, that helps you manage your personal information and keep it synchronized with your smartphone. See [Installing the desktop synchronization software](#).

dialog box

A set of options and command buttons that is enclosed by a border and that enables you to carry out a specific task.

EDGE (Enhanced Data rates for GSM Evolution)

An enhanced version of GPRS that delivers data speeds that are up to three times faster than standard GPRS connections, with rates up to 236.8 Kbps. (Additional charges may apply.) See [What are all those icons?](#)

GPRS (General Packet Radio Service)

A mobile Internet connectivity technology that allows persistent data connections. (Additional charges may apply.) See [What are all those icons?](#)

infrared (IR)

A way of transmitting information using light waves. You use the IR port on your smartphone to transfer information between other IR devices within a short radius. See [Beaming information](#).

Lithium Ion (Li-Ion)

The rechargeable battery technology used in Treo 750v smartphones. See [Charging the battery](#).


Microsoft Exchange ActiveSync®

Technology that allows your smartphone to synchronize email, contacts, calendar events, and tasks wirelessly with Microsoft Exchange Server 2003. See [Setting up wireless synchronization](#).

MMS (Multimedia Messaging System)

An enhanced messaging system that enables you to send pictures, animations, and ringtones almost instantly. See [Creating and sending a multimedia message](#).

Mobile Device

The component on your Windows computer that enables you to install applications and other information on your smartphone. To access it, open Windows Explorer or My Computer and look for the Mobile Device  entry. See [Installing applications from your computer](#).

Option

Press this key and then a second key to enter the character or to access the feature displayed above the letter on the second key. See [Entering numbers, punctuation, and symbols](#).

partnership

The connection that you make between two devices by means of Bluetooth wireless technology. The devices recognize each other because each device finds the same passkey on the other device. After you create a partnership between the devices, you no longer need to enter the passkey. Partnership is also known as paired relationship, pairing, trusted device, and trusted pair on some devices. See [Connecting to devices with Bluetooth® wireless technology](#).

Phone Off

Appearing on the Today screen, this indicates that your smartphone is not connected to any network, and you cannot make calls except those to emergency numbers. You can still use the organizer features, however. To turn the phone on/

off, go to the Wireless Manager. See [Turning your phone on](#).

Phone/Send

The button on your smartphone that provides quick access to your Today screen and dials once you've entered a phone number. See [Making calls from the Today screen](#).

PIM (personal information manager)

A genre of software that includes applications such as Microsoft Outlook, Palm® Desktop software, Lotus Notes, and ACT!. PIMs generally store contacts, schedules, tasks, and memos.

PIN (personal identification number)

The password assigned to your SIM card by your network operator. Turning on the PIN lock secures your wireless account. See also PUK. See [Locking the SIM card](#).

PIN2 (personal identification number 2)

A code that protects certain network settings such as fixed dialing.

PUK (PIN unlock key)

A special extended password assigned to your SIM card. If you enter the wrong PIN

more than the allowed number of times, your SIM is blocked and you must call your network operator for the PUK. See [Locking the SIM card](#).

SIM (Subscriber Identity Module) card

The smartcard, inserted into your smartphone, that contains your mobile account information, such as the services to which you subscribe. Addresses and phone numbers and SMS messages can also be stored on the SIM card. See [Inserting the SIM card and battery](#).

SMS (Short Messaging Service)

The service that exchanges short text messages almost instantly between mobile devices. Treo 750v smartphones can send and receive text messages while you are on a voice call. See [Creating and sending a text message](#).

Start

The menu on your smartphone from which you can open all applications. See [Opening applications](#).

streaming

Technology that enables you to access media content—for example, watch video

or listen to an audio program—directly from the Internet on your smartphone without needing to download a file to save on your smartphone. See [Viewing a video](#).

synchronization

The process in which information that is entered or updated on your smartphone, your computer, or a server is instantly updated in one of the other locations either wirelessly or by means of a cable connection. See [Synchronizing information](#).

UMTS (Universal Mobile Telecommunications System)

One of the third-generation (3G) mobile phone technologies that is designed for high-speed data transfer with rates up to 384 Kbps. It uses W-CDMA as the underlying technology. See [What are all those icons?](#)

username

The name associated with your smartphone that distinguishes it from other Windows Mobile® devices. If you install ActiveSync® desktop software, you are asked to give your smartphone a username. If you only synchronize wirelessly using Microsoft Exchange

ActiveSync, you do not need to give your smartphone a username. See [Installing the desktop synchronization software](#).

Windows Mobile

The operating system of your Treo 750v smartphone. Your smartphone uses Windows Mobile® 5.2. When installing third-party applications to your

smartphone, be sure to install only apps that use Microsoft Windows Mobile 5.0 software for Pocket PC Phone Edition. The Microsoft Windows Mobile 5.0 software for Smartphone is not compatible with your Treo 750v smartphone. See [Installing third-party applications](#).

Regulatory information

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B computer peripheral, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Safety Exposure

To Radio Frequency Energy (SAR) Radio transmitting devices radiate Radio Frequency (RF) energy during its operation. RF energy can be absorbed into the human body and potentially can cause adverse health effects if excessive levels are absorbed. The unit of measurement for human exposure to RF energy is "Specific Absorption Rate" (SAR).

The Federal Communications Commission (FCC), Industrie Canada (IC), and other agencies around the world have established limits that incorporate a substantial safety margin designed to assure the safety of all persons using this equipment.

In order to certify this unit for sale in the US, Canada and Europe this unit has been tested for RF exposure compliance at a qualified test laboratory and found to comply with the regulations regarding exposure to RF Energy.

SAR was measured with the unit transmitting at its maximum certified RF power. Often, however, during normal operation the unit will transmit much less than maximum power. Transmit power is controlled automatically and, in general is reduced as you get closer to a cellular base station. This reduction in transmit power will result in a lower RF energy exposure and resulting SAR value.

FCC RF Safety Statement

In order to comply with FCC RF exposure safety guidelines, users MUST use one of the following types of bodyworn accessories.

- A Palm® brand body-worn accessory that has been tested for SAR compliance and is intended for use with this product.
- An accessory that contains NO metal (snaps, clips, etc) and provides AT LEAST 1.5 cm of separation between the users body and the unit.

Do NOT use the device in a manner such that it is in direct contact with the body (i.e. on the lap or in a breast pocket). Such use will likely exceed FCC RF safety exposure limits. See www.fcc.gov/oet/rfsafety for more information on RF exposure safety.

Responsible party

(North America)
Palm Inc.
950 W. Maude Ave.
Sunnyvale, CA 94085
USA
www.palm.com

(Europe)
Roy Bedlow
Buckhurst Court
London Road
Wokingham, Berkshire RG40 1PA,
UK

Antenna Care/Unauthorized Modifications

Use only the supplied integral antenna. Unauthorized antenna modifications or attachments could damage the unit and may violate FCC regulations. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Potentially Unsafe Areas


Potentially explosive atmospheres: Turn off your smartphone when you are in any areas with a potentially explosive atmosphere, such as fueling areas (gas or petrol stations) or storage facilities for fuel or chemicals.

Declaration of Conformity

Treo 750v

Palm declares that the above model of Treo 750v smartphone is compliant with the regulations below. The declaration applies to the smartphone and its associated accessories (power supply, headset, and USB cable) where applicable.

Maximum Scaled SAR Values (W/kg) FCC				
Band	GSM 850	GSM 1900	WCDMA 850	WCDMA 1900
Head SAR (Held to Ear)	(W/Kg) 0.866	(W/Kg) 0.588	(W/Kg) 0.569	(W/Kg) 1.16
Body SAR (Worn)	(W/Kg) 0.532	(W/Kg) 0.155	(W/Kg) 0.231	(W/Kg) 0.164



Maximum SAR Values (W/kg) CE			
Band	GSM 900	PCS 1800	WCDMA 2100
Head SAR	0.741	0.244	0.447

FCC OET Bulletin 65 Supplement C

Safety: EN 60950: 2000 (Jan-2000)

Radiated Emissions: EN 55022

FCC ID: 08F-KITT

IC ID: 3905A-KITT

Using TTY

A TTY (also known as TDD or text telephone) is a telecommunications device that allows people who are deaf or hard of hearing, or who have speech or language disabilities, to communicate by telephone.

Your Palm Treo 750v smartphone is compatible with select TTY devices. You can connect a TTY/TDD machine to your smartphone through the headset jack, but you cannot use your headset jack with a headset or hands-free kit while this mode is enabled. Please check with the manufacturer of your TTY device for connectivity information and to ensure that the TTY device supports digital wireless transmission.

To use TTY, you may need to make additional arrangements with your network operator. Please contact your network operator's customer service department for more information.

- 1 Press the Start button and select Settings.
- 2 Select Personal, and then select Phone.
- 3 Select Phone.
- 4 Select the TTY/TDD list, and then select either Default mode, VCO mode, or HCO mode.
- 5 Press OK. A keyboard icon appears at the top of your Today screen whenever TTY is enabled.

To disable TTY, repeat steps 1 and 2.

Operational Warnings

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION. Read this information before using your integrated multi-service portable radio.

For the safe and efficient operation of your radio, observe these guidelines:

Potentially Unsafe Areas/Potentially explosive

atmospheres Obey all signs and instructions regarding turning off your smartphone. In particular, turn off your smartphone when you are in any areas with a potentially explosive atmosphere, such as

fueling areas (gas or petrol stations, below deck on boats), storage facilities for fuel or chemicals, blasting areas and areas near electrical blasting caps, and areas where there are chemicals or particles (such as metal powders, grains, and dust) in the air.

Interference to Medical and Personal Electronic Devices Most but not all electronic equipment is shielded from RF signals and certain electronic equipment may not be shielded against the RF signals from your smartphone.

Pacemakers The Health Industry Manufacturers Association recommends that a minimum separation of six inches (6") be maintained between a smartphone and a pacemaker. These recommendations are consistent with the independent research by the recommendations of Wireless Technology Research.

Persons with pacemakers should:

- ALWAYS keep the smartphone more than six inches from their pacemaker when the smartphone is turned ON.
- Not carry the smartphone in a breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- Turn the smartphone OFF immediately if you have any reason to suspect that interference is taking place.

Audio Safety Some hearing aids may be affected by some digital smartphones. You may want to consult your doctor in the event of you experience interference with your hearing aid while using your smartphone. When using the speakerphone feature, it is recommended that you place your smartphone at a safe distance from your ear.

Other Medical Devices If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Turn your smartphone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Interference to Other Electronic Devices RF energy may affect improperly installed or inadequately shielded electronic operating and entertainment systems in motor vehicles. Check with the manufacturer or representative to determine if these systems are adequately shielded from external RF energy. Also check with the manufacturer of any equipment that has been added to the vehicle.

Repetitive Motion Injuries When using the keyboard or playing games on your smartphone, you may experience discomfort in your neck, shoulders, hands, arms, or other parts of the body. To avoid any injury, such as tendonitis, carpal tunnel syndrome, or other musculoskeletal disorder, make sure to take necessary breaks from use, take longer rests (such as several hours) if discomfort or tiring begins, and see a doctor if discomfort persists.

Blackouts and Seizures Blinking lights, such as those experienced with television or playing video games, may cause some people to experience blackout or seizure, even if never experienced before. In the event a smartphone user should experience any disorientation, loss of awareness, convulsion, eye or muscle twitching or other involuntary movements, stop use immediately and consult a doctor. Individuals with personal or family history of such events should consult a doctor before using the device. To limit the possibility of such symptoms, wherever possible every hour take a minimum of 15 minutes, use in a well lighted area, view the screen from the farthest distance and avoid exposure to blinking lights if you are tired.

Aircraft While in aircraft, follow all instructions regarding the operation of your smartphone. Use of your smartphone while on board on aircraft must be done in accordance in compliance with airline instructions and regulations.

Vehicles with Air Bags Your smartphone should not be placed in a position that would affect the operation of air bag deployment or in a position that, should the air bag inflate, could propel the smartphone. Air bags will inflate with great force and care should be taken to protect within a vehicle that has air bags.

Battery Your smartphone includes an internal lithium ion battery. Please note that use of certain data applications can result in heavy battery use and may require frequent battery charging. Any disposal of the smartphone must comply with laws and regulations pertaining to lithium ion batteries.

Driving Safety Tips Overview

Always obey all laws and regulations on the use of smartphones in your driving area.

Safety — Your most important call. The Wireless Industry reminds you to use your smartphone safely when driving.

- 1 Get to know your smartphone and its features, such as speed-dial and redial.
- 2 When available, use a hands-free device.
- 3 Position your smartphone within easy reach.
- 4 Let the person you are speaking to know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.
- 5 Do not take notes or look up phone numbers while driving.
- 6 Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic.
- 7 Do not engage in stressful or emotional conversations that may divert your attention from the road.
- 8 Dial 9-1-1 to report serious emergencies -it's free from your smartphone!
- 9 Use your smartphone to help others in emergencies.
- 10 Call roadside assistance or a special non-emergency wireless number when necessary.

Driving Safety Tips Details

- 1 Get to know your smartphone and its features such as speed-dial and redial. Carefully read your instruction manual and learn to take advantage of valuable features most smartphones offer including, automatic redial and memory dial-most smartphones can store up to 99 numbers in memory dial. Also, work to memorize the smartphone keypad so you can use the speed-dial function without taking your attention off the road.
- 2 When available, use a hands-free device. A number of hands-free smartphone accessories are readily available today. Whether you choose an installed mounted device for your smartphone or a

speaker phone accessory, take advantage of these devices if available to you.

- 3 Position your smartphone within easy reach. Make sure you place your smartphone within easy reach and where you can grab it without removing your eyes from the road. If you get an incoming call at an inconvenient time, let your voice mail answer it for you.
- 4 Suspend conversations during hazardous driving conditions or situations. Let the person you are speaking to know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow and ice can be hazardous, but so is heavy traffic. As a driver, your first responsibility is to pay attention to the road.
- 5 Do not take notes or look up phone numbers while driving. If you are reading an address book or business card while driving a car, or writing a "to do" list, then you are not watching where you are going. It's common sense. Don't get caught in a dangerous situation because you are reading or writing and not paying attention to the road or nearby vehicles.
- 6 Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic. Try to plan your calls before you begin your trip, or attempt to coincide your calls with times you may be stopped at a stop sign, red light or otherwise stationary. But if you need to dial while driving, follow this simple tip-dial only a few numbers, check the road and your mirrors, then continue.
- 7 Do not engage in stressful or emotional conversations that may be distracting. Stressful or emotional conversations and driving do not mix-they are distracting and even dangerous when you are behind the wheel. Make people you are talking with aware you are driving and if necessary, suspend phone conversations which have the potential to divert your attention from the road.
- 8 Use your smartphone to call for help. Your smartphone is one of the greatest tools you can own to protect yourself and your family in dangerous situations-with your smartphone at your side, help is only three numbers away. Dial 9-1-1 in the case of fire,

traffic accident, road hazard, or medical emergencies. Remember, 9-1-1 is a free call on your smartphone!

- 9 Use your smartphone to help others in emergencies. Your smartphone provides you a perfect opportunity to be a "good Samaritan" in your community. If you see an auto accident, crime in progress, or other serious emergency where lives are in danger, call 9-1-1, as you would want others to do for you.
- 10 Call roadside assistance or a special wireless non-emergency assistance number when necessary. Certain situations you encounter while driving may require attention, but are not urgent enough to merit a call to 9-1-1. But you can still use your smartphone to lend a hand. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.


NOTICE FOR CONSUMERS WITH HEARING DISABILITIES

Digital Wireless Phones to be Compatible with Hearing Aids On July 10, 2003, the Federal Communications Commission (FCC) modified the exemption for wireless phones under the Hearing Aid Compatibility Act of 1988. This means that wireless phone manufacturers and service providers must make digital wireless phones accessible to individuals who use hearing aids.

For more information, please go to the FCC's Consumer Alert on accessibility of digital wireless phones at <http://www.fcc.gov/cgb/consumerfacts/accessiblereadings.html>.

Wireless telephones are hand-held phones with built-in antennas, often called cell, mobile, or PCS phones. These phones are popular with callers because they can be carried easily from place to place.

Wireless telephones are two-way radios. When you talk into a wireless telephone, it picks up your voice and converts the sound to radio frequency energy (or radio waves). The radio waves travel through the air until they reach a receiver at a nearby base station. The base station then sends your call through the telephone network until it reaches the person you are calling.



When you receive a call on your wireless telephone, the message travels through the telephone network until it reaches a base station close to your wireless phone. Then the base station sends out radio waves that are detected by a receiver in your telephone, where the signals are changed back into the sound of a voice.

The Federal Communications Commission (FCC) and the Food and Drug Administration (FDA) each regulate wireless telephones. FCC ensures that all wireless phones sold in the United States follow safety guidelines that limit radio frequency (RF) energy. FDA monitors the health effects of wireless telephones. Each agency has the authority to take action if a wireless phone produces hazardous levels of RF energy.

FDA derives its authority to regulate wireless telephones from the Radiation Control provisions of the Federal Food, Drug, and Cosmetic Act (originally enacted as the Radiation Control for Health and Safety Act of 1968). (<http://www.fda.gov/cdrh/comp/efprc.html>).

FCC derives its authority to regulate wireless telephones from the National Environmental Policy Act of 1969 (NEPA) and the Telecommunications Act of 1996 (<http://www.fcc.gov/telecom.html>). Updated 7/16/2003

Hands-Free Capability All CTIA Certified portable products provide the consumer with a toll-free number for the purchase of a compatible hands-free device. 1-800-881-7256

STATIC ELECTRICITY, ESD, AND YOUR PALM DEVICE

Electrostatic discharge (ESD) can cause damage to electronic devices if discharged into the device, so you should take steps to avoid such an occurrence.

Description of ESD Static electricity is an electrical charge caused by the buildup of excess electrons on the surface of a material. To most people, static electricity and ESD are nothing more than annoyances. For example, after walking over a carpet while scuffing your feet, building up electrons on your body, you may get a shock—the discharge event—when you touch a metal doorknob. This little shock discharges the built-up static electricity.

ESD-susceptible equipment Even a small amount of ESD can harm circuitry, so when working with electronic devices, take measures to help protect your electronic devices, including your Palm® device, from ESD harm. While Palm has built protections against ESD into its products, ESD unfortunately exists and, unless neutralized, could build up to levels that could harm your equipment. Any electronic device that contains an external entry point for plugging in anything from cables to docking stations is susceptible to entry of ESD. Devices that you carry with you, such as your Palm device, build up ESD in a unique way because the static electricity that may have built up on your body is automatically passed to the device. Then, when the device is connected to another device such as a docking station, a discharge event can occur.

Precautions against ESD Make sure to discharge any built-up static electricity from yourself and your electronic devices *before* touching an electronic device or connecting one device to another. The recommendation from Palm is that you take this precaution *before* connecting your Palm device to your computer, placing the device in a cradle, or connecting it to any other device. You can do this in many ways, including the following:

- Ground yourself when you're holding your device by simultaneously touching a metal surface that is at earth ground. For example, if your computer has a metal case and is plugged into a standard three-prong grounded outlet, touching the case should discharge the ESD on your body.
- Increase the relative humidity of your environment.
- Install ESD-specific prevention items, such as grounding mats.

Conditions that enhance ESD occurrences Conditions that can contribute to the buildup of static electricity in the environment include the following:

- Low relative humidity.

- Material type (The type of material gathering the charge. For example, synthetics are more prone to static buildup than natural fibers like cotton.)
- The rapidity with which you touch, connect, or disconnect electronic devices.

While you should always take appropriate precautions to discharge electricity, if you are in an environment where you notice ESD events, you may want to take extra precautions to protect your electronic equipment against ESD.

Precaution against hearing loss Protect your hearing. Listening to this device at full volume for a long period of time can damage your hearing.

A pleine puissance, l'écoute prolongée du baladeur peut endommager l'oreille de l'utilisateur. Consultez notre site web www.palm.com/fti pour plus d'informations.



Waste disposal Please recycle appropriately. For appropriate recycling and disposal instructions please visit: www.palm.com/environment.



Précautions d'usage de votre téléphone mobile

Le taux de DAS(1) (Débit d'Absorption Spécifique) de votre Palm Treo 750v smartphone est 0,741 w/kg.

Conseils d'utilisation pour réduire le niveau d'exposition aux rayonnements : Utiliser le plus souvent possible les kits piétons (oreillettes), notamment en cas d'usage fréquent ou prolongé du

téléphone mobile. Ils apportent en outre un plus grand confort d'utilisation.

Eloigner le téléphone mobile de certaines zones sensibles telles que le ventre chez les femmes enceintes ou le bas-ventre chez les adolescents, plus particulièrement lors d'une communication.

Utiliser votre téléphone mobile dans de bonnes conditions de réception. Celle-ci est indiquée sur l'écran de votre téléphone par la matérialisation de barrettes. À partir de 3 ou 4 barrettes, la réception est de bonne qualité pour passer vos communications. Ce n'est pas toujours le cas dans certaines zones ou situations, notamment les parking souterrains, les ascenseurs, en train ou en voiture ou tout simplement dans un secteur mal couvert par le réseau.

Mesures touchant à la sécurité : Dans certains lieux ou situations, tels que les avions, les hôpitaux, les stations-service et les garages professionnels, l'usage du téléphone est interdit. Il est donc impératif de respecter strictement les consignes de sécurité propres à chacune de ces situations et d'éteindre votre téléphone lorsque cela est requis.

Par ailleurs pour éviter les risques d'interférences, les personnes porteuses d'implants électroniques (stimulateurs cardiaques, pompes à insuline, neurostimulateurs...) doivent conserver une distance de 15 cm entre le mobile et l'implant et ne l'utiliser que du côté opposé au côté où celui-ci est situé.

Téléphoner en conduisant, même avec des équipements qui ne sont pas interdits par la réglementation, est dangereux car il augmente potentiellement le risque d'accident provenant de la distraction créée par la conversation elle-même. Aussi, est-il recommandé de ne jamais téléphoner en conduisant et de considérer que l'utilisation d'un kit mains-libres n'est pas une solution.

(1) Valeur DAS la plus élevée pour ce modèle de téléphone et pour une utilisation à l'oreille, communiquée par le constructeur. Le DAS, exprimé en w/kg, quantifie le niveau d'exposition aux ondes électromagnétiques et permet de vérifier la conformité des mobiles à la réglementation française et européenne qui impose que celui-ci soit inférieur à 2w/kg.

Specifications

Radio	<ul style="list-style-type: none">• Dual mode GSM/UMTS phone• GSM 850/900/1800/1900 quad band• UMTS 850/1900/2100 tri-band• GPRS Multi-slot Class 10, Class B• EDGE up to 59kbps per time-slot• UMTS PS data up to 384kbps DL
Phone features	<ul style="list-style-type: none">• Personal speakerphone• Hands-free headset jack (2.5 mm, 3-barrel connector)• Microphone mute option• TTY compatible
Processor technology	<ul style="list-style-type: none">• Samsung processor—300MHz
Expansion	<ul style="list-style-type: none">• miniSD card slot
Battery	<ul style="list-style-type: none">• Rechargeable Lithium Ion• 1200mAh power• Removable for replacement• 3 hours full charge time
Operating system	<ul style="list-style-type: none">• Windows Mobile Edition 5.2. (Phone Edition)
Camera	<ul style="list-style-type: none">• Still image capture resolution:1280 x 1024, 1.3 megapixel• 2x digital zoom

Size	<ul style="list-style-type: none"> • 112.9mm x 59.3mm x 21.3mm (4.44 in x 2.34 in. x 0.84 in.)
Weight	<ul style="list-style-type: none"> • 154 grams (5.4 ounces)
Connectivity	<ul style="list-style-type: none"> • Infrared (1.0 compliant) • Bluetooth® wireless technology (1.2 compliant)
Display	<ul style="list-style-type: none"> • Touch-sensitive LCD screen (includes stylus) • 65,536 colors (16-bit color) • Resolution: 240 x 240 • User-adjustable brightness
Keyboard	<ul style="list-style-type: none"> • Built-in QWERTY keyboard plus 5-way navigator • Backlight for low lighting conditions

Included software	<ul style="list-style-type: none"> • Today/Phone (includes Speed Dial and Dial Pad) • Messaging (text, multimedia, and email) • Internet Explorer Mobile (web browser) • Camera • Pictures & Videos • Windows Media Player Mobile • File Explorer • Contacts • Calendar • Tasks • Notes • Calculator • ActiveSync® • Excel Mobile • Word Mobile • PowerPoint Mobile • Voice Command • Quick Tour • Search • Terminal Services • PicseL PDF Viewer • Bluetooth Plug-in
System requirements	<ul style="list-style-type: none"> • Windows 2000 or XP (later versions may also be supported) • 32MB of available memory (RAM) • 170MB of free hard disk space • Available USB port
Operating and storage temperature range	<ul style="list-style-type: none"> • 0°C to 40°C (32°F to 104°F) 5% to 90% RH

Index

SYMBOLS

! on battery icon 10

NUMERICS

112 calls 35, 210

1st day of week option 156

3GP files 140

3GPP files 102, 136

3GPP2 files 102, 136

5-way navigator 5, 17, 19,
244

911 calls 35, 210

A

AC charger 9, 10

accented characters 26, 27

accessing

 ActiveSync 76

 alternate characters 26

 applications 28, 206

 calculator 198

 Calendar application 151

 Contacts application 149

 Dial Pad 38

 File Explorer 186

 information 29, 217

Internet Explorer 115

 menu items 20, 21, 22

Messaging app 101

Notes application 160

on-device documentation
247

online address books 93

online forums 247

options in lists 22

Outlook folders 236

Palm online support 247

PDF Viewer 165

Phone Settings screen 14

Pictures & Videos

 application 136

Quick Tour 247

remote files 221

speed-dial buttons 35

spreadsheet templates
174

Streaming Media

 application 142

Tasks application 157

Tasks entry bar 159

the Internet 220, 231

Today screen 12, 29

web pages 115, 117, 119,
241

Wireless Manager 33

accounts

 conference calls and 45

 customer service support
 for 247

 missing phone numbers
 and 14

 preventing unauthorized
 use of 210, 217

 removing email 89

 setting up email 87

 troubleshooting 234, 239

Accounts tab 87, 92, 94

action keys 5, 20

actions 20, 203

activating items on screen 20

active call info 42

active calls. *See* phone calls

ActiveSync

 defined 249

 installing 68, 74

 opening 76

 receiving email and 91

 synchronizing with 67, 68,
 76, 224, 234

 troubleshooting 224,
 234–239

ActiveSync icon 76, 79, 249

ActiveSync Plug-in for
 Bluetooth 79

- Add a new VPN server
 - connection option 221
- Add Contact prompt 43
- Add Favorite dialog box 118
- Add Media command 104
- Add Picture command 104
- Add Recipient command 101
- Add Server Source command 71
- Add Sound command 104
- Add to Contacts command 107
- Add to Favorites command 118
- Add to Personal Address Book command 236
- adding
 - a second call 44
 - applications 206
 - appointments 152, 154
 - attachments to email 90, 97, 186
 - bookmarks 117
 - bulleted or numbered lists 169
 - caller ID pictures 149
 - connections 220, 221
 - contacts 43, 57, 149
 - document templates 167
 - expansion cards 193
 - files to playlists 144
 - folders 170
 - notes 149, 160, 161
 - online address book 93
 - passkeys 53, 123, 124
 - signatures 94, 111
 - speed-dial buttons 48
 - spreadsheets 172
 - tasks 157
 - untimed events 153, 154
- address book 93, 96, 151, 236
- Address List Lookup 185
- address messaging options 96
- Address tab 93, 96
- addresses
 - adding 149
 - checking for 96
 - copying 236
 - entering email 89, 96
 - entering web 30, 116
 - looking up corporate 185
 - multiple recipients and 101
 - selecting 20, 242
 - synchronizing 236
- adjusting screen brightness 204
- Advanced tab (Power Settings) 218
- advancing slides 171, 172
- After calls from numbers... option 57
- Agenda View (calendar) 152
- alarm clock 215
- alarm sounds 216
- alarms
 - adding 153, 158
 - setting 204, 215
 - turning on and off 203
- Alarms tab 216
- albums 136
- alert tones. *See* alarms; ringtones
- aligning the screen 205
- alignment settings
 - documents 169
 - spreadsheets 172
- Allow cookies check box 120
- Allow USB connections
 - check box 235
- Alt key 24, 249
- alternate characters 26, 27
- alternate characters list 26, 27

- AMR files 102
- animation 139, 171, 172
- anniversaries 154
- Answer button 39
- answering the phone 39, 44
- antenna 256
- Appearance tab 201, 205
- application icons 28, 206
- applications
 - See also* third-party applications
 - associating with buttons 206
 - battery life and 11
 - caution for hard resets and 225
 - choosing menu items in 21, 22
 - closing 28, 218
 - copying 196
 - customizing 206–210
 - deleting 190, 245
 - displaying 28, 218
 - downloading 187, 188
 - error reporting for 217
 - included with smartphone 265
 - installing 187–188, 243, 244
 - losing information in 226
 - moving through 18, 19
 - moving to expansion cards 196
 - opening 28, 195, 206
 - phone calls and 42, 43
 - reinstalling 224, 226
 - running from expansion cards 195, 245
 - running multiple 28
 - selecting 28
 - storing 245
 - synchronizing information in 69, 81
 - troubleshooting 226, 228
 - turning sounds on or off for 203
 - viewing memory usage for 218
- Appointment tab 152
- appointments
 - adding 152
 - appearing in wrong time slots 237
 - deleting 156
 - hiding 155
 - marking as private 155
 - reminders for 153
 - scheduling repeating 154
 - viewing 152
- Appointments tab 156
- Area code option 151
- arrow icons 17
- ascending sort order 179
- ASF files 136
- Assign a program list 207
- attachments
 - adding 90, 97, 186
 - downloading 91, 92
 - embedded objects in 92
 - internal memory and 245
 - opening 91
 - storing 92, 96
 - troubleshooting 240
- Attendees option 154
- audio 39, 135, 140, 257
- auto-completion options 209
- AutoCorrect command 139
- Autofill option 177
- AutoFilter command 179
- AutoFilter settings (spreadsheets) 173
- auto-keyguard feature 210, 211
- Auto-Keyguard list 211
- Automatically download MMS messages check box 110

auto-off interval 249
available memory 218
available storage space 218

B

back view (smartphone) 6
backgrounds 131, 138, 145, 201
backing up information 65, 223, 226
backlight (keyboard) 24, 219
backlight shut-off interval 25
Backspace key 20, 24, 26
backup and restore application 79
backup utilities 223, 226, 239
backups, restoring 226, 239
battery
 Bluetooth connections and 124
 charging 9–10
 conserving power for 219
 disposing of 227, 258
 inserting 8
 maximizing life of 11–12
 purchasing 9
 removing 225, 227
 replacing 226–227

 specifications for 263
 viewing remaining power for 218
 viewing status of 63
battery door 8
battery door release 6
battery icon 10
Battery Power tab 25
battery status icons 63
Battery tab 218
Beam File command 191
Beam tab 193
Beam... command 192
beaming 12, 186, 191–193, 249
birthdays 154
blank screens 229
Block incoming calls list 58
Block outgoing calls list 58
blocking phone calls 57
Bluetooth connections
 battery level and 124
 battery life and 11
 checking status of 53
 communicating over 51
 hands-free devices and 52, 54
 overview 121
 synchronizing over 79

Bluetooth devices
 beaming to 192
 connecting to 51–53, 121–124
 creating partnerships for 123
 discovery setting for 125
 phone calls and 54
 receiving information over 122, 124
 sending information over 122, 124
 troubleshooting 232
Bluetooth icon 53, 63, 122
Bluetooth Plug-in 122, 126
Bluetooth Settings screen 122–125
Bluetooth wireless technology 113, 191, 249
BMP files 136
Bold option 168
bookmarks 117
 See also favorites
border highlight 19
borders 172
brightness, adjusting 132, 133, 204
browsing files and folders 186, 197

browsing the web. *See* web browsing
built-in applications 190, 265
built-in camera. *See* camera
bulleted lists 169
bullets 166
Burst mode 132
button settings 145
buttons
 assigning to media files 145
 assigning voice commands to 207
 associating with applications 206
 creating speed-dial 48
 disabling 211
 editing speed-dial 49
 opening menus and 20
 reassigning 206–207
 selecting or activating 19
 showing voicemail 49
 turning sounds on or off for 203
Buttons icon 207
Buttons list 207
Buttons screen 206
Buttons tab (Options) 145

C

CAB files 188
calculations 176, 197
Calculator application 197
calculator buttons 198
Calculator icon 198
calendar
 adding items to 153, 154
 displaying 151
 removing events 156
 setting alarms for 153
 setting options for 156
 unavailable slots on 155
Calendar application
 adding contacts and 149
 customizing 156–157
 managing schedules with 152–156
 selecting views 152
 starting 151
 untimed events in 153
calendar options 156–157
Calendar views 152, 156, 157
call forwarding 46
call forwarding icon 46
Call Log 38, 47
Call Sender command 107
Call Timers command 47

call waiting 44
call-barring password 57
caller ID applications 243
caller ID blocking 43
caller ID pictures 131, 149
caller IDs 58
calling plans 47
call-waiting notifications 59
camcorder icon 133
camera
 battery life and 11
 capturing videos with 132–133
 specifications for 263
 taking pictures 131–132
 troubleshooting 242
Camera icon 131
camera lens 6
Camera Preview Mode 243
camera settings 133–135
Camera tab 134
Cancel Bluetooth command 54
Cancel Mute command 42
capitalization 25, 210
Capitalize first letter of sentence check box 210
Caps Lock icon 25
Caps Lock mode 25

- captions 103, 104
- cascading menus 22
- case-sensitive searching 167, 181
- categories
 - contacts 149
 - events 155
 - playlists 143
 - tasks 158, 159
- cell patterns (spreadsheets) 173
- cell phones. *See* wireless phones
- certificates 115, 216
- Certificates icon 216
- Certificates screen 216
- changes, undoing 139
- changing
 - alarm sounds 216
 - color themes 201, 205
 - connections 220
 - contacts 150
 - date and time settings 214
 - email accounts 89
 - information 181
 - picture or video resolution 132, 133, 242
 - PIN numbers 213
 - speed-dial buttons 49
 - text 167
 - text size 204
- character entry 27
- character sets 120
- characters
 - capitalizing 25, 210
 - entering 24, 25, 176, 209
 - phone calls and 49
 - scrolling 18
 - text messages and 101, 102
 - typing alternate 26
- charge indicator 5, 10
- charger cable 10
- charging
 - smartphone 9, 11
 - smartphone battery 9–10
- charging status 10
- Chart command 180
- chart options 180
- charts 173, 180
- Chat icon 108
- chat sessions 107, 111
- Chat tab 111
- check boxes 19
- chronological list of calls 38
- Clear Cookies button 121
- Clear History button 120
- Clear Now Playing command 144
- Clear Type tab 204
- clearing web links 120
- Clock & Alarms icon 215
- Clock & Alarms Settings
 - screen 214, 216
- closing
 - applications 28, 218
 - menus 22
 - notification messages 106
 - screens 19
- color settings 243
- color themes 201, 205
- command button 208, 209
- commands 20, 208
 - See also* menus; voice commands
- company lists 33
- company names 38, 150
- comparisons 180
- completed tasks 158
- compliance statement 256
- components (Treo smartphone) 1
- compressed files 187
- computers
 - connecting to 77

- enabling dial-up
 - networking for 126
 - installing from 189
 - reinstalling desktop
 - software on 224
 - synchronizing with 81, 82
 - system requirements 75
 - viewing videos and pictures on 139
- Conference button 46
- conference calls 45
- confidential events 155
- Confidential option 155
- configurations
 - restoring 225
 - troubleshooting 231
- Configure Server command 241
- configuring
 - data services 231
 - mail servers 241
 - TTY devices 56
- Confirm message deletions
 - check box 110
- confirmation messages 112
- Connect command 221
- Connect via Bluetooth
 - command 80
- Connect via IR command 81
- connecting
 - charger cable 10
 - headsets 50
 - smartphone to PCs 77
 - to a headset 124
 - to Bluetooth devices 51–53, 121–124
 - to hands-free car kits 51, 124
 - to mobile networks 230
 - to service providers 220
 - to the Internet 126, 220, 231
 - to TTY devices 56
 - to VPNs 221
 - to web sites 115, 125
- connection icons 222
- Connection Settings
 - command 235
- connections
 - adding 220, 221
 - changing 220
 - displaying 220
 - ending 222
 - losing 232, 234
 - manually starting 221
 - precautions for 260
 - removing Bluetooth 124
 - setting up 220–221
- setting up wireless 125–127
- timing out 234
- troubleshooting 229–233, 241
- trusted devices and 124
- Connections icon 220
- Connections screen 220, 221, 231, 232
- Connections tab 193, 220
- connectivity specs 264
- conserving battery power 219
- contact categories 149
- contacts
 - adding 43, 57, 149
 - addressing messages to 89, 96, 101, 103
 - assigning ringtones to 48, 56, 137, 150
 - changing 150
 - displaying 150
 - linking speed-dial buttons to 48
 - looking up 30, 36, 151
 - making calls to 36
 - personalizing 56
 - removing 150
 - saving information for 43

- selecting communication method for 37
 - sending messages to 101, 154
 - viewing details list for 37
- Contacts application 149–151
- Contacts list 37, 44, 101, 107, 151
- context-sensitive menus 22
- continuous playback (slides) 172
- cookies 115
- Copy command 119, 138, 168, 196
- copying
 - addresses 236
 - applications 196
 - items in folders 187
 - phone numbers 37, 39, 119
 - pictures and videos 137
 - text 119, 167
- copyrighted items 137
- corporate mail systems 85, 221, 241
- corporate networks 216
- corporate servers 221, 241
- coupling 245
- coverage area 12, 33, 230
- Create chat from messages option 111
- creating
 - appointments 152, 154
 - bookmarks 117
 - bulleted or numbered lists 169
 - caller ID pictures 149
 - connections 220, 221
 - contacts 43, 57, 149
 - documents 165, 166, 167
 - email messages 89
 - folders 170
 - multimedia messages 102
 - notes 160, 161
 - online address book 93
 - partnerships 123
 - passkeys 53, 123, 124
 - playlists 143
 - signatures 94, 111
 - speed-dial buttons 48
 - spreadsheets 172
 - tasks 157
 - templates 107, 167, 174
 - text messages 101
 - untimed events 153, 154
 - video ringtones 137
 - workbooks 174
- credentials 222, 234
- cropping pictures 138
- currency symbols 205
- Currency tab 205
- customer assistance 247
- Customize the playlists...
 - check box 141
- customizing
 - applications 206–210
 - Calendar 156–157
 - camera 133–135
 - chat settings 111
 - Contacts application 151
 - dates and time 214
 - email settings 95
 - Excel Mobile 182
 - format settings 205
 - Internet Explorer Mobile 120–121
 - Media Player Mobile 144
 - Messaging application 110–112
 - network settings 112
 - Notes application 162
 - phone 54–62
 - system settings 214–220
 - system sounds 202
 - tasks 159
 - Today screen 201

- voicemail system 49, 55
- Word Mobile 170
- Cut command 137, 168
- cutting. *See* deleting

D

- daily schedules 152
- data 225
 - See also* information
- data connection icons 222
- data filters 156, 180
- data formats 204
- data service icons 230
- data service providers 220, 231, 240
- data services 1, 230, 231
- data transmission speeds 1
- date format settings 205
- Date tab 205
- dates 177, 205, 214
 - See also* calendar
- Day View 152, 156
- day-planner formats 152
- decimal places 205
- decimal symbols 205
- decompression utility 187
- default document template 170
- default format settings 205

- Default mode option 162
- Default option 116
- default PINs 212
- Default template option 162
- Default zoom level options 210
- defined names
 - (spreadsheets) 178
- delays 34, 231
- Delete Appointment
 - command 156
- Delete Cells command 182
- Delete command 109, 170, 182
- Delete Contact command 150
- Delete Files button 120
- Delete Task command 159
- Deleted folder 96, 245
- deleting
 - applications 190, 245
 - Bluetooth connections 124
 - certificates 217
 - contacts 150
 - directory services 93
 - documents 170
 - email accounts 89
 - events 156

- favorites 118
- files 187, 245
- items from libraries 143
- items from playlists 144
- items in folders 186
- messages 96, 109, 110
- notes 162
- partnerships 124, 233
- pictures 139
- speed-dial buttons 50
- tasks 159
- text 20
- web files 120
- workbooks 182
- worksheets 182
- descending sort order 179
- Desktop option 116
- desktop software 224, 249
 - See also* applications;
 - software
- device names. *See* usernames
- Device Setup Wizard 141
- devices
 - See also* Bluetooth
 - devices; smartphone
 - battery life and 11
 - beaming to 192
 - compliance for 257

- configuring TTY/TTD 56
- discovering trusted 121, 122, 125
- physically-impaired
 - disabilities and 56
- radio frequency emissions and 255, 258
- transferring information from 223
- troubleshooting 232
- Devices tab 123, 232
- diagnostic information 217
- Dial Lookup field 30
- Dial Lookup list 13
- Dial Pad 37, 38, 39
- dialing 12, 34–37, 38, 49
- dialog boxes 250
- dial-up networking 125, 126
- digit grouping 205
- digital cameras 136
 - See also* camera
- digital certificates 115, 216
- dimmed images 229
- Direct Push Technology 70
- directory service 93, 96
- Disable touchscreen check box 211
- Disconnect Bluetooth
 - command 80
- Disconnect command 222
- discoverable setting 125
- discovering trusted devices 121, 122, 125
- discussion groups 247
- disk space 265
 - See also* memory
- Dismiss button 41
- display formats 204
- Display message on screen
 - check box 204
- display options (web) 116
- display settings 204–206
 - See also* screen
- displaying
 - alternate characters 26
 - animated images 139
 - applications on
 - smartphone 28
 - appointments 152
 - calendar 151
 - contacts 37, 150
 - current connection 220
 - daily schedules 152
 - events 153, 155
 - folder contents 186
 - items in folders 170, 181
 - memory usage 218
 - multimedia messages 107
- notifications 55, 204
- on-device documentation 247
- PDF files 165
- pictures 131, 136, 139
- power settings 218
- Quick Tour documentation 247
- running applications 218
- space on expansion cards 196, 218
- tasks 159
- videos 131, 136, 139
- web pages 115, 116
- wireless settings 219
- DOC files 165
- document file types 165, 171
- documentation 2
- documents
 - See also* Word Mobile application
 - creating 165, 166, 167
 - deleting 170
 - finding and replacing text in 167
 - moving or copying text in 167
 - opening 166
 - organizing 170

- saving 165, 166, 168, 170
- sending 83
- setting margins for 169
- spell-checking 169
- supported features for 166
- unsupported features for 165
- documents list 171
- DOT files 165
- downloading
 - applications 187, 188
 - attachments 91, 92
 - email 72, 90, 91
 - files 118
 - images 119, 139
 - multimedia messages 105, 110
 - Palm-specific information and updates 247
 - pictures 136
 - ringtones 54
 - videos 139, 140
- Downloads favorite 118
- downward-pointing arrows 22
- drained battery 11
- drawing 160
- drivers 224
- driving safety tips 258
- Drop and Answer command 45
- drop-down lists
 - accessing 22
 - exiting 23
 - highlighting in 18, 23
 - scrolling through 18
 - selecting items in 20, 23
- drop-down menus 22
- DUN connections 126–127
 - See also* dial-up networking
- E**
 - earpiece 5, 245
 - echoes 245
 - EDGE connections 250
 - Edit command 138, 150
 - Edit Server Settings screen 71
 - Edit Speed Dial command 49, 50
 - editing. *See* changing
 - electrostatic discharge 260
 - email
 - addressing 89, 96
 - creating 89
 - deleting 96
 - dialing from 39
 - downloading 72, 90, 91
 - entering contacts and 149, 154
 - forwarding 94
 - getting from corporate servers 221, 241
 - getting from Exchange Servers 90
 - internal memory and 245
 - priority settings for 90
 - receiving attachments with 91
 - reply options for 95
 - requirements for 1
 - selecting addresses 20
 - sending 90, 91, 97, 117, 239
 - synchronizing 11, 91, 233, 240, 241
 - troubleshooting 239–241
 - email accounts
 - changing 89
 - deleting 89
 - setting up 87
 - troubleshooting 239

- email applications 242
- E-mail button 91
- email client software 240
- email message icons 108
- embedded images 92
- emergency calls 35, 210
- emoticons 102
- Enable Clear Type check box 204
- Enable fixed dialing check box 61
- Enable local network time check box 215
- encoding options 120
- encryption 115
- End Show command 172
- End User License Agreement 2
- ending
 - active calls 42
 - data connections 222
 - playback 142
 - wireless connections 127
- endnotes 166
- entering
 - alternate characters 26, 27
 - data in spreadsheets 174, 177
 - information 24, 25–26
 - numbers 24, 25
 - owner information 214
 - passkeys 53, 123, 124
 - passwords 71, 88, 213
 - phone numbers 12, 34, 37, 38
 - PINs 212
 - text 209, 210
 - web addresses 30, 116
- Entire column option 182
- Entire row option 182
- entry fields
 - deleting text in 20
 - highlighting in 18, 20
 - moving to 18
 - opening drop-down lists in 23
 - scrolling through 18
- Erase all data? prompt 226
- erasing. *See* deleting
- error messages 202, 238
- error reporting 217
- Error Reporting icon 217
- Error Reporting screen 217
- errors 217, 230, 238
- ESD (electrostatic discharge) 260
- ESMTP option 240
- Even when roaming check box 110
- event categories 155
- event icons 157
- Event list 203
- events
 - creating 153, 154
 - deleting 156
 - filtering 156
 - hiding 155
 - marking as sensitive 154
 - reminders for 153
 - selecting sounds for 203
 - setting notification preferences for 203
- Events check box 202
- Excel files 163
 - See also* Excel Mobile; spreadsheets
- Excel Mobile application
 - customizing 182
 - display settings for 175
 - overview 172
 - searching in 181
 - starting 174
 - supported features 172
 - unsupported features 174
- Excel Mobile icon 174

- Exchange ActiveSync 241, 250, 252
- Exchange Address Book 236
- Exchange Server credentials screen 234
- Exchange Server sync
 - options 72, 234
- Exchange Servers
 - accessing 151
 - getting email from 90
 - setting up accounts for 71–73
 - synchronizing with 11, 68, 81, 234
 - troubleshooting 241
- exiting applications 28, 218
- expanding lists in fields 23
- expansion card slot 6, 193, 263
- expansion cards
 - as storage medium 245
 - browsing on 197
 - displaying available space on 196, 218
 - inserting 193–194
 - installing apps on 189
 - moving apps to 196
 - moving information to 170, 181, 196

- opening items on 195
 - removing 194
 - renaming 197
 - searching on 185, 186
 - storing attachments on 92, 96
 - transferring files to 140, 144, 195, 196
 - types supported 193
- extensions (phone) 49
- external power sources 219
- External Power tab 25
- Extra Digits button 41, 49
- Extra Digits text box 49
- Extract command 46

F

- factory settings 145
- factory-installed applications 190, 265
- favorites 117–118
 - See also* web pages
- Favorites button 118
- Favorites command 118
- FCC Statement 255
- features 1
- Federal Trade Commission website 217
- feedback 245

- fields. *See* entry fields
- File Explorer 185, 186–187, 197
- File Explorer icon 186
- file names 168, 170, 185
- file types
 - displaying 171
 - documents 165
 - Media Player 140
 - multimedia 102
 - pictures 136
 - videos 136
- files
 - accessing from corporate accounts 221
 - browsing 186
 - decompressing 187
 - deleting 187, 245
 - downloading 118
 - moving 170, 187
 - saving 195
 - searching for 185, 186
 - selecting multiple 187
 - transferring to expansion cards 140, 144, 195, 196
- Files folder 165
- Files sync option 165
- fill series (spreadsheets) 177

Filter command 150, 156

Filter option 159

filtering

events 156

information 150, 179

tasks 159

filters 156, 180

Find Online command 94,
151

Find/Replace command 167,
181

finding

contacts 30, 36, 151

information 181

text 167

firewalls 233

5-way navigator 5, 17, 19,
244

fixed dialing 60

folder names 170

folders

accessing Outlook 236

adding documents to 168

arranging pictures and
videos in 138

browsing 186, 197

creating 118, 170

displaying contents 170,
181

moving items to 170, 181,
187

opening items in 186

organizing web favorites in
117, 118

sorting contents 170, 181,
186

synchronizing messages
in 91

Font color option 168

Font command 168

Font option 168

fonts 166, 168, 173, 204

footers 166

footnotes 166

forgetting passwords 213

format settings 205

formats, losing 165

formatting

charts 180

paragraphs and lists 169

spreadsheets 172, 178

system data 204

text 168

Formatting toolbar 169

forms (web) 117

formulas 173, 176, 182

forums 247

Forward command 94

forwarding

messages 94, 107

phone calls 46

freeing memory 190, 238,
244

Freeze Panes option 175

front view (smartphone) 5

full charge (battery) 9

Full Screen option 116

functions (spreadsheets)
173, 176

G

games 11

getting started 2, 3, 12, 247

GIF files 102, 136, 139

Global Address List 93, 151

Global Address List Lookup
185

Glossary 249

Go to Slide command 171

GPRS connections 250

graphics programs 138

H

Hands Free check box 53,
124, 232

hands-free car kit 50, 54, 124

- hands-free devices
 - connecting to 51
 - purchasing 260
 - setting up 50
 - tips for 54, 258
 - troubleshooting 232
 - turning Keyguard on or off for 211
- hanging indents 169
- hanging up phone 13, 42
- hard resets 213, 225
- hardware 1
- Hardware buttons check box 203
- headers 166
- headset button 51
- headset jack 5
- headsets
 - configuring as trusted devices 122
 - connecting 50–51, 124
 - disabling Keyguard and 211
 - troubleshooting 232
- hearing-impaired 56, 257, 259
- heat sources 12
- help 223, 247
- Help topics 28

- hiding
 - appointments 155
 - events 155
 - images 116
 - speed-dial buttons 36
 - Tasks entry bar 159
- highlight 19
- Highlight option 169
- highlighting
 - applications 28
 - items in folders 187
 - items on screen 18, 19–20
 - menu items 21, 22
 - options in lists 18, 23
 - text 20, 169
- Hint tab 214
- hints (passwords) 214
- History command 119, 142
- History list 119, 120
- Hold button 42
- home locations 214
- Home page option 120
- hypertext links. *See* links

I

- icons
 - application 28, 206
 - battery status 10

- data connections 222
- data services 230
- email 108
- events 157
- message status 108
- navigator 17
- phone status 62
- signal-strength 33, 220
- Identification tab 214
- Ignore with text message command 40
- image file types 136
- image files 102, 139, 244
- images
 - See also* pictures
 - dimmed 229
 - downloading 119
 - hiding web page 116
 - incorrect color settings and 243
 - receiving 92
 - setting background 138, 201
 - troubleshooting web page 242
- IMAP accounts 87, 92
- inactivity 132, 218
- Inbox 18, 89, 91, 108
- Inbox application 85, 89, 93

- Include file attachments
 - check box 92
- incorrect passwords 213
- Indentation setting 169
- indented lists 166
- indenting text 169
- indicator light 5, 10, 33
- information
 - accessing 29, 217
 - backing up 65, 223, 226
 - changing 181
 - entering 24, 25–26
 - erasing all 233
 - filtering 150, 179
 - losing 165, 225
 - moving 170, 181, 196
 - protecting 210–214
 - removing battery and 227
 - restoring 225, 226
 - searching for 167, 181, 185–186
 - sharing 191
 - sorting 179
 - storing 193, 244, 245
 - synchronizing 68, 69, 233
 - transferring 65, 223
 - updating 65
- infrared port. *See* IR port

- infrared transmissions 80, 250
- Input icon 209
- input options 24, 209
- Input screen 209
- inserting expansion cards 193–194
- installation, troubleshooting 226, 228, 244
- installing
 - ActiveSync 68, 74
 - applications 187–188, 243, 244
 - bonus software 187
 - SIM smartcards 8–14
 - synchronization software 75
 - VPN clients 221
 - Windows drivers 224
- instant messaging applications 243
- internal memory. *See* memory
- Internet 126, 220, 231
 - See also* web browsing; websites
- Internet Connection Speed option 145

- Internet Explorer Mobile
 - browsing with 115–119
 - closing 117
 - customizing 120–121
 - installing from 188
 - scrolling in 18
 - starting 115
 - unsupported elements for 115, 241
- IR connections 192
- IR port 6, 80, 191, 250
- ISP mail systems 85, 87
- ISP settings 220
- ISPs (Internet Service Providers) 220, 240
- Italics option 168
- Items tab 201

J

- JavaScript 115
- JPEG files 102
- JPG files 136

K

- keyboard
 - accessing alternate characters on 26
 - dialing from 34

- entering information from 25–26, 210
- locking 211
- pressing keys on 24
- scrolling with 18
- selecting menu items from 22
- setting key combinations for 207
- specifications for 264
- troubleshooting 244
- keyboard backlight 24, 219
- keyboard icon 24
- Keyguard 211
- Keyguard icon 211
- Known Caller option 55

L

- language-impaired 56
- leading zeros 205
- left action key 20, 152
- Legacy Pocket Word files 166
- libraries (media) 142
- Library command 141
- Library list 141
- Library screen 141, 145
- Library tab 145
- lightening bolt 10

- Li-Ion battery 250
 - See also* battery
- links
 - clearing web 120
 - internal memory and 245
 - media files and 142
 - messages and 108, 117
 - selecting 19, 116
 - troubleshooting 242
- list separators 205
- List setting 169
- Listen button 41
- listening to
 - media files 140
 - voicemail messages 41
- lists
 - accessing 22
 - creating 166, 169
 - displaying alternate characters and 26
 - exiting 23
 - formatting 169
 - highlighting in 18, 23
 - navigating web page 117
 - scrolling through 18
 - selecting items in 20, 23
- Lithium Ion battery 250
 - See also* battery

- locating
 - contacts 30, 36, 151
 - information 181
- location-specific information 204, 214
- Lock icon 116, 137, 213
- Lock screen 213
- locking
 - SIM smartcards 212
 - spreadsheet rows and columns 175
 - the keyboard 211
 - the screen 211
 - Treo smartphone 213
- logging in to
 - corporate servers 221
 - networks 216
- looking up contacts 30, 36, 151
- lookup feature 185
- losing
 - connections 232, 234
 - information 165, 225
 - passwords 213
 - Treo smartphone 79, 214
- low coverage areas 230
- low lighting conditions 24
- lowercase letters 25

M

- magnet **7**
- magnification. *See* zoom settings
- mail servers **221, 241**
- Main tab **218**
- Make the device
 - discoverable check box **122**
- Make this device
 - discoverable setting **125**
- Manage existing connections
 - option **220, 221**
- Manage Folders command **91**
- Manage tab **203**
- management tools **183**
- manually closing applications **29**
- MAPI clients **241**
- maps **242**
- margins **169**
- Match case box **167, 181**
- Match whole words only
 - check box **167, 181**
- measurement units **205**
- media files
 - creating playlists for **143**
 - formats for **140**
 - linking to **142**
 - playing **141**
 - synchronizing **140**
 - transferring **140, 144**
 - troubleshooting **237**
- media libraries **142**
- Media Player **237**
- Media Player Mobile
 - 140–145**
- media players **11**
- Media sync option **140**
- meeting requests **92, 94, 154, 157**
- memory
 - available **265**
 - freeing **190, 238, 244**
 - low conditions for **28, 218**
 - running apps and **28, 195**
 - storing numbers in **198**
 - viewing expansion card **196**
- memory buttons **198**
- memory dial **258**
- Memory icon **196**
- memory options (web) **120**
- Memory screen **218**
- Memory Settings screen **29**
- Memory tab **120**
- memory usage **218**
- memos. *See* messages; notes
- menu items **21**
- Menu key **21, 22**
- menus **20–22**
- Menus icon **206**
- Menus screen **206**
- Message Details command **107**
- message list **107, 109**
- Message Options command **104**
- Message Options screen **104**
- Message Priority list **105**
- message status icons **108**
- Message tab **95**
- Message validity period
 - option **110**
- messages
 - See also* multimedia
 - messages; text
 - messages; voice notes
 - adding signatures to **94, 111**
 - addressing **101, 103**
 - automatically resending **110**
 - creating email **89**

- deleting 96, 109, 110
- dialing from 39
- displaying notification 204
- displaying status of 108
- forwarding 94, 107
- invalid characters and 102
- listening to 41
- receiving notifications for 105, 111, 232
- saving 90
- sorting 109
- storing 245
- Messages tab 110
- Messaging application
 - See also* text messages; multimedia messages
 - adding contacts and 149
 - chat sessions and 107
 - customizing 110–112
 - email settings in 95
 - messaging options in 104
 - notification options in 105
 - overview 101
 - play options in 106
 - starting 101
 - status icons in 108
- messaging applications 243
- messaging services 231, 250
- microphone 5, 42, 135, 245
- microphone icon 208
- Microsoft ActiveSync. *See* ActiveSync
- Microsoft Exchange ActiveSync. *See* Exchange ActiveSync
- Microsoft Office 163, 165
- Microsoft Office Excel 173
 - See also* spreadsheets
- Microsoft Windows Mobile software 188
- Microsoft Windows Mobile website 223
- Microsoft Word documents. *See* documents
- MIDI files 102
- miniSD cards 193
- mirror 6, 132
- Missed call option 55
- MMS files 142
- MMS messaging 101, 250
- mobile accounts. *See* accounts
- Mobile Device component (Windows) 250
- Mobile Device folder 77, 189
- Mobile Device icon 250
- mobile devices 192, 223
- mobile networks 229, 230
- mobile phone numbers 149
- mobile phones. *See* wireless phones
- Mobile to Market certificates 187
- Mobile-Based Device icon 189
- Mode tab 122
- Modem tab 220
- ModemLink application 125
- modems 125
- Modify Sheets command 179, 182
- Month View 152
- most recently dialed numbers list 38
- moving
 - documents to folders 170, 187
 - files to expansion cards 140, 144, 195, 196
 - information 170, 181, 196
 - pictures and videos 137
 - speed-dial buttons 50
 - text 167
 - workbooks 181
- moving around the screen 17–19

moving through web pages

116

MP3 files 140

MP4 files 140

MPEG files 136

MPEG4 files 102

multi-connector 5

multi-line fields 18

multimedia features 99, 129

multimedia file types 136

multimedia files 136, 245

multimedia messages

creating 102

deleting 109, 110

displaying 107

downloading 105, 110

forwarding 107

internal memory and 245

opening 106

overview 99

phone numbers in 39

playing 106–107

previewing 104

receiving 105

replying to 107

requirements for 1

saving 107

sending 102, 104, 108

setting options for 104

sorting 109

troubleshooting 231

Multimedia Messaging

System. *See* MMS

messaging

multiple recipients 101

music 39, 140, 141, 202

See also media files

music files 237

Mute command 42

My Device folder 186

My Device library 142

My Documents folder 185,

186, 226

My Pictures folder 131, 132

My Playlists category 143

My Storage Card library 142

My Text command 89

My Text phrases 89

My Windows Mobile-Based

Device icon 190

N

names 30, 252

naming

document files 168, 170

expansion cards 197

folders 170

groups of pictures 135

speed-dial buttons 48

templates 167, 174

workbooks 181

worksheets 178, 179

navigating the screen 17–19

navigating web pages 116

navigator. *See* 5-way

navigator

navigator buttons 17, 19

negative numbers 205

network protocols 145

network settings 61, 112

Network tab 61, 145

networks

changing 61

connecting to 62

logging in to 216

troubleshooting 229–233

New Account command 87

New Appointment command

152, 153

New MMS command 103

New Partnership option 123

New Sound command 203

New Speed Dial command

48

notes

adding 149, 158

creating 160, 161

- removing 162
- saving 161, 162

Notes application 159–162

Notes icon 160

Notes list 161, 162

Notes tab 149, 214

notification options 105, 111, 203

notification screens. *See* notifications

Notification tab 111

notifications

- changing event 203
- closing 106
- displaying 55
- downloading sounds for 54
- enabling or disabling 204
- phone calls and 59
- previewing sounds for 55
- receiving messages and 105, 111
- receiving phone calls and 44
- receiving transmissions and 125
- receiving voicemail 41
- setting ringtones for 54

- setting system sounds for 202
- silencing sounds for 202
- troubleshooting 232

Notifications check box 203

Notifications tab 54, 203

Now Playing playlist 143, 144

Now Playing screen 143

number format settings 205

number pad 12

number sign symbol 205

Number tab 205

numbered lists 169

numbers

- See also* phone numbers
- entering 24, 25
- formatting 173, 177
- pasting into Calculator 198

O

Off Hold button 42

Office files 165

Office Outlook. *See* Outlook

Office Word documents. *See* documents

offline synchronization 236

Off-peak times options 73

OK button 5, 29

One Column option 116

online address book 93, 96, 151

online forums 247

online support (Palm) 247

Open URL command 142

opening

- ActiveSync 76
- alternate characters list 26
- applications 28, 195, 206
- attachments 91
- calculator 198
- Dial Pad 38
- documents 166
- email applications 242
- File Explorer 186
- items in folders 186
- menus 20, 22
- multimedia messages 106
- on-device documentation 247
- Outlook folders 236
- Phone Settings screen 14
- Picxel PDF Viewer 165
- Quick Tour 247
- templates 174
- text messages 106
- Today screen 12, 29
- web pages 115, 117, 119

- Wireless Manager 33
- operating system (device) 228, 253, 263
- operating systems (PCs) 75
- operational warnings 257
- Option key 18, 24, 25, 251
- Option Lock icon 25
- Option Lock mode 25
- options
 - displaying 155
 - highlighting 18, 19, 23
 - selecting 22, 23
- Options screen (ActiveSync) 81
- Options screen (Internet Explorer) 120
- Options screen (messaging) 95, 110
- Options tab 201, 209, 214
- organizer features 34, 147
- orientation (screen) 206
- orientation (slides) 172
- orientation options 206
- Orientation tab 172
- outages 231
- Outbox 108
- Outlook
 - accessing folders for 236
 - copying addresses to 236

- downloading messages
 - from 91, 92
- email client software and 240
- installing drivers for 224
- synchronizing with 70, 94
- Outlook E-mail screen 87, 89
- overdue tasks 159
- Override playback options 172
- owner information 214
- Owner Information icon 214
- Owner Information screen 214

P

- page breaks 166
- paired devices 126
- paired relationships. *See* partnerships
- pairing. *See* partnerships
- Palm (online support) 247
- Palm applications 188
- Palm devices 223
- Paragraph command 169
- paragraph formatting 169
- partial battery icon 10
- partnerships 123, 233, 251
- passkeys 53, 123, 124

- Password tab 213
- Password type list 213
- passwords
 - call-blocking and 57
 - corporate email accounts and 72
 - entering 71, 88, 213
 - forgetting or losing 213
 - locking smartphone and 210, 213
 - saving 88
 - spreadsheets and 173
- Paste command 138, 168
- patches 190
- patterns in workbooks 173
- Pause playback option 106, 145
- PCS phones. *See* wireless phones
- PDF files 165, 174
- PDF Viewer 165
- Peak times options 73
- performance 228, 243
- Personal Address Book 236
- personal computers
 - connecting to 77
 - enabling dial-up networking for 126
 - installing from 189

- reinstalling desktop
 - software on 224
- synchronizing with 81, 82
- system requirements 75
- viewing videos and
 - pictures on 139
- personal events 155
- personal identification
 - numbers (PINs) 60, 212, 251
- personal information 213, 214, 249
- personal information
 - managers 237, 251
 - See also* PIM applications
- Personal option 155
- Personal tab 54
- personalizing your
 - smartphone 199
- phone
 - See also* phone calls;
 - phone numbers;
 - smartphone
 - adjusting volume 13, 56
 - advanced features 41–47
 - answering 39, 44
 - customizing 54–62
 - dialing 12, 34–37, 38, 49
 - disabling touch-sensitive
 - feature for 211
 - hanging up 13, 42
 - network settings for 61
 - ringtones for 54, 55
 - running applications and
 - 42, 43
 - selecting wireless band for
 - 59
 - silencing ringer 40
 - specifications for 263
 - viewing minutes usage for
 - 47
 - waking up screen for 42
- phone calls
 - See also* phone; phone
 - numbers
 - adding a second 44
 - blocking 57
 - ending 13, 42
 - forwarding 46
 - hands-free devices and
 - 50, 54
 - making 12, 34, 38, 42, 107
 - placing on hold 42
 - receiving 39, 42
 - receiving notifications for
 - 59
 - restricting 60
 - sending to voicemail 39
 - setting up conference 45
 - troubleshooting 232, 245
- Phone dialog box 39
- phone headset 50–51
 - See also* headsets
- Phone icon 212
- phone lock feature 210
- phone numbers
 - See also* phone; phone
 - calls
 - assigning to speed-dial
 - buttons 48
 - copying 37, 39, 119
 - entering 12, 34, 37, 38
 - entering extra digits with
 - 49
 - locating smartphone 13
 - missing from Phone
 - Settings screen 14
 - redialing most recent 38
 - saving 43
 - selecting 20
- Phone Off message 33, 251
- Phone Settings screen 14, 57, 212
- phone status icons 62
- Phone tab 57

- Phone/Send button 5, 13, 35, 251
- Phone/Send icon 34
- phone-off icon 33
- photo albums 136
- photos. *See* pictures
- pick lists
 - accessing 22
 - exiting 23
 - highlighting in 18, 23
 - scrolling through 18
 - selecting items in 20, 23
- Picstel PDF Viewer 165
- picture files 102, 139
- picture formats 136
- Picture Speed Dial button 48
- picture speed-dial buttons 35, 48
- pictures
 - adding as backgrounds 138, 201
 - adding as screensaver 134
 - adding sounds to 104
 - adding to messages 103
 - adjusting resolution of 132, 139
 - creating caller ID 149
 - default resolution settings for 242
 - deleting 139
 - downloading 136
 - editing 138
 - hiding on web pages 116
 - naming groups of 135
 - previewing 132, 243
 - receiving 131
 - saving 135
 - sending 137
 - setting default size 135
 - storing 244
 - synchronizing 139
 - taking 131–132, 242
 - viewing 131, 136, 139
- Pictures & Videos application 133, 136–139
- PIM applications 249, 251
- PIMs 224, 237, 251
- PIN unlock key 251
- PINs 60, 212, 251
- Play button 141
- Play Slide Show command 136
- Play Sound box 55
- Play sound check box 203
- Play Sound list 216
- playback icons 49
- playback options 144, 172
- Playback screen 144, 145
- Playback tab 144, 172
- playing
 - media files 141
 - multimedia messages 106–107
 - presentations 171, 172
 - sounds 135
 - voice notes 161
 - voicemail messages 41
- playlists 140, 141, 143
- plug-ins 115, 201
- POP accounts 87
- pop-up menus 22
- port numbers 222
- portable radio. *See* radio
- ports. *See* IR port; USB ports
- Power icon 218
- Power screen 218
- Power/End button 5, 33
- PowerPoint files 163
- PowerPoint Mobile
 - application 171–172
- PowerPoint Mobile icon 171
- precautions 260
- preferences 111, 199, 225
 - See also* customizing
- preinstalled applications 190, 265
- presentations 171, 172

See also PowerPoint
Mobile
Preview Message command
104
Preview Mode (camera) 243
previewing
multimedia messages 104
pictures 132, 243
sounds 55, 204
videos 133
priority levels 105, 158
Priority list 90
privacy mode 105, 112
private events 155
Private option 155
processor 263
Program Buttons tab 207
Program Files folder 196
Programs check box 203
Programs screen 28
programs. *See* applications;
software
Prompt if device unused for
check box 213
Properties command 117
protected spreadsheets 173
protecting
information 210–214
Treo smartphone 210

proxy servers 221
PSW files 166
PUK (PIN unlock key) 251
punctuation marks 25, 27
Purge command 109
Purge screen 109
push email accounts 87, 90
push technology 70

Q

QCELP files 102
Quality command 133
Quick Keys 36, 48
Quick Tour 247
Quick Tour icon 247
QuickTime Player 139
quitting applications 28, 218

R

radio 257, 263
radio frequency emissions
255, 258
RAS connections 220
reassigning buttons 206–207
Receive all incoming beams
check box 193
receiving
attachments 91
beamed information 193

email 90, 91, 239
meeting requests 92
multimedia messages
105, 110
pictures 131
text messages 101, 105,
232
videos 131
Receiving Data message 193
recently-viewed web pages
119
rechargeable battery. *See*
battery
recipients, sending to
multiple 101
Record button action option
162
recording
sounds 203
videos 132–133
voice notes 209
Recording icon 161
recording toolbar 160
records (data) 192
recurring appointments. *See*
repeating appointments
redialing phone numbers 38
redirector (websites) 242
Refresh command 116

- refreshing web pages 116, 241
- Region tab 205
- regional settings 204, 214
- Regional Settings icon 204
- Regional Settings screen 204
- reinstalling software or applications 224, 226
- Reminder option 153
- reminders
 - adding 153, 158
 - events and 157
 - system alarms and 215
 - tasks and 159
 - turning on and off 203
- remote access servers 220
- remote files 221
- Remove Programs icon 190
- Remove Programs list 190
- Remove Programs screen 190
- Remove Split command 175
- removing
 - applications 190, 245
 - battery 225, 227
 - battery door 8
 - Bluetooth connections 124
 - certificates 217
 - contacts 150
 - directory services 93
 - documents 170
 - email accounts 89
 - events 156
 - expansion cards 194
 - favorites 118
 - files 187, 245
 - items from folders 186
 - items from libraries 143
 - items from playlists 144
 - messages 96, 109, 110
 - notes 162
 - partnerships 124, 233
 - pictures 139
 - speed-dial buttons 50
 - tasks 159
 - text 20
 - web files 120
 - workbooks 182
 - worksheets 182
- Rename command 197
- Rename/Move command 167, 170, 181, 196
- renaming
 - documents 170
 - expansion cards 197
 - items in folders 186
 - workbooks 181
 - worksheets 179
- Repeat check box 204
- Repeat command 142
- repeat patterns 154
- repeating appointments 154
- repeating current song 141
- repeating sounds 204
- repeating tasks 158
- Replace All button 167, 181
- Replace button 167, 181
- Replace text as you type check box 209
- replacing
 - information 181
 - text 167
 - the battery 226–227
- Request Delivery/Read Receipt check box 105
- Require PIN when phone is used check box 212
- reset button 6, 225
- resets 213, 224–226, 230
 - caution for 225
- resizing text 117
- resolution (camera) 242
- resolution (screen) 229, 242
- Resolution command 132, 242

restarting Treo smartphone.

See resets

restoring

backups 226, 239

information 225, 226

preferences and system

settings 225

sound settings 202

Resume playback option

106, 145

retrieving voicemail 41

Return key 24

reverse type 20

Revert to Saved command

139

revision marks 166

RF emissions 255, 258

RF Safety Statement 255

right action key 20

right-click menus. See

shortcut menus

ringer switch 7, 202

ringer volume 56

ringer, silencing 40

ringtone files 102

ringtone managers 243

ringtones

assigning to contacts 48,

56, 137, 150

creating video 137

downloading 54

previewing 55

selecting 54

roaming 74, 238

Roaming option 55

rotating pictures 134, 138

RTF files 165

RTSP files 136, 142

running multiple applications

28

Running Programs tab 29,

218

S

Safety Statement (FCC) 255

Save As command 118, 168

Save Image command 119

Save links... option 120

Save password check box

72, 88

Save to Contact Ring Tone

command 137

Save to Contacts command

44

Save to list 195

Save to option 162

Save to Template command

107

Saved folder 90

saving

documents 165, 166,

168, 170

email messages 90

files 195

multimedia items 107

multimedia messages 107

notes 161, 162, 209

passwords 88

phone numbers 43

pictures and videos 135

text messages 107

workbooks 172, 174, 182

Schedule command 73

Schedule screen 73

scheduled syncs 238, 240

schedules

adding items to 152, 153,

154, 157

managing 152–156

organizing events for 155

removing events 156

removing tasks 159

sorting tasks on 159

unavailable time on 155

viewing daily 152

scheduling synchronization

73–74

- ul style="list-style-type: none;">
- screen
 - activating items on 20
 - activating wrong features 229
 - adjusting brightness 204
 - adjusting display 204–206
 - aligning 205
 - arranging web pages on 116
 - battery life and 12
 - caring for 6
 - changing color themes for 201, 205
 - changing orientation 206
 - disabling touch-sensitivity for 210
 - locking 211
 - moving around on 17–19
 - scrolling in 18–19, 210
 - selecting items on 20
 - setting backgrounds for 138, 201
 - setting delays for 34
 - specifications for 264
 - troubleshooting 205, 229
 - turning on or off 33, 34, 218, 249
 - waking up 34, 42
- screen fonts 204
- Screen icon 204, 205
- screen resolution 229, 264
- Screen taps check box 203
- Screen view 205
- screens, returning to previous 19
- screensavers 134
- scroll arrows 18, 19
- scroll bar 19
- Scroll upon reaching the last line check box 210
- scrolling
 - slides 171
 - smartphone screen 18–19, 210
 - spreadsheets 175
 - web pages 116
- SD expansion cards 193
- SDP files 142
- SDP Streaming files 136
- Search button 186
- Search dialog box 185
- Search for list 185, 186
- Search icon 185
- search results list 185, 186
- searching
 - contacts list 36
 - documents 167
 - spreadsheets 181
 - web pages 115
- searching for files 185, 186
- searching for information 167, 181, 185–186
- searching for signal 12
- secure websites 242
- security 53, 123, 210–214, 217
- security certificates 115, 216
- security options (web) 121
- security software 210
- Security tab 120, 212
- Select All Text command 119
- selecting
 - applications 28
 - items in folders 187
 - items in lists 23
 - items on screen 19, 20
 - menu items 21, 22
 - options in lists 20, 22, 23
 - speed-dial entries 30
 - tabs 18
 - web links 19, 116
- self-portrait mirror 6, 132
- Send Link via E-mail command 117
- Send meeting requests via option 157

- Send outgoing items...
 - check box [74](#)
- Send Sound command [203](#)
- Send via E-Mail command [191](#)
- Send/Receive command [91](#)
- sending
 - copyrighted items [137](#)
 - email [90](#), [91](#), [97](#), [117](#), [239](#)
 - meeting requests [94](#), [154](#), [157](#)
 - multimedia messages [102](#), [104](#), [108](#)
 - pictures [137](#)
 - sounds [203](#)
 - text messages [40](#), [101](#)
 - videos [137](#)
- sensitivity options [155](#), [158](#)
- Sent folder [95](#), [108](#)
- servers, troubleshooting [238](#), [241](#)
 - See also* Exchange Servers
- service contracts [1](#)
- service providers [220](#), [231](#), [240](#)
- Services tab [46](#), [58](#), [59](#), [61](#)
- Set as Hands-Free command [232](#)
- Set as Today Background command [138](#)
- Set reminders for new items option [157](#), [159](#)
- Set up my proxy server option [221](#)
- setting alarm clock [216](#)
- settings. *See* options
- shaded lightning bolt [10](#)
- sharing information [191](#)
- sheet list [175](#)
- Shift cells options [182](#)
- Shift key [24](#), [25](#)
- Short Messaging Service. *See* SMS messaging
- shortcut menus [22](#)
- shortcuts [20](#)
- Show alphabetical index option [151](#)
- Show contact names only option [151](#)
- Show half hour slots option [156](#)
- Show icons option [157](#)
- Show list [136](#), [195](#)
- Show Options command [172](#)
- Show Pictures option [116](#)
- Show start and due dates option [159](#)
- Show Tasks entry bar option [159](#)
- Show time stamps of each message option [111](#)
- Show week numbers option [156](#)
- Shuffle command [141](#)
- side button [5](#)
- signal, searching for [12](#)
- signal strength [62](#), [229](#), [246](#)
- signal-strength icon [33](#), [220](#)
- Signature box [111](#)
- signatures [94](#), [111](#)
- Signatures screen [94](#), [111](#)
- silencing system sounds [7](#), [202](#)
- silencing the ringer [40](#)
- silent alarm [202](#), [204](#)
- SIM smartcards [8](#), [9](#), [212](#), [252](#)
- Size option [168](#)
- sketching [160](#)
- Skins tab [145](#)
- Slide Show tab [134](#)
- slide show toolbar [137](#)
- slide shows [134](#), [136](#), [171](#), [172](#)

- ul style="list-style-type: none;">
- slide timing option 172
- slider 19
- slides 104, 107
- smartcard. *See* SIM
- smartcards
- smartphone
 - caution for electrostatic discharge and 260
 - caution for resetting 225
 - caution for storing 6, 7
 - charging 9, 11
 - compatibility with
 - third-party vendors 75
 - compatible hands-free devices for 51
 - compliance statement for 256
 - components of 1, 5–7
 - connecting to PCs 77
 - disabling touch-sensitivity for 211
 - disposing of 258
 - features described 1
 - freeing space on 190, 244
 - getting help with 223, 247
 - getting phone number for 13
 - locking 213
 - losing 79, 214
 - low lighting conditions and 24
 - management tools for 183
 - moving around on 15
 - not responding 224, 230, 244
 - personalizing 199
 - required items for 2
 - resetting 213, 224–226, 230
 - setting up 8–14
 - specifications for 263
 - system requirements for 265
 - third-party applications and 243
 - troubleshooting 247
 - turning on and off 33, 256
 - unlocking 213
 - updating information on 65
 - usage guidelines for 255, 258
- SMS messaging 101, 252
- SMTP servers 240
- soft resets 224
- software
 - See also* applications
 - caution for hard resets and 225
 - compatibility with
 - Windows Mobile 228
 - included with smartphone 2, 265
 - installing 75, 187
 - purchasing 228
 - reinstalling 224, 226
- songs. *See* music
- Sort By command 159
- Sort by list 179, 186
- Sort command 109, 179
- sort options 159
- sort order 179
- sorting
 - folder items 170, 181, 186
 - History list items 119
 - information 179
 - messages 109
 - pictures and videos 138
 - tasks 159
- sound clips 102
- Sound Mode buttons 202
- sound settings 202
- sounds
 - adding to pictures 104
 - changing alarm 216
 - customizing 202

- playing 135
- previewing 55, 204
- recording 203
- selecting event 203
- sending 203
- setting ringtone 54
- setting system 202
- silencing 7, 202
- turning off event 203
- Sounds & Notifications
 - screen 54
- Sounds & Notifications
 - Settings icon 202
- Sounds & Notifications
 - Settings screen 202, 203
- Sounds tab 202
- Space key 24
- speaker 6, 140
- speakerphone 42, 245, 257
- Speakerphone command 42
- special characters 27
- special characters. *See*
 - alternate characters;
 - symbols
- special occasions 153
- specifications 263
- speech-impaired services 56
- Speed Dial Options
 - command 50
- speed-dial buttons 35, 47–50
- speed-dial entries 30
- Spell Check command 90
- spell-checking 90, 169
- Spelling command 169
- split bar 175
- spreadsheet templates 172, 174, 182
- spreadsheets
 - See also* Excel Mobile;
 - workbooks;
 - worksheets
 - accessing 163
 - adding charts to 180
 - calculations in 176
 - changing order of
 - worksheets 178
 - creating 172
 - defining filters for 180
 - deleting elements in 182
 - display options for 175
 - entering data in 174, 177
 - formatting 172, 178
 - insertion options for 177
 - scrolling 175
 - searching 181
 - sending 83
 - sorting in 179
- unsupported features for 174
- SSL (Secure Sockets Layer) 115
- standby mode 132
- Start button 5, 28
- Start menu 28, 206, 252
- starting
 - data connections 221
 - Excel Mobile 174
 - Internet Explorer Mobile 115
 - Media Player Mobile 141, 144
 - PowerPoint Mobile 171
 - Word Mobile 166
- static electricity 260
- status icons 62, 108
- stereo headphones 140
- still image compression level
 - list 135
- Still Mode command 133
- Stop command 142
- stopping playback 142
- stopping synchronization 82
- Storage Card folder 190, 197
- storage card symbol 186
- Storage Card tab 196, 218

- storage cards. *See* expansion cards
 - storage space **218, 238**
 - Storage tab **96**
 - storage temperatures **265**
 - storing
 - applications **245**
 - attachments **92, 96**
 - document files **168**
 - information **193, 244, 245**
 - passwords **72**
 - pictures **244**
 - smartphone **6, 7**
 - workbooks **181**
 - streaming **119, 252**
 - Streaming Media application **142**
 - Strikethrough option **169**
 - stylus **7**
 - submenus **22**
 - Suggest words when
 - entering text check box **209**
 - support **247**
 - Swap button **45, 46**
 - Symbol command **176**
 - symbols **26, 27, 49, 176**
 - Sync button **74**
 - sync cable **75, 77, 78**
 - sync conflicts **72**
 - sync schedules **238, 240**
 - synchronization
 - backing up information and **226**
 - battery life and **11**
 - benefits of **65**
 - defaults for **67**
 - defined **252**
 - hard resets and **225, 226**
 - overview **67**
 - preparing for **75**
 - scheduling **73–74**
 - setting options for **81**
 - setting up **71, 79, 80**
 - stopping **82**
 - troubleshooting **224, 233–239, 241**
 - synchronization software **69, 75, 236**
 - synchronizing
 - addresses **236**
 - dates and time **215**
 - email **11, 91, 233, 240, 241**
 - information **68, 69, 233**
 - manually **74**
 - media files **140**
 - multimedia files **139**
 - Office files **165**
 - offline **236**
 - over Bluetooth
 - connections **79**
 - over IR ports **80**
 - playlists **141**
 - through USB hubs **235**
 - wirelessly **68, 70, 79, 80, 233**
 - with multiple computers **81**
 - with sync cable **78**
 - with third-party
 - applications **75, 226**
 - system alarms **215**
 - system dates and time **214**
 - system errors **230**
 - system locks **210, 213**
 - system requirements **75, 265**
 - system settings **214–220, 225**
 - system sounds **7, 202**
 - system warnings **202**
- ## T
- tables in documents **166**
 - tabs **18**
 - taking pictures **131–132, 242**

- tapping 17, 20, 205
- tapping sounds 203
- task categories 158, 159
- Task tab 158
- tasks
 - adding notes to 158
 - completing 158
 - creating 157
 - customizing 159
 - deleting 159
 - displaying 159
 - filtering 159
 - filtering and sorting 159
 - marking as sensitive 158
 - setting due dates for 158
 - setting reminders for 158, 159
- Tasks application 157–159
- Tasks entry bar 157, 159
- Tasks icon 157
- Tasks list 159
- Tasks tab (Connections) 220, 221
- TDD devices 56, 257
- technical support 247
- telecommunications devices
 - for impaired. *See* TTY devices
 - devices
- temperature range 265
- templates
 - documents 167, 170
 - multimedia messages 107
 - notes 161, 162
 - spreadsheets 172, 174, 182
 - text messages 107
- Templates folder 167, 174
- tentative appointments 153
- text
 - aligning 169
 - changing 167
 - copying 119
 - deleting 20
 - entering 24, 25, 209, 210
 - finding and replacing 167, 209
 - formatting 168
 - highlighting 20, 169
 - moving or copying 167
 - resizing 117, 204
 - selecting 20
 - spell-checking 90, 169
 - word-processing features
 - for 166
- text captions 104
- text fields
 - moving to 18
- opening drop-down lists in
 - 23
 - removing text in 20
 - scrolling through 18
- text files 217
- text messages
 - creating 101
 - deleting 109, 110
 - forwarding 107
 - links in 108
 - opening 106
 - overview 99
 - phone calls and 42
 - phone numbers in 39
 - receiving 105, 232
 - replying to 107
 - saving 107
 - sending 40, 101
 - setting options for 104
 - sorting 109
 - troubleshooting 231
- Text Size tab 204
- Text Speed Dial button 48
- text speed-dial buttons 35, 48
- text telephone devices. *See* TTY devices
- themes 201, 205

- third-party applications
 - accessing Outlook folders and 236
 - caution for hard resets and 225
 - compatibility with 187
 - deleting 245
 - getting help with 244
 - installing 188, 243, 244
 - navigator and 17, 244
 - previewing pictures and 243
 - reinstalling 224, 226
 - screen resolution and 229
 - synchronizing with 75, 226
 - troubleshooting 188, 228, 243–244
- third-party vendors 75
- Thumbnail View 132, 133
- Thumbnails button 133
- TIF files 136
- time format settings 205
- time system settings 214
- Time tab 205, 215
- time units 153
- time zones 214, 238
- Timer 132
- tips 1
- title bar (Today screen) 30
- Today icon 201
- Today screen
 - accessing 12, 29
 - accessing Dial Pad from 38
 - color themes for 205
 - components of 30
 - customizing 138, 201
 - dialing from 34, 35, 37, 38
 - overview 29
 - recovering settings for 239
 - retrieving voicemail from 41
- Today Settings screen 201
- top view (smartphone) 7
- touchscreen. *See* screen
- touchscreen lockout 210, 211
- touch-sensitive feature 210
- transactions 242
- transferring
 - applications 196
 - files 140, 144, 195, 196
 - information 65, 223
- transition effects (slides) 172
- transmission delays 231
- Transparency level list 138
- Treo 770 smartphone. *See* smartphone
- troubleshooting 223, 247
- Trusted Device list 122
- trusted devices 121, 122, 125
 - See also* partnerships
- trusted pairs. *See* partnerships
- TTY devices 56, 257
- TTY/TDD options 57, 257
- Turn on Bluetooth check box 52, 122
- turning on or off
 - alarms 203, 216
 - caller IDs 58
 - Caps Lock 25
 - event sounds 203
 - keyboard backlight 24
 - Keyguard 211
 - Option Lock 25
 - reminders 203
 - ringer switch 202
 - screen 33, 34, 218
 - smartphone 33, 256
- TXT files 165
- Typing mode 162

U

- UMTS services 252
- unauthorized users 210, 217
- unavailable time slots 155
- Underline option 168
- underlining text 166, 168
- Undo command 139
- Unfreeze Panes option 175
- Unknown Caller option 55
- unlocking
 - SIM smartcards 212
 - smartphone 213
 - spreadsheet rows and columns 175
- unread messages 109
- unretrieved voicemail 41
- unsafe areas 256
- untimed events 153, 154
- Update Library command 143
- updating information 65
- upgrades 223
- uppercase letters 25, 210
- urgent message icon 109
- URLs 142, 171
 - See also* web links
- USB connections 125
- USB controllers 236
- USB hubs 235

- USB ports 77, 235
- USB sync cable 77
- Use above settings while roaming check box 74
- Use network time zone check box 215
- user discussion groups 247
- User Guide* 247
- usernames 252

V

- Validity Period list 105
- vCal attachments 240
- vCard attachments 104, 240
- Vibrate when... check boxes 55, 204
- vibrating alarm 202, 204
- video albums 136
- video file types 136
- video files 102, 139, 237
- Video Mode command 133
- video options 145
- video ringtones 131, 137
- Video tab 135, 145
- videos
 - adding sounds 135
 - adding to messages 103
 - changing resolution 133
 - defaults for 135
 - downloading 139, 140
 - limiting length 135
 - previewing 133
 - receiving 131
 - recording 132–133
 - saving 135
 - sending 137
 - setting resolution for 242
 - synchronizing 139
 - viewing 131, 136, 139
- View By command 150
- View command 116, 151
- View Recording Toolbar command 160
- viewing
 - alternate characters 26
 - animated images 139
 - applications on
 - smartphone 28
 - appointments 152
 - calendar 151
 - contacts 37, 150
 - current connection 220
 - daily schedules 152
 - events 153, 155
 - folder contents 186
 - items in folders 170, 181
 - memory usage 218
 - multimedia messages 107

- notifications 55, 204
 - on-device documentation 247
 - PDF files 165
 - pictures 131, 136, 139
 - power settings 218
 - Quick Tour documentation 247
 - running applications 218
 - space on expansion cards 196, 218
 - tasks 159
 - videos 131, 136, 139
 - web pages 115, 116
 - wireless settings 219
 - virtual private networks. *See* VPN connections
 - voice captions 103
 - Voice Command button 208, 209
 - Voice Command icon 228
 - Voice Command screen 208
 - Voice Command settings 208, 228
 - voice commands 11, 209
 - Voice mail option 55
 - voice notes 160, 209
 - Voice recording format list 209
 - voice recording formats 209
 - voicemail
 - customizing 49, 55
 - receiving notifications for 41
 - retrieving messages 41
 - sending calls to 39, 44
 - setting up 40
 - viewing minutes usage for 47
 - voicemail buttons 49
 - Voicemail icon 40, 41
 - voicemail systems 40
 - volume
 - phone 13, 56
 - ringer 56
 - tapping sounds 203
 - Volume button 5, 13, 56
 - VPN clients 221, 233
 - VPN connections 87, 92, 221
 - VPN software 221
- W**
- waking up screen 34, 42
 - wallpaper 131
 - warnings 202, 257
 - warranty 2
 - WBMP files 102
 - weak signals 229, 246
 - web addresses 30, 116, 242
 - See also* web links
 - web browser. *See* Internet Explorer Mobile
 - web browsing
 - memory consumption and 245
 - requirements for 1
 - secure sites and 115, 116, 242
 - troubleshooting 241
 - web files 120
 - web links
 - clearing 120
 - internal memory and 245
 - messages and 108, 117
 - Palm online support 247
 - selecting 19, 116
 - troubleshooting 242
 - web pages
 - accessing 115, 117, 119, 241
 - arranging on screen 116
 - clearing links to 245
 - copying from 119
 - dialing from 39, 119
 - display options for 116
 - downloading items from 118, 189

- hiding images on 116
- moving through 116
- playing media files from 142
- refreshing 116, 241
- resizing text on 117
- returning to recently viewed 119
- scrolling 116
- searching 115
- security settings for 121
- selecting addresses on 242
- sending email from 117
- setting as home 120
- viewing 115, 116
- Web search field 115
- web-based mail systems 85
- websites
 - See also* web browsing
 - accessing 113
 - compatibility with 115
 - connecting to 115, 125
 - ending connections to 222
 - redirectors and 242
 - searching over 115
 - submitting transactions and 242
- week numbers 156
- Week View 152, 156
- Week view option 156
- Windows Media Player 119
- Windows Mobile devices 192, 223
- Windows Mobile Getting Started Disc 2, 187
- Windows Mobile operating system 228, 253
- Windows Mobile software 188
- wireless band setting 59
- wireless connections 113, 121, 125–127
- wireless coverage 2, 12, 33
- wireless features 113, 219, 243
- Wireless Manager 33, 219
- Wireless Manager command 33
- wireless modems 125
- wireless phones 259, 260
- wireless services 219
- wireless synchronization 68, 70, 79, 80, 233
- WMA files 136, 140
- WMV files 136, 140
- Word application 163
 - See also* documents
- Word Completion tab 209
- word matching 167, 181
- Word Mobile application 18, 165–171
- Word Mobile icon 166
- word-processing features 166
- workbook list 182
- workbooks
 - See also* Excel Mobile application;
spreadsheets
 - creating 174
 - deleting 182
 - displaying 175
 - moving around in 175
 - naming 181
 - organizing 181
 - replacing information in 181
 - saving 172, 174, 182
 - searching 181
 - setting default template for 182
- worksheet names 173
- worksheets
 - See also* spreadsheets;
workbooks
 - adding 178

adjusting column and row
size for 179

deleting 182

entering defined names in
178

entering formulas in 176,
182

entering functions in 176

filtering data in 179

formatting options for 178

inserting cells, rows, and
columns 177

moving between 175

naming 178

removing cells, rows, and
columns 182

renaming 179

Writing mode 162

Y

Year View 152

Z

ZIP files 187

zoom buttons (camera) 132

Zoom command 117, 167

zoom icons (presentations)
171

Zoom In command 171

zoom options 132

zoom settings 173, 175, 210