

# **MobileAccessVE Dual-Band Instant Coverage Solution User Manual**

**P/N: 709C004904  
REV: A01  
Date: JUNE 2011**

MobileAccess

8391 Old Courthouse Road, Suite 300, Vienna, VA 22182

Tel: +1(866)436-9266, +1(703)848-0200 TAC: +1(800)787-1266, Fax: +1(703)848-0280

<http://www.MobileAccess.com>

## Preface Material

© Copyright 2011, MobileAccess. All Rights Reserved.

This document contains confidential and proprietary information of MobileAccess and may not be copied, transmitted, stored in a retrieval system or reproduced in any format or media, in whole or in part, without the prior written consent of MobileAccess. Information contained in this document supersedes any previous manuals, guides, specifications, data sheets or other information that may have been provided or made available to the user.

This document is provided for informational purposes only, and MobileAccess does not warrant or guarantee the accuracy, adequacy, quality, validity, completeness or suitability for any purpose of the information contained in this document. MobileAccess reserves the right to make updates, improvements and enhancements to this document and the products to which it relates at any time without prior notice to the user. MobileAccess makes no warranties, express or implied, including, without limitation, those of merchantability and fitness for a particular purpose, with respect to this document or any information contained herein.

## Policy for Warrantee and Repair

MobileAccess tests and inspects all its products to verify their quality and reliability. MobileAccess uses every reasonable precaution to ensure that each unit meets their declared specifications before shipment. Customers should advise their incoming inspection, assembly, and test personnel about the precautions required in handling and testing our products. Many of these precautions can be found in this manual. The products are covered by the following warranties:

### **General Warranty**

MobileAccess warrants to the original purchaser all standard products sold by MobileAccess to be free of defects in material and workmanship for one (1) year from date of shipment from MobileAccess. During the warranty period, MobileAccess will repair or replace any product that MobileAccess proves to be defective. This warranty does not apply to any product that has been subject to alteration, abuse, improper installation or application, accident, electrical or environmental over-stress, negligence in use, storage, transportation or handling.

### **Specific Product Warranty Instructions**

All MobileAccess products are warranted against defects in workmanship, materials and construction, and to no further extent. Any claim for repair or replacement of units found to be defective on incoming inspection by a customer must be made within (30) days of receipt of shipment, or within (30) days of discovery of a defect within the warranty period.

This warranty is the only warranty made by MobileAccess and is in lieu of all other warranties, expressed or implied. MobileAccess sales agents or representatives are not authorized to make commitments on warranty returns.

## Returns

In the event that it is necessary to return any product against above warranty, the following procedure shall be followed:

1. Return authorization is to be received from MobileAccess prior to returning any unit. Advise MobileAccess of the model, serial number, and discrepancy. The unit may then be forwarded to MobileAccess, transportation prepaid. Devices returned collect or without authorization may not be accepted.
2. Prior to repair, MobileAccess will advise the customer of our test results and any charges for repairing customer-caused problems or out-of-warranty conditions etc.
3. Repaired products are warranted for the balance of the original warranty period, or at least 90 days from date of shipment.

## Limitations of Liabilities

MobileAccess's liability on any claim, of any kind, including negligence for any loss or damage arising from, connected with, or resulting from the purchase order, contract, quotation, or from the performance or breach thereof, or from the design, manufacture, sale, delivery, installation, inspection, operation or use of any equipment covered by or furnished under this contact, shall in no case exceed the purchase price of the device which gives rise to the claim.

EXCEPT AS EXPRESSLY PROVIDED HEREIN, MOBILEACCESS MAKES NO WARRANTY, EXPRESSED OR IMPLIED, WITH RESPECT TO ANY GOODS, PARTS AND SERVICES PROVIDED IN CONNECTION WITH THIS AGREEMENT INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. MOBILEACCESS SHALL NOT BE LIABLE FOR ANY OTHER DAMAGE INCLUDING, BUT NOT LIMITED TO, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH FURNISHING OF GOODS, PARTS AND SERVICE HEREUNDER, OR THE PERFORMANCE, USE OF, OR INABILITY TO USE THE GOODS, PARTS AND SERVICE.

## Reporting Defects

The units were inspected before shipment and found to be free of mechanical and electrical defects. Examine the units for any damage that may have been caused in transit. If damage is discovered, file a claim with the freight carrier immediately. Notify MobileAccess as soon as possible.

**Note:** Keep all packing material until you have completed the inspection

## Safety Warnings

To comply with FCC RF exposure compliance requirement, adhere to the following warnings:

**Warning!** The Access Pod with its built-in antenna must be installed with a separation distance of at least 20cm from all persons and must not be located in conjunction with any other antenna.

**Warning!** The outside antenna must be installed with a separation of at least 20cm from all persons and must not be located in conjunction with any other antenna.

**Warning!** Use of this Access Pod with antennas other than those illustrated could be hazardous. Before using other antennas, contact MobileAccess Support.

**Caution:** Double pole/neutral fusing (two fuses in the appliance inlet)

## Approved Antennas for use with the MobileAccessVE Solution

The gain of external antennas connected to the VAPs should not exceed 10 dBi.

## Compliance with RF Safety Requirements

MobileAccess products have no inherent significant RF radiation.

The RF level on the down link is very low at the downlink ports. Therefore, there is no dangerous RF radiation when the antenna is not connected.

## Certification and Compliance to Standards

Category		Standards
Safety:		IEC 60950-1: 2003; UL-60950-1:2003; CAN/CSA – C22.2 No 60950-1-03
EMC:		EN 301489-8 V1.2.1:2002; EN 301489-1 V1.5.1:2004; EN 61000 V4.6:2005 EN 55022 V4.2:2001 / FCC Part 15; VCCI Class A for VCU and Class B for VAP
Radio:	GSM/DCS	EN-301502 V8.1.2: 2001; EN-301908 v3.2.1:2006; EN 300 609-4 V8.02:2000
	CELL/PCS	FCC Part 24
	UMTS	EN 301 908-11
SAR Body Testing		EN 50385 & FCC OET65C:2001

## About This Guide

This guide provides essential product functionality with all the information necessary for proper installation and configuration of the MobileAccessVE system.

## List of Acronyms

Abbreviation	Description
DB	Dual-Band
PoE	Power Over Ethernet
STP	Shielded Twisted Pair
UTP	Unshielded Twisted Pair
VAP	VE Access Pod
VCU	VE Control Unit
UMTS	Universal Mobile Telecommunications System
EGSM	Extended Global System for Mobile Communications
PCS	Personal Communications Service
DCS	Digital Cellular System

# Table of Contents

<b>1</b>	<b>Overview</b>	<b>1</b>
1.1	Key Features and Capabilities	2
1.2	System Architecture	3
1.3	System Elements	4
1.3.1	VE Control Unit (VCU)	4
1.3.1.1	VCU Front Panel	4
1.3.1.2	VCU Rear Panel	6
1.3.2	VE Access Pod (VAP)	6
1.4	System Monitoring and Management	8
1.4.1	Integration with an External Fault Management System	8
<b>2</b>	<b>Installation Workflow</b>	<b>9</b>
<b>3</b>	<b>Infrastructure Requirements and Layout Planning</b>	<b>10</b>
3.1	General Information on Location and Connections	10
3.2	Infrastructure Requirements	11
3.3	Coverage and Installation Planning	12
3.3.1	Types of Environments	12
3.3.1.1	Standard Environment	13
3.3.1.2	Open Environment	13
3.3.1.3	Dense Environment:	13
3.3.1.4	Combination of Environments	14
3.4	Planning VAP Layout	14
3.4.1	RF Coverage Factors	14
3.4.2	Mapping Locations	14
3.4.3	Optional Directional Antennas	15
3.4.4	Installation Plan Example	15
<b>4</b>	<b>VCU Unit Installation and Provisioning</b>	<b>17</b>
4.1	VCU Kit Contents	17
4.2	VCU Physical Installation	18
4.2.1	Master VCU Installation	18
4.2.1.1	Master VCU Alarm Output Connections	19
4.2.2	Slave VCUs Installation	20

4.3	Ethernet Cable Connections to VAPS .....	22
4.3.1	Shifting Relevant Ethernet LAN Connections.....	22
4.3.2	Operation with LAN Utilizing Power over Ethernet (PoE) .....	23
4.4	Provisioning the VE Control Unit.....	24
4.4.1	Configure the Computer IP Parameters.....	24
4.4.2	Provisioning the Master VCU Unit .....	25
4.4.3	Provisioning the Slave VCUs .....	32
<b>5</b>	<b>VAP Installation and Provisioning .....</b>	<b>34</b>
5.1	VAP Installation .....	34
5.2	Desk and Wall Mount VAP Installations .....	35
5.2.1.1	VAP Kit Contents .....	35
5.2.1.2	Desk Mount Installation .....	36
5.2.1.3	Wall Mount Installation .....	37
5.2.2	Horizontal Ceiling Mount VAP Installations .....	38
5.2.2.1	VAP Kit Contents .....	38
5.2.2.2	Lowered Ceiling Installation .....	39
5.2.2.3	Concrete/Wood Ceiling Installation .....	40
5.2.3	Vertical Ceiling Mount VAP Installations .....	42
5.2.3.1	VAP Kit Contents .....	42
5.2.3.2	Lowered Ceiling Installation .....	43
5.2.3.3	Concrete/Wood Ceiling Installation .....	44
5.3	Verifying Coverage.....	45
5.4	Naming the VAPs, Verifying Connections, and Monitoring .....	46
<b>6</b>	<b>Navigating the Web Access Application .....</b>	<b>49</b>
6.1	Opening a Session and Authentication Levels .....	49
6.2	About the MobileAccessVE Web Access Window.....	50
6.3	Configuration Tab .....	51
6.3.1	Network Topology Tree .....	52
6.3.1.1	Removing Network Element from Baseline .....	53
6.3.2	Configuration Display Area .....	54
6.4	Management Tab.....	55
<b>7</b>	<b>VCU Monitoring and Configuration.....</b>	<b>56</b>
7.1	Viewing VCU General Information .....	56
7.2	Viewing VCU Alarms.....	57
7.3	Master VCU RF Parameters.....	58



---

<b>8</b>	<b>VAP Monitoring and Configuration</b>	<b>60</b>
8.1	Viewing VAP General Information	60
8.2	Viewing VAP Alarms	61
8.3	VAP RF Parameters	62
<b>9</b>	<b>Administrative Operations</b>	<b>64</b>
9.1	Changing Password	64
9.2	Retrieving VCU IP Address	65
9.3	IP Settings	67
9.4	SNMP Configuration Parameters	68
9.5	Upgrading (or Downgrading) VCU and VAP Software	69
9.5.1	Upgrading the VAP SW	70
9.5.2	Upgrading the VCU SW	72
<b>10</b>	<b>Troubleshooting</b>	<b>73</b>
10.1	Finding a Specific VAP in the Building	73
10.2	Wireless Service is Not Available	75
10.3	PoE is Not Working	75
10.4	Ethernet Service is Degraded	76
10.5	No Service from Connected Access Pod	76
10.6	VCU Cannot be Monitored via SNMP	78
	<b>Appendix A - Traps</b>	<b>79</b>
	VE Control Unit (VCU) Traps	79
	VE Access Pod (VAP) Traps	79
	<b>Appendix B – MobileAccess VE Dual Band MIB Tree Structure (Version 1.8)</b>	<b>80</b>
	MobileAccess Version 1.8 MIBs/OID Descriptions	83

# 1 Overview

The MobileAccessVE Dual-Band solution provides enhanced, cost effective, in-building coverage of two services (from a range of available service combinations) for any (small-to-large) sized enterprise environment. This solution is quickly and easily deployed using the existing Ethernet cabling infrastructure, without affecting existing LAN services or performance.

The VE solution converges wireless services from the service provider's equipment and Ethernet services from the corporate LAN, via a VE Control Unit located in the communication closet. The converged services are routed to VE Access Pods (VAPs) installed throughout the enterprise. The VAPs are distributed on each floor and plug into existing standard Ethernet jacks.

The VAPs provide wireless services coverage via integrated internal antennas (or optional external antennas). The VAPs also provide Ethernet connectivity to the LAN terminals (that were previously connected to the jacks).

They are powered via Power over Ethernet (PoE) technology and managed via the VCU located in the floor's IDF/Telco closet. For site coverage that requires more than one VCU, several VCUs can be aggregated under a single Master VCU. The Master VCU provides the interface to the carrier's capacity sources and management.


MobileAccessVE seamlessly coexists with the Enterprise LAN and does not consume LAN capacity. This enhanced Dual-Band coverage solution can be quickly and easily installed with minimal disturbance to the enterprise. In less than a few hours and with no additional cables being required, a scalable and flexible solution is provided at a significantly lower total installation cost.

Currently, the VE Dual-Band system is available for the following band combinations:

- EGSM-UMTS
- CELL-PCS Full Band
- DCS-UMTS


The following figures illustrate *single-tier* and *multi-tier* VE installations.

In a single-tier installation the VCU is connected to both the service provider's equipment and the Ethernet switch, and distributes Ethernet and mobile services to up to 12 VAPs distributed over one more adjacent floors.



*Figure 1-1. Single-Tier VE Installation*

Multi-tier installation includes the Master VCU that supports up to 12 Slave VCUs. In this type of installation the provider's services are fed to the Master VCU through which the Slave VCUs are controlled and managed.



*Figure 1-2. Multi-Tier VE Installation*

## 1.1 Key Features and Capabilities

- Supports the following frequency ranges:
  - EGSM: 925 – 960; UMTS: 2110 - 2170
  - DCS: 1805 – 1880; UMTS: 2110 - 2170
  - Full Band CELL: 869 – 894; Full Band PCS: 1930 - 1990
- Simple installation - Deployed in only a few hours, with minimum disturbance to the enterprise.
- VAPs connect over existing CAT-5e/6 cabling infrastructure and utilize existing Ethernet jacks.
- VAPs are remotely powered using Power-over-Ethernet (PoE). Local power is not required.
- Minimum macro-network impact with low power distributed coverage.
- Seamlessly coexists with the Enterprise LAN and does not consume LAN capacity.
- Connects to all types of capacity sources: BTS, Picocells, Femtocells and BDAs.
- VAPs can be easily relocated for coverage modifications as needed.
- Ease of expansion provides “pay as you grow” scalability.
- Support of connected IP devices (Wi-Fi APs, IP Phones, etc) with Ethernet/IP pass through and PoE maximizes placement flexibility.
- Baseline feature that clearly shows VAPs and VCUs in which communication has been lost and generates corresponding alarms.
- Remote end-to-end system monitoring, management, and configuration via a single connection to the master VCU using a standard web browser and SNMP.

## 1.2 System Architecture

**Main Elements** - The MobileAccessVE solution is based on the following main elements:

- **VE Control Unit (VCU)** – installed in the communication room or shaft. Converges the Ethernet and RF signals and provides secure, central management to up to 12 VAPs or (Slave) VCUs in any combination. The same unit model can be configured either as Master or Slave depending on the installation topology:
- **Master VE Control Unit (Master VCU)** – Installed in the main communication IDF/Telco closet, interfaces to the service provider's RF equipment, and provides secure, central management to up to twelve VCUs and VAP devices in any combination.
- **Slave VE Control Unit (Slave VCU)** – Used to expand coverage to additional floors. Installed in the IDF/Telco closet of the relevant floor. Each Slave VCU interfaces the Master VCU and up to twelve VAPs and twelve Ethernet connections.

The Master and Slave VCUs are connected using *dedicated* CAT-6/7 cables. VCUs distribute wireless service signals to each VAP along with PoE and where relevant Ethernet signals from the Ethernet switch, throughout the *existing* CAT-5e/6 infrastructure.

- **VE Access Pod (VAP)** – These are pluggable antennas distributed at strategic locations on the floor to provide Ethernet connection to an IP device and wireless coverage of the service via integrated internal (or external) antennas. Power to VAPs is provided via PoE from the VCU.


Up to twelve VAPs can be connected to a single VCU using LAN cables (CAT-5e or higher).

---

Note: If the total number of VAPs in the deployment exceeds 72, consult with MobileAccess support.

---

The following figure shows the Multi-tier Dual-Band VE solution architecture.



*Note: If the Master VCU supports VAPs (in addition to VCUs), the relevant Ethernet ports are also connected to an Ethernet switch.*

Figure 1-3. VE Multi-Tier Basic Architecture

---

Note: Connecting both VAPs and slave VCUs to the master VCU simultaneously is supported only with VE network elements running SW version 2.6 and above

---

# 1.3 System Elements

This section describes the interfaces of the VE Control Units and Access Pods.

## 1.3.1 VE Control Unit (VCU)

The VCU can operate as either Master/Standalone or Slave. The front panel supports all the RF, control and optic interfaces, while the rear panel contains the power and alarms interfaces.

### 1.3.1.1 VCU Front Panel

The VCU front panel provides interfaces to RF, management VAP, and VCU interfaces. The type of RF interfaces may vary depending on the VCU model. Below are two models: the top model supports only Duplex N-type interface, while the bottom model supports both Simplex and Duplex QMA connections.




Figure 1-4. Example of VCU with Duplex RF Connectors



Figure 1-5: Example of VCU with both Simplex and Duplex RF Connectors

Interfaces	Description
RF Source	RF connections to the RF source: simplex or duplex, N-type or QMA depending on the model.
Management	Relevant only for Master or Standalone VCU. RJ45 WEB management connection to Master or Standalone VCU.
VE Access Pod Ports 1-12	VAP and or VCU connections (in any combination): Master VCU – Connections to Slave VCUs or VAPs. Slave VCU – Connections to VAPs.
Ethernet Ports 1-12	Ethernet switch connections. Relevant for VCUs with connected VAPs. Connect according to corresponding VAP connections.
Master	Relevant for Slave VCUs. Connection towards Master VCU VE Access Pod Ports.
Reset	N/A in current version.

Interfaces	Description
PWR and ACT LEDs	PWR - VCU power source: Green - Power OK Disabled - No power received by VCU ACT VCU activity LED: Solid Green - During initialization Blinking Green - Normal operation Fast Blinking Green - User activated <i>VCU Identify</i> on this VCU
VAP Status (One LED per Port)	Status of the <i>corresponding</i> unit (VAP or VCU) Blinking Green - Unit is initializing Solid Green - Normal operation of unit Solid Orange - Unit is faulty, or unmanaged. This can be due to mismatch type, VoIP phone, etc. Fast Blinking Green - User selected "Identify" command on the unit Off - No VAP or VCU connected to this port.
RF (One LED per Service)	Status of connected RF capacity source: Green - Master VCU only. Normal RF level Orange - Master VCU only. RF level is either too low, too high, or service has been turned off by the user. Off - VCU is Slave.
Master	Status of the connection to the Master VCU: Off - Master mode (not connected to VCU) Blinking Green - During attachment process with Master VCU Solid green - Slave (IF-IF) mode and connected to Master

Table 1-1: VCU Ports Description

### 1.3.1.2 VCU Rear Panel

The rear panel includes the following: power switch, AC input, AUX alarms, and service personnel connections.




Figure 1-6. VCU Rear Panel

Table 1-2: VCU Rear Panel Description

Connector	Description
Console	RS232 local connection for service personnel (D-Type 9)
Alarms	AUX Alarms Connections – (See section 4.2.1.1). <i>In Master/Slave configuration - relevant only for Master VCU.</i>
Power Input	Standard 3-pins AC power connector equipped with an ON/OFF switch. 90-264V AC, 47-63 Hz AC; 350W power consumption maximum.

### 1.3.2 VE Access Pod (VAP)

Each VAP supports:

- Internal antennas and two interfaces for external antennas. By default, the VAP is set to transmit through the integrated internal antennas. To use the external antennas connectors, select the “External Antenna” option in VAP Config-Service RF tab of the VE Web GUI application (See section 8.3).
- An Ethernet port for physical Ethernet connection to devices such as a computer, IP phone or Wi-Fi Access Point.
- Two LED status indicators.

The VAP can be mounted on the wall or placed on a flat surface. Brackets are provided for each type of installation.

The following figure shows the desktop VAP.



Figure 1-7. VE Access Pod-Front

Table 1-3: VAP LEDs

LED	Description
Power	Solid Green - Power supplied to VAP
	Off - No power supplied to VAP
Activity	Off - No power supplied to VAP or Overall Status of VAP is faulty
	Blinking Blue - Power on, VAP is initializing (connecting to VCU)
	Solid Blue - Power on, unit operating normally
	Fast Blinking Blue - User invoked "Identify" command on corresponding VAP

The following figure shows the desktop VAP rear side and the underside view with the CAT-5e/6 patch-cord cable.




Figure 1-8. VE Access Pod



## 1.4 System Monitoring and Management

The MobileAccess**VE** system (Master VCU, Slave VCUs, and VAPs) is centrally managed via a single Web connection to the Master VCU. The basic screen in the GUI is the **Config** tab, which enables the user to view the system topology and setup parameters, control units, and all Access Pods connected to the control units.

Note: When locally connecting to a specific Slave VCU, only the VAPs connected to this VCU can be monitored. When connected to the Master, the entire deployment can be monitored.

The following figure shows the Master VCU with a single Slave VCU and its nine VAPs. The session is opened by a connection to the Master VCU.




### 1.4.1 Integration with an External Fault Management System

The MobileAccess**VE** system can be seamlessly integrated into any existing Fault Management (FM) system that supports SNMP events. The Master VCU generates a SNMP event for each relevant system alarm and forwards this trap to the pre-configured IP address of the external Fault Management system.

## 2 Installation Workflow

The following figure summarizes the main steps of the installation procedure:

### Installation Workflow



## 3 Infrastructure Requirements and Layout Planning

### 3.1 General Information on Location and Connections

- Service provider's RF equipment (Macrocell, Microcell, Picocell, Femtocell, BDA, etc.) connects to the VCU through a passive interface.
- VCUs:
  - Master VCU installed at the main IDF/Telco cabinet and connected to all VCUs.
  - Slave VCUs installed at the IDF/Telco cabinet of each covered floor and connected to the Master VCU, the Ethernet switch, and the VAPs through the cabling patch panel.
- Wireless service signals from Master VCU to VCUs – Routed through dedicated Ethernet CAT-6/7 cabling.
- Wireless service signals from VCUs to the VAPs – Routed through existing Ethernet CAT-5e/6 cabling infrastructure.
- VAP location and mounting – Wall or desk mounting. Connection to existing Ethernet jack and external antenna if required.
- VAP power source - No power connections required. VAPs are power fed from VCU using PoE (Power over Ethernet) technology.




Figure 3-1. VE Multi-Tier Basic Architecture

## 3.2 Infrastructure Requirements

Ethernet standards specify that the maximum distance between an Ethernet switch and an appliance (computer, WLAN AP etc) should not exceed 100m (300ft). Therefore, when VE shares the IT LAN, the maximum distance for a given cable run cannot be longer than 100m (300ft) between the Ethernet switch and appliance, including all patch cords (from switch to VCU, from VCU to patch panel, from RJ-45 outlet to VAP, and from VAP to appliance).

Typically the horizontal cabling system will be connected to patch-panels in the communication rooms. The entire cabling system, including the patch panels and patch cords, should adhere to the CAT-5e/6 standard. Specifically all pairs of the CAT-5e cable should be wired in the patch panels (and patch cords).

1. IDF/Telco closet space for one or more VCUs depending on the number and locations of the installed VCUs: (48.3cm x 51.3cm x 8.88cm) per VCU.

---

Note: When planning the IDF/Telco shaft, take the RF equipment (picocell/microcell or BDA) and the VCU into consideration.

---

2. 350 Watts of AC power to the VCU IDF/Telco closet.
3. Building infrastructure:
  - CAT-5e/6 cabling, Shielded Twisted Pair (STP)
  - 24 AWG minimum diameter for CAT-5e cabling
  - Dedicated CAT-6/7 STP cable from Master VCU to Slave VCUs with run lengths NOT exceeding 100m (300ft) and no shorter than 10m (33ft).
  - CAT-5e/6 STP cable from VCU to each VAP with run lengths NOT exceeding 100m (300ft) and no shorter than 10m (33ft). VAPs can be connected over existing CAT-5e/6 cabling infrastructure and existing Ethernet jacks without affecting the LAN.

---

Note: Verify with IT department that the existing cables can support the VE installation. If available, review the infrastructure documentation to determine cable types and lengths. If documentation is not available, attempt to visually identify the cable type. Depending on the cable vendor, the cable type may be listed on the cable sheath. Its' recommended to use a Fluke cable tester to measure the cable length of the most remote VAPs.

---

4. Master VCU Cable Connections:
  - (2) N-type female, 50 ohm interfaces to carrier equipment or
  - (6) QMA connectors for MIMO1 and MIMO2 Simplex and Duplex connections to carrier equipment – CELL/PCS Full-Band VCUs only
  - Up to (12) RJ-45 interfaces to Slave VCUs and/or VAPs
  - (1) RJ-45 interface to Management
  - (1) D-Type 9 pins RS-232 interface for local craft
  - (1) D-Type 15 pins interface for External Alarms (dry contacts)
5. Slave VCU Cable Connections
  - (1) RJ-45 interface to Master VCU (not used in small single-tier deployments)
  - (12) RJ-45 interfaces to VAPs

- (12) RJ-45 interfaces to Ethernet Switch for LAN service
- (1) D-Type 9 pins RS-232 interface for local craft

## 3.3 Coverage and Installation Planning

---

Note: The following section provides information required for planning the VAP installation on a single floor. In a multi-tier installation, this procedure is performed for each individual floor.

---

The maximal coverage area of each VAP is affected by the density and type of environment being covered. Therefore, it is recommended to determine the location in two phases:

- Plan the *ideal* location of each VAP in order to achieve complete coverage of the floor.
- Select the *exact* location according to the location feasibility, where each VAP unit may be wall or desk mounted and an option for an external antenna is available.

The supplied services (wireless only or Ethernet and wireless) depend on the jack to which the VAP is connected:

- If the jack supports an active Ethernet connection, the VAP will distribute LAN traffic along with the wireless service. (See section 4.3).
- If the jack is not currently active (not connected to an Ethernet switch), the VAP will distribute only the wireless services.

This section provides information on coverage criteria in various types of environments (Open, Standard, Dense, and Merged) and provides rules-of-thumb for various installations of the VAPs.

---

Note: See section 3.4, which provides a detailed example of installation planning in various types of environment. It is recommended to review this example after reading this section.

---

### 3.3.1 Types of Environments

This section describes the different types of installation environments and provides guidelines for best coverage of each type of space.

The coverage guidelines in this section are conservative “rule of thumb” estimates of RF coverage per VAP, meant to be used in scenarios in which detailed designs are not performed. When the coverage layout is designed, the coverage per VAP is expected to increase by up to 33%. Coverage estimates in this section assume 25% overlap between the coverage areas of neighboring VAPs to ensure robust, full coverage throughout the enterprise with no “dead zones”.

The coverage guidelines in the following tables are provided for the *higher* frequency bands (UMTS & PCS). The lower frequency bands (DCS, EGSM & CELL) are omitted from the tables since coverage in these bands will be better than that of the higher frequency bands. The coverage of a dual-band system will be determined by the higher frequency band (i.e. PCS for CELL/PCS and UMTS for EGSM/UMTS and DCS/UMTS).

### 3.3.1.1 Standard Environment

A standard environment is a traditional office environment with offices, hallways, and scattered cubicles.

Table 3-1: Standard Environment Installation Distances

Band	PCS	PCS	UMTS
Technology	CDMA or GSM	WCDMA	WCDMA
Downlink Frequency	1900 MHz	1900 MHz	2100 MHz
Signal Propagation from VAP	67 feet (20.5 m)	64 feet (19.5 m)	57.5 feet (17.5 m)
Recommend Spacing Between VAPs	134 feet (41 m)	128 feet (39 m)	115 feet (35 m)
Recommended Maximum Distance of VAPs from Outer Walls	67 feet (20.5 m)	64 feet (19.5 m)	57.5 feet (17.5 m)
Coverage Area per VAP	14,250 sqft (1,324 sqm)	12,750 sqft (1,185 sqm)	10,425 sqft (969 sqm)

### 3.3.1.2 Open Environment

An open environment is an environment with minimal obstacles (e.g. walls). This type of space can be a large conference or meeting room, cubical areas, lobby, or an atrium.

Table 3-2: Open Environment Installation Distances

Band	PCS	PCS	UMTS
Technology	CDMA or GSM	WCDMA	WCDMA
Downlink Frequency	1900 MHz	1900 MHz	2100 MHz
Signal Propagation from VAP	90 feet (27 m)	82.5 feet (25 m)	67 feet (20.5 m)
Recommend Spacing Between VAPs	180 feet (55 m)	165 feet (50 m)	134 feet (41 m)
Recommended Maximum Distance of VAPs from Outer Walls	90 feet (27.5 m)	83 feet (25 m)	67 feet (20.5 m)
Coverage Area per VAP	25,425 sqft (2,362 sqm)	21,350 sqft (1,983.5 sqm)	14,250 sqft (1,324 sqm)

### 3.3.1.3 Dense Environment:

A dense environment consists of a relatively large amount of walls, offices, equipment, tall file cabinets, bookshelves, and other items that could potentially impact the wireless signal. Examples include dense offices, hospitals, and manufacturing spaces.

Table 3-3: Dense Environment Installation Distances

Band	PCS	PCS	UMTS
Technology	CDMA or GSM	WCDMA	WCDMA
Downlink Frequency	1900 MHz	1900 MHz	2100 MHz
Signal Propagation from VAP	64 feet (19.5 m)	60 feet (18 m)	45 feet (13.5 m)
Recommend Spacing Between VAPs	128 feet (39 m)	120 feet (36 m)	90 feet (27.5 m)
Recommended Maximum Distance of VAPs from Outer Walls	64 feet (19.5 m)	60 feet (18 m)	45 feet (13.5 m)
Coverage Area per VAP	12,750 sqft (1,185 sqm)	11,250 sqft (1,045 sqm)	6,300 sqft (585 sqm)

### 3.3.1.4 *Combination of Environments*

In areas with a combination of environments, place VAPs on the border between the different environment types slightly closer to the denser area.

For example, in a cubical area with the outside wall having offices, simply locate the VAPs a little *closer to the outside offices* to provide coverage through the office walls. (See VAPs 11 and 13 in the floor plan map in section 3.4.3.). To ensure maximal coverage, VAPs can be re-located or added until coverage gaps are filled.

## 3.4 Planning VAP Layout

The following section describes the steps of planning VAPs along the covered floor. At the end of this section an example of a planning map is provided.

---

Note: It is highly recommended to use a floor plan when planning the VAPs locations.

---

### 3.4.1 RF Coverage Factors

It is important to note the type of factors that can severely impact RF coverage, and should be avoided:

- **Metallic Structures** such as elevators, high file cabinets, and some moveable metallic partitions severely degrade RF signals. All efforts should be made to locate VAPs in front of, or above metallic objects (desks, filing cabinets) to allow the signal to propagate.
- **Wall Materials** such as concrete, tile, and cinderblock, as well as bathroom fixtures typically have fairly high signal attenuation and should be considered as dense spaces.
- **Types of Glass** that have metallic coatings can affect RF coverage, typically exterior or mirrored. However this issue is not normally encountered inside a building.

### 3.4.2 Mapping Locations

#### To Map the VAP Locations

1. Map out the available Ethernet jack locations and mark all CAT-5e/6 drop locations on the floor plan map.

---

TIP: The size and number of the ceiling tiles can be used to measure distances.

---

2. Using the floor plan and the VAPs coverage guidelines (Provided in section 3.4.3), mark approximately where you would like to place each VAP in the facility.  
VAPs may be added or removed at anytime for optimal coverage.
3. For each jack being used to connect a VAP, check if the jack is already connected to the Ethernet switch. .
4. Connect the Ethernet cables corresponding to the selected jacks according to section 4.3.
5. It is also recommended to check the area where each VAP will be installed to ensure that the installation is feasible.

### 3.4.3 Optional Directional Antennas

Each VAP has an integrated internal antenna that provides isotropic radiation. To prevent interference and improve coverage, connect directional antennas to VAPs installed near outer walls. The VAP antenna parameter must be set accordingly via the Web GUI. (See section 8.3).

### 3.4.4 Installation Plan Example

The Following figure shows a floor plan map with all required marks:




Figure 3-2. Floor Plan Example

#### Notes:

- The red VAP coverage circles have an approximate radius of 45, 60 and 70 foot (14, 18 and 21 meters) for the small, medium and large circles respectively. Diagram is drawn according to the guidelines for UMTS service, given in section 3.3.1.
- VAP 3 is surrounded by the bathroom and stairwell, which are considered dense objects and would reduce coverage in that area by the other VAPs.
- VAP 5 is an example of a unit that provides good coverage down the hallways in an Open Environment.
- VAPs 11 and 13 are placed closer to the offices to provide better coverage to them, but on the open side will actually cover a much greater area. This is why the coverage is larger and shown here more as an oval than a circle.
- The area between VAPs 7 and 14 would probably be the lowest coverage spot in the building because of the bathrooms and stairwell on either side. If after the system is installed, this area is still a little low on coverage, a VAP can be added, but it may also be covered by VAP 14.



Note: The plan can be modified at any time by moving the units around or by adding units.

The following figure depicts an actual measured quantified coverage of a floor area planned according to the above rules.




Figure 3-3. Distributed VAPs propagation, 12dBm output power @ 1.8 GHz

## 4 VCU Unit Installation and Provisioning

This chapter describes the installation and basic configuration procedures for VE Control Units (VCU) located on each floor.

In addition, this chapter describes the how to shift the relevant Ethernet connections required for the VAPs.

These should be performed only after planning the floor coverage and installation locations, as described in the previous sections.

### 4.1 VCU Kit Contents

The VE VCU Kit includes:






Item Description	Image
Dual-Band VE Control Unit (VCU) Kit <i>Note: The image shown here is only an example. The supplied unit may differ in connectors.</i>	
Power Cord	
VE SW CD	
Local Configuration Cable (Crossed RJ-45 cable)	
Brackets for securing the VCU to a 19" rack (Shipped assembled to the VCU)	

Table 4-1: VCU Kit

## 4.2 VCU Physical Installation

This section describes the physical installation and connections of the Master VCU, Slave VCUs, and the VAP Ethernet connections to the relevant VCUs.

### 4.2.1 Master VCU Installation

The VE Control Unit can be installed as a Master VCU and control up to (12) Slave VCUs and/or VAPs and is installed in the main IDF/Telco closet. This section describes the Master VCU installation procedures.

---

Note: When Master VCU only supports Slaves (no VAPs), the control units' **Ethernet Ports** are not relevant and are not in use.

---

1. Install the **Master VCU** in the main IDF/Telco closet. The Master VCU can be installed in a rack, placed on a shelf, or secured using the supplied bracket.
2. Apply power to the Master VCU and verify that the **PWR** LED is lit. Also verify that the unit **ACT** LED completes initialization (blinking light) and shows a solid green light.
3. Connect (or request the service provider's service personnel to connect) the provider's **signal source** (Macrocell, Microcell, Picocell, or BDA etc.) to the **Master VCU front panel RF ports** (through passive interface). Power on the signal sources.

---

Note 1: CELL/PCS Full-Band VCUs can be connected to the RF source through simplex or duplex connections.

Note 2: Verify that the Master VCU source LED (See following figure) is GREEN, indicating an RF signal according to Max Expected Pin. If after connecting the capacity source, the LED remains RED, verify that the Max Expected Pin is configured properly and service is enabled.

---

4. To connect VCU Slaves to the Master VCU, connect the **Master VCU VAP ports** to the **Slave VCUs VCU/VCH** ports via the patch-panel that feeds the dedicated CAT-6/7 cabling system.




Figure 4-1. Master VCU Connections

---

*\*NOTE: RF ports differ depending on the VCU model. For example, Full-Band CELL/PCS VCU models include QMA RF connectors supporting both simplex and duplex connections.*

---

5. To connect Auxiliary alarms refer to section 4.2.1.1. *Note: The connector is located on the controller rear panel.*
6. According to VAPs layout plan (as explained in section 3.4.2) connect the Ethernet switch cables (See section 4.3 for a more detailed explanation).
  - If the requested jack is already in use, disconnect it from the Ethernet switch and re-connect it to the corresponding **Ethernet** port in the Slave VCU front panel.

---

Note: After the Slave VCUs are connected (according to section 4.2.2) and the VAPs (according to chapter 5 ), verify that that the Master VCU **VAP Status** LEDs which correspond to the connected **Slave VCUs** and **VAPs**, complete initialization (blinking light) and show a solid green light.

---

#### 4.2.1.1 Master VCU Alarm Output Connections

---

Note: For Master/Slave VCU configuration, the Alarms are relevant only for the Master VCU.

---

The controller can provide Major and Minor Output Alarms. These alarms can be connected directly to either the auxiliary input of the Base Station, or to any additional dry-contact application.

The auxiliary connections are performed through the **Master VCU** rear panel **Alarms** port as shown below.



Figure 4-2. Master VCU Alarms Connections

A Major Alarm is generated when there is an alarm condition in one or more VCUs, while a Minor Alarm is generated when there is an alarm condition in one or more of the VAPs.

---

Note: If only one alarm is required (Minor or Major) an external connection of a wire jumper between pins 8 and 13 is necessary (normally closed).

---

Connect the relevant alarms according to the connector pinout:




Table 4-2. Alarms Connector – used pins

8 – Major Error Signal (Normally closed)	7 – Minor Error Signal (Normally open)
11 – Major COM	12 – Minor COM
15 – Major Error Signal (Normally open)	13 – Minor Error Signal (Normally closed)

## 4.2.2 Slave VCUs Installation

1. Install the Slave VE Control Unit (VCU) in the IDF/Telco closet corresponding to the floor being covered. The Slave VCU can be installed in the rack using the supplied bracket in the IDF/Telco closet. Apply power to the Slave VCUs and note that the VCU **PWR** LED is lit. Note that the unit **ACT** LED completes initialization (solid light) and shows a blinking green light. (See Figure 4-3).




Figure 4-3. VCU PWR, RF and Master LEDs (Example above shows EGSM-UMTS unit)

2. Connect the Slave VCU front panel **Master** port to the Master VCU **VAP** port via the patch panel using dedicated CAT-6 cables. Verify that the **Master** LED completes initialization (blinking light) and shows a solid green light. The RF LEDs (of both services) should turn OFF.




Figure 4-4. Master and Slave VCU Connections

*NOTE: When control unit functions as Master VCU the VCU VAP ports also serve as Slave VCU connection ports.*


3. Connect the Slave VCU **VAP** ports to the patch-panel that feeds the existing structured CAT-5e/6 cabling system.
4. According to VAPs layout plan (as explained in section 3.4.2), connect the Ethernet switch cables (See section 4.3 for more detailed explanation).
  - If the requested jack is already in use, disconnect it from the Ethernet switch and re-connect it to the corresponding **Ethernet** port in the Slave VCU front panel.

## 4.3 Ethernet Cable Connections to VAPS


This section describes the how to perform the relevant Ethernet LAN connections to the VAPs from the VCUs via the Ethernet switch (See section 4.3.1) and provides a description of the PoE transferred between the VCU and the VAPs (See section 4.3.2).

### 4.3.1 Shifting Relevant Ethernet LAN Connections

For VAPs installed on currently ACTIVE Ethernet ports, shift the relevant Ethernet LAN connections to the Ethernet ports on the Master or Slave VCU.



For VAPs installed on currently INACTIVE Ethernet ports, connect as follows.



Note: After the Slave VCUs are installed and connected to the correct ports in the patch panels, please proceed with the VAP installation as described in chapter 5 . However, it is recommended to complete the VCU provisioning first (See section 4.4) because when installing the VAPs they will instantly provide the wireless service (and the installer will be able to check the coverage).

### 4.3.2 Operation with LAN Utilizing Power over Ethernet (PoE)

Power over Ethernet (PoE) is a technology that enables passing electrical power over the Ethernet cabling. Power can either come from a PoE-enabled Ethernet device (e.g. switch) or from a “mid-span” device built specifically for “injecting” power into the Ethernet cabling.

PoE can operate over two different pairs in a CAT-5e/6 cable. These two methods are referred to as “alternative a” and “alternative b”. All PoE compatible appliances, such as WLAN APs and IP Phones, support both alternatives and automatically detect and use the power on the appropriate pairs (alternative a or b).

MobileAccessVE supports sharing LAN infrastructures that use either 802.3af PoE or 802.3at PoE.

In the current release MobileAccessVE supports operation with **“alternative a” PoE**.

Note: Future enhancements will support coexistence with “alternative b” PoE. If this is currently required, consult MobileAccess.



## 4.4 Provisioning the VE Control Unit

This section describes how to set the basic parameters required for operation and remote management of the Master VCU using the Web GUI. The configuration dialogs are fully described in Chapter 6 .

The Master or Slave mode is automatically detected according to the VCU's physical connection. If a connection to another VCU is detected, the VCU will be identified as a Slave, otherwise it will assume the role of a Master.

---

### Notes:

1. The initial configuration of the Master VCU is performed via local connection using a cross-cable and connecting to VCUs default IP address. After performing the initial configuration and assigning the Master VCU an IP address, the system can be connected, monitored, and configured via a remote management connection.
  2. The configuration and management of all of the system units (VCUs and VAPs) is performed via local or remote connection to the Master VCU unit.
- 


### 4.4.1 Configure the Computer IP Parameters

Configure the computer local LAN connection to operate in the same subnet as the default VCU IP address. Note that the procedure may vary slightly depending on the operating system installed on your computer. The following procedure is for Windows XP.

#### To Configure the Computer's IP Parameters:

1. Click the **Start** menu and choose **Control Panel**.
2. In the **Control Panel**, click **Network** and **Internet Connections**.
3. Click **Network Connections** and then double-click **Local Area Connection**.

The Local Area Connections Properties dialog box appears with the General tab displayed by default.




4. In the Items list, select "Internet Protocol (TCP\*IP)" and click the Properties button.
5. The "Internet Protocol (TCP/IP) Properties" dialog appears.

---

*Note: The Master VCU is supplied with the default IP address 192.168.1.1.*

---


- In order to communicate with the unit, it is necessary to assign your computer a *Static IP* address in the same subnet: 192.168.1.2 to 192.168.1.250. (i.e. 192.168.1.9 as shown in the example).
- Define the subnet mask as shown: 255.255.255.0



6. Click **OK**.
7. The computer communication parameters are now defined and you can open a session to the Master VCU and provision the unit.

#### 4.4.2 Provisioning the Master VCU Unit

1. Perform a local connection to the Master VCU unit by connecting the Master VCU front panel **Management** port and a laptop computer.



2. Open a web browser and type the Master VCU IP address in the address bar (Default: 192.168.1.1).





---

Note: If you have forgotten the VCU IP address (or want to change it) it can be retrieved via the IP Recovery Tool application provided on the Setup CD. See section 9.2.

---

The Login window appears.




3. Type the **User Name “engineer”** and enter the **Password “eng”**.

The MobileAccessVE Web GUI appears.



4. To remotely access Master VCU via Ethernet, configure the VCU IP address as follows:

- Choose the **Management** tab in the main menu bar
- Click the **IP Settings** tab on the side bar.



---

Note: See section 6.4 for a description of the Management tab.

---

- Click the **Modify** button to define the **STATIC IP Address** according to existing LAN.




- Set the Static IP address parameter (DHCP is not currently available)  
Default definitions:
    - The Default IP Address : 192.168.1.1
    - The Default Subnet Mask: 255.255.255.0
    - The Default Gateway: 192.168.1.254
  - Click **OK**.
5. Log out and then log in again with the new IP settings.
  6. Select the **Config** tab in the main menu bar.

---

Note: See section 6.3 for a complete description of the **Config** tab.

---

7. The Master VCU appears in the Network Topology Tree as **VCU-M**. Select the Master VCU by clicking on it.



8. Before configuring the Master VCU please give the unit an identifiable name. To assign the Master VCU an identifiable name:

- Select the **Module Info Tab** and click the **Modify** button.



- Type the unit name (up to 17 alpha-numeric characters) in the **Controller Name** dialog and click **OK**.



- Uplink Cable Compensation – enable this parameter **ONLY** if the bonded cable lengths vary between the VCU and VAPs (reduces noise). It is **NOT** recommended to enable this option for similar cable lengths between the VCU and the connected VAPs.
- Set the RF parameters for each connected service (up to two). Select the Service RF tab (Service1 RF / Service2 RF) of the service being configured (each service is configured through its' corresponding tab):



Figure 4-5. Service RF Tab - Example Shows Service RF Tab for UMTS Service

- For EGSM/DCS and EGSM/UMTS services (see figure above) - Click **Modify** and enter the DL central frequency for each service according to the following ranges:
  - EGSM: 925 – 960 MHz
  - UMTS: 2110 – 2170 MHz
  - DCS: 1805 – 1880 MHz



- For CELL-PCS Full Band – Select **BTS Connection** (Simplex/Duplex).



Figure 4-6: Service RF Tab – Example for CELL Full Band

Note 1: CELL-PCS Full Band DL CF is Read Only.


Note 2: The **Service DL CF** dialog displays the relevant range for each service. The figure above shows an example for the UMTS band.

- Click **OK**.
- Define Max expected power of BTS (0-33dBm).
- Define UL system gain for each service (5 to -15dB).

Notes:

1. Max expected Pin and Service CF parameters are service dependent and can be obtained from your service provider.

2. The remaining parameters are predefined to their default values. (Service Bandwidth is set to 15 MHz for EGSM, UMTS and CELL and to 20 MHz for DCS and PCS).
  3. Any updates of the service Central Frequency definition is sent to all connected VAPs.
11. To verify proper operation of the system, refer to the **Alarms** sub-tab (in the Config tab). (See following figure).



12. Verify that all the alarms are GREEN. Refer to section 7.2 for alarm descriptions.

*Note: To briefly check the VCU status, click on the VCU name in the Topology Tree. The VCU icon will appear, showing the LEDs status.*





13. Mask irrelevant alarm conditions to avoid having them reflected to the overall status of the unit.

#### For Example

If the Dual-Band system is currently only being used to provide one service, while the other service is disabled, the “Service Off” alarm can be masked (Disabled).

In the example below, the left dialog shows the alarm response if the Service 2 alarm is NOT masked (enabled). In that case the Overall Status will be RED indicating a fault.

If the Service 2 alarm is MASKED (Disabled), then the LED for the alarm will be RED; but, the Overall Status will be GREEN – showing NO Fault.



Figure 4-7. Service2 Service Off Alarm – Not Masked

Figure 4-8. Service2 Service Off Alarm –Masked

In *Figure 4-9*, the alarm condition for “Service 2 Service Off” actually exists, while the masking prevents this condition from affecting the overall status of the system and therefore the Overall Status led below is green.

### 4.4.3 Provisioning the Slave VCUs

Note: The Slave VCUs management and configuration is performed through a remote connection to the Master VCU, via the Web Management application. Before provisioning the Slave VCUs verify that the Master VCU unit, to which it is connected, has been provisioned (See section 4.4.1).

The Slave VCU RF parameters are set via the Master VCU, therefore there is no need to configure the RF parameters individually for each connected Slave VCU. It is recommended to assign each Slave VCU an identifiable name.

### To assign a name to a Slave VCU:

1. Connect to the Master VCU unit (either locally as explained in section 4.4.1 or remotely) and select the Slave VCU to be provisioned from the Network Topology Tree.



Each VCU has a default name of the form “VCUPx-name”, where:

- **Px** - Master VCU port number to which the Slave VCU is connected
- **Name** - User-defined name

2. To assign the Slave VCU an identifiable name:
  - Select the Module Info Tab
  - Click the **Modify** button



- Type the unit name (up to 17 alpha-numeric characters) and click **OK**.
3. Uplink Cable Compensation – enable this parameter **ONLY** if the bonded cable lengths vary between the VCU and VAPs (reduces noise). It is **NOT** recommended to enable this option for similar cable lengths between the VCU and the connected VAPs.

# 5 VAP Installation and Provisioning

This section provides a description of the VE Access Pods (VAPs) installation, verification, and monitoring procedures.

## 5.1 VAP Installation

The VAPs installation procedure consists of connecting each VAP to an Ethernet jack in the appropriate location to provide optimal coverage (See sections 3.4 and 4.3).

It is recommended to install the VAPs in places located high up so as to maximize the provided coverage per VAP.

---

Note: Mounting a VAP beneath a desk or in another secluded location (e.g. office corner) decreases the effective coverage of the VAP increasing the need for a higher number of VAPs to cover the same area.

---

There are three main types of VAP mounting installations:

- Desk Mount – Used for VAPs mounted on locations such as desks, cubical walls, and filing cabinets. (See section 5.2.1.2).
- Wall Mount – Used for VAPs mounted on walls (*Recommended*). (See section 5.2.1.3).
- Ceiling Mount – Used for VAPs being installed in the ceiling. Two types of ceiling mount installations:
  - Horizontal – ONLY relevant for VAPs to which EXTERNAL antennas are connected. (See section 5.2.2).
  - Vertical – Applicable for VAPs working either with INTERNAL or EXTERNAL antennas. (See section 5.2.35.2.3).

### VAP Installation Considerations

- Placing units in an open area.
- Availability of CAT-5e/6 infrastructure.
- The VAPs plug into standard (RJ-45) Ethernet connection jacks.
- If the jack being used is already connected to Ethernet switch. For more information see sections 3.4.2 and 4.3.
- Aesthetics of the VAP location.






## 5.2 Desk and Wall Mount VAP Installations

### 5.2.1.1 VAP Kit Contents

The Dual-Band VE Access Pod (VAP) Kit includes:

Note: VAPs are provided with two mounting options: Desk Mount and Wall Mount

**Table 5-1: VAP Kit**

Kit Items	Unit
VE Access Pod (VAPs)	
Wall Mount Adaptor (Features double-sided sticky tape located on rear for fast installation)	 <p style="text-align: center;">Front      Rear – showing</p>
Desk Mount Adaptor	
(8) Screws: ○ (4) Short Screws – Used to secure adaptor to pod ○ (4) Long Screws – Used to secure wall mount adaptor to the wall (“anti-theft” installation)	 <p style="text-align: center;">Long screws      Short screws</p>
RJ-45 Jumper Cable	

### 5.2.1.2 Desk Mount Installation

---

Note: All components (adaptor, screws, and cables) are included in the VAP Kit.

---


- Place the VAP on the Desk Mount.
- Secure the Desk Mount adaptor to the VE Access Pod using the (4) short screws.
- Connect the RJ-45 jumper cable (CAT-5e/6) to the VAP's RJ-45 connector.
- Place the VAP on a flat surface according to the planned location.
- Plug the other end of the cable into the VCU (RJ-45) Ethernet jack.
- When using an external antenna, connect the **Ext. Antenna** SMA connector(s) to the external antenna(s). **This option must be SW configured via the web GUI.** (Note: Internal antenna is enabled by default).

---

Note: The maximum external antenna gain should not exceed 10 dBi.

---

- Verify that the VAP receives power and connects to the VCU via the LEDs on the unit, both the GREEN LED and the BLUE LED should be lit.



### 5.2.1.3 Wall Mount Installation

---

Note: All components (adaptor, screws, and cables) are included in the VAP Kit.

---

- Attach the VAP's Wall Mount adaptor to the wall in the planned location, using the double sided sticky tape located on the rear or secure it using the longer screws.
- Place the VAP on the Wall Mount.
- Secure the Wall Mount adaptor to the VE Access Pod using the (4) short screws.
- Connect the RJ-45 jumper cable via CAT-5e/6 to the VAP's RJ-45 connector.
- Plug the other end of the cable into the VCUs (RJ-45) Ethernet jack.
- When using an external antenna, connect the **Ext. Antenna** SMA connector(s) to the external antenna(s). **This option must be SW configured via the web GUI.** (*Note: Internal antenna is enabled by default.*)

---

Note: The maximum external antenna gain should not exceed 10 dBi.

---

- Verify that the VAP receives power and connects to the VCU via the LEDs on the unit, both the GREEN LED and the BLUE LED should be lit.



## 5.2.2 Horizontal Ceiling Mount VAP Installations


*Note: This type of installation is ONLY relevant for VAPs to which EXTERNAL antennas are connected.*

The Horizontal installation procedure varies depending on the type of ceiling:

- Lowered ceilings.
- Concrete/Wood ceilings (See section 5.2.2.3).

### 5.2.2.1 VAP Kit Contents


Please verify that the VAP Ceiling Mount Installation kit (P/N AK-VAP-CEILING-MT-H) includes the items listed below.

Kit Items	Description	Unit
Mounting Brackets	A) Ceiling Bracket B) Locke Bracket	
"Twist on" Track Light Clip assembly	Used for installation on lowered ceilings. A) Track Light Clip B) Screw, Bolt, and Washer	
(3) Flat Head Screws 100', 4/40 x 1/4 [NEROSTA]	Used for assembling brackets	
(4) Self Screws 3dim L=8 ,Flat HD 90 [Steel zinc]	Used for securing bracket assembly to VAP	

### 5.2.2.2 Lowered Ceiling Installation

#### To Install VAP on a Lowered Ceiling

1. *Loosely* assemble the two brackets (Ceiling and Locke) using the provided Flat Head screws. The assembly will be secured at a later stage.
2. Assemble the Track Light Clip to the Ceiling Bracket (top side) using the provided washer and bolt.



3. Hook the assembly onto the VAP rear panel grid and fit to the bottom of VAP.



4. Secure the assembled brackets to the bottom of the VAP using the Self Screws.
5. Adjust the bracket assembly to firmly fit the VAP and tighten the three screws securing the assembly.



6. Mount the VAP on the lowered ceiling as follows:
  - Enlarge large flanges over opposite sides of T-bar. *Note: Apply slight pressure as Twist Clip is made of spring steel.*





- Twist flanges clockwise until small flanges snap over edges. The Twist Clip is now in position.




- Place stud through 1/2" knock-out. Use washer-nut combination and tighten securely.

### 5.2.2.3 Concrete/Wood Ceiling Installation

#### To Install VAP in Lowered Ceiling

1. Mark the location of the (4) screws on the ceiling according to the (4) larger holes on the bracket assembly.
2. Drill the screws in to the marked locations on the ceiling.



3. Align the (3) screw holes of each of the brackets (Ceiling and Locke) as shown in the adjacent figure and using the supplied Flat Head screws, *loosely* assemble the brackets.  
*Note: To be adjusted at a later stage.*



4. Fit the assembled brackets on to the VAP by inserting the (5) hooks in corresponding top rear grid of the VAP and fit the other side on to the underside of the VAP.



5. Secure the assembled brackets to the bottom of the VAP using the Self Screws.
6. Adjust the bracket to the VAP and tighten the assembly screws.
7. Hang the VAP (using the (4) larger screw holes) on to the (4) screws located on the ceiling.



## 5.2.3 Vertical Ceiling Mount VAP Installations





*Note: This type of installation option is applicable for VAPs working with either the INTERNAL antennas or the EXTERNAL antennas (internal antennas are designed to provide uniform coverage when aligned vertically on desk, wall or from ceiling).*

The Vertical installation procedure varies depending on the type of ceiling:

- Lowered ceilings (See section 0).
- Concrete/Wood ceilings (See section 5.2.3.3).

### 5.2.3.1 VAP Kit Contents


Please verify that the VAP Ceiling Mount Installation kit (P/N AK-VAP-CEILING-MT-V) includes the items listed below.

Kit Items	Description	Unit
Mounting Brackets	A) Ceiling Bracket B) Locke Bracket	
"Twist on" Track Light Clip Assembly	A) Track Light Clip B) Screw, Bolt, and Washer	
(3) Flat Head Screws 100', 4/40 x 1/4 [NEROSTA]	Used for assembling brackets together	
(4) Self Screws 3dim L=8 ,Flat HD 90 [Steel zinc]	Used for securing bracket assembly to VAP	

### 5.2.3.2 Lowered Ceiling Installation

#### To Install VAP in Lowered Ceiling

1. *Loosely* assemble the (2) brackets using the provided Flat Head screws. (The assembly will be secured at a later stage.)
2. Assemble the Track Light Clip to the Large Horizontal Bracket (top side) using the provided washer and bolt.



3. Hook the assembly onto the VAP rear panel bottom grid and fit to underside of the VAP.
4. Secure the assembled brackets to the bottom of the VAP using the Self Screws.



5. Adjust the bracket to firmly fit the VAP and tighten the (3) bracket assembly screws.



6. Mount the VAP on the lowered ceiling as follows:
  - Enlarge large flanges over opposite sides of T-bar. Note: Apply slight pressure as Twist Clip is made of spring steel.



- Twist flanges clockwise until small flanges snap over edges. The Twist Clip is now in position.




- Place stud through 1/2" knock-out. Use 4WN washer-nut combination and tighten securely.


### 5.2.3.3 Concrete/Wood Ceiling Installation

#### To Install VAP in Lowered Ceiling

1. Mark the location of the (4) screws on the ceiling according to the (4) larger holes on the bracket assembly.
2. Drill the screws in to the marked locations on the ceiling.




3. Align the (3) screw holes of each of the brackets (Ceiling and Locke) as shown in the adjacent figure and using the Flat Head screws, *loosely* assemble the brackets. *Note: To be adjusted at a later stage.*



4. Fit the assembled brackets on to the VAP by inserting the (3) hooks in corresponding bottom rear grid of the VAP and fit the other side on to the underside of the VAP.
5. Secure to the underside of the VAP using the (4) supplied Self Screws.



6. Tightly adjust the bracket to the VAP and secure the bracket assembly.
7. Hang the VAP on to the (4) screws located on the ceiling, and secure the screws.



8. Hang the VAP using the (4) larger screw holes on to the (4) screws located on the ceiling.



## 5.3 Verifying Coverage

Verify coverage in the areas, adding and moving VAPs for optimal coverage according to the principles described in 3.3.

## 5.4 Naming the VAPs, Verifying Connections, and Monitoring

The VAPs are auto-discovered by the VCU and can be monitored via a remote or a local connection (to the Master VCU). The VAPs are auto-configured by the VCU without user intervention (no configuration procedure is required). However, if you wish, you may assign each VAP an identifiable name corresponding to its physical location.

Note: See section 6 for full explanation about navigating the MobileAccess**VE** Web GUI application.


1. If a session is not already open to the MobileAccess**VE** Web management application, open a session to the Master VCU according to section 4.4.1.

2. Select a VAP from the Network Topology Tree.


Each VAP has a default name of the form **VAP Px-name** where:

- **Px** – Number of Slave VCU port to which the VAP is connected
- **Name** - User-defined name

3. In the Network Topology Tree under the Control Unit, verify that a GREEN (or RED) circle is displayed for each connected VAP.



- If a VAP is not green, select the VAP from the network topology tree. Then select the Config tab. Refer to the **Alarms** tab work area. The alarms for the selected VAP are displayed.



Note: VAP alarm mask is saved in the VCU, associated with the port to which the VAP is connected. In case you replace the VAP, the newly installed VAP will automatically be set with same alarm mask.

4. Refer to the Config **Module info** tab.



5. Assign each VAP a name as follows:

- Click the **Modify** button
- Type the unit name (up to 17 alpha-numeric characters) and click **OK**

Click Modify button to assign name



6. When required to transmit the RF signal through a connected external antenna:
  - Refer to the **Service 1 RF** and/or **Service 2 RF** tabs
  - Enable the **External** Antenna option



---

Note: If the external antenna option is not enabled, the signal will be transmitted via the integrated internal antenna, by default.

---

7. Verify the system connections according to the following section (See section 6 ).

# 6 Navigating the Web Access Application

The MobileAccessVE Web management application is accessed through any standard web browser connected to the Master VCU via a network within the same subnet as the Master VCU or a different subnet which is routable.

## 6.1 Opening a Session and Authentication Levels

After the initial configuration (as explained in 4.4.1) the MobileAccessVE system can be accessed via the network.

### To Access the System:

1. Open a web browser. In the address bar type the Master VCU's IP address as you set it in the Master VCU configuration operation (See section 4.4.1).



2. The Login pane appears.



Enter your User Name and password. The following authentication levels are available:

Level	Default Password	Access
operator	oper	This user has Read Only access.
engineer	eng	This user has access to basic configuration options.
admin	ma98	This user has Field Engineer permissions, in addition to access to changing passwords.

## 6.2 About the MobileAccessVE Web Access Window

The MobileAccessVE Web window includes six main tabs that provide access to the applications' main options. Here the Config tab is displayed by default.

---

Note: The Monitor, Events, Setup, and Help tab are future options.

---

The appearance of the each screen varies according to the tab displayed. The Main Menu Bar tabs are:

- Config(uration) – Displayed by default upon login. Provides the selected units' configuration parameters and alarms
- Management - Provides upgrade, IP configuration and security options

Both of these tabs are described in detail in the following sections



## 6.3 Configuration Tab


The **Configuration** tab provides the general information and service RF parameters for configuration of the units appearing in the Network Topology tree.

### To Access a VCU Configuration Tab

On the left hand side of the window select a Master VCU/Slave VCU from the network topology tree. Select the **Configuration** tab from the menu-bar. The information and parameters displayed in the Configuration sub-tabs vary depending on whether a VCU or VAP is selected in the topology tree.

The Configuration tab is divided in to three main areas:

- Network Topology Tree – Displays the system units (Master VCU, Slave VCUs and VAPs) and their status.
- Display Area – Displays the icon of the selected unit including the LED statuses.
- Work Area – Displays the Module Info, alarms, and RF tabs corresponding to the unit selected in the topology tree (Master VCU, Slave VCU or VAP).




### 6.3.1 Network Topology Tree

The Configuration Network Topology Tree appears on the left hand side when the **Config** tab is selected. Connected Slave VCUs and VAPs are automatically detected and displayed in the topology. The VE Web Access Application includes a Baseline feature providing an indication on network elements (VCUs/VAPs), which were disconnected from the VE network. Connected VCUs and VAPs are automatically added to the Baseline upon detection, and will appear in the topology as grayed out in case they are disconnected. The network elements are displayed in two levels:

- First Level – Up to 12 VCUs
- Second Level – Up to 12 VAPs connected to each VCU

Note: The root is MobileAccess**VE**.



Each unit is assigned a **Type Px-name**:

- Type – VCU-M, VCU or VAP (for Master VCU, Slave VCU or VE Access Pod)
- Px - VCU port number
- Name – User defined

Each unit is displayed with a colored bullet that indicates its' status:

Color	Indicates
Green	OK
Red	Alarm Condition
Gray	Disconnected unit (e.g. faulty connection). Generates RED Baseline alarm in Alarms tab (see 7.2).

The root (the entire MobileAccess**VE** site) is also associated with a colored bullet that indicates the overall status of the deployment:

Color	Indicates
Green	OK
Red	Alarm Condition in one or more VCUs or VAPs


### 6.3.1.1 *Removing Network Element from Baseline*

The Baseline automatically detects the connected units (VCUs and VAPs) and when for some reason a unit is disconnected or the connection with it is no longer detected it will not disappear from the topology but will appear in gray. In addition, the Baseline alarm in the Alarm tab will appear in Red.

In order to remove a unit from the baseline so that it no longer appears in the network topology, it must be done via the GUI from either the Topology Tree or unit icon.

#### **To Remove a Unit from the Baseline**

1. Click on the unit in the Topology Tree or on the unit icon (for example, VAP). The following dialog appears:



2. Click **OK**. The unit will no longer be displayed in the Network Topology Tree and the Baseline Alarm will show Green.

### 6.3.2 Configuration Display Area

When selecting an element (Master VCU/Slave VCU or VAP) in the network topology tree, an icon representing the unit is displayed in the Configuration tab display area.



## 6.4 Management Tab

The Management tab provides user administrative management options and includes the sub-menu tabs:

- Firmware – Used for upgrading/downgrading SW to VCU's.
- Distribute – Used for distributing the upgrade/downgrade SW files to the VAPs.
- Security – Used for changing user passwords.
- SNMP Config – Used for defining the SNMP communities and trap destinations.
- IP Settings – Used for viewing and modifying the network parameters.
- Sys(tem) Log – N/A

The following figure shows the Management screen with the menu options on left.





# 7 VCU Monitoring and Configuration

## 7.1 Viewing VCU General Information

The VCUs general information, such as unit name and SW versions, can be viewed in the Config **Module Info** sub-tab.

### To View VCU General Information

- Click the Config tab from the main menu and select the VCU from the network topology tree. The **Module Info** sub-tab is displayed by default.



The following information is displayed:

Field	Description
Name	User defined name for system element (up to 17 characters)
Serial Number	Factory set ID number
Product Revision	Revision number of VCU/VAP
SW Active Version	Version of the SW currently being used to manage and monitor the system
SW Inactive Version	Version of other system SW version not in use
Restart VCU Button	SW reset of the unit
Uplink Cable Compensation	Used to minimize interference that may be caused by bonded cables that vary in length
Identify	Enabling this option enables finding the physical location of the selected element (See section 10.1). When this option is set to ON, the LEDs on the corresponding VAP/VCU flickers.

## 7.2 Viewing VCU Alarms

The alarms displayed in the Alarms tab correspond to the VCU (Master/Slave) selected in the topology tree. When a VCU element is selected in the topology tree, the Alarm tab displays the main alarms in the unit.

### To View VCU Alarms

In the Topology Tree select the **Control Unit** (VCU) then click the **Config(uration)** tab in the menu bar located at the top of the window. Refer to the **VCU Alarms and Mask** sub tab.



If one or more alarms occur, the corresponding Status indicator will be illuminated in RED. If the VCU is OK and no fault occurs, the **Overall Status** indicator will show GREEN.

Alarm	Description
VCU Faulty	RED - VCU fault. Remove and re-apply power to VCU. If problem persists, replace VCU.
Over Temperature	Temperature of unit exceeds normal range.
Mismatch	Red – Mismatch of services (e.g. CELL/PCS VAP connected to EGSM/UMTS VCU, VCU connected to slave VCU etc.).
Service 1 DL RF Pwr Low	RED - DL RF Power is lower by 15dBm (or more) from the Max Expected Pin.
Service 1 DL RF Pwr High	RED - the input power exceeds the maximum expected Pin by more than 3 dB.
Service 1 Service Off	User has disabled Service 1.

Alarm	Description
Service 2 DL RF Pwr Low	RED - DL RF Power is lower by 15dB (or more) from the Max Expected Pin.
Service 2 DL RF Pwr High	RED - the input power exceeds the maximum expected Pin by more than 3 dB.
Service 2 Service Off	User has disabled Service 2.
VCUs in Baseline	RED – Communication lost with VCU defined in baseline
VAPs in Baseline	RED - Communication lost with VAP defined in baseline
Overall Status	Indicates Fault (RED) level or GREEN if there are no faults.

## 7.3 Master VCU RF Parameters

Note: The RF parameters are not displayed for control units functioning as Slave VCUs.

### To Access the Service RF Tab

Click the **Config** tab from the main menu bar and then select the Master control unit from the network topology and click the *Service RF* tab. The parameters displayed in Service RF tabs correspond to the selected element.



Figure 7-1. Service RF Tab for UMTS Service (similar for EGSM and DCS)



Figure 7-2. Service RF Tab for CELL/PCS

The following table provides a description of the RF parameters displayed in the Service RF tabs.

Parameter	Description
Type	Set (read only) according to unit type (e.g. EGSM / UMTS)
BTS Connection*	Type of BTS RF connection (Simplex/Duplex)
DL CF	DL Center frequency (from BTS): <ul style="list-style-type: none"> <li>**For EGSM/DCS/UMTS - User defined, according to connected service</li> <li>For CELL/PCS – Read Only</li> </ul>
UL CF	UL center frequency (from BTS) – corresponding to defined DL Center Frequency. Automatically assigned by the system according to the DL frequency
Max Exp Pin**	Maximum expected input power from the BTS. Used for adjustment procedure. Range: 0-33 dBm. User defined.
Pin	Actual measured Pin (read only)
UL System Gain	Used for adjusting the UL system gain. Range: -15dB to +5dB
Service Control	Enables (On)/Disables (Off) the service

\* Appears in CELL/PCS Full Band GUI only.

\*\* Required parameters to be provisioned by the user.


## 8 VAP Monitoring and Configuration

### 8.1 Viewing VAP General Information

The VAPs general information, such as unit name and SW versions, can be viewed in the Config **Module Info** sub-tab.

#### To View VAP General Information

Click the Config tab in the main menu and select the VAP from the network topology tree. The **Module Info** sub-tab will be displayed by default.



The following information is displayed:

Field	Description
Name	User defined name for system element (up to 17 characters)
Serial Number	Factory set ID number
Product Revision	Revision number of VCU/VAP
SW Active Version	Version of the SW currently being used to manage and monitor the system
SW Inactive Version	Version of other system SW version not in use
Restart VAP Button	SW reset of the unit
Identify Button	Enabling this option enables finding the physical location of the selected element (See section 10.1). When this option is set to ON, the LEDs on the corresponding Access POD/VCU flickers.


Note: VAP Name is saved in the VCU associated to the port to which the VAP is connected, such that in case you replace a VAP, the new one will be associated with the same name. In case you do not want to keep the configuration of the replaced VAP, remove it from the topology baseline before connecting the new VAP.

## 8.2 Viewing VAP Alarms

When a VAP element is selected in the topology tree, the Alarm tab displays the main alarms in the unit.

### To Access VAP Alarms Tab

Click the Config tab in the main menu and select the VAP from the network topology tree. Select the **VAP Alarms** sub tab.



If one or more alarms occur, the corresponding Status indicator will be illuminated in RED. If the VAP is OK and no fault occurs, the **Overall Status** indicator will show GREEN.

Alarm	Description
Service 1/2 Off	User has disabled the service
DL Adjustment	Cable (between VCU to VAP) is too long (over 100m/300ft)
VAP Faulty	A fault has been detected in the VAP
Overall Temperature	Temperature of unit exceeds normal range
Overall Status	Indicates Fault (RED) level or GREEN if there are no faults

Note: DL adjustment alarm is raised when a VAP is connected over a cable exceeding system cable length limitation. In such cases, the system continues to provide the wireless services, but you should check the coverage of the VAP (as output power may be degraded due to excess cable loss) and check the Ethernet connection (as Ethernet standard maximum cable length has probably been exceeded).

## 8.3 VAP RF Parameters

The **Service1** and **Service2** tabs provide the configurable RF parameters corresponding to the VAP element selected in the network topology tree. Up to two service RF tabs are displayed, one for each service. The displayed RF parameters are similar for both service tabs.

### To View the VAP RF Parameters

Click the **Config** tab from the main menu bar and then select the VAP from the network topology and click the *Service RF* tab. The parameters displayed in Service RF tabs correspond to the selected element.



The following table provides a description of the RF parameters displayed in the Service RF tabs.

Parameter	Description
Type	Set according to unit type (e.g. EGSM /UMTS)
Service Control	Used to Disable (Off) or Enable (On) the service for the specific VAP
DL Pout Level	Normal – Pout from the VAP at normal level (according to the service) Low – Pout from VAP is attenuated by 5 dB
DL Pout	Presents the measured output power
Antenna	Select External only if an external antenna is connected to this VAP. Otherwise, the option should be set to Internal (default)

Note: VAP RF settings (Service Control, DL Pout Level, Antenna) are saved in the VCU associated to the port to which the VAP is connected, such that in case you replace a VAP all parameters are automatically set to the new VAP. In case you do not want to keep the configuration of the replaced VAP, remove it from the topology baseline before connecting the new VAP.



## 9 Administrative Operations

This chapter describes the following Administrative operations:

- Changing a password
- IP configuration parameters
- SNMP Configuration parameters
- Unit software upgrade and software management procedures

### 9.1 Changing Password

The Management - Security tab provides password change options.

#### To Set the Application Password or Change an Existing Password

1. Select the **Security** option of the Management tab at the top of the window.



2. Click the **Modify** button beside the User Name whose password is being modified.
3. Enter the **New Password** and re-enter in the **Confirm New Password** field.
4. Click **OK**.

---

Note: Passwords can only be changed when connected as an administrator.

---

## 9.2 Retrieving VCU IP Address

The IP Recovery Tool enables viewing and/or changing the VCU IP address.

### To Install IP Recovery Tool


1. Install the IP Recovery Tool application, which is provided by MobileAccess on the Setup CD, on the computer to which the VCU is to be connected.
2. Double-click on the Recovery Tool Setup and follow the prompts – standard installation procedure.

### To Retrieve the VCU IP Address

1. Connect the computer, on which the Recovery Tool is installed, to the VCU RS-232 **Console** port located on the rear panel (See section 1.3.1.2).
2. Run the IP Recovery Tool application from the computer Start menu.



The Connection dialog appears.




3. Select the **Comm. Port** corresponding to the connection on the computer.
4. Enter the password **Eng** and click **Connect**.

The current IP parameters dialog appears showing the VCI IP address.



5. To modify the current IP Parameters: click **Change**. The **Change IP Parameters** dialog appears:




Enter the new parameter value and click **OK** and **Exit**.

## 9.3 IP Settings

The IP Settings tab is used for viewing and modifying the network parameters. The default parameter settings are as follows:

- IP Address: 192.168.1.1
- Subnet Mask: 255.255.255.0
- Default Gateway: 192.168.1.254



## 9.4 SNMP Configuration Parameters

The SNMP Config tab is used for defining the SNMP communities in which the devices and management station belongs and to where the traps are sent. The SNMP default communities are:

- Read - public
- Write - private



- The Community Names can be modified by clicking the **Modify** button in the SNMP Configuration display area.
- Additional Trap Destinations can be added by clicking the **Add New** button in the Trap Destination List display area:



## 9.5 Upgrading (or Downgrading) VCU and VAP Software

---

Note: Before you start, verify that the VCU and VAPs upgrade files are located in an accessible location (i.e. on your computer).

---

The software for each VCU and its hosted VAPs can be upgraded through access to the VCU, where the **VAPs must be upgraded first** and only then the VCU.

---

Note: In installations with Slave VCUs, a session should be opened to the IP address of the Slave VCU in order to upgrade the SW of the Slave VCU and associated VAPs.

---

Two types of files are stored on the VCU and on individual VAPs: Active software on which the unit operates, and Standby software. The Active and Standby software can be swapped on each individual unit.

In addition, the VCU holds two software images for VAPs to be used in download process to VAPs.

The upgrade procedure consists of the following main phases:

1. Uploading the new VCU and VAP software to the host VCU.
2. Setting the new software as the Active software.
3. Downloading the new software to selected VAPs and activating it as the Active software on those VAPs.
4. Activating the new VCU software on the VCU.

The procedure is performed via two screens:

- Distribute Screen – Used to download the VAP software version to selected VAPs.
- Firmware Screen – Used to manage the software files stored on the VCU.

## 9.5.1 Upgrading the VAP SW

### To Upgrade the VAPs SW Version:

- Upload the VAP upgrade files from your storage location to the VCU as follows:
  - Click the **Management** menu tab and then select the **Firmware** sub-menu option located on the left side.
  - In the **Load New Firmware** display area, click the **Browse** button.
  - Browse for the file to be loaded from your computer location. The Download button appears and the progress bar will show the download status.



Load New  
Firmware  
Display Area

- After the download is complete, the downloaded SW version will appear in the Standby Bank column of the VAP display area.

#### Notes:

- Locate the Firmware files on your local hard-drive prior to the download process.
- During the download process DO NOT disconnect the Web GUI connection to the VCU.

- To distribute the new software to selected VAPs:
  - Select the **Distribute** sub-menu option found on the left side.

The screenshot shows the mobileaccess management interface. At the top, there is a navigation bar with tabs: Monitor, Config, Events, Set-up, **Management**, and Help. The **Management** tab is highlighted. On the left side, there is a sidebar with buttons for Firmware, **Distribute**, Security, SWMP Config, SysLog, and IP Settings. The **Distribute** button is highlighted. The main content area shows the VAP Firmware Versions in VCU Banks and the VAP Firmware Distribution Table.

**VAP Firmware Versions in VCU Banks**

Ready to Download Version	Standby Version	Swap
Version: 1.3 Build: 0.0	Version: 1.3 Build: 0.0	Swap

**VAP Firmware Distribution Table**

Selected	Device	Serial number	Active ver	Inactive ver	Progress	Status
<input type="checkbox"/>	VAP 1	00094500098	1.3	1.3		Connected
<input type="checkbox"/>	VAP 2	0009450008E	1.3	1.3		Connected
<input type="checkbox"/>	VAP 3	00094500096	1.3	1.3		Connected
<input type="checkbox"/>	VAP 4	000945000A6	1.3	1.3		Connected
<input type="checkbox"/>	VAP 5	000945000AD	1.3	1.3		Connected
<input type="checkbox"/>	VAP 6	000945000A4	1.3	1.3		Connected
<input type="checkbox"/>	VAP 7	000945000AA	1.3	1.3		Connected
<input type="checkbox"/>	VAP 8	000945000A5	1.3	1.3		Connected
<input type="checkbox"/>	VAP 9	0009450005F	1.3	1.3		Connected
<input type="checkbox"/>	VAP 10	000945000AB	1.3	1.3		Connected
<input type="checkbox"/>	VAP 11	0009450009A	1.3	1.3		Connected
<input type="checkbox"/>	VAP 12	000945000AE	1.3	1.3		Connected

Buttons: Distribute, Select All

- Download the new version to the selected VAPs (*Note: The downloaded version is stored as Inactive in the VAPs until a Swap procedure is performed.*)
  - In the **VAP Distribute Table** display area, checkmark the VAPs to be upgraded. The Active and Inactive SW versions for each VAP are listed in the relevant columns.
  - Click the **Distribute** button to download the new software to the selected VAPs. The software is stored as the Inactive version in the VAPs.
  - Set the new software as the Active version in the selected VAPs by clicking the Swap button.
  - The VAP upgrade procedure is complete.

#### Notes:


- As during the distribution process service may be interrupted, it is advised to perform the SW download and distribution in a maintenance window scheduled at off-peak hours (e.g. nights and/or weekends).
- During the distribution process DO NOT perform configuration changes, connect or disconnect VAPs, and/or disconnect the web GUI.
- After the distribution process is complete and swapping between VAP SW images, the VCU will restart automatically. After restart, the VAP firmware distribution table will be empty. Within several seconds it will re-populate as the VCU re-discovers connected VAPs.



## 9.5.2 Upgrading the VCU SW

### To Upgrade the VCU SW Version:

1. Upload the VCU upgrade files from your storage location to the VCU as follows:
  - Click the **Management** menu tab and then select the **Firmware** sub-menu option found on the left side.



- In the **Load New Firmware** display area, click the **Browse** button.
  - Select the file to be loaded from your computer location. The Download button appears and the progress bar will show the download status.
  - After the download is complete the downloaded SW version will appear in the Standby Bank column of the VCU display area.
2. Define the downloaded version as the Active version (to be used for upgrade) as follows:
    - In the VCU display area, click **Swap**. The downloaded version appears in the Active Bank column and the Controller is automatically restarted.
    - The VCU Upgrade procedure is complete.


# 10 Troubleshooting

## 10.1 Finding a Specific VAP in the Building

It is recommended to assign each VAP an identifiable name corresponding to its physical location, as explained in section 5.4. If a name was not configured, or for some other reason a specific VAP cannot be physically located, identify the VAP according to the instructions in the following example.

### To Locate a VAP

1. Select the **Config** tab from the main menu bar and then select the VAP to be located from the topology tree.



2. Click the **Module Info** sub-tab.


3. Set **Identify** to **ON**. The Activity LED (Blue) on the corresponding Access Pod will start blinking fast. (You will need to physically locate the VAP to see the blinking LED).



4. Locate the Access Pod.
5. It is advisable to assign it an identifiable name via the Access Pod **Module Info** tab, as described in section 5.4 (e.g. floor 3, room 2) and set the **Identify** field to **Off** again.

## 10.2 Wireless Service is Not Available

1. Verify that the Master VCU is connected to the BTS, powered up, and configured.
2. Verify that the Max Expected Power setting is correct by either:
  - Viewing the actual VCU Power Measurement (**DL Pin**) in the VCU **Service RF** tab (See below).



- Measuring the actual BTS output using a Spectrum Analyzer.
3. Verify correct settings of Frequencies and UL Gain (See **DL/UL CF** and **UL System Gain** parameters in Service RF sub-tab displayed above).
  4. Verify that the RF cables are properly connected to the VCU.
  5. View the VCU **Alarms** (above image) and verify that the VCU is working properly.

## 10.3 PoE is Not Working

Verify that the PoE used is “alternative a”. The MobileAccessVE system currently only supports this alternative. Verify that all pairs are wired in the patch panels and jumper cords.

---

Note: Future enhancements will support “alternative b”. Consult MobileAccess if you currently require support for “alternative b.”

---

## 10.4 Ethernet Service is Degraded


Ethernet standards specify that 100m (300ft) is the maximum distance between an Ethernet switch and appliance (computer, WLAN AP, etc). This is relevant when MobileAccess**VE** shares the IT LAN. The distance includes all patch cords (from switch to VCU, from VCU to patch panel, from RJ-45 outlet to VAP, and from VAP to appliance).

1. Review the IT documentation, which may be available from your IT department, to determine cable types and lengths.
2. Check the lengths of the patch cords being used and verify the end-to-end distance does not exceed 100m (300ft).
3. A Fluke cable tester can be used to measure cable length.

## 10.5 No Service from Connected Access Pod

This requires physically accessing the Access Pod to check the LEDs, and accessing the Access Pod through the Web GUI to verify the Access Pod configuration.

1. Physically view the Access Pod and confirm that both LEDs on the Access Pod are lit:
  - Power LED (Green) is OFF – Either no connectivity to the VCU or the VAP is faulty. Try replacing the VAP. Try connecting the VAP directly to the VCU if the Power LED is lit check the cable and the patch cords.
  - Activity LED is constantly blinking – The Access Pod cannot initialize due to exceeded cable length. Try using the closest free RJ-45 jack fed with a different cable.



2. Check other Access Pods connected to the same VCU.
3. Verify that the VAP configuration as follows:
  - Connect to the VCU using the MobileAccess**VE** Web GUI application (See section 6.1) and select the VAP from the topology tree.



- In the **Config** tab, click on the relevant **Service RF** sub-tab and verify that the Service Control parameter is set to **On**.
- Confirm that the VCU port is functioning (VAP status LED associated with this Pod is green).
- In case external antennas are connected – verify the VAP was configured to use the external antennas (See **Antenna** parameter in VAP Service RF sub-tab, shown above).

## 10.6 VCU Cannot be Monitored via SNMP

VE traps are not received by the external Fault Monitoring system.

1. Verify that the VCU is powered ON.
2. Verify that the SNMP traps destination address is configured correctly.
3. Verify the IP connectivity to the Fault Monitoring server using "ping."
4. Verify that SNMP port is not blocked or fire-walled in the IP network.
5. Initiate an Alarm and confirm the trap is received by external Fault Monitoring server. For example:
  - Access the VAP Service RF sub-tab (See section 8.3).



- Verify that the alarm is unmasked.
- Set the **Service Control** parameter to **Off**.
- Confirm the trap is received by external Fault Monitoring server.

# Appendix A - Traps

This section lists the MobileAccessVE Dual-Band Controller and Access Pod Traps.

## VE Control Unit (VCU) Traps

Trap Name	Trap Description
vcuChannel_1_DLPowerLow	(Major) Alert for low RF in VCU for Service 1: 15dB less than max expected power
vcuChannel_1_DLPowerHigh	(Minor) Alert for High RF in VCU for Service 1: 3dB more than max expected power
vcuChannel_1_ServiceOff	(Major) User set Service 1 to off
vcuChannel_2_DLPowerLow	(Major) Alert for low RF in VCU for Service 2: 15dB less than max expected power
vcuChannel_2_DLPowerHigh	(Minor) Alert for High RF in VCU for Service 2: 3dB more than max expected power
vcuChannel_2_ServiceOff	(Major) User set Service 2 to off
vcuFault	(Major) HW failure in VCU
vcuOverTemperature	(Minor) VCU temperature is too high
vcuMismatchType	(Minor) When VCU services types is different than VAP services types
vcuAdjustment	(Major) When adjustment (for Slave VCU) has failed (cable too long)

## VE Access Pod (VAP) Traps


Trap Name	Trap Description
vapAdjustment	(Major) Cable is too long (over 100m/300ft)
vapChannel_1_ServiceOff	(Minor) User set service 1 to Off
vapChannel_2_ServiceOff	(Minor) User set service 2 to Off
vapFaulty	(Major) The Access Pod is faulty
vapOverTemperature	(Minor) VAP temperature is too high




## Appendix B – MobileAccess VE Dual Band MIB Tree Structure (Version 1.8)

The following MIB is used for managing the MobileAccess VE VCU and VAPs across the network infrastructure. This MIB Structure and OIDs are specifically related to MIB Release 1.8 with the expectation that New OIDs will be added with the release of future Firmware Versions.

*MIB Tree Structure is on the following pages.*





## MobileAccess Version 1.8 MIBs/OID Descriptions

Module	Node Name	OID String	Description
MaVE-MIB	enterprises	.1.3.6.1.4.1	Enterprise
MaVE-MIB	mobileAccess	.1.3.6.1.4.1.15921	MobileAccess
MaVE-MIB	maVE	.1.3.6.1.4.1.15921.11	MobileAccess VE
MaVE-MIB	maVEVCU	.1.3.6.1.4.1.15921.11.1	MobileAccess VE VCU
MaVE-MIB	maVEVCUTable	.1.3.6.1.4.1.15921.11.1.1	VCU Table
MaVE-MIB	maVEVCUEntry	.1.3.6.1.4.1.15921.11.1.1.1	VCU Table Entries
MaVE-MIB	vcuLocationLevelIndex1	.1.3.6.1.4.1.15921.11.1.1.1.1	1 for Master VCU and 2 to 13 are the Slave VCUs
MaVE-MIB	vcuName	.1.3.6.1.4.1.15921.11.1.1.1.2	MA VCU NAME
MaVE-MIB	vcuSerialNumber	.1.3.6.1.4.1.15921.11.1.1.1.3	MA VCU Serial Number
MaVE-MIB	vcuProductRevision	.1.3.6.1.4.1.15921.11.1.1.1.4	MA VCU Product revision
MaVE-MIB	vcuSWVersionActive	.1.3.6.1.4.1.15921.11.1.1.1.5	MA VCU Active Software Version
MaVE-MIB	vcuSWVersionInactive	.1.3.6.1.4.1.15921.11.1.1.1.6	MA VCU Inactive Software Version
MaVE-MIB	vcuReset	.1.3.6.1.4.1.15921.11.1.1.1.7	MA VCU RESET
MaVE-MIB	vcuIdentify	.1.3.6.1.4.1.15921.11.1.1.1.8	MA VCU Indetify
MaVE-MIB	vcuChannel1ServiceType	.1.3.6.1.4.1.15921.11.1.1.1.9	MA VCU Service Type
MaVE-MIB	vcuChannel1DLCF	.1.3.6.1.4.1.15921.11.1.1.1.10	MA VCU First channel DL CF in 100Khz
MaVE-MIB	vcuChannel1ULCF	.1.3.6.1.4.1.15921.11.1.1.1.11	MA VCU First channel UL CF in 100Khz
MaVE-MIB	vcuChannel1MaxExpectedPin	.1.3.6.1.4.1.15921.11.1.1.1.12	MA VCU First channel Max Expected Input Power - in dBm ;when vcuChannel1ServiceType >50(In WiMAX/PHS)the value is (dBm value + 100))

Module	Node Name	OID String	Description
MaVE-MIB	vcuChannel1ActualPin	.1.3.6.1.4.1.15921.11.1.1.1.13	MA VCU First channel Actual Input Power In - in 0.1 dBm means: (when vcuChannel1ServiceType <50 the value is (dBm value *10) ; when vcuChannel1ServiceType >50(In WiMAX/PHS) the value is (dBm value + 100)*10
MaVE-MIB	vcuChannel1ULSystemGain	.1.3.6.1.4.1.15921.11.1.1.1.14	MA VCU First channel UL System Gain
MaVE-MIB	vcuChannel1ServiceControl	.1.3.6.1.4.1.15921.11.1.1.1.15	MA VCU First channel Service control (N/A in MIMO/SISO services)
MaVE-MIB	vcuChannel2ServiceType	.1.3.6.1.4.1.15921.11.1.1.1.16	MA VCU Service Type
MaVE-MIB	vcuChannel2DLCF	.1.3.6.1.4.1.15921.11.1.1.1.17	MA VCU Second channel DL CF in 100Khz (in MIMO refer to relevant leaf at channel 1)
MaVE-MIB	vcuChannel2ULCF	.1.3.6.1.4.1.15921.11.1.1.1.18	MA VCU Second channel UL CF in 100Khz (in MIMO refer to relevant leaf at channel 1)
MaVE-MIB	vcuChannel2MaxExpectedPin	.1.3.6.1.4.1.15921.11.1.1.1.19	MA VCU Second channel Max Expected Input Power - in dBm (in MIMO refer to relevant leaf at channel 1)
MaVE-MIB	vcuChannel2ActualPin	.1.3.6.1.4.1.15921.11.1.1.1.20	MA VCU Second channel Actual Input Power - in 0.1 dBm means: (when vcuChannel2ServiceType <50 the value is (dBm value *10) ; when vcuChannel2ServiceType >50 the value is (dBm value + 100)*10
MaVE-MIB	vcuChannel2ULSystemGain	.1.3.6.1.4.1.15921.11.1.1.1.21	MA VCU Second channel UL System Gain (in MIMO refer to relevant leaf at channel 1)
MaVE-MIB	vcuChannel2ServiceControl	.1.3.6.1.4.1.15921.11.1.1.1.22	MA VCU Second channel Service control (N/A in MIMO/SISO services)
MaVE-MIB	vcuServiceMode	.1.3.6.1.4.1.15921.11.1.1.1.23	MA VCU Service mode ; set is relevant for values of MIMO/SISO/OFF
MaVE-MIB	vcuAlarms	.1.3.6.1.4.1.15921.11.1.1.1.24	MA VCU Alarms; Bits are as follow: vcuChannel1ServiceType <50: 1 - VCU Faulty; 2 - Over Temperature; 4 - Type Mismatch; 8 - Channel1 RF DL low; 16 - Channel1 RF DL High; 32 - Channel1 RF Off; 64 - Channel2 RF DL low; 128 - Channel2 RF DL High; 256 - Channel2 Off ; vcuChannel1ServiceType >50: 1 - VCU Faulty; 2 - Over Temperature; 4 - Type Mismatch; 8 - service Off; 16 - Channel1 RF DL low; 32 - Channel1 RF DL High; ; 64 - Channel2 RF DL low; 128 - Channel2 RF DL High; 256 - Channel2 Off

Module	Node Name	OID String	Description
MaVE-MIB	vcuAlarmMask	.1.3.6.1.4.1.15921.11.1.1.1.25	MA VCU Alarm Mask; Bits refer to alarms bits described above
MaVE-MIB	vcuOverallStatus	.1.3.6.1.4.1.15921.11.1.1.1.26	MA VCU Overall Status
MaVE-MIB	vcuMACaddress	.1.3.6.1.4.1.15921.11.1.1.1.27	MA VCU MAC Address
MaVE-MIB	vcuIPAddress	.1.3.6.1.4.1.15921.11.1.1.1.28	MA VCU IP Address
MaVE-MIB	vcuSubnetMask	.1.3.6.1.4.1.15921.11.1.1.1.29	MA VCU Subnet Mask
MaVE-MIB	vcuDefaultGateway	.1.3.6.1.4.1.15921.11.1.1.1.30	MA VCU Default Gateway
MaVE-MIB	vcuTrapDestinationIP1	.1.3.6.1.4.1.15921.11.1.1.1.31	MA VCU Trap Destination Ip address 1
MaVE-MIB	vcuTrapDestinationIP2	.1.3.6.1.4.1.15921.11.1.1.1.32	MA VCU Trap Destination Ip address 2
MaVE-MIB	vcuTrapDestinationIP3	.1.3.6.1.4.1.15921.11.1.1.1.33	MA VCU Trap Destination Ip address 3
MaVE-MIB	maVEVAP	.1.3.6.1.4.1.15921.11.2	MobileAccess VE VAP
MaVE-MIB	maVEVAPTable	.1.3.6.1.4.1.15921.11.2.1	VAP Table
MaVE-MIB	maVEVAPEntry	.1.3.6.1.4.1.15921.11.2.1.1	VAP Table Entries
MaVE-MIB	vapLocationLevelIndex1	.1.3.6.1.4.1.15921.11.2.1.1.1	1 to 12 the VAP port itself (single tier), or 2 to 13 for the Slave VCU port index
MaVE-MIB	vapLocationLevelIndex2	.1.3.6.1.4.1.15921.11.2.1.1.2	1 to 12 - for the VAP port index
MaVE-MIB	vapName	.1.3.6.1.4.1.15921.11.2.1.1.3	MA VAP NAME
MaVE-MIB	vapSerialNumber	.1.3.6.1.4.1.15921.11.2.1.1.4	MA VAP Serial Number
MaVE-MIB	vapProductRevision	.1.3.6.1.4.1.15921.11.2.1.1.5	MA VAP Product revision
MaVE-MIB	vapSWVersionActive	.1.3.6.1.4.1.15921.11.2.1.1.6	MA VAP Active Software Version
MaVE-MIB	vapSWVersionInactive	.1.3.6.1.4.1.15921.11.2.1.1.7	MA VAP Inactive Software Version
MaVE-MIB	vapReset	.1.3.6.1.4.1.15921.11.2.1.1.8	MA VAP RESET

Module	Node Name	OID String	Description
MaVE-MIB	vapIdentify	.1.3.6.1.4.1.15921.11.2.1.1.9	MA VAP Indetify
MaVE-MIB	vapChannel1ServiceType	.1.3.6.1.4.1.15921.11.2.1.1.10	MA VAP Service Type
MaVE-MIB	vapChannel1ServiceControl	.1.3.6.1.4.1.15921.11.2.1.1.11	MA VAP First channel Service control (N/A in WiMAX)
MaVE-MIB	vapChannel1DLPoutLevel	.1.3.6.1.4.1.15921.11.2.1.1.12	MA VAP first channel DL output attenuation Level
MaVE-MIB	vapChannel1DLPoutActual	.1.3.6.1.4.1.15921.11.2.1.1.13	MA VAP First channel DL Actual Output Power - in 0.1 dBm means: (when vapChannel1ServiceType <50 the value is (dBm value *10) ; when vapChannel1ServiceType >50 the value is (dBm value + 100)*10
MaVE-MIB	vapChannel1AntennaType	.1.3.6.1.4.1.15921.11.2.1.1.14	MA VAP First channel Antenna Type internal - external
MaVE-MIB	vapChannel2ServiceType	.1.3.6.1.4.1.15921.11.2.1.1.15	MA VAP Service Type
MaVE-MIB	vapChannel2ServiceControl	.1.3.6.1.4.1.15921.11.2.1.1.16	MA VAP Second Band Service control(N/A in MIMO/SISO)
MaVE-MIB	vapChannel2DLPoutLevel	.1.3.6.1.4.1.15921.11.2.1.1.17	MA VAP Second channel DL output attenuation Level
MaVE-MIB	vapChannel2DLPoutActual	.1.3.6.1.4.1.15921.11.2.1.1.18	MA VAP Second channel DL Actual Output Power - in 0.1 dBm means: (when vapChannel2ServiceType <50 the value is (dBm value *10) ; when vapChannel2ServiceType>50 the value is (dBm value + 100)*10
MaVE-MIB	vapChannel2AntennaType	.1.3.6.1.4.1.15921.11.2.1.1.19	MA VAP Second channel Antenna Type internal - external
MaVE-MIB	vapAlarms	.1.3.6.1.4.1.15921.11.2.1.1.20	MA VAP Alarms; Bits are as follow: For non SISO/MIMO services: 1 - Channel1 Off ; 2 - Channel2 Off ; 4- DL Adjustment ; 8 - VAP Faulty ; 16 - Over Temperature when SISO/MIMO services: 1 - DL Adjustment ; 2 - Over Temperature; 4 - VAP Faulty
MaVE-MIB	vapAlarmMask	.1.3.6.1.4.1.15921.11.2.1.1.21	MA VAP Alarm Mask
MaVE-MIB	vapOverallStatus	.1.3.6.1.4.1.15921.11.2.1.1.22	MA VAP Overall Status
MaVE-MIB	maVEEvents	.1.3.6.1.4.1.15921.11.9	MobileAccess VE Events

Module	Node Name	OID String	Description
MaVE-MIB	maVEEventsParams	.1.3.6.1.4.1.15921.11.9.1	MobileAccess VE Events Parameters
MaVE-MIB	maVETrapDeviceType	.1.3.6.1.4.1.15921.11.9.1.1	Device Type
MaVE-MIB	maVETrapDeviceSerial	.1.3.6.1.4.1.15921.11.9.1.2	Serial Number
MaVE-MIB	maVETrapDeviceName	.1.3.6.1.4.1.15921.11.9.1.3	Name of the Trap
MaVE-MIB	maVETrapDeviceIndex	.1.3.6.1.4.1.15921.11.9.1.4	Master VCU port
MaVE-MIB	maVETrapDevicePortIndex	.1.3.6.1.4.1.15921.11.9.1.5	the unit itself or Slave VCU port
MaVE-MIB	maVETrapEventText	.1.3.6.1.4.1.15921.11.9.1.6	Event description
MaVE-MIB	maVETrapSeverity	.1.3.6.1.4.1.15921.11.9.1.7	Trap Severity
MaVE-MIB	maVENotify	.1.3.6.1.4.1.15921.11.9.2	MobileAccess VE Notify
MaVE-MIB	maVETraps	.1.3.6.1.4.1.15921.11.9.2.0	MobileAccess VE Traps
MaVE-MIB	vcuChannel1DLPowerLow	.1.3.6.1.4.1.15921.11.9.2.0.1	The input RF power is 15 dB lower than max expected power (or no signal)
MaVE-MIB	vcuChannel1DLPowerHigh	.1.3.6.1.4.1.15921.11.9.2.0.2	when input RF power is above the defined max expected power
MaVE-MIB	vcuChannel2DLPowerLow	.1.3.6.1.4.1.15921.11.9.2.0.3	when input RF power is 15 dB lower than max expected power (or no signal)
MaVE-MIB	vcuChannel2DLPowerHigh	.1.3.6.1.4.1.15921.11.9.2.0.4	when input RF power is above the defined max expected power
MaVE-MIB	vcuChannel1ServiceOff	.1.3.6.1.4.1.15921.11.9.2.0.5	when service is off
MaVE-MIB	vcuChannel2ServiceOff	.1.3.6.1.4.1.15921.11.9.2.0.6	when service is off
MaVE-MIB	vcuFaulty	.1.3.6.1.4.1.15921.11.9.2.0.7	when VCU HW is faulty
MaVE-MIB	vcuOverTemperature	.1.3.6.1.4.1.15921.11.9.2.0.8	when VCU temperature is above threshold
MaVE-MIB	vcuMismatchType	.1.3.6.1.4.1.15921.11.9.2.0.9	When VCU services types is different than VAP services types
MaVE-MIB	vcuAdjustment	.1.3.6.1.4.1.15921.11.9.2.0.10	when VCU adjustment has failed (or cable too long)



Module	Node Name	OID String	Description
MaVE-MIB	vapAdjustment	.1.3.6.1.4.1.15921.11.9.2.0.11	when VAP adjustment has failed (or cable too long)
MaVE-MIB	vapChannel1ServiceOff	.1.3.6.1.4.1.15921.11.9.2.0.12	when VAP service is off
MaVE-MIB	vapChannel2ServiceOff	.1.3.6.1.4.1.15921.11.9.2.0.13	when VAP service is off
MaVE-MIB	vapFaulty	.1.3.6.1.4.1.15921.11.9.2.0.14	when VAP HW is faulty
MaVE-MIB	vapOverTemperature	.1.3.6.1.4.1.15921.11.9.2.0.15	when VAP temperature is above threshold
MaVE-MIB	vcuHeartbeat	.1.3.6.1.4.1.15921.11.9.2.0.16	system keep alive notification
MaVE-MIB	vcuConnected	.1.3.6.1.4.1.15921.11.9.2.0.17	VCU connected
MaVE-MIB	vcuDisconnected	.1.3.6.1.4.1.15921.11.9.2.0.18	VCU disconnected
MaVE-MIB	vapConnected	.1.3.6.1.4.1.15921.11.9.2.0.19	VAP connected
MaVE-MIB	vapDisconnected	.1.3.6.1.4.1.15921.11.9.2.0.20	VAP disconnected