



Contents

1.	Introduction	4
2.	Hardware	5
	Front View – LED Indicators	5
	Rear View – Data Connections	6
	Antennas – Positioning	7
	Environmental Limits	8
3.	Firmware	9
	File System	9
	Upgradeable Firmware	9
	Reader Setup	10
	Reader Settings	11
	Network Settings	12
	Advanced Network Settings	13
	Programming Options	14
	Configuration Files & Default Settings	15
4.	Troubleshooting	18
A.	List of Acronyms	20
B.	Index	22
C.	FCC Compliance	23
D.	Copyright Statement	24

Document History

Document Revised	Document ID
04 April 2006	UM-P2900-R101-20060404

Issue Date	Rev.	Comment
26 Jul 2005	00	Initial Draft
21 Feb 2006	1.00	Revision – Design change and edits. 24 pgs.
04 Apr 2006	1.01	Minor edits and formatting changes. 24 pgs.
08 Mar 2007	1.02	Addition of new FCC designator



This document is not intended for public distribution. Copying of this material is not permitted without prior written permission.



1. Introduction

The **Mantis™ II 433.92 MHz System** by **RF Code™** is an RFID monitoring system designed to report Tags within defined Reader operating ranges. The system utilizes “beacon” Tags that periodically report their presence with an encoded radio transmission. The **Mantis™ II 433.92 MHz Reader** is a dual-channel radio receiver tuned to the **Mantis™ Tag** transmission frequency of 433.92 MHz.

This manual provides the instructions for the **Mantis™ II 433.92 MHz Reader** setup and operation. This Reader has different modes of operation and optional functions that are user-selected depending on the system’s operational requirements.

The instructions in this manual show how to install, configure, and upgrade the **Mantis™ II 433.92 MHz Reader** as well as tips on **Mantis™ Tag** placement and antenna optimization. Operational instructions for the **Mantis™ II 433.92 MHz System** using the **TAVIS™ Concentrator** software by **RF Code™** are found in the **TAVIS™ Concentrator User Manual**.

2. Hardware

The **Mantis™ II 433.92 MHz Reader** is housed in a 5 x 5 x 1.5 inch (12.7 x 12.7 x 3.81 cm) metal chassis and contains the internal components of a RFID Reader combined with connections to allow for both Ethernet and serial port connectivity.

Front View – LED Indicators



Figure 2.1 – Mantis™ II 433.92 MHz Reader (front view)
shown with standard ¼-wave helical antennae.

Three LEDs are mounted on the front of the **Mantis™ II 433.92 MHz Reader**.

- **Unlabeled LED** – This LED is used for a feature that is not implemented in this version of the Reader.
- **On-Ready LED** – This LED indicates the Reader has power applied through an external power adapter.
- **Tag Activity LED** – This LED is used for two purposes: (1) to show the status of the Reader while in standby mode and (2) to show Tag detections while in operation.

Tag Activity LED

- **While Operating** – The Tag Activity LED flashes intermittently, indicating the Reader has read one or more Tags each time it flashes. Because the Reader can decode Tags faster than the light can be turned on and off, a single flash may indicate more than one Tag being decoded.
- **While in Standby Mode** – The Tag Activity LED turns on and off at a distinctive rate that indicates the Reader is in standby mode.

Rear View – Data Connections



Figure 2.2 – Mantis™ II 433.92 MHz Reader (rear view) showing connections for Network/Ethernet (RJ-45), Power, and Serial/COM (RS-232).

Several connections are housed on the back of the **Mantis™ II 433.92 MHz Reader**.

- **Ethernet** – RJ-45 Ethernet jack. The Ethernet connection has a link-state “LINK” LED and collision “COL” LED such as those found on common Ethernet network connections. The LINK light stays solid when there is no network activity and flashes when activity is present.
- **Power** – A plug allows for connection to both AC and DC power sources. Power requirements are 12 to 28 VDC and 9 to 20 VAC.
- **Serial** – DB-9 RS-232 Serial port.

Antennas – Positioning




Figure 2.3 – Standard 1/4-wave helical antennae shown in various positions.

Each antenna post supplies an RF signal to the two parallel radio receivers in the **Mantis™ II 433.92 MHz Reader**. Antenna input impedance is 50 ohms nominal.

Both the type of antennas used and the Reader range setting determine the effective read range. The normal Reader-range features are defined using **1/4-wave helical** antennas.

These antennas are appropriate for most Reader applications. Optional antennas that offer diverse receiving properties or extend the range of the Reader are available for the **Mantis™ II 433.92 MHz Reader**. Contact your **Mantis™ II 433.92 MHz Reader** distributor for more information.

The **Mantis™ II 433.92 MHz Reader** has two receiver channels that can operate independently or jointly to provide Tag signal diversity reception. The Reader can operate with one antenna on either antenna post, but the benefit of receiver diversity reception is obtained with both antennas attached.

Depending on the location and orientation of the tags, the signal path to the Reader may vary for each Tag. This may allow only one antenna to receive the signal.

To achieve the best receiver diversity:

- **Antenna Angle from Reader** – It is desirable to have the antennas positioned at different angles from the Reader.
- **Antenna Angle from Each Other** – Antennas should be at 90-degree angles relative to each other. It may be necessary to experiment with antenna positions to achieve optimum coverage.
- **Height** – As a rule, the higher a Reader is positioned above the ground or floor, the better the Reader's detection range.



WARNING – Do not allow antennas to overlap. Keep the antennas separated. Allowing the antennas to overlap reduces the effectiveness of each antenna.

To minimize RF interference:

- **Separation** – Maintain a 4-to-6-foot separation between the Reader antennas and potential RF radiators such as computers, monitors, printers and electronic office equipment. The local radio environment can limit the Reader's effective range.
- **Height** – Do not operate the Reader on or close to the floor or ground. Grounded and reflective metallic structures around the Reader and/or Tags affect the system performance. For best results, the Reader should be mounted as high as reasonably possible.



WARNING – Readers should not be positioned close to ceilings as they act as ground planes.



TOOLS – Low loss SMA coaxial extension cables may be used to separate the antennas from the Reader.



NOTE – Optional antennas that offer diverse receiving properties or extend the range of the Reader are available for the Mantis™ II Reader. Contact your Mantis™ II Reader distributor.

Environmental Limits

The **Mantis™ II 433.92 MHz Reader** is approved for use within the temperature ranges set forth below.

- **Operation:** -20 to +70 degrees Celsius.
- **Storage:** -40 to +80 degrees Celsius.

3. Firmware



NOTE – The Mantis™ II Reader can only be configured through an Ethernet connection via the RJ-45 jack on the rear of the Reader.



WARNING – When an Ethernet connection is made directly between the Reader and a PC, a cross-over network cable is necessary.

File System

All embedded operating systems, signal processing software, and configuration options of the **Mantis™ II 433.92 MHz Reader** are stored in a flash-based file system internal to the Reader. If any changes or updates are required, the files are collected in a directory on the PC, packaged into a new file system, and then transferred to the Reader by **TFTP** (Trivial File Transfer Protocol).


Upgradeable Firmware

The **Mantis™ II 433.92 MHz Reader** has the ability to be updated as new firmware is released. It is vital these updates be obtained directly from **RF Code™** or its authorized source, since these files define the operation of the Reader and if defective, the files will render the Reader inoperable.



WARNING – Firmware updates should be obtained directly from RF Code™ or its authorized source. If defective, these files will render the Mantis™ II Reader inoperable.

Reader Setup



```

Configure Mantis II Reader

===== Network-enabled Reader Programmer =====
===== Version 7.1.1 =====
===== RF Code, Inc. Copyright 2004 =====

Reader Settings:  (R) reader #
                  (U) B processor FW
                  (D) A processor SW
                  Calibration <loaded from reader in upload process>

Network Settings:  MAC Addr
                  (I) P Addr
                  (S) ubnet
                  (G) ateway Addr
                  (P) ing TFTP IP Addr
                  (A) RP Table display

Advanced Network Settings:  (1) Keep alive probes = 10
                          (2) Keep alive signal interval <in ms> = 1000
                          (3) Packet size <in bytes> = 1400
                          (4) Packet timeout <in ms> = 500

Programming Options:  (L)oad Defaults
                    (F)ilesystem Upload to Reader
                    (I)FTP Addr

                    (Q)uit

----->

```

Figure 3.1 – Network-enabled Reader Programmer Utility.

To perform a **Reader** setup or update:

Step 1 – Launch the **Configure Mantis II Reader** utility, found in the RF Code Mantis II Reader program group on the Start Menu. (The location will be different if the defaults were not used during the install process.)

Step 2 – The **Network-enabled Reader Programmer** utility appears in a DOS screen (see **Figure 3.1** above). Refer to the commands below:

- **Reader Settings** – Refer to page 11.
- **Network Settings** – Refer to page 12.
- **Advanced Network Settings** – Refer to page 13.
- **Programming Options** – Refer to page 14.
- **Network Installation** – Refer to the example on page 15.



WARNING – Computer administrative privileges are recommended when using the network-enabled Reader programmer utility. In the event of IP resolution conflicts, the utility will attempt to modify the Address Resolution Protocol (ARP) table. On some systems this can only be achieved with sufficient privileges.

Reader Settings

(R)eader #

R

R - Select a new Reader to program.

- Reads and displays a Reader's saved calibration and settings from its configuration file (**SSI_info\AXnnnnnnn.txt** where **AXnnnnnnn** is the serial number). Any undefined settings will remain blank.
- Errors are displayed if the info file is missing or contains bad calibration data.
- The **Reader #** is the **s/n** (serial number) on the silver label on the underside of the Reader. When entering this number ignore the space between the two sets of 4 numbers and input it as a single 8-digit alpha-numeric serial number.

(U)B processor FW

U

U – Choose firmware revision for the network processor.

- Prints list of available files.
- Type the desired filename (case-sensitive).
- An error message is displayed if the firmware file cannot be found.

(D)A processor SW

D

D – Choose firmware revision for the DSP processor.

- Prints list of available files.
- Type the desired filename (case-sensitive).
- An error message is displayed if the firmware file cannot be found.

Calibration (loaded from reader in upload process)

Reader calibration data.

- This field only displays the calibration data for the Reader at the time of the upload process, when this information is retrieved from the Reader. This field is informational only and cannot be modified.

Network Settings

MAC Addr

Reader MAC address.

- Displays the MAC address of the Reader. This field is informational only and cannot be modified.

(I)P Addr

I

I – Change network IP address.

- Enter in normal dotted decimal format, e.g.: **192.168.1.129**
- An error message is displayed if the format is unintelligible or the numbers are out of range.
- This entry represents the new IP address that will be assigned to the Reader during an upload.



WARNING – Microsoft Windows-based PCs have restrictions on certain IP address ranges (e.g. 127.x.x.x and 224.x.x.x through 254.x.x.x). Since addresses fitting these parameters cannot be configured on a Windows-based PC, it will not be possible to use the configuration utility to reconfigure a Reader that has been assigned an address within this scope.

(S)ubnet

S

S – Change subnet mask.

- Enter in normal dotted decimal format, e.g.: **255.255.255.0**
- An error message is displayed if the format is unintelligible or the numbers are out of range.

(G)ateway Addr

G

G – Change gateway address.

- Enter in normal dotted decimal format, e.g.: **192.168.1.1**
- An error message is displayed if the format is unintelligible or the numbers are out of range.

(P)ing TFTP IP Addr

P

P – Pings the TFTP IP address.

- An error message is displayed if the TFTP IP address is blank.
- A status message is displayed which reflects the results of the pinging operation.
- If a ping is unsuccessful, the utility will attempt to remove the TFTP IP address from the ARP table and perform another ping.

(A)RP Table display**A****A – Displays the ARP Table.**

- When two or more Readers initially share the same IP address, it is likely that the ARP will need to be either modified or flushed before sequential accesses to the same IP address can be performed (due to physical addressing). This feature provides a method of querying the ARP table to assess IP resolution issues.

Advanced Network Settings

(1) Keep Alive Probes (default is 10)**1****1 – Change the number of keep-alive probes.**

- Defines the maximum number of keep-alive probes to send.
- An error message will be displayed if an invalid number is entered (and the field will be cleared).

(2) Keep Alive Signal Interval (default is 1000 ms)**2****2 – Change the keep-alive signal interval.**

- Defines how often keep-alive probes are sent on a connection (in milliseconds).
- An error message will be displayed if an invalid number is entered (and the field will be cleared).

(3) Packet Size (default is 1400 bytes)**3****3 – Change the packet size.**

- Defines the maximum packet size in bytes.
- An error message will be displayed if an invalid number is entered (and the field will be cleared).

(4) Packet Timeout (default is 500 ms)**4****4 – Change packet timeout setting.**

- Defines the packet timeout (in milliseconds).
- An error message will be displayed if an invalid number is entered (and the field will be cleared).

Programming Options

(L)oad Defaults

L

L – Load default firmware and network settings.

- These are settings as defined in the **SSI_info\defaults.txt** file.
- This command is useful after a **(R)ead** # command to update to a standard network configuration before programming.
- Errors are displayed if any settings are invalid.

(F)ilesystem Upload to Reader

F

F – Create file system and upload to the Reader.

- Prior to the upload, the Reader parameters are verified and the TFTP IP address is pinged. The process will only continue if these are successful.
- Creates file system (**A.bin**, **Bcom.bin**, **caltable.txt**, **network.txt**) using currently displayed settings, uploads to the Reader, then initiates self-programming.
- If applicable, after re-initialization of the Reader the file system is retrieved from the Reader and verified against the original.
- Errors are displayed if any vital components are missing, if the settings are not properly defined, or if there are problems communicating with the Reader over the network.
- Saves the Reader configuration data upon a successful upload.



WARNING – If the IP address to be assigned to the Reader is out of scope with regard to the subnet mask, the utility will upload the file system to the Reader but will NOT attempt to retrieve this file system back from the Reader for verification.

(T)FTP Addr

T

T – Set TFTP address for the file system upload.

- This address must reflect the current IP address of the Reader, which likely differs from the new IP address to which it is being set with the **(I)P Addr** command.
- Under normal circumstances, this should not have to be changed. The **TFTP** (Trivial File Transfer Protocol) address is automatically updated when the **IP** address of the Reader is changed and a successful upload is performed.

(Q)uit

Q

Q – Quit the Network-enabled Reader Programmer Utility.

Configuration Files & Default Settings

Each Reader has a configuration file under **SSI_info\AXnnnnnn.txt** (where **AXnnnnnn** is the serial number) reflecting its last programmed state. After a successful program upload to a Reader, the configuration file for that Reader is updated with the current settings.

The next time the Reader is selected for configuration, these saved settings are imported and displayed as a baseline configuration. The Reader configuration file is therefore purposely similar to the interactive commands.



WARNING – Do not use [CTRL]+[C] to exit, or the last settings of the Mantis™ II 433.92 MHz Reader will be lost!

Example – Network Installation

Step 1 – Select the **(R)** command, then enter the Reader's serial number when prompted.

Step 2 – Select the **(I)** command, then enter the new IP address for the Reader (e.g. 192.168.4.34).

Step 3 – Select the **(S)** command, then enter the new subnet mask for the Reader (e.g. 255.255.0.0).

Step 4 – Select the **(F)** command to upload the new file system and update the Reader settings.

Serial Settings

The **Mantis™ II 433.92 MHz Reader** supports operation via a standard RS-232 serial port, which may be used instead of, or in conjunction with the Ethernet jack. The Reader will accept commands from either source, or output results to both. In addition, the serial port doubles as a diagnostic port, providing valuable feedback about Reader functionality and configuration during power-up and programming.

Having selected the appropriate serial port (COM port) on your system, use the following settings in your communications package:

Bits Per Second: **115200**
Data Bits: **8**
Parity: **None**
Stop bits: **1**
Flow Control: **None**

ASCII Setup

- ASCII Sending
 - Send line ends with line feeds: **NO**
 - Echo typed characters locally: **NO**
 - Line delay: **10 ms**
 - Character delay: **0**
- ASCII Receiving
 - Append line feeds to incoming line ends: **YES**
 - Force incoming data to 7-bit ASCII: **NO**
 - Wrap lines: **NO**

Ethernet Settings

As shipped, the default network settings for the **Mantis™ II 433.92 MHz Reader** are:

IP address: **192.168.1.129**
 Subnet mask: **255.255.255.0**
 Gateway: **0.0.0.0**



WARNING – These settings must be changed to match the subnet of the network on which the Mantis™ II 433.92 MHz Reader is to be used.

These Ethernet settings are stored in the **network.txt** file, which is read by the Reader at boot time. Each setting is represented as a string of hexadecimal characters. For IP addresses, a pair of hexadecimal characters (00 to FF) represent each decimal component (0 to 255) of the address. For example:

IP address: **192.168.1.239 => COA801EF**
 Subnet mask: **255.255.0.0 => FFFF0000**
 Gateway: **192.168.1.1 => COA80101**

The **network.txt** file consists of these default hexadecimal strings that are concatenated on a single line. For example:

COA80181	FFFFF00	COA80105	0A	3E8	578	1F4
IP Addr	Sub. Mask	Gateway	Keep-alive probes	Keep-alive interval (ms)	Packet size (bytes)	Packet timeout (ms)



WARNING – This network.txt file should not be altered. Instead, the Network-enabled Reader Programmer allows the user to change these settings using dotted decimal notation for IP addresses, the subnet mask, and other advanced settings.

4. Troubleshooting

This is a brief list of potential problems, with possible solutions, that may be encountered while using the **Mantis™ II 433.92 MHz Reader** or the network-enabled Reader programming utility. If the problem cannot be resolved using this list, please call the distributor from which you obtained the **Mantis™ II 433.92 MHz System** for help in resolving the problem.

SYMPTOM – There are no Tags being read at the Reader.

- **CONDITION** – The Reader power light is off.
- **REMEDY** – Plug in the Reader power supply.
- **REMEDY** – Turn on the Reader power switch.

SYMPTOM – There are no Tags being read at the Reader.

- **CONDITION** – The Reader power light is on.
- **CONDITION** – The Reader detect light is turning on and off at a regular interval.
- **REMEDY** – The Reader is in standby mode and needs to be configured and enabled for operation.

SYMPTOM – There are no Tags being read at the Reader.

- **CONDITION** – The Reader has power but is unresponsive to system communications or remote restart commands.
- **REMEDY** – Verify the LAN is connected and the Client Bridge can be “Pinged”.
- **REMEDY** – Verify that the Reader is connected to the LAN by a wired cable or by wireless but not by both. If connected by a wired LAN, remove the wireless card from the Reader.

SYMPTOM – There are no Tags being read at the Reader. The Reader has been configured, enabled and is communicating.

- **CONDITION** – The Reader power light is on.
- **CONDITION** – The Reader detect light is not flashing.
- **CONDITION** – The system is receiving the “status” message from the Reader.
- **REMEDY** – Verify the antennas are attached to the Reader and/or move the Tags closer to the Reader.
- **REMEDY** – Change the range setting on the Reader to a longer range to see the available Tags.
- **REMEDY** – Verify the communication medium between the Reader and the computer is operational.
- **REMEDY** – Verify that the configured group code is the same as the Tags being read.
- **REMEDY** – Verify the computer program is set up correctly to receive TagIDs.

SYMPTOM – Tag IDs do not drop off the computer display when the Tags are moved away from the Reader.

- **CONDITION** – The antenna(s) are installed on the Reader.
- **REMEDY** – Verify that the data communication path from the Reader to the computer is functional.
- **REMEDY** – Change the Reader's range setting to a shorter range.

SYMPTOM – All the indicator lights on the Reader turn off and back on again.

- **REMEDY** – If the Reader is not in operation or off-line, the watchdog timer inside the Reader periodically power-cycles the whole Reader. This is normal operation.

A. List of Acronyms

RFCP – **RF Code** Common Protocol
RFQS – **RF Code** Quick Search
TAVIS™ – Total Asset VISibility

ADO - ActiveX Data Objects
API - Application Program Interface
ARIN – American Registry for Internet Numbers
ARP – Address Resolution Protocol
ASP – Active Server Page

B2B - Business-to-Business
BGP4 - Border Gateway Protocol
BSA - Business Systems Analyst

CDFS - Compact Disc File System
CGI – Common Gateway Interface
COM - Component Object Model
CPU - Central Processing Unit
CSS - Cascading Style Sheet

DDL – Description Definition Language
DHTML - Dynamic Hyper-Text Markup Language
DLL – Dynamic Link Library
DLT - Digital Linear Tape
DMZ - Demilitarized Zone
DNS - Domain Name Server
DoS - Denial of Service

EDI - Electronic Data Interchange
EJB - Enterprise Java Beans
ERP - Enterprise Resource Planning

FTP - File Transfer Protocol

GIF - Graphics Interchange Format
GPS – Global Positioning System
GRE - Generic Routing Encapsulation

HTML - HyperText Markup Language
HTTP - HyperText Transfer Protocol

I/O - Input/Output
IDE - Integrated Drive Electronics
IE - Internet Explorer
IIS - Internet Information Services
IP - Internet Protocol
IPSec - Internet Protocol Security
ISO – International Organization for Standardization
ISP - Internet Service Provider
IT - Information Technology

J2EE - Java 2 Platform, Enterprise Edition

JPEG - Joint Photographic Experts Group

JSP - Java Server Pages

L2TP - Layer 2 Tunneling Protocol

LAN – Local Area Network

NNTP – Network News Transport Protocol

NTP – Network Time Protocol

OBI - Open Buying on the Internet Consortium

OC - Optical Carrier

ODBC - Open Database Connectivity

OLTP – Online Transaction Processing

OS - Operating System

PAT - Port Address Translate

PDF - Portable Document Format

POP - Point of Presence

RAID - Redundant Array of Independent Disks

RAM - Random Access Memory

RFID – Radio Frequency Identification

ROM - Read Only Memory

RTLS – Real Time Location System

SAN - Storage Area Network

SAP™ - Systems, Applications, Products, and Data Processing™

SDK - Software Developer's Kit

SGML - Standard Generalized Markup Language

SNMP – Simple Network Management Protocol

SOAP – Simple Object Access Protocol

SQA - Software Quality Assurance

SSL - Secure Sockets Layer

SSI – Signal Strength Indication

TCP/IP - Transmission Control Protocol/Internet Protocol

TOAD - Tool for Oracle Applications Development

UBC - Unified Buffer Cache

UN/SPSC – United Nations Products & Services Classification

UNSPSC – Universal Standard Products & Services Classification

UPS - Uninterruptible Power Supply

URL - Universal Resource Locator

VPN - Virtual Private Network

VSS - Visual SourceSafe

WAN – Wide Area Network

WSC – Windows Script Components

XML - eXtensible Markup Language

XSL - eXtensible Style Language

XSTL - eXtensible Style Language Transformation

XHTML - eXtensible Table Markup Language

B. Index

1 command, 12
2 command, 12
3 command, 12
4 command, 12
A command, 12
acronyms, 19
Advanced network
 commands, 12
antennas, 6
ARP, 9, 12
calibration, 10
commands, 10, 13
configuration files, 14
copyright statement, 23
D command, 10
data connections, 5
default settings, 14
environmental limits, 7
ethernet settings, 16
example, 14
F command, 13
FCC compliance, 22
file system, 8
files, 14
firmware, 8
front view, 4
G command, 11
hardware, 4
I command, 11
index, 21
introduction, 3
Keep Alive Probes, 12
Keep Alive Signal Interval,
 12
L command, 13
LED indicators, 4
limits, 7
MAC Address, 11
Network commands, 11
network installation, 14
note, 7, 8
on-ready LED, 4
P command, 11
Packet Size, 12
Packet Timeout, 12
positioning, 6
power connection, 5
Programming commands,
 13
Q command, 13
R command, 10
Reader commands, 10
Reader setup, 9
Reader update, 8
rear view, 5
S command, 11
serial connection, 5
serial settings, 15
settings, 14
setup, 9
T command, 13
Tag activity LED, 4, 5
tools, 7
troubleshooting, 17
U command, 10
upgradeable firmware, 8
warning, 7, 8

C. FCC Compliance

Changes or modifications to this equipment, not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee against interference to radio or television reception, which may be determined by turning the equipment off and on; the user must try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense.

The **Mantis™ II 433.92 MHz System** has two major components which are independently certified and comply with Federal Communications Commission (FCC) rules, part 15.

This **Mantis™ II 433.92 MHz Reader** complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The system operates by using **Mantis™ 433.92 MHz Tags** which have been certified or are in the certification process. These devices comply with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) these devices may not cause harmful interference, and (2) these devices must accept any interference received, including interference that may cause undesired operation.

1. FCC IDs
 - a. P6F2005433 for:
 - i. Mantis II Tags 10 second P/N 05102050-47
 - ii. Mantis II Tags with 10 second motion, 12 second beacon P/N 05102050-66
 - iii. Mantis II Tags with tamper P/N 05102050-54
 - iv. Mantis II Tags with panic P/N 05102050-55
 - v. Mantis II Tags with IR and motion P/N 05102050-52
 - b. P6F433MHZ for:
 - i. Security Tag P/N 05162220-01

D. Copyright Statement

Copyright © 2003-2006 RF Code, Inc. All rights reserved.

Mantis™ II 433.92 MHz Reader
User Manual
Document Revision 1.02

This document, as well as the software described therein, is furnished under license and may only be used or copied in accordance with the terms of such license. The information in these pages are furnished for informational use only, are subject to change without notice, and should not be construed as a commitment by RF Code, Inc. RF Code assumes no responsibility or liability for any errors or inaccuracies that may appear in these pages.

Except as permitted by such license, no part of these pages may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means -- electronic, mechanical, recording or otherwise -- without the prior written permission of RF Code.

Every effort has been made to supply complete and accurate information. However, RF Code assumes no responsibility for its use, or for any infringements of patents or other rights of third parties, which would result. Information in these pages is subject to change without notice.

Some of the names of individuals and companies that may appear in these pages are fictitious. Any similarity to real persons or companies is coincidental.

Written and designed by RF Code. Technical Writer: Bob Litt.

Microsoft is a trademark of Microsoft Corporation. All other product names are copyright and registered trademarks or trade names of their respective owners.



RF Code, Inc.
1250 South Clearview Avenue
Mesa, AZ 85208 USA

www.rfcode.com

Technical Support
Visit our website. Click the "Contact Us" link.