

aiwa

OPERATING INSTRUCTIONS
BEDIENUNGSANLEITUNG
MODE D'EMPLOI
INSTRUCCIONES DE MANEJO
GEBRUIKSAANWIJZING

MM-RX400

MEMORY AUDIO PLAYER/FM RADIO
##REPRODUCTOR DE AUDIO DE
MEMORIA

ENGLISH

DEUTSCH

FRANÇAIS

ESPAÑOL

NEDERLANDS

NOTICE TO USERS

WARNING

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

Copyright Notices

Under the copyright laws, neither the documentation nor the software for this product may be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of AIWA Co., Ltd.

Copyright © 2001 AIWA Co., Ltd. All rights reserved.

- Microsoft, Windows, Windows Media and the Windows Logo are trademarks or registered trademarks of Microsoft Corporation.
- Intel and Pentium are registered trademarks of Intel Corporation.
- MultiMediaCard is a trademark of Infineon Technologies AG.
- The names of systems and products appearing in this manual may be registered trademarks or trademarks of their respective companies or organizations. In this manual, the™ or® mark is not always explicitly described.

Disclaimer

AIWA Co., Ltd. will not be responsible for any loss or damage of music files due to their transfer to the MM-RX400 player.

About the supplied software

- For using the supplied Audio Manager software, follow the terms of License Agreement that you can view during the installation of the software.
- You need software upgrades in order to support emerging new compression methods other than WMA and MP3. Some software upgrades may not be free of charge.
- * For FAQs and downloading the new software for the MM-RX400 player, refer to <http://www.aiwa.co.jp/mm/rx400/>.

Warning

You must be aware that distributing copies of WMA- or MP3-format music files to any other person without permission is against the copyright laws. You can use the software in the supplied installation CD-ROM for personal use only.

COPYRIGHT

Please check the laws on copyright relating to recordings from discs, radio or external tape for country in which the machine is being used.

MM-RX400 player is designed to be ready for the SDMI (Secure Digital Music Initiative).

PRECAUTIONS

The following are precautions that you should always keep in mind. Any violation of one or more of the following precautions may cause damage and will void the warranty.

To maintain good performance

- Avoid exposure to heat, moisture and static electricity.
- Do not use the player in places that are extremely hot, cold, dusty, or humid.
- In particular, do not keep the player in a high humidity area such as a bathroom, near a heater or in an area exposed to direct sunlight (e.g., inside a parked car).
- When you carry the battery in your pocket, do not have other metal objects such as coins or keys in the same pocket. Friction caused by the metal and the battery rubbing together may cause a fire.
- Make sure that pins or other foreign objects do not get inside the player.

Caution of impact

Do not drop the player or allow any sharp impact. This may cause serious damage to the player.

Note on listening with the headphones

- Listening to the player at full power for extended periods of time can result in hearing damage.
- Do not wear the headphones while driving or cycling. This may create a traffic hazard.
- You should use extreme caution or temporarily discontinue use in potentially hazardous situations, such as walking, jogging, etc.
- Wear them properly; L is left and R is right.
- The in-ear type headphones should be worn with the longer cord behind your neck.

To clean the cabinet

Do not use chemicals to clean the cabinet. This may change the color of the player or damage the surface. Use a soft towel to clean the surface of the player.

TABLE OF CONTENTS

INTRODUCTION

Main features	5
Accessories	5
System requirements	6
About this manual	6
Viewing Help	7

PREPARATION

Installing the Audio Manager and driver software	8
Uninstalling the Audio Manager and driver software	10
Preparing the MM-RX400 player	10
Charging the battery	10
Inserting the battery	11
Installing a MultiMediaCard	12
Formatting a MultiMediaCard	12
Connecting the MM-RX400 player to your computer	13
Disconnecting the MM-RX400 player	13

USING AUDIO MANAGER

Starting Audio Manager	14
Switching between the Audio Manager window and small player	14
To exit Audio Manager	14
Changing the appearance of the Audio Manager window	14
Identification of Audio Manager controls	15
Audio Manager window	15
Recording tracks from a music CD ...	17
Read a CD window	17
Recording tracks	18
Obtaining track information about a music CD automatically	22
Obtaining music files via the Internet	23
Organizing tracks using play list	25
Play List window	25
Creating a play list	27
Creating a play list so that it contains music files already on your computer	29
Adding tracks to the previously created play list	30
Deleting tracks from the previously created play list	31

Deleting tracks and play lists from your database	32
Editing track information	33
Playing the tracks in the play list	33
Playing the tracks on the music CD	34
Shortcut menus	34

Transferring tracks to the MM-RX400 player	35
Copy to Devices window	35
Transferring tracks to the MM-RX400 player	37
Viewing current memory usage status of the memory media	40
Deleting tracks from the memory media	40
Increasing the number of files that can be transferred to the MM-RX400 player	40
Formatting the internal Flash Memory and MultiMediaCard	41

USING THE MM-RX400 PLAYER

Player overview	42
Main unit	42
Remote control	44
Display window	45
Using the player	46
Playing back tracks	46
Selecting a play mode	47
Playing a desired portion of a track repeatedly (A-B Repeat Playback)	47
Selecting equalizer settings to suit tracks	48
Changing the track information	48
Selecting the AREA setting before you use the player	49
Listening to a radio program (Manual Tuning)	49
Presetting stations automatically (Auto Preset)	50
Presetting stations manually (Manual Preset)	51
Listening to a preset station	51

APPENDIX

Specifications	52
Frequently asked questions	52
General questions	52
Questions about the MM-RX400 player	54
Troubleshooting	55
Messages	59

INTRODUCTION

Main features

- Boosts the capability of portable audio equipment by incorporating the FM radio feature in addition to the high-performance memory audio player.
- Having no drive mechanism results in skip-free sound.
- Incorporates 32MB of Flash Memory, providing up to 96MB of storage for recording music files in combination with the optional MultiMediaCard.
- The USB computer interface provides high-speed transfer of music files.
- Plays back highly compressed CD-quality WMA- and MP3-format music files that have been transferred from your computer using the supplied Audio Manager software.

Accessories


The following accessories are supplied with the MM-RX400 player. Make sure all of the items are in the package.

If anything is missing, please contact the store where you purchased the MM-RX400 player or your nearest AIWA dealer.


① MM-RX400 player



② USB cable




③ Remote control




④ Stereo headphones



⑤ Battery charger




⑥ Rechargeable battery



⑦ Installation CD-ROM



⑧ Carrying case



⑨ Cord clip



⑩ Operating instructions, etc.

System requirements

The following hardware and software are required for using the supplied Audio Manager software.

Hardware requirements

- Intel Pentium 233 MMX or faster
- 64MB RAM or more
- Free hard-disk space
 - 32MB or more for software installation
 - 64MB or more for music-file storage
- CD-ROM drive that supports digital audio extraction
- 1 available USB port
- Sound device (DirectSound-compatible sound card recommended)
- 16-bit color video card and VGA video monitor (SVGA video monitor or higher recommended)
- 28.8-kbps modem or faster required for Internet access (ISDN or LAN connection recommended)

Software requirements

- Microsoft Windows 98 or Windows 98 Second Edition*
 - * You can use the Audio Manager software only on computers on which Microsoft Windows 98 or Windows 98 Second Edition has been preinstalled by the manufacturer. The MM-RX400 player does not support Macintosh computers.
- Microsoft Internet Explorer (Version 4.01 Service Pack 2 or later)

Note

Sound skip may occur, depending on the configuration of the computer system and the applications running on it.

About this manual

This manual includes basic instructions for using the MM-RX400 player and the supplied Audio Manager software. For detailed information on how to use the versatile functions provided by Audio Manager, refer to the Help menu that can be accessed from the Audio Manager window.

You are also recommended to read the Readme file included on the installation CD-ROM, which contains helpful supplemental information.

Installing the Audio Manager and driver software

Before using the MM-RX400 player, you must install the Audio Manager and driver software on your computer.

Before starting the installation

- Do NOT connect the MM-RX400 player to your computer.
- Quit any active applications.
- If you have already installed a different version of Audio Manager, delete it by following the procedure described in “Uninstalling the Audio Manager and driver software” (page 10).
- If you install the Audio Manager software under Windows 98 (but not Windows SE), the installation program will not change the program to be associated with a WAVE (.wav) file by Audio Manager. If your system is running Windows 98, click on “Correct” when the dialog box noticing you for it appears during installation.

You can also change the setting after installation is finished. Click on the box to the left of “Wave Audio Files” under the “File Types” tag that can be accessed by clicking on “Options” of the “View” menu.

- 1 Insert the installation CD-ROM into the CD-ROM drive of your computer.
- 2 Double-click on the My Computer icon on the desktop.
- 3 Double-click on the  icon to access the CD-ROM.
- 4 Double-click on the  icon to start the installation program. The “Welcome!” dialog box appears.



- 5 Click on “Next.” The “Choose Setup Language” dialog box appears.



- 6** Select the desired language from the drop-down menu opened by clicking on the  button, then click on “OK.”

The “License Agreement” dialog box appears.


- 7** Click on “Yes,” if you accept the terms of the Agreement.
- 8** Click on “Yes” in the next “Privacy Statement” dialog box if you accept the terms of the agreement.
- 9** Click on “Next” if you accept the default installation location or click on “Browse” to select your desired location from the “Choose Folder” dialog box.

Tip

If you wish to change the configuration, you can click on “Back” to redo any step of the installation process.


- 10** Click on “Next” if you accept the default location for storing created music files or click on “Browse” to select your desired location from the “Choose Folder” dialog box.

A dialog box appears and asks if you want to register Audio Manager as a default player.



- 11** Click on “Yes” if you want to use Audio Manager as a default player. Otherwise, click on “No” in the dialog box.


- 12** Click on “Finish” in the “InstallShield Wizard Complete” dialog box.



Copying of the driver software to the computer starts.

- 13** Click on “Finish” in the “Installation Complete” dialog box.

- 14** Click on “OK” in the dialog box that prompts you to restart your computer.




When your computer finishes rebooting, installation of the Audio Manager and driver software is completed.

Uninstalling the Audio Manager and driver software

- 1 Click on the “Start” button, point to “Programs” and “Audio Manager,” then click on “Uninstall Audio Manager.”

A dialog box appears and asks if you really want to uninstall the software.



- 2 Click on “Yes” in the dialog box.
- 3 Click on “OK” in the Uninstallation completion dialog box.



Successively uninstall the driver software.

- 4 Click on the “Start” button, point to “Programs” and “Audio Manager,” then click on “Uninstall Driver.”

You are finished uninstalling when you return to the desktop.

Preparing the MM-RX400 player


Charging the battery

Before using the rechargeable battery for the first time, charge it for about 8 hours.

- 1 Insert the rechargeable battery into the supplied battery charger.




- 2 Plug the battery charger into a wall outlet.



Recharging a completely drained battery takes about 8 hours.

When the battery has finished charging, remove it from the battery charger and disconnect the battery charger from the wall outlet.


Inserting the battery



- 1 Remove the battery compartment cover.
- 2 Install the rechargeable battery with the \oplus and \ominus poles correctly aligned.
- 3 Replace the battery compartment cover.

Battery indicator

The battery indicator shows the power remaining.



When  lights, recharge the battery. If you continue to use the MM-RX400 player after  lights, the "LOW BATT" indicator appears, operation stops, and the MM-RX400 player beeps.


Note on the rechargeable battery

- Use only the supplied battery charger to recharge the battery.
- Do NOT carry the battery in a pocket or handbag together with metal objects such as pendants or key holders.
- Do NOT short-circuit the terminals by placing a metal object across them.
- Do NOT try to disassemble the battery, heat it, or put it in water.
- The supplied rechargeable battery can be recharged approximately 300 times.

Installing a MultiMediaCard

A MultiMediaCard is optional. We recommend you to contact your nearest AIWA service personnel to purchase the MultiMediaCard that works best with your MM-RX400 player.

Before installing or removing a MultiMediaCard, be sure to turn off the MM-RX400 player and disconnect the USB cable from it.



1 Remove the battery compartment cover (page 11).

2 Insert the MultiMediaCard into the slot in the correct direction, holding it with the beveled corner to the right.

The mark printed on the player over the slot indicates the correct orientation of the card.

3 Replace the battery compartment cover.

To remove the MultiMediaCard

First push the MultiMediaCard in slightly to release it.

Formatting a MultiMediaCard

In order to use a MultiMediaCard with an MM-RX400 player, you must initialize it to MM-RX400 format using the format function of the supplied Audio Manager. For details on formatting a MultiMediaCard, see "Formatting the internal Flash Memory and MultiMediaCard" (page 37).


Note on the MultiMediaCard

- Insert the MultiMediaCard completely into the slot to ensure that it is recognized by Audio Manager.
- NEVER remove the MultiMediaCard from the MM-RX400 player while Audio Manager is formatting it or transferring music files to the MM-RX400 player. Doing so may cause not only the computer to freeze up but also the memory media to be damaged.
- Music files on the MultiMediaCard cannot be played back with another player.
- A MultiMediaCard that has been used with other players that employs a format different from Windows (DOS-compatible) format cannot be used by the MM-RX400 player even after formatting it with Audio Manager.

Connecting the MM-RX400 player to your computer

Use the supplied USB cable to connect the MM-RX400 player to your computer, as shown below.

- 1 Connect the series A connector (the larger one) to the computer's USB port.**
- 2 Connect the series B connector (the smaller one) to the USB port connector of the MM-RX400 player.**
- 3 Turn on the player by holding the  button pressed until "CONNECT USB" appears on the display of the MM-RX400 player.**
If you connect the USB cable to the MM-RX400 player while it is in Playback mode, the player will stop playback and display "CONNECT USB."



Note

- Before connecting the MM-RX400 player to your computer with the supplied USB cable, be sure to fully charge the battery. If "LOW BATT" or "NO BATT" appears on the display of the MM-RX400 player when it is connected to the computer, disconnect the MM-RX400 player from the computer, then reconnect it after fully charging the battery.
- The following actions are strictly prohibited while transferring music files or formatting the memory media. Doing so may cause not only the computer to freeze up but also the memory media to be damaged.
 - Disconnecting the USB cable from the MM-RX400 player or the computer
 - Removing the battery from the MM-RX400 player
 - Removing the MultiMediaCard from the MM-RX400 player

Disconnecting the MM-RX400 player

You can disconnect the MM-RX400 player from your computer whenever you like except during the process of transferring music files or formatting the memory media.

When you disconnect the USB cable from the MM-RX400 player, it will automatically shut off, leaving the message "GOOD-BY!!!"


Starting Audio Manager

To start Audio Manager, double-click on the  (Audio Manager) icon on the desktop.

You can also click on the “Start” button, point to “Programs” and “Audio Manager,” then click on “Audio Manager.”

Note

When you start Audio Manager for the first time after installation, the following dialog box appears.



If you have ever installed and upgraded Audio Manager, enter your e-mail address and click on “Connect.” If not, click on “Skip,” and “OK” in the next dialog box.

Switching between the Audio Manager window and small player

To switch to the small player, click on the  (Small Player) icon to the right of the navigation buttons bar in the Audio Manager window.

You can also click on “Small Player” of the “View” menu.

To switch to the Audio Manager window (big player), right-click on the area within the small player, then select “Big Player” from the shortcut menu.

Tip

Each time you press the F8 key, Audio Manager switches between the big player and small player.

To exit Audio Manager

Click on  in the upper-right corner of the Audio Manager window and small player.

You can also click on “Exit” from the “File” menu in the Audio Manager window or the shortcut menu of the small player that appears when you right-click.

Changing the appearance of the Audio Manager window

In Audio Manager, several skins of different design are available, which allow you to change the appearance of your Audio Manager window (also of the small player) to suit your preference.

Click on “Link to more skins” of the “Skins” menu in the Audio Manager window to connect to the Web site, where you can find and download skins of your preference.

When you are displaying the small player, click on “Skins” from menu of the small player that appears when you right-click.

Identification of Audio Manager controls

Audio Manager window

To make full use of the MM-RX400 player, you need to learn how to use the basic functions of the Audio Manager.



(Audio Manager with the Play List Window opened)

1 Menu bar

Clicking on an item opens a drop-down menu from which you can select commands. The following is the “View” menu opened by clicking on the “View” item on the menu bar.



To learn how each menu command functions, refer to the “Quick Reference” book in the Online Help window.

2 Audio Manager navigation buttons



make a playlist button

Click on this button to open the Play List window, which allows you to listen to tracks and organize tracks into play lists as you like, such as by artist, genre, etc. (page 25).



copy to devices button

Click on this button to open the Copy to Devices window, which allows you to transfer tracks from your computer to your MM-RX400 player (page 35). The Copy to Devices window also allows you to view a list of tracks and delete tracks stored on the memory media.



write audio cd button

Click on this button to open the Write CD window, which allows you to record tracks from your computer on a CD-R.

Note

AIWA does not support the functions available in the Write CD window. For detailed information about the Write CD window, refer to the "Write to a CD" book in the Online Help window.



read a cd button

Click on this button to open the Read a CD window, which allows you to record tracks from a music CD to your computer (page 17).



go to web button

Click on this button to connect to the WindowsMedia.com Web site (page 22).



Small Player icon

Click on this icon to transform Audio Manager into a Small Player (page 14).

Tip

You can display each window using the "Navigation" command of the "View" menu instead of using above buttons.



For a description of each control, see "5 Player controls" (page 26).

Recording tracks from a music CD

Read a CD window

The Read a CD window allows you to record selected tracks from a music CD or record an entire music CD at once. The recorded tracks can be transferred to your MM-RX400 player for playback.



1 Read a CD button bar

 **button**

Click on this button to obtain information about the inserted music CD from the CDDb server on the Internet (page 22).

 **button**

Click on this button to open the "Preview Play List" window, which allows you to edit the CD or track information manually (page 20).

 **button**

Click on this button to start recording tracks from a music CD.

 **button**

Click on this button to stop recording.

2 Read a CD Track list

Displays information about the loaded music CD, such as an album title, and the title, artist, and length of each track on the music CD.

Select the tracks you want to record by clicking on the box to the left of each track.


3 Read a CD Track list button bar

 **button**

Click on this button to reload information on the music CD.

 **button**

Click on this button to select all the tracks on the list for recording. All the boxes to the left of the tracks are checked at once.

 **button**

Click on this button to clear the check marks for all the tracks on the list at once.

4 Track Details box

Displays information about the selected track, such as the title, artist, playing time, album title, category, and lyrics. You can view more detailed information and edit it by clicking on the “Edit Track Info” button.

5 Status box

Displays the current progress of the recording process. The upper status bar displays the recording progress of the track currently being processed, and the lower status bar shows the overall recording progress for all the tracks selected for recording.

Recording tracks

Before starting

Before starting you may confirm and change the settings to use when recording tracks from a music CD by following the steps below.

To learn more about setting preferences, refer to the “Set Preferences” book in the Online Help window.

- 1 Click on “Options” of the “View” menu to open the “Options” dialog box.
- 2 Under the “Read CD” tab, confirm the following settings and change them if necessary.

Drive:

Choose the CD-ROM drive to use when recording tracks from a music CD. If you have multiple CD-ROM drives in your computer, you can change the current CD-ROM drive by clicking on  to the right of the “Drive:” field.

Record File As:

Choose the file format to use when recording tracks from a music CD by clicking on  to the right of the “Record File As:” field. You can choose between “Mpeg (.mp3)” and “Microsoft Windows Media Audio (.wma).”

Bit Rate:

Select the bit rate to be used to encode tracks recorded from a music CD. Click on  to the right of the “Bit Rate:” field, then select one of items. Higher bit rates create files with better sound quality, but larger file sizes result in less total recording time that can be stored on the memory media.

Note

The MM-RX400 player supports WMA and MP3 files encoded with a following bit rate. Files encoded with other bit rates may cause inaccuracy of elapsed playing time indicated on the display and sound skip.

- WMA files encoded with a bit rate of 64, 80, 96, 128, or 160 kbps
- MP3 files encoded with a bit rate of 64, 80, 96, 128, 160, 192, 256, or 320 kbps.

- ③ Under the “CDDB” tab, check the “Always get title from CDDB when CD is inserted” option by clicking on it if you want information about a music CD to be obtained automatically.

If you check this option, you can obtain general information about a music CD, such as album title, track titles, artist name, and playing time from the CDDB* server on the Internet. Otherwise, leave this option unchecked.

You must have Internet access to use CDDB.

* The disc-recognition service provided via the Internet by CDDB, Inc.

- 1 Double-click on the  icon on the desktop to start Audio Manager.**

- 2 Insert the music CD from which you wish to record tracks into the CD-ROM drive of your computer.**


If the Play List window is open and any tracks remain on the list, the “New CD Detected” dialog box appears, asking you to select “Play this CD,” “Append to Play List,” or “Cancel.” If this dialog box appears, click on “Cancel” in the dialog box.



3 Click on the “ read a cd” button to open the Read a CD window.

The Read a CD window appears with all the tracks on the music CD checked for recording.

If you did not check the “Always get title from CDDb when CD is inserted” option mentioned above, the dialog box appears and prompts you to obtain information about the inserted music CD automatically. Now, click on “No” so you can edit information manually.



If you want to record the entire music CD into your computer, skip steps 4 and 5, and go to step 6.

4 Click on the “Untag All” button to clear the check marks for all the tracks on the “Read a CD Track” list.

5 Select the tracks that you want to record into your computer by clicking on the box to the left of each track.


To cancel a selection, click on the box again.

Tip

If you are not sure that the track you selected is correct, right-click on the track, then select “Play” from the drop-down menu to hear it.


6 Edit track information.

- 1 Click on the “Edit Track Info” button. The “Preview Playlist” window appears.



- 2 Select the track that you want to edit, then click on the “Review/Edit” button.

The “Edit CD Track Information” dialog box appears.



- ③ Enter information about the track such as the title, artist, album title, genre, and lyrics. In some fields, you can select the desired item from the drop-down list by clicking on  to the right of the field.
- ④ Click on “Next” once or more times to go to the next track to edit. When you have no more tracks to edit, click on “Close.”
- ⑤ Click on “Close” to close the “Preview Playlist” window.


To learn more about how to use the “Edit CD Track Information” dialog box, refer to the “Edit Track Information” under the “Play List” book in the Online Help window.

7 Click on the “Start Reading” button.

The recording process for the selected tracks starts. The Status box displays the progress of the track currently being recorded and the total recording progress of all the tracks selected for recording.

To stop recording, click on the “Stop Reading” button.

When the entire track is successfully recorded, the dialog box stating that recording is completed successfully appears.



If you are going to record tracks from a CD for the first time, the “Testing CD drive...” dialog box appears stating that your system and CD-ROM drive is being tested. Through this process, your system and CD-ROM drive will be automatically configured and optimized for recording.

8 Click on “OK.”

The recorded tracks are added to your database.

Now you are ready to go to “Creating a play list” (page 27).

Obtaining track information about a music CD automatically


If you have access to the Internet, you can obtain information about the music CD, such as the album title, track title, and artist name, automatically from the CDDB on the Internet.

The CDDB is a database accessible via the Internet, which stores track information regarding a vast amount of music CDs from all over the world. If your music CD is recorded in the database, the track information about the CD will be added to your list. If not, no change will be made to the list. In such a case, you are left with entering the information manually.

To get track information about your music CD, perform the following.

- 1 Confirm that you are connected to the Internet.**
- 2 Insert the music CD into the CD-ROM drive of your computer.**

A dialog box appears asking you if you want to get information about the CD from the Internet.



- 3 Click on “Yes” in the dialog box.**

The connection to the CDDB is automatically established, and downloading starts.
- 4 When downloading is finished, information about your music CD will be displayed on the list.**

Tip

You can get information at any time you like, but before you start recording, by clicking on the “Get Track Titles” button, even if you clicked “No” in step 3 in “Recording tracks” (page 20). If you click on the “Refresh” button the above dialog box will appear.


Obtaining music files via the Internet

Audio Manager provides easy and convenient means to stream music, download music clips, and purchase music via the Internet. Clicking on a single button automatically connects you to the WindowsMedia.com Web site, where you can find vast amounts of music downloads covering almost all popular artists in the world and genres, a variety of entertainment contents such as movies and radio, and information about hardware and software. This site also provides many links to other entertainment Web sites.

Note

You must have Internet access to download music via the Internet.

- 1 Click on the “ go to web” button on the Audio Manager window. The WindowsMedia.com Web site appears.



- 2 Search for desired music through links of your preference, or enter a different Web site address in the address field if you know it.
- 3 When you find your desired music file, start downloading it by clicking on the “Download” button or other such button that may be displayed in a particular case.

The “File Download” dialog box appears.




Note

With most contents provider on the Internet, you may be required to fill in information on an enrollment form for membership before you can download music files.

4 Check the “Save this file to disk” option and click on “OK.”

The “Save As” dialog box appears.



5 Check that “My Music” is entered in the “Save in” field, enter a filename if necessary, then click on “Save.”

Downloading starts. When downloading is finished, the “Download complete” dialog box appears.

6 Click on “OK” in the dialog box.

Now you are ready to play the downloaded music file on the Audio Manager and your MM-RX400 player.

For detailed information about obtaining downloadable music files, refer to the “Visit the Internet to get audio and video” and “Play Secure Media” books in the Online Help window.

Note

Most downloadable music files are delivered in a secure files that have encrypted information for copyright protection written in them. Therefore, you may be restricted as to playing back and transferring downloaded music files.

Organizing tracks using play list

Play List window

You can use the Play List window to view all the tracks stored on your computer, as well as to create play lists and add selected tracks to them. The Play List window also allows you to play back the tracks you added from your database* to the Play List.

If you save the tracks displayed on the Play List as a play list, you can easily prepare a number of tracks for transfer to your MM-RX400 player.

* Music files recorded or downloaded to your computer using Audio Manager are automatically added to your database. Music files already on your computer can be also added to your database. To learn more about the database, refer to the "Tracks Database" and "Play List Database" books in the Online Help window.



1 Add Tracks to the Play List button bar

Select Tracks From Database button

Click on this button to select desired tracks from your database and add them to the Play List.

Select Playlists From Database button

Click on this button to select desired play lists from your database and add the tracks contained in them to the Play List at once.

Get Tracks From CD button

Click on this button to add the tracks from the music CD in the CD-ROM drive of your computer to the Play List.

2 Play List


Displays the list of the tracks you have added from your database or the music CD in the CD-ROM drive of your computer. Each track has information such as the track title, artist name, original album title and playing time, and also an icon that represents its file type.

 A track in MP3 file format

 A track in WMA (Windows Media Audio) file format

An icon preceding the track in the Play List indicates the play status of the track (stopped, in play, or play paused). This icon changes among ,  and  depending on the play status of the track.

3 Organize the Play List button bar

 **button**

Click on this button to clear all the tracks from the Play List.

 **button**

Click on this button to save the tracks displayed on the Play List as a play list, which gives you an easy way to access these grouped tracks for playback and transfer to your MM-RX400 player.

 **button**

Click on the trash can to delete the selected track from the Play List.

 **button**

Click on this button to move a selected track up in the Play List order.

 **button**

Click on this button to move a selected track down in the Play List order.


4 Track Details box

Displays detailed information about the selected track, such as the track title, artist name, original album title, ratings, artwork, and lyrics.

You can edit these details by right-clicking on the track and selecting the “Edit Track” menu command.

5 Player controls

Provide basic functions for playing back tracks with Audio Manager.



① **Elapsed playing time indicator**

② **Input level indicator**

③ **Balance control slider**

Drag the slider to adjust the balance between the left and right speakers.

④ **Volume control slider**

Drag the slider to the right or left to adjust the volume.


⑤ **Repeat play button**

Plays the current track repeatedly.

- ⑥ **Shuffle play button**
Plays all tracks in random order.
- ⑦ **Track Position slider**
Drag the slider to start playback at a different position within the track.
- ⑧  **(Backward) button**
Plays the previous track.
- ⑨  **(Play) button**
Starts playback of the selected track.
- ⑩  **(Pause) button**
Pauses playback. To resume playback, click on  again or click on .
- ⑪  **(Stop) button**
Stops playback.
- ⑫  **(Forward) button**
Plays the next track.

Creating a play list

- 1 Click on the “ make a playlist” button to open the Play List window if it is not already open.
- 2 Click on the “Clear List” button to clear the tracks already in the Play List.
- 3 Click on the “Select Tracks From Database” button.
The “Select Tracks From Database” window appears.
You can also click on the “Select Playlist from Database” button instead if you have already created play lists.



- 4 Select the tracks that you want to add to the new play list by clicking on the box to the left of each track.
To cancel the selection, click on the box again.


5 Click on “OK” when you have finished selecting the tracks.

The selected tracks are displayed in the Play List.

If there is any track that you want to exclude from the selections, select it and click on .

6 Click on the “Save Tracks as Playlist” button.

The “Add Playlist” window appears.



7 Name the new play list and fill in the other information fields under the “Description” tab.

8 If necessary, enter information about the tracks contained in the new play list in the “Edit Track Info” dialog box that can be opened by right-clicking on the area within the list, then selecting the “Edit Track...” menu command under the “Track List” tab.

9 Click on “Close” in the “Add Playlist” window when you have finished.

The dialog box stating that the play list has been saved appears.

10 Click on “OK.”

You can find the new play list in the “Select Playlist From Database” window that can be opened by clicking on the “Select Playlist From Database” button on the Play List window.

Now you are ready to transfer the tracks to your MM-RX400 player.

Functions available in the Select Tracks From Database window

Following operations are available in the “Select Tracks From Database” window:


- Sort the track order by track title, artist name, original album title or playing time by clicking on the corresponding column label.
- Use the “Find:” field to locate your target track easily. Click on the label of the column that you want to search, then type the name of the target track in the “Find:” field that you can find under that column.
- Edit track information by clicking on the “Edit” button after selecting the track.
- Listen to the track by right-clicking on the track and selecting “Play” from the shortcut menu. This is helpful when you are not sure that the track you selected is correct.

Also in the “Select Playlist From Database” window, similar operations are available with play lists.

Creating a play list so that it contains music files already on your computer

If you know where the music files are stored

- 1 Click on the “ make a playlist” button to open the Play List window if it is not already open.
- 2 Click on the “Clear List” button to clear the tracks on the Play List.
- 3 Click on “Add Tracks” of the “File” menu to open the “Add Tracks” dialog box.



- 4 Select the music files that you want to add to the play list, then click on “Open.”

The selected music files are automatically added to your database and displayed on the Play List.

- 5 Click on the “Save Tracks as Playlist.”
- 6 Name the new play list, fill in the other fields, then click on “Close.”
- 7 Click on “OK” in the dialog box that appears successively.

If you do not know where the music files are stored

- 1 Click the  “make a playlist” button to open the Play List window if it is not already open.
- 2 Click on the “Clear List” button to clear the tracks on the Play List.
- 3 Click on “Search Hard Disks for Tracks” of the “File” menu.
All the music files stored on your computer are automatically added to your database and displayed on the Play List.
- 4 Click on the “Clear List” button to clear the tracks on the Play List.
- 5 Click on the “Select Tracks From Database” button.
The “Select Tracks From Database” window appears.
- 6 Select the tracks that you want to add to the new play list by clicking on the box to the left of each track, then click on “OK” when you have finished.
The selected tracks are displayed in the Play List on the Play List window.
- 7 Click on the “Save Tracks as Playlist.”
- 8 Name the new play list, fill in the other fields, then click on “Close.”
- 9 Click on “OK” in the dialog box that appears successively.

Adding tracks to the previously created play list

- 1 Click on the  “make a playlist” button to open the Play List window if it is not already open.
- 2 Click on “Select Playlists From Database” button.
The “Select Playlists From Database” window appears.
- 3 Select the play list to which you want to add the tracks by clicking on the box to the left of the play list, then click on the “Edit” button.
The “Edit Playlist” window appears.
- 4 Click on the “Add Track” button under the “Track List” tab.
The “Select Tracks From Database” window appears.
- 5 Select the tracks that you want to add to the play list by clicking on the box to the left of each track, then click on “OK.”
- 6 Click on “Close” after confirming that the selected tracks are added to the list in the “Edit Playlist” window.

- 7 Click on “Yes” in the dialog box asking you if you really want to save the changes.



- 8 Click on “OK” in the “Select Playlists From Database” window.

Deleting tracks from the previously created play list

- 1 Click on the “ make a playlist” button to open the Play List window if it is not already open.

- 2 Click on “Select Playlists From Database” button.

The “Select Playlists From Database” window appears.

- 3 Select the play list from which you want to delete the tracks by clicking on the box to the left of the play list, then click on the “Edit” button.

The “Edit Playlist” window appears.

- 4 Select the track that you want to delete from the play list, then click on .

You can also use the shortcut menu that appears when you right-click to delete the selected track.

- 5 Repeat step 4, if necessary.

- 6 Click on “Close” when you have finished.

- 7 Click on “Yes” in the dialog box asking you if you really want to save the changes.




- 8 Click on “OK” in the “Select Playlists From Database” window.

Deleting tracks and play lists from your database

Deleting tracks from your database

- 1 Click on the “ make a playlist” button to open the Play List window if it is not already open.
- 2 Click on the “Select Tracks From Database” button to open the “Select Tracks From Database” window.
- 3 Click on the track you want to delete to highlight it, then click on the “Delete” button.

A dialog box appears and asks you if you really want to delete the track.



NEVER check the “Delete the track file from hard disk” option unless you are sure you want to delete the track, or you may lose your music files forever.

- 4 Click on “Yes.”
- 5 Repeat the procedure for the remaining tracks.
- 6 Click on “OK” when you have finished.

Tip

Instead of using the “Delete” button, you can use the shortcut menu that appears when you right-click to delete all the selected tracks at once.

Select the tracks you want to delete by clicking on the box to the left of each track, then right-click on the area within the list and select “Delete Tagged Tracks” from the shortcut menu.

Deleting play lists from your database

- 1 Click on the “ make a playlist” button to open the Play List window if it is not already open.
- 2 Click on the “Select Playlists From Database” button to open the “Select Playlists From Database” window.
- 3 Click on the play list that you want to delete to highlight it, then click on the “Delete” button.
A dialog box appears and asks you if you really want to delete the play list.
- 4 Click on “Yes.”
- 5 Repeat the same procedure for the remaining play list.
- 6 Click on “OK” when you have finished deleting all the play lists.


Tip

Instead of using the “Delete” button, you can use the shortcut menu that appears when you right-click to delete all the selected play lists at once.

Select the play lists you want to delete by clicking on the box to the left of each play list, then right-click on the area within the list and select “Delete Tagged Playlists” from the shortcut menu.

Editing track information

You can edit track information anywhere you can find the “Edit...” button or “Edit track...” drop-down menu command within Audio Manager. Suppose you are in the “Select Tracks From Database” window. You can click on the “Edit” button to open the “Edit Track Info” dialog box, which allows you to enter or select information about the tracks listed in the window, such as the track title, artist name, original album title and genre.



Note

If you edit information about the tracks in MP3 file format within Audio Manager, track information will be saved in ID3v2 tag format.

To learn more about how to work with the “Edit Track Info” and “Edit Play Lists Info” dialog boxes and meaning of the fields contained in the dialog boxes, refer to the “Work with Tracks” book in the Online Help window.

Playing the tracks in the play list

- 1 Click on the “ make a playlist” button to open the Play List window if it is not already open.
- 2 Click on the “Clear List” button to clear the tracks on the Play List.
- 3 Click on the “Select Playlists From Database” button. The “Select Playlists From Database” window appears.
- 4 Select the desired play list by clicking on the box to the left of the play list, then click on “OK.”
- 5 Click on the desired track, then click on .

Playing the tracks on the music CD

- 1 Click on the “ make a playlist” button to open the Play List window if it is not already open.
- 2 Click on the “Clear List” button to clear the Play List.
- 3 Insert the music CD into the CD-ROM drive of your computer, or click on the “Get Tracks From CD” button if the music CD is already in the CD-ROM drive.

If you do not clear the list in step 2, the “New CD Detected” dialog box appears when you insert the CD into the CD-ROM drive and asks you to select “Play this CD,” “Append to Playlist,” or “Cancel.”



- Click on “Play the list” to delete the current entries in the Play List and replace them with the tracks on the CD. The CD will begin playing.
- Click on “Append to Playlist” to add the tracks on the CD to the tracks already in the Play List.

- 4 The tracks contained on the music CD are displayed on the Play List.


If you did not check the “Always get title from CDDb when CD is inserted” option, a dialog box appears and prompts you to obtain information about the inserted music CD automatically. If you want to get information about the music CD, click on “Yes.” Otherwise, click on “No.”

- 5 Click on the desired track, then click on .

Shortcut menus

With most of the windows of Audio Manager, there is a shortcut menu that appears when you right-click. Right-clicking on a track or play list opens a shortcut menu that allows you to easily select a frequently used command.

Below is the shortcut menu opened by right-clicking on the track listed in the Play List window.



Note

Any grayed-out menu command is disabled. So you cannot select it.


Transferring tracks to the MM-RX400 player

To enjoy listening to music on the MM-RX400 player, you must transfer music files stored on your computer to your MM-RX400 player. You can use Audio Manager to transfer MP3 files as well as WMA (Windows Media Audio) files to the MM-RX400 player.

Copy to Devices window

The Copy to Devices window allows you to select tracks or play lists from your database and transfer them to your MM-RX400 player.

This window also provides the facility to manage the portable player connected to your computer such as formatting memory media on the portable player and deleting tracks from the memory media.



1 Devices window button bar

Select Tracks From Database button

Click on this button to select desired tracks from your database and add them to the Transfer List.

Select Playlists From Database button

Click on this button to select desired play lists from your database and add them to the Transfer List.

Copy To Portable button

Click on this button to start transfer.

Save Tracks as Playlist button

This button is disabled when you connect the MM-RX400 player to your computer.

2 Transfer List

Displays the list of the tracks you have selected from your database for transfer to your MM-RX400 player. Each track has information such as the playing time, size, track title and artist name, and also an icon that represents its file type.

 A track in MP3 file format

 A track in WMA file format

An icon preceding the track on the Transfer List indicates the play status of the track (stopped, in play, or play paused). This icon changes among ,  and  depending on the play status of the track.

3 Organize the Transfer List button bar

Clear List

button

Click on this button to clear all the tracks from the Transfer List.

Save Tracks as Playlist

button

Click on this button to save the tracks displayed on the Transfer List as a play list, which gives you an easy way to access these grouped tracks later.



button

Click on the trash can to delete the selected track from the Transfer List.



button

Click on this button to move a selected track up in the Transfer List order.



button

Click on this button to move a selected track down in the Transfer List order.

4 Memory media drop-down list

Displays the currently selected memory media. If your MM-RX400 player has a MultiMediaCard in the slot, select either “Internal Memory (Flash)” or “External Memory (MMC)” to which you wish to transfer tracks by clicking on .

5 Device Usage bar

Gives you a graphic representation of current memory usage status of the memory media selected in the “Media:” field.

6 Portable Track List

Displays the list of the tracks stored on the currently selected memory media including the track title and size for each track.

7 Portable Track List button bar

Refresh

button

Click on this button to redisplay the Portable Track List to match the contents of the selected memory media.

Advanced

button

Click on this button to open the window, which allows you to configure the advanced features of the MM-RX400 player.

button

Click on this button to initialize the memory media (internal and external) on the MM-RX400 player.

You can usefully use this button when you want to delete all the tracks from the memory media.

button

Click on the trash can to delete the selected track from the Portable Track List. Note that this causes the track not only to disappear from the list but also to be deleted from the memory media.

button

Click on this button to move a selected track up in the Portable Track List order.

button

Click on this button to move a selected track down in the Portable Track List order.

Transferring tracks to the MM-RX400 player

Before starting

- Before connecting the MM-RX400 player to your computer, be sure to fully charge the battery.
- Check that the internal Flash Memory or MultiMediaCard has enough available memory to store the transferred tracks. You can find this information in the Device Usage bar.
- Check that files to be transferred are not encoded with a bit rate or sampling frequency outside the range supported by the MM-RX400 player. For more information about the supported bit rates and sampling frequencies, see page 56.
- The following actions are strictly prohibited while transferring music files. Doing so may cause not only the computer to freeze up but also the memory media to be damaged.
 - Disconnecting the USB cable from the MM-RX400 player or the computer
 - Removing the battery from the MM-RX400 player
 - Removing the MultiMediaCard from the MM-RX400 player

- 1 Connect your MM-RX400 player to your computer (page 13).**
- 2 Turn on the player by holding the  **II/■** button pressed until “CONNECT USB” appears on the display of the MM-RX400 player.**

Note

If you connect the USB cable to the MM-RX400 player while it is in FM radio reception mode, the player does not detect that the USB cable has been connected. Switch to the Memory audio player mode by holding the ►||/■ button pressed or turn on the player after turning it off.

- 3 Click on the **“Copy to Devices”** button to open the **Copy to Devices** window if it is not already open.
- 4 Click on ▼ to the right of the **“Media:”** field and select **“Internal Memory (Flash)”** or **“External Memory (MMC)”** from the drop-down list.

Note

If you select the MultiMediaCard as a memory media, it takes more time to finish transferring tracks.

- 5 **Format the selected memory media if necessary (pages 12, 41).**
- 6 Click on the **“Clear List”** button if any tracks are listed on the **Transfer List**.
- 7 Click on the **“Select Tracks From Database”** button.
The **“Select Tracks From Database”** window appears.

Tip

If you have created a play list that contains the tracks selected for transfer, you can select the play list from the **“Select Playlists From Database”** window that can be opened by clicking on the **“Select Playlists From Database”** button.

- 8 **Select the tracks that you want to transfer to the MM-RX400 player by clicking on the box to the left of each track, then click on “OK.”**
You will be notified if you have selected too many tracks for the selected memory media.




If this dialog box appears, you must delete one or more tracks from the **Transfer List** or **Portable Track List** until the total size of the selected tracks falls below the available memory of the memory media.

- 9 Click on **“Close”** to close the dialog box.

10 Delete the tracks one at a time until the red portion of the Device Usage bar disappears (page 40) by clicking on  after selecting the track in the Transfer List or Portable Track List.

11 When you are all right with your selection, click on the “Copy to Portable” button.

Transfer of the selected tracks starts and the “Sending to device” dialog box appears, where you can see the transfer status of each track and the track title currently being transferred. On the MM-RX400 player, “NOW DOWNLOADING PLEASE WAIT” remains displayed while transfer is in progress.



Tracks are transferred to your MM-RX400 player in the order they appear in the Transfer List.

To cancel transfer, click on the “Abort” button of the dialog box.

Note

If you transfer the selected tracks to memory media that contain one or more files, transfer is not performed in the order tracks are listed. The size of each track selected is compared against that of the remaining available memory each time before starting transfer of a track, and the track the size of which best fits the remaining available memory is transferred. Transfer stops when not enough space to store any of the remaining tracks remains on the memory media.

12 Click on “OK” when the message “Finished transferring tracks” is displayed.

Your MM-RX400 player is now ready for playback.

Note

- The track currently being played back cannot be transferred to the MM-RX400 player.
- You are constrained to playing the tracks on the MultiMediaCard on the original MM-RX400 player that was used to transfer music files.
- Music files cannot be restored to your computer after they have been transferred to the MM-RX400 player.

Viewing current memory usage status of the memory media

The Device Usage bar located on the right pane of the Copy to Devices window gives you color-coded representation of current memory usage status of the selected memory media.



- **Green**

The amount of memory currently being used on the memory media

- **Yellow**

The amount of memory necessary for transferring the selected tracks

- **Gray**

The amount of available memory remaining after transferring the selected tracks

- **Red**

The amount of memory shortage when all the selected tracks are transferred

Deleting tracks from the memory media

- 1 **Click on the track that you want to delete on the Portable Track List.**

- 2 **Click on .**

The selected track is deleted from the memory media.

You can also right-click on the track, then select "Remove" from the shortcut menu.

Tip

If you want to delete all the tracks from the memory media, you may use the "Format Media" button.

Increasing the number of files that can be transferred to the MM-RX400 player

You can transfer more files to the MM-RX400 player by selecting a bit rate lower than that of the tracks selected for transfer.

- 1 **Click on "Options" of the "View" menu to open the "Options" dialog box.**

- 2 **Click on  to the right of the "Bit Rate:" field, then select a bit rate lower than that used to encode the selected tracks under the "Read CD" tab.**

This causes the files to be reduced in size, resulting in increasing the number of files to be stored on the memory media.

Formatting the internal Flash Memory and MultiMediaCard

Before starting

- Formatting the memory media erases all contents stored on it.
- The following actions are strictly prohibited while formatting the memory media. Doing so may cause not only the computer to freeze up but also the memory media to be damaged.
 - Disconnecting the USB cable from the MM-RX400 player or the computer
 - Removing the battery from the MM-RX400 player
 - Removing the MultiMediaCard from the MM-RX400 player
- Check that there is sufficient power remaining.

1 Connect the MM-RX400 player to the computer with the supplied USB cable (page 13).

If it is a MultiMediaCard that you want to format, insert it into the MM-RX400 player before connecting the MM-RX400 player to the computer.

- 2 Turn on the player by holding the  button pressed until “CONNECT USB” appears on the display of the MM-RX400 player.
- 3 Double-click on the  (Audio Manager) icon on the desktop.
- 4 Click on the  “copy to devices” button to open the Copy to Devices window if it is not already open.

- 5 Click on  to the right of the “Media:” field and select the desired memory media “Internal Memory (Flash)” or “External Memory (MMC)” from the drop-down list.

6 Click on the “Format Media” button.

The following dialog box appears.




7 Click on “OK” if you are sure you want to format the selected memory media.

When “NOW FORMATTING PLEASE WAIT” changes to “FORMAT COMPLETED!” on the MM-RX400 player, formatting is completed.

USING THE MM-RX400 PLAYER

Player overview

Main unit



1 PRESET -/AREA/PLAY MODE button

- Press during playback to select the desired play mode from among NORMAL, 1 REPEAT, ALL REPEAT, RANDOM, and RANDOM REP.
- Press during Radio Reception or Station Preset mode to select the desired preset station number or a receiving system (US or EU)*.

* A set of a frequency range and a frequency interval

2 ►|| (play/pause)/■ (off) button


- Press to put the player in playback pause, or to start playback during radio reception.
- Press and hold to turn the power on and start playback, or to turn the power off.

3 PRESET +/A-B/MEMORY/SET button

- Press during playback to set A-B repeat playback.
- Press during Radio Reception or Station Preset mode to enter/exit Station Preset mode, or to select the desired preset station number.

4 HOLD switch

When the player is not being used, set it to the HOLD position to prevent unintentional operation.



5 Multi Jog

- Turn up or down during playback to skip to the beginning of the desired track.
- Turn up or down during radio reception to tune in to the desired frequency.
- Press and hold to turn the power on in Radio Reception mode, or to turn the power off.
- Press to start radio reception during playback.

6 VOLUME +/- button

- Press to increase or decrease volume. Each time you press the button, volume increases or decreases by one step.
- Press and hold to continuously increase or decrease volume.
- Volume is adjusted between 0 and 20.

Note

If you adjust the volume between the level of 14 and 20, it is automatically set to 13 when you turn the power on after turning it off.

7 FM MODE/DISPLAY switch

- Slide during playback to select the display mode between TITLE (track title) or TIME (elapsed playing time of the current track).
- Slide during radio reception to select the reception mode between STEREO and MONO (monaural).

8 AUTO PRESET/DTP button

- Press repeatedly during playback to select the desired DTP (Digital Tone Processor) mode.
- Press and hold during radio reception to preset radio stations automatically.

9 Display window (page 45)**10  (Headphones) jack (stereo mini-jack)**


Used to connect the supplied headphones or remote control.

11 USB port connector

Used to connect the series B (smaller) connector of the supplied USB cable to the player and the series A (larger) connector to the USB port of your computer.

12 Battery compartment cover**13 MultiMediaCard slot****14 Cord clip**

Remote control



1 VOL (Volume) control

Turn to adjust the volume. Make sure that you cannot turn up the volume with the VOL control higher than the volume set with the player's VOLUME +/- buttons.

2 jack (stereo mini-jack)

Used to connect the supplied headphones.

3 (play/pause) button

- Press and hold to turn the power on and start playback.
- Press to put the player in playback pause, to start playback again, or to start playback during radio reception.

4 (off)/RADIO OFF button

- Press to turn the power off.

5 HOLD switch

6 RADIO ON/DTP button

- Press and hold to turn the power on in Radio Reception mode or start radio reception during playback.
- Press repeatedly during playback to select the desired DTP (Digital Tone Processor) mode.

7 buttons, PRESET +/- buttons

- Press repeatedly during playback to skip to the beginning of the desired track.
- Press repeatedly during radio reception to select the desired preset station.

Display window

During playback



- 1 **Play mode indicator**
- 2 **DTP (Digital Tone Processor) indication**
- 3 **Battery indicator**
Displays the remaining battery power.
- 4 **Main indication**

Displays the track number and elapsed playing time of the current track when the DISPLAY switch is set to the TIME position.

Displays the track title of the current track when the DISPLAY switch is set to the TITLE position.


During radio reception



- 5 **Preset station number indication**
- 6 **FM MONO (monaural) indicator**
Shows the FM MODE switch is set to the MONO position.
- 7 **Frequency indication**

Using the player

Playing back tracks



Before starting

Release the HOLD switch to activate the player buttons.


- 1 Connect the supplied remote control with headphones to the Ω jack on the player.**

You can connect the headphones directly to the Ω jack as well.

- 2 Press and hold the $\blacktriangleright \parallel \blacksquare$ button until "Hello!" appears on the display.**

Playback starts automatically from the beginning of the track that was played back last time.

Current track No.



Elapsed playing time of the current track

- 3 Adjust the volume with the VOLUME + or - button.**

Note

The MM-RX400 player allows you to play back up to 99 music files that have been stored on it.

To turn the power off

Press and hold the $\blacktriangleright \parallel \blacksquare$ button until "GOOD-BY!!" appears on the display.

To put the player in playback pause

Press the $\blacktriangleright \parallel \blacksquare$ button during playback. To resume playback, press the $\blacktriangleright \parallel \blacksquare$ button again.

To search for a track

Turn the Multi Jog up or down repeatedly during playback or playback pause until a desired track is located.

To search for a point of a track

During playback, hold turning up or down the Multi Jog until the desired point of the track is located.

Selecting a play mode



Press the PLAY MODE button repeatedly during playback to select the desired play mode.

Select	To play
NORMAL	All the recorded tracks in order. When you are using the player with a MultiMediaCard loaded, playback starts from the Flash Memory, and then proceeds to the MultiMediaCard after the last track in the Flash Memory ends.
1 REPEAT	The current track repeatedly
ALL REPEAT	All recorded tracks repeatedly
RANDOM	All recorded tracks in random order
RANDOM REP	All recorded tracks in random order repeatedly

Note

If you do not press the PLAY MODE button within about 10 seconds after selecting your desired play mode, the normal display is restored, and your selection is not registered.

Playing a desired portion of a track repeatedly (A-B Repeat Playback)



1 Press the A-B button at the beginning of your desired portion during playback.

"A-" appears on the display.



2 Press the A-B button at the end of your desired portion during playback.

The player starts to play the portion between point A and B repeatedly.

To cancel A-B Repeat Playback


Press the A-B button during A-B playback.

Selecting equalizer settings to suit tracks



Press the DTP button repeatedly during playback to select your desired DTP (Digital Tone Processor) mode from among ROCK, POP, JAZZ, and CLASSIC.

Changing the track information



Set the DISPLAY switch to TITLE or TIME during playback.

Set the switch to	To show
TITLE	The track title*
TIME	The elapsed playing time of the current track

* Text too long to display scrolls so that you can read all of it. The scrolling repeats as long as the track plays.


Note

If the track being played back has no information about the track title, "AudioTrack," "no artist," and "no title" scroll across the display.

Note on the auto power off function

If you do not operate the player for about 90 minutes during playback, the power will be automatically turned off.

Selecting the AREA setting before you use the player



Radio broadcasts have different frequency ranges and change in different steps in different countries.

The player has two world reception areas: US (North and South America) and EU (Europe).


The player is set to US at the factory.

- 1 Press and hold the Multi Jog until radio reception display appears on the display.**
- 2 Press and hold the AREA button until "US" or "EU" flashes on the display.**
- 3 Press the AREA button repeatedly to select the desired setting.**
- 4 Press and hold the AREA button until the radio reception display appears again on the display.**

Note

If you do not press the AREA button within about 10 seconds after selecting your desired setting, the former setting is restored, and your selection is not registered.

Listening to a radio program (Manual Tuning)



- 1 Press and hold the Multi Jog until radio reception display appears on the display.**
- 2 Turn up or down the Multi Jog repeatedly to tune in to your desired station.**
- 3 Adjust the volume with the VOLUME + or - button.**

To turn the power off

Press and hold the Multi Jog until "GOOD-BY!!" appears on the display.

To tune in to a station quickly (Auto Tuning)

Hold the Multi Jog to turn up or down until the frequency starts and continues to increase or decrease. The player tunes in to the next receivable station to the frequency from which you started Auto Tuning.

However, the Auto Tuning may not stop and will instead continue to search for a strong station if the broadcast signals are weak. If you want to try tuning in a weak station, turn up or down the Multi Jog repeatedly to cancel Auto Tuning, then tune in to the station manually.

To obtain a better reception


Set the FM MODE switch to the MONO position.

The reception may improve, but sound will not be in stereo.

Note on the auto power off function

If you do not operate the player for about 90 minutes during radio reception, the power will be automatically turned off.

Presetting stations automatically (Auto Preset)




Press and hold the AUTO PRESET button during radio reception until "AUTO PRESET" appears on the display.

The player presets up to 20 receivable stations automatically. After Auto Preset is complete, the player tunes in to the station stored on the preset number "01."

Note

When broadcast signals are very weak, stations cannot be preset automatically. In such a case, preset the desired stations manually.

Presetting stations manually (Manual Preset)



- 1 Tune in to a desired station.
- 2 Press and hold the MEMORY button until the preset number flashes on the display.
- 3 Press the PRESET + or – button repeatedly to select the desired preset number.
- 4 Press and hold the MEMORY button until the preset number stops flashing on the display.


To preset two or more stations

Repeat the procedure from the beginning.

To erase all preset stations

Press and hold the PRESET – button and Multi Jog simultaneously until “PRESET MEMORY INITIALIZED” appears on the display.

Listening to a preset station



- 1 Press and hold the Multi Jog until radio reception display appears on the display.
- 2 Press the PRESET + or – button repeatedly to select the desired preset station.
- 3 Adjust the volume with the VOLUME + or – button.

To turn the power off

Press and hold the Multi Jog until “GOOD-BY!!” appears on the display.

Specifications

Storage media Built-in 32MB Flash Memory
MultiMediaCard slot for a
removable 16MB, 32MB or
64MB MultiMediaCard

Maximum output level
5 mW + 5 mW (16 ohms)

Frequency range
20 Hz – 20 kHz

Load impedance
16 – 32 ohms

S/N ratio
85 dB

Distortion rate
0.35 or less

FM tuner
87.5 MHz – 108.0 MHz
(50 kHz steps)

Tuner preset
20 stations

Power supply 1.2 V DC using the supplied
MHB-901 Ni-MH
rechargeable battery

**Continuous playing time with a fully
charged battery**

Approx. 5 hours

Display Graphic LCD (69 × 32 dots)

PC interface USB cable

Maximum outside dimensions

41.6 mm (W) × 90.5 mm (H)
× 22.8 mm (D) (not including
projecting parts and controls)

Weight Approx. 72 g without battery

Accessories USB cable (1)

Battery charger (1)

Rechargeable battery (1)

Installation CD-ROM (1)

Remote control (1)

Stereo headphones (1 set)

Carrying case (1)

Cord clip (1)

* Player specifications and external appearance
are subject to change without notice.

Frequently asked questions

General questions

What is MP3?

MPEG-1 Audio Layer 3, one of most popular audio formats. It compresses standard audio tracks into much smaller sizes without significantly compromising sound quality. Since the MP3 file format has no mechanism for copyright protection, it is not widely used by commercial music data distribution sites.

What is WMA?

Windows Media Audio is an audio format developed by Microsoft Corporation in order to distribute CD-quality music even via low-speed communication lines such as ISDN. WMA employs a more efficient compression method than MP3, and has the advantage of reducing the bit rate with the least loss of sound quality (80 kbps encoding results in almost the same sound quality as MP3 encoded at 128 kbps). WMA is a format suitable for portable players with limited memory. WMA also provides the mechanism that allows music files to contain encrypted data such as copyright-protection information in them in combination with Windows Media Rights Manager.

What is the bit rate?

Data flow per second denoted by “kbps.” Audio Manager allows you to select a bit rate of 160, 128, 96, 80, or 64 kbps for WMA format encoding and 320, 256, 192, 128, 96, 80, or 64 kbps for MP3 format encoding.

What is a variable bit rate (VBR)?

The variable bit rate (VBR) encoding method allocates fewer bits to silent sections or those with relatively narrow stereo separation, and allocates additional bits to sections that have relatively wide stereo separation. The constant bit rate encoding method uses a consistent bit rate throughout an encoded file. VBR allows smaller encoded file sizes without compromising sound quality. However, VBR is not recommended if you want the MP3 player to report accurate information about the duration of MP3 files, since it is difficult to predict MP3 file size.

What is the CDDB?

A database server that provides information about a music CD in your computer's CD-ROM drive. CDDB-enabled encoding software will search the CDDB database on the Internet for information about your music CD, such as the album title, artist names, and track titles, and automatically enter the information to its track list. You do not have to manually enter information about your music CD.

What is SDMI?

The Secure Digital Music Initiative, a forum founded to develop technological specifications for enabling the secure distribution and use of music in digital form, as well as providing copyright protection for artists' work.

SDMI-compliant music files have the following transfer restrictions:

- You can copy a music file as many times as the information encrypted in the file allows.
- You can transfer a music file to up to 3 SDMI-compliant portable players only from the computer that was used to download or record the file.
When a music file is downloaded from an SDMI-compliant music data distribution site, the number of players to which you can transfer the music file is governed by the information contained in the file.
- You can play a music file stored on a MultiMediaCard if the player unit is the same one that was used to transfer the music file.

Questions about the MM-RX400 player

How do I expand the memory?

The MM-RX400 player incorporates 32MB of Flash Memory. You can add memory by installing a MultiMediaCard (64MB, 32MB or 16MB).

Can files on a MultiMediaCard that have been written to by an MM-RX400 player be played back on another portable player?

No, they can not be played back on another portable player.

How many minutes of music files can an MM-RX400 player hold?

It depends on the amount of installed memory and the bit rate used for encoding. If you select "96 kBit/s, Near CD, 15:1 reduction" in the "Options" dialog box for encoding WMA (page 18), an optional 32MB MultiMediaCard in combination with the internal Flash Memory allows you to store about 80 minutes of music files. The time is reduced to about 60 minutes with the "128 kBit/s, CD Quality, 11.25:1 reduction."

How long does the battery last?

A fully charged battery gives you about 5 hours of playback time.

The volume level differs among tracks.

The volume level of the encoded music files depends on the music source and the software used for encoding.

You need to adjust the volume level manually on the player, because the encoding software usually does not support a function to adjust volume level.

Can I use the MM-RX400 player with a Macintosh computer?

No, you cannot. The MM-RX400 player does not support Macintosh computers.

Troubleshooting

If you encounter a problem while using the MM-RX400 player, try the remedial actions listed below. Should the problem persist, consult the store where you purchased the MM-RX400 player or your nearest AIWA dealer.

The buttons are not functional.

→ Check to see if the HOLD switch is set to the HOLD position (page 42).

→ Check to see if the rechargeable battery is installed properly (page 11).

Check if the ⊕ and ⊖ poles of the rechargeable battery are properly aligned.

→ Check to see if the rechargeable battery needs recharging (page 11).

→ Check to see if memory status is all right.

Format the memory media using the format function of the supplied Audio Manager software (pages 12, 41).

→ If the problem persists, remove the battery, then reinstall it to reset the player (page 11).

This often helps solve a problem.

Nothing or unusual action on the display

→ Check to see if the rechargeable battery needs recharging (page 11).

→ Remove the battery, then reinstall it to reset the player (page 11).

This often helps solve a problem.

Various troubles with playback

- "NO FILE" is displayed on the MM-RX400 player. You may have failed to transfer music files to the MM-RX400 player.

→ Check the USB cable connection and remaining battery power, and try to transfer music files to the MM-RX400 player again (page 35).

- Some parts of a data stream may be damaged because of power fluctuations while transferring music files.

→ Format the memory media using the format function of the supplied Audio Manager software (pages 12, 41).

- The player cannot play tracks that are stored on the MultiMediaCard.

→ Check that the MultiMediaCard has been inserted into the card slot properly (page 12).

Push the MultiMediaCard into the card slot until it is locked, holding it with the beveled corner to the right.

→ Check that you are not using a MultiMediaCard written to by another player.

You can only play a MultiMediaCard on the MM-RX400 player that was used to transfer the music files.

The MM-RX400 player does not play tracks.

- The MM-RX400 player supports WMA and MP3 files encoded with one of the following bit rates and sampling frequency.

- WMA files encoded with a bit rate of 64, 80, 96, 128, or 160 kbps and a sampling frequency of 44.1 kHz

- MP3 files encoded with a bit rate of 64, 80, 96, 128, 160, 192, 256, or 320 kbps and a sampling frequency of 22 kHz to 48 kHz

Files other than WMA- or MP3-format files may not be played back on the MM-RX400 player even if they are transferred to the player. Even files in WMA or MP3 file format may not be played back, if they are encoded with a bit rate or sampling frequency outside the range supported by the MM-RX400 player.

→ Retransfer the files after encoding them using WMA or MP3 file format with an appropriate bit rate and sampling frequency, if possible.

- Some MP3 files that are encoded with VBR (variable bit rate) may not be played back on the MM-RX400 player.

→ Retransfer the files after encoding them with a constant bit rate.

With some files, the elapsed playing time indicated on the display is not accurate, and sound skip occurs.

- Files encoded with a bit rate or sampling frequency outside the range supported by the MM-RX400 player may cause inaccuracy of elapsed playing time indicated on the display and sound skip.

→ Retransfer the files after encoding them with an appropriate bit rate and sampling frequency.

* This problem may still remain with some files even if they are encoded with an appropriate bit rate and sampling frequency.

- MP3 files that are encoded with VBR (variable bit rate) also may cause inaccuracy of elapsed playing time indicated on the display and sound skip.

→ Retransfer the files after encoding them with a constant bit rate.

* This problem may still remain with some files even if they are encoded with a constant bit rate.

Your computer does not recognize the MM-RX400 player.

- “CONNECT USB” does not appear on the MM-RX400 player display.
 - Check that the USB cable is connected properly to the player and computer ports (page 13).
 - Check that the player is not connected to a port on a cascaded USB hub.
- The MM-RX400 player display shows “LOW BATT” or “NO BATT.”
 - Charge the battery or replace the battery with a fully charged one.
- Audio Manager does not detect the MM-RX400 player. Either the internal Flash Memory or the MultiMediaCard on the MM-RX400 player does not appear on the Memory Media drop-down list of the Copy to Devices window.
 - Try restarting Audio Manager.

Cannot transfer music files.

- Check that the USB cable is connected properly to the player and computer ports (page 13).
- Check that there is sufficient available memory in the internal Flash Memory or MultiMediaCard.
 - You can view available memory on the Device Usage bar located in the right pane of the Copy to Devices window (page 40).
- Check that the rechargeable battery still has power (page 11).
 - If the remaining power is insufficient, “LOW BATT” appears on the display.
 - If the battery is completely discharged, “NO BATT” appears on the display.
- Check the file format of the music files to be transferred. Audio Manager supports WMA and MP3 file formats for transfer.

Some music files that have been downloaded for free via the Internet cannot be transferred to the MM-RX400 player.

- Some free downloadable music files may not be transferred to the MM-RX400 player, because of restrictions written in the files.

You cannot tune in to any station.

- The AREA setting is not the right one for your receiving area.
→ Select the right setting.

The reception is distorted or has a hum.

- Set the FM MODE switch to the MONO position.
You may hear the sound more clearly, but it will not be in stereo.

AIWA Co., Ltd. will not be responsible for any loss or damage of music files due to their transfer to the MM-RX400 player.

Messages

The table shows the messages displayed on the MM-RX400 player.

Display	Description
HOLD	Displayed when any operation button other than the FM MODE/DISPLAY switch is pressed while the HOLD switch is in the "HOLD" position.
CONNECT USB	Displayed when the MM-RX400 player is connected to a computer with the supplied USB cable.
LOW BATT	Displayed if the remaining power of the battery is insufficient.
NO BATT	Displayed if the battery is completely discharged when the USB connector is connected to the MM-RX400 player.
NOW DOWNLOADING PLEASE WAIT	Displayed while transfer of music files is in progress.
DOWNLOADING COMPLETED!	Displayed when transfer of music files is finished.
NOW FORMATTING PLEASE WAIT	Displayed while formatting of the internal Flash Memory or MultiMediaCard is in progress.
FORMAT COMPLETED!	Displayed when formatting of the internal Flash Memory or MultiMediaCard is finished.
INTERNAL MEMORY ERROR	Displayed when an error has occurred with the internal Flash Memory.
EXTERNAL MEMORY ERROR	Displayed when an error has occurred with the MultiMediaCard in the card slot.
CAN'T PLAY	Displayed when access to a music file is rejected.
NO FILE	Displayed if no file is found in memory media when the power is turned on.

AIWA CO.,LTD.



<http://www.aiwa.co.jp>

8A-HZ5-905-01
010323AYO-OX