

ID RW02.ABC-A (RS232 Interface)

ID RW02.ABC-B (RS485 Interface)

(english)



ENGLISH

Note

© Copyright 1999 - 2002 by
FEIG ELECTRONIC GmbH
Lange Strasse 4
D-35781 Weilburg-Waldhausen
Tel.: +49 6471 3109-0
<http://www.feig.de>

ENGLISH

With the edition of this document, all previous editions become void. Indications made in this manual may be changed without previous notice.

Copying of this document, and giving it to others and the use or communication of the contents thereof are forbidden without express authority. Offenders are liable to the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design.

Composition of the information in this document has been done to the best of our knowledge. FEIG ELECTRONIC GmbH does not guarantee the correctness and completeness of the details given in this manual and may not be held liable for damages ensuing from incorrect or incomplete information. Since, despite all our efforts, errors may not be completely avoided, we are always grateful for your useful advises.

The instructions given in this manual are based on advantageous boundary conditions. FEIG ELECTRONIC GmbH does not give any guarantee promise for perfect function in cross environments.

FEIG ELECTRONIC GmbH assumes no responsibility for the use of any information contained in this document and makes no representation that they free of patent infringement. FEIG ELECTRONIC GmbH does not convey any license under its patent rights nor the rights of others.

OBID® is registered trademark of FEIG ELECTRONIC GmbH.

General information's regarding this document

The sign "👉" indicates extensions or changes of this manual compared with the former issue.

Content

1.	Safety instructions	4
2.	Installation	5
2.1	Installation on flush-mounting box	6
2.2	Installation with surface frame ID APR-A	7
3.	Reader-connection	8
3.1	(☞) Jumper and Switches	9
3.2	Power supply.....	10
3.3	Relay	10
3.4	Digital inputs (IN1 / IN2).....	10
3.5	RS232 Interface (ID RW02.ABC-A)	10
3.6	(☞) RS485 Interface (ID RW02.ABC-B)	11
3.7	(☞) Data-/Clock interface.....	12
4.	Operation	13
4.1	Address setting (Bus mode with RS485 interface).....	13
5.	(☞) Technical data	14
5.1	Approval	15
5.2	USA (FCC).....	15
5.3	Dimensions for concealed installation	16
5.4	Dimensions for surface installation with ID APR-A.....	17
6.	System delivery contents:	18
6.1	Optional Accessories	18

1. Safety instructions

- The device has to be used only for the purpose designed by the manufacturer.
- The operation manual has to be stored available at any time and has to be handed over to each user.
- Unauthorized changes and the use of spare parts and additional devices which have not been sold or recommended by the manufacturer may cause fire, electric shocks or injuries. Such measures will lead to exclusion of any liability by the manufacturer.
- The liability-prescriptions of the manufacturer in the issue valid at the time of purchase are valid for the device. The manufacturer is not legally responsible for incorrect, unsuitable manual or automatical setting of parameters for a device or the incorrect application of a device.
- Repairs can only be executed by the manufacturer.
- Installation-, operation- and maintenance procedures should only be carried out by qualified personnel.
- Before opening the device, the power supply must always be interrupted. Make sure that the device is without voltage by measuring. **CAUTION!** The fading of an operation control (LED) is no indicator for an interrupted power supply or the device being without voltage!
- Works at the device and its installation have to be executed according to the national legal requirements and local prescriptions.
- When working on devices the valid safety regulations must be observed.

2. Installation

The Reader has been designed for wall installation on 60 mm flush-mounting box. For surface installation, the bottom part of the casing can be substituted by the surface frame ID APR-A, which is available as an attachment.

NOTES:

- *The Reader must not be installed directly upon conductive materials as e.g. metal surfaces, metal grids (reinforcements) or metallized surfaces, as these surfaces reduce the detection range of the Reader. The distance between the Reader and such surfaces should be min. 3 cm.*

If an installation to a metal surface becomes necessary, the surface frame ID APR-A can be employed in order to keep the minimal distance.

- *The distance between two Readers of the same type should not fall below 30 cm.*
- *Before any installation the intended position of the Reader should be tested for its suitability.*
- *The opening (A) in the casing (see Fig 1) has to be installed downwards!*




Fig 1: mounting direction (A) downwards

2.1 Installation on flush-mounting box

1. Select installation place:

The installation should be executed always on a surface as even as possible.

2. Connection:

see chapter Reader-connection

3. Operation:

- snap connection board into bottom part of casing (see Fig 2).
- Put the top of the casing onto its bottom part. The pin board of the Reader electronic has to be inserted carefully into the socket board X3!
- see chapter Installation

4. Wall installation:

The wall installation should be executed only after a control of all functions.

- Remove top of the casing from its bottom part again.
- Screw bottom part of casing with snapped-in connection board to selected surface.
- Put top of the casing again onto its bottom part. Insert the pin board of the Reader electronic carefully in the socket board X3!
- Screw top of casing to bottom part by using thread cutting screw 3,2 x 25 mm.
- Attach adhesive label to clean and non-greasy casing.




Fig 2: Rear view with snapped-in connection board (1)

2.2 Installation with surface frame ID APR-A

1. Wall installation:

- The installation should be executed always on a surface as even as possible.
- Make openings into the bottom part of the casing for lead-in wire, eventually attach twisting sleeve and pull wire into the casing.
- Screw bottom part of casing to surface.

2. Connection:

see chapter Reader-connection

3. Close casing:

- Put the connection board (1) out of the bottom part of the concealed casing and snap it into the bottom part of casing according to Fig 3 with the connectors in downward direction. In order to do this, press the notches slightly apart with your fingers.
- Put top of the casing onto its bottom part. Insert the pin board of the Reader electronic carefully into the socket board X3!!
- Screw top of casing to bottom part by using thread cutting screw 3,2 x 25 mm.

4. Operation:

see chapter Reader-connection

5. Adhesive label:

Attach label to clean and non-greasy casing




Fig 3: Surface installation (LED top left)
Open surface casing with snapped-in connection board (1)

3. Reader-connection

The connection of the Reader is executed via the connection board. (see: Fig 4) which is snapped into the bottom part of the casing.

ENGLISH




Fig 4: Connection board


connector		function	
board	name	ID RW02.ABC-A	ID RW02.ABC-B
X2	+ / ~	power supply 12 - 24 AC / DC	
	- / ~		
	CLS	data-/clock interface – cls	
	COM	 relay	
	NO		
	GND	internal GND	
	R/A	RS232 - RxD	RS485 - A
	T/B	RS232 - TxD	RS485 - B
X1	CLK	data-/clock interface – clock	
	DAT	data-/clock interface – data	
	IN1	digital input 1 (IN1)	
	IN2	digital input 2 (IN1)	

Table 1: connection plan

3.1 (🔧) Jumper and Switches

Fig 5 shows the position of the jumpers and switches on the printed circuit board of the ID RW02.ABC. The jumpers and switches are only accessible at opened device.




Fig 5: Jumper and switches

S1:

DIP-switch to configure the Reader address.

X1:

Terminal for sticking up the connection board.

X2 / X3 / X4:

Jumper for termination resistors of the RS485 interface (only ID RW02.ABC-B).

X7:

Interface for firmware update.

J1 / J2:

Jumper for firmware update.

3.2 Power supply

The power supply is effected via the connectors [+ / ~] and [- / ~]. The device may be supplied either with 12 - 24 V AC or DC. In case of DC supply, the polarity may be chosen freely.

NOTE:

The lead-in wire should not be laid directly parallel to other power supply- and low voltage wires.

ENGLISH

3.3 Relay

The device is equipped with an relay (normally open contact). The connection is executed via the connectors [NO] and [COM].

3.4 Digital inputs (IN1 / IN2)

The digital inputs [IN1] and [IN2] can only be connected to internal GND (terminal [GND]) according to Fig 6.

Any connection to external voltage might damage the unit!




Fig 6: connection of the digital inputs

3.5 RS232 Interface (ID RW02.ABC-A)

Readers with RS232 interface have to be connected to the host according to Fig 7.




Fig 7: connection of the RS232-interface

3.6 (🔌) RS485 Interface (ID RW02.ABC-B)

With RS485 data buses, it can be necessary to use terminating resistors. For each installation, checks should be made as to whether it is necessary to use terminating resistors, because this e.g. is dependent on line lengths, bus structure, powering of the Readers and the employed host computer. Generally, a terminating resistor is only required at the end of the bus, i.e. on the last unit. In order to do this, the Jumper needs to be put on X2 terminals 1 and 2 (see Fig 8 and Fig 5).

To operate the bus, you need a host computer with a terminating resistor and active termination. A twisted paired or stranded wire is recommended.

ENGLISH




Fig 8: data bus with RS485 interface

If no host computer with active termination is available, a active termination can be implemented as an alternative at maximum one Reader. The Jumpers X3 and X4 are available to this.




Fig 9: Jumper positions of the RS485 interface




Fig 10: intern construction of the RS485 interface

3.7 (🔗) Data-/Clock interface

The connection of the data-/clock interface is executed according to Fig 11. If no CLS signal is required on host, this connection can be abandon.




Fig 11: connection of the data-/clock interface

4. Operation

4.1 Address setting (Bus mode with RS485 interface)

For Readers with RS232 interfaces usually no address setting is necessary. In case of units with RS485 interface, the unit address can be set either via the DIP-switch on the opened unit (see Fig 5), or via the host.

Bus mode with up to 16 Readers:

The setting of the individual addresses is executed via the DIP-switches S1, DIP1 - DIP 4 according to the table seen below (DIP5 - DIP8 are unused). Thus, each Reader is being provided with an individual address.

Address	DIP 1	DIP 2	DIP 3	DIP 4
0	OFF	OFF	OFF	OFF
1	ON	OFF	OFF	OFF
2	OFF	ON	OFF	OFF
3	ON	ON	OFF	OFF
4	OFF	OFF	ON	OFF
5	ON	OFF	ON	OFF
6	OFF	ON	ON	OFF
7	ON	ON	ON	OFF
8	OFF	OFF	OFF	ON
9	ON	OFF	OFF	ON
10	OFF	ON	OFF	ON
11	ON	ON	OFF	ON
12	OFF	OFF	ON	ON
13	ON	OFF	ON	ON
14	OFF	ON	ON	ON
15	ON	ON	ON	ON

Bus mode with 16 - 32 Readers:

The setting of addresses is executed by the host-PC (host).

NOTE:

Due to the default value 0 of each Reader, they have to be connected and configured one after another.

5. (🔧) Technical data

ENGLISH

casing	Plastic material ASA
colour	bottom part of casing: similar to RAL 9002 (greyish white) top of casing: similar to RAL 7043 (traffic grey)
weight	approx. 120 g
protective system	IP 54
power supply	12 - 24 V AC/DC
power consumption	max. 2,5 W
temperature range	-25°C to 70°C
relative air humidity	95 % (non-condensing)
antenna	integrated
data transmission with transponder	125 kHz
for transponder	<ul style="list-style-type: none"> • ID CTx.A • ID DTx.B • ID DTx.C
signal transmitter	1 x bicolor-LED (red, green, orange) 1 x buzzer
relay	1 x normally open capacity of contacts: 24 V AC/DC 1,5 A
digital inputs	2 x configurable length of lead-in wire max. 3 m
interfaces	<p>asynchrony (bi-directional) 2400 to 38400 Baud</p> <ul style="list-style-type: none"> • RS232 (ID RW02.ABC-A) length of lead-in wire max. 10 m • RS485 (ID RW02.ABC-B) max. 32 units on each data bus <p>data / clock (unidirectional) TTL</p> <p>length of lead-in wire max. 3 m</p> <ul style="list-style-type: none"> • Magnetic Stripe Emulation, track 1 (7 Bit), track 2+3 (5 Bit) • Wiegand Emulation
DIP-switch	8-channel
EEPROM	10.000 writing cycles

Default values (factory aligned):

asynchronous interface:	9600 Baud, 8 data- 1 stopbit, even parity
IN1	activates LED red and relay
IN2	aktivates LED green and buzzer
LED-operation control	orange

5.1 Approval

When properly used this radio equipment conforms to the basic requirements of Article 3 and the other relevant provisions of the R&TTE Directive 1999/5/E6 of March 99.



5.2 USA (FCC)

FCC ID: PJMRW02

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device is labeled with an FCC ID number.

If this label is not visible when installed in an end device, the outside of the device **MUST** also display a label referring to the enclosed module.

Wording on the label similar to the following shall be used:

This device contains transmitter module FCC ID PJMRW02

5.3 Dimensions for concealed installation

ENGLISH





Fig 12: Dimensions of concealed casing
(A) = below

5.4 Dimensions for surface installation with ID APR-A



ENGLISH

Fig 13: Dimensions for installation with surface frame ID APR-A
(A) = below

6. System delivery contents:

- 1 x bottom part of casing (concealed casing)
- 1 x top of casing with Reader electronic
- 1 x connection board
- 1 x adhesive label
- 1 x thread cutting screw 3,2 x 25 mm (for connecting parts of casing)
- 2 x thread cutting screws 3,2 x 15 mm (for wall installation)
- 1 x Installation instructions

6.1 Optional Accessories

bottom part of casing for surface installation

ID APR-A

Order-No.: 1144.001.00

adhesive front label

ID AKL.02

Order-No.: 1424.000.00