

User Guide

WP8990 Zephyr

CHAPTER 1. BEFORE USING

BEFORE USING	6
INSIDE THE PACKAGE.....	6
HANDSET DESCRIPTIONS	7
DISPLAY INDICATORS.....	9
INSTALLING THE BATTERY	12
REMOVING THE BATTERY	12
CHARGING YOUR BATTERY	13
BATTERY HANDLING INFORMATION.....	13
INSTALLING A SIM CARD	14

CHAPTER 2. BASIC OPERATION

BASIC OPERATION	16
TURNING THE PHONE ON/OFF	16
ACCESSING THE MENU	16
MENU SUMMARY	17
MAKING A CALL	19
ANSWERING CALLS	20
ENDING A CALL	20
MISSED CALL NOTIFICATION.....	20
WAIT/PAUSE	20

MAKING AN INTERNATIONAL CALL	21
3 WAY CALLING.....	22
CALL WAITING	22
CALLING A NUMBER FROM CONTACTS.....	22
ADJUSTING THE VOLUME	22
CALLER ID.....	23
TURNING VIBRATE MODE ON OR OFF	23
SPEAKERPHONE.....	23
AVAILABLE OPTIONS DURING A CALL	23
MAKING AN EMERGENCY CALL	23

CHAPTER 3. MEMORY FUNCTION

MEMORY FUNCTION	26
STORING A PHONE NUMBER	26
ENTERING LETTERS, NUMBERS & SYMBOLS	30
ONE, TWO, THREE TOUCH DIALING.....	32

CHAPTER 4. MENU FUNCTION

CONTACTS	34
NEW CONTACT	34
CONTACT LIST	34

BACKUP ASSISTANT.....	34
GROUPS	34
SPEED DIALS.....	36
IN CASE OF EMERGENCY	37
MY NAME CARD	39
RECENT CALLS	40
RECENT CALLS.....	40
MISSED	40
RECEIVED	41
DIALED.....	41
BLOCKED	42
ALL	42
VIEW TIMERS.....	42
SETTINGS	43
BLUETOOTH MENU	43
SOUNDS SETTINGS	46
DISPLAY SETTINGS	49
PHONE SETTINGS	54
CALL SETTINGS	63
MEMORY	65
PHONE INFO	66
SET UP WIZARD.....	67

VOICE TOOLS	68
VOICE COMMANDS	68
TOOLS	72
CALCULATOR.....	72
TIP CALCULATOR	73
CALENDAR.....	73
ALARM CLOCK.....	75
STOP WATCH	76
WORLD CLOCK	77
UNIT CONVERTER	78
NOTEPAD.....	78
MY VERIZON	79
MY VERIZON	79

CHAPTER 5. MEDIA CENTER

MEDIA CENTER	82
TUNES & TONES	82
PICTURES	84
GAMES	86
MOBILE WEB	86
BROWSER & DOWNLOAD	88
EXTRAS	88

MEDIA CENTER INFO.....	89
VZ NAVIGATOR	89

CHAPTER 6. MESSAGING MENU

MESSAGING	92
WHEN A NEW MESSAGE ARRIVES	92
NEW MESSAGE.....	92
INBOX	94
SENT	95
DRAFTS	95
VOICEMAIL	96
MOBILE IM	96
EMAIL	96
CHAT	97
ERASE MESSAGES.....	97
SETTINGS	97

CHAPTER 7. SAFETY AND WARRANTY

SAFETY	102
SAFETY INFORMATION FOR WIRELESS HANDHELD PHONES.....	102
SAFETY INFORMATION FOR FCC RF EXPOSURE	105

SAR INFORMATION	105
HEARING AID COMPATIBILITY (HAC) FOR WIRELESS TELECOMMUNICATIONS DEVICES.....	106
FDA CONSUMER UPDATE.....	107
AVOID POTENTIAL HEARING LOSS.....	112
FCC COMPLIANCE INFORMATION	113
CTIA BATTERY CERTIFICATION REQUIREMENTS.....	114
WARRANTY.....	115
12 MONTH LIMITED WARRANTY	115


CHAPTER 1 BEFORE USING

This chapter provides important information about using your handset.

- Inside the package
- Handset descriptions
- Display indicators
- Installing the battery
- Removing the battery
- Charging your battery
- Battery handling information
- Installing a SIM card

INSIDE THE PACKAGE

This package should include all items pictured below. If any are missing or different, immediately contact the retailer where you purchased the phone.



Handset




Standard Battery




User Guide



Battery Cover




QRG (Quick Reference Guide)




Wall Charger

HANDSET DESCRIPTIONS



- Earpiece:** Allows you to hear the other caller.
- Main Display Screen:** Displays all the information needed to operate your phone.
- [] Directional Key:** Allows you to scroll through phone menu options and provides a shortcut to phone functions from idle mode.
- [] Left Soft Key:** Press to access the **Message** menu or access the function listed above the key.
- [] Speakerphone Key:** With the flip open, press to turn speakerphone on or off.
- [] SEND Key:** Press to make or receive a call. In idle mode, press to access the **All Calls** list.
- [] Voicemail Key:** In idle mode, press and hold to automatically connect to your voicemail server.
- [] Shift Key:** Press to enter an asterisk (*) character for calling features. In text entry mode, press to change the character input type. Press and hold to display the plus sign (+) for international dialing.
- Microphone:** Allows the other caller to hear you.
- [] Vibrate Mode Key:** Press and hold to activate/deactivate vibrate mode in idle mode. Press to enter the (#) character for calling features. In text entry mode, press to accept the word and add a space.
- [] CLR Key:** Press to clear a digit from the display. Press and hold to clear all digits. Within a menu, press to return to the previous menu.
- [] END/PWR Key:** Press and hold to turn the phone on/off or press to end a call or browser session. Within a menu, press to return to idle mode.
- [] Mobile Email Key:** Press to access **Mobile Email** in idle mode.
- [] Right Soft Key:** Press to access **Contacts** in idle mode or access the function listed above the key.
- [] OK Key:** Press to access the **MENU** in idle mode. It also allows you to accept choices when navigating through a menu.














- 16. **External Speaker:** Allows you to listen to music, sounds or ringtones.
- 17. **Front Display Screen:** Displays incoming calls, messages, signal, battery strength, time and date.
- 18. **Wrist Strap Eyelet:** Accessory eyelet (optional straps and lanyards - sold separately).
- 19. **Camera:** Built-in camera lens.
- 20. **2.5mm Headset Jack:** Allows you to plug in an optional headset for convenient, hands-free conversations.
- 21. **[A/V] Volume Keys:** Press to adjust the master volume in idle mode or adjust the voice volume during a call.
- 22. **[C] Camera Key:** With the flip open, press to access the built-in camera.
- 23. **[V] Voice Commands Key:** With the flip open, press for quick access to Voice Commands.
- 24. **Charging / Data Jack:** Plug in the wall charger or USB cable (USB cable sold separately).

DISPLAY INDICATORS

Main Indicator Icons	
	1X Signal Strength: 1X service is available.
	D Signal Strength: Digital service is available.
	GSM Signal Strength: GSM service is available.
	GPRS Signal Strength: GPRS service is available.
	Airplane Mode: Transmitting and receiving information is restricted.
	Roaming: The phone is outside of the home service area.
	SSL (Secured Socket Layer): Indicates that secure communication between client and server has been established during data communication using encryption.
	Voice Privacy: Indicates Voice Privacy mode is active.
	Data Call: Data Session is in progress.
	Dormant: Phone is in a dormant state during a data call. Phone reverts to Dormant mode when there hasn't been activity on a page for some time. The connection is still active and you can make and receive calls.
	No Service: Phone cannot receive a signal from the system.

Main Indicator Icons	
	TTY: TTY mode is active.
	Voice Call: A call is in progress. * No icon indicates the phone is in idle mode.
	GPS E911 Icon: Location Service of your phone is E911.
	GPS Location On Icon: Location Service of your phone is Location On.
	Bluetooth: Indicates Bluetooth mode.
	Bluetooth Active: Indicates Bluetooth Active mode.
	Bluetooth Connected: Indicates a Bluetooth Device is connected.
	Battery Level: Battery charging level - the more blocks, the stronger the charge.
	AVC Active: AVC mode is active.
	AVC Listening: Indicates AVC listening.













Main Indicator Icons

	Phone: Indicates using Phone memory.
	All Sounds Off: Ringer volume is set to off.
	SIM Card: Indicates using SIM Card memory.
	Alarm Only: Phone will alert you with an alarm tone.
	Vibrate Only: Phone will vibrate when call is received.
	Speakerphone: Speakerphone mode is active.
	Missed Calls: Indicates you have missed calls.
	Message: Indicates you have a new message.
	Calendar Appointment: Event Alarm is active.
	Voicemail: Indicates you have voicemail messages.
	Alarm On: Appears when an alarm is set.























Recent Call Icons

	Dialed Call		Missed Call
	Received Call		











New Contact Icons

	Mobile1		Group
	Mobile2		Picture
	Home		Ringtone
	Work		FAX
	Email 1		Speed Dial
	Email 2		Voice Dial

Message Icons

	New/Unread Message		Unopened Message Notification
	Opened/Read Message		Opened Download Picture Message
	Unread EMS		Corrupt Message
	Read EMS		Pending Message Send
	Message Delivered		Unread MMS
	Incomplete Delivery		Read MMS
	Sent Message, Delivery Failed		Sent Message
	Message Locked		Received Message
	Text Message Draft		Unread WAP Push
	Picture Message Draft		Multiple Message Failed
	Priority		Read WAP Push

Message Icons


	Multiple Message Delivered		Street
	Multiple Message Incomplete		City
	Multiple Message Pending		State
	Multiple SMS/MMS ACK		Zip Code
	IM Screen		Country

INSTALLING THE BATTERY

1. Remove the battery cover from the back of the unit.




2. Slide the battery (1) into the slot by aligning the contacts located at the bottom of the unit and press (2) until you hear it “click”.




3. Align the cover tabs with the slots at the back of the device and slide the battery cover onto the unit.

REMOVING THE BATTERY

1. To remove the battery, push down (1) on the top of the battery while inserting your finger into the slot and pulling up (2) from the back of the battery and slide it out.




2. Align the cover tabs with the slots at the back of the device and slide the battery cover onto the unit.



 If the battery is not correctly placed in the compartment, the handset will not turn on and/or the battery may detach during use.

CHARGING YOUR BATTERY


1. To charge, open the Charging/Data Jack cover on the top left side of the phone, and connect the charger adapter.



2. Plug the other end into a standard outlet.

3. To remove the adapter connection, press the adapter's side buttons (1) and pull the adapter from the device (2).



-  When you charge the battery with the phone power off, you will see a charging status screen. You cannot operate the phone until it is powered on.
- The battery is not fully charged at the time of purchase. Fully charge the battery before use.
- It is more efficient to charge the battery with the handset powered off.
- Battery operating time gradually decreases over time.
- If the battery fails to perform normally, you may need to replace the battery.

BATTERY HANDLING INFORMATION

DO'S

- Only use the battery and charger approved for use with this device.
- Only use the battery for its original purpose.
- Try to keep batteries in a temperature between 41 °F (5 °C) and 95 °F (35 °C). If the battery is stored in temperatures above or below the recommended range, give it time to warm up or cool down before using.
- Store the discharged battery in a cool, dark and dry place.
- Purchase a new battery when its operating time gradually decreases after fully charging.
- Properly dispose of the battery according to local laws.

DON'TS

- Don't attempt to disassemble the battery. It is a sealed unit with no serviceable parts.
- Don't accidentally short circuit the battery by carrying it in your pocket or purse with other metallic objects such as coins, clips and pens. This may critically damage the battery.
- Don't leave the battery in extremely hot or cold temperatures. Otherwise, it could significantly reduce the capacity and lifetime of the battery.
- Don't dispose of the battery by placing into a fire.

INSTALLING A SIM CARD

Your wireless device comes with a SIM card installed which along with a Global Feature on your account, enables you to make calls and access email in GSM Networks while traveling overseas. Should your SIM card be lost or damaged, please follow these instructions for the installation of your new SIM.

- If your SIM card is lost or damaged within the United States, please dial *611 from your device or 1.800.922.0204 to speak with a Customer Service Representative. From outside of the United States dial +1- 908-559-4899.
- Do not bend or scratch your SIM card. Avoid exposing your SIM card to static electricity, water or dirt.


1. Remove the battery cover from the back of the unit.




2. To remove the battery, push down (1) on the top of the battery while inserting your finger into the slot and pulling up (2) from the back of the battery and slide it out.



3. Make sure the gold contacts of the SIM card are face down, then slide the SIM card completely into the socket.



4. Slide the battery (1) into the slot by aligning the contacts located at the bottom of the unit and press (2) until you hear it "click".



5. Align the cover tabs with the slots at the back of the device and slide the battery cover onto the unit.



BASIC OPERATION

This chapter addresses and explains the basic features of your phone including:

- | | |
|------------------------------|---------------------------------|
| Turning the phone on/off | Call waiting |
| Accessing the menu | Calling a number from contacts |
| Menu summary | Adjusting the volume |
| Making a call | Caller ID |
| Answering calls | Turning vibrate mode on or off |
| Ending a call | Speakerphone |
| Missed call notification | Available options during a call |
| Wait/Pause | Making an emergency call |
| Making an international call | |
| 3 way calling | |

TURNING THE PHONE ON/OFF

TURNING ON

1. Press and hold the END Key until your display turns on.

- If **Enter Lock Code** appears on the display, enter your 4-digit lock code to unlock your phone.
- The default lock code is the last 4 digits of your Mobile Telephone Number.


TURNING OFF

1. Press and hold the END Key until your display turns off.

- Immediately change or recharge the battery when **BATTERY LOW** appears on the display. Memory may possibly be damaged if the phone turns off due to the battery completely draining.
- Turn the phone off before removing or replacing the battery. If the phone is on, unsaved data may be lost.

ACCESSING THE MENU

Your phone can be customized via the menu. Each function can be accessed by scrolling with the Directional Key  or by pressing the number that corresponds with the menu item.

1. To access the menu, press the OK Key [**MENU**].
2. To scroll through the menu, press the Directional Key  up, down, left or right.
3. To return to the previous page, press the CLR Key. To exit the current menu, press the END Key.
4. To access the **Messaging** menu, press the Left Soft Key [**Msg**].
5. To access the **Contact List**, press the Right Soft Key [**Contacts**].

- All directions in this manual are based on the **List Menu Layout** and **Water Display Theme**. If you have changed the settings, the directions may vary.

MENU SUMMARY

Main Menu	2 ND DEPTH	3 RD DEPTH
1. Media Center	1. Tunes & Tones	1. Get New Ringtones 2. My Ringtones 3. My Sounds
	2. Pictures	1. Get New Pictures 2. My Pictures 3. Take Picture 4. Online Album
	3. Games	1. Get New Applications
	4. Mobile Web	
	5. Browse & Download	1. Get New Applications
	6. Extras	1. Get New Applications
2. Messaging	1. New Message	1. TXT Message 2. Picture Message 3. Voice Message
	2. Inbox	
	3. Sent	

Main Menu	2 ND DEPTH	3 RD DEPTH	
2. Messaging	4. Drafts		
	5. Voicemail		
	6. Mobile IM		
	7. Email	Mobile Email Mobile Web Mail	
	8. Chat		
	3. My Ringtones	1. Get New Ringtones	
	4. My Pictures		
	5. Bluetooth Menu	1. Add New Device	
6. Contacts	1. New Contact		
	2. Contact List		
	3. Backup Assistant		
	4. Groups		

Main Menu	2 ND DEPTH	3 RD DEPTH
6. Contacts	5. Speed Dials	
	6. In Case of Emergency	
	7. My Name Card	
7. Recent Calls	1. Missed	
	2. Received	
	3. Dialed	
	4. Blocked – This menu appears only when Incoming Call Restriction is set. For details see page 59.	
	5. All	
	6. View Timers	
8. VZ Navigator		
9. Settings & Tools	1. My Verizon	

Main Menu	2 ND DEPTH	3 RD DEPTH
9. Settings & Tools	2. Tools	1. Voice Commands
		2. Calculator
		3. Tip Calculator
		4. Calendar
		5. Alarm Clock
	6. Stop Watch	
	7. World Clock	
	8. Unit Convert	
	9. Notepad	
	3. Bluetooth Menu	1. Add New Device
	4. Sounds Settings	1. Easy Set Up
		2. Call Sounds
		3. Alert Sounds
		4. Keypad Sounds
		5. Digit Dial Readout
		6. Keypad Volume
		7. Service Alerts
		8. Device Connect
		9. Power On/Off
		0. Open/Close Sounds
	5. Display Settings	1. Easy Set Up
		2. Banner

Main Menu	2 ND DEPTH	3 RD DEPTH
9. Settings & Tools	5. Display Settings	3. Backlight
		4. Wallpaper
		5. Display Themes
	6. Main Menu Settings	
	7. Dial Fonts	
	8. Menu Font Size	
	9. Time & Date	
	0. Clock Format	
	6. Phone Settings	1. Airplane Mode
		2. Set Shortcuts
		3. Voice Commands Settings
		4. Language
		5. Location
		6. Current Country
		7. Phone Security
		8. SIM Security
		9. Network Mode
		0. System Select
	7. Call Settings	1. Answer Options
		2. Auto Retry
		3. TTY Mode
		4. One Touch Dial

Main Menu	2 ND DEPTH	3 RD DEPTH
9. Settings & Tools	7. Call Settings	5. Voice Privacy
		6. DTMF Tones
		7. Assisted Dial
		8. Memory
	9. Phone Info	1. Phone Memory
		1. My Number
		2. SW/HW Version
		3. Icon Glossary
		4. Software Update
	0. SIM Info	
	*. Set Up Wizard	

MAKING A CALL

1. Enter the phone number including the area code if needed and press the SEND Key.



When you place or receive a call from phone numbers stored in your Contact List, the name will be displayed.