

Table of Contents 1

Legal notices	3	Contacts	41
Safety precautions	5	Voice-activated dialling	48
Antenna care	7	Call records	50
Phone operation	7	Call log lists	50
Phone overview	11	Time & charges	51
Display symbols	13	Camera	52
Getting started	15	Create message	56
Inserting the SIM card/ battery	15	SMS/MMS	56
RS MultiMediaCard	16	E-mail	60
Charging the battery	17	Inbox	62
Switch phone on/off, enter PIN	19	Message lists	69
Emergency number (SOS)	20	Drafts	69
General instructions	21	Sent messages	69
Standby mode	21	Message settings	70
Signal strength	21	SMS settings	70
Offline mode	22	MMS settings	72
Digital Rights Mgmt. (DRM)	22	E-mail settings	74
Main menu	23	CB settings	77
Tabs	23	Inst. message settings	77
Navigation key	23	Instant messaging	78
Standard functions	24	Starting/viewing/ ending conversations	80
Security	28	Receiving conversations	82
PIN codes	28	Voice mail	88
Text entry	30	Settings	88
Calling	34	Internet	89
Video calls	34	Enter URL	89
Accepting a call	35	Bookmarks list	89
Rejecting a call	36	History	89
Tone sequences (DTMF)	40	Browser settings	89
		Games	95

See also index at the end of this User Guide

2 Table of Contents

Organiser	96	Mobile Phone Manager	138
Calendar	96	Questions & Answers	140
Dictat. machine	98	Customer Care	144
Time zones	98	Care and maintenance	146
Remote sync	99	Product data	147
Extras	101	SAR	148
My menu	101	Accessories	149
SIM toolkit (optional)	101	U.S. FDA	151
Alarm clock	102	FCC/Industry Canada Notice ...	157
FM radio	103	Intellectual Property	158
Calculator	104	Ten Driving Safety Tips	159
Unit converter	104	End user license agreement ...	161
Sound recorder	105	Menu tree	165
Stopwatch	106	Index	172
Media player	107		
My stuff	110		
Settings	113		
Profiles	113		
Ringtones	114		
Themes	115		
Display	115		
Vibration (silent alert)	117		
Connectivity	118		
Shortcuts	122		
Call setup	123		
Phone	126		
Clock	130		
Security	132		
Network	134		
Accessories	136		

See also index at the end of this User Guide

Legal notices

The mobile phone described in this guide is approved for use on the GSM and GPRS networks operating on the GSM 900, 1800 (DCS/PCN) and 1900 (PCS) bands. It is approved for use in the country where it was originally sold and may be approved for use in other countries.

© 2005 Siemens Information and Communication Mobile, LLC.
All rights reserved.

Siemens and the SXG75 model phone are trademarks or registered trademarks of Siemens AG and/or its affiliates in the United States and/or other countries.

T9® is a registered trademark of America Online, Inc. in the United States. Java and all Java-based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S and other countries. The names of actual companies and products mentioned herein may be the trademarks of their respective owners.

Disclaimer

THE INFORMATION CONTAINED IN THE USER GUIDE IS WRITTEN FOR THE SXG75 PHONE. SIEMENS RESERVES THE RIGHT TO MAKE CHANGES AND IMPROVEMENTS TO THE PRODUCTS AND ANY OF THE FEATURES OF THE PRODUCTS DESCRIBED IN THIS DOCUMENT WITHOUT PRIOR NOTICE. THE CONTENTS OF THE USER GUIDE ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED

TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. SIEMENS RESERVES THE RIGHT TO REVISE THE USER GUIDE OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE. UNDER NO CIRCUMSTANCES SHALL SIEMENS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

Export Information

The mobile phone may be subject to export regulation of the United States and other countries. Diversion contrary to law is prohibited. You must comply with all applicable export laws, restrictions and regulations of the United States foreign agencies or authorities, and may not export, or transfer for the purpose of re-export, the mobile phone or any part of the phone in violation of any applicable restrictions, laws or regulations, or without all necessary approvals.

Network Services

A number of features included in this guide are called Network Services. They are special services provided by wireless service providers. In order to use any of these Network Services, you must subscribe to these service(s) from your service provider and obtain instructions for their use. Some of these Network Services may not be available when roaming on a network other than your home network.

Standby and Talk Time Information

The mobile phone incorporates features that are new to the mobile phone world. These may include color displays and lighting, graphic games, music reproduction and browsing the Internet. The way you use the display and the features will affect the performance of the battery and how long it lasts between charge cycles. The quoted standby times and talk times show the minimum and maximum performance that can be expected from the battery under normal network conditions and with the default settings as set by the factory. However, playing games (particularly with the backlight continuously switched on) and

listening to music will shorten the time available for standby and to make and receive telephone calls. Operation times also vary depending on network conditions, SIM settings, charging and battery condition, how you use your phone and other factors.

Memory

The mobile phone contains an internal memory device that stores the software required to operate the mobile phone, communicate with the GSM/GPRS network and provide the user interface. Some features in the internal memory run additional devices and some additional games and utilities. The amount of memory available in the mobile phone is finite and may be insufficient to store large numbers of applications and files.

Warning!

Remember to back up your data and to do so frequently. Always back up all data and programs before sending the mobile phone in for repair.

Safety precautions

Information for parents

Please read the operating instructions and safety precautions carefully before use.

Explain the content and the hazards associated with using the phone to your children.



Remember to comply with legal requirements and local restrictions when using the phone. For example in aeroplanes, petrol stations, hospitals or while driving.



Cellular phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. Keep at least 9 inches (20 cm) between phone and pacemaker. When using the cell phone hold it to the ear which is farthest from the pacemaker. For more information consult your doctor.



The ringtone, info tones and speakerphone talking are reproduced through the loudspeaker. Do not hold the phone to your ear when it rings or when you have switched on the speakerphone function. Otherwise you risk serious, permanent damage to your hearing.



Only use original Siemens batteries (100 % mercury-free) and – charging devices. Otherwise you risk serious damage to health and property. The battery could explode, for instance.



Small parts such as the SIM card, sealing stop, lens ring and lens cap can be dismantled and swallowed by small children. The phone must therefore be stored out of the reach of small children.



The mains voltage specified on the power supply unit (V) must not be exceeded. Otherwise the charging device may be destroyed.

The power supply must be plugged into an easily accessible AC mains power socket when charging the battery. The only way to turn off the charging device after charging the battery is to unplug it.



Do not use a handheld while driving.



Do not look at the LED (e.g. activated infrared port, flash LED) with optical magnifiers because of the risk of radiation.

This product complies with IEC/EN 60825-1 2 Safety of Laser Products² for LED Class 1M products; such products are safe under reasonably foreseeable operating conditions.



Do not place the phone near to electromagnetic data carriers such as credit cards and floppy disks. Information stored on them could be lost.



You may only open the phone to replace the battery (100% mercury-free) or SIM card. You must not open the battery under any circumstances. All other changes to this device are strictly prohibited and will invalidate the guarantee.

Important



Please dispose of unwanted batteries and phones as permitted by the laws in your country.



The phone may cause interference in the vicinity of TV sets, radios and PCs.



Use only Siemens original accessories. This will avoid potential risks to health or property and ensure compliance with all relevant regulations.

Improper use will invalidate the guarantee! These safety instructions also apply to Siemens original accessories.

This cellular phone offers a range of functions, it can be used in positions other than the head, such as on the body. In this case, separation distance of 1.0 cm is required. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the device the above-stated distance from your body.

Bluetooth®

Your phone has a Bluetooth interface. This makes it possible to establish a wireless connection of your phone with a headset of a car kit, or with other Bluetooth-enabled devices.

In order to establish a secure link between the devices and to prevent a third party from having access to your phone, you should observe the following points:

- The initial connection between two devices, called "pairing", should take place in familiar surroundings.
- Both devices must be able to identify themselves once by using a password/PIN. To ensure sufficient security, you should choose a 16-digit number combination for a password that would be difficult to guess (if a PIN has not been assigned).
- An automatic connection acceptance ("connection without confirmation") should only be used in exceptional cases.
- In general, only trustworthy devices should be linked in order to minimize security risks.
- You should restrict the "visibility" of your phone if possible. This will make it much more difficult for unknown devices to establish a connection with your phone. To do this, in the Bluetooth menu, set the option **Visib.to others** of **Always visible** to **Not visible** (see page 120).
- The name of your phone is transmitted in a Bluetooth connection. The factory default is the "Bluetooth ID". The first time Bluetooth is activated, or later in the Bluetooth menu, you can change this name (**My BT name**, page 119).
- If Bluetooth is not needed, this function should be deactivated.

Before using Bluetooth accessories, or a mobile phone inside a vehicle, check the vehicle user guide for any limitations on the use of these products.

Important

Read this information before using your wireless handheld phone.

As this mobile phone is equipped with a fixed (non-retractable) antenna, some paragraphs in the text below may not be applicable.

Antenna care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone operation

Normal position

Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

Tips on efficient operation

For your phone to operate most efficiently:

- Extend your antenna fully (if applicable).
- Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

Driving

Laws pertaining to the use of mobile phones while driving vary significantly from state to state and sometimes even from locality to locality within states. For example, some areas may allow persons to use their mobile phones only if they employ a hands-free device, and some areas may prohibit the use of cell phones entirely. Accordingly, Siemens recommends that persons check the laws for the areas in which they drive or will be driving. For areas where the use of mobile phones while driving is permitted, Siemens encourages persons to use their phones responsibly and to employ hands-free devices. Also, if using your phone while driving, please:

- Give full attention to driving – driving safely is your first responsibility;
- Use hands-free operation, if available;
- Pull off the road and park before making or answering a call, if driving conditions so require.

For vehicles equipped with air bags

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is

improperly installed and the air bag inflates, serious injury could result.

Electronic devices

Most modern electronic equipment is shielded from radio frequency (RF) signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers' Association recommends that a minimum separation of six inches (6") be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

Persons with pacemakers

- should ALWAYS keep the phone more than six inches from their pacemaker when the phone is turned ON;
- should not carry the phone in a breast pocket;
- should use the ear opposite the pacemaker to minimize the potential for interference;
- should turn the phone OFF immediately if there is any reason to suspect that interference is taking place.

Hearing aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your service provider or your hearing aid manufacturer to discuss alternatives.

Other medical devices

If you use any other personal medical devices, consult the manufacturers of your devices to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle. You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted facilities

Turn your phone OFF in any facility where posted notices so require.

Airplanes

FCC and Airline Regulations prohibit using your phone while in the air. Turn your phone OFF when requested by the airline.

Check and comply with the policy of your airline regarding the use of your phone while the airplane is on the ground.

Blasting areas

To avoid interfering with blasting operations, turn your phone OFF when in a "blasting area" or in areas posted: "Turn off two-way radio." Obey all signs and instructions.

Potentially explosive atmospheres

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often but not always clearly marked. They include: fueling areas such as gasoline stations; below deck on boats; fuel or chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or particles, such as grain, dust or metal powders; and any other area where

you would normally be advised to turn off your vehicle engine.

Emergency calls (SOS)

Your wireless phone can be used to make emergency calls. You can make an emergency call from the main display screen. Enter the local emergency number such as 911 and then press the  key.

This phone, like any wireless phone, operates using radio signals, wireless and landline networks, and user-programmed functions. Because of this, connections in all conditions cannot be guaranteed. Therefore, you should never rely solely on any wireless phone for essential communications (for example, medical emergencies). Remember – to make or receive any calls, the phone must be switched on and be used in a service area that has adequate signal strength. Emergency calls might not be possible on all wireless phone networks or when certain network services or phone features are in use. Check with local service providers regarding their network features.

Always make certain that your phone is properly charged before attempting any emergency calls. If you allow your battery to discharge, you will be unable to receive or make calls, including emergency calls. You must then wait a few minutes after

the charging begins to place any emergency calls.

When making an emergency call, remember to give all of the necessary information as accurately as possible. Remember that your wireless phone might be the only means of communication at the scene of an accident, therefore you should not terminate the call until given permission to do so.

Batteries and Chargers

Only use original Siemens batteries (100% mercury-free) and charging devices. Use of non-Siemens batteries and/or charging devices may cause explosion resulting in serious injury and/or property damage. Use original Siemens accessories in order to avoid possible injury and property damage and to ensure compliance with applicable laws and regulations. Improper use invalidates the warranty.

Battery safety precautions

To reduce the risk of fire, injury or electric shock, and to properly dispose of batteries, please read and understand the following instructions. CONTAINS LITHIUM-ION OR NICKEL-METAL HYDRIDE BATTERY. BATTERY MUST BE RECYCLED OR DISPOSED OF PROPERLY. DO NOT DISPOSE IN MUNICIPAL WASTE.

1. Only use the batteries specified for use with this mobile phone.
2. Do not use batteries of different sizes or from different manufacturers in this mobile phone.
3. Do not dispose of the battery in a fire; it may explode. Dispose of used batteries and phones in accordance with applicable laws and safety regulations. Do not expose battery to water. Check with local codes for special disposal instructions.
4. Do not open or mutilate the battery. Doing so may cause damage to the eyes or skin.
5. Exercise care in handling the battery in order not to short the battery with conducting materials such as rings, bracelets, and keys. The battery or conducting material may overheat and cause burns or fire.
6. Charge the battery provided with, or identified for use with, this product only in accordance with the instructions and limitations specified in the User's Guide. Do not attempt to charge the battery by any means other than those specified in the User's Guide.

Phone overview

① Video call key

Press the video call key. The phone is in video call mode.

② WAP key

Open the browser if not predefined.

③ Call key

Dial the number/name displayed/high-lighted, take calls.

④ On/Off/End key

- Switched off: Press and **hold** to switch on.
- During a conversation or in an application: press **briefly** to finish.
- In menus: Press and **hold** to go back to standby mode.
- In standby mode: Press and **hold** to switch off.
Press **briefly**: Power down menu.

⑤ Softkeys

The current functions of these keys are shown in the bottom line of the display as **Text**/symbol.

⑥ Task key

Press **briefly**: open task switcher.
Press and **hold**: open main menu.

⑦ Clear key

Text input: Clear characters one by one in text input mode. Press and **hold** to delete text quickly.
Lists/Input fields: Delete highlighted item(s).

⑧ Navigation key


-  Press the navigation key to open the main menu or start an application/function (page 23).

⑨ In standby mode

-  Press **briefly**: Open the user profiles.
Press and **hold**: Start the voice dialling.
-  Open the Contacts.
-  Open the Calendar.
-  Start the FM radio.

In lists, messages and menus

-  Scroll up and down.



12 Phone overview

① Earpiece

② Integrated antenna

Do not obstruct the phone above the battery cover unnecessarily. This reduces the signal quality.

③ Camera lens

④ Camera key

⑤ Media player key

Start the Media player.

⑥ Volume control

⑦ Display

⑧ RS MultiMediaCard tray

⑨ Infrared interface (IrDA)

⑩ Ringtone

- Press and **hold** in standby mode: Switch all audible signals on/off (except alarm). Vibration is activated automatically.
- Press and **hold** on incoming call: Switch off ringtone for this call only.

⑪ Key lock

Press and **hold** in standby mode to switch key lock on/off. Only emergency numbers can be dialed.
While dialling: Enter wildcard "?".


⑫ Connection socket

For charger, headset, flash, etc.

⑬ Connection for external antenna

⑭ Camera lens

⑮ Loudspeaker



Display symbols

Display symbols (selection)

	Signal strength
	Charging
	Battery charge level, e.g. 50 %
	Contacts
	Call records
	Internet
	Camera
	Messages
	Organiser
	Games
	Media player
	Video telephony
	Extras
	My stuff (file management)
	Settings
	All calls are diverted
	Ringtone off
	Alarm set
	Keypad locked

	Auto answer feature on
	IrDA activated
	IrDA transmission
	Bluetooth activated
	Bluetooth visible for others
	Bluetooth during data transfer
	Call accepted at Bluetooth device
	Inst. Message login
	Mobile Navigation

Events (selection)

	SMS memory full
	Missed calls
	Phone memory full
	No network access
	Inbox
	Memory assistant
	Data liable to pay costs (DRM, (page 22))

14 Display symbols

Message symbols (selection)


	Unread
	Read
	Draft
	Sent
	MMS not sent
	MMS received
	MMS read
	MMS with DRM contents (page 22)
	E-mail forwarded
	E-mail with attachment
	Voice mail received

Camera symbols

	Brightness
	Zoom factor
	White balance
	Flash connected

Getting started


Your phone's display is supplied with a protective film. Remove this film slowly before using the phone.




In rare cases, static discharge may cause discolouration at the edges of the display. However, this will disappear within approx. 10 minutes.

Inserting the SIM card/ battery

The service provider supplies you with a SIM card on which all the important data for your line is stored. If the SIM card has been delivered in credit-card size, snap the smaller segment out and remove any rough edges.




- Push the cover towards the front in the direction indicated by the arrow ①.




- Place the SIM card in front of the slot with the contact surface facing **downwards**. Then press the SIM card slightly to push it in ② (ensure that the chamfered corner is in the correct position).

- Insert the battery sideways into the phone ①, then press it downwards ② until it engages.



- To remove, press the retaining tab on the side of the battery, then lift the battery out.



- Place the cover in position, then push it towards the front in the direction indicated by the arrow, until it clicks into place.

Additional information

Please switch off your phone before removing the battery!

RS MultiMediaCard

The RS MultiMediaCard gives your phone a very large memory capacity. This allows you to save picture/video files and sound recordings, for example. However, you can also use this MultiMediaCard like a floppy disk to save any other files.

You can access the list of folders and files in the **My stuff** menu (page 110). If the MultiMediaCard assigns a file to a function in the phone such as a ringtone, the file is copied to the phone memory.

Additional information

RS MultiMediaCard™ is a trademark of the MultiMediaCard Association.

New RS MultiMediaCard

- Create a backup copy of the data on the old MultiMediaCard on a PC.
- Format the new MultiMediaCard.
- Copy the data from the PC onto the new MultiMediaCard.


Inserting/removing the RS MultiMediaCard

Please observe the manufacturer's operating instructions that come with the RS MultiMediaCard.

Attention

Before removing the **RS MultiMediaCard**, carry out the **Eject card** function in the settings menu (page 127). This prevents any possible data loss.

- Press on the tray. The tray for the card is opened. You can remove the tray.
- Insert the card on the tray (ensure that the chamfered corner is in the correct position ①). Insert the tray with the card into the phone ② until it snaps in.




Charging the battery

The battery is not fully charged when delivered. Plug the charger cable into the bottom of the phone, plug the power supply unit into a mains power socket and charge for at least **two hours**.

Only use the plug-in power supply included in delivery!

As an alternative, the battery can be charged via the USB port (Accessories, page 137).



Display during charging.

Charging time

An empty battery is fully charged after about 2 hours. Charging is only possible within a temperature range of +5 °C to 45 °C (41 °F to 113 °F). If the temperature rises/falls 5 °C (9 °F) above/below this, the charge symbol flashes a warning. The mains voltage specified on the power supply unit must not be exceeded.

The charge level of the battery is only displayed correctly after an uninterrupted charging/discharging cycle. You should therefore **not remove the battery unnecessarily** and where

18 Getting started

possible **not end the charging process prematurely**.

Additional information

The power supply unit heats up when used for long periods. This is normal and not dangerous.

If the battery is removed for longer than 30 seconds, the clock must be reset.

Operating time

The operating time depends on the operating conditions. Extreme temperatures considerably reduce the phone's standby time. Avoid placing the phone in the sun or on a heater.

Talktime:

- UMTS: up to 300 minutes
- GSM: up to 360 minutes

Standby time: Up to 400 hours

Additional information

The talktime and standby time depend on the network environment. For more examples of functions that reduce the standby time, e.g. animated screensaver, fast search, see page 140.

Charge icon not visible

If the battery has been discharged fully, the charge icon is not immediately visible when the power supply is plugged in. It will appear after up to two hours. In this case the battery is fully charged after 3 to 4 hours.

Display while in service

Charge level display during operation (empty–full):



Battery low warning

When the battery is almost empty you are warned twice. The first warning appears when the battery has 10 minutes of power remaining.

The second warning appears when the battery has 1 minute of power remaining.



Press to confirm warning.

Power off

If battery is completely empty, the phone switches off automatically.

Additional information

If phone powered down because of low battery, it will power on again automatically when charged.

Switch phone on/off, enter PIN

Switching the phone on/off

Switching the phone on



Press and **hold** On/Off/End key to switch phone on.

Enter PIN or confirm request (page 29).

Your greeting message and the start-up animation are displayed if activated (page 116). Press any key to end the animation.

The phone switches on automatically when:

- You charge the phone via USB or
- an alert or calendar event appears. If you do not respond, the phone switches off again. If you respond to the alert, the PIN is required.

Yes

Press to activate.

Or

Offline

Press to start in offline mode (page 22).

Entering the PIN

The SIM card can be protected with a 4 to 8-digit PIN.



Enter PIN using number keys. Asterisks appear to ensure nobody can read your PIN on the display. Correct with .

OK

Confirm. Logging on to the network will take a few seconds.

Additional information

Change PINpage 28

Clear SIM card barringpage 29

Switching the phone off



Press and **hold** On/Off/End key.

Or



Press **briefly** and select one of the following options.

Switch off

Switch phone off. Phone switches on automatically if alarm or calendar event occurs.

Offline mode

Phone is not switched off, but has no connectivity (page 22).

The shutdown animation (page 116) is displayed.

Additional information

The shutdown is interrupted, if:

- some files occur to be not saved or
- the phone is receiving an MMS.

A warning message is displayed. Press **Yes** to continue shutdown. Files are not saved. Message is received when phone is switched on again.

Emergency number (SOS)

Only to be used in real emergencies!

By pressing the softkey **SOS** you can make an emergency call on any network **without** a SIM card and without entering a PIN (not available in all countries).

Additional information

If key lock is active (page 12) only emergency numbers can be dialled: Enter number and press **SOS**.

Switching on your phone for the first time

When you switch on the phone for the first time or after the battery has been removed, you are prompted to set the time/date.



Select if you want to enter time/date.

Time/Date

When you first switch on, set the clock and date so that it displays the correct time. You will not have to make this setting again.



First enter date (day/month/year), then time (24 hours).



Press to update time and date.

Additional information

You can activate **Auto time mode** (page 131) to display local time by network if the network supports this function.

Time zones



Select the desired setting and change time zone in world map.



Select a city in the selected time zone.

Options

Open menu and select **Set time zone** to save.

Further options and settings on page 130.

General instructions

Standby mode

The phone is in **standby mode** and is **ready for use** when the name of the service provider appears on the display.



Press and **hold** the On/Off End key to return to standby mode from any situation.

The following information might be displayed:

Logo

If logo or wallpaper is enabled (page 115) logo is displayed.

CB messages

If CB display is enabled (page 77) a CB ticker with the latest CB message is displayed, scrolling horizontally if needed. The CB ticker is only available if the alert region is not used, i.e. there are no current events.

Alert region

In the alert region above the softkeys the following message types can be displayed:

- New entries in missed calls list, voice mail or inbox.
- New content via IrDA/Bluetooth.
- Missed calendar events.

The number of new entries is displayed (e.g. 1 Missed call).

Signal strength



Strong signal.



A weak signal reduces the call quality and may lead to loss of the connection. Change your location.

If phone cannot obtain network service after 15 minutes the power save mode is used. The phone only attempts to acquire service in intervals.

Offline mode

In offline mode you can operate many phone functions but you are not connected to any network (you are not available for incoming calls and you cannot initiate a call).

This is the mode to be used in aircrafts.

Switching between offline and online mode:



Press **briefly** and select **Offline mode/Online mode**.



Confirm request.

Digital Rights Mgmt. (DRM)

Remember that your phone has digital rights management. The use of downloaded pictures, sounds or applications can be restricted by the suppliers, e.g. copy protection, use for a limited period of time only, number of times they can be used, etc.

User guide

Symbols

The following symbols are used to explain operation:



Enter numbers or letters.



On/Off/End key



Call key



Displays a softkey function.



Press the navigation key down, to call up the menu for example.



Display navigation function. Press navigation key in the direction indicated.



Function dependent on service provider, may require special registration.


Main menu

The main menu is displayed graphically with symbols:

-  Call up from standby mode.
-  /  Select application symbols.
-  Start application.

Tabs

Tabs allow fast access to information and applications.



-  Switch between tabs.
While editing a tab, you navigate within the input field.
-  Leave input field, to switch to the next tab.

Navigation key

The symbol in the centre of the lower line of the display shows the current function when the navigation key is pressed down vertically.

In this User Guide the symbol  is used universally when the navigation key is pressed down vertically. The following functions are available (selection):

-  Display main menu
-  Confirm/select
-  Change (open options list)
-  Call, accept call
-  Edit
-  Camera
-  Send
-  View
-  Save
-  Play
-  Pause
-  Stop
-  Record
-  Zoom
-  Insert calendar
-  Insert picture
-  Insert contact

24 General instructions

Menu control

The steps needed to reach a function are shown in a **condensed form** in the user guide, e. g. to set ringtones

 →  → Ringtones

This comprises the following steps:

-  Open main menu.
-  /  Select  to open Settings menu.
-  Confirm selection.
-  Select Ringtones function.
-  Confirm selection.

Standard functions

Options menu

The list contains functions that are offered in several options menus.

Options Open menu.

<New entry>	Create new entry.
Save	Store entry.
Change	Open options list. Select option and confirm.
View	Display entry.
Info	Display properties of selected entry.
Details	Display additional information about message (e.g. date, sender, save location, attached files, size)
Delete/ Delete all	Delete entry/delete all entries after confirmation.
Exit	Exit application. Confirm request with  if you want to save changes.
Edit	Open entry to edit/open input field to edit.
Text input meth.	Open input method menu (page 30).
Text edit menu	Open text edit menu (page 31).
Sort by	Select sort criterion (e.g. alphabetical, type, status, sender, date/time).

Set as	e.g. set picture as wallpaper, logo, screensaver, melodies as ringtones.
Rename	Rename selected entry.
Send	Select transmission type (e.g. MMS, SMS, Instant Message, e-mail, IrDA or Bluetooth) and send entry. If you send via Bluetooth, select Search/Known devices/Last connected (page 119). If a DRM protected file is selected, the send option is not available.
Create message	Select transmission type (see above) and create message. If contact/call list entry is selected, it is used for receiver data.
Reply/Reply to all	The sender becomes the recipient, "Re." is placed in front of the subject matter and the received text is transferred into the new message.
Capacity/ Memory status	Display memory status for respective application, phone, SIM card or the RS MultiMediaCard . If memory is insufficient to save required data, a notification is displayed. Confirm with  to open Memory assistant (see below).

Fast list search

Pressing number keys while you are in alphabetically ordered lists (e.g. Contacts, My Stuff) opens a fast search window.



Enter text to jump quickly to the entry that corresponds most closely with the entered text.

Memory assistant

The memory assistant is launched automatically if memory is low.

Start via main menu:



Phone → File system
→ Memory assistant

All saved folders and files in phone memory and on **RS MultiMediaCard** (page 16) are listed. Display name and size of folders/files.

If **RS MultiMediaCard** is inserted, folders/files are organised on a separate tab.



Select tab (phone memory/**RS Multi-MediaCard**).



Select folder/file.

Options

Open menu and select function (standard functions page 24).

To free up required memory open file before deleting or delete files directly.

Mark mode

Within some applications (e.g. Contacts/My Stuff) one or more entries in a list can be highlighted to carry out a function jointly.

Options Open menu and select Mark.



Select entry/entries.



Mark/unmark entry.

Mark options

Depending on the current situation, different functions will be offered.

Options Open menu.

Mark/ Unmark	Mark/unmark selected entry.
Mark all	Mark all entries.
Unmark all	Unmark all marked entries.
Delete marked	Delete all marked entries.
Send marked	Send marked messages (e.g. e-mails from draft folder).
Retrieve marked	Retrieve marked e-mails (if only header is retrieved).
Remove marked	Remove selected contact(s) e.g. from a distribution list or group.

Menu speed dialling

All menu functions are numbered internally. A function may be selected directly by entering these numbers in sequence.

E.g., write new SMS (from standby mode):



Press this key to display the main menu.



Press this key for **Messages**.



Press this key to create new message.



Press this key for **SMS**.

Task switching

The phone supports the use of multiple applications at the same time. The function you are currently using is in foreground, the other open applications are in the background.

You can switch from the current application to the main menu, standby mode or to any open application.



Press the Task key. All currently open applications are listed.

You can directly switch to the Main Menu, Home or to any open application:

Menu/Home/<Application>

Select and confirm with .

If you are holding a call, select **Current call** to return to the call.

Task switching options

If any applications are currently open, an options menu is offered.

Options Open menu.

Switch to	Move highlighted application to foreground.
Close	Close highlighted application.
Close all	Close all open applications except main menu.

Security

The phone and SIM card are protected against misuse by several security codes.

Keep these confidential numbers in a safe place where you can access them again if required.

PIN codes

PIN	Protects your SIM card (personal identification number).
PIN2	This is needed to set the charge detail display and to access additional functions on special SIM cards.
PUK PUK2	Key code. Used to unlock SIM cards after the wrong PIN has been entered repeatedly.
Phone code	Protects your phone. Must be entered at the first security setting.

 →  → Security → PIN codes
→ Select function.

PIN control

The PIN is usually requested each time the phone is switched on. You can deactivate this feature but you risk unauthorised use of the phone. Some service providers do not permit deactivating the control.

On/Off Activate/deactivate PIN control.

 Enter PIN code.

 Confirm.

Change PIN

You can change the PIN to any 4 to 8-digit number you find easier to remember.

 Enter current PIN code and confirm with .

 Enter **new** PIN code and confirm with .

 Re-enter **new** PIN code and confirm with .

 Confirm.

Change PIN2

(Display only if PIN2 is available).

Proceed as with **Change PIN**.

Change phonecode

You define the phone code (4–8 digits) when you call up a phone-code protected function for the first time. It is then valid for all phone-code protected functions.

To change phone code proceed as with **Change PIN**.

Following the third unsuccessful attempt, access to the phone code and the functions that use it is denied. Contact the Siemens Service Centre (page 144).

Clearing SIM card barring

If the PIN is entered incorrectly three times, the SIM card is barred.



Enter **new** PIN code and confirm with



Enter **new** PIN code again and confirm with



Enter PUK code (MASTER PIN) provided by your service provider with the SIM card in accordance with the instructions and confirm with



Confirm.

Additional information

If the PUK (MASTER PIN) has been lost, please contact your service provider.

Preventing accidental activation

Even if PIN use is deactivated (page 19) confirmation is required to switch on the phone.

This prevents accidental activation of the phone, e.g. when you are carrying it in a bag or when you are travelling in an aircraft.



Press and **hold**.



Press. The phone switches on.



Press or take no action. The phone does not switch on.

Connecting to Windows® PCs

You can connect your phone to a Windows® PC using IrDA, Bluetooth or a data cable (accessories, page 149). The Windows® PC program MPM (Mobile Phone Manager, page 138) enables you to backup data on your Windows® PC and to synchronise the contacts with Outlook®, Lotus Notes™ and other Siemens phones (as well as some Gigaset). You can download the Mobile Phone Manager from the Internet at:

www.siemens.com/sxg75

Text entry

Text entry without T9

Press number key repeatedly until the required letter appears. After a brief interval the cursor will advance. Example:



Press **once briefly** to write the letter **a**, twice to write **b** etc.

Press and **hold** to write the number.



Unusual characters and numbers are displayed after the relevant letters.



Press **briefly** to delete the letter left of the cursor or marked text. Press and **hold** to delete text quickly.



Move the cursor (forwards/back).



Press **briefly**: Swap between: abc, Abc, ABC, T9 abc, T9 Abc, T9 ABC, 123.

Press and **hold**: Input method menu is displayed.

The sequence of the input methods is language-dependent.



Press **briefly**: Special characters are shown.

Press and **hold**: Open edit menu.



Press **once/repeatedly**:
., ? ! ' " 0 + - () @ / : _

Press and **hold**: inserts 0.



Press to insert space.
Press twice to insert line feed.

Special characters



Press **briefly**. The symbols chart is displayed:

1)	¿	¡	_	;	.	,	? !
+	-	"	'	:	*	/	()
¤	¥	\$	£	€	@	\	& #
[	]	{	}	%	~	<	= >
	^	`	§	Γ	Δ	Θ	Λ ≡
Π	Σ	Φ	Ψ	Ω			

1) Line feed



Navigate to characters.



Confirm.

Text edit menu

For text entry:



Press and **hold**: The edit menu is displayed:

Insert symbol

Spell word

Mark text

Copy/Paste

Input language

Selecting the input language

Select the language in which you want to compose your message.

Options

Open edit menu.

Input language

Select.



Select language. If you select **Automatic**, the **Input language** is based on the **Display language** (page 126).



Confirm, the new language is set.

Languages with T9 support are marked with the **T9** symbol. The input language setting applies to all applications.

Marking text

You can highlight text in order to copy and paste it to a different place.



Press and **hold**. The edit menu is displayed.

Mark text

Activate highlighting mode.



Scroll to highlight text.

Copy

Copy highlighted text to the clipboard.

Paste

Paste the copied text into the desired location.

Text entry with T9

"T9" deduces the correct word from the individual key entries by making comparisons with an extensive dictionary.

Activating, deactivating T9



Press and **hold**: Input method menu is displayed.

Select desired input mode.

Select

Activate/deactivate T9.

Writing with T9

The display changes as you proceed.

It is best if you finish a word without looking at the display.

Simply press the keys **once** where the relevant letter is located. For "hotel", for example:

 Press **briefly** for T9 **Abc** then



 A blank ends a word.

Do not use special characters such as Ä. Use standard characters instead, e.g. A; T9 will do the rest for you.

T9® Text Input is licensed under one or more of the following: U.S. Pat. Nos. 5,187,480, 5,818,437, 5,945,928, 5,953,541, 6,011,554, 6,286,064, 6,307,548, 6,307,549, 6,636,162 and 6,646,573; Australian Pat. Nos. 727539, 746674 and 747901; Canadian Pat. Nos. 1,331,057, 2,302,595 and 2,227,904; Japan Pat. No. 3532780, 3492981; United Kingdom Pat. No. 2238414B; Hong Kong Standard Pat. No. HK1010924; Republic of Singapore Pat. No. 51383, 66959 and 71979; European Pat. Nos. 0 842 463 (96927260.8), 1 010 057 (98903671.0), 1 018 069 (98950708.2); Republic of Korea Pat. Nos. KR201211B1 and KR226206B1. People's Republic of China Pat. Application Nos. 98802801.8, 98809472.X and 96196739.0; Mexico Pat. No. 208141; Russian Federation Pat. No. 2206118; and additional patents are pending worldwide.

T9-word suggestions

If several options are found in the dictionary for a key sequence (a word), the most probable is displayed first. If the word you want has not been recognised, the next suggestion from T9 may be correct.

The word must be shown **highlighted**. Then press

 The displayed word is replaced with a different word. If this word is also incorrect, press again

 Repeat until the correct word is displayed.

If the word you want is not in the dictionary, it can also be written without T9.

To add a word to the dictionary:

 Select.

The last suggestion is deleted and the word may now be entered without T9 support. Press **OK** to add it automatically to the dictionary.

Correcting a word

 Move left or right, word by word, until the required word is **highlighted**.

 Scroll through the T9 word suggestions again.

 Deletes the character to the left of cursor **and** displays a new possible word!

Additional information

Within a "T9-word", individual letters may not be edited without first removing the T9 status. In most cases it is better to rewrite the complete word.



Set a full stop. Word is concluded if it is followed by space. Within a word, full stop represents an apostrophe or hyphen:

e.g. **provider.s** = provider's.



Moving the cursor to the right ends the word.

Input method



Press **briefly**: Switch between: **abc, Abc, T9 abc, T9 Abc, 123**. Status shown in top line of display.

Press and **hold**: All input variants are displayed.

Special characters



Press **briefly**: Select special characters (page 30).

Press and **hold**: Open edit menu (page 31).

Text templates

Text templates are short excerpts of texts that you can insert in your messages (SMS, MMS).

Creating text templates



→ Template

The list of existing templates is displayed.

Options

Open menu and select **New template**.



Write text.

Options

Open menu and select **Save**.

Additional information

If you want to create a new message from the template menu select **Options** **New message**.

Inserting text templates

SMS/MMS:



Write message.

Options

Open menu and select **Insert text**.

Template

Select.



Select a text template from the list and confirm with .

The text template is inserted in the message to the right of the cursor.

Calling

With your phone you can make conventional (voice) calls as well as video calls. However, it is not possible to make a voice call and a video call at the same time.

Video calls

To initiate a video call (in standby mode):



The phone switches to video call mode. A preview is displayed. You can enter a number (see Dialling with number keys).

Or



Enter the number (always with prefix/international dialling code).



Press the video call key.

The phone switches to video call mode.

You can also decide to make a video call **after** you have already entered a number or selected a number from a call list.

Prerequisite

The called party as well as the network have to be capable of handling video calls. If you are calling a number that does not meet these requirements you will be offered the option of making a voice call instead.

Dialling with number keys

The phone must be switched on (standby mode).



Enter the number (always with prefix/international dialling code).

Press the Call key.



Or



Press.

Or



Press the video call key to make a video call.

The displayed number is dialled.

Ending a call



Press the End key **briefly**. Press this key even if the person on the other end of the line has hung up first.

Setting the volume

+/- — Regulate the volume (only possible during a call).

If a Car Kit is used, its volume setting will not affect the usual setting on the phone.

Redialling previous numbers

To enter the **Dialled calls** list (in stand-by mode):

 Press the Call key.

To redial the number last called:

 Press the Call key **again** (not in video call mode).

Or

 Press the video call key to make a video call.

To redial other numbers that were dialled previously:

 Pick out the number from the list.

 Press the Call key (not in video call mode).

Or

 Press the video call key to make a video call.

Additional information

 Press and **hold** to switch microphone off.

International dialling codes

 Press and **hold** until a "+" is displayed.

Number memo

You can enter a number during the call. The person to whom you are speaking can hear these entries. When the connection has ended you can save or dial the number.

Accepting a call

The phone must be switched on. An incoming call is indicated by a special screen:

A number and the name of the caller transmitted by the network will be displayed if the number is saved in the contacts. A picture of the caller may also be displayed (page 42).

If the incoming call is a video call a video of the caller is displayed. However, the transmission of the video may be suppressed by the caller.

 Press.

Or

 Press.

Or

 Press to accept a video call.

If the incoming call is a video call and **Show my image** is deactivated (default, page 125) **Do you want to show your video image?** is displayed. You have the following options:

- Yes** Your video is shown to the caller.
- No** The video mute picture is shown to the caller (**Select image**, page 125).

Rejecting a call

Reject Press.

Or



Press **briefly**.

Warning!

Please make sure you have accepted the call before holding the phone to your ear. This will avoid damage to your hearing from loud ringtones.

Additional information

-  Press and **hold** to switch silent mode on/off.
-  Press and **hold** to switch key lock on/off.
-  Missed call display.

Handsfree talking

You can put the phone aside during a call. You can then hear the caller via the loudspeaker.

Options Open menu.

Speakerphone

Activate/deactivate handsfree talking and confirm with .

Warning!

Always switch off "handsfree talking" before holding the phone to your ear! Otherwise you will damage your hearing!

Additional information

During a video call the speakerphone is activated by default.

Swapping between 2 calls



(not during video calls)

Establish a second connection

You can call another number during a call.



Dial the new number and press . The current call is put on hold.

When the new connection is established you can swap between calls:

Options Open menu and select **Swap**.

Or



Press.

Incoming calls during a call

You may need to register for this service with your service provider and set your phone accordingly. During a call, you may be advised that there is another call waiting. You will hear a special tone during the call (page 123). You have the following options:

Accepting the waiting call in addition to the first

Swap  Accept the waiting call. The current call is put on hold.

To swap between the two calls when two connections are established, always press .

Rejecting the waiting call

Reject Press.

Accepting the waiting call, ending the current call

 End the current call.

 Accept the new call.

Ending calls

 Press the End key **briefly**.

Or

Options Open menu and select **Drop**.

After the **Return to held call?** display, you have the following options:

Yes You accept the held call.

No You end the held call.

Conference



(not during video calls)

Call up to 5 parties one by one and link them together in a multiparty call. Some of the functions described may not be supported by your service provider or may have to be enabled specially.

Once a call has already been established:

Options Open menu and select **Hold call**. The current call is put on hold.



Dial a new number. When the new connection is established ...

Options ... open menu and select **Conference**. The held call is joined.

Repeat procedure until all participants are linked together (up to 5 participants).

Ending a conference

Ending all calls



All calls in the multiparty conversation are ended when the End key is pressed.

Ending one call

Options Open menu and select **Drop**. Then select the call to be ended.

38 Calling

After the **Return to conference call?** display, you have the following options:

Yes You return to the conference.

No You end all calls.

Private call

You can remove a party from a conference and make a private call to that party while the conference is put on hold.

Options Open menu and select **Private**. Then select the entry for the private call.

You can swap between the private call and the conference:

Options Open menu and select **Swap**.

When your private call is finished you have the following options:

 End the private call and return to the conference.

Or

Options Open menu and select **Conference**. The private call is joined to the conference again.

Call options

The following functions are only available during a call:

Options Open menu.

**Mute call/
Mute sound** If switched off, the person on the other end of the line cannot hear you (muting).

Also: Press and **hold**



In video calls your video is still shown on the other end of the line.

**Speaker-
phone** Call via the loudspeaker.

**Upgrade to
vid/Switch to
voice** Change the current voice call to a video call or vice versa. The current call is ended and a new connection with the same partner is established.

**Transf
access'ry/
Transfer
phone** Switch the sound of the current call to the headset and back to the phone.

**Add to
contacts** Select **To a new contact/To exist. contact**. Select number type to store the number in the contacts. Confirm save notification with .

Not during video calls

Hold call Hold current call.

Swap Swap between calls.

Conference (see page 37)

Drop	End a call in a conference.
Private	Make private call in a conference (see page 38).
Transfer	Connect two calls in a conference and disconnect oneself.
DTMF	Enter tone sequences (numbers) for remote inquiries to an answering machine.
Only during video calls	
Mute video	If switched off, the incoming video is muted and the video mute picture is sent (Select image , page 125).
Pause inc./ Pause outg.	Pause the incoming video (of the other party) or outgoing video (yours). The menu entry changes to Resume inc./Resume outg.
Switch camera	Switch between front and rear camera.
Full/split screen	Select the video presentation on your display (see below).

Frame rate	Adjust how many frames per second the camera will capture.
White Balance	Adjust the sensitivity to light.
Flicker Adjustment	Adjust the sensitivity to indoor lightening flicker rate.
Send picture/ Send video	Select a picture/video from My stuff and show it to the person on the other end of the line.

Full/split screen

Select the video presentation on your display. You have the following options:

Them fullscreen

The video of the other party is shown in full screen mode.

Splitscr. -- me sm.

The video of the other party is shown in full screen mode and your video is shown in an additional small frame.

Splitscr. -- me lg.

Your video is shown in full screen mode and the video of the other party is shown in an additional small frame.

Me fullscreen

Your video is shown in full screen mode.

Tone sequences (DTMF)

You can enter control codes (numbers) for remote access to an automatic answering machine **while another connection exists**. These inputs are transmitted directly as DTMF codes (control codes).

Options

Open menu.

DTMF

Select.



Enter digits and confirm with .

Using Contacts

Store numbers **and** control codes (DTMF codes) in Contacts in the same way as a normal entry.



Enter number.



Press until a "+" appears in the display (wait for the connection to be established).



Enter DTMF codes (numbers).



If necessary, wait again for three seconds at a time for the receiver to process the entries safely.



Enter a name.

Save

Store entry.

You may also store just the DTMF codes (numbers) and then send them during the call.

Contacts

You can store contacts with a variety of phone and fax numbers as well as additional address details.

The contacts may contain the following types of entries:

- Contacts saved on the phone (page 42).
- SIM contacts saved on the SIM card (page 44).
- Distribution lists: short-cuts for communication with more than one person. Contacts may belong to several distribution lists (page 46).
- Groups: contact categories (e.g. shared ringtone). A contact can belong only to one group (page 44).



Or



Open Contacts.

For fast access, contacts are organised on 4 tabs.



Switch between tabs.

Contacts	All contacts (including SIM contacts) and distribution lists.
Groups	All groups.
SIM contacts	Contacts saved on the SIM card.
Filter	Apply different filter criteria to all contacts.

Dialling contact



Call selected contact.

Or



Make (video) call.

Or



Press and **hold** to activate voice dialling.

Contact selected

Call the default/video enabled number. If no default number is stored, select which number to call.

SIM contact selected

Call the number. If several numbers are stored, select which number to call.

Several numbers selected

If several contacts or a distribution list is selected:

- The call key  and the video call key  have no effect.

Contacts

All contacts (excluding SIM contacts) are displayed in alphabetical order. Distribution lists and groups are displayed additionally.

Contacts can include 4 numbers, 4 e-mail addresses, 2 URLs, 2 fax numbers and 2 postal addresses. You can set one value as default for each type (page 43).

New entry

<New entry>

 Select.
 Select the number type.
 The possible input fields are organised on 4 tabs:

General info	First and last name, important numbers (private, business, mobile phone).
Private	E-mail address, fax number, address and notes.
Business	Office information and address.
Personal	Audio/video ringtone, picture, group, birthday and display name.

Within the tabs:

 Select input fields.
 Fill in input fields.

At least one name must be entered. The name of each contact must be unique. Always enter the number with prefix.

Assign media files

In some input fields (ringtone, video, picture) you can assign audio/video ringtones and pictures.

 Select media field (e.g. picture) and confirm with .

Depending on the media type you can either record a new media file via camera or sound recorder or select a file from the corresponding **My stuff** folder (page 110).

Additional information

In many situations, you can use the Camera key to open the camera application:

 Start camera application in picture/video mode (depending on the selected field).

Save contact

Options  Open menu and select **Save**. Confirm request with .

 Confirm save notification.

Contact options

Options Open menu.

Set as default	Set selected field as default for that type (e.g. default number or e-mail). Current default is marked with *.
Create e-mail	Send e-mail to selected contact(s).
Switch tab...	Select contact tab for more input fields.
Add birthday/ Remove birthday	If no birthday is entered, open birthday field. If birthday is entered, delete after confirmation.
Set date	If birthday field is selected: Open calendar to currently entered date.

Number field selected

Insert 2-s pause	Insert pause ("P").
Insert wildcard	Insert wildcard ("?"), see below.
Record voice tag	Start recording voice tag (page 48).
Play voice tag	Start playback of current voice tag.
Delete voice tag	Confirm to delete voice tag.

Further options on page 46.

Number extensions in contacts (wildcards)

Digits may be replaced by a "?" (wildcard) when numbers are entered in contacts:

Options Open menu and select **Insert wildcard**.

Or



Press down to insert "?".

These wildcards must be replaced with numbers before dialling (e.g., with the extension numbers in a phone system).

To make a call, select the number from contacts.



Press.



Replace "?" with numbers.



Press. Number is dialled.

Groups

Groups are collections of contacts that can be used to categorise contacts. A group can have the same incoming audio/video call alert. SIM contacts cannot belong to a group, you have to copy them to the phone contacts first.

The following groups have already been created and can be renamed but not deleted: **Family**, **Friends**, **Office**, **VIP**.

New group

You can add personal groups.

<New group>

Select and enter the name of a new group.

Done

Press to confirm.

Add member



Select a group. The number of entries is displayed in the second line when highlighted.

Options

Open menu and select **Add new member**. A list of all contacts that are not already in the group is displayed.



Select new members and confirm with .

Add

Confirm selection.

Edit Group

Options

Open menu and select **Edit**.

You can rename the group and attach an audio ringtone and a picture (page 42).

SIM contacts

Contacts saved on SIM card are managed on this tab. SIM contacts contain less information than contacts saved on the phone.

New entry

<New entry>

Select to create a new entry.



Navigate to input fields.



Fill in input fields: name and up to 3 numbers. Protected SIM contacts provide only one number field.

SIM/Protected SIM

Select storage location. Special SIM cards can save numbers in a protected area (protected SIM) (PIN2 required).



Select available number.

Options

Open menu and select **Save** and confirm request with .



Confirm save notification.

Additional information

If you want to save/edit/delete contacts in the protected SIM area, the PIN2 is required.

Convert SIM contact**Options**

Open menu and select **Add more fields**.

SIM contact is converted to regular contact. You cannot convert protected SIM contacts. Further options on page 46.

Filter

Depending on the selected filter, all contact categories (contacts, SIM contacts, distribution lists and groups) can be listed on the filter tab.

Options

Open menu and select **Filter** and confirm with .

The following filter criteria are available:

- Voice dialling: All contacts are listed that have a voice tag associated with one or more of their numbers.

- Video telephony: Contacts with a video allowed number (page 46) are listed.
- E-mail
- URL
- Birthday
- Stored on phone: all contacts (except SIM contacts)
- Distribution lists



Select criterion and confirm with .

A list is displayed with contacts that contain the chosen feature, e.g. all contacts including a birthday entry.

Remove contact/reset filter

Select contact(s)/list.

Options

Open menu and select **Remove from list/Reset list** and confirm with .

Options menu

Depending on the current situation, different functions will be offered. These functions can be applied to the entry currently selected as well as to multiple selected entries.

Options Open menu.

Distribution lists

New distr. list Enter name. You can rename the distribution list and attach an audio/video ringtone and a picture.

Add to distr. list Add contact of distribution list/group to a new or existing distribution list. If SIM contact is added, confirm request to convert into contact.

Add new member Open contact list. Select contacts and add them to the selected distribution list.

Groups

New group Enter name.

Add to group Add contact(s) to new or existing group. If contact(s) already belong to a group confirm to switch to new group. If SIM contact selected, confirm to move contact to phone memory.

SIM contacts

Add more fields Convert SIM contact to regular contact (not for protected SIM contacts).

Special numbers  Your provider may supply you with special numbers. Select classes you want to show/hide.

Business card

Create biz card Create a business card, which is a contact containing your own contact information.
The business card is displayed outside the sort order at the top of the contact list.

Set as biz card Confirm request. Selected contact is set as business card. If a business card already exists, it is converted to a regular contact. SIM contacts cannot be set as business cards.

Undo biz card Convert selected business card to a regular contact.

Media field selected	
e.g. Play ringtone	Start playback of current ringtone. Same for video and picture.
e.g. Replace ringtone	Select new ringtone. Same for video and picture.
e.g. Remove ringtone	Confirm to delete current ringtone from contacts. Same for video and picture.
General options	
Synchronise	Initiate synchronisation (see below).
Open web site	If contact information contains URL, start the browser and load URL.
Send contact	Send contact as vCard (see below).
Set as vid. allow'd/ Undo vid.allow'd	Only one number of the contact can be set as video allowed. Option is set automatically if you get/initiate a video call from/to that number. Note that this option is not available for SIM contacts.

Save options	Depending on save location, select • copy/move to SIM: Only SIM information is saved. Extended version of the contact is kept. • copy/move to phone. Protected SIM contacts, special numbers and the business card cannot be copied or moved to another save location.
Save location	Select SIM/Phone as default save location.
Duplicate	Open new contact with duplicate information.
Find	Open menu (page 48).
For standard functions see page 24.	

Synchronise

Initiate synchronisation of contacts (page 99).

Additional information

With the Siemens MPM (Mobile Phone Manager, page 138) you can hold your addresses in a Windows® PC and synchronise with the contacts.

Send contact

If you want to send/receive complete contacts, the contact is transmitted as a vCard.

You can send your own/other contacts via Bluetooth, IrDA, SMS, MMS or e-mail.

Receiving vCard

You can receive contacts included in a message or via IrDA/Bluetooth. You can save vCards as contacts:

Options Open menu and select **Save contact** to save vCard as new contact.

Find

To find a contact more easily you can either search for the contact, change the sort order of the contact list or set filter criteria for the list.

Contacts search



Enter text/number and confirm with .

A list is displayed with contacts which contain the text/number sequence.

Sort contacts

The contact list is resorted.



Select sort order and confirm with .

Filter contacts



Select filter criterion (page 45) and confirm with .

Voice-activated dialling

You can dial numbers from the contacts by speaking the name. SIM contacts, distribution lists and groups cannot have a voice tag.

You have to record a voice tag for every number so your phone "recognises" you. To record voice tags you speak the name loudly and clearly into the phone and store it.

You can store about 100 voice tags. You can assign one voice tag to each number of a contact.

Recording a voice tag

Record the voice tag in a quiet environment. You should speak into the phone from a distance of about 25 cm. The voice tag may be 3 sec. long.

Additional information

If you use voice-activated dialling mainly with a handsfree set it is useful to record the voice tag with the handsfree set.



Open the Contacts tab.



Select a contact.



Select number input field.

Options

Open menu and select **Record voice tag**.

Start

Start recording.

A short signal is sounded. An appropriate prompt appears on the display. Speak the name (max. 3 seconds). Repeat the name after playback. A second signal tone is sounded and you are prompted on the display.



Confirm completed recording.

If your two recordings are too different or if they are too similar to an existing voice tag, you will be prompted to repeat recording.

Retry / Restart

Press to start recording again.

If three attempts fail you have to start a new voice tag.

Additional information

If there is not enough memory for a new voice tag, a notification is displayed. Confirm notification, delete existing tags and try again.

Voice-activated dialling

Voice dialling must be enabled (page 126).



Press and **hold**.

Speak the name after the signal tone. If the name matches the saved voice tag the number is dialled.

Call records



The different call information is listed on 5 tabs:

All calls, Dialed calls, Missed calls, Received calls and Time & charges.



Navigate to tabs.

Each list displays the 100 most recent calls.

Call log lists

The number of a caller is displayed if

- the caller has switched off the Hide ID function and
- the network supports the Caller ID function.

Alternatively, a caller's name is displayed if it is stored as a contact.

If the number was not transmitted for the reasons above a message is displayed instead.

Your phone stores the numbers of calls for convenient redialling.

Audio and video calls are stored.

Redial number



Select call log list (e.g. **Missed calls**).



Select entry.



Dial number (if available), make video call.

All calls

Access all missed, dialled and received calls.

Dialled calls

Access last numbers dialled by you.



Fast access in standby mode.

Missed calls



The numbers of calls that you have received but not answered are stored for callback purposes.

Missed calls are displayed in standby mode (page 21). Select entry and confirm with to open missed calls list.

Received calls

Accepted calls are listed.

Call log list menu

Depending on the current situation, different functions will be offered.

Options Open menu.

Call	Dial number (if number is available)
View contact/ Add to Contacts	If number is saved as contact, view contact. If number is not yet saved, create new contact.
Details	Display call type (video/voice call), number, name, time/date and duration of the call.
For standard functions see page 24.	

Note

If the display of costs is disabled or the currency is not entered, cost information is not displayed.

Reset all incoming/outgoing calls lists

View list (see above).

Reset Press to reset the current list.

Yes Confirm reset notification.

Charge settings

Settings Select and confirm with .

Currency

(PIN2 protected)



Enter currency (up to 3 characters).

Options Open menu and select **Save**.

Rate

(PIN2 protected)



Enter per minute rate.

Options Open menu and select **Save**.

Display costs

On/Off Activate/deactivate cost display and confirm with .

Time & charges

You can display the call duration and currency and rate of a call. You can set the currency and rate for charge display.

Last call/All incoming calls/

All outgoing calls

Select list and confirm with .

For the selected call type the following information is displayed: the date/time and the duration and charges. For all incoming and all outgoing calls the number of recorded calls is displayed, too.

Camera

The phone has a front and rear camera (page 11).

You can view photos/videos recorded with the integrated camera immediately:

- Use a picture as background image, logo or screensaver.
- Send picture/video via MMS or e-mail.
- Save pictures/videos on the phone or on the RS MultiMediaCard (page 16).

Start the camera via the main menu:



Or



Press the side key to start the camera in standby mode and from other applications.

Picture mode/Video mode

Select mode and confirm with  / .

The current (preview) image is displayed.

You can also start the camera using the media player or MMS editor.

Displayed information

The following symbols are displayed over the preview:



current brightness setting



current zoom level

Only in picture mode and if active self timer and flash are indicated.

The following memory information is displayed in the bottom right corner of the preview image:

- Memory location: Pictures/videos can be saved either on the phone or on the **RS MultiMediaCard**. To change save location see page 54.
- Remaining memory: Picture count/available record time on the current memory location. The remaining memory depends mainly on the selected resolution and the motif.

Additional information

When video recording is started from the MMS application, the maximum length will be the time allocated for messaging (10 seconds).

The selected resolution is displayed in the top line.

Taking pictures/videos

Settings prior to taking pictures/recording videos



Decrease/increase brightness. Brightness can be set in 7 levels (-3 to +3).



Zoom in/out in 7 levels.

For further settings see options menu.

Taking pictures

Start the camera in picture mode.



Take picture.

Recording videos

Start the camera in video mode.



Start recording. You can record up to 5 minutes.

Pause/Resume

Control recording.

Stop

End recording.

Reviewing pictures/videos



Confirm save notification. The picture/video is displayed.

The picture/video is saved with a name, the date and the time in the **Media player** folder (page 107).



Open view finder to take another picture/record another video.

Or

Discard

Delete picture/video and open view finder.

Additional information

- If available memory is insufficient, confirm warning with and change save location.
- If camera was launched from another application (contacts/messages), press to add picture/video and return to the original application.

Camera options

The following functions are available, depending on the current situation.

Options Open menu.

Record	Start video recording.
New picture/ New video	Open view finder to take another picture/record another video.
Add	Add picture/video to original application (contacts/messages).
Play	Play recorded video.
View pictures/ View videos	Open corresponding My stuff folder (page 110).
Picture mode/Video mode	Switch between picture and video mode.
Switch camera	Switch between front and rear camera.
Message mode	Switch to message mode after confirmation. Message mode is optimised for sending via MMS/Bluetooth: • record time 10 seconds • low resolution Message mode is activated automatically if video mode is started from MMS application.
Audio record	Turn microphone on/off.

Flash Turn flash auto/off (only included if flash accessory is plugged into phone).

Self timer Picture is taken approx. 10 seconds after triggering. For the last 3 seconds, you will hear a signal tone each second.

**Picture settings/
Video settings** Open settings (see below).

For standard functions see page 24.

Picture settings/Video settings

Resolution front/Resolution back

Change Open settings.



Select resolution and confirm with .

A setting can be made for the quality of the picture/video regardless of the preview image resolution.

The resolution setting concerns the current active camera mode. The resolution may decrease depending on the selected digital zoom.

Default name**Change** Open settings.

Enter default file name (up to 4 digits).

Options Open menu and select Save.**Save location****Change** Open settings.**Phone memory/Card**Select default save location and confirm with .**Frame rate (only for video settings)**

Set how many frames per second the video should capture.

Low (7 fps)/High (15 fps)Select and confirm with .**White balance****Change** Open settings.**Auto/Indoor/Outdoor**Select and confirm with .**Flicker adjustment**

Adjust the sensibility to indoor lightening flicker rates.

Off/50 Hz/60 HzSelect and confirm with .**Additional information**Press  to start video call with current camera and current settings.**Flash (Accessories)**

If the flash is active, this is shown by a symbol in the display. The flash is constantly charged while connected to the phone. This reduces the standby time.



While charging, the symbol blinks.

Create message

You can create SMS and MMS messages and e-mails.



Additional information

You will find information on writing texts with and without T9 in the chapter "Text entry" (page 30).

SMS/MMS

About SMS

You can transmit and receive long messages (up to 760 characters) on your phone. They are automatically divided into concatenated SMS messages (note higher charges).

About MMS

The **Multimedia Message Service** (MMS) enables you to send texts, pictures/videos and sounds in a combined message to another mobile phone or to an e-mail address. All elements of an MMS message are merged into a "slide show".

Depending on your phone's settings, you will receive either the complete message automatically or notification that an MMS has been saved in the network, giving sender and size details. You may then download it to your phone to read it.

Ask your service provider whether this service is available. You may need to register for this service separately.

Writing/sending an SMS



Enter text/add items
(see options menu).

Options

Open menu and select
Add recipient (page 59).



Send message.



Confirm.

If the SMS could not be sent successfully, press **Retry**.

Additional information

- The following is displayed in the top display line: text entry mode, number of segments needed to send the current message and number of remaining characters.
- If text is too long for a single SMS, you can choose whether to convert SMS to an MMS or not.

SMS options

Depending on the current situation, different functions will be offered.

Options Open menu.

Add item	Select Picture/Video/Sound. Select file from the corresponding My stuff folder (page 110). Remember that files may be protected (DRM, page 22). If you try to add items that cannot be sent via SMS, message is converted to MMS after confirmation.
Send options	Set Status report/Validity period/SMS type/Send with for current SMS. See also SMS settings (page 70).
Further functions, see page 59.	



→ Create message

→ MMS



Enter text (up to 1024 characters)/add items (see options menu).

Options

Open menu and select **Add recipient** (page 59).



Send message.



Confirm.

If the MMS could not be sent successfully, press **Retry**.

Additional information

The following is displayed in the top display line: text entry mode, number of remaining characters and size of the message.

Writing/sending an MMS

An MMS is composed of slides, each containing text/pictures/sounds or a video.



Navigate MMS slides.

Please note that media files may be protected (DRM, page 22).

58 Create message

MMS options

Depending on the current situation, different functions will be offered.

Options Open menu.

Add item	• Picture/Video/Sound (see SMS options). • Text: add text to current slide. • Contact: select and add as vCard. • Appointment: select and add as vCard.
Add subject	Enter subject.
Preview MMS	Start view mode (see below).
Playback video/ Playback sound	Start Media player and play back video/sound.
Send options	Set Read Report, Set Delivery Report, Validity Period and Priority for current MMS. See also MMS settings (page 72).
Further functions, see page 59.	

View mode

If you start the view mode you can change the presentation of the message.

Options Open menu.

Play again	Start playback of all slides.
Page duration	Select time interval (in sec.), each slide is displayed when presented.
Order page	Select +1/-1 to swap current slide with previous/next.

SMS/MMS options

Depending on the current situation, different functions will be offered.

Options Open menu.

Add recipient	See below.
Edit recipient	Edit entered number/address.
Create item	• Take picture/Record video: start camera in message mode (page 54). You may also press  to start the camera. • Record sound: start dictating machine (page 98).
Insert text	• Template (page 33). • Contact Details: open contact and select contact information. • Bookmark: open browser and select bookmark (page 92).
Save as	Select Draft (page 69)/ Template (page 33). If memory is insufficient: • SMS: confirm request if you want to delete messages from Inbox. • MMS: confirm request if you want to upload MMS to the media album .
e.g. Remove picture	Remove picture/video/sound/contact/appointment or recipient from message.
For standard functions see page 24.	

Add recipient

After at least one recipient is added, the To: field is displayed. You can add multiple recipients.

Enter number/address or select contact:

Add frm Contacts

Select and confirm with  to open contacts.



Select contact(s)/distribution list(s) and confirm with .

If you select a contact with more than one respective entry (e.g. several numbers), the possible entries are displayed in a second line when contact is highlighted:



Select entry you want to use.

E-mail

Your phone has an e-mail program (client). You can use it to create and receive e-mails.

If you enter the e-mail editor from another application, eg. the Inbox, all used input fields (To:, CC:, Bcc:, Subject:, Attachment) are displayed.

Additional information

If the cursor is at the top of the text entry, you can navigate the input fields with  / .

Writing/sending e-mails



→ Create message
→ E-mail



Enter text/add items
(see options menu).

Options

Open menu and
select **Add recipient**
(see options menu).



Send message. The send-
ing progress is displayed.

Additional information

If you send a new e-mail, e-mails from the draft folder will be sent as well. The progress is displayed in terms of either the number of bytes or the number of e-mails.

E-mail options

Depending on the current situation, different functions will be offered.

Options Open menu.

Add recipient	• Add frm Contacts: Open contacts (page 42). • Enter e-mail addr.: Enter address manually.
Edit recipient	Edit entered address.
Add subject	Enter subject.
Edit subject	Edit subject.
Attach item	• From My stuff: Select any file (also unknown type). • From Contacts: Select contact and add as vCard. • From Calendar: Select Appointment and add as vCard. Name and size of the attachment is displayed.
Add Cc	Add contact(s) of copy recipient(s). See also Add recipient .
Add Bcc	Add contact(s) of copy recipient(s) (See also Add recipient). Bcc recipients are not visible for other recipients.
e.g. Remove item	Remove highlighted attachment/recipient.
Save as draft	Confirm request to save e-mail in draft folder (page 69).

Add signature	Add signature at the end of the text.
----------------------	---------------------------------------

Send options	Set Req. deliv. receipt; Request read receipt; Priority: for current e-mail. See also e-mail settings (page 73).
---------------------	--

For standard functions see page 24.

Inbox

The inbox contains all MMS, SMS, CB, e-mail and WAP push messages received on the phone.



Or

Inbox

Press and **hold**.

Receiving messages

SMS

If a new SMS is received a notification is displayed. New messages are saved in the Inbox automatically.

View

Press if you want to read new message immediately.

Or

Ignore

Press if you want to open message via the Inbox later.

MMS

An MMS is received in two steps: First the MMS notification, then the MMS.

If a new MMS message is available for downloading, the MMS notification is displayed including number/contact and subject of the MMS. You can download the MMS immediately or later:

Yes

Press if you want to download MMS immediately. The download progress is displayed.

Or

No

Press if you want to download later. The notification is saved in the Inbox.

When download is completed, a notification is displayed (see SMS section).

CB

Some service providers offer information services (**Cell Broadcast Service**). If reception is activated (page 77), your provider will supply you with messages on the activated topics.

When the function is activated (page 77), CB messages are received automatically. Depending on the current setting, CB messages are displayed in standby mode (page 21).

Only one CB of the same type is saved. If another message is received, it overwrites the older one.

E-mail

E-mails are not received automatically. Before an e-mail can be read, it must be retrieved from the server (page 65).

WAP push

WAP push messages are provided by special service centres. Depending on the current setting (page 91) WAP push messages are received/rejected automatically or you are prompted to accept/reject when WAP push is received.

If you receive the message that a software update is available, you can start a DM session (page 127).

Inbox structure

For fast access, the inbox is organised on three tabs:

- MMS, SMS, CB
- E-mail
- WAP push messages

If the inbox contains a new message a symbol is displayed in standby mode (page 21). If you open the inbox in this case, you directly access the message folder containing the new message.

If the message is highlighted, two lines are displayed:

- The first line contains the number or the respective contact and the time or date the message was received. An icon indicates the message type.
- In the second line either the beginning of the message or the subject is displayed.

Additional information

Make a call: Select SMS, MMS or e-mail and press .

SMS, MMS, CB

All new messages are shown in chronological order.



Select message and confirm with .

Numbers, bookmarks, e-mail addresses, vCards and other saveable objects are highlighted automatically.

Additional information



Set volume.



Switch sound on/off.

Only MMS:



Navigate within a slide.



Switch to next/previous slide. On first/last page switch to last/first page.



Play media file.

Options menu

Depending on the current situation, different functions will be offered.

Options Open menu.

View	Read SMS, MMS, MMS Notification or CB.
Downld message	Download MMS if MMS notification is received.
Reply/Reply to all	Select SMS/MMS and create message.
Forward	Forward Message to another recipient. • SMS: Select SMS/MMS. • CB: Create SMS. • MMS: Select MMS. If you forward as SMS, attached media files are removed automatically.
Mark as unread	Display message in bold type.
Add to Contacts	Save as contact (page 67).
For standard functions see page 24.	

Additional information

- SMS messages may be stored on the phone memory or on the SIM card. The storage location is indicated with an icon.
- You can activate the option to have the oldest SMS message in the inbox automatically deleted when a new message arrives (page 71).

Read options menu

Depending on the current situation, different functions will be offered.

Options Open menu.

View	Start view mode (page 58).
Send	CB: If e-mail address is highlighted select MMS/E-mail .
Send MMS	MMS: If e-mail address is highlighted create new MMS.
Open link	If URL is highlighted: Start browser (page 89).
Save link	If URL is highlighted: Start browser and add URL to bookmarks (page 92).
Play again	MMS: Start playback video/audio slide.
e.g. Save sound	Select To phone/To card as save location. Downloaded file is saved in corresponding My stuff folder (page 110). Same for picture, text and attachment.
Call number	If number is highlighted: Dial number.
Save appoint.	If calendar object is selected: Save calendar event (page 98).
For standard functions see page 24.	

Downloading ringtones and logos

You can receive links for downloading ringtones, logos, screensavers, animations and information about applications with an SMS. Highlight this link and, by pressing the Call key , start the download. Please check that the dial-in access is configured.

Remember that ringtones/logos may be protected (DRM, page 22).

E-mail

If more than one account is configured, the list of accounts is displayed (page 75).

Before an e-mail can be read, it must be retrieved from the server. The e-mail application is blocked until download is completed.

The listed files and the options menu vary depending on the receive server type (page 75) of the selected account.

POP3 account

The inbox on the phone contains all the e-mails that are in the inbox on the POP3 server.

You can configure whether or not an e-mail is deleted on the server when deleted on the phone (page 76).

IMAP4 account

The inbox lists e-mails as well as subscribed folders (e.g. mailboxes). You can subscribe to various folders on the IMAP4 server. E-mails are retrieved only from the subscribed folders.

If you delete e-mails on the phone they are deleted on the server automatically.

E-mail options menu

Depending on the current situation, different functions will be offered.

Options Open menu.

View	If only headers are retrieved, retrieve body and display e-mail.
Retrieve e-mail	Retrieve new e-mail for selected account (page 66).
Retrieve all accts	Retrieve new e-mail headers for all configured accounts.
Account settings	Open account settings for highlighted account (page 75). If no account is configured create new account.
Reply/ Reply to all	Create new e-mail.
Forward	Forward e-mail to another recipient.

Add to Contacts	Save as contact (page 67).
Only POP3 account	
Delete on server	Delete e-mail on server only. The local copy is retained.
Only IMAP4 account	
Subscr. to folders	(page 66)
Move to folder	(page 66)
Unsubscribe	E-mail within the folder is deleted on the phone only. The synchronisation of e-mails to server is stopped.
Display order	Select Folders first/ E-mail first.
For standard functions see page 24.	

Additional information

You can set the max. size of downloaded e-mails (page 74).

Retrieve e-mail

Depending on the download mode (page 76), either entire e-mails or only the headers are retrieved, or you may be asked whether the entire e-mail or only the header should be downloaded. The number of retrieved e-mails is displayed.

Additional information

IMAP4 accounts: only e-mails in the subscribed folders are retrieved.

Subscr. to folders

(only IMAP4 accounts)

You have to subscribe to folders on the receive server in order to retrieve e-mail from these folders.

All subscribed and unsubscribed folders on the receive server are listed. Only two levels of folders are supported.



Select folder(s) and confirm with  to subscribe/unsubscribe to folders.

Options

Open menu and select **Subscr. to marked**.

Move to folder

You can move e-mails from one subscribed folder to another. The move is synchronised with the server the next time you retrieve e-mails.



Select e-mail(s) you want to move.

Options

Open menu and select **Move to folder**. The subscribed folders are listed.



Select folder and confirm with **Move**.

Read options menu

Depending on the current situation, different functions will be offered.

Options Open menu.

Voice call/ Video call	Start voice/video call to sender (if number available).
Go to URL	If e-mail address is highlighted: create new e-mail.
View/ Download	View/play attachment. If not downloaded download attachment.
Delete on phone	Delete downloaded attachment on phone. POP3 account: the attachment is deleted permanently on phone and cannot be downloaded again.
Go to URL	If URL is highlighted: Start browser and load URL (page 89).
Save as bookmark	If URL is highlighted: Start Browser and add URL to bookmarks (page 92).
Save	Select To phone / To card as save location. Downloaded file is saved in corresponding My stuff folder (page 110). Selected vCard is saved as contact. Selected calendar object saved as calendar event.
For standard functions see page 24	

Add to Contacts

You can add contacts received via SMS, MMS or e-mail.

You can add the following contact details:

- contact details of the sender
- contact details (e.g. number, e-mail address) included in the message as contact (page 41).
- vCard: contact included in a message.

Save sender/contact details

Contact details included in a message are displayed in the **highlighted** text. Numbers can be dialled immediately (☎).

Options Open menu and select **Add to Contacts**.

To exist. contact

Select and confirm with .

Or

To a new contact

Select and confirm with . Select number/address type (e.g. private number) and confirm with .

 Press to confirm save notification.

Save vCard

Options Open menu and select **Save contact**.

 Press to confirm save notification.

WAP push

The following messages are displayed:

- Service Indication (SI)
- Audio, video, image, text
- Service loading

Reading WAP push message



Select desired message and confirm with .

Read messages/information about received data/software. Where required start download.

Service loading message

You are connected to the browser and the service is downloaded automatically. Otherwise you are asked whether you want to download the service or not.



Press to open server and load service.

DM request

If the pushed operation causes initial configuration of the handset and provisioning of application settings, the device manager is started (page 127). A notification is displayed:



Press to carry out action.

Message lists

Messages are displayed the same as in the inbox (page 62). The most recently edited/sent message is displayed at the top of the list.

Drafts



The list is organised on two tabs: SMS/MMS and e-mail.

You can save a message as a draft while creating it. Messages are saved as drafts automatically

- if transmission fails, or
- you start another application while creating a message (e.g. you accept an incoming call).

Additional information

E-mails are not sorted by configured accounts. Draft e-mails are not synchronised with the server.

Draft options

Depending on the current situation, different functions will be offered.



Select message.

Options

Open menu.

Edit

Edit Message.

Send

Send directly without editing (at least one recipient is added).

For standard functions see page 24.

Sent messages



The list contains all sent messages and is organised on two tabs: SMS/MMS and e-mail.

Send options

Depending on the current situation, different functions will be offered.



Select message.

Options

Open menu.

View

Read message.

Voice call/
Video call

Start voice/video call to sender (if number available).

Forward

- E-mail: Create e-mail and send it.
- SMS/MMS: Select **SMS/MMS** (menu depends on selected message type). Create message and send it.

For standard functions see page 24.

Message settings

You can configure SMS, MMS, e-mails, cell broadcast (CB), voice mail and instant messages.

SMS settings

 →  → Message settings
→ SMS → Select function.

SMS profiles

The SMS parameters are configured in up to 5 different profiles. Profiles can be renamed, edited and set as default.

Setting default profile

If profile is already configured:

 Select profile and press  to set profile as default.

Edit profile

 Select profile and press **Edit** to open editor.

 Select option (see table).

Select Press to edit option, confirm setting with .

The following options are displayed:

Message centre	Enter number of message centre.
Recipient	You can set a default recipient for the profile. Select Add fr. contacts and select contact/distribution list or enter number.
Validity period	Select Maximum/1 week/1 day/12 hours/1 hour . If SMS could not be delivered during this period, it is deleted from message centre automatically.
Status report	Select On/Off/Ask on send . A status report is sent when a message is delivered successfully. If Ask on send is activated, a prompt is displayed when SMS is sent.
Send confirmation	Select On/Off/Ask on send to set whether or not a confirmation for successfully sent messages is displayed.
SMS access	Select GSM/GPRS .
SMS memory	Select Phone/SIM as default save location for incoming SMS.
SMS type 	Select delivery type.

Reset profile



Select profile.

Options

Open menu and select
Restore to default.

Yes

Confirm request.

The SMS profile is reset to an unconfigured state. If your provider has locked a predefined profile, it cannot be reset.

Auto header

If the function is activated the Header template is automatically inserted at the start of any created SMS.

On/Off Activate/deactivate and confirm with

Auto signature

If the function is activated, the Signature template is automatically inserted at the end of any created SMS.

On/Off Activate/deactivate and confirm with

Autosave sent

If the function is activated, all sent SMS messages are saved automatically in the Sent folder (page 69).

On/Off Activate/deactivate and confirm with

Auto SMS delete

If the function is activated, the oldest SMS message in the Inbox will be deleted upon arrival of a new SMS message.

On/Off Activate/deactivate and confirm with

Emoticons

Emoticons are little symbols (Smilies) expressing your feelings. If the function is activated, emoticons are automatically displayed as little pictures.

On/Off Activate/deactivate and confirm with

Text size

You can set the displayed size of the text in the SMS Viewer.

Small/Standard/Large

Select size and confirm with

Additional information

The message sent notification is displayed, when an SMS is transmitted successfully to the SMS centre. The centre forwards the SMS to the recipient.

If the message was not transmitted to the SMS centre, you can retry once. If transmission fails again, contact your service provider.

MMS settings

 →  → Message settings
→ MMS → Select function.

MMS profiles

The MMS parameters are configured in up to 5 different profiles. Profiles can be renamed, edited and set as default. You will receive the necessary data from your service provider or via the "Setting Configurator" (page 140).

Setting default profile

If profile is already configured:

 Select profile and press  to set profile as default.

Edit profile

 Select profile and press **Edit** to open editor.

 Select option and edit settings.

The following options are displayed:

Name	Enter profile name.
Connect. profile:	Select profile (page 120).
Internet profile:	Select profile (page 121).
Relayserver URL:	Enter Internet address.
Secure rs URL:	Enter Internet address.

Reset profile

 Select profile.

Options Open menu and select **Restore to default**.

Yes Confirm request.

The MMS profile is reset to an unconfigured state. If your provider has locked a predefined profile, it cannot be reset.

Home retrieval/Roaming retrieval

You can configure when new MMS messages are to be downloaded from the message server for Home and Roaming retrieval.

The following settings are possible:

Automatic	Messages are automatically downloaded as soon as an MMS notification is received.
Always ask	When an MMS notification is received, you are asked whether to download it or not.
Restricted	(only for Home state) When an MMS notification is received, only the notification is displayed.

 Select option and confirm with .

Creation mode

You can restrict the content that can be added to an MMS.

The following settings are possible:

Free	You can add any content to the MMS.
Warning	You are warned when attempting to add content to an MMS that cannot be sent.
Restricted	If you attempt to add content that is not compliant (see above) an error message is displayed.



Select option and confirm with .

Req. read report

If the function is activated a report is sent back when the recipient reads the MMS message for the first time.

Yes/No Activate/deactivate function and confirm with .

Req. deliv report

If the function is activated a report is sent back when the recipient has downloaded the MMS message.

Yes/No Activate/deactivate function and confirm with .

Delivery time

Select how long an MMS message should be held on the server before sending it to the recipient.

Immediate/7 days

Select and confirm with .

Validity period

If an MMS message could not be delivered during this period, it is deleted from the server automatically.

Maximum/1 week/2 days/1 day

Select and confirm with .

Hide number

If the function is activated your number is withheld from the recipient.

Yes/No Activate/deactivate function and confirm with .

Anon. messages

If set to **Reject**, anonymous MMS messages are rejected automatically.

Accept/Reject

Select and confirm with .

Allow read report



If the function is activated, requested read reports are enabled.

Yes/No Activate/deactivate function and confirm with .

Allow deliv report

If the function is activated, requested delivery reports are enabled.

Yes/No Activate/deactivate function and confirm with .

Auto signature

See SMS settings page 71.

Autosave sent

See SMS settings page 71.

Allow adverts

If the function is deactivated MMS-based advertisements are automatically rejected.

Yes/No Activate/deactivate function and confirm with .

Emoticons

See SMS settings page 71.

Text size

See SMS settings page 71.

Max msg size

The size restriction affects downloaded and created MMS messages.

95 kb/195 kb/Network max

Select and confirm with .

E-mail settings

Before using this service you must set the server access and your e-mail parameters. You will receive the necessary data from the service provider or via the "Setting Configurator" (page 140).

The e-mail parameters are configured in up to 5 different accounts. One account might be predefined by your provider. You cannot edit predefined accounts. You can activate, edit or rename accounts.

Additional information

Forwarded and answered e-mails use the account that was used to receive the original e-mail.

 →  → Message settings
→ E-mail → Select function.

Activating an account

If account is already configured:

 Select account and press  to activate.

Deleting an account



Select account.

Options

Open menu and select Delete.

Yes

Confirm warning request.

Additional information

All e-mails in the Inbox, the Drafts and the Sent folders and all attachments belonging to the deleted account are deleted.

Editing an account

The account settings are grouped in the following areas: User Info, Connection Info and Message preference. Additionally you can add/create a signature.

Edit the account according to the information from your provider.



Select account.

Options

Open menu and select Edit.

User info/Connection info/

Msg preferences/Add signature/

Create signature

Select and press **Change** (see below).



Navigate to input fields.



Open/close input fields.

User info

You can edit the following fields:

Your name:	Your name.
E-mail address:	Your e-mail address (name@domain.abc)
Reply-to address:	Additional e-mail address to use for replies.
User ID:	Your login name for the e-mail server.
Password:	Your password for the e-mail server.

Connection info

You can configure accounts with two different receive server types: POP3 and IMAP4. The configured accounts may have different server types.

You can edit the following fields:

Data service provider:	Select connection profile (page 120).
Receive server type:	Select POP3/IMAP4.
POP3 server:	If you want to use a POP3 server, enter the Internet address of the receive server or leave the input field empty.
POP3 server port:	Enter the port number of the POP3 receive server (default: 110).

POP3 uses SSL/TLS:	Select Yes/No to activate/deactivate encryption in communication with the POP3 server.
IMAP4 server:	If you want to use an IMAP4 server, enter the Internet address of the receive server or leave the input field empty.
IMAP4 server port:	Enter the port number of the IMAP4 receive server (default: 143).
IMAP4 uses SSL/TLS:	Select Yes/No to activate/deactivate encryption for communication with the IMAP4 server.
SMTP server:	Enter the Internet address of the send server.
SMTP server port:	Enter port number of send server (default: 25).
SMTP uses SSL/TLS:	Select Yes/No to activate/deactivate encryption in communication with the send server.
SMTP authenticate:	Select Yes/No to activate/deactivate authentication on the send server.
SMTP password:	A user password will be required if "Authentication" is set to Yes . Enter password.

Msg preferences

You can edit the following fields:

Download mode:	Select Only headers/ All e-mails/Ask user .
Max msg size (KB):	Enter maximum e-mail size that is retrieved on the phone (in KB).
Leave copy on server:	(Only POP3 accounts) Select Yes/No . If No is selected, the e-mail is deleted on the server when it has been downloaded to the phone.
When delete phone:	(Only POP3 accounts) Select Delete on serv./ Leave on srver . If Delete on serv. is selected, the e-mail is deleted on the server when it is deleted on the phone. IMAP4 accounts always delete e-mail on server when deleted on phone.
Save sent message:	Select Yes/No to save a copy of the sent e-mails in the local Sent folder (page 69). To save sent e-mails on server you should set your own address as CC.
Include orig on reply:	Select Yes/No to include the original text in the reply message or not.
Req. deliv. receipt:	Select Yes/No .
Request read receipt:	Select Yes/No .

Add signature

Select **No e-mail/**
New e-mail/All e-mails and
confirm with

Create signature

The signature may span multiple
lines.



Enter signature and
confirm with

CB settings

- → Message settings
→ Cell broadcast
→ Select function.

Rec. broadcasts

You can activate and deactivate the
CB service. If the CB service is activat-
ed, the standby time for the phone
will be reduced.

On/Off Select and confirm
with .

Cell info display

You can select whether or not the
local cell information should be
displayed in standby mode.

On/Off Select and confirm
with .

Topic list

You can configure the types of
broadcast messages you want to re-
ceive. The list of configured topics
is displayed. You can add/remove
topics.

Options Open menu.

Topic status	Select • Receive: New messag- es are received and stored in the Inbox. No notification is dis- played. • Receive and notify: New messages are re- ceived and stored in the Inbox. A notification is displayed in standby mode (page 62). • Do not receive: Messages on this topic are rejected.
Add topic by list	Select topic (e.g. News) from list.
Add topic: index	Enter topic index number.
Remove topic	Delete list entry.

Inst. message settings

- → Message settings
→ Instant messaging

Open Inst. message settings
(page 85).

Instant messaging



This function allows text-based conversation with one or more users who are also registered for this service. This function is not offered by all service providers. Please refer to your service provider for further information.

Your dialogue partners are entered in the contact lists. When a connection has been established, these lists show who is available, whether they want to be disturbed and what mood they are in.

Logging in/out

You have to login to Instant message application. If you are logged in, you are online.



Symbol is displayed in top line of display if you are online.

Symbol is changed to  if a new message or an invitation is received.

Manual login

When you start Instant message and the phone is not connected to server, you are asked to login.

Your service provider supplies you with your account information.

User ID: Enter your user name for Instant message service.



Switch to next line.

Password: Enter password for Instant message service.



Press to establish a connection to server. The account information is saved.

If connection is established successfully and no Alias has been entered yet a notification is displayed.



Confirm to enter Alias.

Alias: Enter name that should be displayed in the conversation window for the other user to see, and confirm with . Alias is saved automatically.

Additional information

- The saved account information is displayed when you start Instant message again. You can edit information.
- If you are already online, login and alias are not requested when you start Instant message.

Auto login

If auto login is activated (page 87), the phone uses saved account information (see above) to establish a connection to the server when the phone is powered on.

Log out

Options Open menu and select Exit.

Yes Press to confirm log off request.

Instant message in offline state

If you are offline, a new instant message or a conversation invitation is sent either via SMS or via WAP push message (page 62).

The messages are stored on the server temporarily.

If you want to join the conversation you have to start the Instant message application and log in. The info message is displayed as soon as you are online (page 82).

Tabs overview

When you are online the following tabs are displayed:

- **Online contacts**
- **Conversations**
- **Contacts**
- **Info messages**

Online contacts

This is a filtered list of all Instant message contacts that are currently online.

The icon indicates the availability:

- Green: Contact is available
- Yellow: Contact is busy.

When a contact is highlighted, the text of the user is displayed in the second line. An icon is displayed, if the user is added to the private list.

Conversations

Active (group) conversations are listed. Up to 5 conversations can be active at the same time.

New conversations are listed as soon as you receive an invitation message (page 81). To start, end and view conversations see page 81.

Contacts

Instant message contacts are stored within the Instant message application and on the Instant message server. To create a new Instant message contact you may browse the contacts application.

Availability is indicated in the same way as in the online contacts list (see above).

80 Instant messaging

Add new contact

You can enter either a mobile number or the Instant message ID.

<Add new contact>

Select and confirm with .



Navigate to input fields.

Nickname: Enter name (optional).

Select: Select **Phone number:/ Messenger ID:.**

Entry: Enter number/ID.

Options Open menu and select **Save.**

Additional information

To browse the contacts application press **Options** and select **Contacts.**

Find new users

Options Open menu and select **Find new users.**



Enter **Screen name:/ Messenger ID:/Phone number:** as search criteria.

Options Open menu and select **Search.**

The results are listed by screen name.

Options Open menu and select **New search** to configure new search criteria.

Authorisation message

If the user you want to add to your contact list has privacy settings (page 86), the presence is not available immediately. A request is sent to the user. If the user confirms the request an authorisation message is sent. Presence is displayed.

As long as presence cannot be displayed, the contact is not listed in the online contacts (page 79).

Info messages

Info messages can be authorisation messages or server messages (e.g. knock service messages if availability of a user changes, page 86).

Info messages are stored automatically if you ignore an info message or if you are offline.

Starting/viewing/ending conversations

Instant messages are exchanged between users in ongoing conversations. You can join up to 5 conversations. Active conversations are listed on the **Conversations** tab (page 79).

Start conversation

You can initiate a new conversation from any tab within the Instant message application.

Options Open menu and select **Start conversation**.



Enter text
(up to 500 digits).

Options Open menu and select **Send**.

- If a single contact is selected, message is sent directly.
- If several contacts are selected or if you invite additional users to an ongoing conversation (page 82), a conversation request is sent to each user. The invited users have to accept the request in order to join the conversation. If user accepts, message is sent. If user rejects invitation, you receive a reject notification.
- If no contact is selected, the Invite contact option is started automatically (page 82).

A notification message is sent if the user is currently offline. Depending on your provider, sent messages may be stored on the server until the user logs in.

Open text input field

During a conversation you can open the input field by pressing  or any key  - .

Additional information

- If you do not enter text for about 3 seconds, the input field disappears. Already entered text is saved and displayed when you open the input field the next time.
- You cannot switch between conversations while the input field is open.

View convers.

Options Open menu and select **View convers.**

Each ongoing conversation is displayed on its own tab. The name of the contact/group the conversation is with is displayed as the conversation title.

The date/time of the conversation is displayed once at the top. The dialogue is displayed including pictures/URLs. Numbers, Bookmarks, vCard and other saveable objects are highlighted automatically. Sent messages are marked with <, incoming messages are marked with >.



Scroll conversation dialogue.

Press and **hold**: Accelerate scrolling.



Navigate to conversation tabs.

82 Instant messaging

View conversation options menu

Depending on the current situation, different functions will be offered.

Options Open menu.

Dial	If number is highlighted: Dial number.
Send e-mail	If e-mail address is highlighted: Create e-mail.
Open link	If URL is highlighted: Start browser and load URL (page 89).
Add bookmark	If URL is highlighted: Start browser and add URL to bookmarks (page 92).
Enter text	Open text input field.
Insert emoticons	Select emoticon.
Invite contacts	Select contact (page 82).
Participants	List of users currently participating in the conversation is displayed (see below).
Next call/Previous convers.	Switch between conversation tabs.
Further options on page 84.	

Invite contacts

During an ongoing conversation or at the start of a new conversation you may invite contacts to join in.

Options Open menu and select **Invite contacts**. All contacts are displayed. The availability is indicated (page 79).



Select contact(s) and confirm with **OK** to start conversation with selected contacts (page 79).

End conversations

Options Open menu and select **End conversation**. The conversation is closed.

Receiving conversations

Alerts

An information alert is displayed when you receive a new message or a conversation request (page 81).

Additional information

- If alerts are activated, the information is also displayed when Instant message is not open but you are online.
- If you already have 5 ongoing conversations a notification for incoming messages or invitations is displayed. If you want to join a new conversation you have to end an ongoing conversation first.

Receive message

View Press if you want to view the conversation immediately (page 81).

Or

Ignore Press if you want to view conversation later.

Receive invitation message

Accept Press if you want to join the conversation.

Or

Reject Press if you want to reject the invitation.

Receive authorisation request

Depending on your setting (page 86) you may receive a notification if a user attempts to save your contact data.

Authorise

Options Open menu and select **Authorise & add** if the user should be able to add your contact details.

If the user is not saved as a contact, the contact is saved automatically.

Block

Options Open menu and select **Block contact** if the user should not be able to add your contact details.

The user is added to the Block list (page 86) automatically.

Delete notification

Options Open menu and select **Delete message**.

The user is not able to add your contact details but is not added to the block list.

Unknown user

If you receive a message from a user who is not saved in your contacts, a notification is displayed. The contact is added to your contact list automatically when you accept the conversation or answer the message. You can also add unknown users to the block list (page 86).

Inst. message options menu

Depending on the current situation, different functions will be offered. These functions can be applied to the entry currently selected as well as to multiple selected entries.

Options Open menu.

Start conversation	Start conversation with selected contact(s) (page 81).
End conversation	- Initial message: Reject request. - Ongoing conversation: End conversation.
View convers.	Display conversation tab (page 79).
Online stat. data	Display presence details (name, status, text, logo and mood) of the highlighted contact.
Contact details	Display Instant message details of the highlighted contact (Name, Instant message ID, Mobile number and knock alert status). Press Edit to open editor (page 80).
Add to contacts	Confirm safety prompt to add user to contacts (page 79). If the warning message should not be displayed again, select Options Don't show again.

Add to private list	Confirm notification. User is added to private list (page 86).
Add to block list	Confirm notification. User is blocked (page 86).
My online status	Set presence attributes (see below).
Settings	Open Settings menu (see below).
Standard functions see page 24.	

My online status

You can configure your online status, text, logo, mood and access your privacy settings via the options menu.



Navigate to input fields.

Online status:

Select **Available/Busy**.

My text:

Enter text.

My menu

Press  to select logo (see below).

My mood:

Select mood.

Options

Open menu and select **Save**.

Select Logo

You can either set a logo from My Stuff or enter a URL pointing to an image to display as logo. The maximum size for a logo is 2 KB with maximum resolution 100x60 pixel.

If a logo is already set, it is displayed.

Options Open menu.

Insert image	Select file from My stuff folder (page 110).
Insert link	Enter Internet address.
Clear Logo	Remove Logo.

Privacy settings

You can configure whether or not the attributes in **My online status** are private. Possible privacy states:

- **Public:** all Instant message users that are not on the block list can see attributes.
- **Private:** only contacts on your private list can see the presence attributes.
- **Hidden:** No user can see attributes.

Options Open menu and select **Privacy**.



Navigate to input fields.

Online status:/My text:/

My menu/My mood:

Select privacy state (see above) for presence attributes and confirm with .

Additional information

If you set **Online status:** to **Hidden**, all other attributes are hidden as well and cannot be edited.

Settings

My details

Alias: Select and open editor with **Edit**. Enter/edit alias (page 78) and confirm with .

Messenger ID

Depending on your provider you may not be able to change the Instant message ID. If you want to edit the ID, you will have to log out and enter the new ID during manual login (page 78).

Watcher list

All remote users are listed who have you on their contact list. Note that the list also contains users you have already blocked.

Private list

All remote users are listed who can see your private presence attributes (page 84).

If you want notify the server that a contact no longer has access to your private presence attributes:

Options Open menu and select
Del. from priv. list.

Block list

All remote users are listed who are blocked from contacting you.

Remove user from block list:

Options Open menu and select
Unblock.

Add notifications

You can configure whether or not other users have open access to your presence information. Other users may need your authorisation to add your ID to their contact list.

**Receive notific'n/
No notification/Auth. required**
Select and confirm
with .

Alerts

You can configure whether a notification is displayed when you receive new messages while Instant message is not open and you are online.

When you are in the Instant message application, new message prompts are always displayed.

If **Knock service** is enabled, you will be notified when a contact's availability status changes from offline or busy to available.



Navigate to input fields.

Convers. requests

Select **On/Off** to activate/
deactivate alert.

Info messages

Select **On/Off** to activate/
deactivate alert.

Knock service

Select **On/Off** to configure
alert.

Options Open menu and select
Save.

Sounds

You can switch sounds on/off. The settings directly correlate to the ring-tone settings (page 114).



Navigate to input fields.

Receiving msgs

Select **On/Off** to activate/deactivate alert for new received messages.

Sending messages

Select **On/Off** to activate/deactivate alert for sent messages.

Alert messages

Select **On/Off** to activate/deactivate alert for all notifications including knock alerts.

Options

Open menu and select **Save**.

Server

You can configure the server you use for Instant Messages. Depending on your provider you may not be able to edit the server data.

Changes will take effect after logging out and logging in again.



Navigate to input fields.

Server:

Enter IP address or domain.

Port:

Enter number of the communication port, e.g. 80.

Connect. profile:/Internet profile:

Select profile (page 120).

Auto login: Select **On startup/Off** to activate/deactivate auto login.

Options

Open menu and select **Save**.

Display data services:

Options

Open menu and select **Data services**.

Voice mail



Most service providers supply you with a mailbox in which a caller can leave a voice mail for you if

- your phone is switched off or not ready to receive,
- you do not want to answer,
- you are making a phone call (and if **Call waiting** (page 123) is not activated).

If the voice mail service is not part of your service provider's standard package, you will need to register for it, and possibly set the voice mail manually. The following sequence may vary from service provider to service provider.

Settings

 →  → **Voicemail**

If number is not yet entered:

Yes Confirm request to open input field.

Or open editor via main menu:

 →  → **Message settings**
→ **Voicemail**

Voicemail no.:

 Enter number and confirm with .

Notification

You can activate and deactivate display of a message notifying of new voice mail entries.

On/Off Select and confirm with .

The service provider supplies you with two numbers:

Save mailbox number

You call this number to listen to the voice mails left for you.

 /  Select number from contacts or enter/change it and confirm with .

Save call divert number

Calls are diverted to this number.

 Enter number.

Or

 Open menu and select **Mailbox**. Adopt number or enter if necessary.

Listening to messages

A new voice message may be announced as:

- Icon plus beep or
- Notification via SMS or
- You receive a call with an automatic announcement.

Call your mailbox and play the message(s) back.

 Press and **hold** (if necessary enter mailbox) and confirm.

Internet



→  → Select function.

Or



Press the key to start the browser.

Get the latest information from the Internet that is specifically adapted to the display options of your phone. In addition, you can download games and applications to your phone. Internet access may require registration with the service provider.

The browser is activated with the preset option as soon as you call up the function. Browser settings (page 89) may be specified/pre-assigned by the service provider.

Enter URL



Enter URL.



Open menu and select Go.

Start the browser and display the entered Internet site.

Changing the prefix



Open menu and select Prefix.



Enter URL prefix (e.g. http://).

Bookmarks list

Display the list of bookmarks stored in the phone.



Select the bookmark and confirm with  to call up URL.

History

Display the list of most recently visited Internet domains and pages. Up to 10 domains and 30 pages per domain can be stored.



Select the history entry.



Call up the URL.

Standard functions see page 24.

Browser settings

Change the settings of the browser.



Select one of following functions:

Multimedia

Choose whether or not to download images, sounds or objects embedded on the Internet pages.



Navigate to functions.

Images

Select **Show images/**
Don't show.

Sounds

Select **Play sounds/**
Don't play.

90 Internet

Objects Select Dwnld objects/
Don't dwnld.

Options Open menu and select
Save.

Look and feel

 Navigate to functions.

Font size Select Small/Medium/Large.

Text wrap Select Char. bounds./Word
bounds..

Scroll step
Select Single line/Half page/
Whole page. Set the incre-
ment by which pages are
scrolled when navigating
within the Internet page.

Connection timeout
Set the maximum wait
time for the web re-
sponse. Select 30 seconds/
60 seconds/No timeout.

Title region
Set whether or not to
show title region of
phone when browsing.
Select Show/Don't show.

Options Open menu and select
Save.

Security

 Navigate to functions.

Secure prompt

Select Yes/No. Display a
security request when
leaving a page with se-
cure connection to enter a
page that is non-secure.

ID cache Select Enable service/
Disable service. Set wheth-
er or not the browser
should store your user ID
and password.

Cookies Select Enabled/Disabled
to activate/deactivate
cookies.

Link referral

Allow the current page to
see previous URL. Select
Allow/Do not allow.

Certificates

Display the list of stored certificates.

Current

Display the current certificate
information.

Certificate List

 Select certificate.

 Display the selected cer-
tificate information, e.g.
serial number, algorithm,
validity period.

Options Open menu and select
Enable/Disable for the
highlighted certificate.

WAP push

You can accept or reject message requests from trusted and untrusted sources. If **Ask first** is set, you can decide for each message request whether or not the content should be loaded.



Navigate to functions.

Trusted content/Untrusted content

Select **Fetch content/Ignore/Ask first**.

Lockout time

Enter lockout time (in seconds) and confirm with .

Options

Open menu and select **Save**.

Browser profiles

You can choose one of 5 browser profiles. A browser profile is a super-set of an Internet profile, a connection profile, a startpage URL and the show/hide title region setting.

The current browser profile is marked.

Activate profile



Select profile and confirm with .

Edit profile

Options

Open menu and select **Edit**.



Navigate to input fields.

Navi

Enter profile name.

Internet profile/Connection profile

Select profile (page 121).

Start page

Set current URL as start-page for the profile.

Options

Open menu and select **Save**.

Browser options

Options Open menu.

Go	Load entered URL.
Prefix	Change URL prefix.
Home	Call up the pre-set homepage for the current profile.
Bookmarks list	Display the list of stored bookmarks.
Add bookmark	Edit bookmarks. Enter name and address and select whether to save the bookmark for offline browsing.
Update bookmark	(only if offline bookmark) Reload bookmark.
Enter URL	Enter the URL for direct dial to an Internet address.
Save items	Show the list of items (images/sounds) of current page. Select Save from options menu. Select save location and save selected item in My stuff folder (page 110).
History	Display recently visited pages (page 89).
Forward	Load the following page in the current session, if there is one.
Reload page	Reload the current page.

Send link	Display the URL of the current page for sending via SMS/MMS/e-mail.
Privacy	Clear cache, Clear cookies or Clear history and confirm with  .
Set as startpage	Set the current page as browser startpage and confirm with  .
Settings	Open browser settings (page 89).
For standard functions see page 24.	

Ending a connection



Press to end the connection and close the browser.

Navigation in the browser



- Select a link.
- Settings, status on/off.

Back



Press to go back a page.



- One input field/link forward/back.
- Scroll one line.

Tab through active content (links on page).

Entering special characters



Select special characters.

The Internet browser is under licence of:



OPENWAVE™



Download

Downloads are offered on the Internet. Once downloaded, the content is available to you on the phone.

There are 3 categories of downloads:

- Web browsing.
- Open Mobile Alliance (OMA): Download of the media content that has associated digital rights. Normally you have to pay for the content. The Browser interacts with the DRM (page 22) while downloading.
- Java applications are decrypted and processed by the Java Application Manager (JAM). When you start the download, JAM is started automatically (see below).

Additional information

- To start the browser, see page 89.
- If you quit the browser while downloading: Confirm request if you would like to continue downloading in the background.
- When the download is completed, you can either continue browsing or use the downloaded content via the Options menu (e.g. set picture as wallpaper, play sound/video).
- Downloaded content is listed in the corresponding folder in **My stuff** (page 110).

Java Application Manager (JAM)

Display the list of Java applications currently available on the phone and manage those applications.



Select application.



Open menu.

Depending on the application selected, different options are available:

Select	Open the selected link.
Launch	Launch the selected application, that has been fully installed.
Open suite	Select MIDlet application from the MIDlet suite.
Move	Move the MIDlet application to another folder.
Attributes	Display the MIDlet application information, e.g.name/version.
Security	Edit the security settings of the MIDlet application (see page 94).
Download	Download and install the application, if JAR file has not been downloaded.
Reinstall	Download and reinstall the MIDlet application (update).
Java settings	Select connection and Internet profile (see page 94).
For standard functions see page 24.	

94 Internet

Security



Navigate to input fields.

Application is:

Select **Trusted/Untrusted**.

Send/rec. message:/Internet access:

Select the security permission for the application.

Available settings are:

Allow always/Ask at start/

Ask each time/Never Allow.

Java settings



Navigate to input fields.

Connection profile:

Select profile (page 120).

Proxy deactive:

You can configure whether or not the JAM should use the Internet profile when opening an http connection. Select **Yes/No**.

Internet profile:

(only if **Proxy deactive**: is **No**) Select profile (page 121).

Options

Open menu and select **Save**.

Additional information

You can use the browser to download applications (e.g. ringtones, games, pictures, animations) from the Internet.

Siemens excludes all warranty and liability claims in respect of or in connection with any applications subsequently installed by the customer and any software not included in the original delivery package. This also applies to functions enabled subsequently at the customer's instigation. The purchaser bears sole risk for the loss of, damage to, and any defects arising in, this device or the applications and for any direct damage or consequential damage of whatever nature resulting from the use of this application. For technical reasons, such applications and subsequent enabling of certain functions are lost in the event of the device being replaced/re-supplied and may be lost if it is repaired. In such cases, the buyer is required to download or enable the application again.

Please ensure that your phone has Digital Rights Management (DRM) so that downloaded applications are protected from unauthorised reproduction. These applications are then exclusively intended for your phone and cannot be transferred from this even to create a backup. Siemens offers no warranty or guarantee nor does it accept any liability for the customer's ability to download or enable applications again or to do so free of charge. We recommend that you carry out a backup from time to time of the applications on your Windows® PC using the "Mobile Phone Manager" (www.siemens.com/sxg75).

Games



Games are offered on the Internet. You can download games to the phone (page 93). Once downloaded, these are available to you via the phone.

Some games are already pre-installed on your phone. You will find these listed here:

www.siemens.com/sxg75

Organiser

Calendar



You can enter events in the calendar. The time and date must be set for the calendar to work correctly.

AM/PM or 24 h display depends on your settings (page 130).

The calendar offers you 3 views: daily, weekly and monthly. When you switch the view, the current hour/day/week is marked.

Daily view

Display events of the current day. You can scroll from 12 AM to 11 PM. A vertical line indicates the event duration.



One day forward/back.



One hour forward/back.



Edit/New event (page 98).

Additional information

Birthdays are displayed with subject "Birthday" in a single hour slot at the day start time (page 97). If a birthday event is highlighted, press to open the contact.

Weekly view

Events are shown as vertical bars of different colours on the horizontal hour division. The first 2 upcoming events for the current day are displayed below the calendar.



One day forward/back or one week forward/back if Monday or Saturday is highlighted.



Forward/back one hour through the day.



Display daily view for highlighted day.

Monthly view

Events are shown as a horizontal line at the bottom of the day slot. Week numbers are displayed in the first column. The first 2 upcoming events for the current day are displayed below the calendar.



One day forward/back or one month forward/back if first or last day is highlighted.



One row up/down or one month forward/back if first or last row is highlighted.



Display daily view for highlighted day.

Calendar options

Depending on the current view different functions are offered.

Options Open menu.

Delete event	Non-repeating event: Confirm with Yes . Repeating event: Select One / All occurrences.
e.g. Daily view	Switch to the daily/weekly/ monthly view.
Go to date	Enter the date and confirm.
Synchro- nise	Initiate the synchronisation of the calendar (page 99).
Settings	Open the calendar settings (see below).
Delete events	Delete all events of the day/ week/month. Confirm with Yes . If there are repeating events, only the current event is deleted.

For standard functions see page 24.

Settings

Options Open menu and select
Settings.



Navigate to functions.

Default repeat

Set the default repeat state for newly created events.



Select the required time
frame and confirm
with .

Possible settings are: **Never, Daily, Weekly, Monthly, Yearly**

Default alarm mode

Set the default alarm state for newly created events.



Select the required time
span before the event
and confirm with .

Possible settings are: **1 day before, 1 hour before, 30 mins before, 15 mins before, 5 mins before, 1 min before, Never.**

Additional information

To set the ringtone see page 114.

Day start time

Set the time displayed on the first
line in the daily/weekly view.



Select time and confirm
with .

New event/Edit event

Events are displayed in all calendar views. Overlapping events are displayed in parallel as different vertical bars.

Options Open menu and select
New event/Edit event.

Additional information

If you edit a repeating event, select whether you want to save changes to the highlighted event or to all occurrences: Press **One** or **All**.



Navigate to input fields.

Subject: Enter description of event
(max. one line).

Start date:/Start time:
Select the date/time when
event starts.

End date:/End time:
Select the date/time when
event ends.

Alarm:/Repeat:
Default setting is selected
(page 97). You can
change the alarm/repeat
for the current event.

Done Save the event.

Information on the alarm

When the set date and time of the event are reached an audio and a visual alarm occur.

Snooze Select the snooze option.
Reset the alarm for
10 minutes.

Off Disable the alarm.

Launch the calendar and
display the event.

Additional information

An alarm sounds even when the phone is switched off. The phone does not go to standby mode. To deactivate it press any key.

Dictat. machine

→ → Dictat. machine

Use the function to record short
memos.

- Use your phone as a dictating machine when on the move.
- Record a memo as a reminder or as a note for others.

To start/play back recording see
sound recorder (page 105).

Memos are saved in .amr format in
sound the folder (page 110).

Time zones

→ → Time zones

You can select the time zone in the
world map or the city list (page 130).

Remote sync

 →  → Remote sync
→ Select function.

You can use this function remotely to access externally filed data (addresses, calendar) and synchronise these with the data on your phone. The data can, for example, be saved on a company computer or on the Internet.

www.siemens-mobile.com/syncml

Additional information

If you receive a update request via WAP push (page 68), you have to confirm the update to initiate it.

Remote sync

You can configure up to 5 profiles for remote synchronisation. Before you start the synchronisation, check **Active profile**, **Sync mode** and **Apps to synchronise** (page 100).

Initiate the synchronisation. The computer is selected and synchronisation started. When completed, the actions which have been performed are displayed.

Additional information

If an error message is displayed, correct respective settings.

Active profile



Select profile you want to use for synchronisation and confirm with .

Edit profile



Select profile.

Options

Open menu and select **Edit profile**.



Navigate to input fields.

Provider: Select a service provider.

URL: Enter the URL that points to SyncML server, e.g.:
//path.to/syncmlserver

Port: Enter the port number to connect with the SyncML server, e.g. 80.

Username: Enter your login name.

Password: Enter your password (shown as a series of asterisks).

Cont.database:

Enter the path to the contact database on the synchronisation server.

Cal. database:

Enter the path to the calendar database on the synchronisation server.

HTTP authent.:

Enable/disable HTTP authentication.
Select **No/Yes**.

100 Organiser

HTTP username:

Enter your user name
when HTTP authent.:
is active.

HTTP passwd:

Enter your password
when HTTP authent.: is ac-
tive (shown as a series of
asterisks).

Restore defaults

Options Open menu and select
Restore defaults.

Sync mode



Navigate to input fields.

Data to sync:

Select whether **All data** or
only **Modified data** is to
be transferred during
synchronisation.

Sync direction:

Select the direction in
which synchronisation is
to occur. Possible
settings: **Two-way**,
Mob.overwrite,
Serv.overwrite

Options Open menu and select
Save to confirm.

Apps to synchronise



Check/Uncheck highlight-
ed item. Select the data
type: **Contacts**, **Calendar** or
both.

Done

Press to confirm.

Sync log

Display a summary of the latest syn-
chronisation. The log indicates
whether the synchronisation at-
tempt was successful, e.g. date, time
and details about the synchronised
application.

Additional information

For original Siemens Accessories, e.g.
Data Cable, see page 149. During the syn-
chronisation all applications are locked.

Extras

My menu

Create your own menu with frequently used functions, phone numbers from the contact list or applications. The list of 10 entries is preset. You can, however, change it as you wish.

Using



Select an entry.



Confirm.

Or



If the selected entry is a phone number, you can also call it with the call key.

Change menu

You can replace each entry with another entry from the selection list.



Select an entry.

Change

Press to open the function list.



Select the **new** entry from the list.



Confirm to save the entry.

If **<None>** is selected, the assignment is cleared from the list.

If **Assign shortcut** is selected, the contacts list is opened. Select a contact. If the contacts list is empty, select **Initialising...** to create a new contact.

SIM toolkit (optional)



→ SIM toolkit

Your service provider may offer special applications such as mobile banking, share prices, etc. via the SIM card.

If you have such a SIM card, the SIM services will appear in the main menu under "Extras" or directly above the softkey (on the left).



Symbol for SIM services.

Where there are several applications, these are displayed in a SIM services menu. With the SIM services menu, your phone can support future additions in your service provider's user package. For further information, please contact your service provider.

Alarm clock



The alarm clock can be set for each day of the week separately.

Set alarm



Select day of the week.



Options Open menu and select Set alarm.



Select time (hh:mm).



Options Open menu and select **Save**. The saved alarm is activated automatically.

Additional information

The alarm will ring with the set melody and volume, page 114.

End alarm

The alarm will ring at the set time, even when the ringtone or the phone is switched off.

Snooze Stop the alarm tone, and reset it for 10 minutes.

The original time of the alarm is not changed. If the phone was off when the alarm rang, it will turn off again, but power itself up after 10 minutes for the next alarm.

Or



End alarm.

The alarm remains active and will occur at the same time in one week.

Additional information



Display in standby mode: alarm clock is turned on.

Apply every day



Open menu and select Apply every day.

Options alarm clock



Open menu.

Set alarm Edit currently highlighted alarm and save it (see above).

Turn on/ Turn off If alarm is off, turn is on and vice versa.

Apply every day Use the time of the highlighted alarm for every day of the week.

For standard functions see page 24.

FM radio

 →  → FM radio

To use the radio function, the stereo headset must be connected to the phone.

If no stereo headset is connected when the radio is started or while the radio is active, a message to this effect is displayed. Connect headset or press **OK** to return to the main menu.

Additional information

- Volume is set by pressing the volume keys +/- (page 11).
- An incoming call or messages interrupts the radio application. The radio starts playing again after you reject or end the incoming call.

Selecting a radio station

You can either select a frequency, scan for radio stations or select a radio station from the preset list.

Selecting frequency or scanning



Press **briefly**: Go up/down one frequency.

Press and **hold**: Start scan mode to search for reachable radio stations. Confirm radio station with **OK** to end scan mode.

Selecting from preset list

Options

Open menu and select **Preset stations**.



Select station 1–10 from the list and confirm with **OK**.

You can also enter the preset number:



Press **briefly**.

Adding a radio station to preset list

You can add the current radio station to the preset list.



Press and **hold**.

Or

Options

Open menu.

Add to presets

Select and confirm with . The first unassigned preset number is pre-selected. Press  if you want to change preset number.

Select

Press softkey and confirm with **OK**.

To overwrite a preset number, select a number which is already assigned.

FM radio options

Options Open menu.

Preset stations	Open list of preset radio stations.
Add to presets	Add current radio station to preset list.
Speakerphone	Press Change to turn speakerphone on/off.
Auto store	Start automatic search for the 10 strongest radio stations and stores them in the preset list.
Mono mode	Press Change to turn mono audio mode on/off.

Basic functions

+, -, *, /	Basic calculator types
=	Result
1/x	Reversion
%	Convert to percentage
.	Decimal point
±	Sign change "+"/ "-"

Options Expansion of the range of functions:

$\sqrt{x}$	Square root
x²	Square
e	Exponent
MS	Save displayed number
MR	Call up saved number
M+	Insert number from memory

Calculator

 →  → Calculator

The calculator can be used in a basic version and with an advanced range of functions. The input line and two calculation lines (including the matrix with the calculation functions) are located in the top display half.

-  Enter digit(s).
-  /  Navigate to functions.
-  Select function.
-  Enter digit(s).
-  Use function. The result is calculated and displayed immediately.

Unit converter

 →  → Unit converter

You can convert various amounts into other units.

Converting the units/currency

-  Select the source unit/currency.
-  Switch to the input field.
-  Enter the quantity to be converted.
-  Switch to the selection field.
-  Select the target amount/currency. The result is displayed.

You can use both input fields alternately.



Opens the calculator with the current converted value.

Special key functions:



Set decimal point.



Change sign.

Currency

When you call up the function, you must enter a basic currency into which the conversions are to be made.



Enter currency (e.g. euro).



Store entry.

Enter the name and the exchange rate of the currency to be converted.

Sound recorder



→ **Sound recorder**

Use the sound recorder to record noises and tones for use as ring tones. Tone recording is normally started by other applications/functions such as the "Media Player".

New recording

Record new

Select.

If a MultiMediaCard is inserted (page 17), select save location:

Phone memory/Card

Select default save location and confirm with

The remaining recording time as well as the available time are displayed.



Press to start recording. A brief tone sounds when the recording starts.



Pause/record alternately.

Done

End recording.

The recording is saved in a file in .wav format with a time stamp in the sounds folder (page 110).

If the sound recorder was started from another application, e.g. Media Player, you return to that state automatically.

Additional information

- A brief tone sounds when the remaining time available is less than 5 sec.
- If available memory is insufficient, recording is not started. If phone runs out of memory during recording, recording stops. An corresponding message is displayed.

Playback



Select recording.



Playback/pause, alternately.



Stop playback.

For volume settings and additional options see media player (page 107).

Stopwatch



→ ★ → Stopwatch

Use the stopwatch to measure time or to save intermediate times.



Start/Stop/Restart.



When stopwatch is running: Switch to lap mode.

After a stop:



Reset time to zero.

Lap mode

While the stopwatch is running, the lap mode is available (see above). In lap mode, a lap is counted as the time between subsequent key presses.

The stopwatch continues to run and is displayed above the laps.



Save lap time.



Start/Stop/Restart stopwatch.

After a stop:



Reset lap times to zero.

99 laps can be saved. The last 6 laps are displayed.

Additional information



Stop and exit application.



Exit application, but stopwatch continues to run.

Media player



Or



Press to launch the Media player.

When you view a picture/video or listen to a melody, the application (e.g. Camera, Messages, My stuff) starts the media player automatically.

The media player functions are accessible via 4 tabs: **Music**, **Pictures**, **Videos** and **Bookmarks**.



Select tab.

The media player contains files stored on the phone memory as well as files stored on the **RS MultiMediaCard** (those files are marked).

Additional information

An incoming call puts playback in the background automatically (page 27).

Music

The music tab includes, for example, MP3 and AAC files. For fast access, the tracks are sorted by the following categories:

- **Playlists:** Display configured/new playlists (page 108).
- **Recent:** Display the 20 most recently played tracks (up to 25).
- **All:** Display all saved tracks sorted by track name.

Playback



Select track/playlist (page 108) and confirm with

The playback is started. At the end of the track, the next track in the list/playlist is played automatically.

Additional information

If playback was started from another application, e.g. My Stuff, playback stops at the end of the track.

The media player offers the following functions for music playback:



Playback/Pause depending on current state.



Press **briefly**: Skip to previous/next track.

Press and **hold**: Rewind/fast forward within the current track (not within live stream).



Press **briefly**: Raise/decrease volume by one level.

Press and **hold**: Set volume to maximum/minimum.

Create new playlist

You can order several tracks in playlists.

Playlists Select category on the top level of the music tab and confirm with .

<New playlist>

Select and confirm with .



Enter name and confirm with .

Add files to playlist via the options menu (page 109).

Pictures

All files are listed with thumbnail, file name and size.

Display picture



Select file and confirm with .

The following functions can be applied to a displayed picture:



Zoom picture (see below).  /  navigate within the picture in zoom mode



Skip to previous/next picture in the directory.

If started from another application, e.g. MMS, skip to previous/next picture of that folder.



Switch full screen mode and normal view.

Videos



Select file and confirm with .

The media player offers the following functions for video playback:



Playback/Pause depending on current state.



(Not within live stream.)
Rewind/Fast forward if supported.

For volume settings, see music playback (page 107).

Bookmarks

The Bookmarks tab shows a listing of up to 30 streaming content links on the phone and **RS MultiMediaCard**. Each URL must correspond to a single online audio/video file. These bookmarks are not listed as browser bookmarks.

The first line of each item is the name of the bookmark. When selected, a second line with the URL/path to the online content is displayed.



Select bookmark and confirm with . Start Playback music/video directly from bookmark (live stream).

Music/Video is downloaded. To ensure a continuous playback, the data is buffered on the phone. The playback starts about 5 seconds after the connection was established. The

buffer progress is displayed before and during playback.

For volume settings, see music playback (page 107).

Media Player options

Different functions are offered depending on the starting situation and the selected object.

Options Open menu.

Music file selected

Add to playlist Open list of all tracks. Select track(s) you want to add, press **Options** to open menu and select **Done**. Select new/existing playlist. The highlighted tracks are added.

Remove tracks Delete track from playlist.

Change order Select move option depending on current position of the track.

Picture file selected

Zoom in/Zoom out Zoom picture.

Fit to screen If picture is zoomed, return to original sizing.

Slideshow Start automatic flow through pictures of current folder. Jump to next/previous picture manually with navigation key. Slide show ends when all pictures in the folder are viewed. End manually with softkey.

Further functions

Play/Pause Playback/Pause current file.

Full screen Enter full screen mode.

Open from Select file from **My stuff/History** (see below).

Create new

- **Photo/Video:** Start camera (page 54). You may also press  to start the camera.
- **Sound:** Start Sound recorder (page 105).

Set as bookmark Add to bookmarks list.

For standard functions see page 24.

History

You can access a history comprising the last 10 files opened regardless of their type and their storage location (e.g. **RS MultiMediaCard**, online). Streaming data is also included. If you try to open a file which has been deleted already, an error message is displayed.

My stuff

To organise your files, you can use the file system like a PC file manager. There are some folders in **My stuff** for various data types for this purpose. If, for example, you want to download new pictures or sounds, the download function is contained in the relevant folder.

Remember that pictures and sounds may be protected (DRM, page 22).

You can open **My stuff** either from other applications, e.g. media player, messages, settings or via the main menu:



If **RS MultiMediaCard** is inserted (page 16), folders/files are organised on a separate tab. Files are managed the same way as files saved on the phone.



Select tab (phone memory/**RS MultiMediaCard**). List of folders/files is displayed.



Select folder/file or link and confirm with .

Back

Go back to previous folder level.

Depending on your selection, the file and respective application are opened, or the download is started.

Index structure

Files are organised in folders. Some folders have already been created for different data types. These folders cannot be changed: **Sounds**, **Pictures**, **Videos**, **Misc**.

The phone memory tab has, additionally, the folders **Themes**, **Games** and **Appl.**. When selected, the number of entries is displayed.

The content of the fixed folders is filtered. The folders contain special media types (see table page 111). Files that do not fit in another folder are listed in **Misc**.

You can add personal folders on the top level as well as subfolders. Personal folders are displayed behind the default folders.

Personal folders on the top level can contain mixed media types. Personal folders can be renamed and deleted.

Within fixed folders you can add personal subfolders, which are restricted to the media type of the fixed folder.

Additional information

When you enter **My stuff** from other applications, e.g. messages, to open/send file with a specific media type, the respective fixed folder is opened. In that mode you can select files of the same type stored in personal folders or in the media album via links from fixed folders.

Folder	Content/Options	Formats (e.g.)
Sounds	Melodies, records • New entry: Start sound recorder (page 105).	mp3, aac, aac+, aac+, m3u, mid, amr, wav, real audio 8/9
Pictures	Pictures • New entry: Start camera in picture mode	bmp, jpg, jpeg, png, gif
Videos	Videos • New entry: Start camera in picture mode	3gp, H263, MPEG4
Themes	Load theme (packed) Theme configuration (unpacked) • select theme to activate it.	*
Games	Launch Java Application Manager (page 93).	jar, jad

Appl.	Launch Java Application Manager (page 93) and display list of saved applications, e.g. Mobile Navigation (page 112).	*
Misc.	Files of media types that are not included in other folders, e.g. text modules, internet pages. If you try to open a file of unknown type an error message is displayed.	e.g. html, wml

Depending on your provider the structure, content and functionality may differ.

Options

The following functions are available, depending on the current situation.

Options Open menu.

View/Play	Start Media player and view/play selected file.
New folder	Create new folder on the current level and name it.
Search	Open file search dialogue (see below).
Move/Copy	Place highlighted file(s)/ folder(s) in temporary memory. Move: delete selection in the originating folder. Copy: duplicate selection in the destination folder. If a DRM protected file is selected, the copy/move option is not available.
Paste	Transfer content of temporary memory into current folder. If you paste content to another top level folder, only folders are displayed which accept this media type. Note that protected items cannot be transferred to the RS MultiMediaCard (DRM, page 22).
Assign to contact	Assign media file as ring-tone, picture or video caller ID to a contact.
For standard functions see page 24.	

File search

For easy file search you can enter several criteria: name, file type and date of creation.

Options Open menu and select Search.



Navigate to input fields.



Enter file name.



Select file type.



Open date editor. Enter number and select range in next line.

Search results are displayed in list.
The symbol shows the save location.

Mobile Navigation

With this navigation service you use the latest satellite and communication technology to reach your destination conveniently, quickly and safely.

You are guided by clear maps and arrows plus voice directions. The built-in GPS receiver determines your current position. This information, plus details of your destination, are used to calculate the route for you.

At the same time, the central navigation computer makes use of currently available traffic information and real time traffic data.

Settings

Profiles



Several settings can be stored in a phone profile, for example to adapt the phone to the surrounding level of noise.

- 6 standard profiles are provided with default settings: **General**, **Silent**, **Meeting**, **Outdoor**, **Car kit**, **Headset**. You can edit the default settings.
- You can set and rename 2 personal profiles (**User profile 1** and **User profile 2**).

Additional Information

- Bluetooth Car Kits do not support profiles, e.g. General, Silent, Meeting, Outdoor, Car kit, Headset.
- If you change settings when not in the profile menu, changes are not saved in the current selected profile.

Activating a profile



Select a default profile or a personal profile.



Activate profile.

Profile settings

Edit a default profile or create a new personal profile:



Select profile.

Options

Open menu and select **Change settings**.

The list of available settings is displayed. For details see corresponding menu descriptions.

When you have finished setting one function, you return to the profile menu and can change further settings.

Additional Information

In standby mode: Press **briefly** to display Profile list.

Profile options

Options

Open menu.

Activate/Deactivate

Activate/deactivate selected profile.

Change settings

Change profile settings.

Return to default

Enter phone code (page 28) and confirm with **Yes** to set profile settings to default.

Copy from

Copy settings from another profile. Select profile whose settings you want to copy and confirm with .

Headset

The special profile **Headset** is automatically set when an original Siemens headset is attached (see also accessories, page 149).

Ringtones

 →  → Ringtones

Volume

Set the tones on the phone to suit your requirements. The volume setting controls the volume of the ringtone as well as the general volume level of beeps and tones played by different applications. The volume setting does not affect the media player or the FM radio.

You can set the volume in 5 Levels or switch ringtones off.

 Set volume and confirm with .

While editing the volume level, the currently set level is played.

Voice calls/Video calls/Calendar/Alarm clock

Select function and set melody and tone for each function separately.

Melody

Select a sound file to use as ringtone.

 Select melody from **My stuff** folder (page 110) and confirm with **Select**.

Tone

Depending on the selected function, the following options will be offered:

On/Off	Activate/deactivate melody specified above. You cannot turn off the alarm clock tone.
Beep	Set ringtone to beep.
Ascending	Set ringtone to melody with ascending volume.

Additional information

Please make sure you have accepted the call before holding the phone to your ear. This will avoid damage to your hearing from loud ringtones.

Messaging

Melody

Melody settings on see above.

SMS & MMS tone/CBS alert tone/E-mail tone

Set alert tone used for the different types of messages.

Tone settings on see above.

Inst.msg sounds/Game sounds/Startup sound/Shutdown sound

Set pre-defined sound effect for the selected function.

On/Off Activate/deactivate tone and confirm with .

Themes



Load a completely new user interface in your phone. With the press of a key, various functions are re-organised based on a theme, e.g.

- switch on/off animation
- switch on/off melody
- additional animations

Theme files are packed to save memory space. After a download (page 93) or a call from **My stuff** (page 110), themes are automatically unzipped when activated.

In addition to the automatic exchange of theme parameters (e.g. switch on/off animation), you will have to manually set parameters such as Logo, Screensaver.

Additional information

When you select a theme all the components of the theme apply to the phone, e.g. ringtones, wallpaper. The existing settings might be overwritten.

Activating a theme



Select theme and confirm with .

If you delete an active theme, some used elements are reset to default.

Display



Set Wallpaper/Logo

You can set pictures separately for following functions:

Wallpaper

Background image used on standby display.

Logo

Graphic to be displayed instead of the provider logo.

Set Wallpaper/Logo

Wallpaper/Logo

Select and confirm with .



Select file from corresponding folder in **My stuff** (page 110) and confirm with **Select**.

Change Wallpaper/Logo

Options

Open menu and select **Change**.



Select file and confirm with **Select**.

Screensaver

Picture displayed when a time period specified by you has elapsed. An incoming callor pressing any key will end the function unless the safety function is activated.



Navigate to input fields.

Style: Select style.

Picture: If style **Picture:** is selected: Select file from corresponding folder in **My stuff** (page 110).

Timeout: Select standby time before screensaver is shown.

Code protection:

Activate/deactivate prompt to turn off an active screensaver. Select **On/Off**. If you activate the prompt, you must enter the phone code to turn off the screensaver

Auto key lock

Activate/deactivate function to automatically lock the keys when screensaver is active. Select **On/Off**.

Warning!

When the screensaver is manually set,

- the talk/standby time is reduced dramatically
- the screensaver can cause irreversible display burn-in effects.

Additional information

The screensaver is not activated during a voice call, IrDA or Bluetooth session, while the camera application is active or during video playback.

Set animation

You can set animations for startup and shutdown of the phone. The animation is determined by the currently active theme (page 115).

Startup animation

Animation displayed when phone is switched on.

Shutdown anim.

Animation displayed when phone is switched off.

Activate/deactivate animation

Startup animation/Shutdown anim.

Select and confirm with .

On/Off

Activate/deactivate animation and confirm with .

Greeting message

Set a message to be displayed instead of an animation when phone is switched on.



Enter greeting
(up to 2 lines).

Backlight time

Set the backlight duration for the display.



Select time and confirm
with .

Brightness

Set the brightness level for the display.



Decrease/increase brightness and confirm with .

Power save

Set the time when the display goes into power save mode automatically.

After 1 minute/After 5 minutes/

After 10 minutes/Never

Select time and confirm
with .

Vibration (silent alert)



Vibration

To avoid the disturbance caused by a ringing phone, you can activate the silent alert function as an alternative. The silent alert can also be activated in addition to the ringtone (e.g. in noisy environments).

Additional information

Vibration is deactivated when the battery is being charged and accessories are connected (except the headset).

Vibration

Select the vibration pattern.

*Off/Standard/Helicopter/UFO/
Shock/Mosquito/Train*

Select vibration and
confirm with .

Connectivity



IrDA

Your phone has an infrared interface. With this interface, you can exchange data such as pictures, ringtones, contacts, business cards or organiser data with other appliances which also have an infrared interface.

The infrared interface is on the left side of the phone. The distance between the two devices must not exceed 30 cm. The infrared windows in both appliances must be aligned as accurately as possible with each other.

IrDA active

On/Off Activate/deactivate the infrared interface and confirm with .

If IrDA (Infrared) is activated, Bluetooth is deactivated and vice versa.

Shown on display:

 IrDA activated.

 During transmission.

File location

Select where the files are to be stored after being transferred via IrDA.

Phone/MultiMediaCard

Select and confirm with .

Bluetooth® (BT)

Bluetooth is a short-range radio connection by means of which a headset or car kit or such can be connected without the need for wires.

Using the **Send** function in the options menu for the application concerned you can also use this route to send data.

Each Bluetooth device has its own specific address and can be given a self-explanatory name as an option. Password protection ensures the security of a Bluetooth connection, as does including the BT partner in a list of "confidential" devices.

To establish a Bluetooth connection between your phone and other Bluetooth devices you must activate the function.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Siemens is under license. Other trademarks and trade names are those of their respective owners. Bluetooth QDID (Qualified Design ID): B02421

Bluetooth active

On/Off Activate/deactivate Bluetooth and confirm with .

If Bluetooth is activated, IrDA (Infrared) is deactivated and vice versa.

Bluetooth reduces the phone's standby time if it is activated.

Shown on the display:

-  Bluetooth activated.
-  Bluetooth visible to other users.
-  During transmission.
-  Call on Bluetooth device accepted.

File location

Select where the files are to be stored after being transferred via Bluetooth.

Phone/MultiMediaCard

Select and confirm with .

Search

Search for specific categories of devices or for all Bluetooth devices.

All devices/Audio/Phone/PC

Select and confirm with  to start search.

Found devices are displayed in a list (for list options see page 120).

If **Audio** is selected Headsets, Car kit and audio or video devices are listed.

Known devices

Display the list of known devices.

Last connected

Display the list of last 10 connected devices, including those that are currently connected.

My BT name

Display device address. Enter the device name that is shown to other BT devices when they request this (see Bluetooth visibility).



Enter BT name for your phone (up to 16 characters) and confirm with .

If no name is entered, the device address is shown to other BT users (the device address cannot be changed).

Bluetooth visibility

The device address/name is shown or not to other BT devices if they request this in order to receive or send data.



Select one of the following options and confirm with .

On/Off	Activate/deactivate visibility.
Auto	Set visibility for 5 minutes, then visibility is disabled automatically.

List options

Depending on the current list (known or last connected), different functions will be offered.



Select device from list.

Options

Open menu.

Trust/ Do not trust	Enter the password to trust the device or remove trust option of device. Trusted devices are added to the known list automatically and do not require the password to connect.
View details	Display the device details: Name: , Device type: and Address: .
Add to known list	Add the device to the known list.
New search	Start a new search.

GPRS

(General Packet Radio Service)

GPRS can be enabled or disabled depending on your service provider.

Data counter

Display the data transfer information for GPRS and UMTS.



Reset the data counter and confirm with .

Connect'n profiles

Depending on your provider up to 25 profiles may be preset containing a collection of settings utilised by applications. Depending on your provider you may rename/edit/delete the profiles via the options menu.



Select profile from list and confirm with .

The following information is displayed and may be edited:

Profile name:

Default/changed name.

APN:

Access point name (URL).

Login:

Your login name.

Password:

Your password.

Authentication:

Select authentication mode: **Normal/Secure/ <None>**.

DNS 1 (opt):, DNS 2 (opt):

The IP addresses of the used primary/secondary DNS server. DNS servers are used on the Internet to translate IP addresses into domain names and vice versa.

Your provider will supply you with your login and password.

Internet profiles

Depending on your provider up to 25 profiles are preset containing a collection of settings utilised by applications. Dependig on your provider you may rename/edit/delete the profiles via the options menu.



Select profile from list and confirm with

The following information is displayed and may be edited:

Profile name:

Default/changed name.

Type: Select profile type: HTTP/WAP.

Security: Select security mode.

Proxy server:

IP address or domain of the server used for Internet access.

Proxy port:

Communication port of the server.

Login: Your login name.

Password: Your password.

Your provider will supply you with your login and password.

Linger time

Depending on your provider you may be able to specify the linger time which will apply to all applications.



Enter time
(1–999 seconds).

Shortcuts

You can assign one important number/function to each softkey, the navigation key (every direction) and the number keys 2 to 9 (speed-dial numbers).



Select key

Left soft key/Right soft key

Select key and confirm with .

Navigation key

Select and confirm with . Select **Up/Down/Left/Right** and confirm with .

Number keys

Select and confirm with . Select number key and confirm with .

Set/change shortcut function

 Select function and confirm with .

If you assign a contact, the contact application is opened for selection.

Additional information

If no function is assigned, you can set a function if you

- press and **hold** the number key in stand-by mode
- press the softkey **briefly**.

Start function/call number

The function is started or the number is dialled at the touch of a button.

Press and **hold** key to start application/dial number.

Pre-defined key functions

The following key functions are pre-defined. You cannot change their function.



Open **Contacts** (page 41).



Dial the mailbox number (page 88).



Switch between two connections during a call (page 134).

Additional information

The service provider may have already assigned functions to a softkey (e.g access to "SIM services" or direct call-up of the Internet portal). It may not be possible to modify this key assignment.

The left softkey may sometimes be replaced automatically by / to access a new message for example.

Call setup

 →  → Call setup
→ Select function.

Hide ID



When you make a call, your number can be shown on the display of the called party or suppressed. You may need to register separately with your service provider for these functions.

 Select one of the following options and confirm with .

On/Off	Activate/deactivate display of the number for all subsequent calls.
Next call only	Activate/deactivate display of the number just for next call.
Check status 	The current setting is checked on the network and displayed.

Additional information

The setting applies to voice and video calls.

Call waiting



If you are registered for this service, set call waiting.

On/Off Activate/deactivate call waiting and confirm with .

Or

Check status

Select to display current setting.

Diverts

You can specify the conditions under which the call types should be diverted to your mailbox or other numbers.

Additional information

The different call types are described below.

 Confirm the warning message.

Divert video calls/voice calls

Voice calls/Video calls

Select call type and confirm with .

All video calls/All voice calls/

Unanswered/Not reachable/

No reply/Busy

Select option and confirm with .

Options



Open menu and select Set.

Enter the number you want to divert to. Or select **Contacts** from the options menu and select a contact.

Divert other call types**All calls/Data/Fax/Messages**

Select a call type and confirm with .

Options

Open menu and select **Set**.



Enter the number you want to divert to. Or select **Contacts** from the options menu and select a contact.

Check status**Options**

Open menu and select **Check status**.

You can check the current divert status for all conditions. After a short pause, the current situation is transmitted by the network and displayed.

Clear all**Options**

Open menu and select **Clear all**.

All set diversions are cleared. Confirm with .

Additional information

Note that the divert is stored in the network and not in the phone (e.g., when the SIM card is changed).

Reactivate divert

The last divert has been stored. Proceed as with "Set divert". The stored number is displayed. Confirm number.

All calls

All calls are diverted.



Symbol in the top line of the display in standby mode.

Unanswered

A call is diverted in the following situations: **Not reachable**, **No reply**, **Busy** (see below).

Not reachable

A call is diverted if the phone is switched off or is out of range.

No reply

A call is only diverted after a delay that is determined by the network. The period can be set to a maximum of 30 seconds in 5 second intervals.

Busy

A call is diverted if another call is in progress. If you activated **Call waiting** (page 123), you will hear the call waiting tone during a call (page 37).

Fax

Fax calls are diverted to a number with a fax connection.

Data/Messages

Data calls are diverted to a number with a PC connection.

Any key answer

Incoming calls can be accepted by pressing any key (except for .

On/Off Activate/deactivate and confirm with .

Auto volume

Set automatic gain control (AGC) and automatic volume control (AVC). This feature automatically controls earpiece volume and microphone sensitivity depending on ambient noise level.

On/Off Activate/deactivate and confirm with .

Video calls

Specify the additional settings for video calls.

Show my image

If the function is activated your video image is always transmitted to the caller during a video call.

If the function is deactivated, you can choose whether or not to send the video image when you receive an incoming video call.

On/Off Activate/deactivate and confirm with .

Select image

When you do not want to transmit your video image to the caller (**Show my image** is deactivated) you can select a video mute picture that is shown instead.



Select one of the following options and confirm with .

Standard Display the default video mute file provided by the manufacturer or the service provider.

Custom Select a picture from **My stuff** (page 110) folder.

Additional information

You cannot send protected files during a video call (DRM, page 22).

Phone

 →  → Phone
→ Select function.

Language

Set the language of the display text.

Display language

Show the currently set display language. When **Automatic** is set, the language of your home service provider is used.

Input language

Select a language for text entry. Languages with T9 support are marked with the T9 symbol. When **Automatic** is set, the input language is based on the display language.

If a language that you do not understand happens to be set, the phone can be reset to the language of your home service provider with the following input (in standby mode):

***#0000#** 

T9 mode

Set T9 (intelligent text entry) or the multi-tap as default text entry method for most of the text entry items.

On/Off Activate/deactivate T9 and confirm with .

Key tones

Set the tone that is played when pressing keys.

 →  → Shortcuts
→ Key tones

Tone/Silent

Select and confirm with .

Info tones

Set the service and alarm tones.

On/Off Activate/deactivate T9 and confirm with .

Voice dialling

If this function is enabled, you can enter voice-activated dialling when you press and **hold**  the navigation key.

On/Off Activate/deactivate and confirm with .

File system

Format card

Format the **RS MultiMediaCard** and delete **all** saved data. Formatting can last longer than one minute.

 Press to confirm request.

Eject card

Eject the **RS MultiMediaCard** from the phone safely without losing data that is still being transmitted to the card.



Press to confirm request.

If card is still busy, confirm the error message with  and try again later.

Memory assistant

Start the memory assistant (page 25).

Phone identity

The phone identity number (IMEI) is displayed. This information may be useful for customer service.



Switch between tabs to display additional information about the device.

Device check

After the last information page, a self-test as well as the individual test are offered. If you select **Self test**, all individual tests are carried out.

Software version

To display the software version for your phone in standby mode:

*** # 0 6 #**, and select the Configuration tab.

Device manager (DM)

Sessions can be initiated in different ways.

- **Manual session:** You start the DM session via this menu option.
- **WAP push:** Your service provider initiates a DM session via WAP push (page 68). You receive an Over The Air Provisioning (OTAP) message. The message is displayed. Confirm the request to start the DM session.

The OTAP message can be protected and you may need a PIN to open it. Contact your provider for further information.

- **Software update:** The phone checks the software status each time it is switched on. If an update is available a request is displayed. Confirm the requests to start the software update and to re-boot your phone.

Additional information

If you want to start a session the battery must be charged at least 50 %.

128 Settings

The phone default settings vary from service provider to service provider and can be as follows:

- The settings have already been implemented by the provider. You can start immediately.
- Access profiles have already been created by your provider. Select and activate a profile.
- The access profiles must be configured manually. If necessary, check with your service provider for details. You will find the current settings for the service provider on the Internet at www.siemens.com/mobilephonescustomercare under "FAQ".

Manual session

Display the currently active profile and summary results of the last session.

Options Open menu.

Start	Start the DM session.
Select profile	Select a profile (profile options see below).
Last session	Show the details of the last session (e.g. date, time, additional info).
Resume session	If the last session can be resumed: resume last session.
For standard functions see page 24.	

Profile options

Options Open menu.

Activate	Activate the highlighted profile.
Edit profile	Edit the highlighted profile (see below).
Restore defaults	Restore the profile to the default values.
For standard functions see page 24.	

Edit profile



Navigate to input fields.

Address: Enter the server address.

Port: Enter the port number to connect with the server, e.g. 80.

Provider: Select a service provider.

User name: Enter your login name.

Password: Enter your password (shown as a series of asterisks).

Server ID: Enter the server ID.

Server password: Enter your password (shown as a series of asterisks).

HTTP authent.

Enable/disable HTTP authentication.
Select No/Yes.

HTTP name:

Enter your user name
when HTTP authent. is
active.

HTTP password:

Enter your password
when HTTP authent. is ac-
tive (shown as a series of
asterisks).

Master reset

Reset the phone to default values
(factory setting). This does not affect
the SIM card or the network settings.

Alternatively enter in standby mode:

***#9999#** 



Enter the phone code
(page 28) and confirm
with .

Clock



The clock must be set correctly once at start-up (page 20).

Setting the time and date

Time/Date Select and confirm with .

 /  Enter time (hours/minutes) or date (day/month/year) and confirm with .

If **Auto time** is activated (page 131), the network time is displayed.

Additional information

- Press  to reset time/date.
- If the battery is removed for longer than 30 seconds, the clock is reset automatically.

Time zone

The world clock shows the current system time, the time zone (grey vertical bar on the map), the time zone name and the time in the selected city.

The time zone can be changed:

-  Select the desired setting and change the time zone in the world map.
-  Select a city in the selected time zone.
-  Display set time zone.

Options

Open menu and select option.

Set time zone Set a new time zone for the selected city. Confirm with **Yes**.

Auto time Enable/disable automatic update of the time and the time zone.

Search city Open the city list and select a city.

For standard functions see page 24.

Additional information

If you changed the time zone:

- Alarm clock is changed to the current time zone.
- Calendar events are not affected by time zone changes.

Time format

Set the display format for time used in various applications.

24-hour/12-hour am/pm

Select and confirm with .

Date format

Set the display format for date.



Select date format and confirm with .

Show clock

Set the time and date display in standby mode.

On/Off Activate/deactivate and confirm with .

Auto time



If you activate auto time, the time zone is switched automatically to local time by the network.

On/Off Activate/deactivate and confirm with .

Security



→  → Security

→ Select function.

Auto key lock

If activated, the keypad is locked automatically if no key has been pressed for one minute in standby mode. This prevents the phone from being used accidentally. However, you can still be called and you can still make an emergency call.

On/Off Activate/deactivate and confirm with .

Additional information

The keypad can also be directly locked and unlocked in standby mode. In each case:



Press and hold.

Only



(PIN2 or phone-code protected)

Dialling options are restricted to the SIM protected numbers in the contacts. If only area codes are entered, relevant numbers can be added to these manually before dialling.

If the SIM card does not support PIN2 input, **all** the contacts can be protected with the phone code.

On/Off Activate/deactivate and confirm with .

PIN codes

Description on page 28:

PIN control, Change PIN, Change PIN2, Change phonecode

This SIM only



(PIN2 or phone-code protected)

The phone can be linked to a SIM card when the phone code is entered. Unless the phone code is known the phone will not operate with a **different** SIM card.

If the phone is to be used with a different SIM card, enter the phone code when requested.

On/Off Activate/deactivate and confirm with .

Barrings



Barring restricts the use of your SIM card (not supported by all service providers). You need a 4-digit network password for network barring. Your service provider will supply you with this password. You may need to register separately for each barring.

Activate/deactivate Barrings



Confirm warning message.



Select call type described below and confirm with .

Activate/Deactivate

Select and confirm with .



Enter the network password and confirm with  to activate/deactivate barring for selected call type.



Confirm barring message.

All outgoing

All outgoing calls except emergency numbers are barred.

Outg. internat. (International outgoing)

Only national calls can be made.

Outg. int. x home (International outgoing without home country)

International calls are not permitted. However you can make calls to your home country when abroad.

All incoming

The phone is barred for all incoming calls (forwarding of all calls to mailbox provides a similar effect).

When roaming

You do not receive calls when you are outside your home network. This means that no charges are incurred for incoming calls.

Check status of selected call type or of all call types.

Status check

Check the status of selected or all call type(s).



Enter the network password.



Confirm barring message.

Clear all

All barrings are deleted.



Enter the network password.



Confirm to clear all barrings.

Content downl'd ?

Enable or disable a content download notification (page 22).

On/Off

Activate/deactivate and confirm with .

Content expiry

Enable/disable warning message when a license is about to expire (page 22).

Warn of expiry/Don't warn

Select and confirm with .


Network



Select line



This function is only displayed if it is supported by the service provider.
Two separate numbers must be registered on the phone.






Additional information

This setting affects only outgoing calls. You may still receive calls on the other line.

Lock/unlock lines

(PIN2-code protected, see page 28)

You may limit the usage to one number. If you lock a line, you cannot select this line until it is unlocked. You can lock only one of the lines at once.




Additional information

Special settings may be made for each number (e.g. melody, call divert etc.) To do this, first switch to the required number.

Network info

Retrieve information about the network operator currently set. Information is displayed.







Choose network

Start network search. This is useful if you are **not** in your home network or want to register in a **different** network.


If **Auto network** is activated (page 134), confirm request to deactivate the auto network function.

The list of networks currently available is displayed.



Auto network

If you activate this function, the phone searches automatically and selects the next network on the preferred network list. Otherwise you can select a different network manually from the network list.



When function is deactivated, the **Choose network** function is started automatically (page 134).

Preferred network

Display a list of preferred networks. Customise the list by changing entries.



Select entry.

Options

Open menu and select **Change**.



Select network and confirm with .

Additional information

If you are outside your home network, your phone automatically dials another network.

If the signal strength of the preferred network is inadequate when you switch on the phone, the phone may register in a different network.

Mode selection



Make sure that your service provider supports the selected mode.



Select **Automatic/GSM only/UMTS only** and confirm with .

Options

Open menu and select **Save**.

Additional information

Combinations of several modes may be prohibited. Confirm the error message and change selection.

Fast search

If you activate this function, the phone searches for a network faster (standby time is reduced).

On/Off

Activate/deactivate function and confirm with .

Accessories



→ → Accessories
→ Select function.

Car kit

The **Car kit** profile is activated automatically as soon as the phone is connected to the car kit.

Edit profile

To edit the **Car kit** profile see page 113.

Auto answer

Voice and video calls are accepted automatically after a few seconds.

On/Off Activate/deactivate and confirm with .

Additional information

- **Auto answer** does not apply if you are already in a call.
- If you do not notice that your phone has accepted a call, there is the danger that the caller may eavesdrop.

Accept by voice

Voice and video calls may be accepted by voice command.

On/Off Activate/deactivate and confirm with .

Announce caller

Caller ID of an incoming call is announced to user.

On/Off Activate/deactivate and confirm with .

Car loudspeaker

Use the car loudspeaker as default for each new call made while connected to the car kit. This may improve the playback quality.

On/Off Activate/deactivate and confirm with .

Additional information

This setting is not available (hidden) if **Bluetooth portable** or **Car Kit portable** is attached to phone.

Auto off

The phone is powered by the power supply of the car. You can adjust the time between switching off the ignition and the automatic switching off of the phone.



Enter time when phone should switch off.

Enable

Enable function.

Or

Disable

Disable function.

Additional information

This setting is not available (hidden) if **Bluetooth portable** or **Car Kit portable** is attached to phone.

Read SMS

(only for Car Kit Bluetooth)

SMS messages received on the phone are read via TTS when the phone is attached to the car kit.

On/Off Activate/deactivate and confirm with .

Key assignments

(only for Car Kit Comfort)

You can assign new functions to keys on the car kit.

Key 1/Key 2/Key 3

Select the key and confirm with .



Select function and confirm with .

Headset

Only in combination with an original Siemens handsfree headset (page 149). If an original Siemens headset is used the **Headset** profile is automatically activated when the headset is plugged in.

Edit profile

To edit **Headset** profile see page 113.

Auto answer

Voice and video calls are accepted automatically after a few seconds.

On/Off Activate/deactivate and confirm with .

Additional information

- **Auto answer** does not apply if you are already in a call.
- If you do not notice that your phone has accepted a call, there is the danger that the caller may eavesdrop.

Charge via USB

Phone is charged via USB when connected to a computer via USB cable.

On/Off Activate/deactivate and confirm with .

Mobile Phone Manager

MPM (Mobile Phone Manager) enables you to use extended phone functions from your PC. The phone and PC communicate via IrDA, Bluetooth or a data cable (see Accessories, page 149).



You can download the newest version of MPM from the Internet: www.siemens.com/sxg75

Please consult the help files and the readme file for further information on the functions and use of MPM.

Organiser



With the Organiser you can administer the contacts of your phone, Outlook® and other Siemens phones (including Gigaset).

Backup and restore



With the backup function, you can regularly make a copy of your phone data on the PC. If you ever lose the data on your phone or replace the phone, you can quickly retrieve all data with the restore function. Please observe all applicable restrictions for DRM protected data.

Bookmark Management



Use your PC to browse the Internet and define your preferred Internet sites. Save the Internet addresses as bookmarks on your phone so that you can quickly call them up at a later time when you are on the move.

Phone Explorer



With Phone Explorer you can access your phone's data fast and comfortably. The phone is simply added to your PC's file structure as if it was just another folder on your PC.

Mobile Modem Assistant



Mobile Modem Assistant quickly and effortlessly sets up an Internet connection over your mobile phone so that you can at once surf the Internet at home or abroad without difficulty.

Media Pool



Media Pool offers you a convenient way of managing ringtones, music, playlists and videos. You can move music files to your phone and automatically convert them into a suitable format in the process.

Plug & Sync



Plug & Sync can relieve you of routine tasks. With "Music > Phone" you can always transfer your up-to-date music files and playlists to the phone automatically. With "Photos > PC" you can transfer your newly taken pictures to the PC.

SmartSync



With SmartSync you can synchronise your data with Outlook®, Outlook Express® or Lotus Notes™ as soon as your phone is connected to the PC. New and edited contacts are synchronised automatically as are messages and appointments.

Questions & Answers

If you have any questions about using your phone, visit us at **www.siemens.com/mobilephonescustomer care** any time. For additional help, we have listed below some frequently asked questions and answers.

Configuration service

To help you set up your mobile phone for the data service WAP, MMS, e-mail and Internet, you can use a configuration service. This service is used to have the necessary settings for your mobile phone sent to you by SMS. We recommend that you contact your network provider who will send you the configuration messages.

As an alternative you can also use the "Setting Configurator" at **www.siemens.com/mobilephonescustomer care**. Siemens will then send you the configuration messages. Please follow the instructions contained in those messages.

Problem	Possible causes	Possible solution
Phone cannot be switched on.	On/Off key not pressed long enough.	Press On/Off key for at least two seconds.
	Flat battery.	Charge battery. Check charging indicator in the display.
	Battery contacts dirty.	Clean contacts.
	See also below under "Charging error".	
Too little standby time.	The operating time depends on the respective operating conditions. Extreme temperatures significantly reduce the phone's standby time!	
	Some settings/functions negatively affect the standby time.	It may be useful to restrict the use of the following functions in order to improve the standby time: Bluetooth function, Cell Broadcast, Infrared interface, Silent Alert/Vibrator Alarm, Fast Search, GPRS, display illumination (can be adjusted to a lower level or switched off), frequent use of organizer and games, continuous animated screensaver.
	Data cable connected.	When a data cable is connected, the battery will be empty within a few hours even if there is no active data connection at all. Connect data cable only if necessary.
	Unintentional keystrokes (illumination!).	Activate auto key lock (page 132).

Questions & Answers

141

Problem	Possible causes	Possible solution
Charging error (charge icon not displayed).	Battery totally discharged.	1) Plug in charger cable, battery is on charge. 2) Charge icon appears after approx. 2 hours. 3) Charge battery.
	Temperature out of range: +5 °C to +45 °C (41 °F to 113 °F).	Make sure the ambient temperature is right, wait for a while, then recharge.
	Contact problem	Check power supply and connection to the phone. Check battery contacts and phone connection socket, clean them if necessary, then insert battery again.
	No mains voltage.	Use different mains power socket, check mains voltage.
	Wrong charger. Battery faulty.	Only use original Siemens accessories. Replace battery.
SIM error.	SIM card not inserted correctly.	Check that the SIM card is inserted correctly (page 15).
	Dirty SIM card contacts.	Clean SIM card with a dry cloth.
	SIM card with wrong voltage.	Use 3V SIM cards only.
	SIM card damaged (e.g. broken).	Carry out a visual check. Change SIM card at service provider.
No network connection.	Weak signal.	Move higher, to a window or an open space.
	Outside GSM/UMTS range.	Check service provider's coverage area.
	Invalid SIM card.	Complain to the service provider.
	New network not authorised.	Try manual selection or select a different network (page 134).
	Network call barring is set. Network overloaded.	Check network barrings (page 132). Try again later.
Phone loses network.	Signal too weak.	Reconnection to another service provider is automatic (page 135). Switching phone off and on again can speed this up.
Calls not possible.	Second line set.	Set first line (page 134).
	New SIM card inserted.	Check for new barrings.
	Charge limit reached.	Reset limit with PIN2 (page 28).
	Credit used up.	Load credit.

142 Questions & Answers

Problem	Possible causes	Possible solution
Certain uses of phone not possible.	Call restrictions are in place.	Barrings can be set by service provider. Check barrings (page 132).
Impossible to make entries in contacts.	Memory is full.	Delete entries in contacts (For standard functions see page 24) or call up memory assistant (page 25).
Voice mail not functioning.	Call divert to mailbox not set.	Set call divert to mailbox (page 88).
 flashes to indicate an SMS.	SMS memory is full.	Delete (For standard functions see page 24) or call up memory assistant (page 25).
 flashes to indicate an MMS.	MMS memory full.	Delete MMS (For standard functions see page 24).
 flashes to indicate an MMS.	Phone memory full.	Delete messages, pictures, videos, games or applications or call up memory assistant (page 25).
Function cannot be set.	Not supported by service provider or registration required.	Contact your service provider.
Capacity problems with, for example, Games & More, ringtones, pictures, videos, SMS archive.	Phone memory full.	Delete files in the relevant areas. You can use the memory assistant to delete specific files (page 25).
No WAP access, downloading not possible.	Wrong or incomplete WAP settings.	Check WAP settings (page 91). If necessary ask your service provider.
Text message cannot be sent.	Service provider does not support this service.	Contact your service provider.
	Number for service centre not set or incorrectly set.	Set service centre (page 70).
	SIM card contract does not support this service.	Contact your service provider.
	Service centre too busy.	Repeat message.
	Recipient does not have a compatible phone.	Check.
No Internet access possible.	Wrong or incomplete WAP settings.	Check WAP settings (page 91) and contact your service provider if necessary.

Questions & Answers 143

Problem	Possible causes	Possible solution
PIN error/ PIN2 error.	Three wrong entries.	Enter the PUK (MASTER PIN) supplied with the SIM card according to the instructions. If the PUK (MASTER PIN) has been lost, please contact your service provider.
Phone code error.	Three wrong entries.	Contact Siemens Service (page 144).
Service provider code error.	No authorisation for this service.	Contact your service provider.
Too few/too many menu entries.	Functions may have been added or deleted by the service provider via the SIM card.	Check with your service provider.
No fax possible.	Wrong settings in the PC. No authorisation for this service.	Check settings. Contact your service provider.
Charge meter does not work.	Charge pulse is not transmitted.	Contact your service provider.
Damage		
Severe shock.	Remove battery and SIM and re-insert them. Do not dismantle the phone!	
Phone became wet.	Remove battery and SIM. Dry immediately with a cloth, but do not apply heat. Dry connector contacts thoroughly. Stand mobile upright in an air current. Do not dismantle the phone!	

Reset all settings to factory default, page 127: * # 9 9 9 9 # 

Customer Care

We offer fast, individual advice! You have several options:

Our online support on the Internet:

**[www.siemens.com/
mobilephonescustomer-care](http://www.siemens.com/mobilephonescustomer-care)**

We can be reached any time, any place. You are given 24 hour support on all aspects of our products. Here you will find an interactive fault-finding system, a compilation of the most frequently asked questions and answers, plus user guides and current software updates to download.

When calling customer service, please have ready your receipt and the phone identity number (IMEI, to display press *#06#, the software version (to display, press *#06#, then select the Configuration tab) and if available, your Siemens Service customer number.

You will also find the most frequently asked questions and answers in the section entitled "Questions & Answers" in this user guide on page 140.

In some countries repair and replace services are impossible where the products are not sold through our authorised dealers.

If repair work is necessary, please contact one of our service centres:

Abu Dhabi	0 26 42 38 00
Argentina	0 80 08 88 98 78
Australia	13 00 66 53 66
Austria	05 17 07 50 04
Bahrain	40 42 34
Bangladesh	0 17 52 74 47
Belgium	0 78 15 22 21
Bolivia	0 21 21 41 14
Bosnia Herzegovina	0 33 27 66 49
Brunei	02 43 08 01
Bulgaria	02 73 94 88

Cambodia	12 80 05 00
Canada	1 88 87 77 02 11
Chile	8 00 53 06 62
China	0 21 23 01 71 88
Colombia	01 80 07 00 66 24
Croatia	0 16 10 53 81
Czech Republic	2 33 03 27 27
Denmark	35 25 86 00
Dubai	0 43 96 64 33
Ecuador	18 00 10 10 00
Egypt	0 23 33 41 11
Estonia	6 30 47 97
Finland	09 22 94 37 00
France	01 56 38 42 00
Germany	0 18 05 33 32 26
Greece	80 11 11 11 16
Hong Kong	28 61 11 18
Hungary	06 14 71 24 44
Iceland	5 11 30 00
India	22 24 98 70 00 Extn: 70 40
Indonesia	0 21 46 82 60 81
Ireland	18 50 77 72 77
Italy	02 24 36 44 00
Ivory Coast	05 02 02 59
Jordan	0 64 39 86 42
Kenya	2 72 37 17
Kuwait	2 45 41 78
Latvia	7 50 11 18
Lebanon	01 44 30 43
Libya	02 13 50 28 82
Lithuania	8 70 07 07 00
Luxembourg	43 84 33 99
Macedonia	0 23 13 14 84
Malaysia	+ 6 03 77 12 43 04
Malta	+ 35 32 14 94 06 32
Mauritius	2 11 62 13
Mexico	01 80 07 11 00 03
Morocco	22 66 92 09
Netherlands	0 90 03 33 31 00
New Zealand	08 00 27 43 63
Nigeria	0 14 50 05 00
Norway	22 70 84 00
Oman	79 10 12
Pakistan	02 15 66 22 00
Paraguay	8 00 10 20 04

Customer Care 145

Peru	0 80 05 24 00
Philippines	0 27 57 11 18
Poland	08 01 30 00 30
Portugal	8 08 20 15 21
Qatar	04 32 20 10
Romania	02 12 09 99 66
Russia	8 80 02 00 10 10
Saudi Arabia	0 22 26 00 43
Serbia	01 13 07 00 80
Singapore	62 27 11 18
Slovak Republic	02 59 68 22 66
Slovenia	0 14 74 63 36
South Africa	08 60 10 11 57
Spain	9 02 11 50 61
Sweden	0 87 50 99 11
Switzerland	08 48 21 20 00
Taiwan	02 23 96 10 06
Thailand	0 27 22 11 18
Tunisia	71 86 19 02
Turkey	0 21 64 59 98 98
Ukraine	8 80 05 01 00 00
United Arab Emirates	0 43 66 03 86
United Kingdom	0 87 05 33 44 11
USA	1 88 87 77 02 11
Venezuela	0 80 01 00 56 66
Vietnam	84 89 20 24 64
Zimbabwe	04 36 94 24

Care and maintenance

Your phone has been designed and manufactured to the highest of standards and should be treated with great care. The suggestions below will help you to enjoy your phone for many years.

- Protect your phone from moisture and humidity. Precipitation, humidity and liquids contain minerals that will corrode electronic circuits. Nevertheless, should your phone become wet, disconnect it immediately from the power supply to avoid electric shock. Do not place your phone (even to dry it) on/in a source of heat such as a microwave oven, oven or radiator. The phone may become overheated and possibly explode.
- Do not use or store the phone in dusty, dirty areas. Its moving parts may be damaged and the casing may become deformed and discoloured.
- Do not store your phone in hot environments (e.g. vehicle instrument panel in the summer). High temperatures can shorten the life of electronic devices, damage batteries and warp or melt certain plastics.
- Do not store your phone in cold environments. When the phone warms up again (to its normal ambient temperature), moisture can form inside the phone, which may damage electronic circuit boards.
- Do not drop, knock or shake your phone. Rough handling can damage internal circuit boards!
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the phone!

The suggestions given above apply equally to your phone, battery, charger and all accessories. If any of these parts is not working properly, obtain fast and reliable help at our service centres.

Battery quality statement

The capacity of your mobile phone battery will reduce each time it is charged/emptied. Storage at too high or low temperatures will also result in a gradual capacity loss. As a result the operating time of your mobile phone may be considerably reduced, even after a full recharge of the battery.

Regardless of this, the battery has been designed and manufactured so that it can be recharged and used for six months after the purchase of your mobile phone. After six months, if the battery is clearly suffering from loss of performance, we recommend that you replace it. Please buy only Siemens original batteries.

Display quality declaration

For technological reasons, a few small dots with different colours may appear in the display in exceptional cases.

Just remember that the appearance of brighter or darker dots generally does not mean that a fault has occurred.

Product data

Declaration of conformity

BenQ Mobile hereby declares that the phone described in this user guide is in compliance with the essential requirements and other relevant provisions of European Directive 1999/5/EC (R&TTE). The declaration of conformity (DoC) concerned has been signed. Please call the company hotline if you require a copy of the original, or:

www.siemens.com/mobiledocs

CE 0168

Technical data

UMTS class:	3 (0.25 watt)
Frequency range:	2 100 MHz
GSM class:	4 (2 watt)
Frequency range:	880–960 MHz
GSM class:	1 (1 watt)
Frequency range:	1 710–1 880 MHz
GSM class:	1 (1 watt)
Frequency range:	1 850–1 990 MHz
Weight:	134 g (4.73 oz)
Size:	111 × 53 × 20 mm (108 ccm)
Li-Ion battery:	1 000 mAh
Operating temperature:	–10 °C to 55 °C (14 °F to 131 °F)
SIM card:	3.0/1.8 V
RS MultiMediaCard:	max. 256 MB

Phone ID

You will need the following details if you lose your phone or SIM card:
the number of the SIM card (on the card):

.....
15 digit serial number of the phone
(under the battery):

.....
the customer service number of the service
provider:

Lost phone

If you lose your phone or SIM card contact your service provider immediately to prevent misuse.

Operating time

The operating time depends upon the respective conditions of use: Extreme temperatures considerably reduce the phone's standby time. Avoid placing the phone in the sun or on a heater.

Call time

- UMTS: up to 300 minutes
- GSM: up to 360 minutes

Standby time

Up to 400 hours

Action taken	Time (min)	Reduction of standby time by
Calling	1	30–90 minutes
Light *	1	50 minutes
Network search	1	15 minutes
* Key input, games, organiser etc.		

SAR

INFORMATION ON RF EXPOSURE/
SPECIFIC ABSORPTION RATE (SAR)

THIS MODEL MEETS THE GOVERN- MENT'S REQUIREMENTS FOR EXPO- SURE TO RADIO WAVES

Your cellular phone is a radio transmitter and receiver. It is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (FCC, USA) and by Health Canada. These requirements include safety margins designed to assure the protection of all persons, regardless of age and health. They use a unit of measurement known as the Specific Absorption Rate (SAR). The SAR limit is 1.6 W/kg averaged over one gram of tissue.

The highest SAR value for this device when tested at the ear was 0.27 W/kg. In positions other than the head, such as on the body, a separation distance of 1.0 cm is required. The highest SAR value in this case was 0.92 W/kg.

Information about this device model can be found at <http://www.fcc.gov/oet/fccid> by searching the equipment authorization system using **FCC ID: PWX-SXG75**

As SAR is measured utilizing the device's highest transmitting power, the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network.


Additional Information can be found on the websites of the World Health Organization <http://www.who.int/emf> the Cellular Telecommunications Industry Association (CTIA) web-site at www.phonefacts.net, the Canadian Wireless Telecommunications Association (CWTA) website www.cwta.ca or Siemens www.siemens.com/mobilephones

Accessories

Fashion & Carry

Carrying Cases

A range of carry cases is available at specialist shops or you can visit the our online shop at:



Energy

Li-Ion Battery EBA-750 (1000 mAh)

Spare battery.

Travel Charger

Travel Charger EU ETC-500

Travel Charger UK ETC-510

Travel charger with an extended input voltage range of 100–240 V.

Car Charger Plus ECC-600

Charger for the cigarette lighter socket in the car. It is possible to make phone calls during charging.

Handsfree Portable

Headset Basic HHS-500

Simple headset without key to accept calls.

Headset HHS-510

Headset with key to accept and end calls.

Headset Purestyle HHS-610

High quality headset with removable ear-piece and key to accept calls.

Headset Stereo HHS-700

Stereo headset with key for listening to music and making calls.

Headset Bluetooth®

HHB-700 with EU power supply unit

HHB-710 with UK power supply unit

HHB-720 with Australian power supply unit

Elegant, small, easy to wear Bluetooth headset.

Office

Data Cable USB DCA-540

For connecting the phone to the USB port of the PC. With charging capacity.

Multitainment

Flash IFL-600

Plug-in flash module for taking photos in areas with low ambient light.

Mobile Music Set IMS-700

The portable Mobile Music Set allows users to listen to music on the mobile phone in excellent sound quality anywhere and share it with others via active loudspeakers.

Car Solutions

Car Kit Portable HKP-500

The portable handsfree car kit can easily be moved from one car to another. Simply plug into the cigarette lighter socket, connect and talk.

Car Kit Bluetooth® Portable HKW-700

Bluetooth high-tech handsfree kit without cable connection to the mobile phone. Plugs into cigarette lighter socket - no installation effort required.

Car Kit Bluetooth® 75 HKW-710

Innovative Bluetooth handsfree kit with external display for safe and comfortable calling in the car.

The products are available at specialist shops or you may visit our online shop at:

	Siemens Original Accessories www.siemens.com/shop
---	--



The U.S. Food and Drug Administration's (FDA) Center for Devices and Radiological Health Consumer Update on Mobile Phones

FDA has been receiving inquiries about the safety of mobile phones, including cellular phones and PCS phones. The following summarizes what is known – and what remains unknown – about whether these products can pose a hazard to health, and what can be done to minimize any potential risk. This information may be used to respond to questions.

Why the concern?

Mobile phones emit low levels of radio frequency energy (i.e., radio frequency radiation) in the microwave range while being used. They also emit very low levels of radio frequency energy (RF), considered non-significant, when in the stand-by mode. It is well known that high levels of RF can produce biological damage through heating effects (this is how your microwave oven is able to cook food). However, it is not known whether, to what extent, or through what mechanism, lower levels of RF

might cause adverse health effects as well. Although some research has been done to address these questions, no clear picture of the biological effects of this type of radiation has emerged to date. Thus, the available science does not allow us to conclude that mobile phones are absolutely safe, or that they are unsafe. However, the available scientific evidence does not demonstrate adverse health effects associated with the use of mobile phones.

What kinds of phones are in question?

Questions have been raised about hand-held mobile phones, the kind that have a built-in antenna that is positioned close to the user's head during normal telephone conversation. These types of mobile phones are of concern because of the short distance between the phone's antenna – the primary source of the RF – and the person's head. The exposure to RF from mobile phones in which the antenna is located at greater distances from the user (on the outside of a car, for example) is drastically lower than that from hand-held phones, because a person's RF exposure decreases rapidly with distance from the source. The safety of so-called "cordless phones," which have a base unit connected to the telephone wiring in a house and which operate at far lower power levels and frequencies, has not been questioned.

How much evidence is there that handheld mobile phones might be harmful?

Briefly, there is not enough evidence to know for sure, either way; however, research efforts are on-going. The existing scientific evidence is conflicting and many of the studies that have been done to date have suffered from flaws in their research methods. Animal experiments investigating the effects of RF exposures characteristic of mobile phones have yielded conflicting results. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. In one study, mice genetically altered to be predisposed to developing one type of cancer developed more than twice as many such cancers when they were exposed to RF energy compared to controls. There is much uncertainty among scientists about whether results obtained from animal studies apply to the use of mobile phones. First, it is uncertain how to apply the results obtained in rats and mice to humans. Second, many of the studies showed increased tumor development used animals that had already been treated with cancer-causing chemicals, and other studies exposed the animals to the RF virtually continuously – up to 22 hours per day.

For the past five years in the United States, the mobile phone industry has supported research into the safe-

ty of mobile phones. This research has resulted in two findings in particular that merit additional study:

1. In a hospital-based, case-control study, researchers looked for an association between mobile phone use and either glioma (a type of brain cancer) or acoustic neuroma (a benign tumor of the nerve sheath). No statistically significant association was found between mobile phone use and acoustic neuroma. There was also no association between mobile phone use and gliomas when all types of gliomas were considered together. It should be noted that the average length of mobile phone exposure in this study was less than three years.

When 20 types of glioma were considered separately, however, an association was found between mobile phone use and one rare type of glioma, neuroepitheliomatous tumors. It is possible with multiple comparisons of the same sample that this association occurred by chance. Moreover, the risk did not increase with how often the mobile phone was used, or the length of the calls. In fact, the risk actually decreased with cumulative hours of mobile phone use. Most cancer causing agents increase risk with increased exposure. An ongoing study of brain cancers by the National Cancer Institute is expected to bear on the accuracy and repeatability of these results.¹

2. Researchers conducted a large battery of laboratory tests to assess the effects of exposure to mobile phone RF on genetic material. These included tests for several kinds of abnormalities, including mutations, chromosomal aberrations, DNA strand breaks, and structural changes in the genetic material of blood cells called lymphocytes. None of the tests showed any effect of the RF except for the micronucleus assay, which detects structural effects on the genetic material. The cells in this assay showed changes after exposure to simulated cell phone radiation, but only after 24 hours of exposure. It is possible that exposing the test cells to radiation for this long resulted in heating. Since this assay is known to be sensitive to heating, heat alone could have caused the abnormalities to occur. The data already in the literature on the response of the micronucleus assay to RF are conflicting. Thus follow-up research is necessary.²

FDA is currently working with government, industry, and academic groups to ensure the proper follow-up to these industry-funded research findings. Collaboration with the Cellular Telecommunications Industry Association (CTIA) in particular is expected to lead to FDA providing research recommendations and scientific oversight of new CTIA-funded research based on such recommendations.

Two other studies of interest have been reported recently in the literature:

- Two groups of 18 people were exposed to simulated mobile phone signals under laboratory conditions while they performed cognitive function tests. There were no changes in the subjects' ability to recall words, numbers, or pictures, or in their spatial memory, but they were able to make choices more quickly in one visual test when they were exposed to simulated mobile phone signals. This was the only change noted among more than 20 variables compared.³
- In a study of 209 brain tumor cases and 425 matched controls, there was no increased risk of brain tumors associated with mobile phone use. When tumors did exist in certain locations, however, they were more likely to be on the side of the head where the mobile phone was used. Because this occurred in only a small number of cases, the increased likelihood was too small to be statistically significant.⁴

In summary, we do not have enough information at this point to assure the public that there are, or are not, any low incident health problems associated with use of mobile phones. FDA continues to work with all parties, including other federal agencies

and industry, to assure that research is undertaken to provide the necessary answers to the outstanding questions about the safety of mobile phones.

What is known about cases of human cancer that have been reported in users of hand-held mobile phones?

Some people who have used mobile phones have been diagnosed with brain cancer. But it is important to understand that this type of cancer also occurs among people who have not used mobile phones. In fact, brain cancer occurs in the U.S. population at a rate of about 6 new cases per 100,000 people each year. At that rate, assuming 80 million users of mobile phones (a number increasing at a rate of about 1 million per month), about 4800 cases of brain cancer would be expected each year among those 80 million people, whether or not they used their phones. Thus it is not possible to tell whether any individual's cancer arose because of the phone, or whether it would have happened anyway. A key question is whether the risk of getting a particular form of cancer is greater among people who use mobile phones than among the rest of the population. One way to answer that question is to compare the usage of mobile phones among people with brain cancer with the use of mobile phones among appropriately matched people without brain cancer. This is called a case-

control study. The current case-control study of brain cancers by the National Cancer Institute, as well as the follow-up research to be sponsored by industry, will begin to generate this type of information.

What is FDA's role concerning the safety of mobile phones?

Under the law, FDA does not review the safety of radiation emitting consumer products such as mobile phones before marketing, as it does with new drugs or medical devices. However, the agency has authority to take action if mobile phones are shown to emit radiation at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of mobile phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions at this time, FDA has urged the mobile phone industry to take a number of steps to assure public safety. The agency has recommended that the industry:

- Support needed research into possible biological effects of RF of the type emitted by mobile phones;
- Design mobile phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and

- Cooperate in providing mobile phone users with the best possible information on what is known about possible effects of mobile phone use on human health.

At the same time, FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of mobile phone safety to ensure a coordinated effort at the federal level. These agencies are:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Health and Safety Administration
- National Telecommunications and Information Administration

The National Institutes of Health also participates in this group.

In the absence of conclusive information about any possible risk, what can concerned individuals do?

If there is a risk from these products – and at this point we do not know that there is – it is probably very small. But if people are concerned about avoiding even potential risks, there are simple steps they can take to do so. For example, time is a key factor in how much exposure a person receives. Those persons who spend long periods of time on their

hand-held mobile phones could consider holding lengthy conversations on conventional phones and reserving the hand-held models for shorter conversations or for situations when other types of phones are not available.

People who must conduct extended conversations in their cars every day could switch to a type of mobile phone that places more distance between their bodies and the source of the RF, since the exposure level drops off dramatically with distance. For example, they could switch to:

- a mobile phone in which the antenna is located outside the vehicle,
- a hand-held phone with a built-in antenna connected to a different antenna mounted on the outside of the car or built into a separate package, or
- a headset with a remote antenna to a mobile phone carried at the waist.

Where can I find additional information?

For additional information, see the following websites:

- Federal Communications Commission (FCC) RF Safety Program (select “Information on Human Exposure to RF Fields from Cellular and PCS Radio Transmitters”):
<http://www.fcc.gov/oet/rfsafety>

- World Health Organization (WHO) International Commission on Non-Ionizing Radiation Protection (select Qs & As):
<http://www.who.int/emf>
- United Kingdom, National Radiological Protection Board:
<http://www.nrpb.org.uk>
- Cellular Telecommunications Industry Association (CTIA):
<http://www.wow-com.com>
- U.S. Food and Drug Administration (FDA) Center for devices and Radiological Health:
<http://www.fda.gov/cdhr/consumer/>

¹ Muscat et al. Epidemiological Study of Cellular Telephone Use and Malignant Brain Tumors. In: State of the Science Symposium; 1999 June 20; Long Beach, California.

² Tice et al. Tests of mobile phone signals for activity in genotoxicity and other laboratory assays. In: Annual Meeting of the Environmental Mutagen Society; March 29, 1999, Washington, DC; and personal communication, unpublished results.

³ Preece, AW, Iwi, G, Davies-Smith, A, Wesnes, K, Butler, S, Lim, E, and Varey, A. Effect of a 915- MHz simulated mobile phone signal on cognitive function in man. Int. J. Radiat. Biol., April 8, 1999.

⁴ Hardell, L, Nasman, A, Pahlson, A, Hallquist, A and Mild, KH. Use of cellular telephones and the risk for brain tumors; a case-control study. Int. J. Oncol, 15: 113-116, 1999.

FCC/Industry Canada Notice

Your phone may cause TV or radio interference (for example, when using a telephone in close proximity to receiving equipment). The FCC or Industry Canada can require you to stop using your telephone if such interference cannot be eliminated. If you require assistance, please contact your local service facility.

This device complies with part 15 of the FCC rules. Operation is subject to the condition that this device does not cause harmful interference.

Intellectual Property

Intellectual Property Restrictions

All Intellectual Property, as defined below, which is owned by or otherwise the property of Siemens Information and Communications Mobile, LLC ("Siemens"), its affiliates, partners or suppliers, relating to the Phone, including but not limited to accessories, parts or software relating thereto (the "Phone System"), is proprietary under federal laws, state laws and International treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) disassemble, decompile, reverse engineer, prepare derivative works from, modify or make any other effort to create source code from the software. No title to ownership in the Intellectual Property is transferred to you through purchase or possession of the Phone or its components. All applicable rights of the Intellectual Property shall remain with Siemens, its affiliates, partners or suppliers.

Siemens will have no liability with respect to any claim of patent infringement which is based upon the combination of the Product or parts furnished hereunder with software, apparatus or devices not furnished by Siemens, nor will Siemens have any liability for the use of ancillary equipment or software not furnished by Siemens which is attached to or used in connection with the Product. The foregoing states the entire liability of Siemens with respect to infringement of patents by the Product or any parts thereof.

Laws in the United States and other countries preserve for Siemens certain exclusive rights for copyrighted Siemens software, such as the exclusive rights to reproduce and distribute copies of such Siemens software. Siemens software may be used only in the Product in which the software was originally embodied when purchased, and such software in such Product may not be replaced, copied, distributed, modified in any way, or used to produce any derivative thereof. No other use including, without limitation, alteration, modification, reproduction, distribution, or reverse engineering of such Siemens software or exercise of rights in such Siemens software is permitted. No license is granted by implication, estoppel or otherwise under Siemens patent rights or copyrights.



Ten Driving Safety Tips

Your Siemens wireless phone gives you the power to communicate by voice – almost anywhere, anytime. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. When using your wireless phone behind the wheel of a car, practice good common sense and remember the following tips:

Get to know your phone and its features such as speed dial and redial.

Carefully read your instruction manual and learn to take advantage of valuable features most phones offer including, automatic redial and memory dial – most phones can store up to 99 numbers in memory dial. Also, work to memorize the phone keypad so you can use the speed dial function without taking your attention off the road.

When available, use a hands-free device.



A number of hands-free wireless phone accessories are readily available today. Whether you choose an installed mounted device for your phone or a speaker phone accessory, take advantage of these devices if they are available to you.

Position your phone within easy reach.

Make sure you place your wireless phone within easy reach and where you can grab it without removing your eyes from the road. If you get an incoming call at an inconvenient time, let your voicemail answer it for you.

Suspend conversations during hazardous driving conditions or situations.

Let the person you are speaking to know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow and ice can be hazardous, but so is heavy traffic. As a driver, your first responsibility is to pay attention to the road.

Do not take notes or look up phone numbers while driving.

If you are reading an address book or business card while driving a car, or writing a “to do” list, then you are not watching where you are going. It's common sense. Don't get caught in a dangerous situation because you are reading or writing and not paying attention to the road or nearby vehicles.

Dial sensibly and assess the traffic.

If possible, place calls when you are not moving or before pulling into traffic. Try to plan your calls before you begin your trip, or attempt to coincide your calls with times you may be stopped at a stop sign, red light or otherwise stationary. But if you need to dial while driving, follow this simple tip – dial only a few numbers, check the road and your mirrors, then continue.

Do not engage in stressful or emotional conversations that may be distracting.

Stressful or emotional conversations and driving do not mix – they are distracting and even dangerous when you are behind the wheel. Make people you are talking with aware you are driving and if necessary, suspend phone conversations that have the potential to divert your attention from the road.

Use your phone to call for help.

Your wireless phone is one of the greatest tools you can own to protect yourself and your family in dangerous situations – with your phone at your side, help is only three numbers away. Dial 9-1-1 in the case of fire, traffic accident, road hazard, or medical emergency. Remember, it is a free call on your wireless phone.

Use your phone to help others in emergencies.

Your wireless phone provides you a perfect opportunity to be a “good Samaritan” in your community. If you see an auto accident, crime in progress or other serious emergencies where lives are in danger, call 9-1-1, as you would want others to do for you.

Call roadside assistance or a special wireless non-emergency assistance number when necessary.

Certain situations you encounter while driving may require attention, but are not urgent enough to merit a call to 9-1-1. But you can still use your wireless phone to lend a hand. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless numbers.

“The wireless industry reminds you to use your phone safely when driving.”

For more information, please call 1 (888) 901-SAFE, or visit our Web site at: www.wow-com.com

Provided by the Cellular Telecommunications Industry Association (CTIA)

End user license agreement

This Software License Agreement ("Agreement") is between You and Siemens Information and Communication Mobile, LLC and/or one of its affiliates ("Licensor"). The Agreement authorizes You to use the Software specified in Clause 1 below, which may be included on Your phone, stored on a CD-ROM, sent to You by electronic mail, downloaded from Licensor's Web pages or servers or from other sources under the terms and conditions set forth below. This is an agreement on end user rights and not an agreement for sale. Licensor continues to own the copy of the Software and any other copy that You are authorized to make pursuant to this Agreement. Read this Agreement carefully before installing, downloading or using the Software. Further, by installing, downloading and/or using the Software, You agree to the terms and conditions of this Agreement.

1. Software.

As used in this Agreement, the term "Software" means, collectively: (i) all the software in Your phone, all of the contents of the disk(s), CD-ROM(s), electronic mail and its file attachments, or other media with which this Agreement is provided; (ii) related Licensor or third party software; (iii) digital images, stock photographs, clip art or other artistic works ("Stock Files") (iv) related explanatory

written materials ("Documentation"); (v) fonts (vi) upgrades, modified versions, updates, additions and copies of the Software, if any, licensed to You by Licensor (collectively "Updates") and (vii) any other possible documentation related thereto.

2. End user rights and use.

Licensor grants to You a non-exclusive, non-transferable end user right to install the Software or use the Software installed on the phone. The Software is licensed with the phone as a single integrated product and may be used with the phone only as set forth in these licensing terms.

3. Limitations on end user rights.

(a) You may not copy, distribute, or make derivative works of the Software.

(b) You may not use, modify, translate, reproduce or transfer the right to use the Software or copy the Software except as expressly provided in this Agreement.

(c) You may not resell, sublicense, rent, lease or lend the Software; except You may permanently transfer all of Your rights as set forth in the Agreement only as part of a permanent sale or transfer of the phone, provided the recipient agrees to the terms of this Agreement.

(d) You may not reverse engineer, reverse compile, disassemble or otherwise attempt to discover the source code of the Software (except to the extent that this restriction is expressly prohibited by law) or create derivative works based on the Software.

(e) You shall not display, modify, reproduce or distribute any of the Stock Files included with the Software.

(f) You shall not display, modify, reproduce or distribute any of the pre-loaded content included with the software unless permitted as stated in the User Guide or in the prompts in the Software. In the event that You are allowed to display, modify, reproduce or distribute certain parts of the pre-loaded content, You shall review the "Readme" files associated with the pre-loaded content (contained on the CD) to ascertain what rights You have with respect to such materials. Pre-loaded content may not be used in the production of libelous, defamatory, fraudulent, infringing, lewd, obscene or pornographic material or in any otherwise illegal manner. You agree that You shall only use the pre-loaded content in a manner that complies with all applicable laws, including, but not limited to, applicable restrictions concerning copyright and other intellectual property rights. You may not register or claim any rights in the pre-loaded content or derivative works thereof.

(g) You agree that You shall only use the Software in a manner that complies with all applicable laws in the jurisdiction in which You use the Software, including, but not limited to, applicable restrictions concerning copyright and other intellectual property rights.

4. Copyright.

Licensor and/or its software suppliers and their respective affiliates own the Software and all rights, including without limitation including proprietary rights therein, are protected by international treaty provisions and other applicable national laws of the country in which it is being used. The structure, organization and code of the Software are the valuable trade secrets and confidential information.

5. Multiple copies/updates.

If the Software supports multiple platforms or languages, if You receive the Software on multiple media, or if You otherwise receive multiple copies of the Software, the number of phones on which all versions of the Software are installed shall be one phone. If the Software is an Update to a previous version of the Software, You must possess a valid end user right to such previous version in order to use the Update and You may use the previous version for ninety (90) days after You receive the Update in order to assist You in the transition to the Update.

After such time You no longer have a right to use the previous version, except for the sole purpose of enabling You to install the Update.

6. Commencement & termination.

This Agreement is effective from the first date You use or install the Software. Your end user rights automatically and immediately terminate without notice from Licensor if You fail to comply with any provision of this Agreement. In such event, You must immediately delete, destroy or return at Your own cost and expense, and without entitlement to any refund of the purchase price, the phone and the Software, and all related material to Licensor.

7. Except as expressly provided in the limited warranty for the phone, you acknowledge the Software is provided "as is" without warranty of any kind express or implied. To the maximum extent permitted by applicable law neither Licensor, Licensor's Software suppliers or their respective affiliates, nor the copyright holders make any representations or warranties, express or implied, including but not limited to the warranties of merchantability or fitness for a particular purpose or that the Software will not infringe any third party patents, copyrights, trademarks or other rights. There is no warranty by Licensor or by any other party that the functions contained in the Software will meet your requirements or that

the operation of the Software will be uninterrupted or error free.

8. Not fault tolerant. The Software may contain technology that is not fault tolerant and is not designed, manufactured, or intended for use in environments or applications in which the failure of the licensed Software could lead directly to death, personal injury, or severe physical or environmental damage or financial loss.

9. Limitation of liability.

To the maximum extent permitted by applicable law, in no event shall Licensor or Licensor's Software suppliers or their respective affiliates and employees be liable for any lost profits, revenue, sales, data or costs of procurement of substitute goods or services, property damage, personal injury, interruption of business, loss of business information or for any special, direct, indirect, incidental, economic, cover, punitive, special or consequential damages, however caused and whether arising under contract, tort, negligence, or other theory of liability arising out of the use of or inability to use the Software, even if Licensor or its Software suppliers are advised of the possibility of such damages. Because some countries/states/jurisdictions do not allow the exclusion or limitation of liability, but may allow liability to be limited, in such cases, the liability of Licensor, its Software suppliers and

their respective affiliates and employees shall be limited to, at Licensor's option, either (a) return of the price paid less a reasonable amount for usage, or (b) repair or replacement of the Software that does not meet the limited warranty provided with the phone and which is returned in accordance with the requirements of the limited warranty.

Nothing contained in this Agreement shall prejudice the statutory rights of any party dealing as a consumer. Nothing contained in this Agreement limits Licensor's liability to You in the event of death or personal injury resulting from Licensor's negligence if law prohibits such a limitation. Licensor is acting on behalf of its software suppliers and their respective employees and affiliates for the purpose of disclaiming, excluding and/or restricting obligations, warranties and liability as provided in this clause 9, but in no other respects and for no other purpose.

10. Technical support.

Licensor has no obligation to furnish You with technical support except as agreed in writing between You and Licensor in the Limited Warranty provided with the phone.


11. Export control.

The Software may be subject to export regulations of the United States and other countries. You agree that You shall comply with all applicable export laws, restrictions and regulations of the United States or foreign agencies or authorities, and shall not export, or transfer for the purpose of re-export, any Software, product or technical data received under this Agreement or any Software or product produced by use of such technical data, including processes and services, in violation of any applicable restrictions, laws or regulations, or without all necessary approvals.

12. Applicable law & general provisions.


This Agreement shall be governed by and construed in accordance with the laws of the State of California without regard to its conflicts of laws rules. This is the entire agreement between Licensor and You relating to the Software and it supersedes any prior representations, discussions, undertakings, end user agreements, communications or advertising relating to the Software.

Menu tree




166

Menu tree




Menu tree

167




168 Menu tree




Menu tree

169




170

Menu tree



Menu tree

171



Index

A

Accessories	149
Car solutions	150
Energy	149
Handsfree	149
Multitainment	150
Office	149
Settings	136
Alarm clock	102
Answering service (external)	88
Any key answer	125
Auto key lock	132
Auto time	131
Auto volume	125

B

Backlight time	117
Band selection	135
Barrings	132
Battery	
Charge	17
Insert	15
Operating time	18, 147
quality declaration	146
Bluetooth®	118
Bookmark	
Media player	108
WAP	89
Browser	89
Profiles	91
Settings	89

C

Calculator	104
Calendar	96
Alarm	98
Receive Appointment	64, 67
Call	
Accept/end	35
Charges/Duration	51
Conference	37
Divert	123
End	34
Hold	36
Menu	38
Mute	38
Reject	36

Swap (change)	36
Video	34
Waiting	37, 123
Call log lists	50
Call setup	123
Call waiting on/off	123
Calling	34
Camera	52
Key	12
Lens front/back	12
Options	54
Settings	54
Take picture/video	53
Car kit settings	136
Car solutions	150
Care and maintenance	146
Case sensitivity (T9)	30
Cell broadcast (CB)	
Receive	62
Settings	77
Charge via USB	137
Charges	51
Charging time	17
Choose network	134
Clock	130
Codes	28
Conference call	37
Connection profiles	120
Connectivity	118
Contacts	41
Distribution list	41
Filter	45
Groups	44
Inst. Message	79
New entry	42
Options	46
Receive/save	67
Send	48
SIM Contacts	44
Synchronise	47
Content download prompt	133
Content expiration warning	133
Control code (DTMF)	40
Create messages	56
Currency converter	104
Customer Care	144

D		
Data counter	120	
Date format	131	
Declaration of conformity	147	
Device manager	127	
Dialled calls (call log)	50	
Dialling code	34	
Dialling with number keys	34	
Dictating machine	98	
Digital Rights Management	22	
Display	115	
Backlight time	117	
Brightness	117	
Duration/charges	51	
Greeting message	117	
Language	126	
Logo	115	
Power save	117	
Screensaver	116	
Symbols	13	
Wallpaper	115	
Distribution list	41	
Divert calls	123	
Download	93	
Driving safety	159	
DTMF tones (tone sequences)	40	
Duration/charges	51	
E		
E-mail		
Account	75	
Create	60	
Retrieve/read	65	
Settings	74	
Emergency number	20	
End user license agreement	161	
Extras	101	
F		
Fast access	122	
Fast list search	25	
Fast network search	135	
File system	126	
Flash	55	
FM radio	103	
G		
Games	95	
My Stuff	111	
GPRS	120	
Greeting message	117	
H		
Handset volume	35	
Handsfree talking	36	
Headset		
Accessories	149	
Settings	137	
Hide ID on/off	123	
Hold call	36, 38	
Hotline	144	
I		
IMEI number	127	
Inbox	62	
Info tones	126	
Input language	31, 126	
Inst. Message	78	
Contacts	79	
End conversation	82	
Login/logout	78	
My presence	84	
Options	84	
Receive conversation	82	
Settings	85	
Start conversation	80	
View conversation	81	
International dialling code	35	
Internet	89	
Games	95	
Profiles	121	
IrDA	118	
J		
Java Application Manager (JAM)	93	
K		
Key lock	12	
Automatically	132	
Key tones	126	
L		
Language	126	
Legal notices	3	
Line	134	
Linger time	121	
Logo	115	
Lost of phone, SIM card	147	

174 Index

M

Mailbox	88
Main menu	23
Maintenance of phone	146
Mark mode	26
Master reset	129
Media player	107
Bookmarks	108
Music	107
Options	109
Pictures	108
Videos	108
Memory assistant	25
Menu speed dialling	26
Menu tree	165
Message	
Cell broadcast	62
Drafts	69
E-mail	60
Inbox	62
Inst. Message	78
MMS	56
Sent	69
Settings	70
SMS	56
WAP push	63
Microphone on/off	38
Missed calls (log list)	50
MMS	
Create	56
Receive	62
Settings	72
Mobile Navigation	112
Mobile Phone Manager	138
MultiMediaCard	16
Eject	127
Multitainment	150
Music	107
Muting (microphone)	38
My Stuff	110

N

Navigation key	23
Network	134
Choose	134
Fast search	135
Info	134
Line	134
No connection	141
Preferred	135
Select band	135

O

Offline mode	22
Only protected SIM	132
Operating time	18
Battery	147
Organiser	96
Overview phone	11

P

PC connection	29
Phone	
Operating time	147
Overview	11
Security settings	132
Technical data	147
Phone code	28
Phone identity number (IMEI)	127
Picture	
My Stuff	111
Take picture	53
PIN	
Change	28
Control	28
Enter	19
Error	143
Phone code	28
PIN2	28
Power save	117
Preferred network	135
Preventing accidental activation	29
Product data	147
Profiles	113
PUK, PUK2	28

Q

Questions & Answers	140
---------------------------	-----

R

Radio	103
Received calls (call log)	50
Redial	35
Remote sync	99
Ringtones	114

S

Safety precautions	5
Screensaver	116
Security	
Codes	28
Settings	132
Settings	113
Short cuts	122

	Index	175
Short message (SMS)	56	
Show clock on/off	131	
Shutdown animation	116	
Signal strength	21	
Silent Alert	117	
SIM card		
Clear barring	29	
Insert	15	
Problems	141	
Toolkit	101	
SMS		
Create	56	
Receive	62	
Settings	70	
SOS	9, 20	
Sound recorder	105	
Sounds		
My Stuff	111	
Playback	106	
Record	105	
Special characters	30	
Standard functions	24	
Standby mode	21	
Standby time	18, 147	
Startup animation	116	
Stopwatch	106	
Swap calls	36	
Switch on/off phone	19	
Symbols	13	
T		
T9		
On/off	126	
Text entry	31	
Tabs	23	
Talk time (battery)	147	
Task switching	27	
Key	11	
Technical data	147	
Templates	33	
Text entry		
Edit menu	31	
Input language	31	
T9 on/off	126	
With T9	31	
Without T9	30	
Text module	33	
Themes	115	
This SIM only on/off	132	
Time format	130	
Time zones	20, 98, 130	
Time/Date	20, 130	
U		
User guide symbols	22	
V		
Vibration	117	
Video		
Media player	108	
My Stuff	111	
Take video	53	
Video call		
End	34	
Key	11	
Options	38	
Settings	125	
Voice dialling	48	
Activate	49	
On/off	126	
Record voice tag	48	
Voice message (mailbox)	88	
Volume		
Handset volume	35	
Keys	12	
W		
Wallpaper	115	
Wallpaper (display)	115	
WAP	89	
WAP push		
Read/load	68	
Receive	63	
Settings	91	
Wildcard	43	