

NETGEAR®

LTE Broadband 11n Wireless Router MBR1515

User Manual



350 East Plumeria Drive
San Jose, CA 95134
USA02-10972-01

June 2012
202-10934-01
v1.0

LTE Broadband 11n Wireless Router MBR1515

© 2012 All rights reserved

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means without the written permission of NETGEAR, Inc.

NETGEAR, the NETGEAR logo, and Connect with Innovation are trademarks and/or registered trademarks of NETGEAR, Inc. and/or its subsidiaries in the United States and/or other countries. Information is subject to change without notice. Other brand and product names are registered trademarks or trademarks of their respective holders. © 2012 All rights reserved.

Technical Support

Thank you for choosing NETGEAR. To register your product, get the latest product updates, get support online, or for more information about the topics covered in this manual, visit the Support website at

<http://support.netgear.com>

Phone (US & Canada only): 1-888-NETGEAR

Phone (Other Countries): Check the list of phone numbers at

http://support.netgear.com/app/answers/detail/a_id/984

Statement of Conditions

To improve internal design, operational function, and/or reliability, NETGEAR reserves the right to make changes to the products described in this document without notice. NETGEAR does not assume any liability that may occur due to the use, or application of, the product(s) or circuit layout(s) described herein.

Table of Contents

Chapter 1 Connecting to the Internet

Hardware Features	7
Router Stand	7
Router Front Panel	8
Router Back Panel	10
Router Label	10
Log In to Your Router	11
Access the Configuration Assistant after Installation	13
Manually Configure Your Internet Settings	14
Broadband Settings	14
Mobile Broadband Settings	16
Ethernet Broadband Settings	18

Chapter 2 Wireless Network Configuration

Planning Your Wireless Network	25
Wireless Placement and Range Guidelines	25
Wireless Security Options	26
Manually Configure Your Wireless Settings	27
Configuring WEP	28
Configuring WPA, WPA2, or WPA + WPA2	29
Use Push 'N' Connect (WPS) to Configure Your Wireless Network	30
WPS Button	30
WPS PIN Entry	31
Add Wireless Computers That Do Not Support WPS	32
SIM Card PIN Code	33
SIM Card Modem Unlock Code	34

Chapter 3 Content Filtering

Viewing, Selecting, and Saving Logged Information	37
Log Message Examples	39
Blocking Sites and Keywords	40
Blocking Services	42
Scheduling	43
Setting Your Time Zone	43
Scheduling Firewall Services	43
Enabling Security Event Email Notification	44

Chapter 4 Managing Your Network

Router Status	46
Showing Statistics	48
Connection Status	49
Viewing Attached Devices	50
Backing Up, Restoring, or Erasing Your Settings.	51
Backing Up the Configuration to a File.	51
Restoring the Configuration from a File	51
Erasing the Configuration.	52
Protecting Access to Your Router	52
Changing the Built-In Password	52
Changing the Administrator Login Time-Out	53
Running Diagnostic Utilities and Rebooting the Router	53
Upgrading the Router Firmware	55

Chapter 5 Advanced

SIM Settings.	57
SMS Messages	57
View SMS Messages	57
Send SMS Messages.	59
Advanced Wireless Settings.	60
Wireless Station Access Control	61
Restricting Access by MAC Address	61
Wireless Repeating Function	63
Port Forwarding and Port Triggering	64
Port Forwarding	64
Port Triggering	65
WAN Setup.	65
Setting Up a Default DMZ Server.	66
LAN Setup	67
DHCP Settings	68
Reserved IP Addresses	69
QoS Setup	71
QoS Priority Rule List.	72
QoS Priority Rules	72
Dynamic DNS.	75
Using Static Routes	76
Static Route Example.	76
Enabling Remote Management	77
Universal Plug and Play	78
Traffic Meter	80
IPv6 Internet Configuration and Status Check	81

Chapter 6 Troubleshooting

Basic Functioning	88
Troubleshooting Access to the Router Main Menu	90

LTE Broadband 11n Wireless Router MBR1515

Troubleshooting the ISP Connection	91
Connecting to the Internet	91
Troubleshooting Internet Browsing	92
Troubleshooting a TCP/IP Network Using the Ping Utility	93
Testing the LAN Path to Your Router	93
Testing the Path from Your Computer to a Remote Device	94
Problems with Date and Time	95
Restoring the Default Configuration and Password	95

Appendix A Supplemental Information

Factory Default Settings	97
Technical Specifications	99

Appendix B Wall-Mounting

Appendix C Compliance Notification

Index

Connecting to the Internet

1

This chapter describes how to configure your LTE Broadband 11n Wireless Router MBR1515 Internet connection.

- *Hardware Features*
- *Log In to Your Router*
- *Access the Configuration Assistant after Installation*
- *Manually Configure Your Internet Settings*

Note: For help with installation, see the *LTE Broadband 11n Wireless Router MBR1515 Installation Guide*.

Note: For more information on the topics that are covered in this manual, visit the support website at support.netgear.com.

Hardware Features

This section outlines the physical aspects of your LTE Broadband 11n Wireless Router.

Router Stand

Since the LTE Broadband 11n Wireless Router is a vertical-only device, use the stand to position your router upright.


1. Insert the tabs on the stand into the slot on the bottom of your router.
2. Place your router near an AC power outlet in a location where you can connect the cables you need for your home network.

The router must also be located where you can receive a strong mobile broadband signal while indoors if you are planning to connect to the Internet using mobile broadband.





Router Front Panel

The router front panel contains control buttons and status LEDs. Use the LEDs to verify status and connections.











[Table 1](#) describes each LED and button located on the front panel of the router.

Table 1. LED Descriptions

LED	Activity	Description
WPS 		Press the WPS button to open a 2-minute window for the router to connect with other WPS-enabled devices. For more information about this function, see Use Push 'N' Connect (WPS) to Configure Your Wireless Network on page 30.
Wi-Fi 		This button can be used to control the WiFi radio or both the WiFi radio and mobile broadband radio. Use the router interface to select the options. The default is set for Wi-Fi radio only.


LTE Broadband 11n Wireless Router MBR1515

Table 1. LED Descriptions

LED	Activity	Description
	Solid green	The router is turned on and operating normally.
	Solid amber	POST (power-on self-test) in progress.
	Off	Power is not supplied to the router.
	Solid green	There is an Internet session.
	Solid amber	Traffic meter limit has been reached, traffic is blocked.
	Blinking green	Data is being transmitted over the Internet connection.
	Blinking amber	Traffic meter limit has been reached, but traffic not blocked.
	Blinking green and amber	Failover from WAN to Mobile Broadband.
	Off	No Internet connection detected.
	Solid blue	The Wi-Fi local port is initialized.
	Blinking blue	Data is being transmitted or received over the Wi-Fi link.
	Off	The wireless access point is turned off.
	Solid green	The local Ethernet ports have detected wired links with PCs.
	Blinking	Data is being transmitted or received.
	Off	No link is detected on these ports.
	Solid green	The Ethernet WAN port has detected an active link.
	Blinking	Data is being transmitted or received.
	Off	No link is detected on these ports.
	Solid blue	Indicates the router is in 3G+ coverage.
	Solid green	Indicates the router is in 2G coverage.
	Off	No coverage is detected.
	Solid blue	Excellent coverage detected.
	Solid green	Good coverage detected.
	Solid amber	Marginal coverage detected.
	Off	No coverage detected.
	Locate the small hole outlined in red on the back of the router. Insert a paperclip into the hole and push for 6 seconds. Depressing the reset button causes the LED to blink briefly. After the button is held down for more than 6 seconds, the LED will flash AMBER, and then turn green as the router resets to the factory defaults. See	


Router Back Panel

The back panel of the router contains port connections.



Router Label

The label on the left side of the router shows the router's MAC address, serial number, security PIN, IMEI or ESN number, and factory default login information. It also contains the SSID and passphrase that is unique to each router.



Log In to Your Router

When you first connect to your router during installation, a Setup Wizard displays. For help using the Setup Wizard to configure your Internet and wireless network, see the *LTE Broadband 11n Wireless Router MBR1515 Installation Guide*.

After the initial configuration, you can use your Web browser to log in to the router to view or change its settings. Links to Knowledge Base and documentation are also available on the router main menu.

Note: Your computer must be configured for DHCP. For help configuring DHCP, refer to the documentation that came with your computer.

When you have logged in, if you do not click **Logout**, after 5 minutes of no activity the router automatically logs you out.

➤ **To log in to the router:**

1. Type **http://www.routerlogin.net** in the address field of your browser, and then press enter to display the login window.



The screenshot shows a login dialog box with the following elements:

- User name:** A text field containing the text "admin".
- Password:** A text field containing ten black dots, representing a masked password.
- Remember my password:** An unchecked checkbox.
- Buttons:** "OK" and "Cancel" buttons at the bottom.

2. Enter **admin** for the user name and your password (or the default, **password**).

For information about how to change the password, see [Changing the Built-In Password](#) on page 52.

Note: If you do not remember your password, you can restore the router to its factory default settings, which will reset the password. See [Factory Default Settings](#) on page 97.

3. If the router has not been configured, the Smart Wizard screen displays. After the router has been configured, one of the following screens appears:

- **Firmware Upgrade Assistant screen.** After initial setup, the Firmware Upgrade Assistant screen displays unless the **Check for Updated Firmware Upon Log-in** check box is cleared.

Note: You can disable this automatic checking and updating feature during future log ins by clearing the **Check for Updated Firmware Upon Log-in** check box, but NETGEAR recommends that you keep this feature enabled to ensure your router is using the latest updated firmware.




- **Router Status screen.** The Router Status screen displays the current router connection status. See [Router Status](#) on page 46.
4. You can use different methods to configure your router.
- Select Setup Wizard **from the router menu to set up your Internet connection and wireless network configuration.** See [Access the Configuration Assistant after Installation](#) on page 13.
 - You can manually configure the router settings. See [Manually Configure Your Internet Settings](#) on page 14.

Access the Configuration Assistant after Installation

1. Log in to the router as described in *Log In to Your Router* on page 11.

The Configuration Assistant opens.




2. Click **Next**.

The Configuration Assistant prompts you to set up your Internet connection and wireless network as described in the *LTE Broadband 11n Wireless Router MBR1515 Installation Guide*.

- a. Select your Internet connection mode:

- Use Ethernet first and if fail use mobile broadband connection
- Always use mobile broadband connection
- Always use Ethernet connection



- b. Click **Next**.
- c. Select your **country** and then your **Internet Service Provider**.
- d. Click **Done**.

Manually Configure Your Internet Settings

For you to connect to the network, an active broadband service account is required. Contact your ISP for your user name, password, and the network name. You must also configure some or all of the settings described in the following sections, depending on how you have chosen to connect to the Internet:

- [Broadband Settings](#) on page 14.
- [Mobile Broadband Settings](#) on page 16 (not required if using Ethernet connection only).
- [Ethernet Broadband Settings](#) on page 18 (not required if using mobile broadband connection only).

Broadband Settings

➤ **To manually configure your broadband Internet settings:**

1. Log in to the router as described in [Log In to Your Router](#) on page 11.
2. From the main menu, select Broadband Settings.

3. Adjust the settings as needed based on your Internet connection. The fields in this screen are described in [Table 2](#).

LTE Broadband 11n Wireless Router MBR1515

4. The following buttons are available:
- **Apply.** Apply the changes that you made.
 - **Cancel.** Discard changes.

Table 2. Internet Connection Settings

Fields and Check Boxes	Description
Internet Connection Mode	The choices are: <ul style="list-style-type: none">• Always use an Ethernet connection (default)• Use Ethernet first and if it fails use mobile broadband connection• Always use mobile broadband connection
Failover Detection Method ¹	Select the failover method and enter the related information: <ul style="list-style-type: none">• DNS lookup using WAN DNS Server• Perform a DNS lookup by a hostname• Ping this IP address
Retry Interval is ¹	Enter the retry interval.
Failover after ¹	Enter how many retry attempts to make before failing over.
Resume after ¹	Enter how long to wait for primary link is stabilized before resuming to use the primary link.
Enable Hardware link detection	Enter when to failover when the Ethernet link is dropped. This is independent of the DNS / Ping detection methods.

*1. This field is available only when the Internet Connection Mode is **Use Ethernet first and if fail use 3G mobile connection.***

Mobile Broadband Settings

➤ To manually configure your mobile broadband Internet settings:

1. Log in to the router as described in [Log In to Your Router](#) on page 11.
2. From the main menu, select Mobile Broadband Settings.

Mobile Broadband Settings

User Name

Password

Country

Internet Service Provider

Access Number

APN

PDP Type

Connect automatically at startup

Reconnect automatically when connection is lost

Roaming automatically

Use internal antenna

Wireless Button Configuration

Control WiFi Only Control Both WiFi and Wireless Broadband

Connection Status NO SIM Card Detected

3. Adjust the settings as needed based on your Internet connection. The fields in this screen are described in [Table 3](#).
4. Available buttons are:
 - **Connect.** Manually connect to the network.
 - **Disconnect.** Disconnect from the current network.
 - **Apply.** Apply the changes that you made.
 - **Cancel.** Discard changes.
 - **Refresh.** Update the connection status

LTE Broadband 11n Wireless Router MBR1515

Table 3. Settings

Fields and Check Boxes	Description
User Name	Internet account login user name.
Password	Internet account password for authentication.
Country	Select your country from the drop-down list.
Internet Service Provider	Select your Internet Service Provider from the drop-down list.
Access Number	The remote site's phone number.
PIN code	Pin code of the SIM card, where applicable.
APN	Access point name.
PDP type	Select the type of packet data protocol: <ul style="list-style-type: none"> • IP • PDP-IP • PPP • PPP-IP
Connect automatically at startup	When this check box is selected, the modem automatically connects to the network when powered up. This should be selected after login information is provided.
Reconnect automatically when connection is lost	When this check box is selected, the modem will attempt to reconnect to the network when the connection is lost. Under normal situations, this setting should be selected.
Roaming automatically	When this check box is checked, the unit might roam to any available operator in range and might incur roaming charges.
Use internal antenna	If this check box is selected, the router will use the internal antenna rather than the external antenna.
Wireless Button Configuration	Select the option to determine the behavior of the WPS push button on the front panel when pressed. <ul style="list-style-type: none"> • Control Wi-Fi Only: Pressing the push button toggles the Wi-Fi function. If Wi-Fi is turned on, pressing the push button turns off the Wi-Fi. Pressing it again will turn on the Wi-Fi. This function is available only if the Wi-Fi function is enabled. The Wireless Broadband function is unaffected. • Control Both Wi-Fi and Wireless Broadband: Pressing the push button toggles both the Wi-Fi function and wireless broadband at the same time. If Wi-Fi is turned on, pressing the push button turns off the Wi-Fi. At the same time, the wireless broadband connection is disconnected. If you press the push button again, Wi-Fi is turned on and the router attempts to re-establish the wireless broadband connection. Depending on the coverage, wireless broadband coverage might or might not be connected successfully.
Connection status	Current WAN port status.

Ethernet Broadband Settings

➤ **To manually configure your Ethernet Broadband Internet settings:**

1. Log in to the router as described in [Log In to Your Router](#) on page 11.
2. From the main menu, select Ethernet Broadband Settings.

The following question displays at the top of the screen:



Does Your Internet Connection Require A Login?

Yes

No

Select the option based on the type of account you have with your ISP.

- If you need to enter login information every time you connect to the Internet, or you have a PPPoE account with your ISP, select **Yes**.
- Otherwise, select **No**.

Then fill out the appropriate screen.

For details, see:

[step a, Login required](#) on page 18

or

[step b, Login not required](#) on page 20.

Note: If you have installed PPP software such as WinPoET (from Earthlink) or Enternet (from PacBell), then you have PPPoE. Select **Yes**. After selecting **Yes** and configuring your router, you do not need to run the PPP software on your PC to connect to the Internet.

a. Login required

Adjust the settings as needed based on your Internet connection. The fields in this screen are described in [Table 4](#).

LTE Broadband 11n Wireless Router MBR1515

Ethernet Broadband Settings

Does Your Internet Connection Require A Login?

Yes
 No

Internet Service Provider Other ▾

Login

Password

Service Name (If Required)

Connection Mode Always On ▾

Idle Timeout (In Minutes)

Internet IP Address

Get Dynamically From ISP
 Use Static IP Address 75 . 229 . 41 . 218

Domain Name Server (DNS) Address

Get Automatically From ISP
 Use These DNS Servers

Primary DNS . . .

Secondary DNS . . .

Table 4. Ethernet Broadband Settings When Login Required

Fields and Checkboxes	Description
Internet Service Provider	Select the service provided by your ISP. <ul style="list-style-type: none"> • Other (PPPoE) is the most common. • PPTP is used in Austria and other European countries. • Telstra BigPond is for Australia only.
Login	This is usually the name that you use in your email address. For example, if your main mail account is JerAB@ISP.com, then put JerAB in this field. Some ISPs (such as Mindspring, Earthlink, and T-DSL) require that you use your full email address when you log in. If your ISP requires your full email address, then type it in the Login field.
Password	Type the password that you use to log in to your ISP.
Service Name (If Required)	If your ISP provided a service name, enter it here. Otherwise, this can be left blank.

Table 4. Ethernet Broadband Settings When Login Required

Fields and Checkboxes	Description
Connection Mode	<p>Set the connection mode to Dial on Demand, Always On, or Manually Connect.</p> <ul style="list-style-type: none"> • With the default setting, Dial on Demand, a PPPoE connection automatically starts when there is outbound traffic to the Internet, and it automatically terminates if the connection is idle based on the value in the Idle Timeout field. • When the connection mode is set to Always On, the PPPoE connection automatically starts when the computer boots up, but the connection does not time out. The router will keep trying to bring up the connection if it is disconnected for some reason. • If you select Manually Connect, you must go to the Router Status screen and click the Connect button to connect to the Internet. The manual connection does not time out, and you have to click the Disconnect button on the Router Status screen to disconnect it.
Idle Timeout (In Minutes)	<p>An idle Internet connection will be terminated after this time period. If this value is zero (0), then the router will keep the connection alive by reconnecting immediately whenever the connection is lost.</p>
Internet IP Address	<p>If you log in to your service or your ISP did not provide you with a fixed IP address, the router finds an IP address for you automatically when you connect. Select Get Dynamically from ISP.</p> <p>If you have a fixed (static, permanent) IP address, your ISP has provided you with an IP address. Select Use Static IP Address and type in the IP address.</p>
Domain Name Server (DNS) Address	<p>The DNS server is used to look up site addresses based on their names.</p> <ul style="list-style-type: none"> • If your ISP gave you one or two DNS addresses, select Use These DNS Servers and type the primary and secondary addresses. • Otherwise, select Get Automatically From ISP. <p>Note: If you get “Address not found” errors when you go to a website, it is likely that your DNS servers are not set up correctly. You should contact your ISP to get DNS server addresses.</p>

b. Login not required

Adjust the settings as needed based on your Internet connection. The fields in this screen are described in [Table 5](#).

LTE Broadband 11n Wireless Router MBR1515

Ethernet Broadband Settings

Does Your Internet Connection Require A Login?

Yes

No

Account Name (If Required)

Domain Name (If Required)

Internet IP Address

Get Dynamically From ISP

Use Static IP Address

IP Address

IP Subnet Mask

Gateway IP Address

Domain Name Server (DNS) Address

Get Automatically From ISP

Use These DNS Servers

Primary DNS

Secondary DNS

Router MAC Address

Use Default Address

Use Computer MAC Address

Use This MAC Address

LTE Broadband 11n Wireless Router MBR1515

Table 5. Ethernet Broadband Settings Fields When Login Not Required

Fields and Check Boxes	Description
Account Name (If Required)	<p>This is also known as the host name or system name.</p> <p>For most users, type your account name or user name in this field. For example, if your main mail account is JerAB@ISP.com, then put JerAB in this field.</p> <p>If your ISP has given you a specific host name, then type it (for example, CCA7324-A).</p>
Domain Name (If Required)	<p>For most users, you can leave this field blank, unless required by your ISP. You can type the domain name of your ISP. For example, if your ISP's mail server is mail.xxx.yyy.zzz, you would type xxx.yyy.zzz as the domain name.</p> <p>If you have a domain name given to you by your ISP, type it in this field. (For example, Earthlink Cable might require a host name of home, and Comcast sometimes supplies a domain name.)</p> <p>If you have a cable modem, this is usually the workgroup name.</p>
Internet IP Address	<p>If you log in to your service or your ISP did not provide you with a fixed IP address, the router finds an IP address for you automatically when you connect. Select Get Dynamically From ISP.</p> <p>If you have a fixed (or static IP) address, your ISP has provided you with the required information. Select Use Static IP Address and type the IP address, subnet mask and gateway IP address into the correct fields.</p> <p>For example:</p> <ul style="list-style-type: none"> • IP Address. 24.218.156.183 • Subnet Mask. 255.255.255.0 • Gateway IP Address. 24.218.156.1
Domain Name Server (DNS) Address	<p>The DNS server is used to look up site addresses based on their names.</p> <ul style="list-style-type: none"> • If your ISP gave you one or two DNS addresses, select Use These DNS Servers and type the primary and secondary addresses. • Otherwise, select Get Automatically From ISP. <p>Note: If you get "Address not found" errors when you go to a website, it is likely that your DNS servers are not set up correctly. You should contact your ISP to get DNS server addresses.</p>
Router MAC Address	<p>Your computer's local address is its unique address on your network. This is also referred to as the computer's MAC (Media Access Control) address.</p> <ul style="list-style-type: none"> • Usually, select Use Default MAC Address. • If your ISP requires MAC authentication, then select either Use Computer MAC Address to disguise the router's MAC address with the computer's own MAC address, or Use This MAC Address to manually type the MAC address for a different computer. <p>The format for the MAC address is XX:XX:XX:XX:XX:XX. This value might be changed if Use Computer MAC Address is selected once a value has already been set in the Use This MAC Address selection.</p>

3. The following buttons are available:
 - **Apply**. Apply the changes that you made.
 - **Cancel**. Discard changes.
 - **Test**. Connect to the NETGEAR website. If you connect successfully, your settings work, and you can click **Logout** to exit these screens.

2 Wireless Network Configuration

2

For a wireless connection, the SSID, (also known as the wireless network name), and the wireless security settings must be the same for the router and wireless computers or wireless adapters. NETGEAR strongly recommends that you use wireless security.

The router is pre-configured with WPA-PSK/WPA2-PSK mixed mode and uses a unique SSID and passphrase. This information is printed on the label on the bottom of the router. Use this information to setup your WiFi computer and devices.

This chapter addresses the following:

- *Planning Your Wireless Network*
- *Manually Configure Your Wireless Settings*
- *Use Push 'N' Connect (WPS) to Configure Your Wireless Network*

Note: Computers can connect wirelessly at a range of several hundred feet. If you do not use wireless security, this can allow others outside your immediate area to access your network.

Planning Your Wireless Network

For compliance and compatibility between similar products in your area, the operating channel and region must be set correctly.

To configure the wireless network, you can either specify the wireless settings, or you can use Wi-Fi Protected Setup (WPS) to automatically set the SSID and implement WPA/WPA2 security.

- To manually configure the wireless settings, you must know the following:
 - SSID. The default SSID for the router is NETGEAR-3G.
 - The wireless mode (802.11n, 802.11g, or 802.11b) that each wireless adapter supports.
 - Wireless security option. To successfully implement wireless security, check each wireless adapter to determine which wireless security option it supports.

See *Manually Configure Your Wireless Settings* on page 27.

- Push 'N' Connect (WPS) implements WPA/WPA2 wireless security on the router and your wireless computer or device at the same time. The wireless computer or device must be compatible with WPS.

See *Use Push 'N' Connect (WPS) to Configure Your Wireless Network* on page 30.

Wireless Placement and Range Guidelines

The range of your wireless connection can vary significantly based on the physical placement of the router. The latency, data throughput performance, and notebook power consumption of wireless adapters also vary depending on your configuration choices.

For best results, place your router according to the following guidelines:

- Near the center of the area in which your computers will operate.
- In an elevated location, such as a high shelf, where the wirelessly connected computers have line-of-sight access (even if through walls).
- Away from sources of interference, such as microwave ovens, and 2.4 GHz cordless phones (see *Interference Reduction Table* on page 105).
- Away from large metal surfaces.
- Put the antenna in a vertical position to provide the best side-to-side coverage. Put the antenna in a horizontal position to provide the best up-and-down coverage.
- If using multiple access points, it is better if adjacent access points use different radio frequency channels to reduce interference. The recommended channel spacing between adjacent access points is 5 channels (for example, use Channels 1 and 6, or 6 and 11).

The time it takes to establish a wireless connection can vary depending on both your security settings and placement. WEP connections can take slightly longer to establish. Also, WEP encryption can consume more battery power on a notebook computer.

Wireless Security Options

Indoors, computers can connect over 802.11n wireless networks at a maximum range of up to 300 feet. Such distances can allow others outside your immediate area to access your network.

Unlike wired network data, your wireless data transmissions can extend beyond your walls and can be received by anyone with a compatible adapter. For this reason, use the security features of your wireless equipment. The LTE Broadband 11n Wireless Router provides highly effective security features, which are covered in detail in this chapter. Deploy the security features appropriate to your needs.

Each router is preconfigured for WPA-PSK/WPA2-PSK mixed-mode, and comes with a unique SSID and passphrase for each router.

There are several ways you can enhance the security of your wireless network:



- **Restrict access based on MAC address.** You can allow only trusted PCs to connect so that unknown PCs cannot wirelessly connect to the router. Restricting access by MAC address adds an obstacle against unwanted access to your network, but the data broadcast over the wireless link is fully exposed.
- **Turn off the broadcast of the wireless network name (SSID).** If you disable broadcast of the SSID, only devices that have the correct SSID can connect. This nullifies wireless network “discovery” feature of some products, such as Windows XP, but the data is still exposed.
- **WEP.** Wired Equivalent Privacy (WEP) data encryption provides data security. WEP Shared Key authentication and WEP data encryption block all but the most determined eavesdropper. This data encryption mode has been superseded by WPA-PSK and WPA2-PSK.
- **WPA-PSK (TKIP), WPA2-PSK (AES).** Wi-Fi Protected Access (WPA) using a pre-shared key to perform authentication and generate the initial data encryption keys. The very strong authentication along with dynamic per frame re-keying of WPA makes it virtually impossible to compromise.

Manually Configure Your Wireless Settings

Note: If you use a wireless computer to change the wireless network name (SSID) or wireless security, you will be disconnected when you click **Apply**. To avoid this occurrence, connect your computer directly to the router with an Ethernet cable while you are making changes.

➤ **To view or manually configure the wireless settings:**

1. Log in to the router as described in *Log In to Your Router* on page 11.

2. Select Wireless Settings from the main menu.

The settings for this screen are explained in the table below.

3. Select the region in which the router will operate.

4. For initial configuration and test, leave the other settings unchanged.

5. To save your changes, click **Apply**.

6. Configure and test your computers for wireless connectivity.

Set up your wireless computers with the same SSID and wireless security settings as your router. Check that they have a wireless link and are able to obtain an IP address by DHCP from the router. If there is interference, adjust the channel.

Settings		Description
Wireless Network	Name (SSID)	The SSID is also known as the wireless network name. Enter a 32-character (maximum) name in this field. This field is case-sensitive. When there is more than one wireless network, SSIDs provide a means for separating the traffic. To join a network, a wireless computer or device must use the SSID.
	Region	The location where the router is used.
	Channel	The wireless channel used by the gateway. The default is Auto . Do not change the channel unless you experience interference (shown by lost connections or slow data transfers). If this happens, you might need to try different channels to see which works best.
	Mode	The default is Up to 145 Mbps.

Settings		Description
Security Options	None	Use this setting to establish wireless connectivity before implementing wireless security. NETGEAR strongly recommends that you implement wireless security.
	WEP	Use encryption keys and data encryption for data security. You can select 64-bit or 128-bit encryption. See <i>Configuring WEP</i> on page 28.
	WPA-PSK (TKIP)	Allow only computers configured with WPA to connect to the router. See <i>Configuring WPA, WPA2, or WPA + WPA2</i> on page 29.
	WPA2-PSK (AES)	Allow only computers configured with WPA2 to connect to the router. See <i>Configuring WPA, WPA2, or WPA + WPA2</i> on page 29.
	WPA-PSK (TKIP) + WPA2-PSK (AES)	Allow computers configured with either WPA-PSK or WPA2-PSK security to connect to the router. See <i>Configuring WPA, WPA2, or WPA + WPA2</i> on page 29.

Configuring WEP

Note: If you use a wireless computer to configure wireless security settings, you will be disconnected when you click **Apply**. Reconfigure your wireless computer to match the new settings, or access the router from a wired computer to make further changes.

➤ **To configure WEP data encryption:**

1. Log in to the router as described in *Log In to Your Router* on page 11.
2. From the main menu, select Wireless Settings to display the Wireless Settings screen.
3. In the Security Options section, select the **WEP** (Wired Equivalent Privacy) radio button:
4. Select the **Authentication Type** setting: **Automatic**, **Open System**, or **Shared Key**. The default is **Open System**.

Note: *The authentication is separate from the data encryption. You can select authentication that requires a shared key, but still leaves data transmissions unencrypted. Security is stronger if you use both the Shared Key and WEP encryption settings.*

5. Select the **Encryption Strength** setting:
 - **64-bit.** Enter 10 hexadecimal digits (any combination of 0–9, a–f, or A–F).

- **128-bit.** Enter 26 hexadecimal digits (any combination of 0–9, a–f, or A–F).
6. Enter the encryption keys. You can manually or automatically program the four data encryption keys. These values must be identical on all computers and access points in your network:
- **Passphrase.** To use a passphrase to generate the keys, enter a passphrase, and click **Generate**. This automatically creates the keys. Wireless stations must use the passphrase or keys to access the router.

Note: *Not all wireless adapters support passphrase key generation.*

- **Key 1–Key4.** These values are *not* case-sensitive. You can manually enter the four data encryption keys. These values must be identical on all computers and access points in your network. Enter 10 hexadecimal digits (any combination of 0–9, a–f, or A–F).
7. Select which of the four keys will be the default.
- Data transmissions are always encrypted using the default key. The other keys can be used only to decrypt received data. The four entries are disabled if WPA-PSK or WPA authentication is selected.
8. Click **Apply** to save your settings.

Configuring WPA, WPA2, or WPA + WPA2

Both WPA and WPA2 provide strong data security. WPA with TKIP is a software implementation that can be used on Windows systems with Service Pack 2 or later; WPA2 with AES is a hardware implementation; see your device documentation before implementing it. Consult the product documentation for your wireless adapter for instructions for configuring WPA settings.

Note: If you use a wireless computer to configure wireless security settings, you will be disconnected when you click **Apply**. If this happens, reconfigure your wireless computer to match the new settings, or access the router from a wired computer to make further changes.


➤ **To configure WPA or WPA2 in the router:**

1. Log in to the router as described in [Log In to Your Router](#) on page 11.
2. Select Wireless Settings from the main menu.

3. On the Wireless Setting screen, select the radio button for the WPA or WPA2 option of your choice.

4. For WPA-PSK or WPA2-PSK, enter the passphrase.
5. To save your settings, click **Apply**.

Use Push 'N' Connect (WPS) to Configure Your Wireless Network

To use Push 'N' Connect, your wireless computers or devices must support Wi-Fi Protected Setup (WPS). Compatible equipment usually has the  WPS symbol on it. WPS can configure the network name (SSID) and set up WPA/WPA2 wireless security for the router and the wireless computer or device at the same time.

WPS considerations:

- NETGEAR's Push 'N' Connect feature is based on the WPS standard. All other Wi-Fi-certified and WPS-capable products should be compatible with NETGEAR products that implement Push 'N' Connect.
- If your wireless network will include a combination of WPS-capable devices and non-WPS-capable devices, NETGEAR suggests that you set up your wireless network and security settings manually first, and use WPS only for adding WPS-capable devices.

WPS Button

Any wireless computer or wireless adapter that will connect to the router wirelessly is a client. The client must support a WPS button, and must have a WPS configuration utility, such as the NETGEAR Smart Wizard or Atheros Jumpstart.


➤ **To use the router WPS button to add a WPS client:**

1. Log in to the router as described in [Log In to Your Router](#) on page 11.

2. On the router main menu, select Add WPS Client, and then click **Next**.

By default, the **Push Button (recommended)** radio button is selected.


3. Either click the onscreen button or press the WPS button on the front of the router.



The router tries to communicate with the client (the computer that wants to join the network) for 2 minutes.

4. Go to the client wireless computer, and run a WPS configuration utility. Follow the utility's instructions to click a WPS button.
5. Go back to the router screen to check for a message.

The router WPS screen displays a message confirming that the client was added to the wireless network. The router generates an SSID, and implements WPA/WPA2 wireless security. The router will keep these wireless settings unless you change them, or you clear the **Keep Existing Wireless Settings** check box in the Advanced Wireless Settings/WPS Settings screen.



6. Note the new SSID and WPA/WPA2 password for the wireless network. You can view these settings in the Wireless Settings screen. See [Manually Configure Your Wireless Settings](#) on page 27.

To access the Internet from any computer connected to your router, launch a browser such as Microsoft Internet Explorer or Mozilla Firefox. You should see the router's Internet LED blink, indicating communication to the ISP.

Note: If no WPS-capable client devices are located during the 2-minute time frame, the SSID does not change, and no security is set up.

WPS PIN Entry


Any wireless computer or device that will connect to the router wirelessly is a client. The client must support a WPS PIN, and must have a WPS configuration utility, such as the NETGEAR Smart Wizard or Atheros Jumpstart.

The first time you add a WPS client, make sure that the **Keep Existing Wireless Settings** check box on the WPS Settings screen is cleared. This is the default setting for the router, and allows it to generate the SSID and WPA/WPA2 security settings when it implements

WPS. After WPS is implemented, the router automatically selects this check box so that your SSID and wireless security settings stay the same if other WPS devices are added later.

➤ **To use a PIN to add a WPS client:**

1. Log in to the router as described in [Log In to Your Router](#) on page 11.
2. On the router main menu, select Add WPS Client (computers that will connect wirelessly to the router are clients), and then click **Next**. The Add WPS Client screen displays.
3. Select the **PIN Number** radio button.
4. Go to the client wireless computer. Run a WPS configuration utility. Follow the utility's instructions to generate a PIN. Take note of the client PIN.
5. In the router Add WPS Client screen, enter the client PIN number, and then click **Next**.
 - The router tries to communicate with the client for 4 minutes. If no WPS clients connect during this time, the router wireless settings do not change.
 - The router WPS screen confirms that the client was added to the wireless network. The router generates an SSID, and implements WPA/WPA2 wireless security.
6. Note the new SSID and WPA/WPA2 password for the wireless network. You can view these settings in the Wireless Settings screen. See [Manually Configure Your Wireless Settings](#) on page 27.



To access the Internet from any computer connected to your router, launch an Internet browser such as Mozilla Firefox. You should see the router's Internet LED blink.

Add Wireless Computers That Do Not Support WPS

If you set up your network with WPS, and now you want to add a computer that does not support WPS, you must manually configure that computer. For information about how to view the wireless settings for the router, see [Manually Configure Your Wireless Settings](#) on page 27.

Because WPA randomly creates the SSID and WPA/WPA2 keys, they might be difficult to type or remember (that is one reason why the network is so secure). You can change the wireless settings so that they are easier for you to remember. If you do that, then you will need to set up the WPS-compatible computers again.

Note: Making these changes will cause all wireless computers to be disconnected from network. You will then have to set them up with the new wireless settings.

➤ **To change wireless settings for the network:**

1. Use an Ethernet cable to connect a computer to the router. That way you will not get disconnected when you change the wireless settings.
2. Log in to the router and select Wireless Settings (see [Manually Configure Your Wireless Settings](#) on page 27).
3. Make the following changes:
 - Change the wireless network name (SSID) to a meaningful name.
 - On the WPA/PSK + WPA2/PSK screen, select a passphrase.
 - Make sure that the **Keep Wireless Settings** check box is selected in the WPS Settings screen so that your new settings will not be erased if you use WPS.
4. Click **Apply** so that your changes take effect. Write down your settings.

All existing wireless clients are disassociated and disconnected from the router.

5. For the non-WPS devices that you want to connect, open the networking utility and follow the utility's instructions to enter the security settings that you selected in Step 3 (the SSID, WPA/PSK + WPA2/PSK security method, and passphrase).
6. For the WPS devices that you want to connect, follow the procedure [WPS Button](#) on page 30 or [WPS PIN Entry](#) on page 31.

The settings that you configured in Step 3 are broadcast to the WPS devices so that they can connect to the router.

SIM Card PIN Code

Some SIM cards may have a PIN code associated with them. Without the PIN code, you will not be able to access the internet. This status appears when a PIN is required, but has not yet been entered.




➤ **To enter the PIN code:**

1. Log into the router and select **Mobile Broadband Settings** from the navigation tab.
2. Enter the PIN Code.

LTE Broadband 11n Wireless Router MBR1515

Check with the router company if you do not know the PIN code.


PIN Code →



The screenshot shows the 'Mobile Broadband Settings' page. The 'PIN Code' field is circled in red, and a red arrow points to it from the text 'PIN Code' on the left. The page includes fields for User Name, Password, Country (Canada), Internet Service Provider (Bell Mobility), PIN Code, Access Number (*99#), APN (inet.bell.ca), and PDP Type (IP). There are also checkboxes for 'Connect automatically at startup', 'Reconnect automatically When connection is lost', 'Roaming automatically', and 'Use internal antenna'. The 'Wireless Button Configuration' section has radio buttons for 'Control WiFi Only' (selected) and 'Control Both WiFi and Wireless Broadband'. The 'Connection Status' at the bottom right indicates 'PIN Required'.

SIM Card Modem Unlock Code

If you have a SIM card that is not provided by the company where you got the router, you might get an error indicating the modem is locked. To proceed, you must enter an unlock code.




➤ **To enter the modem unlock code:**

1. Log into the router and select **Mobile Broadband Settings** from the navigation tab.
2. Enter the Modem Unlock Code.

LTE Broadband 11n Wireless Router MBR1515

The modem unlock code can be obtained from the company that supplied the router.

**Modem
Unlock
Code**



Mobile Broadband Settings

User Name: <none>
Password: <none>

Country: Canada
Internet Service Provider: Bell Mobility
Modem Unlock Code:

Access Number: *99#
APN: inet.bell.ca
PDP Type: IP

Connect automatically at startup
 Reconnect automatically When connection is lost
 Roaming automatically
 Use internal antenna

Wireless Button Configuration

Control WiFi Only Control Both WiFi and Wireless Broadband

Connection Status Modem Unlock Code Required

3 Content Filtering

3

This chapter describes how to use the basic firewall features of the router to protect your network.

- *Viewing, Selecting, and Saving Logged Information*
- *Blocking Sites and Keywords*
- *Blocking Services*
- *Scheduling*
- *Enabling Security Event Email Notification*

Note: For information about the advanced content filtering features port forwarding and port triggering, see *Port Forwarding and Port Triggering* on page 64.

Viewing, Selecting, and Saving Logged Information

The router logs security-related events such as denied incoming service requests, hacker probes, and administrator logins. If you enabled content filtering in the Block Sites screen, the Logs screen can show you when someone on your network tries to access a blocked site.

On the main menu, under Content Filtering, select Logs to display this screen:

Logs

Current Time: Thursday, Jun 03, 2010 07:58:48

```
[Internet connected] IP address:
166.187.44.133, Friday, Jul 23, 2010 00:54:23
[Internet disconnected] Friday, Jul 23, 2010
00:54:13
[Admin login] from source 192.168.0.2, Friday,
Jul 23, 2010 00:53:03
[Admin login] from source 192.168.0.2, Friday,
Jul 23, 2010 00:52:44
[DHCP IP: (192.168.0.2)] to MAC address
00:1A:6B:6D:8F:19, Friday, Jul 23, 2010 00:52:40
[Initialized, firmware version:
V1.0.0.41_2.0.11WU] Friday, Jul 23, 2010
00:52:39
```

Include in Log

- Attempted access to blocked sites
- Connections to the Web-based interface of this Router
- Router operation (start up, get time etc)
- Known DoS attacks and Port Scans

Syslog

- Disable
- Broadcast on LAN
- Send to this Syslog server IP address: . . .

Note: You can enable email notification to receive these logs in an email message. See [Enabling Security Event Email Notification](#) on page 44.

LTE Broadband 11n Wireless Router MBR1515

Log entries and action buttons are described in the following table.

Field or Button	Description
Current time	The date and time the log entry was recorded.
Description or action	The type of event and what action was taken, if any.
Source IP	The IP address of the initiating device for this log entry.
Source port and interface	The service port number of the initiating device, and whether it originated from the LAN or WAN.
Destination	The name or IP address of the destination device or website.
Destination port and interface	The service port number of the destination device, and whether it is on the LAN or WAN.
Refresh button	Refresh the log screen.
Clear Log button	Clear the log entries.
Send Log button	Email the log immediately.
Apply button	Apply the current settings.
Cancel button	Clear the current settings.

Selecting Which Information to Log

Besides the standard information listed previously, you can choose to log additional information. Those optional selections are as follows:

- Attempted access to blocked site
- Connections to the router menu
- Router operation (start up, get time, and so on)
- Known DoS attacks and port scans

Saving Log Files on a Server

You can choose to write the logs to a computer running a syslog program. To activate this feature, select to the **Broadcast on LAN** radio button, or enter the IP address of the server where the syslog file will be written.

Log Message Examples

Following are examples of log messages. In all cases, the log entry shows the time stamp as Day, Year-Month-Date Hour:Minute:Second.

Activation and Administration

This entry indicates a power-up or reboot with initial time entry.

```
Tue, 2002-05-21 18:48:39 - NETGEAR activated
```

This entry shows an administrator logging in to and out from IP address 192.168.0.2.

```
Tue, 2002-05-21 18:55:00 - Administrator login successful - IP:192.168.0.2
```

```
Thu, 2002-05-21 18:56:58 - Administrator logout - IP:192.168.0.2
```

This entry shows a time-out of the administrator login.

```
Tue, 2002-05-21 19:00:06 - Login screen timed out - IP:192.168.0.2
```

This entry shows when the log was emailed.

```
Wed, 2002-05-22 22:00:19 - Log emailed
```

Dropped Packets

These entries show an inbound FTP (port 21) packet, User Datagram Protocol (UDP) packet (port 6970), and Internet Control Message Protocol (ICMP) packet (port 0) being dropped as a result of the default inbound rule, which states that all inbound packets are denied.

```
Wed, 2002-05-22 07:15:15 - TCP packet dropped - Source:64.12.47.28,4787,WAN  
- Destination:134.177.0.11,21,LAN - [Inbound Default rule match]
```

```
Sun, 2002-05-22 12:50:33 - UDP packet dropped - Source:64.12.47.28,10714,WAN  
- Destination:134.177.0.11,6970,LAN - [Inbound Default rule match]
```

```
Sun, 2002-05-22 21:02:53 - ICMP packet dropped - Source:64.12.47.28,0,WAN -  
Destination:134.177.0.11,0,LAN - [Inbound Default rule match]
```

Blocking Sites and Keywords

The router provides a variety of options for blocking Internet-based content and communications services. With its content filtering feature, the router prevents objectionable content from reaching your PCs. You can control access to Internet content by screening for keywords within Web addresses. Content filtering options include:

- Keyword blocking of HTTP traffic.
- Outbound service blocking. Limits access from your LAN to Internet locations or services that you specify as off-limits.
- Denial of service (DoS) protection. Detects and thwarts DoS attacks such as Ping of Death, SYN flood, LAND attack, and IP spoofing.
- Blocking unwanted traffic from the Internet to your LAN.

The router allows you to restrict access to Internet content based on Web addresses and Web address keywords.

1. Log in to the router as described in [Log In to Your Router](#) on page 11.
2. On the main menu, select Block Sites to display the Block Sites screen:

3. To enable keyword blocking, select one of the following:
 - **Per Schedule.** Turn on keyword blocking according to the settings on the Schedule screen.
 - **Always.** Turn on keyword blocking all the time, independent of the setting in the Schedule screen.
4. Enter a keyword or domain in the **Keyword** field, click **Add Keyword**, and then click **Apply**.

Some examples of keyword applications are shown in the following chart.

Keyword	Result
XXX	Block the URL http://www.badstuf.com/xxx.html.
.com	Only websites with other domain suffixes (such as .edu or .gov) can be viewed.
. (a period)	Block all Internet browsing access.

Up to 32 entries are supported in the Keyword list.

Note: If you block sites, you can set up the router to log attempts to access them. See *Viewing, Selecting, and Saving Logged Information* on page 37.

5. To delete a keyword or domain, select it from the list, click **Delete Keyword**, and then click **Apply**.
6. To specify a trusted user, enter that computer's IP address in the **Trusted IP Address** field, and then click **Apply**.

You can specify one trusted user, which is a computer that will be exempt from blocking and logging. Since the trusted user will be identified by an IP address, you should configure that computer with a fixed IP address.

7. Click **Apply** to save your settings.

Blocking Services

1. Log in to the router as described in *Log In to Your Router* on page 11.
2. In the main menu, under Content Filtering, select Block Services to display this screen:

Block Services

Services Blocking

Never

Per Schedule

Always

Service Table

#	Service Type	Port	IP

Add Edit Delete

Apply Cancel

3. Select one of the following:
 - **Per Schedule.** Turn on keyword blocking according to the settings in the Schedule screen.
 - **Always.** Turn on keyword blocking all the time, independent of the Schedule screen.
4. Click **Add**, and the following screen displays:

Block Services Setup

Service Type: AIM

Protocol: TCP

Starting Port: 5190 (1-65534)

Ending Port: 5190 (1-65534)

Service Type/User Defined: AIM

Filter Services For :

Only This IP Address : 1.92 . 1.68 . 0 .

IP Address Range: 1.92 . 1.68 . 0 . to 1.92 . 1.68 . 0 .

All IP Addresses

Add Cancel

5. Either select a service from the **Service Type** drop-down list, or use the **Service/Type User Defined** field to create a custom service.
6. Click **Add** to create the service, and it will be listed in the Service Table on the Block Services screen.
7. Click **Apply** to save your settings.

Scheduling

The router uses Network Time Protocol (NTP) to obtain the current time and date from one of several network time servers on the Internet.

Setting Your Time Zone

To localize the time for your log entries, you must specify your time zone:

1. Log in to the router as described in [Log In to Your Router](#) on page 11.
2. On the main menu under Content Filtering, select Schedule:
3. Select your time zone. This setting will be used for the blocking schedule according to your local time zone and for time-stamping log entries.

If your time zone is currently in daylight savings time, select the **Automatically adjust for daylight savings time** check box.

4. Click **Apply** to save your settings.

The screenshot shows the 'Schedule' configuration page. It includes the following sections:

- Days to Block:** A list of days from Sunday to Saturday, each with a checked checkbox.
- Time of day to block:(use 24-hour clock):** A section with a checked 'All Day' checkbox and two rows of input fields for 'Start Blocking' and 'End Blocking', each with 'Hour' and 'Minute' sub-fields. The 'End Blocking' 'Hour' field contains the value '24'.
- Time Zone:** A dropdown menu showing '(GMT-08:00) Pacific Time (US & Canada): Tijuana' and an unchecked checkbox for 'Automatically adjust for daylight savings time'.
- Current Time:** A text field displaying 'Wednesday, 01 Jan 2003 00:00:24'.
- Buttons:** 'Apply' and 'Cancel' buttons at the bottom.

Scheduling Firewall Services

If you enabled service blocking in the Block Services screen or port forwarding in the Ports screen, you can set up a schedule for when blocking occurs or when access is not restricted.

1. Log in to the router as described in [Log In to Your Router](#) on page 11.
2. On the main menu, select the Schedule. The Schedule screen appears.
3. To block Internet services based on a schedule, select **Every Day**, or select one or more days. If you want to limit access completely for the selected days, select **All Day**. Otherwise, to limit access during certain times for the selected days, fill in the **Start Blocking** and **End Blocking** fields.
4. Enter the values in 24-hour time format. For example, 10:30 a.m. would be 10 hours and 30 minutes, and 10:30 p.m. would be 22 hours and 30 minutes. If you set the start time after the end time, the schedule will be effective through midnight the next day.
5. Click **Apply** to save your changes.

Enabling Security Event Email Notification

To set up the router so that you can receive logs and alerts by email, select Email from the router menu to display the following screen:

➤ **To receive alerts and logs by email:**

1. Select the **Turn Email Notification On** check box.
2. Fill in the fields to send alerts and logs through email.
 - **Your Outgoing Mail Server.** Enter the name or IP address of the outgoing SMTP mail server of your ISP (such as mail.myISP.com).
 - **Send to This Email Address.** Enter the e-mail address where you want to send the alerts and logs. Use a full email address, such as ChrisXY@myISP.com.
 - **My mail server requires authentication.** Select this check box if you need to log in to your SMTP server to send email. If you select this feature, you must enter the user name and password for the mail server.

Tip: If you cannot remember this information, check the settings in your email program.

3. Specify when you want the alerts and logs to be sent:
 - **Send alert immediately.** Select the corresponding check box if you would like immediate notification of a significant security event, such as a known attack, port scan, or attempted access to a blocked site.
 - **Send logs according to this schedule.** Specifies how often to send the logs: **Hourly, Daily, Weekly, or When Full.**
 - **Day for sending log.** Specifies which day of the week to send the log. Relevant when the log is sent weekly.
 - **Time for sending log.** Specifies the time of day to send the log. Relevant when the log is sent daily or weekly.

If the **Weekly, Daily, or Hourly** option is selected and the log fills up before the specified period, the log is automatically e-mailed to the specified email address. After the log is sent, it is cleared from the router's memory. If the router cannot e-mail the log file, the log buffer might fill up. In this case, the router overwrites the log and discards its contents.

4. Click **Apply** so that your changes take effect.

4 Managing Your Network

4

This chapter describes how to perform network management tasks with your LTE Broadband 11n Wireless Router.

- *Router Status*
- *Backing Up, Restoring, or Erasing Your Settings*
- *Protecting Access to Your Router*
- *Running Diagnostic Utilities and Rebooting the Router*
- *Upgrading the Router Firmware*

Router Status

From the main menu, under Maintenance, select Router Status to view this screen.

You can use this screen to view the status of the router, to show statistics, or to view the connection status.

- For information about the fields on this screen, see the table below.
- See *Showing Statistics* on page 48 for information about statistics.
- For information about the Internet connection, see *Connection Status* on page 49.

Router Status	
Active Connection Ethernet	
Account Name	MBR1515
Firmware Version	V1.2.2.57
Ethernet Port	
MAC Address	84:1B:5E:33:50:B5
IP Address	192.168.0.10
Network Type	DHCPClient
IP Subnet Mask	255.255.255.0
Gateway IP Address	192.168.0.1
Domain Name Server	192.168.0.1
Mobile Broadband Modem	
Modem Identity	
Modem SW version	
Modem driver version	
IMSI	
IMEI	
Operator	
Network mode	
Network band	
Wireless Broadband Port	
Connection Status	NO SIM Card Detected
IP Address	0.0.0.0
Protocol	DHCP
IP Subnet Mask	0.0.0.0
Domain Name Server	0.0.0.0
LAN Port	
MAC Address	84:1B:5E:33:50:B4
IP Address	192.168.1.1
DHCP	ON
IP Subnet Mask	255.255.255.0
Wireless Port	
Name (SSID)	NETGEAR-3G
Region	Australia
Channel	Auto (11)
Wireless AP	On
Broadcast Name	On
<input type="button" value="Connection Status"/> <input type="button" value="Refresh"/>	
<input type="button" value="Show Statistics"/>	

LTE Broadband 11n Wireless Router MBR1515

Field	Description	
Firmware Version	This field displays the router firmware version.	
Mobile Broadband	Modem Identity	Shows the modem in use.
	Modem sw version	The software version of the modem.
	Modem driver version	The driver version of the modem.
	IMSI	International Mobile Subscriber Identity. SIM card identity.
	IMEI	International Mobile Equipment Identity. Unique identity of the modem.
	Operator	The ISP for the broadband wireless network.
	Network mode	The mode of the current network the modem is connected to. This is dependent on coverage and distance from the cell site.
WAN Port	Connection Status	The status of the Internet connection.
	IP Address	The IP address used by the modem. If no address is shown, the router cannot connect to the Internet.
	Protocol	The protocol for the Internet connection, which is PPP (Point-to-Point).
	IP Subnet Mask	The IP subnet mask used by the router's USB port.
	Gateway IP Address	The IP address used by the router.
	Domain Name Server	The DNS server IP addresses used by the router. These addresses are usually obtained dynamically from the ISP.
LAN Port	MAC Address	The Ethernet MAC address used by the router's LAN port.
	IP Address	The LAN port IP address. The default is 192.168.0.1.
	DHCP	<ul style="list-style-type: none"> • Off. The router does not assign IP addresses to PCs on the LAN. • On. The router assigns IP addresses to PCs on the LAN.
	IP Subnet Mask	The LAN port IP subnet mask. The default is 255.255.255.0.
Wireless Port (See <i>Manually Configure Your Wireless Settings</i> on page 27.)	Name (SSID)	The service set ID, also known as the wireless network name.
	Region	The country where the unit is set up for use.
	Channel	The current channel, which determines the operating frequency.
	Wireless AP	Indicates if the access point feature is disabled or not. If not enabled, the Wireless LED on the front panel will be off.
	Broadcast Name	Indicates if the router is configured to broadcast its SSID.

Showing Statistics

Click the **Show Statistics** button on the Router Status screen to display router usage statistics:

System Up Time 00:10:53							
Port	Status	TxPkts	RxPkts	Collisions	Tx B/s	Rx B/s	Up Time
WAN	PPP	150	33	0	0	0	00:10:09
LAN1	10M/100M	966	1041	0	827	247	00:10:53
LAN2	Link Down						--
LAN3	Link Down						--
LAN4	Link Down						--
WLAN	300M	69	0	0	19	0	00:10:53

Poll Interval: (secs)

The following table explains the statistic fields.

Field	Description
Status	The link status. Note that LAN2, LAN3, and LAN4 are guest networks.
TxPkts	The number of packets transmitted on this port since reset or manual clear.
RxPkts	The number of packets received on this port since reset or manual clear.
Collisions	The number of collisions on this port since reset or manual clear.
Tx B/s	The average egress line utilization for this port.
Rx B/s	The average ingress line utilization for this port.
Up Time	The time elapsed since the last power cycle or reset.

Connection Status

Click the **Connection Status** button on the Router Status screen:

Mobile broadband Status	
Connection Status	Connected
Received Signal Quality(in dbm)	-93
Bytes Transmitted	28192417
Bytes Received	40438051
Tx B/s	7803
Rx B/s	3600
System Uptime	00:42:01
Connection Status	
Connection Time	00:40:11
Connecting to Server	ON
Negotiation	ON
Authentication	ON
Getting IP Address	166.129.82.85
Getting Network Mask	255.255.255.255
Poll Interval: <input type="text" value="5"/> (secs) <input type="button" value="Set Interval"/> <input type="button" value="Stop"/> <input type="button" value="Close Window"/>	

This screen shows the following statistics:

Field	Description	
Mobile Broadband Service	Connection Status	The status of the Internet connection. <ul style="list-style-type: none"> • Scanning. The modem is scanning for broadband wireless networks in your area. • Connected. The router is connected to the Internet. • No USB Device Attached. The router does not detect a USB modem connected to its USB port. Either the modem is disconnected, or it is not correctly seated. To correct the problem remove the modem and reinsert it into the port.
	Received Signal Quality (in dBm)	Modem radio reception. A small, negative number indicates good signal quality.
	Bytes Transmitted	The number of bytes transmitted in the most recent connection session.
	Bytes Received	The number of bytes received in the most recent connection session.
	Tx B/s	The transmission rate.
	Rx B/s	The receiving rate.
	System Uptime	Time elapsed since the last reboot.

LTE Broadband 11n Wireless Router MBR1515

Field		Description
Connection Status	Connection Time	The time elapsed since the last connection to the Internet through the broadband port.
	Connecting to Server	The connection status.
	Negotiation	Success or Failed.
	Authentication	Success or Failed.
	Getting IP Address	The IP address assigned to the WAN port by the ADSL Internet Service Provider.
	Getting Network Mask	The network mask assigned to the WAN port by the ADSL Internet Service Provider.

Viewing Attached Devices

The Attached Devices screen shows all IP devices that the router discovered on the local network. From the main menu, under Maintenance, select Attached Devices:



#	IP Address	Device Name	MAC Address
1	192.168.0.2	BDU/ALL-CONTRACTOR	00:1A:8B:6D:8F:19

Refresh


For each device, the table shows the IP address, device name if available, and the Ethernet MAC address. If the router is rebooted, this data is lost until the router rediscovers the devices. To force the router to look for attached devices, click the **Refresh** button.

Backing Up, Restoring, or Erasing Your Settings

The configuration settings of the router are stored in a configuration file in the router. This file can be backed up to your computer, restored, or reverted to factory default settings. The procedures in the following sections explain how to do these tasks.

Backing Up the Configuration to a File

1. Log in to the router. Type **http://www.routerlogin.net** in the address field of your Internet browser. Enter **admin** for the user name and your password (or the default, **password**).
2. Under Maintenance on the main menu, select Backup Settings to display the Backup Settings screen.



3. Click **Save** to save a copy of the current settings.
4. Store the .cfg file on a computer on your network.

Restoring the Configuration from a File

➤ **To restore the configuration:**

1. Log in to the router. Type **http://www.routerlogin.net** in the address field of your Internet browser. Enter **admin** for the user name and your password (or the default, **password**).
2. Under Maintenance on the main menu, select Backup Settings.
3. Enter the full path to the file on your network, or click **Browse** to locate the file.
4. When you have located the .cfg file, click **Restore** to upload the file to the router.

The router reboots.

Erasing the Configuration

You can use the Erase feature to erase its configuration settings and restore the router to the factory default settings.

➤ **To erase the configuration:**

1. Under Maintenance on the main menu, select Backup Settings.
2. Click **Erase**.

The router reboots.

After an erase, the router password is **password**, the LAN IP address is **192.168.0.1**, and the router DHCP client is enabled.

Note: To restore the factory default settings when you do not know the login password or IP address, press the Restore Factory Settings button on the bottom of the router for 6 seconds.

Protecting Access to Your Router

For security reasons, the router has its own user name and password. Also, after a period of inactivity, the login automatically disconnects. The user name and password are not the same as a user name or password you might use to log in to your Internet connection.

NETGEAR recommends that you change this password to a more secure password. The ideal password should contain no dictionary words from any language, and should be a mixture of both uppercase and lowercase letters, numbers, and symbols. Your password can be up to 30 characters.

Changing the Built-In Password

1. To log in to the router, type **http://www.routerlogin.net** in the address field of your Internet browser. Enter **admin** for the user name and your password (or the default, **password**).

Note: If you changed the password and do not remember what it is, you can reset the router to its factory default settings. See [Restoring the Default Configuration and Password](#) on page 95.

- From the main menu, under Maintenance, select Set Password.

The screenshot shows a web interface for setting a password. It includes three text input fields for 'Old Password', 'New Password', and 'Repeat New Password'. Below these is a field for 'Administrator login times out after idle for' with a numeric input set to '5' and the text 'minutes.'. At the bottom of the form are two buttons: 'Apply' and 'Cancel'.

- To change the password, first enter the old password, and then enter the new password twice.
- Click **Apply** to save your changes.

Note: After changing the password, you must log in again to continue the configuration. If you have backed up the router settings previously, you should do a new backup so that the saved settings file includes the new password.

Changing the Administrator Login Time-Out

For security, the administrator login to the router configuration times out after a period of inactivity. To change the login time-out period:

- In the Set Password screen, type a number in the **Administrator login times out** field. The suggested default value is 5 minutes.
- Click **Apply** to save your changes, or click **Cancel** to keep the current period.

Running Diagnostic Utilities and Rebooting the Router

The router has a diagnostics feature. You can use the Diagnostics screen to perform the following functions from the router:

- Ping an IP address to test connectivity to see if you can reach a remote host. If Ping VPN is enabled, the ping packet always goes through the VPN if the VPN tunnel is enabled and working.
- Perform a DNS lookup to test if an Internet name resolves to an IP address to verify that the DNS server configuration is working.
- Display the routing table to identify what other routers the router is communicating with.
- Reboot the router to enable new network configurations to take effect or to clear problems with the router's network connection.

LTE Broadband 11n Wireless Router MBR1515

From the main menu, under Maintenance, select **Diagnostics**.

- **Ping.** Ping an IP address.
- **Lookup.** A Domain Name Server (DNS) converts the Internet name such as www.netgear.com to an IP address. If you need the IP address of a server on the Internet, you can do a DNS lookup to find the IP address.
- **Display.** View the internal routing table. Typically, this information is used only by Technical Support.
- **Reboot.** Shut down and restart the router. If you reboot the router you will lose your connection. To access the router you will need to log in again after it has finished rebooting.
- **Save.** Save diagnostic information.
- **Module Data.** Click to view the module data.

Diagnostics

Ping an IP address
 IP Address: . . .

Perform a DNS Lookup
 Internet Name:
 IP Address:
 DNS Server: 192.168.0.1

Display the Routing Table

Reboot the Router

Save diagnostics information

Module data

Signal quality (dbm)	System <input checked="" type="checkbox"/>
RSSI	Modem status
Basic	Service status
System mode	Service type
Current band	Roaming
	Network selection
	Country Initials
	Network name
	MCC
	MNC
	LAC
	RAC
	Cell ID
	Channel number(ARFCN)
	Primary scramble code
<hr/>	
RscpEcIo (UMTS only)	Radio Power <input type="checkbox"/>
PriScramCode	RSCP
	EcIo
	Power mode
	Temperature
	Battery state(mV)
<input type="button" value="apply"/> <input type="button" value="clear"/> 10 Sec	

Upgrading the Router Firmware

The router firmware is stored in flash memory, and can be upgraded as new firmware is released by NETGEAR. Upgrade files can be downloaded from the NETGEAR web site. If the upgrade file is compressed (a .zip file), you must first extract the binary (.bin or .img) file before uploading it to the router.

NETGEAR recommends that you back up your configuration before doing a firmware upgrade. After the upgrade is complete, you might need to restore your configuration settings.

1. Download and unzip the new firmware file from NETGEAR.

The Web browser used to upload new firmware into the router must support HTTP uploads. NETGEAR recommends using Microsoft Internet Explorer 5.0 or later, or Mozilla Firefox 2.0 or later.

2. Log in to the router. Type **http://www.routerlogin.net** in the address field of your Internet browser. Enter **admin** for the user name and your password (or the default, **password**).
3. From the main menu, under Maintenance, select Router Upgrade to display this screen.



4. Click **Browse** to locate the binary (.bin or .img) upgrade file.
5. Click **Upload**.



WARNING:

When uploading firmware to the router, do not interrupt the Web browser by closing the window, clicking a link, or loading a new page. If the browser is interrupted, it might corrupt the firmware, causing router to be unworkable and inaccessible. When the upload is complete, your router will automatically restart. The upgrade process typically takes about 1 minute. In some cases, you might need to clear the configuration and reconfigure the router after upgrading.

This chapter describes how to configure the advanced features of your LTE Broadband 11n Wireless Router.

- *SIM Settings*
- *SMS Messages*
- *Advanced Wireless Settings*
- *Wireless Repeating Function*
- *Port Forwarding and Port Triggering*
- *WAN Setup*
- *LAN Setup*
- *QoS Setup*
- *Dynamic DNS*
- *Using Static Routes*
- *Enabling Remote Management*
- *Universal Plug and Play*
- *Traffic Meter*
- *IPv6 Internet Configuration and Status Check*

SIM Settings

From the main menu, select SIM Settings to display the following screen:

Field	Description
Enabling or Disabling the PIN Code	Controls whether the PIN code on the SIM card will be used to connect to the network.
Changing the PIN Code	Changes the PIN code on the SIM card.
SIM status	Current SIM card access status.

SMS Messages

Short Message Service (SMS) is a text messaging service for communication systems. The SMS screens enable you to perform the tasks that are explained in the following sections:


- [View SMS Messages](#)
- [Send SMS Messages](#)

View SMS Messages

New SMS messages are available when the SMS  LED on the front panel is solid green.

➤ **To view new SMS messages:**


1. On the main menu, under Advanced, select **SMS Messages**, and then select **Inbox** from the drop-down list to display the SMS Message screen:



2. Click a particular message to view it.
 - Click **Forward** or **Reply** to forward or reply to the specified message.
 - Click **Delete** to delete the specified SMS message.
3. Otherwise, do one of the following:
 - Click **Refresh** to redisplay all SMS messages from the SIM card.
 - Click **Delete All** to delete all SMS messages from the SIM card
 - Click **New** to open a new message. See [Send SMS Messages](#) on page 59 for more information.

➤ **To view sent SMS messages:**

1. On the main menu, under Advanced, select **SMS Settings**, and then select **Sent** from the drop-down list to display the SMS Message screen:



2. Click a particular message to display it.
 - Click **Forward** to forward the specified SMS message.
 - Click **Resend** to resend the specified SMS message.
 - Click **Delete** to delete the specified SMS message.

3. Click **New** to open a new message. See [Send SMS Messages](#) on page 59 for more information.

➤ **To view draft SMS messages:**

1. On the main menu, under Advanced, select **SMS Settings**, and then select **Draft** from the drop-down list to display the SMS Message screen:



2. Click a particular message to display it.
 - Click **Edit** to edit the specified SMS message.
 - Click **Send** to send the specified SMS message.
 - Click **Delete** to delete the specified SMS message.
3. Click **New** to open a new message. See [Send SMS Messages](#) on page 59 for more information.

Send SMS Messages

You can create a new SMS message or send an SMS message over email.

➤ **To send SMS messages:**

1. From either the SMS Message Inbox or Sent screen, click **New** to display the SMS Message Compose screen:



2. In the To field, enter the phone number that you want to send your SMS message to, or the email address to send a SMS message over email.

For multitarget messages, you can send a message to multiple phone numbers. Each phone number has to be separated by a comma (,).

3. In the Content field, enter the content of the SMS message. The length of the message is shown at the bottom of the content box.
4. Click **Send** to send the SMS message.

Alternatively, you can also take one of the following actions:

- Click **Clear** to remove the information in the To and Content fields.
- Click **Save** to save message to Draft.
- Click **Cancel** to return to the Inbox without sending the message.

Advanced Wireless Settings

From the main menu, select Advanced Wireless Settings to display the following screen:

Field	Description
Enable Wireless Router Radio	Selected by default, this setting enables the wireless radio, which allows the router to work as a wireless access point. Turning off the wireless radio can be helpful for configuration, network tuning, or troubleshooting.
Fragmentation Length, CTS/RTS Threshold, and Preamble Mode	These should be left at their default settings.
Router PIN	The PIN number used for Push 'N' Connect.
Disable Router PIN	By default, this check box is cleared. This allows the WPS clients to discover the router's PIN.

Field	Description
Keep Wireless Settings	By default, this check box is cleared. This allows the router to automatically generate the SSID and WPA/WPA2 security settings when it implements WPS. After WPS is implemented, the router automatically selects the Keep Existing Wireless Settings check box so that your SSID and wireless security settings remain the same if other WPS-enabled devices are added later.
Turn Access Control On	Access control is disabled by default so that any computer configured with the correct SSID can connect. See Restricting Access by MAC Address on page 61.

Wireless Station Access Control

By default, any wireless PC configured with the correct SSID and wireless security settings is allowed access to your wireless network. You can use wireless access point settings in the Wireless Setting screen to further restrict wireless access to your network:

- **Turn off wireless connectivity completely.**
You can completely turn off the wireless portion of the router. For example, if you use your notebook computer to wirelessly connect to your router, and you take a business trip, you can turn off the wireless portion of the router while you are traveling. Other members of your household who use computers connected to the router via Ethernet cables can still use the router. To do this, clear the **Enable Wireless Router Radio** check box on the Wireless Settings screen, and then click **Apply**.
- **Hide your wireless network name (SSID).**
By default, the router is set to broadcast its wireless network name (SSID). You can restrict wireless access to your network by not broadcasting the wireless network name (SSID). To do this, clear the **Enable SSID Broadcast** check box on the Wireless Settings screen, and then click **Apply**. Wireless devices will not “see” your router. You must configure your wireless devices to match the wireless network name (SSID) of the router.

Note: The SSID of any wireless access adapters must match the SSID you configure in the router. If they do not match, you will not get a wireless connection to the router.

Restricting Access by MAC Address

For increased security, you can restrict access to the wireless network to allow only specific PCs based on their MAC addresses. You can restrict access to only trusted PCs so that unknown PCs cannot wirelessly connect to the LTE Broadband 11n Wireless Router. MAC address filtering adds an obstacle against unwanted access to your network, but the data broadcast over the wireless link is fully exposed.

Note: If you configure the router from a wireless computer, add your computer's MAC address to the access list. Otherwise you will lose your wireless connection when you click **Apply**. You must then access the router from a wired computer, or from a wireless computer that is on the access control list, to make any further changes.

➤ **To restrict access based on MAC addresses:**

1. From the main menu, under Advanced, select Wireless Settings. Click **Setup Access List** to display the Wireless Station Access List screen.



2. Adjust the list as needed for your network. You can add devices to the Trusted Wireless Stations list. Click **Add** to display the following screen:



3. You can add devices to the list using either of the following methods:
 - If the computer is in the Available Wireless Cards table, select its radio button to capture its MAC address.
 - Use the Wireless Card Entry fields to enter the MAC address of the device to be added. The MAC address can usually be found on the bottom of the wireless device.
 - If no device name appears when you enter the MAC address, you can type a descriptive name for the computer that you are adding.
4. Click **Apply** to save these settings. Now, only devices on this list will be allowed to wirelessly connect to the router.

Wireless Repeating Function

From the main menu, select Wireless Repeating Function to display the following screen:

Field	Description
Enable Wireless Repeating	<p>Enable this if you wish to use either Bridge mode or Repeater mode, and then select the mode you want for your environment.</p> <ul style="list-style-type: none"> Wireless Repeater. In this mode, the MBR1515 will communicate <i>only</i> with another Base Station–mode wireless station. You must enter the MAC address (physical address) of the other Base Station–mode wireless station in the field provided. WEP / WPA-PSK [TKIP] can (and should) be used to protect this communication. Wireless Base Station. Select this only if this MBR1515 is the "master" for a group of Repeater-mode wireless stations. The other Repeater–mode wireless stations must be set to Wireless Repeater–mode, using this MBR1515's MAC address. They then send all traffic to this master, rather than communicate directly with each other. WEP / WPA-PSK [TKIP] can (and should) be used to protect this traffic. If this option is selected, you must enter the MAC addresses of the other access points in the fields provided.

Port Forwarding and Port Triggering

Port forwarding and port triggering are advanced features that affect the behavior of the firewall in your router. In the Port Forwarding / Port Triggering screen, you can make local computers or servers available to the Internet for different services (for example, FTP or HTTP), to play Internet games (like Quake III), or to use Internet applications (like CU-SeeMe).

- Port forwarding is designed for FTP, Web server, or other server-based services. Once port forwarding is set up, requests from the Internet are forwarded to the correct server.
- Port triggering monitors outbound traffic. When the router detects traffic on the specified outbound port, it remembers the IP address of the computer that sent the data and triggers the incoming port. Incoming traffic on the triggered port is then forwarded to the triggering computer. Port triggering allows requests from the Internet only after a designated port is triggered. Port triggering applies to chat and Internet games.

Port Forwarding

➤ To set up port forwarding:

1. From the main menu, under Advanced, select Port Forwarding/Port Triggering. The following screen displays:

The screenshot shows the 'Port Forwarding / Port Triggering' configuration interface. It includes a section for selecting the service type, with 'Port Forwarding' selected. Below this, there are fields for 'Service Name' (set to 'Age-of-Empire') and 'Server IP Address' (set to '192.168.0'). A table at the bottom lists existing services with columns for '#', 'Service Name', 'Start Port', 'End Port', and 'Server IP Address'. Control buttons for 'Edit Service', 'Delete Service', and 'Add Custom Service' are also visible.

By default, the **Port Forwarding** radio button is selected.

2. You can select a service or create a custom service.
 - Select a service from the **Service Name** drop-down list and specify the computer's IP address.
 - If you want to add a service that is not in the list, click the **Add Custom Service** button. Fill in the fields in the Add Custom Service screen.

The service appears in the list.

Port Triggering

➤ **To set up port triggering:**

1. From the main menu, under Advanced, select Port Forwarding/Port Triggering.
2. Select the **Port Triggering** radio button to display the following screen:

Port Forwarding / Port Triggering

Please select the service type.

Port Forwarding
 Port Triggering

Service Name: Age-of-Empire
 Server IP Address: 192.168.0

#	Service Name	Start Port	End Port	Server IP Address

Buttons: Edit Service, Delete Service, Add Custom Service

3. Click **Add Service** and fill in the fields in the Add Service screen.

The service appears in the list. For more detailed information, see the Port Forwarding/Port Triggering help.

WAN Setup

To change broadband Internet connection settings, use the Broadband Settings screen, as described in *Manually Configure Your Internet Settings* on page 14.

➤ **To view or change the WAN setup:**

1. From the main menu, select WAN Setup to display the WAN Setup screen.
2. Make the changes that you want, and then click **Apply** to save the settings.

WAN Setup

Disable Port Scan and DoS Protection

Default DMZ Server: 192.168.0.0

Respond to Ping on Internet Port

MTU Size (in bytes): 1500

NAT Filtering: Secured Open

Disable SIP ALG

Buttons: Apply, Cancel

The WAN Setup fields are described in the table below.

Setting	Description
Disable SPI Firewall	This check box is usually cleared so that the firewall protects your LAN against port scans and denial of service attacks. This check box should be selected only in special circumstances.
Default DMZ Server	This feature is sometimes helpful when you are using some online games and videoconferencing. Be careful when using this feature because it makes the firewall security less effective. See Setting Up a Default DMZ Server on page 66.
Respond to Ping on Internet	If you want the router to respond to a ping from the Internet, select this check box. This should be used only as a diagnostic tool, since it allows your router to be discovered. Do not select this check box unless you have a specific reason to do so.
MTU Size	Maximum Transmit Unit (MTU) value. For most Ethernet networks this is 1500 bytes, or 1492 bytes for PPPoE connections, or 1436 bytes for PPTP connections.
NAT Filtering	This is set to Secured to provide a secure firewall to protect computers on the LAN from attacks from the Internet. The Open setting is less secure.
Disable SIP ALG	Some VoIP applications do not work well with SIP ALG. Selecting this check box might help your VoIP devices create or accept a call through the router.

Setting Up a Default DMZ Server



WARNING:

For security reasons, you should avoid using the default DMZ server feature. When a computer is designated as the default DMZ server, it loses much of the protection of the firewall, and is exposed to many exploits from the Internet. If compromised, the computer can be used to attack your network.

The default DMZ server feature is helpful when you are using some online games and videoconferencing applications that are incompatible with NAT. The router is programmed to recognize some of these applications and to work correctly with them, but there are other applications that might not function well. In some cases, one local computer can run the application correctly if that computer's IP address is entered as the default DMZ server.

Incoming traffic from the Internet is normally discarded by the router unless the traffic is a response to one of your local computers or a service that you have configured in the Ports screen. Instead of discarding this traffic, you can have it forwarded to one computer on your network. This computer is called the default DMZ server.

➤ **To assign a computer or server to be a default DMZ server:**

1. Go to the WAN Setup screen as described in the previous section.
2. Select the **Default DMZ Server** check box.
3. Type the IP address for that server.
4. Click **Apply** to save your changes.

LAN Setup

The LAN Setup screen allows configuration of LAN IP services such as DHCP and RIP. These features can be found under Advanced in the router main menu.

The router is shipped preconfigured to use private IP addresses on the LAN side, and to act as a DHCP server. The router default LAN IP configuration is:

- LAN IP address. 192.168.0.1
- Subnet mask. 255.255.255.0

These addresses are part of the Internet Engineering Task Force (IETF)–designated private address range for use in private networks, and should be suitable in most applications. If your network has a requirement to use a different IP addressing scheme, you can make those changes in this screen.

Tip: If you change the LAN IP address of the router while connected through the browser, you will be disconnected, and so will others connected to the router. To connect to the router, you must open a new connection to the new IP address and log in again. Others using the router must restart their computers to connect to the router again.

➤ **To view or change the LAN setup:**

1. Select LAN IP to display the LAN Setup screen.

The screenshot shows the LAN Setup configuration interface. At the top, the title is "LAN Setup". Below it, there are several sections:

- Device Name:** A text field containing "MBR1515".
- LAN TCP/IP Setup:**
 - IP Address:** Four input boxes containing "192", "168", "1", and "1".
 - IP Subnet Mask:** Four input boxes containing "255", "255", "255", and "0".
 - RIP Direction:** A dropdown menu set to "Both".
 - RIP Version:** A dropdown menu set to "Disabled".
- Use Router as DHCP Server:** A checked checkbox.
- Starting IP Address:** Four input boxes containing "192", "168", "1", and "2".
- Ending IP Address:** Four input boxes containing "192", "168", "1", and "254".
- Address Reservation:** A table with columns for "#", "IP Address", "Device Name", and "MAC Address". Below the table are "Add", "Edit", and "Delete" buttons.

At the bottom of the form are "Apply" and "Cancel" buttons.

2. Change the settings. For more information, see [DHCP Settings](#) on page 68, or [Reserved IP Addresses](#) on page 69.

3. Click **Apply** to save the changes.

The LAN TCP/IP Setup parameters are explained in the table below.

Settings		Description
Device Name		
LAN TCP/IP Setup	IP Address	The LAN IP address of the router.
	IP Subnet Mask	The LAN subnet mask of the router. Combined with the IP address, the IP subnet mask allows a device to know which other addresses are local to it, and which must be reached through a gateway or router.
	RIP Direction	RIP (Routing Information Protocol, RFC1058 and RFC1389) allows a router to exchange routing information with other routers. The RIP Direction selection controls how the router sends and receives RIP packets. Both is the default. <ul style="list-style-type: none"> • When set to Both or Out Only, the router broadcasts its routing table periodically. • When set to Both or In Only, it incorporates the RIP information that it receives.
	RIP Version	RIP Version: This controls the format and the broadcasting method of the RIP packets that the router sends. (It recognizes both formats when receiving.) By default, this is set for Disabled. <ul style="list-style-type: none"> • RIP-1 is universally supported. RIP-1 is probably adequate for most networks, unless you have an unusual network setup. • RIP-2 carries more information. Both RIP-2B and RIP-2M send the routing data in RIP-2 format. <ul style="list-style-type: none"> - RIP-2B uses subnet broadcasting. - RIP-2M uses multicasting.
DHCP Server For more information, see DHCP Settings on page 68.	Use Router as a DHCP Server	This check box is usually selected so that the router functions as a Dynamic Host Configuration Protocol (DHCP) server. See DHCP Settings on page 68.
	Starting IP Address	Specify the start of the range for the pool of IP addresses in the same subnet as the router.
	Ending IP Address	Specify the end of the range for the pool of IP addresses in the same subnet as the router.
Address Reservation For more information, see DHCP Settings on page 68.		When you specify a reserved IP address for a computer on the LAN, that computer receives the same IP address each time it access the router's DHCP server. Assign reserved IP addresses to servers that require permanent IP settings.

DHCP Settings

By default, the router functions as a Dynamic Host Configuration Protocol (DHCP) server, allowing it to assign IP, DNS server, and default gateway addresses to all computers connected to the router's LAN. The assigned default gateway address is the LAN address of the router. IP addresses is assigned to the attached PCs from a pool of addresses specified

in this screen. Each pool address is tested before it is assigned to avoid duplicate addresses on the LAN.

For most applications, the default DHCP and TCP/IP settings of the router are satisfactory.

Use Router as DHCP Server

If another device on your network will be the DHCP server, or if you will manually configure the network settings of all of your computers, clear the **Use Router as DHCP Server** check box on the LAN IP Setup screen. Otherwise, leave it selected.

Specify the pool of IP addresses to be assigned by filling in the **Starting IP Address** and **Ending IP Address** fields. These addresses should be part of the same IP address subnet as the router's LAN IP address. Using the default addressing scheme, you should define a range between 192.168.0.2 and 192.168.0.254, although you might want to save part of the range for devices with fixed addresses.

The router delivers the following parameters to any LAN device that requests DHCP:

- An IP address from the range you have defined.
- Subnet mask.
- Gateway IP address is the router's LAN IP address.
- Primary DNS server, if you entered a primary DNS address in the Basic Settings screen; otherwise, the router's LAN IP address.
- Secondary DNS server, if you entered a secondary DNS address in the Basic Settings screen.
- WINS server (Windows Internet Naming Service Server) determines the IP address associated with a particular Windows computer. A WINS server records and reports a list of names and IP address of Windows PCs on its local network. If you connect to a remote network that contains a WINS server, enter the server's IP address here. This allows your PCs to browse the network using the Network Neighborhood feature of Windows.

Reserved IP Addresses

When you specify a reserved IP address for a computer on the LAN, that computer always receives the same IP address each time it access the router's DHCP server. Reserved IP addresses should be assigned to servers that require permanent IP settings.

➤ **To reserve an IP address:**

1. Click the **Add** button.
2. In the **IP Address** field, type the IP address to assign to the computer or server. Choose an IP address from the router's LAN subnet, such as 192.168.0.x.
3. Type the MAC address of the computer or server.

Tip: If the computer is on your network, it is listed on the same screen for your convenience. Clicking the radio button for each entry in the attached device list fills in the fields automatically with the computer's MAC address and name.

4. Click **Apply** to enter the reserved address into the table.

Note: The reserved address will not be assigned until the next time the computer contacts the router's DHCP server. Reboot the computer or access its IP configuration and force a DHCP release and renew.

➤ **To edit or delete a reserved address entry:**

1. Click the button next to the reserved address you want to edit or delete.
2. Click **Edit** or **Delete**.

QoS Setup

QoS is an advanced feature that can be used to prioritize some Internet applications and online gaming, and to minimize the impact when the bandwidth is busy.

From the main menu, select QoS Setup to display the following screen:

Field	Description
Wi-Fi Multi-media (WMM) Settings	WMM (Wireless Multimedia) is a subset of the 802.11e standard. WMM allows wireless traffic to have a range of priorities depending on the kind of data. Time-dependent information, such as video or audio, has a higher priority than normal traffic. For WMM to function correctly, wireless clients must also support WMM.
Turn Internet Access QoS On	If you enable QoS, the QoS function works to prioritize Internet access traffic. For the applications that already exist in the drop-down list (e.g., On-line Gaming, Ethernet LAN Port, or a specified MAC address), you can modify the priority level by clicking the Edit button, or clicking the Delete button to erase the priority rule. Otherwise, you can also define the priority policy for online gaming, an application, a LAN port, or the computer's MAC address by clicking the Add Priority Rule button.
Bandwidth Control	To set up the total maximum uplink bandwidth, click the Check button to detect current uplink bandwidth that will help you to determinate the maximum bandwidth setting.

QoS Priority Rule List

From the QoS Setup screen, click **Setup QoS Rule** to display the following screen:

QoS Priority Rule List				
#	QoS Policy	Priority	Description	
<input type="radio"/>	1	MSN Messenger	High	MSN Messenger application
<input type="radio"/>	2	Yahoo Messenger	High	Yahoo Messenger application
<input type="radio"/>	3	IP Phone	Highest	IP Phone application
<input type="radio"/>	4	Vonage IP Phone	Highest	Vonage IP Phone application
<input type="radio"/>	5	NetMeeting	High	NetMeeting application
<input type="radio"/>	6	AIM	High	AIM application
<input type="radio"/>	7	Google Talk	Highest	Google Talk application
<input type="radio"/>	8	Netgear EVA	Highest	Netgear EVA application
<input type="radio"/>	9	SSH	High	SSH application
<input type="radio"/>	10	Telnet	High	Telnet application
<input type="radio"/>	11	VPN	High	VPN application
<input type="radio"/>	12	FTP	Normal	FTP application
<input type="radio"/>	13	SMTP	Normal	SMTP application
<input type="radio"/>	14	WWW	Normal	WWW application
<input type="radio"/>	15	DNS	Normal	DNS application
<input type="radio"/>	16	ICMP	Normal	ICMP application
<input type="radio"/>	17	eMule / eDonkey	Low	eMule / eDonkey application
<input type="radio"/>	18	Kazaa	Low	Kazaa application
<input type="radio"/>	19	Gnutella	Low	Gnutella application
<input type="radio"/>	20	BT / Azureus	Low	BT / Azureus application
<input type="radio"/>	21	Counter Strike	High	On-line gaming Counter Strike
<input type="radio"/>	22	Ages of Empires	High	On-line gaming Age of Empires
<input type="radio"/>	23	Everquest	High	On-line gaming Everquest
<input type="radio"/>	24	Quake 2	High	On-line gaming Quake 2
<input type="radio"/>	25	Quake 3	High	On-line gaming Quake 3
<input type="radio"/>	26	Unreal Tournament	High	On-line gaming Unreal Tournament
<input type="radio"/>	27	Warcraft	High	On-line gaming Warcraft

QoS Priority Rules

From the QoS Priority Rule List, click **Add Priority Rule** to display the following screen:

QoS - Priority rules	
Priority	
QoS Policy for	<input type="text"/>
Priority Category	Applications <input type="button" value="v"/>
Applications	Add a new Application <input type="button" value="v"/>
Priority	Normal <input type="button" value="v"/>
Specified port range	
Connection Type	TCP/UDP <input type="button" value="v"/>
Starting Port	<input type="text"/> (1-65535)
Ending Port	<input type="text"/> (1-65535)
<input type="button" value="Apply"/> <input type="button" value="Cancel"/>	

For Applications or Online Gaming

➤ To set up the priority for an application or online gaming:

1. Select **Applications** or **On-line Gaming** from the **Priority Category** lists.

2. Select the Internet application or game for which you want to set the priority from the relevant list.
3. Select the priority level: **Highest**, **High**, **Normal**, or **Low**.
4. You can also type the name in the **QoS Policy** field for this rule if you prefer.
5. Click **Apply**.

For Ethernet LAN Ports

To set up the priority for LAN port:

1. Select **Ethernet LAN Port** from the **Priority Category** list.

2. Select the LAN port number you plan to specify the priority level for those computers connecting on this LAN port.
3. Select the priority level: **Highest**, **High**, **Normal**, or **Low**.
4. You can also type the name in the **QoS Policy** field for this rule if you prefer.
5. Click **Apply**.

For MAC Addresses

➤ **To set up the priority for specified computer via its MAC address:**

1. Select **MAC Address** from the **Priority Category** list.

QoS - Priority rules

Priority
QoS Policy for:
Priority Category: **MAC Address**

	QoS Policy	Priority	Device Name	MAC Address
<input type="radio"/>	Pri_MAC_2BDCF6	Normal	ROGERSTECIAK	00:13:02:2B:DC:F6
<input type="radio"/>	Pri_MAC_12133F	Normal	MPAWLAN-SPARE	00:13:02:12:13:3F

MAC Address:
Device Name:
Priority: **Normal**

2. Click the **Refresh** button to update the list of computers already connected to the router.
3. Select the entry's radio button.
4. Modify the information in the **MAC Address** and **Device Name** fields.
5. Select the priority level: **Highest, High, Normal**, or **Low**.
6. You can also type the name in the **QoS Policy** field for this rule if you prefer.
7. Click the **Edit** button.
8. Click **Apply**.

➤ **To add the priority for specified computer via its MAC address:**

1. Choose **MAC Address** from the **Priority Category** list.
2. Enter the MAC address for the computer for which you are specifying the priority.
3. You can also type a name that is easy to remember in the **Device Name** fields.
4. Select the priority level: **Highest, High, Normal**, or **Low**.
5. You can also type a name in the **QoS Policy** field for this rule if you prefer.
6. Click the **Add** button.
7. Click **Apply**.

➤ **To delete a priority rule entry:**

1. Select the entry's radio button of the table.
2. Click the **Delete** button.
3. Click **Apply**.

Dynamic DNS

If your network has a permanently assigned IP address, you can register a domain name and have that name linked with your IP address by public Domain Name Servers (DNS). However, if your Internet account uses a dynamically assigned IP address, you will not know in advance what your IP address will be, and the address can change frequently. In this case, you can use a commercial Dynamic DNS service to register your domain to their IP address, and forward traffic directed at your domain to your frequently changing IP address.

The router contains a client that can connect to a Dynamic DNS service provider. To use this feature, you must select a service provider and obtain an account with them. After you have configured your account information in the router, whenever your ISP-assigned IP address changes, your router will automatically contact your Dynamic DNS service provider, log in to your account, and register your new IP address.



WARNING:

If your ISP assigns a private WAN IP address such as 192.168.x.x or 10.x.x.x, the Dynamic DNS service will not work because private addresses will not be routed on the Internet.

➤ To configure Dynamic DNS:

1. From the main menu, select **Dynamic DNS** to display the Dynamic DNS screen:
2. Access the website of one of the Dynamic DNS service providers whose names appear in the **Service Provider** drop-down list, and register for an account.

For example, for dyndns.org, go to www.dyndns.org.

3. Select the **Use a Dynamic DNS Service** check box.
4. Select the name of your Dynamic DNS service provider.
5. Fill in the **Host Name**, **User Name**, and **Password** fields.

The Dynamic DNS service provider might call the host name a domain name. If your URL is myName.dyndns.org, then your host name is myName. The password can be a key for your Dynamic DNS account.

If your Dynamic DNS provider allows the use of wildcards in resolving your URL, you can select the **Use wildcards** check box to activate this feature.

For example, the wildcard feature will cause *.yourhost.dyndns.org to be aliased to the same IP address as yourhost.dyndns.org.

6. Click **Apply** to save your configuration.

Using Static Routes

Static routes provide additional routing information to your router. Under normal circumstances, the router has adequate routing information after it has been configured for Internet access, and you do not need to configure additional static routes. You must configure static routes only for unusual cases such as multiple routers or multiple IP subnets located on your network.

Static Route Example

As an example of when a static route is needed, consider the following case:

- Your primary Internet access is through a cable modem to an ISP.
- You have an ISDN router on your home network for connecting to the company where you are employed. This router's address on your LAN is 192.168.0.100.
- Your company's network is 134.177.0.0.

When you first configured your router, two implicit static routes were created. A default route was created with your ISP as the router, and a second static route was created to your local network for all 192.168.0.x addresses. With this configuration, if you attempt to access a device on the 134.177.0.0 network, your router forwards your request to the ISP. The ISP forwards your request to the company where you are employed, and the request is likely to be denied by the company's firewall.

In this case you must define a static route, telling your router that 134.177.0.0 should be accessed through the ISDN router at 192.168.0.100.

In this example:

- The **Destination IP Address** and **IP Subnet Mask** fields specify that this static route applies to all 134.177.x.x addresses.
- The **Gateway IP Address** fields specify that all traffic for these addresses should be forwarded to the ISDN router at 192.168.0.100.
- In the **Metric** field, a value of 1 will work since the ISDN router is on the LAN. This represents the number of routers between your network and the destination. This is a direct connection, so it is set to 1.
- **Private** is selected only as a precautionary security measure in case RIP is activated.

➤ To configure static routes:

1. From the main menu, under Advanced, select Static Routes to view the Static Routes screen.



2. Select the radio button of the static route you want to configure.
3. Click **Add** or **Edit** to display the following screen:

4. Fill in or change the fields:
 - **Route Name.** The route name is for identification purposes only.
 - **Private.** Select this check box if you want to limit access to the LAN only. The static route will not be reported in RIP.
 - **Active.** Select this check box to make this route effective.
 - **Destination IP Address**, and **IP Subnet Mask.** If the destination is a single host, type a subnet value of **255.255.255.255**.
 - **Gateway IP Address.** This must be a router on the same LAN segment as the router.
 - **Metric.** Type a number between 2 and 15. This represents the number of routers between your network and the destination. Usually, a setting of 2 or 3 works, but if this is a direct connection, set it to 2.
5. Click **Apply** to save your changes. If you added a static route, it is added to the Static Routes screen.

Enabling Remote Management

Using the Remote Management screen, you can allow a user or users on the Internet to configure, upgrade, and check the status of your router.

Tip: Be sure to change the router default password to a very secure password. The ideal password should contain no dictionary words from any language, and should be a mixture of letters (both upper-case and lower-case), numbers, and symbols. Your password can be up to 30 characters.

➤ To configure Remote Management

1. Log in to the router. Type **http://www.routerlogin.net** in the address field of your Internet browser. Enter **admin** for the user name and your password (or the default, **password**).

2. Under Advanced, select **Remote Management**:
3. Select the **Turn Remote Management On** check box.
4. Specify which external addresses will be allowed to access the router's remote management.

For security, restrict access to as few external IP addresses as practical:

- To allow access from any IP address on the Internet, select **Everyone**.
- To allow access from a range of IP addresses on the Internet, select **IP Address Range**. Enter a beginning and ending IP address to define the allowed range.
- To allow access from a single IP address on the Internet, select **Only This Computer**. Enter the IP address that will be allowed access.

5. Specify the port number that will be used for accessing the router menu.

Access normally uses the standard HTTP service port 80. For greater security, you can enter a different port number. Choose a number between 1024 and 65535, but do not use the number of any common service port. The default is 8080, which is a common alternate for HTTP.

6. Click **Apply** to have your changes take effect.

When accessing your router from the Internet, type your router WAN IP address in your Internet browser address or location field, followed by a colon (:) and the custom port number. For example, if your external address is 134.177.0.123 and you use port number 8080, enter: **http://134.177.0.123:8080**. Be sure to include http:// in the address.

Universal Plug and Play

Universal Plug and Play (UPnP) helps devices such as Internet appliances and computers access the network and connect to other devices as needed. UPnP devices can automatically discover the services from other registered UPnP devices on the network.

1. Select UPnP on the main menu to display the UPnP screen:

2. Fill in the settings on the UPnP screen:

- **Turn UPnP On.** UPnP can be enabled or disabled for automatic device configuration. The default setting for UPnP is enabled. If this feature is disabled, the router will not allow any device to automatically control the resources, such as port forwarding (mapping), of the router.
 - **Advertisement Period.** The advertisement period is how often the router advertises (broadcasts) its UPnP information. This value can range from 1 to 1440 minutes. The default period is 30 minutes. Shorter durations ensure that control points have current device status at the expense of additional network traffic. Longer durations might compromise the freshness of the device status but can significantly reduce network traffic.
 - **Advertisement Time To Live.** The time to live for the advertisement is measured in hops for each UPnP packet sent. A hop is the number of steps allowed to propagate for each UPnP advertisement before it disappears. The number of hops can range from 1 to 255. The default value for the advertisement time to live is 4 hops, which should be fine for most home networks. If you notice that some devices are not being updated or reached correctly, then it might be necessary to increase this value a little.
 - **UPnP Portmap Table.** The UPnP Portmap Table displays the IP address of each UPnP device that is currently accessing the router and which ports (internal and external) that device has opened.
3. To save or cancel your changes or refresh the table:
- Click **Apply** to save the new settings to the router.
 - Click **Cancel** to disregard any unsaved changes.
 - Click **Refresh** to update the portmap table and to show the active ports that are currently opened by UPnP devices.

Traffic Meter

Traffic metering allows you to monitor the volume of Internet traffic passing through your router's Internet port. With the Traffic Meter utility, you can set limits for traffic volume, set a monthly limit, and get a live update of traffic usage. You enable separate traffic meters for the mobile broadband connection and the Ethernet connection.

➤ **To monitor traffic on your router:**

- Under Advanced on the router menu, select Traffic Meter.
- Click the appropriate **Show Traffic Meter Application for ...** radio button for the type of Internet connection (e.g., mobile broadband or Ethernet) you are setting up.
- To enable the traffic meter, select the **Enable Traffic Meter** check box.
- If you would like to record and restrict the volume of Internet traffic, select the **Traffic volume control by** radio button. You can select one of the following options for controlling the traffic volume:
 - No Limit.** No restriction is applied when the traffic limit is reached.
 - Download only.** The restriction is applied to incoming traffic only.
 - Both Directions.** The restriction is applied to both incoming and outgoing traffic.
- You can limit the amount of data traffic allowed per month:
 - By specifying how many Mbytes per month are allowed.
 - By specifying how many hours of traffic are allowed.
- Set the Traffic Counter to begin at a specific time and date.
- Set up traffic control to issue a warning message before the monthly limit of Mbytes or hours is reached. You can select one of the following to occur when the limit is attained:
 - The Internet LED flashes green or amber.
 - The Internet connection is disconnected and disabled.
- Set up **Internet Traffic Statistics** to monitor the data traffic.
- Click the **Traffic Status** button if you want a live update on Internet traffic status on your router.
- Click **Apply** to save your settings.

Traffic Meter

Traffic Meter Options

Show Traffic Meter options for Mobile Broadband Connection
 Show Traffic Meter options for Ethernet Connection

Enable Traffic Meter for Mobile Broadband

Traffic volume control by No limit

Monthly limit: (MBytes)

Round up data volume for each connection by: (MBytes)

Connection time control

Monthly limit: (hours)

Traffic Counter

Restart traffic counter at am on the day of each month

Traffic control

Pop up a warning message

MBytes/Minutes before the monthly limit is reached

When the monthly limit is reached

Turn the Internet LED amber solid/flashing
 Disable Internet connection when the limit has been reached

Internet Traffic Statistics

Start Date/Time: Tuesday, 01 Jun 2010 00:00
 Current Date/Time: Thursday, 17 Jun 2010 20:32
 Traffic Volume Left: No limit

Period	Connection Time (hh:mm)	Traffic Volume (MBytes)		Total/Avg
		Upload/Avg	Download/Avg	
Today	00:00	0.00	0.00	0.00
Yesterday	00:00	0.00	0.00	0.00
This week	00:00	0.00 /	0.00 /	0.00 /
This month	00:00	0.00 /	0.00 /	0.00 /
Last month	00:00	0.00 /	0.00 /	0.00 /

IPv6 Internet Configuration and Status Check

The IPv6 screen allows you to configure and check the status of your IPv6 Internet connection.

➤ **To configure the Internet connection type:**

1. From the main menu, under Advanced, select **IPv6**. The IPv6 Configuration screen displays.

The screenshot shows the IPv6 Configuration screen. At the top, it says "IPv6". Below that, there is a section for "Internet Connection Type" with a dropdown menu currently set to "Disabled". At the bottom of the screen, there are two buttons: "Apply" and "Cancel".

The default setting is Disabled, which turns off the IPv6 function.

2. Select the IPv6 Internet connection type you want to use, which should be provided by your ISP.
 - **6to4 Tunnel.** If your ISP does not provide a specific IPv6 connection, select **6to4 Tunnel**.

The screenshot shows the IPv6 Configuration screen with the "Internet Connection Type" dropdown set to "6to4 Tunnel". Below this, there is a section for "Remote 6to4 Relay Router" with radio buttons for "Auto" (selected) and "Static IP Address" (with four input fields). Below that is the "LAN Setup" section, which includes "Router's IPv6 Address on LAN" (set to "Not Available"), "IP Address Assignment" (with radio buttons for "Use DHCP Server" and "Auto Config" (selected)), and "Use This Interface ID" (with a checkbox and four input fields). At the bottom, there are three buttons: "Apply", "Cancel", and "Status Refresh".

This screen specifies the remote relay router to which your router creates the 6to4 tunnel. If your ISP provides the address of its own relay router, you can put it here. You can also leave it as Auto, and the router will use any address that is available.

Note: The 6to4 tunnel connection needs the IPv4 Internet connection to be up first.

In the LAN Setup section, enter the requested information:

- **Router's IPv6 Address on LAN.** This shows the IPv6 address acquired for the router's LAN interface. The number after the slash (/) is the length of the prefix, which is also roughly indicated by the underline () under the IPv6 address.

- **IP Address Assignment.** You can select how you want to assign IPv6 addresses to the devices on the LAN (for example, your home network). You can select either the Use DHCP Server or Auto Config option to assign IPv6 addresses. Using a DHCP server might pass more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function. Auto Config is selected by default.
- **Use This Interface ID.** You can enable this option and specify the interface ID you want for the IPv6 address for the router's LAN interface. If you do not specify an ID here, the router will generate one automatically from its MAC address.
- **Auto Detect.** If you are not clear about the IPv6 connection, select **Auto Detect**, and let the router decide the correct type for you.

Enter the requested information:

- **Connection Type.** This indicates the connection type detected.
- **Router's IPv6 Address on WAN.** This shows the IPv6 address acquired for the router's WAN (or Internet) interface. The number after the slash (/) is the length of the prefix, which is also roughly indicated by the underline () under the IPv6 address.
- **Router's IPv6 Address on LAN.** This shows the IPv6 address acquired for the router's LAN interface. The number after the slash (/) is the length of the prefix, which is also roughly indicated by the underline () under the IPv6 address.
- **IP Address Assignment.** You can select how you want to assign IPv6 addresses to the devices on the LAN (for example, your home network). You can select either the Use DHCP Server or Auto Config option to assign IPv6 addresses. Using a DHCP server might pass more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function. Auto Config is selected by default.
- **Use This Interface ID.** You can enable this option and specify the interface ID you want for the IPv6 address for the router's LAN interface. If you do not specify an ID here, the router will generate one automatically from its MAC address.

- **DHCP.** If your ISP indicates that your IPv6 connection is DHCP, select **DHCP**.

Enter the requested information:

- **User Class.** Most users should not need to fill in this field, but if your ISP has given you a specific host name, then enter it here.
- **Domain Name.** This is not needed for most users. You can type the domain name of your ISP. For example, if your ISP's mail server is mail.xxx.yyy.zzz, you would type xxx.yyy.zzz as the domain name. If you have a domain name given to you by your ISP, type it in this box. (For example, Earthlink Cable might require a host name of home, and Comcast sometimes supplies a domain name.)

Note: This is the domain name for the IPv6 connection. The domain name for the IPv4 connection is not specified here.

- **Router's IPv6 Address on WAN.** This shows the IPv6 address acquired for the router's WAN (or Internet) interface. The number after the slash (/) is the length of the prefix, which is also roughly indicated by the underline () under the IPv6 address.
- **Router's IPv6 Address on LAN.** This shows the IPv6 address acquired for the router's LAN interface. The number after the slash (/) is the length of the prefix, which is also roughly indicated by the underline () under the IPv6 address.
- **IP Address Assignment.** You can select how you want to assign IPv6 addresses to the devices on the LAN (for example, your home network). You can select either the Use DHCP Server or Auto Config option to assign IPv6 addresses. Using a DHCP server might pass more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function. Auto Config is selected by default.
- **Use This Interface ID.** You can enable this option and specify the interface ID you want for the IPv6 address for the router's LAN interface. If you do not specify an ID here, the router will generate one automatically from its MAC address.

- **PPPoE.** If your ISP indicates that your IPv6 connection is PPPoE, select **PPPoE**.

Enter the requested information:

- **Login.** This is usually the name that you use in your e-mail address. For example, if your main mail account is JerAB@ISP.com, then put JerAB in this field. Some ISPs (like Mindspring, Earthlink, and T-DSL) require that you use your full e-mail address when you log in. If your ISP requires your full e-mail address, then type it in the Login field.
- **Password.** Type the password that you use to log in to your ISP.
- **Service Name.** If your ISP provided a service name, enter it here. Otherwise, this may be left blank.
- **Connection Mode.** This is the setting specifies when the router should establish the PPPoE connection. Currently the connection mode is always on in order to provide a steady IPv6 connection. The router will never disconnect the connection, and in case the connection is broken (for example, the cable/DSL modem is turned off somehow), the router will bring up the connection right after the PPPoE connection is available.
- **Router's IPv6 Address on WAN.** This shows the IPv6 address acquired for the router's WAN (or Internet) interface. The number after the slash (/) is the length of the prefix, which is also roughly indicated by the underline () under the IPv6 address.
- **Router's IPv6 Address on LAN.** This shows the IPv6 address acquired for the router's LAN interface. The number after the slash (/) is the length of the prefix, which is also roughly indicated by the underline () under the IPv6 address.
- **IP Address Assignment.** You can select how you want to assign IPv6 addresses to the devices on the LAN (for example, your home network). You can select either the Use DHCP Server or Auto Config option to assign IPv6 addresses.

Using a DHCP server might pass more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function. Auto Config is selected by default.


- **Use This Interface ID.** You can enable this option and specify the interface ID you want for the IPv6 address for the router's LAN interface. If you do not specify an ID here, the router will generate one automatically from its MAC address.
- **Fixed.** If your ISP indicates that your IPv6 connection is Fixed IP, select **Fixed**.

Enter the requested information:

- **Fixed.** The fixed IPv6 connection is very rarely used. If you need this type of connection, your ISP provides you with the IPv6 address configurations.
- WAN Setup:
 - **IPv6 Address/Prefix Length.** This specifies the IPv6 address and prefix length of the router's WAN interface.
 - **Default IPv6 Gateway.** This specifies the IPv6 address of the default IPv6 gateway, which is supposed to be on the router's WAN interface.
 - **Primary/Secondary DNS Server.** These specify the DNS servers that will resolve IPv6 domain name records for you. If these fields are not specified, the router uses the DNS servers configured for the IPv4 Internet connection (on the Basic Settings screen).
 - **IP Address Assignment.** You can select how you want to assign IPv6 addresses to the devices on the LAN (for example, your home network). You can select either the Use DHCP Server or Auto Config option to assign IPv6 addresses. Using a DHCP server might pass more information to LAN devices, but some IPv6 systems might not support the DHCv6 client function. Auto Config is selected by default.
- LAN Setup:
 - **IPv6 Address/Prefix Length.** This setting specifies the IPv6 address and prefix length of the router's LAN interface.

LTE Broadband 11n Wireless Router MBR1515

- **Pass Through.** If your ISP explicitly indicates that your IPv6 connection is not DHCP, PPPoE, or Fixed IP, or your ISP indicates that it is IPv6 auto config, select **Pass Through**.



The screenshot shows a web interface for IPv6 configuration. At the top left, the text "IPv6" is displayed in blue. Below this, there is a horizontal line. Underneath the line, the label "Internet Connection Type" is positioned on the left, and a dropdown menu is on the right, currently showing "Pass Through". At the bottom of the form, there are two buttons: "Apply" and "Cancel".

3. Click **Apply** to save the new settings to the router.
4. Click **Cancel** to discard any unsaved changes.
5. Click **Status Refresh** to update the screen and see the information about the current IPv6 connection.

6 Troubleshooting


6

This chapter gives information about troubleshooting your LTE Broadband 11n Wireless Router. After each problem description, instructions are provided to help you diagnose and solve the problem. For the common problems listed, go to the section indicated.


- Is the router on?
Go to *Basic Functioning* on page 88.
- Have I connected the router correctly?
Go to *Basic Functioning* on page 88.
- I can't access the router's configuration with my browser.
Go to *Troubleshooting Access to the Router Main Menu* on page 90.
- I've configured the router but I can't access the Internet.
Go to *Troubleshooting the ISP Connection* on page 91.
- I want to clear the configuration and start over again.
Go to *Restoring the Default Configuration and Password* on page 95.

Basic Functioning







After you turn on power to the router, the following sequence of events should occur:

1. When power is first applied, verify that the Power  LED is on.
2. After approximately 10 seconds, verify that:
 - a. The Power LED is still solid green. An amber light indicates the unit has failed its power-on self-test (POST).
 - b. The Internet LED is lit.
 - c. The Wi-Fi radio LED is lit. The Wi-Fi radio is on by default.
 - d. The Ethernet LAN port LED is lit when any local ports are connected.
If a LAN port's LED is lit, a link has been established to the connected device. If a LAN port is connected to a 100 Mbps device, verify that the port's LED is green. If the port is 10 Mbps, the LED is amber.
 - e. The Ethernet WAN port LED is lit when the router is connected to a wired modem.
 - f. The Signal LED is lit when the router has detected a mobile broadband signal.
 - A blue LED indicates excellent coverage.
 - A green LED indicates good coverage.
 - An amber LED indicates marginal coverage.

If any of these conditions does not occur, refer to the following table.

LED		Action
Power 	Power LED is off.	<ul style="list-style-type: none"> • Make sure the power cord is correctly connected to your router, and that the power supply adapter is correctly connected to a functioning power outlet. • Check that you are using the power adapter supplied by NETGEAR for this product. • If the error persists, you might have a hardware problem and should contact Technical Support.
	Power LED is amber.	There is a fault within the router. Try to clear the fault as follows: <ul style="list-style-type: none"> • Cycle the power to see if the router recovers. • Clear the router's configuration to factory defaults. This sets the router's IP address to 192.168.0.1. This procedure is explained in Restoring the Default Configuration and Password on page 95. If the error persists, you might have a hardware problem and should contact Technical Support.

LTE Broadband 11n Wireless Router MBR1515

LED		Action
Internet Port 	Internet LED is off.	Be sure the SIM card you received is in the router. SIM cards from other devices will not function in the router, and the this SIM card will not function in other devices.
	Internet LED is amber.	The router cannot connect to the Internet. Check the Internet connection option being used. <ul style="list-style-type: none"> • For the mobile broadband connection option, check the Signal LED. • For the Ethernet connection option, check the WAN LED.
	Internet LED is blinking amber and green.	The Traffic Meter feature is enabled, and the limit set has been reached.
Wi-Fi 	Wi-Fi LED is off.	The Wi-Fi radio has been turned off. If you want a Wi-Fi connection with the router, push the Wi-Fi button to turn the Wi-Fi radio back on.
	Wi-Fi LED is not blinking.	If this LED does not blink when you are attempting to send data over the Wi-Fi link, log in to the router menu using the Ethernet LAN connection and check your router's wireless (Wi-Fi) configuration.
LAN Ports 	LAN LED is off.	If this LED does not light when an Ethernet connection is made, check the following: <ul style="list-style-type: none"> • Make sure that the Ethernet cable connections are secure at the router and at the hub or workstation. • Make sure that power is turned on to the connected hub or workstation.
WAN Port 	WAN LED is off.	If this LED does not light when an Ethernet connection is made using the Ethernet connection option, check the following: <ul style="list-style-type: none"> • Make sure that the Ethernet cable connections are secure at the router and at the modem. • Make sure that power is turned on to the modem.
2G/3G 	2G/3G LED is off.	The router cannot tell if the mobile broadband connection uses 2G or 3G signals.
Signal 	Signal LED is off or amber.	If this LED does not light when the Mobile Broadband connection option is used, check the following: <ul style="list-style-type: none"> • Check with your ISP to ensure that there is good coverage in the area. • Ensure that your mobile broadband account is active. • Ensure that the SIM card is inserted correctly into the router. • Locate the router near the window or other area of the building. Make sure that the Signal LED is lit, indicating there is mobile broadband coverage with the router. • Log in to the router menu and check the Internet configuration. Check that the user name, password, and APN with ISP are set correctly. If you use a PIN to connect to the Internet, make sure it is entered correctly.

Troubleshooting Access to the Router Main Menu

If you are unable to access the router main menu from a computer on your local network, check the following:

- If you are using an Ethernet-connected computer, check the Ethernet connection between the computer and the router as described in the previous section.
- Make sure your computer's IP address is on the same subnet as the router. If you are using the recommended addressing scheme, your computer's address should be in the range of 192.168.0.2 to 192.168.0.254.

Note: If your computer's IP address is shown as 169.254.x.x:
Recent versions of Windows and MacOS generate and assign an IP address if the computer cannot reach a DHCP server. These auto-generated addresses are in the range of 169.254.x.x. If your IP address is in this range, check the connection from the computer to the router, and reboot your computer.

- If your router's IP address was changed and you do not know the current IP address, clear the router's configuration to factory defaults. This will set the router's IP address to 192.168.0.1. This procedure is explained in [Restoring the Default Configuration and Password](#) on page 95.
- Make sure that your browser has Java, JavaScript, or ActiveX enabled. If you are using Internet Explorer, click **Refresh** to be sure that the Java applet is loaded.
- Try quitting the browser and launching it again.
- Make sure that you are using the correct login information. The factory default login name is **admin**, and the password is **password**. Make sure that Caps Lock is off when entering this information.

If the router does not save changes you have made in the Web Management Interface, check the following:

- When entering configuration settings, be sure to click the **Apply** button before moving to another screen or tab, or your changes are lost.
- Click the **Refresh** or **Reload** button in the Web browser. The changes might have occurred, but the Web browser might be caching the old configuration.

Troubleshooting the ISP Connection

Check these possible sources of trouble if you are having difficulty connecting to or browsing the Internet.

Connecting to the Internet

If unable to connect to Internet, check the following:

1. The Internet account is active.

If your ISP has provided you with a SIM card and you haven't inserted it into the SIM card slot on the back of the router yet, do so now.

2. Wireless broadband coverage is available where the unit is located.


3. Access the router main menu to verify that the broadband settings are correct. Check with your ISP if you are unsure.

4. Check the location of the router.

- a. Move the router closer to a window for better access to the Internet signal.

- A blue Signal LED indicates excellent coverage.
- A green Signal LED indicates good coverage.
- An amber Signal LED indicates marginal coverage.
- An unlighted Signal LED indicates no coverage.

- b. Maintain recommended minimum distances between NETGEAR equipment and household appliances to reduce interference (see [Interference Reduction Table](#) on page 105).



5. Using an external antenna for improved signal strength:



- a. Install an external antenna. (The external antenna is an optional accessory that you can purchase.)

Mobile Broadband Settings

User Name: <none>

Password: <none>

Initialize Script: AT&F&D2&C1S0=0

Connect automatically at startup

Reconnect automatically When connection is lost

Roaming automatically

Use internal antenna

Wireless Button Configuration

Control WIFI Only Control Both WIFI and Wireless Broadband

Connection Status: Connected

Buttons: Connect, Disconnect, Apply, Cancel, Refresh

- b. Clear the **Use Internal Antenna** check box on the Mobile Broadband Settings screen and then click **Apply**.

- c. Click **Connect** to connect to the Internet.

Troubleshooting Internet Browsing

If your router can obtain an IP address but your computer is unable to load any Web pages from the Internet:

- The traffic meter is enabled, and the limit might have been reached.

By configuring the traffic meter not to block, you can resume Internet access. If you have an usage limit, your ISP might charge you for the overage.

- Your computer might not recognize any DNS server addresses.

A DNS server is a host on the Internet that translates Internet names (such as www addresses) to numeric IP addresses. Typically your ISP provides the addresses of one or two DNS servers for your use. If you entered a DNS address during the router's configuration, reboot your computer and verify the DNS address. Alternatively, you can configure your computer manually with DNS addresses, as explained in your operating system documentation.

- Your computer might not have the router configured as its TCP/IP router.

If your computer obtains its information from the router by DHCP, reboot the computer, and verify the router address.

Troubleshooting a TCP/IP Network Using the Ping Utility

Most TCP/IP terminal devices and routers contain a ping utility that sends an echo request packet to the designated device. The device then responds with an echo reply. You can easily troubleshoot a TCP/IP network by using the ping utility in your computer.

Testing the LAN Path to Your Router

You can ping the router from your PC to verify that the LAN path to your router is set up correctly.

➤ **To ping the router from a PC running Windows 95 or later:**

1. From the Windows toolbar, click the Start button, and select Run.
2. In the field provided, type **ping** followed by the IP address of the router, as in this example:
ping 192.168.0.1

3. Click **OK**.

You should see a message like this one:

Pinging <IP address> with 32 bytes of data

If the path is working, you see this message:

Reply from < IP address >: bytes=32 time=NN ms TTL=xxx

If the path is not working, you see this message:

Request timed out

If the path is not working correctly, you could have one of the following problems:

- Wrong physical connections
 - Make sure that the LAN port LED is on. If the LED is off, follow the instructions in *Connecting to the Internet* on page 91.
 - Check that the corresponding Link LEDs are on for your network interface card and for the hub ports (if any) that are connected to your workstation and router.
- Wrong network configuration
 - Verify that the Ethernet card driver software and TCP/IP software are both installed and configured on your PC or workstation.
 - Verify that the IP address for your router and your workstation are correct and that the addresses are on the same subnet.

Testing the Path from Your Computer to a Remote Device

After verifying that the LAN path works correctly, test the path from your PC to a remote device.

1. From the Windows toolbar, click the Start button, and select Run.
2. In the Windows Run window, type:

```
ping -n 10 IP address
```

where *IP address* is the IP address of a remote device such as your ISP's DNS server.

If the path is functioning correctly, replies as in the previous section are displayed. If you do not receive replies:

- Check that your PC has the IP address of your router listed as the default router. If the IP configuration of your PC is assigned by DHCP, this information is not visible in your PC's Network Control Panel. Verify that the IP address of the router is listed as the default router.
- Make sure that the network address of your PC (the portion of the IP address specified by the netmask) is different from the network address of the remote device.
- Check that your cable or DSL modem is connected and functioning.
- If your ISP assigned a host name to your PC, enter that host name as the account name in the Basic Settings screen.
- Your ISP could be rejecting the Ethernet MAC addresses of all but one of your PCs. Many broadband ISPs restrict access by allowing only traffic from the MAC address of your broadband modem, but some ISPs additionally restrict access to the MAC address of a single PC connected to that modem. If this is the case, you must configure your router to clone or spoof the MAC address from the authorized PC. See the *LTE Broadband 11n Wireless Router MBR1515 Installation Guide*.

Problems with Date and Time

The email screen displays the current date and time of day. The LTE Broadband 11n Wireless Router uses the Network Time Protocol (NTP) to obtain the current time from one of several network time servers on the Internet. Each entry in the log is stamped with the date and time of day. Problems with the date and time function can include the following:

- Date shown is January 1, 2000.
Cause: The router has not yet successfully reached a network time server. Check that your Internet access settings are configured correctly. If you have just completed configuring the router, wait at least 5 minutes, and check the date and time again.
- Time is off by one hour.
Cause: The router does not automatically sense daylight savings time. On the E-mail screen, select or clear the **Adjust for Daylight Savings Time** check box.

Restoring the Default Configuration and Password

This section explains how to restore the factory default configuration settings, changing the router's admin password to **password** and the IP address to **192.168.0.1**. You can erase the current configuration and restore factory defaults in two ways:

- Use the Erase feature (see [Erasing the Configuration](#) on page 52).
- Press the Restore Factory Settings button on the bottom of the router for 6 seconds. Use this method for cases when the administration password or IP address is not known.

The factory default settings are shown in [Factory Default Settings](#) on page 97.

A Supplemental Information



This appendix provides the following information:

- *Factory Default Settings*
- *Technical Specifications*

Factory Default Settings

Use the Restore Factory Settings button located on the bottom of your router to reset all settings to their original factory default settings. This is called a hard reset. To perform a hard reset, push and hold the Restore Factory Settings button for 6 seconds. Your router will return to the factory configuration settings that are shown in the following table.

Feature		Default Behavior
Router login	User login URL	http://www.routerlogin.net or http://www.routerlogin.com
	User name (case-sensitive)	admin
	Login password (case-sensitive)	password
Internet Connection	WAN MAC address	Use default address
	WAN MTU size	1500
	Port speed	AutoSense
Local network (LAN)	LAN IP	192.168.0.1
	Subnet mask	255.255.255.0
	RIP direction	None
	RIP version	Disabled
	RIP authentication	None
	DHCP server	Enabled
	DHCP starting IP address	192.168.0.2
	DHCP ending IP address	192.168.0.254
	DMZ	Disabled
	Time zone	PST for North America
	Daylight saving time adjustment	Disabled
Firewall	Inbound communication from the Internet	Disabled (except traffic on port 80, the HTTP port)
	Outbound communication to the Internet)	Enabled (all)
	Source MAC filtering	Disabled

LTE Broadband 11n Wireless Router MBR1515

Feature (continued)		Default Behavior (continued)
Mobile Broadband	Internet Service Provider:	Bell Mobility
	APN:	inet.bell.ca
	Access Number:	*99#
	PDP Type:	IP
	Username:	none required
WiFi	Wireless communication	Enabled
	SSID name	See label on the bottom of router
	Security	WPA-PSK/WPA2-PSK mixed mode
	Broadcast SSID	Enabled
	Transmission speed	Auto (maximum wireless signal rate derived from IEEE Standard 802.11 specifications. Actual throughput will vary. Network conditions and environmental factors, including volume of network traffic, building materials and construction, and network overhead, lower actual data throughput rate.)
	Country/Region	Canada
	RF channel	Auto
	Operating mode	Up to 145 Mbps
	Data rate	Best
	Output power	Full
	Access point	Enabled
	Authentication type	Open system
	Wireless Card Access List	All wireless stations allowed

Technical Specifications

Technical Specifications	
Network Protocol and Standards Compatibility	TCP/IP, DHCP
Power adapter	<ul style="list-style-type: none"> North America: 120V AC, 60 Hz, input 12V DC @ 1.5A output
Physical specifications	<ul style="list-style-type: none"> Dimensions: 6.8 in. x 5.03 in. x 1.28 in. (173 mm x 128 mm x 33 mm) Weight: 0.65 lbs. without the stand (0.29 kg)
Environmental Specifications	<ul style="list-style-type: none"> Operating temperature: 0° to 40° C (32° to 104° F) Operating humidity: 90% maximum relative humidity, noncondensing
Electromagnetic Emissions	FCC Part 15 Class B; IC; EN 55 022 (CISPR 22), Class B
Interface Specifications	<ul style="list-style-type: none"> LAN: 10BASE-T or 100BASE-Tx, RJ-45 WAN: 10BASE-T or 100BASE-TX, RJ-45
Antenna Connection (Optional)	<ul style="list-style-type: none"> R-TNC connector

Wall-Mounting

B

This appendix provides instructions for wall-mounting your router.


Your router's location can affect wireless connections. For example, the thickness and number of walls the wireless signal needs to pass through might limit its range. For best results, place your router:

- Near an AC power outlet, close to computers you plan to connect with Ethernet cables, and near locations where you use wireless computers. For best signal strength, the router should be within line of sight of your wireless devices.
- In an elevated location, keeping the number of walls and ceilings between the router and your wireless computers to a minimum.
- Away from electrical devices that are potential sources of interference, such as ceiling fans, home security systems, microwaves, or the base for a cordless phone.


➤ **To wall-mount the router:**

1. Drill holes in the wall where you will wall-mount the router.

Holes should be 9.5 in.
(24.1 cm) center to center.




2. Install wall anchors in the holes.



Use pan head Phillips wood screws, 3.5 x 20 mm (diameter x length, European) or #6 type screw, 1 inch long (U.S.).

3. Insert screws into the wall anchors, leaving 3/16 in. (0.5 cm) of each screw exposed.



LTE Broadband 11n Wireless Router MBR1515

4. For best wireless performance, position the wireless antennas as shown.



Compliance Notification



NETGEAR Wireless Routers, Gateways, AP's

Regulatory Compliance Information

Note: This section includes user requirements for operating this product in accordance with National laws for usage of radio spectrum and operation of radio devices. Failure of the end-user to comply with the applicable requirements may result in unlawful operation and adverse action against the end-user by the applicable National regulatory authority.

Note: This product's firmware limits operation to only the channels allowed in a particular Region or Country. Therefore, all options described in this user's guide may not be available in your version of the product.

FCC Requirements for Operation in the United States

FCC Information to User

This product does not contain any user serviceable components and is to be used with approved antennas only. Any product changes or modifications will invalidate all applicable regulatory certifications and approvals.

FCC Guidelines for Human Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Declaration of Conformity

We, NETGEAR, Inc., 350 East Plumeria Drive, San Jose, CA 95134, declare under our sole responsibility that the LTE Broadband 11n Wireless Router MBR1515 complies with Part 15 Subpart B of FCC CFR47 Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

FCC Radio Frequency Interference Warnings & Instructions

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following methods:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an electrical outlet on a circuit different from that which the radio receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

LTE Broadband 11n Wireless Router MBR1515

FCC Caution

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- For product available in the USA market, only channel 1~11 can be operated. Selection of other channels is not possible.
- This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Canadian Department of Communications Radio Interference Regulations

This digital apparatus (LTE Broadband 11n Wireless Router MBR1515) does not exceed the Class B limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

This Class [B] digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada

Industry Canada

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE: Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Caution:

Ce dispositif est conforme à la norme CNR-210 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

NOTE IMPORTANTE: Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

GPL License Agreement

GPL may be included in this product; to view the GPL license agreement go to

<ftp://downloads.netgear.com/files/GPLnotice.pdf>.

For GNU General Public License (GPL) related information, please visit

http://support.netgear.com/app/answers/detail/a_id/2649.

LTE Broadband 11n Wireless Router MBR1515

Interference Reduction Table

The table below shows the Recommended Minimum Distance between NETGEAR equipment and household appliances to reduce interference (in feet and meters).

Household Appliance	Recommended Minimum Distance (in feet and meters)
Microwave ovens	30 feet / 9 meters
Baby Monitor - Analog	20 feet / 6 meters
Baby Monitor - Digital	40 feet / 12 meters
Cordless phone - Analog	20 feet / 6 meters
Cordless phone - Digital	30 feet / 9 meters
Bluetooth devices	20 feet / 6 meters
ZigBee	20 feet / 6 meters

Index

Numerics

2G/3G LED [9](#)

A

access [52](#)

- restrict by MAC address [61](#)
- restricting by MAC address [26](#)
- router password [52](#)

access control [61](#)

administrator login [53](#)

attached devices [50](#)

auto-detect connection [13](#)

B

blocking

- keywords [40](#)
- services [42](#)
- sites [40](#)

broadband settings [14](#)

C

compliance, adapters [103](#)

configuration backup [51](#)

connection mode [13](#)

connection status [49](#)

control buttons [8](#)

D

date and time [95](#)

daylight savings time [43](#), [95](#)

Denial of Service (DoS) [40](#)

DHCP [11](#), [68](#)

diagnostics [53](#)

DMZ server [66](#)

Dynamic DNS, configure [75](#)

E

email notification [37](#), [44](#)

ethernet broadband settings [18](#)

F

factory defaults [9](#), [52](#)

Firmware Upgrade Assistant [12](#)

flash memory [55](#)

I

interference [25](#)

internet port LED [9](#)

Internet traffic statistics [80](#)

IP addresses, auto-generated [90](#)

IPv6 connections, configuring [81](#)

K

keywords, blocking [40](#)

L

LAN

setup [67](#)

LED descriptions [8](#)

log files, save [38](#)

log in [11](#)

log messages [39](#)

log out [11](#)

login not required [20](#)

login required [18](#)

logs, sending [44](#)

M

MAC address [94](#)

location of [62](#)

restricting access [26](#)

manual configuration [14](#)

metric (static route) [77](#)

mobile broadband settings [16](#)

modem unlock code [34](#)

mounting modem router on wall [100](#)

N

network management **45**
 Network Time Protocol (NTP) **43, 95**

P

password
 change **52**
 restoring **95**
 placement **25**
 port forwarding **64**
 port triggering **64**
 ports
 LAN **9**
 WAN **9**
 power LED **9**
 Push 'N' Connect **30**

Q

Quality of Service (QoS) **71**

R

range **25**
 remote management **77**
 reserved IP addresses **69**
 restore factory defaults **9, 52**
 restricted access **61**
 router
 access **52**
 assembly **7**
 back panel **10**
 front panel **8, 88**
 label **10**
 logs **37**
 status **46**

S

show statistics **48**
 signal quality **9**
 SIM
 modem unlock **34**
 PIN Code **33**
 settings **57**
 SMS (Short Message Service), configuring **59**
 SMTP **44**
 static routes **76**
 status LEDs **8, 88**
 syslog **38**

T

TCP/IP network, troubleshooting **93**
 technical support **2**
 time of day **95**
 time zone **43**
 timeout **53**
 time-stamping **43**
 trademarks **2**
 traffic counter **80**
 traffic meter **80**
 traffic status **80**
 troubleshooting **87**
 trusted host **41**

U

Universal Plug and Play (UPnP) **78**
 update firmware **12**

W

wall-mounting modem router **100**
 WAN
 setup **65**
 WAN port LED **9**
 websites, blocking **40**
 WEP
 26
 configure **28**
 Wi-Fi
 button **8**
 LED **9**
 WINS **69**
 wireless
 access control **61**
 configuration **24**
 repeat function **63**
 security **26**
 settings **27**
 WPA
 26, 29
 configure **29**
 WPA + WPA2 **29**
 WPA2
 26, 29
 configure **29**
 WPS
 8, 30
 PIN entry **31**
 unsupported **32**