NETGEAR[®]

Installation Guide

ProSafe® Wall Mount Access Point WN370

Package Contents

Unpack the box and verify the contents:

- ProSafe® Wall Mount Access Point WN370
- Mounting bracket with four mounting screws
- Punch down RJ45 connector
- Warranty card
- Software license agreement
- Regulatory flyer
- Installation Guide

Installation Requirements

You must have the following items to successfully install your access point:

- A 6mm Phillips screwdriver
- A T8 screwdriver
- A computer running Windows XP or Windows 7
- A Standard EU or US wall outlet junction box with an ethernet cable routed through the wall from your LAN to the junction box
- An IEEE 802.3af/at compliant PoE switch or IEEE 802.3af/at compliant PoE iniector

Mount the Access Point

The access point requires an electrical outlet junction box mounted in a wall.

To mount the access point to the wall:

1. Remove the faceplate from the outlet junction box.

- 2. Run the Ethernet cable through the junction box with enough slack to reach the access point.
- 3. Run the Ethernet cables through the mounting bracket.
- Align the mounting bracket with the holes on the junction box. 4.
- 5. Attach the mounting bracket to the junction box using the included Phillips head screws.



6. Connect the Ethernet cable providing PoE and network connectivity to the PoE port on the back of the access point.



Set Up the Access Point

controller:

Note: If the Ethernet cable does not have a standard RJ45 connector, use the included RJ45 punch down connector to connect the Ethernet cable.

- screws.

7. (Optional) Connect the Ethernet cable providing pass through support to the pass through port on the back of the access point.

8. Mount the access point to the mounting bracket using the included T8



The WN370 access point can only be deployed in a network managed by a ProSAFE WC7600 wireless controller. If you have a DHCP server in your network, option 43 must be enabled pointing towards the IP address of the WC7600.

To discover and configure the access point using the WC7600 wireless

1. Access the wireless controller at the network IP address that you configured. 2. Select Access Point > Discovery > Discovery Wizard.

- 3. Follow the steps onscreen to discover the access point and review the discovery results.
- 4. Select Access Point > Discovery > Managed AP List. Add the access points that you want to be managed by the wireless controller to the Managed AP List.

Note: For extensive information about the Discovery Wizard and the discovery process, see the WC7600 reference manual.

Verify Wireless Connectivity

Using a computer with an 802.11b/g/n wireless adapter, verify connectivity by using a browser to connect to the Internet, or check for file and printer access on your network.

You can also check the access point LEDs to verify a successful installation and connection.

LED	Description
Power	Solid amber. The access point is booting. Slow blinking amber. The access point is not managed by a wireless controller. Green.The access point has successfully booted and is managed by a wireless controller.

NETGEAR, the NETGEAR logo, and Connect with Innovation are trademarks and/or registered trademarks of NETGEAR, Inc. and/or its subsidiaries in the United States and/or other countries. Information is subject to change without notice. © NETGEAR, Inc. All rights reserved.

For indoor use only. Valid in all EU member states, EFTA states, and Switzerland.

December 2013



NETGEAR. Inc. 350 East Plumeria Drive San Jose, CA 95134 USA

LED	Description
Active	Blinking Green. There is network traffic through the access point.
	Off . There is not network traffic through the access point.
WiFi On/Off ((*))	Solid Green . The access point's WiFi is active. Off . The access point's WiFi is off.

Note: If you cannot connect, see *Troubleshooting Tips* in this guide.

Troubleshooting Tips

Here are some tips for correcting simple problems you might have.

The WC7600 Cannot Discover or Manage the Access Point

If the WC7600 cannot discover or manage the access point, you can log in to the access point to troubleshoot and download the system log. NETGEAR support will use the system log to help diagnose any problems with the access point.

Note: The WN370 has DHCP enabled by default and receives an IP address if you have a DHCP server in your network. If you have a DHCP server in your network, use the address assigned to the WN370 to log in to the access point.

To log in to the access point and download the system log:

- 1. Configure a computer with the following IP options:
 - IP address. 192.168.0.22
 - Subnet mask. 255.255.255.0
 - Default gateway. 192.168.0.1
- 2. Enter http://192.168.0.160 or your access point's assigned IP address into a browser.
- 3. Log in to the access point using the following default credentials:
 - ID. admin
 - Password, password.

4. Click Monitoring > Logs.

- 5. Click the Save As button.

The Power LED is Solid Amber After Five Minutes

There has been a boot up error and the access point needs to be reset.

To reset the access point:

- cable.
- seconds.

Support

Thank you for selecting NETGEAR products.

After installing your device, locate the serial number on the label of your product and use it to register your product at https://my.netgear.com.

You must register your product before you can use NETGEAR telephone support. NETGEAR recommends registering your product through the NETGEAR website. For product updates and web support, visit http://support.netgear.com.

resources.

For the current EU Declaration of Conformity, visit http://support.netgear.com/app/answers/detail/a id/11621/.

regulatory/.

6. Send the log to NETGEAR support

1. Remove the access point from the wall without disconnecting the Ethernet

2. Press the reset button on the back of the access point for at least five

3. Mount the access point to the wall.

4. Follow the procedure for discovering the access point.

NETGEAR recommends that you use only the official NETGEAR support

For regulatory compliance information, visit http://www.netgear.com/about/