

Preface

Thank you for buying "Xperia" (simply called "the product" or "main unit" from here on). Before using the product, read "Basic Manual" (this manual), "Cautions on using the product" and "Setting Guide" for proper handling.

Packaged items

Before your start using the product, make sure that you have all the following packaged items with the product.

- Xperia
 - USB Type-C™-3.5 φ conversion/TV Antenna cable 01 (03SOHSA)

- 取扱説明書 (Basic Manual) (Japanese)
- ご利用にあたっての注意事項 (Cautions on using the product) (Japanese)
- 設定ガイド (Setting Guide) (Japanese)

The following items are not included in the package.

- microSD memory card
- AC adapter
- Earphones
- Desktop holder
- USB Type-C™ cable

■ Online Manual (Japanese)

Check "Online Manual" (Japanese) which describes detail explanations on various functions on the product from the following procedure.

From the Home screen, ▶**[お客さまサポート (Customer support)]▶[取扱説明書 (Online Manual)] (Japanese)**




Also, you can check "Online Manual" (Japanese) on the au homepage.

<https://www.au.com/online-manual/sovXX/>

In this manual, the contents on Android 9.0 are provided.

CE mark and FCC ID

- Put your fingertip (nail) into the groove of the microSD memory card/au IC card slot and pull out the cover, and insert a fingernail into the hook at the edge of the label tray, then pull it out straight.



Notification LED

The Notification LED prompts charging, or informs battery level while charging, missed calls, new mails, etc. by turning on or flashing.

LED Status	Description
Red	The battery is charging when the remaining battery level is 14% or lower.
Orange	The battery is charging when the remaining battery level is 15% - 89%.
Green	The battery is charging when the remaining battery level is 90% or higher.
Flashing red	The remaining battery level is 14% or lower.
Flashing white¹	Indicates a missed call, new au-mail, etc.
Flashing pale blue¹	Indicates a new message etc.

¹Flashes in sleep mode

❖Information

- Flashing of Notification LED several times in red when Power key is pressed with the power off indicates that the remaining battery is not sufficient.
- Although Notification LED turns in red at the start of charging with the product powered off, the color of Notification LED changes according to the battery level after the charging status screen activates.

■ Charging with the AC Adapter

Charging with connecting TypeC Common AC Adapter 02 (sold separately) is explained.

- Insert the power plug of TypeC Common AC Adapter 02 (sold separately) into an outlet

- Insert the USB Type-C plug of TypeC Common AC Adapter 02 (sold separately) into the USB Type-C connection terminal of the product straight

When charging is started with the product powered on, the start sound for charging sounds and the Notification LED of the product lights.

Connecting headphones or earphones

To hear sound from commercially available headphones or earphones, watch the TV, connect the supplied USB Type-C™-3.5 φ conversion/TV Antenna cable 01.

- Insert the USB Type-C plug of USB Type-C™-3.5 φ conversion/TV Antenna cable 01 to the USB Type-C connection terminal of the product

Turning the power on/off

■ Turning the power on

- Press and hold Power key (over 1 sec.)

The product vibrates and after a while, the lock screen appears.

When "ようこそ (Welcome)" appears after the product is powered on, follow the onscreen instructions to set the initial settings.

For details on the initial settings, refer to "Setting Guide" supplied with the product.

- Swipe (flick) the screen up

The Home screen appears.

■ Turning the power off

- Press and hold Power key (over 1 sec.)

- [Power off]

❖Information

- To restart the product in safe mode (start with almost default state), press and hold Power key (over 1 sec.)▶Long-touch "Power off"▶[OK].

■ For Those Requiring an English Instruction Manual

Download URL:


<https://www.au.com/english/support/manual/>

Regarding notations used in this document

- In this manual, keys (key icons) are represented by simplified illustrations such as . Please be forewarned.
- In this manual, operations of tapping menu items/icons/buttons on the screen, etc. are indicated as [(name of the item, etc.)].
- In this manual, screens and operations for the product with au Nano IC Card 04 attached are described.
- Screen illustrations shown in this manual may look different from the actual screens. In some cases, minor details or a part of a screen may be omitted.
- In this manual, "Basic Manual" (this manual), "Cautions on using the product", "Setting Guide" and "取扱説明書 (詳細版) (Full instruction manual)" (Japanese) are collectively referred to as "Instruction Manual".
- In this manual, explanations for the wallpaper "Black" are provided.
- In this manual, operations in portrait view are described as a standard. In horizontal view, menu items, icons, buttons on the screen, etc. may differ.
- In this manual, "au Nano IC Card 04" is abbreviated as "au IC card".

au IC card

Your phone number etc. is recorded in au IC card. The product is compatible with au Nano IC Card 04.



Attaching/removing au IC card

Before attaching/removing au IC card, make sure to turn off the product.

■ Attaching au IC card

- Put your fingertip (nail) into the groove of the microSD memory card/au IC card slot and draw the cover in the direction of arrow

- Pull out the tray straight from the main unit to remove

- Set au IC card into the tray with the IC (metal) part facing up

Pay attention to the orientation of notch. Surely set au IC card into the tray not to come off.

- Keep the product horizontal, insert the tray with the card into the main unit, and then push it straight

Pay attention to the orientation of the main unit and the tray.

- Firmly press the tray to the end and check that there is no gap between the main unit and the cover

■ Removing au IC card

- Put your fingertip (nail) into the groove of the microSD memory card/au IC card slot and pull out the cover

- Pull out the tray straight from the main unit to remove

- Remove au IC card from the tray, insert and push the tray straight into the main unit

Pay attention to the orientation of the tray and the main unit.

- Firmly press the tray to the end and check that there is no gap between the main unit and the cover

Locking the screen/Unlocking screen lock

■ Locking the screen

Turn off the screen to set sleep mode to prevent the touch panel or key from operating mistakenly or lock the screen.

- While the screen is displayed, press Power key

■ Unlocking screen lock

The lock screen appears when turning the power on or the screen backlight is canceled by pressing Power key.

- While Ambient display (which allows you to check date & time or notifications in sleep mode) is activated, double-tap the screen or press Power key to display the lock screen.

- On the lock screen, swipe (flick) the screen up

❖Information

- In the lock screen, swipe (flick) or to use Google Assistant or Camera.

Changing the language to English

You can change the display language from Japanese to English after the initial settings.

From the Home screen, tap ▶[設定 (Settings)]▶[システム (System)]▶[言語と入力 (Languages & input)]▶[言語 (Languages)]▶[言語を追加 (Add a language)] and select "English"▶"United States", and then drag of "English (United States)" up to the top in the language list.



Key icons


The operations for at the bottom of screen are as follows.




Getting Ready

Names and functions of parts

- Second microphone¹: Reduces noise so that the other party can easily hear your voice.
- microSD memory card/au IC card slot
- Notification LED (▶P.8)
- Proximity/Light sensor: Switches the touch panel on and off to prevent from erroneous operation during a call/Auto-control for display brightness.
- Front camera
- Earpiece/Speaker
- Display (Touch panel)
- Mouthpiece/Microphone
- USB Type-C connection terminal
- Speaker
- Volume key/Zoom key
- Fingerprint sensor
- Power key/Screen lock key
- Camera key



- Nameplate³
- Flash/Photo light
- RGB-C-IR sensor: Detects element of lighting source of shooting environment to adjust white balance automatically when shooting.
- Built-in antenna²
- au IC card
- mark
- Wi-Fi®/Built-in antenna²
- Camera lens
- GPS/Wi-Fi®/Bluetooth® antenna²
- Wi-Fi® antenna²
- Back cover⁴



- Do not jab with a sharp object such as a needle. Doing so may cause a malfunction.
- The antenna is built into the main unit. Covering around the antenna by your hand may affect the quality of call/communication.
- CE mark, FCC ID, IMEI information, etc. can be checked. Do not remove the sticker or nameplate.
- The back cover is not removable. Removing forcibly might cause damage or a malfunction. Also, battery is built into the main unit and not removable by customers.

- Keep the product horizontal, insert the tray with the card into the main unit, and then push it straight

Pay attention to the orientation of the main unit and the tray.

- Firmly press the tray to the end and check that there is no gap between the main unit and the cover

Charging

When you purchase your product, the internal battery is not fully charged. Charge the battery before use.

❖Information

- When charging starts, the Notification LED of the product lights according to the battery level. To check the battery level, see the status bar in the top of the screen, or from the Home screen, ▶[Settings]▶[Battery].
- If you start charging with the product turned off, a screen launches indicating the charging status but operations are not available. Thus, do not charge the product in a place where the use is prohibited.
- The charging time may take longer when charging with a PC or while using the camera function.
- To watch the TV while charging, use the Wireless Charging Pad compatible with Qi (sold separately).

- Firmly press the tray to the end and check that there is no gap between the main unit and the cover

❖Information

- Do not touch the terminal of the microSD memory card.
- Insert a microSD memory card in the appropriate direction. Inserting forcibly could result in removal failure or may cause damage the card.

■ Removing a microSD memory card

- Put your fingertip (nail) into the groove of the microSD memory card/au IC card slot and pull out the cover

- Pull out the tray straight from the main unit to remove

- Remove the microSD card from the tray, keep the product horizontal, insert and push the tray straight into the main unit



Pay attention to the orientation of the tray and the main unit.

■ Pinch

Touch the screen with two fingers and widen (pinch-out) or narrow (pinch-in) the fingers' distance.

■ Drag

Keep touching an item or icon, trace it to the desired direction to move.



Displaying the menu

To display the menu: tap the menu icon (or) or long touch the input field or item.

- Depending on application/function, color or shape of menu icon, or menu display may differ.

