

About the User Guide

Most operation descriptions are based on default settings.

Unless noted otherwise, descriptions are for Home Screen. Some operation descriptions may be omitted.

↓ [Before You Begin](#)

↓ [Data Communication](#)

↓ [Screenshots & Key Labels](#)

↓ [Other Notations](#)

Before You Begin

- Read "Safety Precautions" and this guide thoroughly beforehand for proper usage.
- Accessible services may be limited by contract conditions.
- Unauthorized copying of any part of this guide is prohibited.
- Guide content subject to change without prior notice.

Data Communication

- Handset is designed to be always connected to the Internet. Some functionality, such as data syncing, initiate transmission automatically.
- Large-volume data communication (application downloads, video viewing, etc.) incur expensive transmission fees. Subscription to a flat-rate data plan is strongly recommended.
- Depending on applications and services used, transmission fees may be incurred even while connected by Wi-Fi®.

Screenshots & Key Labels

Screenshots and Key labels are provided for reference only. Actual handset windows, menus, etc. may differ in appearance.

Other Notations

- Xperia XX XX is referred to as "handset" in this guide.
- In this guide, microSD™/microSDHC™/microSDXC™ Card is referred to as "SD Card."
- In this guide and on handset, "abroad" means "outside Japan" with regard to handset/service usage.

Parts & Functions


↓ Handset (Front)

↓ Handset (Back/Side)

↓ Handset Keys


↓ FCC ID

Handset (Front)



Part	Description
1 Front Camera	Use to shoot still images, videos of yourself, etc.
2 Earpiece	Hear the other party's voice here.
3 Proximity/Light Sensor	Detects surrounding brightness to automatically adjust Display or backlight and prevent Touchscreen misoperation during a call.
4 Notification Lamp	Flashes for notifications while Display is off. Lights while charging.
5 Display	Touchscreen-type display, operate with your fingers on Display.
6 Speaker	Listen to music as well as video, etc. audio.

Handset (Back/Side)



Part	Description
1 Second Mic	Reduces noise for calling.
2 5G/4G Antenna Area	Internal Antennas for calls and data communication.
3 Flash/Photo Light	Use as camera flash when taking photos, etc.
4 Main Camera	Capture still images and videos.
5 5G Antenna Area	Internal Antennas for calls, data communication.
6 USB Type-C® Port	Connect USB Type-C cable (commercially available), etc.
7 Headset Jack	Connect commercially available headphones. This port supports tetrapolar headset that conforms to the CTIA standard.
8 5G/4G Antenna/Wi-Fi/Bluetooth®/GPS Antenna Area	Internal Antennas for calls, data communication, Wi-Fi, Bluetooth, and GPS.
9 NFC/Osaifu-Keitai® Detection Area	Hold up to a reader/writer to use NFC/Osaifu-Keitai®.
10 Mic	Speak here.
11 SIM Card/SD Card Slot	Insert SIM Card/SD Card.

Handset Keys



Part	Description
1 Volume/Zoom Up/Down Key	Adjust Volume. Adjust Zoom while using Camera.
2 Power Key/Fingerprint Sensor	Power on/off. Turn Display on/off. Or, use Fingerprint authentication.

FCC ID

To view the regulatory compliance mark

- Find and tap **Settings** → **About phone** → **Certificates**

Regulatory compliance mark such as FCC ID is displayed on the screen.

eSIM

eSIM is an integrated SIM already built into handset. An eSIM-capable handset allows you to use a phonenumber simply with a contract subscription and configuring handset, without the needed replacement of SIM cards.

 [Downloading eSIM](#)

Handling eSIM

For eSIM handling, see the following website.

<https://www.softbank.jp/mobile/support/product/sim/esim/> (Japanese)


Downloading eSIM


1


In Home Screen,  (Settings)  **Network & internet**


Settings

Search settings


 **Network & internet**
Mobile, Wi-Fi, hotspot


 **Device connection**
Bluetooth, Android Auto, NFC

 **Apps**
App permissions, Default apps

 **Notifications**
Notification history, conversations


 **Battery**
100%


 **Storage**
XX% used - XXX GB free

 **Sound**
Audio, Ringtone, Do not disturb

 **Display**
Brightness level, Sleep, Font size

2

 for "SIMs"



- If no SIM Card is installed, Tap **SIMs**.

3


Download a SIM instead?



Connect to mobile network

To use a new SIM card, you'll need to remove the one that's currently in the device



 **Download a SIM instead?**
Add a number using eSIM

Cancel


4

Next



Download your SIM

Connect to your mobile network by downloading the info that's usually on a SIM card. This replaces standard SIM cards and is just as safe.



[Open source licenses](#), [Privacy policy](#) and [Terms of service](#)

Next

5

Scan the QR code



Scan QR code from network

If your network provider gave you a QR code, scan it now by keeping the code centered in the box



[Need help?](#)

6

Download




Use SoftBank?


1 SoftBank number is available for this device.

[Use a different network](#)

Download

7

Enter verification code issued at time of subscription with SoftBank  **Continue**



8

Close



 eSIM download is completed.

- Tap **Settings** to enable eSIM. Continue by following onscreen instructions.

SIM Card


SIM Card is an IC card containing phone number and other customer information.

↓ [Inserting SIM Card](#)

↓ [Removing SIM Card](#)

Handling SIM Card

For SIM Card handling, see following items.



① IC chip

For SIM Card handling, see SoftBank Website.

<https://www.softbank.jp/mobile/support/protect/usim/> (Japanese)

- Always keep the IC chip clean.
- Wipe clean with a dry, soft cloth.
- Avoid applying labels. May damage SIM Card.

SIM Card Cautions

Observe the following when using SIM Card.

- Customer is responsible for any damage caused by inserting SIM Card in an other-brand IC card reader, etc. SoftBank Corp. is not responsible in such case.
- SIM Card is the property of SoftBank Corp.
- SIM is replaceable (at cost) in case of loss/damage.
- Return SIM Card to SoftBank Corp. when cancelling subscription.
- Returned SIM Cards are recycled for environmental purposes.
- Note that SIM Card specifications and performance may change without notice.
- It is recommended that you keep a separate copy of information that is stored on SIM Card. SoftBank Corp. is not responsible for damages from stored information that is lost.
- Always follow emergency procedures to suspend service if your SIM Card or handset (SIM Card inserted) is lost/stolen. For details, contact Customer Service.
- Always power off handset before inserting/removing SIM Card.
- Some services, functions, etc. may have restrictions when an other-carrier SIM card is used.


SoftBank Corp. does not guarantee operation whatsoever.

Inserting SIM Card

Always unmount SD Card beforehand. For details, see "Unmounting SD Card."

1


Pull Tray out from handset



- Pull SIM Card/SD Card Slot Cover out straight using fingernail in groove.

2


Set SIM Card into Tray with IC chip (metal) facing down





- Check SIM Card orientation by notch.
- Make sure SIM Card is in Tray securely.

3

Holding handset held level, press Tray in straight



 SIM Card is inserted.


- Check Tray orientation.
- Press firmly where circled , and make sure there is no gap between handset and SIM Card/SD Card Slot Cover.

Removing SIM Card

Always unmount SD Card beforehand. For details, see "Unmounting SD Card."

1


Pull Tray out from handset



- Pull SIM Card/SD Card Slot Cover out straight using fingernail in groove.


2


Remove SIM Card from Tray




3

Holding handset held level, press Tray in straight



 SIM Card is removed.

- Check Tray orientation.
- Press firmly where circled , and make sure there is no gap between handset and SIM Card/SD Card Slot Cover.

SD Card

Handset supports SD Cards up to 1 TB. Some SD Cards may not operate properly. When using a new SD Card for the first time, always format it on handset.

↓ [Inserting SD Card](#)

↓ [Formatting SD Card](#)

↓ [Unmounting SD Card](#)

↓ [Removing SD Card](#)

SD Card Cautions

Data

Information stored on SD Card can become lost or changed accidentally or as a result of damage. It is recommended that you keep a separate copy of important data. SoftBank Corp. is not responsible for damages from data that is lost or changed.

Reading/Writing Data

Never power off while reading or writing data.

Battery Level

A low battery charge may prevent reading/writing to SD Card.


Handling SD Card

Use/store SD Cards away from the reach of infants. May cause choking if swallowed.

Inserting SD Card

1


Pull Tray out from handset



- Pull SIM Card/SD Card Slot Cover out straight using fingernail in groove.

2


Set SD Card into Tray with metal terminals facing down





- Make sure SD Card is in Tray securely.

3

Holding handset held level, press Tray in straight




 SD Card is inserted.

- Check Tray orientation.
- Press firmly where circled , and make sure there is no gap between handset and SIM Card/SD Card Slot Cover.

Formatting SD Card

1

In Home Screen,  (Settings)




2


Storage


Settings


Search settings


 **Network & internet**
Mobile, Wi-Fi, hotspot


 **Device connection**
Bluetooth, Android Auto, NFC

 **Apps**
App permissions, Default apps

 **Notifications**
Notification history, conversations

 **Battery**
100%


 **Storage**
XX% used - XXX GB free

 **Sound**
Audio, Ringtone, Do not disturb

 **Display**
Brightness level, Sleep, Font size


3

THIS DEVICE




4

SD CARD




5






6

Format



7

FORMAT SD CARD



8

Done

 All data on SD Card is erased.

Cautions when Formatting SD Card


Observe the following when formatting SD Card.

- Formatting erases all data on SD Card. Carefully check any SD Card that was used on another device before formatting.
- Charge Internal Battery while formatting, or format with adequate battery charge.

Unmounting SD Card

Always unmount SD Card before removing.

1

In Home Screen,  (Settings)




2


Storage


Settings

Search settings


 **Network & internet**
Mobile, Wi-Fi, hotspot


 **Device connection**
Bluetooth, Android Auto, NFC


 **Apps**
App permissions, Default apps

 **Notifications**
Notification history, conversations

 **Battery**
100%


 **Storage**
XX% used - XXX GB free

 **Sound**
Audio, Ringtone, Do not disturb

 **Display**
Brightness level, Sleep, Font size


3

THIS DEVICE




4

SD CARD




5






6

Eject




 SD Card is unmounted.

Removing SD Card

Always unmount SD Card beforehand. For details, see "Unmounting SD Card."

1


Pull Tray out from handset



- Pull SIM Card/SD Card Slot Cover out straight using fingernail in groove.


2


Remove SD Card from Tray



3

Holding handset held level, press Tray in straight



 SD Card is removed.

- Check Tray orientation.
- Press firmly where circled ○, and make sure there is no gap between handset and SIM Card/SD Card Slot Cover.

Charging Internal Battery


↓ Charging with AC Charger

! Charging Cautions

Observe the following when charging.

- Never connect USB Type-C plug while handset or peripheral equipment is wet.
- If the message below appears on handset, a charging malfunction has occurred.

Please stop using handset and contact Customer Service for repair.




Charging with AC Charger

AC Charger is an optional accessory. Be sure to use an AC Charger specified by SoftBank. For information on AC Charger and other peripheral devices, see SoftBank Website.

Charging with AC Charger (USB Type-C[®] rapid charging AC Charger with USB PD-PPS capability [ZSDBAV] (SB-AC22-TCPD)) is described as an example.


1

Insert USB Type-C connector of AC Charger straight into USB Type-C Port



2


Unfold power plug of AC Charger and plug into household AC



 Charging start sound sounds and Notification Lamp on handset lights up when charging starts.

3

When charging is complete, unplug AC Charger and remove USB Type-C connector of AC Charger straight from handset



🚩 Charging ends.

Power On/Off


↓ Powering On


↓ Powering Off

Powering On

1

Long Press Power Key until handset vibrates




 Lock Screen appears.

- For details on unlocking screen, see "Unlocking Screen."
- Initial settings appear for the first time handset is powered on. For details on initial settings, see "Making Initial Settings."
- Battery level is not sufficient if Notification Lamp flashes red or low battery indicator appears when Power Key is Long Pressed with handset powered off. Charge Internal Battery.

Powering Off


1

Press Power Key and Volume Up Key



2

Power off



Handset powers off.

Making Initial Settings

When powering on the first time, an initial settings wizard appears for optionally making Wi-Fi, Google™ account, and other settings. Follow onscreen instructions to set items.

To use SIM Card, insert SIM Card before powering on handset.

↓ [Making Initial Settings](#)

eSIM Cautions


When using eSIM, do the following before powering on.

- Remove SIM Card from handset.
- Make sure that handset can connect to the Wi-Fi network.
- Have the QR code ready for eSIM registration.

Making Initial Settings

1


[日本語](#) → [English](#) → [United States](#) → [GET STARTED](#)



- To use eSIM, next select **Download a SIM instead?** → **Next**. Continue by following onscreen instructions.
- To use SIM Card, next Tap **Skip**.

2

Follow onscreen instructions to set Wi-Fi



- To skip Wi-Fi settings while using SIM Card, Tap **Use mobile network for setup/Set up offline**. Continue by following onscreen instructions.

3

Set items to check → **Accept**



Check the following

I am aware of the contents of the [END USER LICENSE AGREEMENT](#)


Yes, I want to help improve Xperia by sharing [app usage and diagnostics data](#). This personal data will be handled appropriately according to the Xperia [Privacy Policy](#).

By tapping ACCEPT, you agree to the [END USER LICENSE AGREEMENT](#). You also confirm your selection of the sharing app usage and diagnostics data. Note: The Xperia [privacy policy](#) describes how data is handled when the app usage and diagnostics data are shared.

Accept

4


Follow onscreen instructions to transfer data



- To set up handset new, Tap **Don't copy**.
- To copy data from another handset on which a Google account is set, Tap **Next**, then follow onscreen instructions.

5


Follow onscreen instructions to set a Google account




- For details on Google accounts, see "Setting a Google Account."
- If not making Google account settings, Tap **Skip**.

6

Select items to set → **Accept**



Follow onscreen instructions to set screen lock / unlocking using fingerprint



- To not set, Tap **Skip**.
- A screen lock is required after restarting handset, fingerprint is not recognized, etc. Do not forget to set.

8

Follow onscreen instructions to set Google Assistant/Voice Match/Google Pay



Access your Assistant with “Hey Google”

If you agree, Google Assistant will wait in standby mode to detect “Hey Google.”



Ask questions

“What’s the weather this weekend?”

Get directions

“Where’s the nearest coffee shop?”

Get things done

“Set an alarm for 5:00am tomorrow.”

You can update this choice in Assistant settings.

[Skip](#)

[I agree](#)

9

Continue



Continue setup?

Keep going to get your device fully set up. Or, leave now and get a reminder to finish later.

Continue

Leave & get reminder

- To complete setup later, Tap **Leave & get reminder**.

10

OK



Review additional apps

Apps will be downloaded when Wi-Fi is available

From SoftBank



Yahoo! JAPAN
Included



PayPay-ペイペイ(キャッシュレスで)
Included



Yahoo!ショッピング-アプリでお得
Included



Disaster Message Board
Included



緊急速報メール
Included



Wi-Fiスポット設定
Included



ボイスメッセージ
Included



5G LAB
Included



スマートセキュリティ powered by I
Included




詐欺ウォール / Internet SagiWall
Included

Ok

11


Next



- To use gesture action, Tap **Gesture navigation**.

12


Follow onscreen instructions make other settings



- To not make other settings, Tap **No thanks**.

13

FINISH



🚩 Settings are complete.

- If confirmation appears, follow onscreen instructions.

Setting a Google Account

Use a Google account and get more convenience with Google services. A Google account is required to use some services or fully use some applications.

↓ [Creating a Google Account](#)


↓ [Logging In with a Google Account](#)

Google Account Cautions

Be careful not to forget your Google account mail address or password.

Creating a Google Account


1

In Home Screen,  (Settings)




2

Passwords & accounts




3


Add account



4

Google



 Window for logging in to a Google account opens.

- If fingerprints are already saved, screen for fingerprint authentication may appear. Hold finger to sensor to authenticate fingerprint.
- If method for unlocking screen is "Pattern" / "PIN" / "Password," screen for unlocking screen lock may appear. Enter method for unlocking screen.

5

Create account



Sign in

with your Google Account. [Learn more](#)


[Forgot email?](#)

Create account

Next

6

For myself



- To create a child's account, Tap **For my child** then follow onscreen instructions.
- To create a business account, Tap **To manage my business** then follow onscreen instructions.

7

Enter First name → Last name → **Next**



8

Enter date of birth → Select gender → Next



Basic information

Enter your birthday and gender

Month	Day	Year
January ▾	1	19XX

Gender
Rather not say ▾

Next

9

Select Gmail™ address → Next

Google

Choose your Gmail address

Pick a Gmail address or create your own

.....@gmail.com

.....@gmail.com


Create your own Gmail address

Next

- To create a Gmail address, **Create your own Gmail address** → Enter username (mail address) → **Next**.


10

Enter password → **Next**



11

Yes, I'm in



- To not add a phone number, Tap **Skip**.
- To add a phone number only for security protection, Tap **More options**. Continue by following onscreen instructions.

12

Next



Review your account info

You can use this Gmail address to sign in later

 XXXXXXXX
.....@gmail.com

Next

13

Check the privacy policy and terms of usage, **I agree**

We process this data for the purposes described in [our policy](#), including to:

- Help our services deliver more useful, customized content such as more relevant search results;
 - Improve the quality of our services and develop new ones;
 - Deliver personalized ads, depending on your account settings, both on Google services and on sites and apps that partner with Google;
 - Improve security by protecting against fraud and abuse; and
 - Conduct analytics and measurement to understand how our services are used. We also have partners that measure how our services are used.
- [Learn more](#) about these specific advertising and measurement partners.

Combining data

We also combine this data among our services and across your devices for these purposes. For example, depending on your account settings, we show you ads based on information about your interests, which we can derive from your use of Search and YouTube, and we use data from trillions of search queries to build spell-correction models that we use across all of our services.

You're in control


Depending on your account settings, some of this data may be associated with your Google Account and we treat this data as personal information. You can control how we collect and use this data now by clicking "More Options" below. You can always adjust your controls later or withdraw your consent for the future by visiting My Account (myaccount.google.com).


[More options](#) ▾

I agree

14


Set Google service → Accept



 Account is created.

Logging In with a Google Account


1

In Home Screen,  (Settings)




2

Passwords & accounts




3


Add account



4

Google




 Window for logging in to a Google account opens.

- If fingerprints are already saved, screen for fingerprint authentication may appear. Hold finger to sensor to authenticate fingerprint.
- If method for unlocking screen is "Pattern" / "PIN" / "Password," screen for unlocking screen lock may appear. Enter method for unlocking screen.


5

Enter mail address  **Next**



6

Enter password → Next



7

Follow onscreen instructions



Welcome


 ●●●●●@gmail.com

We publish the [Google Terms of Service](#) so that you know what to expect as you use our services. By clicking 'I Agree,' you agree to these terms.

You are also agreeing to the [Google Play Terms of Service](#) to enable discovery and management of apps.

And remember, the [Google Privacy Policy](#) describes how Google handles information generated as you use Google services. You can always visit your [Google Account](#) ([account.google.com](#)) to take a [Privacy Checkup](#) or to adjust your privacy controls.

I agree

 You are logged in to your Google account.

Locking Screen

↓ Screen Lock


↓ Unlocking Screen

Screen Lock

Display goes out after a set period of inactivity to save battery power (screen lock).

This also prevents accidental Touchscreen operation.

While Display is off (screen is locked), Press Power Key for Lock Screen.



- To activate Screen lock manually, Press Power Key when Display is turned on.




When Screen Locks during Music Playback

Music playback continues. While Display is off (screen is locked), Press Power Key for music panel in Lock Screen. Use pause, next song, etc. (operation may differ with application).

Unlocking Screen

1


While Display is off (screen is locked), Press Power Key



 Lock Screen appears.

2

Flick screen up



🚩 Screen is unlocked.

- The method for unlocking the screen can be changed.
- For fingerprint authentication, Touch Fingerprint Sensor with authentication finger to unlock screen.


Basic Operation


↓ Selecting Options and Navigating Screens

↓ Menu Operations

Selecting Options and Navigating Screens


Tap items, icons, onscreen keys, etc. to open assigned items.


■ Tap  to go back to previous screen.



Menu Operations


1

Tap  for available settings and items.



2

Screens may also have settings and items that are available by Touching & Holding Display.




Using Touchscreen

Handset uses a touchscreen-type Display. Operate with your fingers on Display.

- ↓ Tap
- ↓ Touch & Hold
- ↓ Drag
- ↓ Swipe/Flick
- ↓ Pinch/Spread


Tap

Contact Display lightly and briefly.




Touch & Hold

Touch screen lightly and hold it for a while. When the screen changes, release finger.




Drag

Touch icon or other item lightly, move it where desired, and release finger.




Swipe/Flick

Contact Display lightly, then brush screen up/down or left/right.



Pinch/Spread

Contact Display lightly, then close/widen fingers.



Silent Mode

Set ringtone, operation sounds, etc. not to sound to avoid disturbing others around you.

↓ [Entering Silent Mode \(Vibrate\)](#)

↓ [Entering Silent Mode \(No Vibrate\)](#)


Silent Mode Cautions

Camera shutter, video start/stop tones, Alarm, etc. sound even in Silent mode.


Entering Silent Mode (Vibrate)

1

Press Volume Up or Down Key



2



3



While volume adjustment bar is shown, 



 Icon changes to , and handset enters Silent mode (vibrate).

Entering from Quick Settings


Also use Quick Settings to enter Silent mode (vibrate).

Flick Status Bar down  Flick window down  **Silent mode (off)**

Entering Silent Mode (No Vibrate)


1

Press Volume Up or Down Key



2





3




While volume adjustment bar is shown, 



 Icon changes to , and handset enters Silent mode (no vibrate).

Entering from Quick Settings

Also use Quick Settings to enter Silent mode (no vibrate).

Flick Status Bar down  Flick window down  **Silent mode (off)**  **Silent mode (vibrate)**

Airplane Mode

Disable all functions that emit signals. Handset stays powered on.

↓ [Using Airplane Mode](#)


Using Airplane Mode

1

Flick Status Bar down



Airplane mode



 Handset is in Airplane mode.

- Use same operation again while in Airplane mode to cancel.

Text Entry


↓ [Keyboards](#)

↓ [QWERTY Keyboard Layout](#)

↓ [Switching Character Types \(Entry Modes\)](#)

Keyboards

Enter text with onscreen QWERTY keyboard by Tapping each character individually, or by using Glide typing feature and sliding finger from character to character (on by default). Touch & Hold each character for extended characters.

- Tap  to hide keyboard.

Keyboard Operations

Setting Keyboard to Use

In a text entry window,   Languages  English (US)  Select keyboard  Done

- Set several keyboards.


Switching Keyboards

Set several keyboards to switch between.

In a text entry window, 

- Alternatively, Long Press   Tap keyboard to switch to.

QWERTY Keyboard Layout





- ① Use the keyboard option menu (Toolbar).
- ② Enter a character.
- ③ Switch between all lower case and sentence case. Double-Tap for all upper case.
- ④ Toggle entry modes.
- ⑤ Use voice input.
- ⑥ Delete a character before cursor.
- ⑦ Confirm text input or enter line break. 🔍, →, ↵, or ✓ appears depending on application.
- ⑧ Enter a comma. Touch & Hold for text entry settings or to set one-handed mode. With several set keyboards, Touch & Hold 🗂️ for emoji, emoticons, etc.
- ⑨ Show emoji, emoticons, etc. With several set keyboards, 🌐 to switch between keyboards.
- ⑩ Enter a space.



Switching Character Types (Entry Modes)

1

In QWERTY keyboard, Tap 



 Entry mode is changed to number and symbol mode.

- To enter more symbols, Tap .
- Tap  to back to alphabet mode.

Updating Software

Steps to update software depend on what is being updated in the software. Checking/updating does not incur transmission fees.

↓ [Updating Software Automatically](#)

↓ [Updating Software Manually](#)

Software Update Cautions

Signal Reception

Operate handset where signal reception is good and without changing location. Also operate with adequate battery charge. Signal becoming weak or Internal Battery becoming low during an update may cause an update failure. An update failure may disable handset.

Saved Data/Settings

Saved data may be lost depending on condition of handset (malfunctioning, damaged, water exposure, etc.). SoftBank Corp. is not responsible for damages from loss of data.

Updating software may revert some settings to their defaults.

Updating Software Automatically

Update software automatically.

When the update is complete, Tap the notification in the Notifications Window and restart handset.


Updating Software Manually

Tap the software update notification in the Notifications Window and follow onscreen instructions.

Alternatively:

1

In Home Screen,  (Settings)  System



2

System update