SOV32

Basic Manual

Preface

Thank you for buying "Xperia™ XX" (simply called the "product"

Before using the product, read "Basic Manual" (this manual) and "取扱説明書 (詳細版) (Full Instruction Manual)" (Japanese) to ensure safe use and handling.

Packaged items

Before your start using the product, make sure that you have all the following packaged with the product

- Xperia[™] XX^{*1}
- Sonv Mobile TV antenna cable 02 (02SOHSA)
- *1 Including warranty
- 取扱説明書 (Instruction Manual) (Japanese)
- Xperia[™] XXのご利用にあたっての注意事項 (Cautions on using)
- ・設定ガイド (Setting Guide) (Japanese)

The following items are not included in the package

 microSD memory card AC adapter

(17) Wi-Fi® antenna*2

19 au Nano IC Card 04

Built-in antenna*2

microSD memory

24 microUSB connection

card/au Nano IC Card

(18) Nameplate*3

20 Back cover

04 slot

3 Strap hole

terminal

cause a fault.

7

14

and IMEI information printed

not removable by customers.

■ Charging with the DC Adapter

■ Charging with a PC

port of a PC

USB port of the PC

- Desktop holder
- Earphones
- microUSB cable

SONY

*1 Do not jab with a sharp object such as a needle. Doing so may

*3 Do not remove the nameplate with stickers of CE mark, FCC ID

*4 Back cover is not removable. Removing so forcibly might cause

3 When charging is complete, remove the microUSB plug of

4 Remove Common AC Adapter 05 (sold separately) from

You can charge from cigarette lighter socket in a car by using

Common DC Adapter 03 (sold separately). For details, refer to

The followings describe charging procedure by connecting

1 Insert the microUSB plug of the microUSB cable, with

the engraved side () facing up, straight into the

2 Insert the USB plug of the microUSB cable into the USB

3 When charging is complete, remove the microUSB plug

4 Remove the USB plug of the microUSB cable from the

of the microUSB cable from the product and close the microUSB connection terminal cover firmly

the product to chargeable USB port on a PC using the

microUSB cable of Sony Mobile AC adapter 05 (sold

microUSB connection terminal of the product

When a confirmation screen for software installation

appears on the product, tap "Skip" or "Cancel"

Notification LED lights on the product.

instruction manual of Common DC Adapter 03 (sold

Common AC Adapter 05 (sold separately) from the product

damage or a fault. Also, battery is built into the main unit and

*2 The antenna is built in. Covering around the antenna by the

hand may affect the quality of call/communication.

0

4 5 6

SONY

Names and functions of parts

Getting Ready

1 Headset connection ② Second microphone* Reduces noise to make easy to listen (3) Notification LED

Front camera 5 Earpiece/Speaker 6 Proximity sensor: Switches touch panel on and off to prevent from

during a call/Auto-control for display brightness 7 Display (Touch panel)

erroneous operation

8 Microphone/speaker 9 @ Power key/Screen lock key

10 Volume key/Zoom key ① Camera key

12 Camera lens (13) GPS/Built-in antenna*2

14 Flash/Photo light 15 2 mark

16 Wi-Fi®/Bluetooth®/antenna part*2

■ Charging with the AC Adapter

Charging with Common AC Adapter 05 (sold separately) is

1 Insert the microUSB plug of Common AC Adapter 05 (sold separately), with the engraved side (\blacktriangle) facing up, straight into the microUSB connection terminal of the product

2 Insert the power plug of Common AC Adapter 05 (sold

. The battery is built into the product.

Illustrations used in this manual are just images for explanations They may be different from actual ones.

About Operating Instructions

■ Basic Manual (this manual)

♦Information

Handles only basic operations for main features. For detailed descriptions on various functions, refer to the "Basic Manual" (Japanese) app installed on the product or "取 扱説明書 (詳細版) (Full Instruction Manual) (Japanese)" available on the au homepage. http://www.au.kddi.com/support/mobile/quide/manual

 Company names and product names referred to in this manual are trademarks or registered trademarks of respective companies. The TM, ® marks may be omitted in this manual.

■ "Basic Manual" (Japanese) app This product allows you to use the "Basic Manual" (Japanese) app on the product to confirm detailed operational procedures

Certain functions can be directly activated from the app screens on which their operations are described.

• When you activate for the first time, follow the onscreen

instructions to download and install app.

CE mark and FCC ID

1 Open the au Nano IC Card 04 slot cover, and insert a fingernail into the hook at the edge of the label tray, then pull it out straight.



au Nano IC Card 04

Your phone number etc. is recorded in the au Nano IC Card 04. The product is compatible only au Nano IC Card 04 with au Nano IC Card 04. You cannot use the product with an IC card other than au Nano IC Card Front

Attaching/removing the au Nano IC Card 04

Before attaching/removing the miroSD memory card, make sure to turn off the product.

Attaching the au Nano IC Card 04

1 Open the microSD memory card/au Nano IC Card 04 slot cover while hooking the groove with your fingernail

Turning on (Initial settings)

Turning the power on

1 (b) (over 1 sec)

The product vibrates and after a while the lock screen appears.

When you turn on the product for the first time, follow the onscreen instructions to set the initial settings

2 Swipe (flick) the screen up

■ Turning the power of

1 (b) (over 1 sec)

2 [Power off]

• Press (b) (over 1 sec) ► Long-touch "Power off" ► [OK] to restart the product in safe mode (a function that enables to start the product in a status equivalent to the status at the time of purchase)

cover while hooking the groove with your fingernail, for approximately three seconds, and release your finger

as needle may cause malfunction

 Alternatively, press and hold (1) and upper part of the volume key at the same time for approximately three seconds, and release your finger after it vibrates three times

Initial settings

When you turn on the product for the first time, follow the onscreen instructions to set language, functions, service, etc. For details, refer to "Setting Guide".

Do not insert au Nano IC Card 04 with conversion adapter attached. Doing so may cause a fault.

Attaching/Removing microSD memory card Before attaching/removing the miroSD memory card, make sure to turn off the product.

♦Information

• To change the language later, from the Home screen, [....] ▶[設定 (Settings)]▶[言語と入力 (Language & input)]▶[地域 /言語 (Language)]. To make settings, from the Home screen, [●]▶[Settings]▶[Setup guide]. To make settings for au service etc., from the Home screen, [:::]▶[Settings]

害用音声お届けサービス (Disaster Voice Messaging Service), and

1 From the Home screen, [⊞]▶[お客さまサポート (Custome

au災害対策 (au Disaster Countermeasure) menu appears.

An agreement screen regarding the use or an initial setting

screen appears for the first time you activate this program

■ Using 災害用伝言板 (Disaster Message Board)

Disaster Message Board service enables you to register information of well-being from an area of distress via LTE NET in case of large-scale

disaster such as earthquake with a seismic intensity of over 6 lower.

1 au災害対策 (au Disaster Countermeasure) menu▶[災害

(~ezweb.ne.jp) is required. Set up E-mail address beforehand.

■ Using 緊急速報メール (Emergency Rapid Mail)

Emergency Rapid Mail is a service that distributes Earthquake

meteorological bureau or Disaster and Evacuation Information

When you receive Earthquake Early Warning, ensure your

around you. When you receive a Tsunami Warning, draw away

from sea coast immediately and evacuate to safe place such

1 au災害対策 (au Disaster Countermeasure) menu▶[緊急

1 Open the cover while hooking the groove of microSD

2 Hook the projection of the tray with your fingernail to

3 Remove au Nano IC Card 04 out of the tray, insert the

tray into the main unit and then press it all the way

4 Close the microSD memory card/au Nano IC Card 04

slot cover, press it firmly to ensure that there are no

• Note the following points, otherwise handling the au Nano IC

· Do not touch the IC (metal) part of the au Nano IC Card 04.

· Do not lose the au Nano IC Card 04 after it has been

Pay attention to the direction of pushing the tray

gaps between the cover and the main unit

Card 04 may cause malfunction or damage

· Do not use force to attach or remove

· Insert in the correct direction.

memory card/au Nano IC Card 04 slot cover with your

slide the tray straight out, then remove the tray from the

safety and take proper action according to the situation

delivered from the government or local public organization to all

support)]▶[au災害対策 (au Disaster Counter

災害関連情報 (Disaster related information)

Follow the onscreen instructions.

用伝言板 (Disaster Message Board)]

• To register information of well-being, E-mail address

Early Warning or Tsunami Warning delivered from the

au cell phones in specified areas simultaneously.

速報メール (Emergency Rapid Mail)]

Removing au Nano IC Card 04

main unit

♦Information

removed.

as upland or well-built high building

When the screen lock is set, the backlight turns off to avoid the keys and touch panel from false operations. When the specified time elapses, the product's screen backlight turns off automatically and screen lock is activated.

Unlocking screen

The lock screen appears when turning the power on or the backlight on by pressing (b).

1 Swipe (flick) the screen up on the lock screen

• On the lock screen, swipe " or " to activate "Phone" app or "Camera" app, respective

♦Information

- Reception of Emergency Rapid Mail is notified by a special warning tone and vibration. It is not possible to change the warning tone. Earthquake Early Warning is notified by warning tone and voice
 - sound ("地震です" (It is an earthquake)), and vibration The warning tone does not sound when receiving
 - Emergency Rapid Mail during a call.
- Earthquake Early Warning may not arrive before strong tremors in areas near the epicenter.
- Tsunami Warning is a major tidal wave/seismic sea wave notification delivered from the meteorological bureau to the
- area including target coast.

 Disaster and Evacuation Information is a service that distributes bulletins concerning residents' safety including
- evacuation advisories, evacuation orders and other warnings issued by the national and local governments.
- The service is available only in Japan (it cannot be used overseas) • No information fee or communication charge is required for receiving Emergency Rapid Mail.
- KDDI is not liable for damages suffered by customers resulting from the service's information, lack or delay in the information caused by transmission or system breakdowns or other events that are outside the responsibility of KDDI.
- · Refer to the Japan Meteorological Agency web page for details about distribution of Earthquake Early Warning. http://www.jma.go.jp/

You cannot receive Emergency Rapid Mail when your cell

- phone is turned off · Emergency Rapid Mail may not be received if you are in a place where signal does not reach even in the service area
- (e.g. in a tunnel, basement) or in a place with a poor reception. • You cannot receive the Emergency Rapid Mail that the
- reception is failed.



■ Attaching microSD memory card

- 1 Open the microSD memory card/au Nano IC Card 04 slot cover while hooking the groove with your fingernal 2 Hook the projection of the tray with your fingernail to
- slide the tray straight out, then remove the tray from the product 3 Set microSD memory card into the tray with IC (metal)
- part facing up (10), insert the tray with the card into the main unit and press it all the way Pay attention to the direction of pushing the tray.

4 Close the microSD memory card/au Nano IC Card 04

gaps between the cover and the main unit

slot cover, press it firmly to ensure that there are no

· Insert a microSD memory card in the appropriate direction.

Inserting a microSD memory card forcefully into the slot

• Do not touch the terminal of the microSD memory card.

could result in failure to remove the microSD memory card

When you purchase your product, the internal battery is not

♦Information

- When the charging starts, notification LED lights according to
- the instructions of each airline or medical facility for the use of
- while using the camera function.

The display of the product is a touch panel operated by

■ Tap/Double-tap Tap: Gently touch a screen and then immediately release your

finger. Double tap: Touch the same position twice. ■ Long-touch

Keep touching an item with your finger.

Operate the screen by quickly moving (flicking) your finger

Touch the screen with two fingers and widen (pinch-out) or narrow (pinch-in) the fingers' distance.

Drag





- separately) into an outlet
- Notification LED lights on the product



Purchase a specified charger (sold separately).

For Those Requiring an English Instruction Manual You can download the English version of the instruction manual from the au homepage (available in approximately one month after the product is released). Download URL:

http://www.au.kddi.com/support/mobile/guide/manual/

Regarding notations used in this document

simplified illustrations such as <a> \bigai . <a> \bi

Operations of tapping menu items/icons/buttons on the

Screen illustrations shown in this manual may look different

from the actual screens. In some cases, minor details or a

screen etc. are indicated as [(name of the item etc.)]

part of a screen may be omitted.
• In this manual, "microSD™ memory card", "microSDHC"

memory card" and "microSDXC™ memory card" are

abbreviated as "microSD memory card" or "microSD"

• "The Company" as appears in the manual refers to the

Manufactured by: Sony Mobile Communications Inc.

following companies

TELEPHONE COMPANY

All of the indicated amounts exclude tax unless otherwise

Sold by: KDDI CORPORATION, OKINAWA CELLULAR

Using au 災害対策 (au Disaster Countermeasure)

You can use 災害用伝言板 (Disaster Message Board) service, 緊

急速報メール (Emergency Rapid Mail) service that distributes 緊

急地震速報 (Earthquake Early Warning), 災害・避難情報 (Disaster

and Evacuation Information) and 津波警報 (Tsunami Warning), 災

2 Hook the projection of the tray (1) with your fingernail

to slide the tray straight out, then remove the tray from

• In this manual, keys (key icons) are represented by

3 Set au Nano IC Card 04 into the tray with IC (metal) part

facing up (2), insert the tray with the card into the

main unit and press it all the way Pay attention to the orientation of the notch and pressing tray.

4 Close the microSD memory card/au Nano IC Card 04 slot cover, press it firmly to ensure that there are no gaps between the cover and the main unit

■ Force-quitting 1 Open the microSD memory card/au Nano IC Card 04 slot press the OFF button (YELLOW) with a fine-tipped object

♦Information

• Pressing the OFF button (YELLOW) by a sharp object such

Setting Screen lock

1 While the screen is displayed, (6)

Basic Operation

Key icons

or damage

The followings are the main functions of \square , \square keys located at the bottom of the screen



Back	box, menu, or the Notifications panel.
	Display the Home screen. Long-touch and drag it to "[]" to activate "Google" app.
Recently	Display recently used apps on a list and activate or end them from the list. Also, you can use small apps.

♦Information To use Wi-Fi[®], initial settings via 4G (LTE/WiMAX 2+) network is required

• This delivery system is different from Earthquake Early

Warning arrives may vary.

Messaging Service)

may be received

Warning provided through TV, radio, or other communication

procedures, which means that the time the Earthquake Early

• Information from someplace other than your current location

■ Using 災害用音声お届けサービス (Disaster Voice

Disaster Voice Messaging Service is a service which allows

1 au災害対策 (au Disaster Countermeasure) menu▶「災害用

音声お届けサービス (Disaster Voice Messaging Service)]

you to record your voice and send someone you want to


inform your well-being in case of a large-scale disaster


- Voice message can be recorded for up to 30 seconds.
- Voice messages cannot be saved or played if the product does not have available memory

■ Using 災害関連情報 (Disaster related information) You can check history of Disaster and Evacuation Information delivered by local government, disaster related information

1 au災害対策 (au Disaster Countermeasure) menu▶[災害関 連情報 (Disaster related information)]▶ Follow the







2 Hook the projection of the tray with your fingernail to slide the tray straight out, then remove the tray from the

insert the tray into the main unit and then press it all the Pay attention to the direction of pushing the tray.

3 Remove the microSD memory card out of the tray,

4 Close the microSD memory card/au Nano IC Card 04 slot cover, press it firmly to ensure that there are no gaps between the cover and the main unit

Charging

fully charged. Charge the battery before use.

- the battery level. To check the battery level, see the status bar in the top of the Home screen. Alternatively, from the Home screen. [⊕] ▶ [Settings] ▶ [About phone] ▶ [Status] and see "Battery
- When you start charging with the product powered off, the power turns on even though operation is not available. Follow
- cell phones on their premises. • It may take longer to complete for charging with a PC or





Using the touch panel


touching it with your finger.

While your finger is gently touching the screen, trace it to the

Flick (swipe)

up/down or left/right.

Keep touching an item or icon, trace it to the desired direction to move









Adding to Home screen/Editing Home screen

add/delete/move shortcuts of apps, widgets, folders, etc. on the Home screen

are displayed

When airplane mode is set, all wireless functions (phone, packet communication, Wi-Fi® function, Bluetooth® function,

To display the software keyboard, tap a character input box

on the character entry screen for adding contacts, creating a

With "International keyboard", you can use QWERTY keyboard

to enter characters, Numeric keypad to enter numbers and

For Symbol keypad, tap " on the Numeric keypad.

Tap " Tap " at the bottom of the screen to hide the software

• Switch between lower-case " " ", upper-case " 1 and

When using QWERTY keyboard, touch and hold a character

Tap " to delete the character before the cursor

1 From the Home screen, [....] ▶ [Settings] ▶ [More]

NFC Reader/Writer, P2P function) are turned off.

Use software keyboard to enter characters.

symbols, and Symbol keypad for more symbols

You can change wallpaper or theme of the Home screen and

1 Long-touch an area of the Home screen where no icons

Alternatively, pinch-in on the Home screen.

■ Setting Airplane mode

2 [] of "Airplane mode"

Entering characters

Switching keyboards

1 Tap a character input box

QWERTY keyboard appears

2 Tap [127] to display Numeric keypad

caps " on QWERTY keyboard

For inquiries, call: Customer Service Center

Business hours 9:00-20:00 (7 days a week)

For loss or theft (toll free)

Business hours: 24 hours live supp

6120-977-033 (except Okinawa)

Keitai Guarantee Service Center

Business hours 9:00-21:00 (7 days a week)

0120-977-699 (Okinawa)

For loss, theft, damage.

H 0120-925-919 (toll free)

From fixed-line phones: | From au cell phones

0077-7-113 113 without area code

rom fixed-line phones: | From au cell phones

0077-7-111 157 without area code

AFTER CALLING 157 ON YOUR au CELLPHONE

PRESSING ZERO WILL CONNECT YOU TO AN OPERATOR

In case above numbers are not available (toll free).

to select a character variant.

message, etc.

2 Widgets & Apps Add shortcuts of widgets or elect an image from albums lallpapers set as a wallpaper. To set image range, adjust cropping area by dragging, Select a content from albums to set as a wallpaper. 'allpape hotos Select an image from photos to set as a wallpaper. 'Xperia™'s Select an image to set as a Vallpaper) wallpaper Images displayed to the right of "Photos"/"Live Wallpapers" are "Xperia™'s Wallpaper' hemes Set the wallpapers etc. for the Home screen or the lock Iome Settings Set auto rotation of the Home screen or size of icons.

Adding a folder

- 1 From the Home screen, long-touch an icon
- 2 Drag the icon onto another icon

Support

Introduction of related accessories

For details, refer to the instruction manual for each device. • Sony Mobile Desktop Holder 01 (01SOPUA) (sold

- Sony Mobile TV antenna cable 02 (02SOHSA)
- Sony Mobile AC adapter 05 (EP880) (sold separately)
- microUSB cable 01 (0301HVA) (sold separately) microUSB cable 01 Navy (0301HBA) (sold separately) microUSB cable 01 Green (0301HGA) (sold separately) microUSB cable 01 Pink (0301HPA) (sold separately) microUSB cable 01 Blue (0301HLA) (sold separately)
- · Common DC Adapter 03 (0301PEA) (sold separately)
- · au Carrying Case F Black (0105FCA) (sold separately)
- · au Carrying Case G Black (0106FCA) (sold separately)
- · au Carrying Case H Black (0107FCA) (sold separately)
- · Common AC Adapter 05 (0501PWA) (sold separately)

- For the latest information on accessories, visit the au homepage (http://www.au.kddi.com/) or contact the Customer Service
- Accessories described above can be purchased from the au Online Shop. Some accessories may not be purchased due to the availability

http://auonlineshop.kddi.com/

■ Keitai Guarantee Service Plus LTE

An after-sales service membership program on a monthly For general information, charges and operation information (toll free) basis called "Keitai Guarantee Service Plus LTE" (monthly fee: 380 yen tax excluded) is available for using your au cell phone for a long time without worries. This service expands coverage for many troubles including malfunction, theft and loss. For details of this service, refer to au homepage or contact Keitai Guarantee Service Cente

28

· You can apply for membership only at the time of purchasing your au cell phone.

• Once you cancel the membership, you cannot reapply for it until you purchase an au cell phone next time.

Note that when changing the model or purchasing an extra cell phone, this service only covers the most recently

purchased au cell phone. When an au cell phone is handed over to you or someone else, the Keitai Guarantee Service Plus LTE membership is also handed over to the successor of the cell phone.

When you get a new au cell phone by changing the model or purchasing an extra cell phone, the "Keitai Guarantee Service Plus"/"Keitai Guarantee Service Plus LTE" membership for the

old au cell phone is automatically canceled. Service contents are subject to change without notice

au Nano IC Card 04

The au Nano IC Card 04 is lent to you by au. In case of loss or damage, the card will be replaced at your expense. When a malfunction is suspected, or in case of theft or loss, contact an au shop or PiPit.

vou want to delete

To delete a folder, then tap "DELETE". It also deletes

· Long-touch a shortcut, widget, or folder icon to move.

■ Deleting shortcuts/widgets/folders Downloading apps You can download and install apps or games, etc. by using Google 1 From the Home screen, long-touch an icon or a folder

> • To use Google Play, you need to set a Google account. For details, refer to "Setting Guide" ■ Deleting (uninstalling) apps

Before deleting installed apps, back up contents related to

担号节

Google

Examples of notification icon

New Gmail message

Talking*1/ Calling*

Symptom

Cannot charge the

LED does not light,

the battery icon

ouch panel

Cannot operate

touch panel as

Charging is not

is short

A message such as

charge the battery

does not change

into charging one)

attery (Notification

New PC mail message

the app that you want to save including data saved in the app. • Some apps may not be deleted.

left of the status bar, notification icons appear to inform missed

calls, new mails, operations in progress, etc., and on the right,

100 12:3

What you should check

s the specified charging equipmen

sold separately) attached properly?

Turn off the power and then turn it on

Are you operating with a fingernail or

oreign object on the operating

s the temperature of the product

Charge until the notification LED turn

Is the internal battery end-of-life?

Is the product used for a long period

at places where (Out of service

24

status icons appear to indicate the status of the product.

New E-mail (@ezweb.ne.jp) message

w Receiving notification

Cannot operate key/ Is the power turned on?

Battery usage time Is the battery fully charged?

New SMS/Receiving notification service message,

s "Screen lock" set?

ised or very low?

area) appears?

The battery is almost dead

Knowing the status of the product

Status bar You may incur communication charges depending on the The status bar is located at the top of the product screen. On the

You can call up functions from the Apps screen. App icons

2 Drag the icon or the folder to "Remove"

shortcuts etc. in the folder

Using the Apps screen

2 Tap an app to use

🌈 , 🛂	Phone, Contacts		Play Store
305	E-mail, SMS	📵 , 🕝	Camera, Album
9	Chrome	8	Maps
Ö	Settings	8,	Google, Voice Search
•	Calendar	N CONTRACTOR	Basic Manual
			·-

Troubleshooting

Before you assume that the product is malfunctioning, check

Symptom	What you should check
Power is not turned	Is the internal battery charged?
on even though (b) is pressed	Is @ pressed for over 1 second?
The power goes off	Is the internal battery charged?
The power turns off while activation screen is displayed	Is the internal battery charged?
The screen freezes and the power cannot be turned off	Open the microSD memory card/au Nano IC Card 04 slot cover while hooking the groove with your fingernail, press the OFF button (YELLOW) with a fine-tipped object for approximately three seconds release your finger after it vibrates three times. Alternatively, press and hold (a) and upper part of volume key at the same time for approximately three seconds, and release your finger after it vibrates three times.
(Out of service area) appears	Is the product out of the service area or in an area where the signal is weak? Is the built-in antenna covered with hand?
	Is au Nano IC Card 04 inserted?

If you are unsure about anything regarding after-sales service, contact the following service contact.

From a land-line phone, Free cut 0077-7-113 (toll free)

From an au mobile phone, 113 without area code (toll free)

Keitai Guarantee Service Center (for loss, theft, damage)

0120-925-919 (toll free)

Business hours 9:00 - 21:00 (7 days a week) Online Repair Desk (24 hours a day over the Internet)

Reception only from PC or smartphone https://cs.kddi.com/support/n_login.html

• The App for the Internet acceptance, if "damage", "wet", "theft" and "loss" are eligible. In the case of spontaneous failure (not the cause damage, such as water wet, but does not power on, the screen does not function or other), it will

To apply for the Internet, you need the e-mail address

au after-sales service information Replacement cell phone delivery service

Keitai Guarantee Service Plus LTE members

Spontaneous failure 1st year	Free of charge
Spontaneous failure 2nd year or later	Customer charge
Partially damage, water soak, irreparable damage, theft or loss	1st: 5,000 yen 2nd: 8,000 yen

Non-Keitai Guarantee Service Plus LTE members

Spontaneous failure 1st year	
Spontaneous failure 2nd	
year or later	No recompense
Partially damage, water	140 recempende
soak, irreparable damage,	
theft or loss	

Reliai Guarantee Service Flus LTE members		
Spontaneous failure 1st year	Free of charge	
Spontaneous failure 2nd year or later	Free of charge (three-year warranty)	
Partially damage	Customer charge Upper limit: 5,000 yen	
Water soak, irreparable damage	Customer charge 10,000 yen	
Theft, loss	No recompense	

Non-Keitai Guarantee Servic	e Plus LTE members
Spontaneous failure 1st year	Free of charge
Spontaneous failure 2nd year or later	
Partially damage	Actual cost
Water soak, irreparable damage	
Theft, loss	No recompense (model change)

Replacement cell phone delivery service

cell phone (same model, same color) is delivered by calling to. Return your damaged cell phone within 14 days after the replacement cell phone is delivered.

service as a start day. If you do not use this service in the past year for the subscription to this service, it will be 1st and if you use, it will be the 2nd. * For details, refer to au homepage

Holding over and repair

 Damages and malfunctions intentionally caused by the disassembly, change of parts, painting, etc.) by the

· You cannot receive a refund for the replacement of the outer casing due to stains, scratches, paint removal, etc. on the

 You can check notifications on the lock screen. Or set to hide notifications on the lock screen.

■ Notification LED

Notification LED informs charging prompt, battery level while charging, missed calls, new mails, etc. by turning on or flashing Status

Status	Description	
Red	The battery is charging when the remaining battery level is 14% or lower.	
Orange	The battery is charging when the remaining battery level is 15% - 89%.	
Green	The battery is charging when the remaining battery level is 90% or higher.	
Flashing red	The remaining battery level is 14% or lower.	
Flashing white	Indicates missed call, new Gmail message, new SMS message.*1	
*1 Notification LED flashes while backlight is turned off.		
Alufarmatian		

When the remaining battery is not sufficient for turning the

product ON, pressing (b) makes LED flash red three times.

When you start charging with the product powered off, the notification LED turns in red. When the status of battery appears on the display, however, the notification LED lights in color that indicates the battery level

· For details, visit http://www.sonymobile.co.jp/support/ or

Update files can be downloaded from the Internet web site

• Note that when Wi-Fi® communication becomes unstable,

1 From the Home screen, [⊕]▶[Settings]▶[About

For repair, contact Keitai Guarantee Service Center.

During the Repairs will be done based on the terms of

described on the warranty card.

The product supports SIM unlock. By unlocking SIM lock, you

• The SIM unlock service is provided at the au homepage and

• Some services, functions, etc. may be unavailable when using

non-au SIM card. The Company is not liable for any

• For SIM unlock, operate from the Home screen, [......]▶

[Settings]▶[About phone]▶[Status]▶[SIM card status].

Approx. 5.2 inches

1,080 x 1,920 dots

atterv)

Approx. 16.77 million colors

Approx. 144 g (with internal

Approx. 72 mm x 146 mm x

Outside the We shall repair the product for a charge as

services of the free-of-charge repair warranty

requested by the customer if repair renders it

packet communication takes the place automatically, which

"取扱説明書(詳細版)(Full instruction manual)"(Japanese)

refer to the "Basic Manual" (Japanese) app or

■ Downloading and updating software

available on au homepage

may apply communication fees

phone]▶[Software update

When asking for repair

ısable.

into the product directly

2 []▶[Refresh]

warrantv

varrantv

SIM unlock

au shops

operations.

can use non-au SIM cards

Main specifications

period

32

After-sales service

■ Checking own phone number

1 From the Home screen, [⊕]▶[Settings] 2 [About phone]▶[Status]

The phone number of the product is shown under "My phone number".

・Alternatively, from the Home screen, [:::] ▶[ツール (Tool)]▶ [Contacts]▶ [Myself] to check your phone numbe

■ Setting the silent mode (vibrate) 1 Press the volume up key or down key

2 [] The icon for the volume adjusting bar changes to] and the silent mode (vibrate) is set.

Tap " to cancel the silent mode (vibrate)

Setting the silent mode (not vibrate)

the silent mode (not vibrate) is set.

1 Press the volume down key for over 1second The icon on the volume adjusting bar changes to and

❖Information

• When the "silent mode" is set, sounds for shutter, playback of video or music, alarm, etc. are not muted.

· When the "silent mode" is set, adjusting "Ring volume" of "Sound & notification" or raising the volume by pressing the volume up key cancels the silent mode

• Before handing in the product for repair, make a backup of the contents of memory since they may disappear during repair. Note that the Company shall not be liable for any damages and loss of income should the contents of memory be altered or lost.

• Recycled parts that meet the Company's quality standards are sometimes used for repair • Collected au cell phones by Replacement cell phone

delivery service which you used before are recycled to cell phones for replacement after repairs. Also replaced parts by au after-sales service are collected and recycled by KDDI. They are not returned to customers.

• The product which is processed, remodeled, analyzed (including by modifying or analyzing the software (including by rooting etc.), reverse engineering, decompiling), or repaired by an unauthorized repair office is not covered by the warranty and repair may be refused.

Performance parts for repair

The Company retains performance parts for repair of the Xperia™ XX main unit and its peripherals for four years after discontinuation of production. "Performance parts for repair" refers to parts required for maintaining the functions of the product.

■ Warranty card

At the store of purchase, thoroughly check and read the name of the retailer, date of purchase and other necessary details

Charging time

watching time

Continuous 1Seg

Continuous Full Seg

maximum connection

33

filled in on the warranty card, and be sure to keep it in a safe

Ising Common AC Adapter 05 sold separately): pprox. 140 min. pprox. 6 hours 40 min.

pprox. 9 hours 00 min.

viewina time pprox. 420 min Continuous tethering Wi-Fi® tethering

number **♦Information**

. The continuous call time, continuous stand-by time continuous Full Seg watching time, continuous 1Seg viewing time and continuous tethering time may drop to less than half depending on the battery charging status, usage environment such as temperature, reception condition at the location where the product is used, and the function settings

 $SONY_{\mathbb{R}}$







batteries and battery chargers at stores bearing the ② logo regardless of brand 歩きスマホ。



やめましょう、

■ Starting an app

1 From the Home screen, [iii] Slide or flick left or right to switch the Apps screen.

installed to the product are also displayed

Some apps are stored in a folder

Main apps

23

29

35

■ After-sales service

Customer Service Center (for service canceling procedure in case of loss or theft)

Business hours: 24 hours live support

From a land-line phone/From an au cell phone,

be accepted by phone for interview is required.

Holding over and repair

* Charge amounts are all tax excluded

Missed call

■ Main status icons

■ Notification panel

Symptom

backlight turns off

on the screen/pres

microSD memory

http://www.au.kddi.com/support

Updating Software

updating software.

he keys

n a short while

The screen

100 , 1 € [97%]

USB connecting

Wi-Fi[®]open network available

downloading)

appears on the screen for both networks

Appears when switched to another screen such as the Home screen

Signal level (Level 4, Out of service area)

4G (LTE/WiMAX 2+) data communication

status*1 (Available, data transferring or

Wi-Fi[®]connected, Wi-Fi[®]communicating

Battery level (100%, Charging)

lent mode (vibrate) is set

Airplane mode is activated

*1 Two types of network, "LTE"/"WiMAX 2+" can be used. "4G"

If any notification icons are displayed, slide down the status

bar to open the Notification panel. You can check details of

• To delete a notification, flick the notification left or right. • Some notifications may not be deleted depending on the content.

The display is dark | Is "Brightness level" set to dark?

What you should check

s set "Sleep" period too short'

s the proximity sensor blocked or

ize data between the product and

icroSD memory card, the screen

Is the microSD memory card unmounted

sponse may be delayed.

vered by sticker?

Screen response is When a large amount of data is saved

Cannot recognize a Is the microSD memory card inserted

For more details, visit au Customer Support site of au homepage

You can update the product to the most recent software for

You are charged for data communications when connecting to

the Internet from the product by using packet communication

optimal performance and to get the latest enhancements.

· You are recommended to back up your data before

properly?

slow when you tap in the product or transferring large

The company determines which network is less busy

depending on the condition of the line to connect.

notification icons or start corresponding apps.

Silent mode (not vibrate) is set

· When you have trouble with your au cell phone, replacement

Available up to twice in a year from the day you use this

customer as well as those due to modification (e.g. customer are not covered by this service.

outer casing.

.9 mm Approx. 1,280 min. Continuous In Japan all time Overseas Approx. 720 min (GSM)

· For details, refer to the au homepage

Continuous In Japan stand-by Overseas

Approx. 460 hours Approx. 500 hours (GSM)

FRILUMINOS® Display for mobile



37 38 39