

Thank you for purchasing a Sony Ericsson W890i. A slim and stylish phone with everything you need to enjoy your music wherever you go.

For additional phone content, go to www.sonyericsson.com/fun. Register now to get a suite of tools, free online storage, special offers, news and competitions at www.sonyericsson.com/myphone.

For product support, go to www.sonyericsson.com/support.

Accessories – More for your phone

Stereo Bluetooth™ Headset HBH-DS200

Enjoy wireless music without missing a call.



Stereo Portable Handsfree HPM-83

Street-style neck band headset with superior audio performance.



Portable Bluetooth™ Speaker MBS-100

A wireless sphere of music.



These accessories can be purchased separately but may not be available in every market. To view the full range go to www.sonyericsson.com/accessories.

Contents

| | |
|---------------------------------------|-----------|
| Getting started..... | 5 |
| Assembly..... | 5 |
| Turning on the phone..... | 6 |
| Help in your phone..... | 7 |
| Charging the battery..... | 7 |
| Phone overview..... | 8 |
| Menu overview..... | 10 |
| Navigation..... | 12 |
| File manager..... | 13 |
| Phone language..... | 15 |
| Entering text..... | 15 |
| Calling..... | 16 |
| Making and receiving calls..... | 16 |
| Contacts..... | 18 |
| Call list..... | 22 |
| Speed dial..... | 22 |
| Voicemail..... | 23 |
| Voice control..... | 23 |
| Diverting calls..... | 25 |
| More than one call..... | 25 |
| Conference calls..... | 26 |
| My numbers..... | 26 |
| Accept calls..... | 26 |
| Restricted dialling..... | 27 |
| Fixed dialling..... | 27 |
| Call time and cost..... | 28 |
| Messaging..... | 28 |
| Receiving and saving messages..... | 28 |
| Text messages..... | 29 |
| Picture messages..... | 30 |
| Message options..... | 31 |
| Templates..... | 31 |
| Voice messages..... | 31 |
| Email..... | 32 |
| My friends | 33 |
| Area and cell information..... | 35 |
| Imaging..... | 35 |
| Camera and video recorder..... | 35 |
| Viewfinder and camera keys..... | 35 |
| Using the camera..... | 36 |
| Camera icons and settings..... | 36 |
| Camera shortcuts..... | 36 |
| Transferring pictures..... | 37 |
| Camera printing..... | 38 |
| Pictures..... | 38 |
| PhotoDJ™ and VideoDJ™..... | 39 |
| Themes..... | 39 |
| Entertainment..... | 40 |
| Stereo portable handsfree..... | 40 |
| Walkman® player..... | 40 |
| Video player..... | 40 |

| | |
|---|-----------|
| Music and video controls..... | 40 |
| TrackID™..... | 43 |
| Radio..... | 44 |
| PlayNow™..... | 44 |
| Ringtones and melodies..... | 45 |
| MusicDJ™..... | 45 |
| Sound recorder..... | 46 |
| Games..... | 46 |
| Applications..... | 46 |
| Connectivity..... | 47 |
| Settings..... | 47 |
| Phone name..... | 47 |
| Using the Internet..... | 48 |
| Web feeds..... | 49 |
| Bluetooth™ wireless technology..... | 50 |
| Using the USB cable..... | 52 |
| Synchronizing..... | 54 |
| Update service..... | 56 |
| More features..... | 57 |
| Flight mode..... | 57 |
| Location services..... | 57 |
| Alarms..... | 58 |
| Calendar..... | 58 |
| Notes..... | 60 |
| Tasks..... | 60 |
| Profiles..... | 61 |
| Time and date..... | 61 |
| Locks..... | 61 |
| Troubleshooting..... | 63 |
| Common questions..... | 63 |
| Error messages..... | 65 |
| Important information..... | 67 |
| Sony Ericsson Consumer Web site..... | 67 |
| Service and support..... | 67 |
| Guidelines for Safe and Efficient Use..... | 69 |
| End User Licence Agreement..... | 73 |
| Limited Warranty..... | 74 |
| FCC Statement..... | 76 |
| Declaration of Conformity for W890i..... | 76 |
| Index..... | 77 |

Sony Ericsson W890i

UMTS 2100 GSM EDGE 850/900/1800/1900
This User guide is published by Sony Ericsson Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide.

All rights reserved.

©Sony Ericsson Mobile Communications AB, 2007
Publication number: 1203-2747.1

Please note:

Some of the services in this User guide are not supported by all networks. *This also applies to the GSM International Emergency Number 112.*

Please contact your network operator or service provider if you are in doubt whether you can use a particular service or not.

Please read the *Guidelines for safe and efficient use* and the *Limited warranty* chapters before you use your mobile phone.

Your mobile phone has the capability to download, store and forward additional content, e.g. ringtones. The use of such content may be restricted or prohibited by rights of third parties, including but not limited to restriction under applicable copyright laws. You, and not Sony Ericsson, are entirely responsible for additional content that you download to or forward from your mobile phone. Prior to your use of any additional content, please verify that your intended use is properly licensed or is otherwise authorized. Sony Ericsson does not guarantee the accuracy, integrity or quality of any additional content or any other third party content. Under no circumstances will Sony Ericsson be liable

in any way for your improper use of additional content or other third party content.

Smart-Fit Rendering is a trademark or a registered trademark of ACCESS Co., Ltd.

Bluetooth is a trademark or a registered trademark of Bluetooth SIG Inc. and any use of such mark by Sony Ericsson is under license.

The Liquid Identity logo, SensMe, PlayNow, MusicDJ, PhotoDJ, TrackID and VideoDJ are trademarks or registered trademarks of Sony Ericsson Mobile Communications AB. TrackID™ is powered by Gracenote Mobile MusicID™. Gracenote and Gracenote Mobile MusicID are trademarks or registered trademarks of Gracenote, Inc.

WALKMAN is a trademark or a registered trademark of Sony Corporation.

Sony, Memory Stick Micro™ and M2™ are trademarks or registered trademarks of Sony Corporation.

Google™ and Google Maps™ are trademarks or registered trademarks of Google, Inc.

SyncML is a trademark or registered trademark of Open Mobile Alliance LTD.

Ericsson is a trademark or registered trademark of Telefonaktiebolaget LM Ericsson.

Adobe Photoshop Album Starter Edition is a trademark or registered trademark of Adobe Systems Incorporated in the United States and/or other countries.

Microsoft, ActiveSync, Windows, Outlook, and Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

T9™ Text Input is a trademark or a registered trademark of Tegic Communications. T9™ Text Input is licensed under one or more of the following: U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, and 6,011,554; Canadian Pat. No. 1,331,057, United Kingdom Pat. No. 2238414B;

Hong Kong Standard Pat. No. HK0940329; Republic of Singapore Pat. No. 51383; Euro.Pat. No. 0 842 463(96927260.8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; and additional patents are pending worldwide. Java and all Java based trademarks and logos are trademarks registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. End-user license agreement for Sun™ Java™ J2ME™.

Restrictions: Software is confidential copyrighted information of Sun and title to all copies is retained by Sun and/or its licensors. Customer shall not modify, decompile, disassemble, decrypt, extract, or otherwise reverse engineer Software. Software may not be leased, assigned, or sublicensed, in whole or in part.

Export Regulations: Software, including technical data, is subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Customer agrees to comply strictly with all such regulations and acknowledges that it has the responsibility to obtain licenses to export, re-export, or import Software. Software may not be downloaded, or otherwise exported or re-exported (i) into, or to a national or resident of, Cuba, Iraq, Iran, North Korea, Libya, Sudan, Syria (as such listing may be revised from time to time) or any country to which the U.S. has embargoed goods; or (ii) to anyone on the U.S. Treasury Department's list of Specially Designated Nations or the U.S. Commerce Department's Table of Denial Orders.

Restricted Rights: Use, duplication or disclosure by the United States government is subject to the restrictions as set forth in the Rights in Technical Data and Computer Software Clauses in DFARS 252.227-7013(c) (1) (ii) and FAR 52.227-19(c) (2) as applicable.

Other product and company names mentioned herein may be the trademarks of their respective owners.

Any rights not expressly granted herein are reserved.

All illustrations are for illustration only and may not accurately depict the actual phone.

Instruction symbols

These symbols may appear in the User guide.



Note



Tip



Warning



A service or function is network- or subscription-dependent. Contact your network operator for details.

- > Use a selection or navigation key to scroll and select. See *Navigation* on page 12.

Getting started

Assembly

Before you start using your phone, you need to insert a SIM card and the battery.

To insert the SIM card



- 1 Unlock the battery cover locks on both sides.
- 2 Remove the battery cover.
- 3 Slide the SIM card into its holder with the gold-coloured contacts facing down.

To insert the battery



- 1 Insert the battery with the label side up and the connectors facing each other.
- 2 Slide the battery cover into place and lock it.

Turning on the phone

To turn on the phone



- 1 Press and hold down ①.
- 2 Enter your SIM card PIN, if requested and select **OK**.
- 3 Select a language.
- 4 Select **Yes** to use the setup wizard while settings are downloaded.

! If you want to correct a mistake when you enter your PIN, press **C.**

SIM card

The SIM (Subscriber Identity Module) card, which you get from your network operator, contains information about your subscription. Always turn off your

phone and detach the charger before you insert or remove the SIM card.

! You can save contacts on the SIM card before you remove it from your phone. See *To copy names and numbers to the SIM card* on page 20.

PIN

You may need a PIN (Personal Identification Number) to activate the services in your phone. Your PIN is supplied by your network operator. Each PIN digit appears as *, unless it starts with emergency number digits, for example, 112 or 911. You can see and call an emergency number without entering a PIN.

! If you enter the wrong PIN three times in a row, the SIM card is blocked. See *SIM card lock* on page 61.

Startup screen

The startup screen appears when you turn your phone on. See *Using pictures* on page 38.

Standby

After you have turned your phone on and entered your PIN, the name of the network operator appears. This view is called standby.

Help in your phone

Help and information are available in your phone. See *Navigation* on page 12.

To use the setup wizard

- 1 From standby select Menu > Settings > the General tab > Setup wizard.
- 2 Select an option.

To view information about functions

- Scroll to a function and select Info, if available. In some cases, Info appears under Options.

To view the phone demonstration

- From standby select Menu > Entertainment > Demo tour.

To view status information

- From standby press the volume key up.

Charging the battery

The phone battery is partly charged when you buy it.

To charge the battery




- 1 Connect the charger to the phone. It takes approximately 2.5 hours to fully charge the battery. Press a key to view the screen.
- 2 Remove the charger by tilting the plug upwards.

 You can use your phone while it is charging. You can charge the battery at any time and for more or less than 2.5 hours. You can interrupt the charging without damaging the battery.

Phone overview

- 1 On/off key
- 2 Video call camera
- 3 Walkman® key
- 4 Selection keys
- 5 Call key
- 6 Connector for charger, handsfree and USB cable
- 7 Activity menu key
- 8 Memory card slot (under the cover)
- 9 Keylock key
- 10 Ear speaker
- 11 Screen light sensor
- 12 Screen
- 13 End key
- 14 C key (Clear)
- 15 Navigation key, Walkman® player control
- 16 Silent key



8 Getting started



- 17 Main camera
- 18 Battery cover locks
- 19 Volume, digital zoom keys
- 20 Camera key
- 21 Strap hole

Menu overview

| | | |
|--|--|---|
|  PlayNow™ |  Contacts Myself New contact |  Media |
|  Camera |  Organizer File manager ** Alarms Applications Video call Calendar Tasks Notes Synchronization Timer Stopwatch Calculator Code memo |  WALKMAN |
|  Radio |  Settings** General Profiles Time & date Language Update service Voice control New events Shortcuts Flight mode Security Setup wizard Accessibility* Phone status Master reset  Sounds & alerts Ring volume Ringtone Silent mode Increasing ring Vibrating alert Message alert Key sound  Display Wallpaper Themes Startup screen | |
|  Calls**  All  Answered  Dialed  Missed |  Entertainment Online services* Games TrackID™ Location services VideoDJ™ PhotoDJ™ MusicDJ™ Remote control Record sound Demo tour | |
|  Internet | | |
|  Messaging Write new Inbox Email Web feeds Drafts Outbox Sent messages Saved messages My friends* Call voicemail Templates Manage messages Settings | | |



Screen saver

Clock size

Brightness

Edit line names*



Calls

Speed dial

Smart search

Divert calls

Switch to line 2*

Manage calls

Time & cost*

Show/hide my no.

Handsfree



Connectivity

Bluetooth

USB

Phone name

Network sharing

Synchronization

Device management

Mobile networks

Internet settings

Streaming settings

Message settings*

Accessories

* Some menus are operator-,
network- and subscription-
dependent.

** You can use the navigation
key to scroll between tabs in
submenus. For more
information, see *Navigation*
on page 12.






Navigation

The main menus are shown as icons. Some submenus include tabs.

To navigate the phone menus



- 1 From standby select **Menu**.
- 2 Use the navigation key to move through the menus.

To select actions on the screen

- Select an action shown at the bottom of the screen by pressing the left or right selection key, or the centre navigation key.

To view options for an item

- Select **Options** to, for example, edit.

To scroll between the tabs

- Scroll to a tab by pressing the navigation key left or right.

To return to standby

- Press

To end a function

- Press .

To navigate your media

- 1 From standby select Menu > Media.
- 2 Press the navigation key right to select an item.
- 3 To go back, press the navigation key left

To delete items

- Press **c** to delete items such as numbers, letters, pictures and sounds.

Shortcuts

You can use keypad shortcuts to go directly to a menu. Menu numbering starts from the top left icon and moves across and then down row by row.

To go directly to a main menu

- From standby select Menu and press **1** - **9**, *** #**, **0 +** or **# -**.

To use navigation key shortcuts

- From standby press , ,  or  to go directly to a function.

To edit a navigation key shortcut

- 1 From standby select Menu > Settings > the General tab > Shortcuts.
- 2 Scroll to an option and select Edit.
- 3 Scroll to a menu option and select Shortc..

Activity menu

The activity menu gives you quick access to certain functions.

To open the activity menu

- Press .

Activity menu tabs

- **New events** – missed calls and new messages.
- **Running apps** – applications that are running in the background.
- **My shortcuts** – add your favourite functions to access them quickly.
- **Internet** – quick access to the Internet.

File manager

You can use the file manager to handle files saved in the phone memory or on a memory card.

- **!** You may have to purchase a memory card separately.

Memory card


Your phone supports Memory Stick Micro™ (M2™) memory card adding more storage space to your phone. It can also be used as a portable memory card with other compatible devices.

To insert a memory card



- Open the cover and insert the memory card with the gold-coloured contacts facing down.

To remove a memory card



- Open the cover and press the edge of the memory card to release and remove it.

To view memory card options

- 1 From standby select **Menu > Organizer > File manager** > the **On memory card** tab.
- 2 Select **Options**.

Handling files

You can move and copy files between your phone, a computer and a memory card. Files are saved on the memory card first and then in the phone memory. Unrecognized files are saved in the **Other** folder.

You can create subfolders to move or copy files to. You can select more than one or all the files in a folder at the same time for all folders except **Games** and **Applications**.

If the memory is full, delete some content to create space.

File manager tabs

The file manager is divided into three tabs, and icons indicate where the files are saved.

- **All files** – all content in the phone memory and on a memory card
- **In phone** – all content in the phone memory
- **On memory card** – all content on a memory card

To view information about files

- 1 From standby select **Menu > Organizer > File manager**.
- 2 Find a file and select **Options > Information**.



To move a file in the file manager

- 1 From standby select Menu > Organizer > File manager.
- 2 Find a file and select Options > Manage file > Move.
- 3 Select an option.

To select more than one file in a folder

- 1 From standby select Menu > Organizer > File manager.
- 2 Scroll to a folder and select Open.
- 3 Select Options > Mark > Mark several.
- 4 For each file you want to mark, scroll to the file and select Mark.

To delete a file from the file manager

- 1 From standby select Menu > Organizer > File manager.
- 2 Find the file and press **C**.

Phone language

You can select a language to use in your phone.

To change the phone language

- 1 From standby select Menu > Settings > the General tab > Language > Phone language.
- 2 Select an option.



Entering text

You can use multitap text input or T9™ Text Input **T9** to enter text. The T9 Text Input method uses a built-in dictionary.

To change text input method

- When you enter text, press and hold down **(*****abc****)**.

To shift between capitals and lower-case letters

- When you enter text, press **(#****abc****)**.

To enter numbers

- When you enter text, press and hold down **(0 +)** – **(9)**.

To enter full stops and commas

- When you enter text, press **(1)**.

To enter text using T9™ Text Input

- 1 From standby select, for example, Menu > Messaging > Write new > Text message.
- 2 If **T9** is not displayed, press and hold down **(*****abc****)** to change to T9 Text Input.
- 3 Press each key only once, even if the letter you want is not the first letter on the key. For example, to write the word "Jane", press **(5)**, **(2)**, **(6)**, **(3)**. Write the whole word before looking at the suggestions.
- 4 Use **(@)** or **(#)** to view suggestions.





- 5 Press  to accept a suggestion.

To enter text using multitap

- 1 From standby select, for example, Menu > Messaging > Write new > Text message.
- 2 If  is displayed, press and hold down  to change to multitap text input.
- 3 Press  –  repeatedly until the desired letter appears.
- 4 When a word is written, press  to add a space.

To add words to the built-in dictionary

- 1 When you enter text using T9 Text Input, select Options > Spell word.
- 2 Write the word using multitap input and select Insert.



Calling

Making and receiving calls

You need to turn on your phone and be within range of a network.

To make a call

- 1 From standby enter a phone number (with international country code and area code, if applicable).
- 2 Press . See *Video call* on page 18.

 You can call numbers from your contacts and call list. See *Contacts* on page 18 and *Call list* on page 22. You can also use your voice to make calls. See *Voice control* on page 23.

To end a call

- Press .

To make international calls

- 1 From standby press and hold down  until a “+” sign appears.
- 2 Enter the country code, area code (without the first zero) and phone number.
- 3 Press .



To re-dial a number

- When **Retry?** appears select **Yes**.

⚠ *Do not hold your phone to your ear when waiting. When the call connects, your phone gives a loud signal.*

To answer a call

- Press .

To reject a call

- Press .

To change the ear speaker volume during a call

- Press the volume key up or down.

To mute the microphone during a call

- 1 Press and hold down .
- 2 Press and hold down  again to resume.

To turn the loudspeaker on during a call

- Select **SpkrOn**.

⚠ *Do not hold your phone to your ear when using the loudspeaker. This could damage your hearing.*

To view missed calls from standby

- Press .



Networks

Your phone switches automatically between GSM and 3G (UMTS) networks depending on availability. Some network operators allow you to switch networks manually.

To switch networks manually

- 1 From standby select **Menu > Settings > the Connectivity tab > Mobile networks > GSM/3G networks**.
- 2 Select an option.

Emergency calls

Your phone supports international emergency numbers, for example, 112 and 911. These numbers can normally be used to make emergency calls in any country, with or without the SIM card inserted, if a 3G (UMTS) or GSM network is within range.

! *In some countries, other emergency numbers may also be promoted. Your network operator may therefore have saved additional local emergency numbers on the SIM card.*

To make an emergency call

- From standby enter 112 (the international emergency number) and press .





To view your local emergency numbers

- 1 From standby select **Menu > Contacts**.
- 2 Scroll to **New contact** and select **Options > Special numbers > Emergency nos..**

Video call

See a person on the screen during calls. Both parties need a subscription that supports the 3G (UMTS) service, and you need to be within range of a 3G (UMTS) network. 3G (UMTS) service is available when **3G** appears.

To make a video call

- 1 From standby enter a phone number (with international country code and area code, if applicable).
- 2 Select **Options > Make video call**.

To use the zoom with an outgoing video call

- Press **•** or **•**.

To view video call options

- During the call, select **Options**.

Contacts

You can save names, phone numbers and personal information in **Contacts**.

Information can be saved in the phone memory or on the SIM card.

Default contacts

You can choose which contact information is shown as default. If **Phone contacts** is selected as default, your contacts show all the information saved in **Contacts**. If you select **SIM contacts** as default, your contacts show names and numbers saved on the SIM card.

To select default contacts

- 1 From standby select **Menu > Contacts**.
- 2 Scroll to **New contact** and select **Options > Advanced > Default contacts**.
- 3 Select an option.

Phone contacts

Phone contacts can contain names, phone numbers and personal information. They are saved in the phone memory.

To add a phone contact

- 1 From standby select **Menu > Contacts**.
- 2 Scroll to **New contact** and select **Add**.
- 3 Enter the name and select **OK**.
- 4 Enter the number and select **OK**.