

# Sony Ericsson

## Important information

## Sony Ericsson Consumer Web site

At [www.sonyericsson.com/support](http://www.sonyericsson.com/support) there is a support section where help and tips are only a few clicks away. Here you will find the latest computer software updates and tips on how to use your product more efficiently.

## Service and support

You have access to a portfolio of exclusive service advantages such as:

- Global and local Web sites providing support.
- A global network of Contact Centers.
- An extensive network of Sony Ericsson service partners.
- A warranty period. Learn more about the warranty conditions in the *Limited warranty* section.

At [www.sonyericsson.com/support](http://www.sonyericsson.com/support), you can find the latest support tools and information. For operator-specific services and features, please contact your network operator.

You can also contact our Contact Centers. If your country/region is not represented in the list below, please contact your local dealer. (Calls are charged according to national rates, including local taxes, unless the phone number is a toll-free number.)

If your product needs service, please contact the dealer from whom it was purchased, or one of our service partners. For warranty claims, save proof of purchase.

## Guidelines for Safe and Efficient Use

Please follow these guidelines. Failure to do so might entail a potential health risk or product malfunction. If in doubt as to its proper function, have the product checked by a certified service partner before charging or using it.



## Recommendations for care and safe use of our products

- Handle with care and keep in a clean and dust-free place.

- **Warning!** May explode if disposed of in fire.
- Do not expose to liquid or moisture or excess humidity.
- For optimum performance, the product should not be operated in temperatures below -10°C(+14°F) or above +45°C(+113°F). Do not expose the battery to temperatures above +60°C(+140°F).
- Do not expose to flames or lit tobacco products.
- Do not drop, throw or try to bend the product.
- Do not paint or attempt to disassemble or modify the product. Only Sony Ericsson authorised personnel should perform service.
- Consult with authorised medical staff and the instructions of the medical device manufacturer before using the product near pacemakers or other medical devices or equipment.
- Discontinue use of electronic devices, or disable the radio transmitting functionality of the device, where required or requested to do so.
- Do not use where a potentially explosive atmosphere exists.
- Do not place the product, or install wireless equipment, in the area above an air bag in a car.
- **Caution:** Cracked or broken displays may create sharp edges or splinters that could be harmful upon contact.
- Do not use the Bluetooth Headset in positions where it is uncomfortable or will be subject to pressure.



## Children

**Warning!** Keep out of the reach of children. Do not allow children to play with mobile phones or accessories. They could hurt themselves or others. Products may contain small parts that could become detached and create a choking hazard.



## Power supply (Charger)

Connect the charger to power sources as marked on the product. Do not use outdoors or in damp areas. Do not alter or subject the cord to damage or stress. Unplug the unit before

cleaning it. Never alter the plug. If it does not fit into the outlet, have a proper outlet installed by an electrician. When a power supply is connected there is a small drain of power. To avoid this small energy waste, disconnect the power supply when the product is fully charged. Use of charging devices that are not Sony Ericsson branded may pose increased safety risks.

## **Battery**

New or idle batteries can have short-term reduced capacity. Fully charge the battery before initial use. Use for the intended purpose only. Charge the battery in temperatures between +5°C(+41°F) and +45°C(+113°F). Do not put the battery into your mouth. Do not let the battery contacts touch another metal object. Turn off the product before removing the battery. Performance depends on temperatures, signal strength, usage patterns, features selected and voice or data transmissions. Only Sony Ericsson service partners should remove or replace built-in batteries. Use of batteries that are not Sony Ericsson branded may pose increased safety risks. Replace the battery only with another Sony Ericsson battery that has been qualified with the product per the standard IEEE-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.

## **Personal medical devices**

Mobile phones may affect implanted medical equipment. Reduce risk of interference by keeping a minimum distance of 15 cm(6 inches) between the phone and the device. Use the phone at your right ear. Do not carry the phone in your breast pocket. Turn off the phone if you suspect interference. For all medical devices, consult a physician and the manufacturer.

## **Driving**

Some vehicle manufacturers forbid the use of phones in their vehicles unless a handsfree kit with an external antenna supports the installation. Check with the vehicle manufacturer's representative to be sure that the mobile phone or Bluetooth

handsfree will not affect the electronic systems in the vehicle. Full attention should be given to driving at all times and local laws and regulations restricting the use of wireless devices while driving must be observed.

### **GPS/Location based functions**

Some products provide GPS/Location based functions. Location determining functionality is provided "As is" and "With all faults". Sony Ericsson does not make any representation or warranty as to the accuracy of such location information.

Use of location-based information by the device may not be uninterrupted or error free and may additionally be dependent on network service availability. Please note that functionality may be reduced or prevented in certain environments such as building interiors or areas adjacent to buildings.

Caution: Do not use GPS functionality in a manner which causes distraction from driving.

### **Emergency calls**

Calls cannot be guaranteed under all conditions. Never rely solely upon mobile phones for essential communication. Calls may not be possible in all areas, on all networks, or when certain network services and/or phone features are used.

### **Antenna**

Use of antenna devices not marketed by Sony Ericsson could damage the phone, reduce performance, and produce SAR levels above the established limits. Do not cover the antenna with your hand as this affects call quality, power levels and can shorten talk and standby times.

### **Radio Frequency (RF) exposure and Specific Absorption Rate (SAR)**

When the phone or Bluetooth handsfree is turned on, it emits low levels of radio frequency energy. International safety guidelines have been developed through periodic and thorough evaluation of scientific studies. These guidelines establish

permitted levels of radio wave exposure. The guidelines include a safety margin designed to assure the safety of all persons and to account for any variations in measurements.

Specific Absorption Rate (SAR) is used to measure radio frequency energy absorbed by the body when using a mobile phone. The SAR value is determined at the highest certified power level in laboratory conditions, but because the phone is designed to use the minimum power necessary to access the chosen network, the actual SAR level can be well below this value. There is no proof of difference in safety based on difference in SAR value.

Products with radio transmitters sold in the US must be certified by the Federal Communications Commission (FCC). When required, tests are performed when the phone is placed at the ear and when worn on the body. For body-worn operation, the phone has been tested when positioned a minimum of 15 mm from the body without any metal parts in the vicinity of the phone or when properly used with an appropriate Sony Ericsson accessory and worn on the body.

For more information about SAR and radio frequency exposure, go to: [www.sonyericsson.com/health](http://www.sonyericsson.com/health).

### **Flight mode**

Bluetooth and WLAN functionality, if available in the device, can be enabled in Flight mode but may be prohibited onboard aircraft or in other areas where radio transmissions are prohibited. In such environments, please seek proper authorisation before enabling Bluetooth or WLAN functionality even in Flight mode.

### **Malware**

Malware (short for malicious software) is software that can harm the mobile phone or other computers. Malware or harmful applications can include viruses, worms, spyware, and other unwanted programs. While the device does employ security measures to resist such efforts, Sony Ericsson does not warrant or represent that the device will be impervious to the introduction of malware. You can however reduce the risk of malware attacks

by using care when downloading content or accepting applications, refraining from opening or responding to messages from unknown sources, using trustworthy services to access the Internet, and only downloading content to the mobile phone from known, reliable sources.

### **Accessories**

Use only Sony Ericsson branded original accessories and certified service partners. Sony Ericsson does not test third-party accessories. Accessories may influence RF exposure, radio performance, loudness, electric safety and other areas. Third-party accessories and parts may pose a risk to your health or safety or decrease performance.

### **Accessible Solutions/Special Needs**

In the US, compatible Sony Ericsson phones may offer compatibility with TTY terminals (with use of necessary accessory). For more information call the Sony Ericsson Special Needs Center on 877 878 1996 (TTY) or 877 207 2056 (voice), or go to [www.sonyericsson-snc.com](http://www.sonyericsson-snc.com).

### **Disposal of old electrical and electronic equipment**

Electronic equipment and batteries should not be included as household waste but should be left at an appropriate collection point for recycling. This helps prevent potential negative consequences for the environment and human health. Check local regulations by contacting your local city office, your household waste disposal service, the shop where you purchased the product or calling a Sony Ericsson Contact Center. Do not attempt to remove internal batteries. Internal batteries shall be removed only by a waste treatment facility or trained service professional.



### Disposing of the battery

Check local regulations or call a Sony Ericsson Contact Center for information. Never use municipal waste.



### Memory card

If the product comes complete with a removable memory card, it is generally compatible with the handset purchased but may not be compatible with other devices or the capabilities of their memory cards. Check other devices for compatibility before purchase or use. If the product is equipped with a memory card reader, check memory card compatibility before purchase or use.

Memory cards are generally formatted prior to shipping. To reformat the memory card, use a compatible device. Do not use the standard operating system format when formatting the memory card on a PC. For details, refer to the operating instructions of the device or contact customer support.

### Warning!

If the device requires an adapter for insertion into the handset or another device, do not insert the card directly without the required adapter.

### Precautions on memory card use

- Do not expose the memory card to moisture.
- Do not touch terminal connections with your hand or any metal object.
- Do not strike, bend, or drop the memory card.
- Do not attempt to disassemble or modify the memory card.
- Do not use or store the memory card in humid or corrosive locations or in excessive heat such as a closed car in summer, in direct sunlight or near a heater, etc.
- Do not press or bend the end of the memory card adapter with excessive force.
- Do not let dirt, dust, or foreign objects get into the insert port of any memory card adapter.
- Check you have inserted the memory card correctly.

- Insert the memory card as far as it will go into any memory card adapter needed. The memory card may not operate properly unless fully inserted.
- We recommend that you make a backup copy of important data. We are not responsible for any loss or damage to content you store on the memory card.
- Recorded data may be damaged or lost when you remove the memory card or memory card adapter, turn off the power while formatting, reading or writing data, or use the memory card in locations subject to static electricity or high electrical field emissions.

### **Protection of personal information**

Erase personal data before disposing of the product. To delete data, perform a master reset. Deleting data from the phone memory does not ensure that it cannot be recovered.

Sony Ericsson does not warrant against recovery of information and does not assume responsibility for disclosure of any information even after a master reset.

### **Loudness warning!**

Avoid volume levels that may be harmful to your hearing.

## **End User Licence Agreement**

Software delivered with this device and its media is owned by Sony Ericsson Mobile Communications AB, and/or its affiliated companies and its suppliers and licensors.

Sony Ericsson grants you a non-exclusive limited licence to use the Software solely in conjunction with the Device on which it is installed or delivered. Ownership of the Software is not sold, transferred or otherwise conveyed.

Do not use any means to discover the source code or any component of the Software, reproduce and distribute the Software, or modify the Software. You are entitled to transfer rights and obligations to the Software to a third party, solely together with the Device with which you received the Software,

provided the third party agrees in writing to be bound by the terms of this Licence.

This licence exists throughout the useful life of this Device. It can be terminated by transferring your rights to the Device to a third party in writing.

Failure to comply with any of these terms and conditions will terminate the licence immediately.

Sony Ericsson and its third party suppliers and licensors retain all rights, title and interest in and to the Software. To the extent that the Software contains material or code of a third party, such third parties shall be beneficiaries of these terms.

This licence is governed by the laws of Sweden. When applicable, the foregoing applies to statutory consumer rights.

In the event Software accompanying or provided in conjunction with your device is provided with additional terms and conditions, such provisions shall also govern your possession and usage of the Software.

## Export regulations

Export regulations: This product, including any software or technical data contained in or accompanying the product, may be subject to import and export regulations of the European Union, the United States and other countries. The user and any possessor of the product agrees to comply strictly with all such regulations and acknowledges that it is their responsibility to obtain any required licenses to export, re-export, or import this product. Without limiting the foregoing, and as an example, the user and any possessor of the product: (1) must not knowingly export or re-export Products to destinations identified pursuant to Articles in Chapter II of European Council Regulation (EC) 1334/2000; (2), must comply with U.S. government Export Administration Regulations ("EAR", 15 C.F.R. §§ 730-774, <http://www.bis.doc.gov/> ) administered by Department of Commerce, Bureau of Industry and Security; and (3) must comply with economic sanctions regulations (30 C.F.R. §§ 500 et. seq.,, <http://www.treas.gov/offices/enforcement/ofac/>) administered by

the U.S. Department of Treasury, Office of Foreign Assets Control. The user and any possessor of the product may not transport or deliver the product, its accessories or separate software to any country, region, entity or person prohibited by these regulations.

## Limited Warranty

Sony Ericsson Mobile Communications AB, SE-221 88 Lund, Sweden, (Sony Ericsson) or its local affiliated company, provides this Limited Warranty for your mobile phone, original accessory delivered with your mobile phone, and/or your mobile computing product (hereinafter referred to as "Product").

Should your Product need warranty service, please return it to the dealer from whom it was purchased, or contact your local Sony Ericsson Contact Center (national rates may apply) or visit [www.sonyericsson.com](http://www.sonyericsson.com) to get further information.

## Our warranty

Subject to the conditions of this Limited Warranty, Sony Ericsson warrants this Product to be free from defects in design, material and workmanship at the time of its original purchase by a consumer. This Limited Warranty will last for a period of two (2) years as from the original date of purchase of the Product for your mobile phone, and for a period of one (1) year following the original purchase date of the Product for all original accessories (such as the battery, charger or handsfree kit) which may be delivered with your mobile phone.

## What we will do

If, during the warranty period, this Product fails to operate under normal use and service, due to defects in design, materials or workmanship, Sony Ericsson authorised distributors or service partners, in the country/region\* where you purchased the Product, will, at their option, either repair or replace the Product in accordance with the terms and conditions stipulated herein.

Sony Ericsson and its service partners reserve the right to charge a handling fee if a returned Product is found not to be under warranty according to the conditions below.

Please note that some of your personal settings, downloads and other information may be lost when your Sony Ericsson Product is repaired or replaced. At present, Sony Ericsson may be prevented by applicable law, other regulation or technical restrictions from making a backup copy of certain downloads. Sony Ericsson does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the information stored on your Sony Ericsson Product such as downloads, calendar and contacts before handing in your Sony Ericsson Product for repair or replacement.

### **Conditions**

1. This Limited Warranty is valid only if the original proof of purchase for this Product issued by a Sony Ericsson authorised dealer specifying the date of purchase and serial number\*\*, is presented with the Product to be repaired or replaced. Sony Ericsson reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.
2. If Sony Ericsson repairs or replaces the Product, the repair for the defect concerned, or the replaced Product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sony Ericsson.
3. This warranty does not cover any failure of the Product due to normal wear and tear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with the Sony Ericsson instructions for use and maintenance of the Product. Nor does this warranty cover any failure of the Product due to accident, software or hardware

modification or adjustment, acts of God or damage resulting from liquid.

A rechargeable battery can be charged and discharged more than a hundred times. However, it will eventually wear out – this is not a defect and corresponds to normal wear and tear. When the talk-time or standby time is noticeably shorter, it is time to replace the battery. Sony Ericsson recommends that you use only batteries and chargers approved by Sony Ericsson.

Minor variations in display brightness and colour may occur between phones. There may be tiny bright or dark dots on the display. These are called defective pixels and occur when individual dots have malfunctioned and can not be adjusted. Two defective pixels are deemed acceptable.

Minor variations in camera image appearance may occur between phones. This is nothing uncommon and is not regarded as a defective camera module.

4. Since the cellular system on which the Product is to operate is provided by a carrier independent from Sony Ericsson, Sony Ericsson will not be responsible for the operation, availability, coverage, services or range of that system.
5. This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a non-Sony Ericsson authorised person.
6. The warranty does not cover Product failures which have been caused by use of accessories or other peripheral devices which are not Sony Ericsson branded original accessories intended for use with the Product.

Sony Ericsson disclaims any and all warranties, whether express or implied, for failures caused to the Product or peripheral devices as a result of viruses, trojan horses, spyware, or other malicious software. Sony Ericsson strongly recommends that you install appropriate virus protection software on your Product and any peripheral devices connected to it, as available, and update it regularly, to better protect your device. It is understood, however, that such software will never fully protect your Product or its peripheral

devices and Sony Ericsson disclaims all warranties, whether express or implied, in case of failure by such antivirus software to fulfil its intended purpose.

7. Tampering with any of the seals on the Product will void the warranty.
8. THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONY ERICSSON OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

The warranty provided does not affect the consumer's statutory rights under applicable legislation in force, nor the consumer's rights against the dealer arising from their sales / purchase contract.

#### **\*Geographical scope of the warranty**

If you have purchased your Product in a country member of the European Economic Area (EEA) or in Switzerland or the Republic of Turkey, and such Product was intended for sale in the EEA or in Switzerland or in Turkey, you can have your Product serviced in any EEA country or in Switzerland or in Turkey, under the warranty conditions prevailing in the country in which you require servicing, provided that an identical Product is sold in such country by an authorised Sony Ericsson distributor. To find out if your Product is sold in the country you are in, please call the local Sony Ericsson Contact Center. Please observe that certain

services may not be available outside the country of original purchase, for example, due to the fact that your Product may have an interior or exterior which is different from equivalent models sold in other countries. Please note in addition that it may sometimes not be possible to repair SIM-locked Products.

\*\* In some countries/regions additional information (such as a valid warranty card) may be requested.

## **Trademarks and acknowledgements**

The Liquid Identity logo and Xperia are trademarks or registered trademarks of Sony Ericsson Mobile Communications AB.

Sony is a trademark or a registered trademark of Sony Corporation.

Ericsson is a trademark or registered trademark of Telefonaktiebolaget LM Ericsson.

Bluetooth is a trademark or a registered trademark of Bluetooth SIG Inc. and any use of such mark by Sony Ericsson is under license.

Other product and company names mentioned herein may be the trademarks of their respective owners.

Any rights not expressly granted herein are reserved.

## Support

|                                   |                                               |                                       |
|-----------------------------------|-----------------------------------------------|---------------------------------------|
| Anguilla                          | 1-800-080-9518<br>(Toll Free)                 | questions.CO@support.sonyericsson.com |
| Antigua and Barbuda               | 1-800-081-9518<br>(Toll Free)                 | questions.CO@support.sonyericsson.com |
| Argentina                         | 0800-333-7427<br>(número gratuito)            | questions.CO@support.sonyericsson.com |
| Australia                         | 1300 650-050<br>(Toll Free)                   | questions.AU@support.sonyericsson.com |
| The Bahamas                       | 1-800-205-6062<br>(Toll Free)                 | questions.CO@support.sonyericsson.com |
| Barbados                          | 1-800-082-9518<br>(Toll Free)                 | questions.CO@support.sonyericsson.com |
| Belgique/<br>België               | 02-0745 1611                                  | questions.BE@support.sonyericsson.com |
| Belize                            | AN 815, PIN 5597<br>(Toll Free)               | questions.CO@support.sonyericsson.com |
| Bermuda                           | 1-800-083-9518<br>(Toll Free)                 | questions.CO@support.sonyericsson.com |
| Bolivia                           | 800-100-542<br>(número gratuito)              | questions.CO@support.sonyericsson.com |
| Brasil                            | 4001-0444<br>(ligação gratuita)               | questions.BR@support.sonyericsson.com |
| Canada                            | 1 866 766 9374<br>(Toll Free / sans<br>frais) | questions.CA@support.sonyericsson.com |
| Cayman<br>Islands                 | 1-800-084-9518<br>(Toll Free)                 | questions.CO@support.sonyericsson.com |
| Central and<br>Southern<br>Africa | +27 11 506 0123                               | questions.CF@support.sonyericsson.com |
| Česká<br>republika                | 844 550 055                                   | questions.CZ@support.sonyericsson.com |
| Chile                             | 800-646-425<br>(número gratuito)              | questions.CO@support.sonyericsson.com |
| Colombia                          | 01800-0966-080<br>(número gratuito)           | questions.CO@support.sonyericsson.com |
| Costa Rica                        | 0 800 011 0400<br>(número gratuito)           | questions.CO@support.sonyericsson.com |
| Danmark                           | 3331 2828                                     | questions.DK@support.sonyericsson.com |

|              |                                                                 |                                       |
|--------------|-----------------------------------------------------------------|---------------------------------------|
| Deutschland  | 0180 534 2020<br>(ortsübliche<br>Gebühren)                      | questions.DE@support.sonyericsson.com |
| Dominica     | 1-800-085-9518<br>(Toll Free)                                   | questions.CO@support.sonyericsson.com |
| Ecuador      | 1-800-0102-50<br>(número gratuito)                              | questions.CO@support.sonyericsson.com |
| Eesti        | 06 032 032                                                      | questions.EE@support.sonyericsson.com |
| Egypt/مصر    | 16727                                                           | questions.EG@support.sonyericsson.com |
| Ελλάδα       | 801 11 810 810<br>+30 210 899 19<br>19 (από κινητό<br>τηλέφωνο) | questions.GR@support.sonyericsson.com |
| El Salvador  | 800-6323 (número<br>gratuito)                                   | questions.CO@support.sonyericsson.com |
| España       | 902 180 576<br>(tarifa local)                                   | questions.ES@support.sonyericsson.com |
| France       | 09 69 32 21 21<br>09 69 32 21 22<br>(Xperia™<br>uniquement)     | questions.FR@support.sonyericsson.com |
| Guatemala    | 1-800-300-0057<br>(número gratuito)                             | questions.CO@support.sonyericsson.com |
| Haïti/Ayiti  | AN 193, PIN 5598<br>(numéro gratuit /<br>nimewo gratis)         | questions.CO@support.sonyericsson.com |
| Honduras     | AN 8000122, PIN<br>5599 (número<br>gratuito)                    | questions.CO@support.sonyericsson.com |
| Hong Kong/香港 | +852 8203 8863                                                  | questions.HK@support.sonyericsson.com |
| Hrvatska     | 062 000 000                                                     | questions.HR@support.sonyericsson.com |
| India/भारत   | 1800 11 1800 (Toll<br>Free)<br>+91 (011)<br>39011111            | questions.IN@support.sonyericsson.com |
| Indonesia    | 021 2701388                                                     | questions.ID@support.sonyericsson.com |
| Ireland      | 1850 545 888<br>(Local rate)                                    | questions.IE@support.sonyericsson.com |
| Italia       | 06 48895206<br>(tariffa locale)                                 | questions.IT@support.sonyericsson.com |
| Jamaica      | 1-800-442-3471<br>(Toll Free)                                   | questions.CO@support.sonyericsson.com |

|                           |                                                |                                       |
|---------------------------|------------------------------------------------|---------------------------------------|
| Kύπρος/<br>Kıbrıs         | 0800 90 909                                    | questions.CY@support.sonyericsson.com |
| Latvija                   | 67 21 43 01                                    | questions.LV@support.sonyericsson.com |
| Lietuva                   | 8 700 55030                                    | questions.LT@support.sonyericsson.com |
| Magyarország              | 01 880 47 47                                   | questions.HU@support.sonyericsson.com |
| Malaysia                  | 1800-88-9900<br>(Toll Free / bebas<br>tol)     | questions.MY@support.sonyericsson.com |
| Maroc/<br>المغرب          | +212 2 2958 344                                | questions.MA@support.sonyericsson.com |
| México                    | 0 1800 000 4722<br>(número gratuito)           | questions.MX@support.sonyericsson.com |
| Nederland                 | 0900 8998318                                   | questions.NL@support.sonyericsson.com |
| Nederlandse<br>Antillen   | 001-866-509-8660<br>(gratis nummer)            | questions.CO@support.sonyericsson.com |
| New Zealand               | 0800-100-150<br>(Toll Free)                    | questions.NZ@support.sonyericsson.com |
| Nicaragua                 | AN 1800-0166,<br>PIN 5600 (número<br>gratuito) | questions.CO@support.sonyericsson.com |
| Norge                     | 815 00 840<br>(lokaltakst)                     | questions.NO@support.sonyericsson.com |
| Österreich                | 0810 200 245                                   | questions.AT@support.sonyericsson.com |
| Pakistan/<br>پاکستان      | 021 - 111 22 55 73                             | questions.PK@support.sonyericsson.com |
| Panamá                    | 00800-787-0009<br>(número gratuito)            | questions.CO@support.sonyericsson.com |
| Paraguay                  | 009 800 54 20032<br>(número gratuito)          | questions.CO@support.sonyericsson.com |
| Perú                      | 0800-532-38<br>(número gratuito)               | questions.CO@support.sonyericsson.com |
| Philippines/<br>Pilipinas | +63 2 7891860                                  | questions.PH@support.sonyericsson.com |
| Polska                    | +48 22 22 77 444                               | questions.PL@support.sonyericsson.com |
| Portugal                  | 808 204 466<br>(chamada local)                 | questions.PT@support.sonyericsson.com |
| República<br>Dominicana   | 1-800-751-3370<br>(número gratuito)            | questions.CO@support.sonyericsson.com |
| România                   | +40 21 401 0401                                | questions.RO@support.sonyericsson.com |
| Saint Kitts<br>and Nevis  | 1-800-087-9518<br>(Toll Free)                  | questions.CO@support.sonyericsson.com |

|                                  |                                   |                                       |
|----------------------------------|-----------------------------------|---------------------------------------|
| Saint Vincent and the Grenadines | 1-800-088-9518 (Toll Free)        | questions.CO@support.sonyericsson.com |
| Schweiz/ Suisse/ Svizzera        | 0848 824 040                      | questions.CH@support.sonyericsson.com |
| Singapore                        | +65 6744 0733                     | questions.SG@support.sonyericsson.com |
| Slovenia                         | 01 600 5000                       | questions.SI@support.sonyericsson.com |
| Slovensko                        | 02 5443 6443                      | questions.SK@support.sonyericsson.com |
| South Africa                     | 0861 632222                       | questions.ZA@support.sonyericsson.com |
| South Korea/ 대한민국                | (+82) 1588 4170                   | questions.KO@support.sonyericsson.com |
| Suomi                            | 09 299 2000                       | questions.FI@support.sonyericsson.com |
| Sverige                          | 013 24 45 00 (lokal taxa)         | questions.SE@support.sonyericsson.com |
| Trinidad and Tobago              | 1-800-080-9521 (Toll Free)        | questions.CO@support.sonyericsson.com |
| Türkiye                          | +90 212 473 77 77                 | questions.TR@support.sonyericsson.com |
| United Kingdom                   | 08705 237 237 (Local rate)        | questions.GB@support.sonyericsson.com |
| United States                    | 1 866 766 9374                    | questions.US@support.sonyericsson.com |
| Uruguay                          | 000-401-787-013 (número gratuito) | questions.CO@support.sonyericsson.com |
| Venezuela                        | 0-800-1-00-2250 (número gratuito) | questions.CO@support.sonyericsson.com |
| Việt Nam                         | 1900 1525 (miễn phí)              | questions.VN@support.sonyericsson.com |
| Беларусь                         | 8 82 00 361 0001                  | questions.BY@support.sonyericsson.com |
| България                         | 0800 1 8778                       | questions.BG@support.sonyericsson.com |
| Россия                           | +7 (495) 7870986                  | questions.RU@support.sonyericsson.com |
| Україна                          | (+380) 44 590 1515                | questions.UA@support.sonyericsson.com |
| الأردن                           | +971 4 3919 880                   | questions.JO@support.sonyericsson.com |
| الإمارات العربية المتحدة         | +971 4 3919 880 (UAE)             | questions.AE@support.sonyericsson.com |
| الكويت                           | +971 4 3919 880                   | questions.KW@support.sonyericsson.com |
| المملكة العربية السعودية         | 800-8200-727                      | questions.SA@support.sonyericsson.com |
| 中国                               | +86 400 810 0000                  | questions.CN@support.sonyericsson.com |
| 台灣                               | +886 2 25625511                   | questions.TW@support.sonyericsson.com |
| ไทย                              | 02 2483 030                       | questions.TH@support.sonyericsson.com |

[www.sonyericsson.com](http://www.sonyericsson.com)



**Sony Ericsson**

Sony Ericsson Mobile Communications AB  
SE-221 88 Lund, Sweden

1222-9269.2