

Your cellphone.....



- 1 Information bar
- 2 Desktop
- 3 Send key
- 4 Voicemail key
- 5 Shift key
- 6 Fn key
- 7 Left/right navigation key
- 8 Space key
- 9 Tool bar
- 10 Status bar
- 11 End key
- 12 Vibration key
- 13 Delete key
- 14 Enter key
- 15 Sym key
- 16 Wi-Fi key
- 17 Micro-USB connector
- 18 Headset connector
- 19 Volume key

- Answer/Send a call
- Enter Call log
- Short key press: End a call
Lock the screen
Return to the main screen
- Long key press: Power on/off
- Long key press: Access your voicemail
- Press once: Input a capitalized character
- Press twice: Lock the keyboard in capital letter input mode
- Short key press: Press once: Input a top-half character
Press twice: Lock the keyboard in top-half key input mode
- Fn + B: Access Bluetooth
- Fn + M: Access Music player
- Fn + P: Access Profiles
- Fn + J: Access Java applications
- Press to go left and right
- Short key press: Enter a space
- Long key press: Access language list
- Hold down Fn key, then press space key to select input method
- Enter a dot
- Hold down Fn key, then press sym key to enter symbol table
- Confirm an option
- Enter the next line
- Vibration alert
- Volume up/down
- Scroll up/down
- Press to enter Wi-Fi function

1.1 Status bar icons ⁽¹⁾

- Battery charge level**
- Vibrate alert:** your cellphone vibrates, but does not ring or beep with the exception of the alarm.
- Bluetooth status (Activated).**
- Bluetooth status (Connected to an audio device).**
- Java status (Activated).**
- Headset connected.**
- Keypad & LCD touch locked.**
- Keypad& LCD touch unlocked.**
- Call forwarding activated:** your calls are forwarded.
- Alarm or appointments programmed.**
- Level of network reception.**
- Wi-Fi connected.**
- Wi-Fi disconnected.**
- Voicemail message arrived.**
- Missed calls.**
- Stopwatch is active.**
- Radio is on.**

⁽¹⁾ The icons and illustrations in this guide are provided for information purposes only.


- WAP alerts ⁽¹⁾.**
- Roaming.**
- Memory card scanning in progress.**
- Memory card scanning completed.**
- SIM card unavailable.**
- Line switching ⁽¹⁾:** indicates the selected line.
- GPRS connection status (Activated).**
- GPRS connecting.**
- EDGE attached.**
- EDGE connecting.**
- Music player active.**
- Message receipt in progress.**
- Sending a SMS.**
- Sending a MMS.**
- Silence mode:** your cellphone does not ring, beep or vibrate with the exception of the alarm.
- SMS unread.**
- (In red) Message list is full:** your cellphone cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.
- Flight mode.**
- A2DP connected.**
- Broadcast is on.**

⁽¹⁾ Depending on your network operator.

2 Getting started

2.1 Set-up

Removing or installing the back cover



Inserting or removing the SIM card

You must insert your SIM card to make phone calls. Please power off your cellphone and remove battery before inserting or removing the SIM card.



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press and slide it out.

Installing or removing the battery



- Insert and click the battery into place, then close the cellphone cover.
- Unclip the cover, then remove the battery.

2.2 Power on your cellphone

Hold down the key until the cellphone powers on.

2.3 Power off your cellphone

Hold down the key from the main screen.

2.4 Using the touchscreen

- Tap** To access an application, tap it with your finger.
- Drag** Place your finger on the screen to drag the object to the destination.
- Scroll** Slide the screen to scroll up and down the applications, images, web pages... at your convenience.

3 Making a call.....

Enter the desired number on the on-screen keypad directly or select a contact from Call log or Directory by tapping or respectively, then tap or press key to place the call. The number you entered can be saved to Directory by selecting . If you make a mistake, you can delete the incorrect digits by tapping .

To hang up the call, press the key.

4 Menu arrange

The main menu is designed to vary according to your preference. To access this function, select to enter the main menu, then tap .

Change the order

Access "Menu arrange", focus on the main menu item you want to move, and then tap "Options|Move", it will go to the main menu screen and tick "✓" will be shown on the main menu you selected, then release it to your favourite destination.

Show/Hide

Access "Menu arrange", tap the left check box of the selected menu once to show/hide, then tap "Options|Save" to save the operation.

Restore default

From main menu, select "Menu arrange", then tap "Options|Restore default settings" to return to the default menu display.

5 Messages

5.1 Conversational On (Off) mode

In conversational on mode, you can view chat history in chronological order. In conversational off mode, you may have access to the following folders: **Inbox, Outbox, Sent, Broadcast SMS, Voicemail, Drafts**, etc. You can switch between these two modes by selecting "Settings|Conversational mode|On (Off)". Conversational mode is set as the default mode and following instructions are based on this mode.

5.2 Create message

Select "Messages|Write msg" to create text/multimedia message. An SMS will be converted to MMS automatically when: images, videos, audio, slides or attachments are inserted; Subject, C/C/BCC/email address is added; or the message contains more than 8 pages of text.

Timer send

Schedule a SMS/MMS to be sent out at predefined time ("Option|Timer send").

6 Email

Your cellphone has an email client with the settings predefined for a few popular email services like - GoogleMail, Yahoo, AOL, etc. Besides this, you can set up other POP3 or IMAP4 email accounts that you may be using.

7 Palringo ⁽¹⁾

Palringo Instant messaging (IM) allows you to chat with other people using Palringo account. You can also connect to other popular IM services through Palringo, like Yahoo, AIM, GG, ICQ, GTalk, iChat etc. Please note that the services accessible to you will depend on your client version and dynamic Palringo server options.

8 Directory

8.1 Consulting your directory

To access the Directory, tap from tool bar on main screen, or select "Directory" from main menu.

8.2 Adding a contact

You can add a new contact by tapping .

Birthday reminder

You can set a birthday reminder when editing contact information. This will remind you at regular intervals during the day prior to the set date.

9 Call log

9.1 Access

You may access this function from the main menu "Call log" or by pressing from the main screen.

9.2 Available options

When you tap , you may have access to **Delete, Send message, Save to directory, Edit before call**, etc.

9.2.1 Billing ⁽¹⁾

You can access different items with this option: **Last call cost, Total cost, Max cost, Reset cost, Price per unit, Duration, GPRS counter, Beep duration**.

9.2.2 Call settings ⁽¹⁾

You can access a number of items with this option: **Call waiting, Call forwarding, Call barring, Caller ID, Line switching, Auto redial**, etc.

⁽¹⁾ Contact your network operator to check service availability.

10 Media applications

10.1 Music

To access this function, tap to enter the main menu and select . You will have full flexibility of managing music both on your cellphone and memory card.

10.2 Image

A library links to the images in "My creations" in cellphone to be shown in list, slide, or thumbnail, set as Wallpaper, Power on/off display, and Contact ID, or sent by MMS, Email, Bluetooth.

10.3 Video

"My videos" album contains video clips recorded, received or downloaded. All video clips in this folder can be played, set as Power on/off display, sent, deleted, renamed, sorted.

10.4 Radio

Your cellphone is equipped with a radio ⁽¹⁾ with RDS functionality. You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

11 Internet ⁽²⁾

11.1 My friends

It migrates self-contained sub-trees of the websites to let you stay in touch with your friends by flicking through Bebo, Friendster, Hi5, Myspace, etc.

⁽¹⁾ The quality of the radio depends on the coverage of the radio station in that particular area.

⁽²⁾ Depending on your network operator. May cause additional network charges for data flow to provide this service. Extra fees might also be charged in roaming states.

11.2 Opera

Not only does Opera Mini give you the full Web experience where you stay in touch with your friends, obtain information, do your online banking etc., but it is also designed to save time by using compressed web pages.

11.3 Wap

Access Wap options: **Homepage, Bookmarks, Go to URL, Last web address, Recent pages, Offline pages, Service inbox, Settings**.

11.4 News

It is a huge time saver providing news updates from a website in a simple form. Once subscribed to a channel, it gives you the ability to track and manage all your favourite RSS content on your cellphone at anytime, anywhere!

11.5 Weather

Your cellphone is equipped with a weather function for consulting up to 3-day forecasts of favourite cities.

11.6 Facebook

Facebook is a social utility that connects people with friends and others who work, study and live around them. It provides a number of features with which users may interact: Wall, a space on every user's profile page that allows friends to post messages for the user to see; Pokes, which allow users to send a virtual "poke" to each other; Gifts, a feature allowing users to send virtual gifts which appear on the recipient's profile; Market places, which lets users post free classified goods, etc. To open an account online, please go to: <http://www.facebook.com/>.

11.7 mTweet

Twitter is a social networking and microblogging service that has gained notability and popularity worldwide. This feature enables cellphone users to exchange news updates and ideas with a community in the form of messages or posts. Posts are displayed on the author's profile page and delivered to the author's subscribers or followers. To open an account online, please go to: <http://twitter.com/>.

12 Entertainment

12.1 Stopwatch

The stopwatch is a simple application for measuring time with the possibility to register several results and suspend/resume measurement.

12.2 Ebook

A bookshelf contains the electronic books (.txt and .pdb file only). While reading the book, you may add bookmark, or reach the text by searching words, phrases (Options|Find, Options|Jump to).

12.3 Java

Your Alcatel cellphone may include ⁽¹⁾ some Java™ applications and games. You can also download new applications and games to your cellphone.

13 Camera

Your cellphone is fitted with a camera for taking photos and shooting videos that you can use in different ways:

- store them in your "File manager|My creations".
- send them in a multimedia message (MMS) to a cellphone or an email address.
- send them directly by Email or Bluetooth.
- customize your main screen.
- select them as incoming call image to a contact in your directory.
- transfer them by data cable or microSD card to your computer.

⁽¹⁾ Depending on your network operator.


14 Profiles

With this menu, you may personalize ringtones for different events and environments.

15 File manager

You will have access to all audio and visual files stored in cellphone or memory card in File manager. You can access a number of items with this option: **My audios, My images, My videos, Ebook, My creations, Others, Phone, Memory card and Memory status**.

Inserting the memory card:



- Unclip the cover and insert the MicroSD card into the slot.
- Unclip the cover and gently push the memory card until unlocked. Take out your MicroSD card and clip the cover closed.

16 Bluetooth™

Access this feature by tapping to enter the main menu, then selecting "Bluetooth".

17 Wi-Fi

To access this function, tap to enter the main menu, and select .

18 Others

18.1 Calendar

Once you enter this menu from the main menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

18.2 Calculator

Access this feature by selecting "Calculator" from the main menu. Enter a number, select the type of operation to be performed, and enter the second number, then press "=" to display the result.

18.3 Notes

You can create a note in text or voice format by accessing "Notes" from the main menu.

18.4 Tasks

Enables you to easily manage and track the progress of a task with priorities. All the tasks will be sorted by due date.

18.5 Clock

18.5.1 Alarm

Your cellphone has a built-in alarm clock with a snooze feature.

18.5.2 World clock

The World clock shows current local time and the time zone in different cities.

18.5.3 Clock

Allows you to have settings of date and time, including 12/24h format.

18.6 Converter

You can use the Weight and Length conversion by selecting the unit you wish to convert via , then tap to input the digits. Finally confirm with "OK".

19 Settings



From the main menu, select the menu icon and select the function of your choice in order to customize your cellphone: **phone settings, Call settings, Security, Network, Connectivity.**

Touch settings

- LCD Touch Calibration** To calibrate the touch screen, tap anywhere on the screen to start calibration.
- Touch Vibration** When "On", the cellphone vibrates when the screen is touched.

Screen lock during call

Select "On"/"Off" to activate/deactivate screen lock during call.

20 Making the most of your cellphone.....

PC suite

You can download software upgrade for free from the website.

Webcam

You can use your cellphone as a webcam for instant messaging on your PC.

21 Latin input mode

There are two text entry methods that can be used to write messages

- Normal:** this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key.
- TouchPal mode:** This mode can perform predictive input on both hardware keypad and on-screen soft keypad, and supports multi-languages input.

Keyboard inputting

- Key:** Press once: Input a capitalized character
Press twice: Lock the keyboard in capital letter input mode
- Key:** Press once: Input a top-half character
Press twice: Lock the keyboard in top-half key input mode
- Key:** Short key press: Enter a space
Long key press: Access language list
Hold down Fn key, then press space key to select input mode
- key:** Short key press: Delete one by one
Long key press: Delete all
- key:** Confirm an option
Enter the next line
- Key:** Enter a dot
Hold down Fn key, then press sym key to enter symbol table

Safety and use.....

We recommend that you read this chapter carefully before using your cellphone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

-TRAFFIC SAFETY:
Given that studies show that using a cellphone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their cellphone when the vehicle is not parked. Check the laws and regulations on the use of wireless cellphones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

When driving, do not use your cellphone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas. When switched on, your cellphone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:
- do not place your cellphone on top of the dashboard or within an airbag deployment area,
- check with your car dealer or the car manufacturer to make sure that the car's electronic devices are shielded from cellphone RF energy.

-CONDITIONS OF USE:
You are advised to switch off the cellphone from time to time to optimize its performance. Remember to abide by local authority rules of cellphone use on aircrafts. Switch the cellphone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, cellphones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the cellphone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, gas station, or chemical plant, or in any potentially explosive atmosphere. When the cellphone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump. In particular when using the cellphone you should hold it against the ear on the opposite side to the device, if any.

To avoid hearing impairment, answer the call before holding your cellphone to your ear. Also move the handset away from your ear while using the "hands-free" option because the amplified volume might cause hearing damage. It is recommended to have proper supervision while small children use your cellphone. When replacing the cover please note that your cellphone may contain substances that could create an allergic reaction. Always handle your cellphone with care and keep it in a clean and dust-free place. Do not allow your cellphone to be exposed to adverse weather or environmental

conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc.).
- PRIVACY:
Please note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your cellphone regarding taking photographs and recording sounds with your cellphone. Pursuant to such laws and regulations, it may be strictly forbidden to take photographs and/or to record the voices of other people or any of their personal attributes, and reproduce or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorization be obtained, if necessary, in order to record private or confidential conversations or take a photograph of another person; the manufacturer, the seller or vendor of your cellphone (including the operator) disclaim any liability which may result from the improper use of the cellphone.

- BATTERY AND ACCESSORIES:
Before removing the battery from your cellphone, please make sure that the cellphone is switched off. Observe the following precautions for battery use:
- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery.
- Do not burn or dispose of a used battery in the garbage or store it at temperatures above 60°C.

Batteries must be disposed of in accordance with locally applicable environmental regulations. Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCT Mobile Limited and/or its affiliates. This symbol on your cellphone, the battery and the accessories means that these products must be taken to collection points at the end of their life:
- Municipal waste disposal centers with specific bins for these items of equipment
- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.
In European Union countries:
These collection points are accessible free of charge. All products with this sign must be brought to these collection points.
In non European Union jurisdictions:
Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

In the United States you may learn more about CTIA's Recycling Program at www.recyclewirelessphones.com
CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Warning: Prolonged exposure to music at full volume using the music player may damage your hearing. Set your cellphone's volume to its lowest setting prior to inserting headphones in your ears and adjust the volume to your preference. Only use headphones that are recommended by TCT Mobile Limited and its affiliates.

- Damage from exposure to water or other liquids, moisture, humidity, excessive temperatures or extreme environmental conditions, sand, excess dust and any condition outside the operating guidelines;
- Defects in appearance, cosmetic, decorative or structural items such as framing and non-operative parts.

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your jurisdiction. In no event shall TCT Mobile or any of its affiliates be liable for incidental or consequential damages of any nature whatsoever, including but not limited to commercial loss, to the full extent those damages can be disclaimed by law. Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

How to obtain Support: Contact the customer care center by calling (877-702-3444) or going to www.alcatel-mobilephones.com. We have placed many self-help tools that may help you to isolate the problem and eliminate the need to send your wireless device in for service. In the case that your wireless device is no longer covered by this limited warranty due to time or condition we have other options that you may utilize our out of warranty repair options.

To obtain hardware repairs or replacement within the terms of this warranty, contact TCT Mobile to get an RMA number, include a copy of the original proof of warranty coverage (e.g. original copy of the dated bill of sale, invoice), the consumer's return address, your wireless carrier's name, alternate daytime phone number, and email address with a complete problem description. Only ship the wireless device. Do not ship the SIM card, memory cards, or any other accessories such as the power adapter. You must properly package and ship the wireless device to the repair center. TCT Mobile is not responsible for wireless devices that do not arrive at the service center. Upon receipt, the service center will verify the warranty conditions, repair, and return your wireless device to the address provided.

Troubleshooting.....

Before contacting the aftersales department, you are advised to follow the instructions below:
- You are advised to switch off the cellphone from time to time to optimize its performance.
- You are advised to fully charge the battery for optimal operation.
- Avoid storing large amounts of data in your cellphone as this may affect the performance of your cellphone.

and carry out the following checks:
My cellphone will not switch on
- Press until the screen comes on
- Check the battery charge level
- Check the battery contacts, remove and reinstall your battery, then turn your cellphone back on
My cellphone has not responded for several minutes
- Press the key
- Remove the battery and re-insert it, then switch the cellphone back on
My screen is difficult to read
- Clean your screen
- Use your cellphone in accordance with the recommended conditions of use
My cellphone turns off by itself
- Check that your keypad is locked when you are not using your cellphone
- Check the battery charge level
My cellphone will not charge properly
- Make sure that your battery is not completely discharged; the battery charge indicator can take several minutes and may be accompanied by a quiet whistling sound
- Make sure charging is carried out under normal conditions (0°C +40°C)
- Make sure your battery is inserted. It must be inserted before plugging in the charger
- Make sure you are using an Alcatel battery and charger in the box
- When abroad, check that the electrical current is compatible

My cellphone will not connect to a network
- Try connecting in another location
- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually
- Try connecting at a later time if the network is overloaded
SIM card error
- Make sure the SIM card has been correctly inserted
- Verify with your operator that your SIM card is 3V or 1.8V compatible; the old 5V SIM cards cannot be used
- Make sure the chip on your SIM card is not damaged or scratched

Unable to make outgoing calls
- Make sure you have dialled a valid number and press the key
- For international calls, check the country and area codes
- Make sure your cellphone is connected to a network, and that the network is not overloaded or unavailable
- Check your subscription status with your operator (credit, SIM card valid, etc.)
- Make sure you have not barred outgoing calls
Unable to receive incoming calls
- Make sure your cellphone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit, SIM card valid, etc.)
- Make sure you have not forwarded incoming calls
- Make sure that you have not barred certain calls

The caller's name does not appear when a call is received
- Check that you have subscribed to this service with your operator
- Your caller has concealed his/her number
The sound quality of the calls is not optimal
- You can adjust the volume during a call by means of the Volume key
- Check the network strength
I am unable to use the features described in the manual
- Check with your operator to make sure that your subscription includes this service
- Make sure this feature does not require an Alcatel accessory

When I select a number from my directory, the number is not dialled
- Make sure that you have correctly recorded the number in your file
- Make sure that you have selected the country prefix when calling a foreign country

- CHARGERS
Home A.C./ Travel chargers will operate within the temperature range of: 0°C to 40°C.
The chargers designed for your cellphone meet with the standard for safety of information technology equipment and office equipment use. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only.
Characteristics of power supply (depending on the country):
Travel charger: Input: 100-240V 50/60 Hz, 0.15 A
Output: 5V, 350/400 mA
Lithium 850 mAh

- RADIO WAVES:
THIS CELLPHONE MEETS THE GOVERNMENT'S REQUIREMENTS FOR EXPOSURE TO RADIO WAVES.
Your cellphone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio-frequency (RF) energy. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. These guidelines include a substantial safety margin designed to ensure the safety of all persons, regardless of age and health. The exposure standard for cellphones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by public authorities such as the Federal Communications Commission of the US Government (FCC), or by Industry Canada, is 1.6 W/kg averaged over 1 gram of body tissue. Tests for SAR are conducted using standard operating positions with the cellphone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the cellphone while operating can be well below the maximum value. This is because the cellphone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the cellphone. Before a cellphone model is available for sale to the public, compliance with national regulations and standards must be shown. The highest SAR value for this model cellphone when tested is 0.592 W/Kg (OT-806A), 0.636 W/Kg (OT-807A) for use at the ear and 0.976 W/Kg (OT-806A), 1.17 W/Kg (OT-807A) for use close to the body. While there may be differences between the SAR levels of various cellphones and at various positions, they all meet the government requirement for RF exposure. For body-worn operation, the cellphone meets FCC RF exposure guidelines provided that it is used with a non-metallic accessory with the handset at least 1.5 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. The World Health Organization (WHO) considers that present scientific information does not indicate the need for any special precautions for use of cellphones. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep cellphones away from the head and body. (fact sheet n°193). Additional WHO information about electromagnetic fields and public health are available on the following website: <http://www.who.int/peh-emf>.

- LICENCES
Obigo® is a registered trademark of Obigo AB.
microSD Logo is a trademark.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCT Mobile Limited and its affiliates is under license. Other trademarks and trade names are those of their respective owners.
OT-806A/OT-807A Bluetooth QD ID B016239
TouchPal™ and CooTek™ are trademarks of Shanghai HanXiang (CooTek) Information Technology Co., Ltd. and/or its Affiliates.

I am unable to add a contact in my directory
- Make sure that your SIM card directory is not full; delete some contacts or save the contacts in the cellphone directory (i.e. your professional or personal directories)
My callers are unable to leave messages on my voicemail
- Contact your network operator to check service availability
I cannot access my voicemail
- Make sure your operator's voicemail number is correctly entered in "My numbers"
- Try later if the network is busy

I am unable to send and receive MMS
- Check your cellphone memory available as it might be full
- Contact your network operator to check service availability and check MMS parameters
- Verify the server center number or your MMS profile with your operator
- The server center may be swamped; try again later
The red icon is displayed on my standby screen
- You have saved too many short messages on your SIM card; delete some of them or archive them in the cellphone memory

"No service" is displayed
- You are outside of the network coverage area
I have already entered 3 incorrect PIN codes
- Contact your network operator to obtain the PLUK code (Personal Unlocking Key)
I am unable to connect my cellphone to my computer
- Install first of all Alcatel's PC suite
- Use "Install the connection" and perform the installation
- Check that your computer meets the requirements for Alcatel's PC Suite installation

I am unable to download new files
- Check for free space
- Delete some files
- Select the MicroSD Card to store the files you downloaded
- Check your subscription status with your operator
The cellphone can't be detected by others via Bluetooth
- Make sure that Bluetooth is turned on and your cellphone is visible to other users

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. For the receiver devices associated with the operation of a licensed radio service (e.g. FM broadcast), they bear the following statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference. For other devices, they bear the following statement: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference
(2) this device must accept any interference received, including interference that may cause undesired operation.

Your cellphone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it. As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or usb data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the cellphone at least 2cm away from the body.

- LICENCES
Obigo® is a registered trademark of Obigo AB.
microSD Logo is a trademark.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TCT Mobile Limited and its affiliates is under license. Other trademarks and trade names are those of their respective owners.
OT-806A/OT-807A Bluetooth QD ID B016239
TouchPal™ and CooTek™ are trademarks of Shanghai HanXiang (CooTek) Information Technology Co., Ltd. and/or its Affiliates.

Java™ and all Java™ based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Opera Mini™ is a registered trademark of Opera Mini.

Facebook and the f Logo are trademarks of Facebook, Inc., and are used under license.

Twitter and the T Logo are trademarks of Twitter, Inc., and are used under license.

The Wi-Fi Logo is a certification mark of the Wi-Fi Alliance.

Hearing Aid Compatibility

Your cellphone is rated: "For Hearing Aid", to assist hearing device users in finding cellphones that may be compatible with their hearing devices. This device is HAC M3 compatible. For more information please refer to "Hearing Aid Compatibility with Mobile Phones" leaflet or visit our website <http://www.alcatel-mobilephones.com/>

General information

- Website:** www.alcatel-mobilephones.com
- Facebook:** <http://www.facebook.com/alcatelnetouchtribe>
- Twitter:** <http://www.twitter.com/Alcateltribes>
- Hot Line Number:** In the United States, call 877-702-3444 for technical support.

On our Internet site, you will find our FAQ (Frequently Asked Questions) section. You can also contact us by e-mail to ask any questions you may have. An electronic version of this user guide is available in English and other languages according to availability on our server: www.alcatel-mobilephones.com
Your cellphone is a transceiver that operates on GSM networks with 850 and 1900 MHz bands.

Protection against theft⁽¹⁾

Your cellphone is identified by an IMEI (cellphone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your cellphone by entering *#06# and keep it in a safe place. It may be requested by the police or your operator if your cellphone is stolen.

Disclaimer

There may be certain differences between the user manual description and the cellphone's operation, depending on the software release of your cellphone or specific operator services.

⁽¹⁾ Contact your network operator for service availability.