

SIMRAD®

V5043 Class A AIS Transceiver

Installation manual

English



Scan here
to save a copy

www.navico-commercial.com

PREFACE

Copyright

© 2024 Navico Group. All Rights Reserved. Navico Group is a division of Brunswick Corporation.

Trademarks

®Reg. U.S. Pat. & Tm. Off, and ™ common law marks.

Visit www.navico.com/intellectual-property to review the global trademark rights and accreditations for Navico Group and other entities.

- Navico® is a trademark of Navico Group.
- Simrad® is a trademark of Kongsberg Maritime AS, licensed to Navico Group.
- NMEA®, NMEA 0183® and NMEA 2000® are trademarks of the National Marine Electronics Association.
- SD® and microSD® are trademarks of SD-3C, LLC.

Disclaimer

Navico Group is devoted to publish and maintain this product manual. As we continue to improve our AIS products to satisfy all customers' needs, information in this document is subject to change without notice. Navico Group does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential, or other damage.

Governing language

This statement, any instruction manuals, user guides and other information relating to the product (Documentation) may be translated to, or has been translated from, another language (Translation).

In the event of any conflict between any Translation of the Documentation, the English language version of the Documentation will be the official version of the Documentation.

Safety Warning

It is important to know that AIS is designed for the purpose of anti-collision and serves as a complement to navigation. It is not the absolute navigational equipment and does not replace any navigational system installed onboard. This device is meant to enhance situational awareness and may not prevent vessel collisions in all circumstances. It is your obligation to be aware of your surroundings and to ensure safe operation of the vessel.



Any AIS device cannot guarantee monitoring and receiving signals from all vessels in the surroundings unless those vessels are equipped with AIS devices.



ELECTRICAL SHOCK HAZARD

Improper disassembly or modification could cause electrical shocks, fire, or personal injury.
Only qualified personnel could work on the interior of the equipment.



MAKE SURE THE POWER SOURCE AND THE POWER INPUT MATCH

Incorrect power sources will damage the equipment and may even result in fire.
Please ensure the correct power input on the adaptor before installation.



AVOID DIRECT CONTACT WITH RAIN OR SPLASHING WATER

Electrical shock or fire could be resulted if water leaks into the equipment.



NOTE/INFORMATION

→ *Note: Important notices and information will be noted in this manual.*

Product category

This product is categorized as "protected" in accordance with the requirements as defined in IEC 60945.

Compass safe distance

Safe distance to the transceiver (and junction box) unit is:

- Standard magnetic compass: 0.30 m
- Steering magnetic compass: 0.30 m

RF exposure safe distance

The Simrad® V5043 Class A AIS Transceiver has been tested and meets applicable limits for radio frequency (RF) exposure. This device generates and radiates RF electromagnetic energy and requires a Maximum Permissible Exposure of 1.9 m from the antenna during operation.

Hardware/software version

- Software version: 2.X.X-XX

The model name/number, hardware information, and firmware (software) version of the transceiver can be identified through MKD at **Menu > Diagnostics > Version**. The software maintenance/upgrade of the transceiver can be carried out onboard via microSD® card. The onboard documentation in **Appendix C: Installation and Maintenance Record** on page 61 can be used to assist reflecting software maintenance records.

Type approval

The Simrad® V5043 Class A AIS Transceiver complies with applicable international standards and is type approved in accordance with the European Marine Equipment Directive.

Declaration of conformity

Navico declare under our sole responsibility that this Simrad® V5043 Class A AIS Transceiver conforms with the requirements of the European Council Directive 2014/90/EU on Marine Equipment, modified by Commission Implementing Regulation (EU) 2023/1667 (8 August 2023) - Wheelmark. All compliance documents are available from the V5043 section on the following website:

www.navico-commercial.com.

Disposal instruction

Do not dispose of this device with unsorted waste.

Improper disposal may be harmful to the environment and human health. Please refer to your local waste authority for information on return and collection systems in your area.

Contact information

For sales, services, and technical support, please contact a Simrad® representative at: www.navico-commercial.com.

Warranty

The warranty card is supplied as a separate document. In case of any queries, refer to the brand website for your unit or system:

www.navico-commercial.com

About this manual

Features described and illustrated in this guide may vary from your display unit due to continuous development of the software.

Document version 001.

For the latest version of this document in supported languages, visit: www.navico-commercial.com.

CONTENTS

5 What is AIS?

6 V5043 System overview

- 6 Product description
- 6 Main features
- 7 Interconnection diagram

8 Installation

- 8 Equipment in the box
- 9 Installation procedure
- 9 RF cable requirements
- 10 GPS antenna installation
- 10 VHF antenna installation
- 12 Mounting the V5043 transceiver main unit
- 15 Mounting the junction box
- 16 Junction box connectors
- 19 Connecting the transceiver to the junction box
- 20 Connecting to power supply
- 20 Connecting the optional pilot plug
- 21 Password

22 Product specifications

26 Mechanical dimensions

- 26 Transceiver main unit
- 28 Junction box
- 28 Extension cable
- 28 Ethernet cable
- 29 Mounting template (V5043, not to scale)
- 29 GPS antenna
- 30 Pilot plug (optional)

31 Troubleshooting

- 32 Troubleshooting alarm messages

34 Appendix A: Data Interface technical information

- 34 AIS interface overview
- 35 Data interface (IEC 61162-2)
- 37 Supported data sentences (IEC 61162)
- 37 Interpretation of input sentences
- 49 Interpretation of output sentences

58 Appendix B: NMEA 2000® PGN Information

61 Appendix C: Installation and Maintenance Record

- 61 Installation and maintenance record
- 61 AIS Class A transceiver information
- 62 GPS (GNSS) antenna location
- 62 Connected sensors and devices
- 63 Installer information

WHAT IS AIS?

The Automatic Identification System (AIS) is a Very High Frequency (VHF) radio broadcasting system that transfers packets of data over the VHF data link (VDL) and enables AIS equipped vessels and shore-based stations to exchange identification information and navigational data. Ships with AIS transceivers continually transmit their ID, position, course, speed and other data to all nearby ships and shore stations. Such information can aid greatly in situational awareness and provide a means to assist in collision avoidance.

AIS equipment is standardized by ITU, IEC, IALA and IMO and is subject to approval by a certification body. The following AIS devices have been developed for variant applications.

AIS Class A

Mandated by the IMO for vessels of 300 gross tonnages and upwards engaged on international voyages, cargo ships of 500 gross tonnages and upwards, as well as passenger ships. It transmits typically on 12.5 W output power.

AIS Class B

Provides limited functionality and is intended for non-SOLAS commercial vessels and recreational vessels. It transmits typically on 2 W output power.

AIS Receiver

Only receives AIS signal and does not have transmitter to send out AIS signal. Suitable for recreational vessels that do not want to send out its vessel information.

AIS Base Station

Is provided by aids-to-navigation authorities to enable the ship to shore / shore to ship transmission of information. Networked AIS Base Stations can assist in providing overall maritime domain awareness.

AIS AtoN (Aids to Navigation)

Provides an opportunity to transmit position and status of buoys and lights through the same VDL, which can then show up on AIS-ready devices within the range.

AIS SART

Search and Rescue Transmitter using AIS can be used to help determine the location of a vessel in distress. It is typically used on life rafts.

AIS on search and rescue (SAR) aircraft

AIS is used on airplanes and helicopters to assist search and rescue operations.

V5043 SYSTEM OVERVIEW

Product description

The Simrad® model V5043 is a new generation AIS Class A transceiver fully compliant with IMO, IEC, and ITU international standards. It provides a compact single box solution, easy to install and operate. The product is designed with advanced technology which sets a new standard for quality, performance, and value. It is an excellent choice for SOLAS vessels, commercial ships, professional vessels, and non-SOLAS applications.




The V5043 can be connected to the ship's sensors as required by the IALA guidelines through junction box. The device can also interface external navigation and presentation systems that support IEC 61162-1 related sentences. It is also capable for connection to Long Range system like Inmarsat C. The V5043 supports both SOLAS and Inland AIS mode which is configurable by the software.

The color LCD display and menu keypads provide an intuitive graphical user-friendly interface to the system. It can display the location of other vessels, aids to navigation and search and rescue vessels. The AIS transmit and receive status are shown on the screen which helps user to know the working status of the unit easily. The LCD and keypad can also be used to send and receive messages, perform configuration as well as supervise the system status.

Main features

- Compact AIS Class A solution, easy to install and operate
- Fully compliant with IMO, IEC, and ITU international standards
- Color 4.3" LCD display with various display modes
- User-friendly intuitive GUI and keypad operation
- IMO/Inland AIS mode selectable
- Compliance with CESNI Inland AIS test standard Ed. 2021/3.0
- Multiple sensor input ports and bidirectional data ports
- USB, NMEA 2000®, and Ethernet connectivity, SD® card for software upgrade
- Support type P of BAM function type


Interconnection diagram



INSTALLATION

Equipment in the box

The standard package includes the following items. Please contact your local representative if an item is missing.



Parts list		Part number	
1	Class A AIS transceiver unit	x1	000-16280-001
2	Junction box	x1	000-12324-001
3	GPS antenna with 10 m cable	x1	000-12326-001
4	8-pin Ethernet cable (RJ45 female)	x1	-
5	Gimbal mounting kit	x1	-
6	37-pin extension cable, 1.8 m	x1	000-12328-001
7	3-pin power cable, 1.5 m	x1	000-12329-001
8	Installation manual	x1	988-13175-001
	Operator manual	x1	988-13176-001
9	Junction box mounting kit	x1	-
10	Panel mount holder kit	x1	-
11	Panel mount cutting template	x1	-
12	Pilot plug (optional)	-	000-12325-001, sold separately

Installation procedure

Familiarize yourself with the manual content before you begin installation. Use the following recommended steps for installation:

- 1 Mount the transceiver unit to a desired location.
- 2 Mount junction box.
- 3 Install VHF antenna (not included with the V5043).
- 4 Install GPS antenna.
- 5 Connect all external sensors and data interfaces to the junction box.
- 6 Connect all required cables to the main transceiver unit.
- 7 Power on the main transceiver unit.
- 8 Complete configuration settings.
- 9 Perform system functional test.

RF cable requirements

The following radio frequency (RF) cable is recommended for installation of the VHF antenna (not supplied).

- VHF Antenna Cable
Type: 5D-FB or equivalent
Connector: PL-259 (Male)

A suitable cable and connector for the GPS antenna is supplied with the GPS antenna.

GPS antenna installation

A GPS (GNSS) antenna and cable is supplied with the V5043.

- Install the GPS antenna in a position where it has a clear view of the sky. The aim is to see 360° around the horizon, with a clear vertical view from 5° above the horizon to 90° above the horizon.
- Mount the GPS antenna for AIS as far as possible from, and at least 3 m away from, any other high-power transmitting device.
- Ensure the GPS antenna is not positioned within the beam of any other transmitting device.

Enter the GPS antenna location data in **Ship setting** after the installation.

You should record the GPS antenna's location on the vessel in the maintenance records section **GPS (GNSS) antenna location** on page 62.

VHF antenna installation


AIS requires a VHF antenna (antenna and cable not included).

- Mount the VHF antenna as high as possible to allow a clear view of the horizon and the greatest possible line-of-sight.
- If the vessel has more than one VHF antenna, they should be mounted one above the other if possible, and separated vertically by a minimum of 2 m.
- The recommended minimum horizontal distance between two VHF antennas on the same horizontal plane is 10 m.
- Mount the VHF antenna for AIS as far as possible from, and at least 3 m away from, any other high-power transmitting device such as radar.
- Ensure the VHF antenna is not positioned within the beam of any other transmitting device.
- Mount the VHF antenna a minimum of 2 m (horizontally) from any structure made of conducting material.

Example GPS and VHF antenna locations

The diagram below gives an example of the GPS and VHF antennas' locations on a vessel. Existing equipment or structures on a vessel may require the antennas to be positioned differently.

In all cases, for correct operation of the AIS, ensure the positions chosen for the GPS antenna and VHF antenna adhere to the guidelines in the sections **GPS antenna installation** and **VHF antenna installation** on page 10. We advise following current best practice for installing any equipment on your vessel.




A	VHF antenna for AIS
B	Mast, with navigation lights
C	VHF antenna
D	Radar (or other high-power transmitting device)
E	GPS heading sensor
F	GPS receiver for AIS

Mounting the V5043 transceiver main unit


Use the following guidelines to check the installation location for your AIS transceiver:

- The AIS transceiver should be mounted in a location that is accessible and readable to user at all time.
- The transceiver should be installed in a protected environment away from direct rain and water contact.
- The transceiver is designed to operate in an environmental temperature of -25°C to $+55^{\circ}\text{C}$ temperature. Environments with excessive heat may cause damage to the transceiver.
- The transceiver should not be installed near flammable or hazardous environments.
- The AIS transceiver should be installed at least 0.5 m away from magnetic compasses.




Panel mounting


- 1 Line up the mounting template on control panel to sketch an outline for the cutting area.
- 2 Using a jigsaw, carefully cut along the sketched cutting area.
- 3 If necessary, clean up edge with glass paper or file.
- 4 Mount the transceiver through the opening.
- 5 Behind the panel, attach a mounting bracket to each side of the unit using the M3X6 screws.
→ *Note: The brackets are directional, so ensure the correct one is fitted to each side.*
- 6 Apply the mounting bracket screw on each side for a firm fix.



Panel mounting (side view)



External connectors (transceiver main unit)



Name	Description	Type	
1	POWER	Power input connector	Round type, 3 pins
2	DATA	Connect to junction box/ Connect to sensor or data ports	D-Sub 37 pins
3	ETHERNET	10Base-T/100Base-TX	Round type, 8 pins
4	GPS	GPS antenna connector	TNC (female)
5	VHF	VHF antenna connector	SO-239 (female)
6	Frame ground	Connect to ship frame	

Vessel power supply requirement



Connect to the ship's power source, ideally an uninterrupted power supply (UPS), through a 2-pole switched supply with a fuse to allow isolation for servicing.

The power requirement is nominal 24 V DC (2 A minimum) or 12 V DC (4 A minimum).

For cable length 0–10 m, the minimum conductor area is 1.5 mm².

- **Note:** The Class A power supply requirement should comply with IMO guidelines for the class of vessel concerned. National authorities and classification societies may have their own power supply requirements; these should also be considered.
- **Note:** Some boats require frame ground connection of all electronic devices on the ship frame.


Mounting the junction box



Junction box connectors

Baud rate support: 115200, 57600, 38400, 19200, 14400, 9600, 4800.


Junction box external connectors



Function		
1	Termination switches	The switches provide line termination configuration.
		<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Termination off</p> </div> <div style="text-align: center;"> <p>Termination on</p> </div> </div>
2	Jumper for NMEA 2000® shield and ground	The jumper's purpose is to wire together NMEA 2000® cable's shield and ground. Depending on your scenario, you may choose not to connect them together.
3	Frame ground strip	
4	NMEA 2000®	
5	Cable glands	
6	Connectors	
7	Frame ground	

Junction box connectors

→ **NOTE:** A suitable wire gauge (single wire) for junction box connectors is AWG 26–16. See image of connector below.



Connector	Label name	Description	Function	
A	Sensor 1 ⁽¹⁾	GND	Ground	Connect to data sources such as gyro, heading or other types of sensors.
	SEN1_IN A	Sensor 1 input A		
	SEN1_IN B	Sensor 1 input B		
B	Sensor 2 ⁽¹⁾	GND	Ground	Connect to data sources such as gyro, heading or other types of sensors.
	SEN2_IN A	Sensor 2 input A		
	SEN2_IN B	Sensor 2 input B		
C	Sensor 3 ⁽¹⁾	GND	Ground	Connect to data sources such as gyro, heading or other types of sensors.
	SEN3_IN A	Sensor 3 input A		
	SEN3_IN B	Sensor 3 input B		
D	Alarm	ALARM N.O.	Alarm normally open	
		ALARM N.C.	Alarm normally closed	
		ALARM COM	Alarm common	

⁽¹⁾The default baud rate is 4800.

Connector	Label name	Description	Function	
E	DGPS input ⁽²⁾	GND	Ground	DGPS sensor
		DGPS_IN A	DGPS input A	
		DGPS_IN B	DGPS input B	
F	DGPS output ⁽²⁾	GND	Ground	DGPS sensor
		DGPS_OUT A	DGPS output A	
		DGPS_OUT B	DGPS output B	
G	LR input ⁽²⁾	GND	Ground	Long range input
		LR_IN A	LR input A	
		LR_IN B	LR input B	
H	LR output ⁽²⁾	GND	Ground	Long range output
		LR_OUT A	LR output A	
		LR_OUT B	LR output B	
I	Display ⁽²⁾	GND	Ground	Connect to the data input of an external display system such as ECDIS.
		DISP_IN A	DISP input A	
		DISP_IN B	DISP input B	
J		GND	Ground	Connect to the data input of an external display system such as ECDIS.
		DISP_OUT A	DISP output A	
		DISP_OUT B	DISP output B	
K	Pilot plug ⁽²⁾	GND	Ground	Pilot plug port
		PILOT_IN A	Input A	
		PILOT_IN B	Input B	
L		GND	Ground	
		PILOT_OUT A	Output A	
		PILOT_OUT B	Output B	


⁽²⁾The default baud rate is 38400.

Connector	Label name	Description	Function
M	Blue sign	BLUE_SIGN A	Connect to a blue sign switch.
		BLUE_SIGN B	

Connecting the transceiver to the junction box

Use the 37-pin-extension cable (1.8 m) provided in the package to connect the V5043 to the junction box.


→ *Note: The end of the extension cable with the EMI ferrite core should be connected at the V5043 main unit.*



1	V5043 unit
2	EMI ferrite core on 1.8 m extension cable
3	Junction box

Connecting to power supply

The V5043 requires a 12 V or 24 V DC power supply capable of supplying 4 A peak current. The red wire and the black wire on the 3-pin cable are used to connect the power supply's positive and negative terminals. A 4 A fuse or circuit breaker must be used in the connection between the power supply and the unit.




Connecting the optional pilot plug

The V5043 has an integrated pilot plug on the front panel with the IMO-standard AMP connector. Open the waterproof lid to connect the PPU (Personal Pilot Unit). When needed, an optional pilot plug is available for purchase to be connected through the junction box.

It is recommended to keep the pilot plug lid closed when not in use.

Pilot plug	Signal type
Pin 9	RS-422 GND
Pin 1	RS-422 TX-A
Pin 5	RS-422 RX-A
Pin 4	RS-422 TX-B
Pin 6	RS-422 RX-B




Password


Certain information stored in the transceiver can only be changed with the password. The password is required to access the following chapters:

- Own ship: contains information about MMSI, vessel name, IMO, call sign and dimension.
- Long range settings -
- Long range broadcast -
- Transceiver: enables the option to activate/deactivate AIS transmission.
- I/O port settings: about baud rate configuration of sensors.

The **Password Setting** sub-menu enables users to change the password.

→ *Note: Default password: "000000"*

Use direction keys to select **Old Password**, **New Password** and then press  to enter value. To save the settings, press **Save** button in the view and the system will ask whether the changes should be saved. Select **Yes** to save or **No** to discard and return to **System Configuration** sub-menu.



36° 45.030'S
174° 41.530'E

2023/05/09
09:50:49

Password Setting SAVE

Old Password *****

New Password *****

PRODUCT SPECIFICATIONS

Applicable standards

IEC 61993-2 Ed.3.0, 2018	IMO Resolution A.694(17)
IEC 61108-1 Ed.2.0, 2003	IMO Resolution MSC.74(69) Annex 3
IEC 60945 Ed.4.0, 2002 incl. Corr. 1, 2008	IMO Resolution MSC.191(79)
IEC 61162-1 Ed.5.0, 2016	IMO Resolution MSC.302(87)
IEC 61162-2 Ed.1.0, 1998	ITU-R M.1371-5 (Class A), 2014
IEC 61162-450 Ed.2.0, 2018	IEC 62288 Ed.3.0, 2021
IEC 62923-1 Ed. 1.0, 2018	IEC 62923-2 Ed. 1.0, 2018
CESNI Inland AIS test standard Ed. 2021/3.0	

VHF transceiver

Frequency range	156.025 MHz–162.025 MHz
Channel bandwidth	25 kHz
Modulation	GMSK / FM
Data rate	9,600 bps
Number of AIS transmitter	1
Number of AIS receiver	2
Number of DSC receiver	1
AIS Channel 1	CH 87B (161.975 MHz)
AIS Channel 2	CH 88B (162.025 MHz)
Tx power output	1/12.5 W (30/41 dBm ± 1.5 dB)
Rx sensitivity	< -110 dBm @ 20% PER

DSC receiver

Frequency	156.525 MHz
Modulation	FSK
Channel bandwidth	25K
Sensitivity	< -112 dBm @ BER $< 10^{-2}$
Spurious response rejection	≥ 70 dB for signal @ -104 dBm; BER ≤ 1 %
Blocking	≥ 84 dB for signal @ -104 dBm; BER ≤ 1 %

GPS (GNSS) receiver (internal)

Receiver type	72-channel; GPS, GLONASS, BeiDou, Galileo, SBAS: WASS, EGNOS, MSAS, GAGAN
Accuracy	Position: 2.5 m CEP SBAS: 2.0 m CEP
Sensitivity	Default mode: GPS & GLONASS Tracking and Navigation: -164 dBm Reacquisition: -160 dBm

GPS (GNSS) antenna

Cable type	RG58A/U or equivalent
Cable length	10 m
Connector	TNC (male)

Power supply

Supply voltage	12 V DC or 24 V DC
Supply voltage range	9.6 V DC–31.2 V DC
Peak current draw	3.50 A @ 12 V DC; 1.72 A @ 24 V DC

LCD display

Screen size	4.3" color TFT
Pixel number (resolution)	480x272
Dimmer control	Change brightness manually or automatically
Nominal viewing distance	0.52 m

Keypad

11 keys with backlight	Function, escape, voyage/SRM, menu, screen brightness, display, enter, 4 arrow keys
------------------------	---

Connection interface

V5043 main unit front panel	
USB	Mini type-B USB interface
SD® card slot	MicroSD® type
Pilot plug	206486-2
V5043 main unit rear panel	
Power connector	Round type, 3 pins
GPS antenna connector	TNC (female)
VHF antenna connector	SO-239 (female)
Ethernet	Compliance with IEEE 802.3u, 10Base-T/100Base-TX
Data	37-pins, connect to junction box via extension cable
Junction box connectors [*Baud rate support: 38400 (default), 9600, 4800.]	
Sensor interfaces 1 to 3*	IEC 61162-1 or -2
Pilot/auxiliary*	IEC 61162-2
External display*	IEC 61162-2
Long range*	IEC 61162-2
DGNSS correction input*	RTCM-SC-104
*Baud rate support: 38400 (default), 9600, 4800.	
Alarm relay	Normally closed
NMEA 2000®	IEC61162-3
Alarm output	Relay contact
Blue sign switch	Connect to external blue sign switch

Environmental

Operating conditions	IEC 60945 "protected" category
Operating temperature	-25°C to +55°C
Operating humidity	93% RH at 40°C
Waterproof	IP54

Physical

Width	238 mm (9.37")
Height	135 mm (5.32")
Depth (including connectors)	192.6 mm (7.58")
Weight (main unit)	1.25 kg


Pilot Plug (optional)

Cable length	2 m
Connector type	206486-2


MECHANICAL DIMENSIONS

Transceiver main unit


Front (width: 238.14 mm, 9.37 in)




Side (height: 135 mm, 5.32 in)




Back (width: 238 mm, 9.37 in)




Bottom (depth: 192.6 mm, 7.58 in)




Junction box



Extension cable




Ethernet cable




Mounting template (V5043, not to scale)



UNIT: mm



GPS antenna



Pilot plug (optional)



TROUBLESHOOTING

Use the following guide to perform simple troubleshooting in case the transceiver does not function as it is expected. Due to the complexity of the operation environment of marine electronics, we recommend minimizing sources of interference before proceeding with the troubleshooting by:

- Disconnecting other NMEA® equipment such as ECDIS, heading, gyro, etc from the AIS transceiver.
- Switching off other emission sources such as radar or VHF radio.

Symptom	Possible cause and remedy
The transceiver will not power on	<ul style="list-style-type: none"> • Check that the voltage of the power supply has 12 V or 24 V. • Check that the polarity is not switched. • Check that the available current is sufficient for start-up. • Check that the power connector is correctly connected and secured. • Increase dimmer level of the display.
No GPS position fix	<ul style="list-style-type: none"> • Check for failed GPS antenna, damaged antenna cable and connectors • When the transceiver's internal GPS does not have a position fix, the time and date appearing in the upper right corner of the display will not be correct. • Check the GNSS status to see the received satellites and their noise ratio.
No AIS transmission	<ul style="list-style-type: none"> • Make sure that MMSI number is correctly configured. • Make sure that silent mode is switched off. • Check that the available current is sufficient for transmission. • Check if the transceiver might be operating in a regional area set with different operating mode.
AIS range seems too low	<ul style="list-style-type: none"> • Check VHF antenna and cable installation • Make sure the transceiver is not operating in low power (1 W) mode.
No AIS targets on radar view and target list	<ul style="list-style-type: none"> • Check if VHF antenna, cabling and connector installations are damaged.
Sensor or data ports not response	<ul style="list-style-type: none"> • Check that wiring polarity is not switched • Check that the transceiver and the connected sensor have the same baud rate

Troubleshooting alarm messages


The V5043 is monitoring itself constantly for failures or other important parameters with the built-in integrity test (BIIT). If abnormal operation is detected in one or more of the following conditions, an alert will be triggered and displayed on the screen, and the transceiver will react as described in the following table.

Description text	BIIT ID	Reaction of the system (transceiver)
<p>AIS: Tx malfunction</p> <p>The V5043 has a built-in lock detector (high active) to monitor the local oscillator (PLL circuit) of the transmitter. If the operation of PLL circuit becomes abnormal, a logic low (Tx malfunction) will be sent from the lock detector to notify the system. At the same time, system will output an BIIT ID 001 alert at the related PI port.</p>	001	Stop transmission
<p>AIS: Antenna VSWR exceeds limit</p> <p>The V5043 has a built-in RF output power detector to monitor the VSWR (Voltage Standing Wave Ratio) of the VHF antenna port. If the antenna VSWR exceeds a given limit, an alarm will be generated. If the VSWR goes below the defined threshold, the alarm is cleared.</p>	002	Continue operation
<p>AIS: Rx channel 1 malfunction</p> <p>The V5043 has 3 built-in lock detectors (high active) to monitor each local oscillator (PLL circuit) of receiver channel 1, channel 2, and channel 70 respectively. If the operation of PLL circuit becomes abnormal, a logic low level will be sent from the lock detector to notify the system. At the same time, the system will output BIIT ID 003, BIIT ID 004 or BIIT ID 005 alert to indicate the CH1 or CH2 or CH70 RX malfunction respectively.</p>	003	Stop transmission on affected channel
<p>AIS: Rx channel 2 malfunction</p>	004	Stop transmission on affected channel
<p>AIS: Rx channel 70 malfunction</p>	005	Continue operation
<p>AIS: general failure</p>	006	Stop transmission
<p>AIS: UTC sync invalid</p> <p>This alarm is triggered when the transceiver lost UTC direct synchronization or cannot synchronize from the internal GPS receiver.</p>	007	Continue operation using indirect or semaphore synchronization
<p>AIS: MKD connection lost</p> <p>This alarm is active if the communication between the control unit and the display in the transceiver does not work.</p>	008	Continue operation

Description text	BIIT ID	Reaction of the system (transceiver)
<p>AIS: internal/external GNSS position mismatch This alarm is active if the difference between the internal and external GNSS position is more than 100 m for more than 1 hour.</p>	009	Continue operation
<p>AIS: NavStatus incorrect For example, if the navigational status is set to “At Anchor” but the ship is moving faster than 3 knots, this alarm will become active.</p>	010	Continue operation
<p>Heading sensor offset This alarm is active when SOG is greater than 5kn and the difference between COG and HDT is greater than 45° for 5 min.</p>	011	Continue operation
<p>AIS: active AIS SART This alarm is active when the transceiver receives an AIS SART position report.</p>	014	Continue operation
<p>AIS: external EPFS lost This alarm is active if the position from the external Electronic Position Fixing System is invalid.</p>	025	Continue operation
<p>AIS: no sensor position in use This alarm is active if there is no valid position from any sensor is available.</p>	026	Continue operation
<p>AIS: no valid SOG information This alarm is active if the transceiver does not have a valid SOG from any sensor</p>	029	Continue operation using default data
<p>AIS: no valid COG information This alarm is active if the transceiver does not have a valid COG from any sensor</p>	030	Continue operation using default data
<p>AIS: Heading lost/invalid This alarm is active if either the heading info from external sensor is lost or if the heading is undefined.</p>	032	Continue operation using default data
<p>AIS: no valid ROT information This alarm is active if ROT is undefined or if no valid ROT info is available.</p>	035	Continue operation using default data

APPENDIX A: DATA INTERFACE TECHNICAL INFORMATION

AIS interface overview



Data interface (IEC 61162-2)

The V5043 Class A AIS transceiver provides two types of IEC 61162-2 data interface for user applications. The first type of interface includes three input-only sensor data ports, and the second type of interface includes four bidirectional input/output ports.

Sensor data input ports

The schematic for an input-only sensor data port is shown below (**Schematic of a sensor data input port**).


The schematic shows an isolated half duplex RS-485 transceiver IC which is used as the main component to receive external data. The transceiver IC is isolated from external input.

To avoid signal reflection, the transceiver IC has an optional built-in 120 Ω loop termination, which is selected using the dip-switch on the junction box. The switch should be set to ON when connecting an external data source with a long cable.

All sensor data-input ports are isolated from one another and are also isolated from the internal power supply. The input impedance on A/B wires is greater than 12 k Ω , and the levels on the A/B wires are defined as follows:

- Logic low input: A-B < -0.2 V
- Logic high input: A-B > -0.02 V

Schematic of a sensor data input port



Bidirectional data ports


The schematic for a bidirectional data port is shown below (**Schematic of a bidirectional data port**).

The schematic includes an isolated full duplex RS-485 transceiver IC which is used as the main component to handle both data input and output from external data source. The transceiver IC is isolated from external input.

To avoid signal reflection, the transceiver IC has an optional built-in 120 Ω loop termination, which is selected using the dip-switch on the junction box. The switch should be set to ON when connecting an external data source with a long cable. All bidirectional data ports are isolated from one another and are also isolated from the internal power supply. The transceiver internal power supply is fully isolated from the external power supply.

The output driver capability of a bidirectional data port can provide a maximum of 60 mA, and the minimum differential output swing under 100 Ω load can be 2.3 V.

Schematic of a bidirectional data port



A and B signal lines

Refer to **Sensor data input ports** on page 35, and **Bidirectional data ports** on page 36.

Input load

Refer to **Sensor data input ports** on page 35, and **Bidirectional data ports** on page 36.

Hardware input/output circuit

Refer to **Sensor data input ports** on page 35, and **Bidirectional data ports** on page 36.

Supported data sentences (IEC 61162)

Data Port	Input Sentences	Output Sentences
Sensor 1 Sensor 2 Sensor 3 DGPS	DTM, GBS, GGA, GLL, GNS, GSA, GSV, HDT, RMC, ROT, THS, VBW, VHW, VTG	N/A
External display pilot	ABM, ACA, ACN, ACK, AIQ, AIR, BBM, EPV, LRF, LRI, SSA, SSD, VSD	ABK, ACA, ACS, ALC, ALF, ALR, ARC, LR1, LR2, LR3, LRF, NAK, TXT, VDM, VDO, VER For query (AIQ): ACA, EPV, SSD, TRL, TXT, VER, VSD
Long range	LRF, LRI	LR1, LR2, LR3, LRF

Sentence output interval

Sentence	Interval
VDO	Once per second
ALR, ALC, ALF (active)	Once every 30 s
ALR (inactive)	Once every 60 s

Interpretation of input sentences

ABM: AIS addressed binary and safety related message

This sentence supports ITU-R M.1371 Messages 6, 12, 25, 26 and provides an external application with a means to exchange data via an AIS transceiver.

!-ABM,x,x,x,xxxxxxxx,x,xx,s-s,x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Total number of sentences needed to transfer the message	
2	x	Sentence number	
3	x	Sequential message identifier	
4	xxxxxxxx	The MMSI of the destination AIS unit for the ITU-R M.1371 message	
5	x	AIS channel for broadcast of the radio message	
6	xx	ITU-R M.1371 message ID	
7	s-s	Encapsulated data	
8	x	Number of fill-bits	

ACA – AIS Channel assignment message

An AIS device can receive regional channel management information.

\$--ACA,x,IIII.II,a,yyyyy.yy,a,IIII.II,a,yyyyy.yy,a,x,xxxx,x,xxxx,x,x,a,x,hmmss.ss*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Sequence Number	
2	IIII.II,a	Region northeast corner latitude – N/S	
3	yyyyy.yy,a	Region northeast corner longitude – E/W	
4	IIII.II,a	Region southwest corner latitude – N/S	
5	yyyyy.yy,a	Region southwest corner longitude – E/W	
6	x	Transition zone size	
7	xxxx	Channel A	
8	x	Channel A bandwidth	
9	xxxx	Channel B	
10	x	Channel B bandwidth	
11	x	Tx/Rx mode control	
12	x	Power level control	
13	a	Information source	
14	x	In-use flag	
15	hmmss.ss	Time of “in use” change	

ACK – Acknowledge alarm

This sentence is used to acknowledge an alarm condition reported by a device.

\$--ACK,xxx*hh<CR><LF>			
Field No.	Format	Description	Remark
1	xxx	Unique alarm number (identifier) at alarm source	

AIQ - Query sentence

This sentence is used to inquire AIS sentence information.

\$--AIQ,c--c*hh<CR><LF>			
Field No.	Format	Description	Remark
1	c--c	Support query sentence of ACA, EPV, SSD, TRL, TXT, VER, VSD	

AIR – AIS interrogation request

This sentence supports ITU-R M.1371 messages 15 and 10. It provides an external application with the means to initiate requests for specific ITU-R M.1371 messages from AIS unit.

\$--AIR,xxxxxxxx,x,x,x,x,x,xxxxxxxx,x,x,x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	xxxxxxxx	MMSI of interrogated station 1	
2	x.x	ITU-R M.1371 message requested from station-1	
3	x	Message sub-section	ignored
4	x.x	Number of second message requested from station-1	
5	x	Message sub-section	ignored
6	xxxxxxxx	MMSI of interrogated station-2	
7	x.x	Number of messages requested from station-2	
8	x	Message sub-section	ignored

BBM – AIS broadcast binary message

This sentence supports generation of ITU-R M.1371 binary messages 8, 14, 25, and 26. This provides the application with a means to broadcast data, as defined by the application only.

!--BBM,x,x,x,x,x,x,s--s,x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Total number of sentences needed to transfer the message	
2	x	Sentence number	
3	x	Sequential message identifier	
4	x	AIS channel for broadcast of the radio message	
5	x.x	ITU-R M.1371 Message ID	
6	s--s	Encapsulated data	
7	x	Number of fill-bits	

DTM - Datum reference

Local geodetic datum and datum offsets from a reference datum.

\$--DTM,ccc,a,x.x,a,x.x,a, x.x,ccc*hh<CR><LF>			
Field No.	Format	Description	Remark
1	ccc	Local datum	
2	a	Local datum subdivision code	ignored
3	x.x, a	Lat offset, min, N/S	ignored
4	x.x, a	Lon offset, min, E/W	ignored
5	x.x	Altitude offset, m	ignored
6	ccc	Reference datum	

EPV - Command or report equipment property value

\$--EPV,a,cc,c--c,x.x,c--c*hh<CR><LF>			
Field No.	Format	Description	Remark
1	a	Sentence status flag	
2	cc	Destination equipment type	
3	c--c	Unique identifier	
4	x.x	Property identifier	
5	c--c	Value of property to be set	

GBS - GNSS satellite fault detection

This sentence is used to support receiver autonomous integrity monitoring (RAIM).

\$--GBS, hhmss.ss, x.x, x.x, x.x, xx, x.x, x.x, x.x *hh <CR><LF>			
Field No.	Format	Description	Remark
1	hhmss.ss	UTC time of the GGA or GNS fix associated with this sentence	
2	x.x	Expected error in latitude	
3	x.x	Expected error in longitude	
4	x.x	Expected error in altitude	ignored
5	xx	ID number of most likely failed satellite	ignored
6	x.x	Probability of missed detection for most likely failed satellite	ignored
7	x.x	Estimate of bias on most likely failed satellite	ignored
8	x.x	Standard deviation of bias estimate	ignored

GGA – Global positioning system (GPS) fix data

Time, position and fix-related data for a GPS receiver.

\$-GGA, hhmmss.ss, llll.ll, a, yyyyy.yy, a, x, xx, x.x, x.x, M, x.x, M, x.x, xxxx*hh<CR><LF>			
Field No.	Format	Description	Remark
1	hhmmss.ss	UTC of position	
2	llll.ll,a	Latitude N/S	
3	yyyyy.yy,a	Longitude E/W	
4	x	GPS quality indicator	ignored
5	xx	Number of satellites in use, 00-12, may be different from the number in view	ignored
6	x.x	Horizontal dilution of precision	ignored
7	x.x	Antenna altitude above/below mean sea level (geoid)	ignored
8	M	Units of antenna altitude, m	ignored
9	x.x	Geoidal separation	ignored
10	M	Units of geoidal separation, m	ignored
11	x.x	Age of differential GPS data	ignored
12	xxxx	Differential reference station ID, 0000-1023	ignored

GLL – geographic position – latitude/longitude

Latitude and longitude of vessel position, time of position fix and status.

\$-GLL, llll.ll, a, yyyyy.yy, a, hhmmss.ss, A, a *hh<CR><LF>			
Field No.	Format	Description	Remark
1	llll.ll, a	Latitude, N/S	
2	yyyyy.yy, a	Longitude, E/W	
3	hhmmss.ss	UTC of position	
4	A	Status, A = data valid V = data invalid	
5	a	Mode indicator	

GNS – GNSS fix data

Fix data for single or combined satellite navigation systems (GNSS). This sentence provides fix data for GPS, GLONASS, possible future satellite systems and systems combining these.

\$- GNS, hhmss.ss, llll.ll, a, yyyy.yy, a, c--c,xx,x.x,x.x,x.x,x.x,x.x,a *hh<CR><LF>			
Field No.	Format	Description	Remark
1	hhmss.ss	UTC of position	
2	llll.ll, a	Latitude, N/S	
3	yyyy.yy, a	Longitude, E/W	
4	c--c	Mode indicator	
5	xx	Total number of satellites in use	ignored
6	x.x	HDOP	ignored
7	x.x	Antenna altitude, m, re:mean-sea-level (geoid)	ignored
8	x.x	Geoidal separation, m	ignored
9	x.x	Age of differential data	ignored
10	x.x	Differential reference station ID	ignored
11	a	Nacigational status indicator	

GSA – GNSS DOP and active satellites

GNSS receiver operating mode, satellites used in the navigation solution reported by the GGA or GNS sentences, and DOP values. If only GPS, GLONASS, etc. are used for the reported position solution, the talker ID is GP, GL, etc. and the DOP values pertain to the individual system.

\$-GSA, a, x, xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,x.x,x.x,x.x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	a	Mode: M = manual, forced to operate in 2D or 3D mode A = automatic, allowed to automatically switch 2D/3D	
2	x	Mode: 1 = fix not available, 2 = 2D, 3 = 3D	
3	xx,xx,xx,xx, xx,xx,xx,xx, xx,xx,xx,xx	ID numbers of satellites used in solution	
4	x.x	PDOP	
5	x.x	HDOP	
6	x.x	VDOP	

HDT – Heading true

Actual vessel heading in degrees true produced by any device or system producing true heading.

\$--HDT,x,x,T*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x,x, T	Heading, degrees true	

LRF – AIS long-range function

This sentence is used in both long-range interrogation requests and long-range interrogation replies. The LRF-sentence is the second sentence of the long-range interrogation request pair, LRI and LRF (see the LRI-sentence).

\$--LRF,x,xxxxxxxx,c--c,c--c,c--c*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Sequence number	
2	xxxxxxxx	MMSI of requester	
3	c--c	Name of requester	
4	c--c	Function request	
5	c--c	Function reply status	

LRI – AIS Long-range interrogation

The long-range interrogation of the AIS unit is accomplished through the use of two sentences. The pair of interrogation sentence formatters, a LRI sentence followed by a LRF sentence, provides the information needed by a universal AIS unit to determine if it should construct and provide the reply sentences (LRF, LR1, LR2, and LR3).

\$--LRI,x,a,xxxxxxxx,xxxxxxxx,IIII.II,a,yyyy.yy,a,IIII.II,a,yyyy.yy,a*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Sequence number	
2	a	Control flag	
3	xxxxxxxx	MMSI of requester	
4	xxxxxxxx	MMSI of destination	
5	IIII.II,a	Latitude – N/S	
6	yyyy.yy,a	Longitude – E/W	
7	IIII.II,a	Latitude – N/S	
8	yyyy.yy,a	Longitude – E/W	

RMC – Recommended minimum specific GNSS data

Time, date, position, course and speed data provided by a GNSS navigation receiver.

\$-RMC, hhmss.ss, A, llll.ll,a, yyyy.yy, a, x.x, x.x, xxxxxx, x.x,a, a*hh<CR><LF>			
Field No.	Format	Description	Remark
1	hhmss.ss	UTC of position fix	
2	A	Status	
3	llll.ll,a	Latitude, N/S	
4	yyyy.yy, a	Longitude, E/W	
5	x.x	Speed over ground, knots	
6	x.x	Course over ground, degrees true	
7	xxxxxx	Date: dd/mm/yy	
8	x.x,a	Magnetic variation, degrees, E/W	
9	a	Mode indicator	
10	a	Navigational status	

ROT – Rate of turn

Rate of turn and direction of turn.

\$-ROT, x.x, A*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x.x	Rate of turn, °/min	
2	A	Status: A = data valid, V = data invalid	

SSA –Sender signature authentication

This sentence can be used both for authentication of sender and for authentication of untampered content. For this purpose, the sentence has to be applied before the protected sentence (for example EPV, SSD).

Other sentences shall not be interleaved between the sender signature authentication sentence and protected sentence, and the time between the SSA and the protected sentence should be limited. The sender signature authentication protected sentence pair shall be sent without unnecessary delay between sentences, and the time interval between the sentences shall not exceed 2 s. Note that any of the sentences may be lost and timed out.

\$--SSA,ccc,c,h--h,*hh<CR><LF>			
Field No.	Format	Description	Remark
1	ccc	The following sentence formatter that should be protected (for example EPV or SSD).	
2	c	Type of method to calculate signature: 1: MD5	
3	h--h	Hexadecimal representation of the signature, for example 32 hexacodes for MD5.	

SSD – AIS ship static data

This sentence is used to enter static parameters into a shipboard AIS unit. The parameters in this sentence support a number of the ITU-R M.1371 Messages.

\$--SSD,c--c,c--c,xxx,xxx,xx,xx,c,aa*hh<CR><LF>			
Field No.	Format	Description	Remark
1	c--c	Ship's call sign	
2	c--c	Ship's name	
3	xxx	Pos. ref., point dist. "A,"	
4	xxx	Pos. ref.,point dist. "B,"	
5	xx	Pos. ref., point dist. "C,"	
6	xx	Pos. ref.,point dist. "D,"	
7	c	DTE indicator flag	
8	aa	Source identifier	

THS – True heading and status

Actual vessel heading in degrees true produced by any device or system producing true heading. This sentence includes a “mode indicator” field providing critical safety related information about the heading data, and replaces the deprecated HDT sentence.

\$--THS,x.x,a*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x.x	Heading, degrees true	
2	a	Mode indicator	

VBW – Dual ground/water speed

Water-referenced and ground-referenced speed data.

\$--VBW,x.x,x.x,A,x.x,x.x,A,x.x,A,x.x,A*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x.x	Longitudinal water speed, knots	ignored
2	x.x	Transverse water speed, knots	ignored
3	A	Status : water speed, A = data valid, V = data invalid	ignored
4	x.x	Longitudinal ground speed, knots	
5	x.x	Transverse ground speed, knots	
6	A	Status , ground speed, A = data valid, V = data invalid	
7	x.x	Stern transverse water speed, knots	ignored
8	A	Status : stern water speed, A = data valid, V = data invalid	ignored
9	x.x	Stern transverse ground speed, knots	ignored
10	A	Status : stern ground speed, A = data valid, V = data invalid	ignored

VHW – Water speed and heading

The compass heading to which the vessel points and the speed of the vessel relative to the water.

\$--VHW,x.x,T,x.x,M,x.x,N,x.x,K*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x.x, T	Heading, degrees true	
2	x.x, M	Heading, degrees magnetic	Ignored
3	x.x, N	Speed, knots	Ignored
4	x.x, K	Speed, km/h	Ignored

VSD – AIS voyage static data

This sentence is used to enter information about a ship's transit that remains relatively static during the voyage.

\$--VSD, x.x, x.x, x.x, c--c, hhmss.ss, xx, xx, x.x, x.x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x.x	Type of ship and cargo category	
2	x.x	Maximum present static draught	
3	x.x	Persons on-board	
4	c--c	Destination	
5	hhmss.ss	Estimated UTC of arrival at destination	
6	xx	Estimated day of arrival at destination	
7	xx	Estimated month of arrival at destination	
8	x.x	Navigational status	
9	x.x	Regional application flags	

VTG – Course over ground and ground speed

The actual course and speed relative to the ground.

\$--VTG, x.x, T, x.x, M, x.x, N, x.x, K, a*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x.x, T	Course over ground, degrees true	
2	x.x, M	Course over ground, degrees magnetic	ignored
3	x.x, N	Speed over ground, knots	
4	x.x, K	Speed over ground, km/h	ignored
5	a	Mode indicator	

PAMC, DBG – proprietary sentences, debug

The proprietary sentences are additional sentences only applicable to this product. Its main usage is for enabling testing mode and parameter settings.

This sentence is used for configuration. It commands unit with given parameters.

\$PAMC,C,c-c,x,x,x,x,x,x,x,x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	C	Command : "C"	
2	c-c	Function type. For example, DBG.	
3	x	Parameter Id 1, 0-998	
4	x	Parameter value 1, 0-1000000000	
5	x	Parameter Id 2, 0-998	
6	x	Parameter value 2, 0-1000000000	
7	x	Parameter Id 3, 0-998	
8	x	Parameter value 3, 0-1000000000	
9	x	Parameter Id 4, 0-998	
10	x	Parameter value 4, 0-1000000000	

This sentence is used for retrieving responses.

\$PAMC,R,c-c,x,x,x,x,x,x,x,x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	R	Response : "R"	
2	c-c	Function type. For example, DBG.	
3	x	Parameter Id 1, 0-998	
4	x	Parameter value 1, 0-1000000000	
5	x	Parameter Id 2, 0-998	
6	x	Parameter value 2, 0-1000000000	
7	x	Parameter Id 3, 0-998	
8	x	Parameter value 3, 0-1000000000	
9	x	Parameter Id 4, 0-998	
10	x	Parameter value 4, 0-1000000000	

PAMC, DSC – Proprietary sentences, digital selective calling

When AIS transceiver receives DCS messages, this sentence is used to output DSC pattern.

\$PAMC,R,DSC,c-c*hh<CR><LF>			
Field No.	Format	Description	Remark
1	c-c	DSC pattern	

ACN – Alert command

This sentence is used for acknowledge, silence, responsibility transfer and to request repeat of alert details in case the reception process has detected, based on ALC, that ALF has been missed.

\$--ACN,hhmmss.ss,aaa,x.x,x.x,c,a*hh <CR><LF>			
Field No.	Format	Description	Remark
1	hhmmss.ss	Time	
2	aaa	Manufacturer mnemonic code	
3	x.x	Alert Identifier	
4	x.x	Alert Instance, 1 to 999999	
5	c	Alert command, A, Q, O or S	
6	a	Sentence status flag	

Interpretation of output sentences

ABK – AIS addressed and binary broadcast acknowledgment

The ABK-sentence is generated when a transaction, initiated by reception of an ABM, AIR, or BBM sentence, is completed or terminated.

\$--ABK,xxxxxxxx,x,x,x,x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	xxxxxxxx	MMSI of the addressed AIS unit	
2	x	AIS channel of reception	
3	x.x	ITU-R M.1371 message ID	
4	x	Message sequence number	
5	x	Type of acknowledgment	

ACA – AIS channel assignment message

An AIS device can receive regional channel management information.

\$-ACA,x,IIII.II,a,yyyy.yy,a,IIII.II,a,yyyy.yy,a,x,xxxx,x,xxxx,x,x,x,a,x,hmmss.ss*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Sequence number	
2	IIII.II,a	Region northeast corner latitude – N/S	
3	yyyy.yy,a	Region northeast corner longitude – E/W	
4	IIII.II,a	Region southwest corner latitude – N/S	
5	yyyy.yy,a	Region southwest corner longitude – E/W	
6	x	Transition zone size	
7	xxxx	Channel A	
8	x	Channel A bandwidth	
9	xxxx	Channel B	
10	x	Channel B bandwidth	
11	x	Tx/Rx mode control	
12	x	Power level control	
13	a	Information source	
14	x	In-use flag	
15	hmmss.ss	Time of “in use” change	

ALR – Set alarm state

Local alarm condition and status. This sentence is used to report an alarm condition on a device and its current state of acknowledgment.

\$--ALR,hhmmss.ss,xxx,A, A,c--c*hh<CR><LF>			
Field No.	Format	Description	Remark
1	hhmmss.ss	Time of alarm condition change, UTC	
2	xxx	Unique alarm number (identifier) at alarm source	
3	A	Alarm condition, A = threshold exceeded, V = not exceeded	
4	A	Alarm's acknowledge state, A = acknowledged, V = unacknowledged	
5	c--c	Alarm's description text	

EPV – Command or report equipment property value

\$--EPV,a,cc,c--c,x.x,c--c*hh<CR><LF>			
Field No.	Format	Description	Remark
1	a	Sentence status flag	
2	cc	Destination equipment type	
3	c--c	Unique identifier	
4	x.x	Property identifier	
5	c--c	Value of property to be set	

LR1 – AIS long-range reply sentence 1

The LR1 sentence identifies the destination for the reply and contains the information items requested by the "A" function identification character (see the LRF sentence).

\$--LR1,x,xxxxxxxx,xxxxxxxx,c--c,c--c,xxxxxxxx*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Sequence number	
2	xxxxxxxx	MMSI of responder	
3	xxxxxxxx	MMSI of requester	
4	c--c	Ship's name, 1 to 20 characters	
5	c--c	Call sign, 1 to 7 characters	
6	xxxxxxxx	IMO number, 9-digit number	

LR2 – AIS long-range reply sentence 2

The LR2-sentence contains the information items requested by the "B, C, E and F" function identification characters, (see the LRF sentence).

\$--LR2,x,xxxxxxxx,xxxxxxxx,hhmmss.ss,IIII.II,a,yyyy.yy,a,x.x,T,x.x,N*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Sequence number	
2	xxxxxxxx	MMSI of responder	
3	xxxxxxx	Date: ddmmyyyy, 8 digits	
4	hhmmss.ss	UTC time of position	
5	IIII.II,a	Latitude - N/S	
6	yyyy.yy,a	Longitude, E/W	
7	x.x,T	Course over ground, degrees, true	
8	x.x,N	Speed over ground, knots	

LR3 – AIS long-range reply sentence 3

The LR3 sentence contains the information items requested by the “I, O, P, U and W” function identification character (see the LRF sentence).

\$-LR3,x,xxxxxxxx,c-c,xxxxxx,hhmmss.ss,x.x,x.x,x.x,x.x,x.x,x.x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Sequence number	
2	xxxxxxxx	MMSI of responder	
3	c--c	Voyage destination, 1 to 20 characters	
4	xxxxxx	ETA date: ddmmyy	
5	hhmmss.ss	ETA time	
6	x.x	Draught	
7	x.x	Ship/cargo	
8	x.x	Ship length	
9	x.x	Ship breadth	
10	x.x	Ship type	
11	x.x	Persons, 0 to 8191	

LRF – AIS long-range function

This sentence is used in both long-range interrogation requests and long-range interrogation replies. The LRF-sentence is the second sentence of the long-range interrogation request pair, LRI and LRF (see the LRI-sentence).

\$-LRF,x,xxxxxxxx,c-c,c-c,c-c*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Sequence number	
2	xxxxxxxx	MMSI of requester	
3	c--c	Name of requester	
4	c--c	Function request	
5	c--c	Function reply status	

TRL -AIS transmitter-non-functioning log

This sentence is specific to AIS class A stations. It is intended to support the retrieval of the AIS non-functioning log information.

\$--TRL,x,x,x,x,x,xxxxxxxx,hhmmss.ss,xxxxxxxx,hhmmss.ss,x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x.x	Total number of log entries	
2	x.x	Log entry number	
3	x	Sequential message identifier	
4	xxxxxxx	Switch off date	
5	hhmmss.ss	Switch off UTC time	
6	xxxxxxx	Switch on date	
7	hhmmss.ss	Switch on UTC time	
8	x	Reason code 1 = power off 2 = silent mode 3 = transmission switched off by channel management command 4 = equipment malfunction 5 = invalid configuration	

TXT - Text transmission

For the transmission of short text messages. Longer text messages may be transmitted by using multiple sentences.

\$--TXT,xx,xx,xx,c--c*hh<CR><LF>			
Field No.	Format	Description	Remark
1	xx	Total number of sentences	
2	xx	Sentence number	
3	xx	Text identifier	
4	c--c	Text message	

VDM – AIS VHF data-link message

This sentence is used to transfer the entire contents of a received AIS message packet, as defined in ITU-R M.1371 and as received on the VHF Data Link (VDL), using the “six-bit” field type.

!-VDM,x,x,x,a,s--s,x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Total number of sentences needed to transfer the message	
2	x	Sentence number	
3	x	Sequential message identifier	
4	a	AIS channel	
5	s--s	Encapsulated ITU-R M.1371 radio message	
6	x	Number of fill-bits	

VDO – AIS VHF data-link own-vessel report

This sentence is used to transfer the entire contents of an AIS unit’s broadcast message packet, as defined in ITU-R M.1371 and as sent out by the AIS unit over the VHF data link (VDL) using the “six-bit” field type.

!-VDO,x,x,x,a,s--s,x*hh<CR><LF>			
Field No.	Format	Description	Remark
1	x	Total number of sentences needed to transfer the message	
2	x	Sentence number	
3	x	Sequential message identifier	
4	a	AIS channel	
5	s--s	Encapsulated ITU-R M.1371 radio message	
6	x	Number of fill-bits	

ALC – Cyclic alert list

The purpose of this sentence is to satisfy the needs for safe and consistent data distribution with minimal data traffic. Each change on an alert's data leads to an incremented revision counter, so an alert-processing device needs only check the alert entries in the ALC messages to ensure that no ALF message has been lost.

\$--ALC,xx,xx,xx,xx,x,x,aaa,x,x,x,x,x,.....,aaa,x,x,x,x,x*hh <CR><LF>			
Field No.	Format	Description	Remark
1	xx	Total number of sentences for this message, 01 to 99	
2	xx	Sentence number, 01 to 99	
3	xx	Sequential message identifier, 00 to 99	
4	x.x	Number of alert entries	
5	aaa	Manufacturer mnemonic code	
6	x.x	Alert identifier	
7	x.x	Alert instance (BIIT ID)	
8	x.x	Revision counter	
9	Additional Alert entries	
10	aaa,x,x,x,x,x	Alert entry n	

ALF – Alert sentence

This sentence is used to report an alert condition and the alert state of a device. An ALF message shall be published for an alert each time the alert information in this sentence changes and on alert request.

\$--ALF,x,x,x,hhmmss.ss,a,a,a,aaa,x.x,x.x,x.x,c---c*hh <CR><LF>			
Field No.	Format	Description	Remark
1	x	Total number of ALF sentences for this message, 1 to 2	
2	x	Sentence number, 1 to 2	
3	x	Sequential message identifier, 0 to 9	
4	hhmmss.ss	Time of last change	
5	a	Alert category, A, B or C	
6	a	Alert priority, E, A, W or C	
7	a	Alert state, A, S, N, O, U or V	
8	aaa	Manufacturer mnemonic code	
9	x.x	Alert identifier	
10	x.x	Alert instance (BIIT ID), 1 to 999999	
11	x.x	Revision counter, 1 to 99	
12	x	Escalation counter, 0 to 9	
13	c---c	Alert text	

ARC – Alert command refused

This sentence is used for which it is illegal to accept acknowledge or responsibility transfer, e.g. not enough information for decision support available or the source of acknowledgment is not acceptable.

\$--ARC,hhmmss.ss,aaa,x.x,x.x,c*hh <CR><LF>			
Field No.	Format	Description	Remark
1	hhmmss.ss	Time	
2	aaa	Manufacturer mnemonic code	
3	x.x	Alert identifier	
4	x.x	Alert instance (BIIT ID), 1 to 999999	
5	c	Refused alert command, A, Q, O or S	

APPENDIX B: NMEA 2000® PGN INFORMATION

The following table is a list of the NMEA 2000® PGNs supported by the V5043 unit.

Output	
PGN	Description
59392	ISO Acknowledgment
59904	ISO Request
60160	ISO Transport Protocol, Data Transfer
60416	ISO Transport Protocol, Connection Management
60928	ISO Address Claim
126208	NMEA® – Acknowledge group function
126464	PGN List – Transmit PGN's group function
126993	Heartbeat
126996	Product Information
126998	Configuration Information
129038	AIS Class A Position Report
129039	AIS Class B Position Report
129040	AIS Class B Extended Position Report
129041	AIS Aids to Navigation (AtoN) Report
129792	AIS DGNSS Broadcast Binary Message
129793	AIS UTC and Date Report
129794	AIS Class A Static and Voyage Related Data
129795	AIS Addressed Binary Message
129797	AIS Binary Broadcast Message
129798	AIS SAR Aircraft Position Report
129800	AIS UTC/Date Inquiry
129801	AIS Addressed Safety Related Message
129802	AIS Safety Related Broadcast Message
129803	AIS Interrogation
129804	AIS Assignment Mode Command
129805	AIS Data Link Management Message
129806	AIS Channel Management
129807	AIS Group Assignment

129809	AIS Class B "CS" Static Data Report, Part A
129810	AIS Class B "CS" Static Data Report, Part B
129811	AIS Single Slot Binary Message
129812	AIS Multi Slot Binary Message
129813	AIS Long-Range Broadcast Message
129816	AIS Acknowledge
129793	AIS UTC and Date Report
129794	AIS Class A Static and Voyage Related Data
129795	AIS Addressed Binary Message
129797	AIS Binary Broadcast Message
129798	AIS SAR Aircraft Position Report
129800	AIS UTC/Date Inquiry
129801	AIS Addressed Safety Related Message
129802	AIS Safety Related Broadcast Message
129803	AIS Interrogation
129804	AIS Assignment Mode Command
129805	AIS Data Link Management Message
129806	AIS Channel Management
129807	AIS Group Assignment
129809	AIS Class B "CS" Static Data Report, Part A
129810	AIS Class B "CS" Static Data Report, Part B
129811	AIS Single Slot Binary Message
129812	AIS Multi Slot Binary Message
129813	AIS Long-Range Broadcast Message
129816	AIS Acknowledge

Input	
PGN	Description
59392	ISO Acknowledgment
59904	ISO Request
60160	ISO Transport Protocol, Data Transfer
60416	ISO Transport Protocol, Connection Management
60928	ISO Address Claim
65240	ISO Commanded Address
126208	NMEA® - Request group function NMEA® - Command group function

APPENDIX C: INSTALLATION AND MAINTENANCE RECORD

The following installation information should be completed and retained on board the vessel for maintenance records.

Installation and maintenance record


Vessel information			
Vessel name		Flag state	
IMO number		MMSI number	
Owner/Company		Radio call sign	
Type of vessel		Gross tonnage	
Length (m)		Beam (m)	

AIS Class A transceiver information

AIS Class A transceiver information			
Transceiver S/N		Pilot Plug S/N	
Junction Box S/N		GPS Ant. S/N	
Password			
Power supply voltage (V):			
Power supply maximum output current (A)			
Note			

GPS (GNSS) antenna location

GPS (GNSS) antenna location	
A: distance to bow (m)	
B: distance to stern (m)	
C: distance to port-side (m)	
D: distance to starboard (m)	



Connected sensors and devices

Connected sensors and devices		
Connected port	Equipment	Model number
Sensor 1		
Sensor 2		
Sensor 3		
Ext Display Port		
Pilot Port		
Long Range Port		
DGNSS Data Port		
Other Device		

Installer information

Installer information		
Connected port	Equipment	Model number
Company name		
Technician's name		
Telephone/Mobile no.		
Address		
Place	Date	Installer's Signature



©2024 Navico Group. All Rights Reserved. Navico Group is a division of Brunswick Corporation.

®Reg. U.S. Pat. & Tm. Off, and ™ common law marks.
Visit www.navico.com/intellectual-property to review the global trademark rights and accreditations for Navico Group and other entities.

www.navico-commercial.com