


Hampton Bay

Entry Level Battery Doorbell Model WD-1120




Pack contents:

- Battery Chime Base.
- Wireless doorbell pushbutton & CR2032 Lithium coin cell battery.
- Adhesive pad, 2 screws and 2 wall plugs for mounting the doorbell pushbutton.

You will require:

- A small phillipshead and flathead screwdriver.

Parts List with Drawing




1. Push button
2. Front cover (front view)
3. CR 2032 Lithium coin cell battery
4. Battery holder
5. Front cover (back view)
6. Base
7. Screw holes

Installation Instructions


Please note: Positioning the pushbutton or door chime on or near metal structures or reinforced PVC doors or doorframes will reduce the transmission range.

Open the doorbell pushbutton as shown in Figure 1. Remove the front cover by inserting a flat blade screwdriver into the slot and twisting gently (A).




Install the battery (Refer to Figure 2)

Position the front cover as shown and slide the CR 2032 Lithium battery into the holder as shown, with the + side of the battery facing you.




Mount the Base and Install the Pushbutton (Figure 3)

Ensure the wall surface is clean and dry. Mount the base using either the double-sided tape on a smooth surface, or the screws and wall plugs provided. Do not mount the push on or near large metal objects, as this can block signals from the wireless pushbutton.





Hook the top of the pushbutton over the base as shown in Figure 4 and then press down at the base to snap in place.



Installing the Door Chime (Refer to Figure 5 & 6)

Remove the battery compartment cover by pressing the plastic catch as shown in Figure 5. Insert three LR6 (AA) alkaline batteries in the order shown in Figure 6. Refit the battery compartment cover.



Programming Doorbell Pushbutton Transmitters

The Chime will play all of the tones that are available when it is first powered up. Program the Front Doorbell pushbutton by pressing the Front Doorbell pushbutton until the base responds with a chime.

Note: A second Hampton Bay wireless pushbutton transmitter can be added for the back door if desired. Program the Back Doorbell pushbutton by pressing the Back Doorbell pushbutton until the base responds with a chime.

Master reset (Refer to Figure 7)

To Reset the Chime Programming, press and hold button B until the chime sounds. The chime will play all of the chimes available indicating that previous programs have been erased. Return to the Programming Doorbell Pushbutton Transmitters and repeat this section.




Figure 7

Note:

This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

The FCC require the user to be notified that any changes or modification made to this device that are not expressly approved by IQ Group may void the user's authority to operate the equipment. To comply with FCC RF exposure requirement, this device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

Specification

Range.....up to 100 ft.

Electrical Load.....1 x CR2032 Lithium Battery for Doorbell Pushbutton
3 x LR6 (AA) alkaline batteries

Troubleshooting

Check all batteries have been inserted correctly.

Doorbell pushbutton may be positioned out of range of the door chime. Move the pushbutton closer to the door chime.

Note: During the programming cycle, the transmission range may be reduced and will resume optimum range after 5 minutes.

A metallic object may be blocking the signal to the door chime from the pushbutton position. Experiment with the location of the door chime to see if you can move it to a more suitable place.

Battery in the pushbutton may need replacing.

See instruction for Installing the Battery.

Note: In cold conditions, poor location or environment, operating at maximum range it is advisable to replace the battery more frequently (i.e. every 12-18 months) to maintain optimum performance.

Your bell push and chime haven't been programmed. Reset the automatic programming of your chime and doorbell pushbutton by Pressing and holding down buttons B (Figure 7) for 5 seconds. The chime will sound all of the sounds available indicating the programming has been erased. Program the doorbell pushbutton following the installation instructions.

For any other problem, call 1-800-296-1869 between 8am and 5pm EST.

IQ America Two Year Warranty

This is a "Limited Warranty" which gives you specific legal rights. You may also have other rights which vary from state to state and province to province.

For a period of two years from the date of purchase, any malfunction caused by factory defective parts or workmanship will be corrected at no charge to you. To obtain a refund or a replacement, call 1-800-296-1869.

NOT COVERED: Repair service, adjustment and calibration due to misuse, abuse or negligence. Unauthorized service or modification of the product or of any furnished component will void this warranty. This warranty does not include reimbursement for inconvenience, installation, setup time, loss of use or unauthorized service.

This warranty covers only IQ America products and is not extended to other equipment and components that a customer uses in conjunction with our products.

This warranty is expressly in lieu of all other warranties, express or implied, including any warranty, representation or condition of merchant ability of that the products are fit for any particular purpose or use, and specifically in lieu of all special, indirect or incidental or consequential damages.

Repair or replacement shall be the sole remedy of the customer and there shall be no liability on the part of IQ America for any special, indirect, incidental or consequential damages, including but not limited to any loss of business or profit, whether or not foreseeable. Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Retain receipt for warranty claims.