Voice Message

Message waiting indicator on the idle screen indicates that one or more voice messages are waiting at the message center. The MESSAGE key LED lights up.

To listen to voice messages :

- 1. Press \bigcirc or the **Conn** soft key.
- 2. Follow the voice prompts to listen to your voice messages.

Customizing Your Phone

Call History

- 1. Press the **History** soft key when the phone is idle, press ♠ or ♠ to scroll through the list.
- 2. Select an entry from the list, you can do the following:
 - Press the **Send** soft key to call the entry.
 - Press the Delete soft key to delete the entry from the list.

If you press the Option soft key, you can also do the following:

- Select **Detail** to view detailed information about the entry.
- Select Add to Contacts to add the entry to the local directory.
- Select Add to Blacklist to add the entry to the blacklist.
- Select Delete All to delete all entries from the list.

Contact Directory

To add a contact:

- 1. Press the Dir soft key when the phone is idle, and then select All Contacts or the desired group.
- 2. Press the Add soft key to add a contact.
- 3. Enter a unique contact name in the ${\it Name}$ field, and enter the phone number in the proper field.
- 4. Press the Add soft key to accept the change.

To edit a contact:

- 1. Press the Dir soft key when the phone is idle, and then select All Contacts.
- 2. Press () or () to select the desired entry, press the **Option** soft key and then select **Detail** from the prompt list.
- 3. Edit the contact information.
- 4. Press the Save soft key to accept the change.

To delete a contact:

- 1. Press the Dir soft key when the phone is idle, and then select All Contacts.
- 2. Press (*) or (*) to select the desired entry, press the **Option** soft key and then select **Delete** from the prompt list.
- 3. Press the OK soft key when the LCD screen prompts "Delete selected item?".

Note: You can add contacts from call history easily. For more information, refer to Call History above.

Volume Adjustment

- Press ————— during a call to adjust the receiver volume of the handset/speakerphone/headset.
- Press ———— when the phone is idle to adjust the ringer volume.

Ring Tones

- $1. \ {\it Press the \ Menu} \ {\it soft key when the phone is idle, and then select \ {\it Settings-} > {\it Basic Settings-} > {\it Ring Tones.} \\$
- 2. Press or to select the desired ring tone.
- 3. Press the Save soft key to accept the change.

7

About us

Founded in 2001, Yealink, the global TOP 3 SIP phone provider and a leading provider of VoIP Phone and IP communication solutions, has been focusing on VoIP products characterized by reliable quality, easy deployment and affordable price for more than a decade. Today, customers from over 140 countries rely on Yealink as the backbone of global collaboration to extend the value of network communications.

More about Yealink

Since 2001, Yealink has continued to develop state-of-the art, hi-tech VoIP communication terminals that include IP video phones, IP phones and USB phones. With a worldwide market in more than 140 countries, the company has also established a first-class international service network.

Our priorities are quality, functionality, ease-of-use, customer support and competitive pricing. To provide new solutions for the future in this fast-evolving sector, Yealink's large, talented and highly-experienced VoIP R&D team is totally committed to the pursuit of excellence.

To date, we have passed more than 80 interoperability tests and meet certification requirements set by leading VoIP system and platforms. Yealink works in close partnership with T-Mobile, Telefonica, Portugal Telecom and other leading telecommunication service providers.



FCC Caution:

Any change or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.