



Using the Manuals

The following two manuals are included with your Caplio 500SE.

	<p>"Camera User Guide" (This booklet)</p> <p>This guide explains the usage and functions of the camera. It also explains how to install the provided software on your computer.</p> <p>* The "Camera User Guide" (English edition) is available from the provided CD-ROM as a PDF file.</p>
	<p>"Software User Guide" (PDF file)</p> <p>This guide explains how to download images from the camera to your computer and display and edit them on your computer.</p> <p>* The "Software User Guide" is available in the following folders on the provided CD-ROM.</p> <p>Each language has its own "Software User Guide" in the respective folder.</p> <pre> Caplio CD-ROM (D:) ├── Caplio Manual │ ├── English │ ├── English_Camera_Manual │ └── Japanese └── "Camera User Guide" (English edition) (PDF file) </pre> <p>To copy the Software User Guide onto your hard disk, copy the PDF file from the above folder directly to your hard disk.</p>

The camera is provided with the ImageMixer software that allows you to display and edit images on your computer. For details on how to use ImageMixer, click the [?] button on the ImageMixer window and see the displayed manual.

For more information on ImageMixer, contact the Customer Support Center below.

North America (Los Angeles)	TEL: +1-213-341-0163
Europe (U.K.)	TEL: +44-1489-564-764
Asia (Philippines)	TEL: +63-2-438-0090
China	TEL: +86-21-5450-0391


Business hours: 9:00 AM to 5:00 PM

Key Features



Rugged camera body stands up to water, dust and shocks


The camera body is water resistant (JIS protection grade 7, IEC IP67), dust resistant (JIS protection grade 6, IEC IP67) and shock resistant when dropped from a height of up to 1 meter.



Wide-angle zoom lens can capture wide-angle pictures


The camera comes with a wide-angle optical zoom (3.0 \times) lens for a wide shooting range of between 28 mm and 85 mm*. Add the optional wide conversion lens to extend the shooting range to 22 mm* for even wider angle shooting.

*Equivalent to that on a 35mm camera




Antiblur function minimizes blurring (P.63)

Turn on the antiblur function to raise the ISO setting and minimize blurring when shooting.




Built-in flash with a maximum range of 10 m (P.39)

The built-in flash has a maximum range of 10 m when used in wide-angle mode and 6.5 m when used in telephoto mode. This enables you to take a wider variety of pictures. You can also attach an external flash.




Power your camera in one of three ways (P.20)

You can power the camera using the optional rechargeable battery, AA alkaline or nickel-hydrogen batteries, or the optional AC adapter for convenient shooting anytime, anywhere.




Large LCD monitor and optical viewfinder

Depending on the subject and shooting conditions, you can use either the 2.5-inch LCD monitor or the real optical viewfinder to compose your shots. Taken pictures can be viewed on the large, bright LCD monitor.



ADJ. (Adjust) button enables easier camera operations (P.56)

The ADJ. button simplifies the camera setting procedures. It allows you to make adjustments with minimum steps for settings, such as the exposure compensation and white balance. You can also assign a function as required.



Take close-up shots 1 cm (5 mm from the very front of the camera) away (P.38)

The unsurpassed macro shooting function allows you to capture details from a very close distance at only approximately 1 cm (5 mm from the very front of the camera).




Skew correction mode helps straighten skewed images (P.40)

In skew correction mode, a rectangular object shot at an angle can be straightened to look as if it were shot squarely. With the simple touch of a button, you can straighten skewed images of objects such as a message board, a display panel, or a name card.



High sensitivity mode for shooting in dimly lit places (P.40)


The high sensitivity mode enables shooting in dark places. The LCD monitor becomes brighter, making it easier to compose the shot.



Direct printing without the use of a computer (P.98)

A Direct Print-compatible printer can be connected to the camera with the USB cable to directly transfer images to the printer. This allows for easy printing without using a computer.


You can also print reports and camera memos.



Camera memos enable easy sorting, searching and management of images

Load memo items preset with a computer and add them to shot still images. There are two types of camera memos: text and voice memos.

For details about camera memos, refer to the "Software User Guide" (PDF file P.24).



Bluetooth® function for wireless connectivity (P.154)


The integrated Bluetooth® function allows you to wirelessly send still images to a Bluetooth®-enabled computer and wirelessly print still images on a Bluetooth®-enabled printer.



Shoot with GPS information (P.180)

You can connect the camera to a Bluetooth®-enabled GPS receiver or external GPS module and shoot still images with latitude/longitude, position and distance information.

Shot images can be used with various GIS (Geographic Information System) applications.



Wireless LAN function (Only for Caplio 500SE-W) (P.191)

You can send images to wireless LAN-enabled computers. Send images as e-mail attachments or send them to the FTP server.

Access point

Contents

Using the Manuals.....	1
Key Features	2
Contents	5

Basic Operations

11

If you are using the camera for the first time, read this section.

Getting Ready	20
About the Battery	20
SD Memory Card (available in stores)	22
Charging the Rechargeable Battery (sold separately)	24
Loading the Battery and SD Memory Card	25
Using the AC Adapter (sold separately)	27
Turning the Power On/Off	29
Setting the Language	30
Setting the Date and Time	31
Basic Shooting	32
Holding the Camera	32
Shooting	34
Using the Zoom Function	37
Shooting Close-Ups (Macro Shooting).....	38
Using the Flash	39
Shooting with Optimal Settings According to Shooting Conditions	40
Shooting in CALS Mode.....	44
☺ Using the Self-Timer	45
Playing Back Images	46
Reviewing the Image You Just Took (Quick Review)	46
Viewing Your Images	47
Three-frame View/List View (Thumbnail Display)	48
Magnifying Images.....	50
Deleting Files.....	51
Deleting a File	51
Deleting All Files	51
Deleting Multiple Files at One Time	52
Changing the Display with the DISP. Button	54
Maximizing the LCD Monitor Brightness	54

Advanced Operations

55

Read this section when you want to learn more about the different camera functions.

1	Various Shooting Functions	56
	Using the ADJ. Button	56
	Settings by Mode	56
	Changing the Text Density (SCENE).....	57
	Shifting the AF Target (Macro).....	58
	Shooting Setting Menu	59
	Using the Menu	60
	Choosing Picture Quality Mode/Image Size (PIC QUALITY/SIZE).....	61
	Shooting with the Antiblur Function (ANTIBLUR).....	63
	Changing the Focusing Mode (FOCUS).....	64
	Manual Focus Shooting (MF).....	65
	Changing the Light Metering (PHOTOMETRY).....	67
	Changing the Edge Quality of Still Images (SHARPNESS)	68
	Shooting with Multi-Shot (S-CONT/M-CONT)	69
	Viewing an S-CONT or M-CONT Still Image in Enlarged Display Mode	71
	Setting the Color Depth (COLOR DEPTH).....	72
	Using Long Time Exposure (TIME EXPOSURE)	73
	Shooting Pictures Automatically at Set Intervals (INTERVAL)....	74
	Shooting a Still Image with Sound (IMAGE WITH SOUND).....	76
	Inserting the Date into a Still Image (DATE IMPRINT).....	77
	Changing the Exposure (EXPOSURE COMP.).....	78
	Using Natural and Artificial Lighting (WHITE BALANCE).....	79
	Setting the White Balance Manually (MANUAL SETTINGS).....	80
	Changing the Sensitivity (ISO SETTING).....	81
	Returning the Shooting Setting Menu Settings to their Defaults (RESTORE DEFAULTS).....	82
2	Shooting/Playing Back Movies	83
	Shooting Movies	83
	Setting the Frame Rate (FRAME RATE)	84
	Playing Back Movies.....	85
3	Recording/Playing Back Sound	86
	Recording Sound.....	86
	Playing Back Sound.....	87

4 Other Playback Functions 88

Playback Setting Menu.....	88
Using the Menu	88
Displaying Photos in Order Automatically (SLIDE SHOW)	89
Write-protecting Files (PROTECT).....	90
Protecting a File	90
Protecting All Files	91
Protecting Multiple Files at Once	92
Using a Printing Service (DPOF).....	93
Setting DPOF for the Displayed Still Image	93
Setting DPOF for All Still Images	94
Setting DPOF for Multiple Still Images.....	95
Changing the Image Size (RESIZE).....	96
Copying the Contents of the Internal Memory to an SD Memory Card (COPY TO CARD)	97

5 Direct Printing 98

Direct Print Function	98
Connecting the Camera to a Printer	99
Printing Still Images.....	100
Printing One or All Still Images	100
Printing Several Still Images	102
Printing Reports	104
Printing a Camera Memo on a Report	105

6 Changing Camera Settings 106

SETUP Menu	106
Using the SETUP Menu	107
Preparing the SD Memory Card (FORMAT [CARD])	109
Formatting the Internal Memory (FORMAT [INT. MEM.].....)	110
Adjusting the Brightness of the LCD Monitor (LCD BRIGHTNESS).....	111
Assigning a Function to the ADJ. Button (ADJ. BTN. SET.).....	112
Changing the Auto Power Off Setting (AUTO POWER OFF) ...	113
Changing the Beep Sound Setting (BEEP SOUND)	114
Changing the Beep Sound Volume (VOL. SETTINGS).....	115
Changing Image Confirmation Time (LCD CONFIRM.)	116
Changing File Name Settings (SEQUENTIAL NO.)	117
Setting the Date and Time (DATE SETTINGS).....	119
Changing the Display Language (LANGUAGE/言語)	120
Changing the Step Zooming Setting (STEP ZOOM).....	121

Displaying a Settings Change Warning (SHTG STGS WARNG.)	122
Changing the USB Setting (USB CONNECTION).....	123
Enlarging Icon Display (ENLGE PHOTO ICON)	125
Registering the Power-on Settings (REG. MY SETTINGS)	126
Changing the Startup Settings (START SETTINGS)	127

7 Downloading Images to Your Computer 128

For Windows	128
Using the Caplio Software CD-ROM.....	129
System Requirements for Using Caplio Software CD-ROM	133
Installing the Software Required for Handling the Camera and Images on Your Computer.....	134
Installing the DeskTopBinder Lite	136
Installing Other Software on Your Computer	138
Uninstalling the Software	140
For Macintosh.....	142
Using the Caplio Software CD-ROM.....	142
System Requirements for Using the Caplio Software CD-ROM	144
Installing the Software Required for Handling the Camera and Images on Your Computer (Mac OS 8.6 to 9.2.2)	145
Installing the Software Required for Handling the Camera and Images on Your Computer (Mac OS X 10.1.2 to 10.4.6).....	146
Uninstalling the Software	148
Connecting the Camera to Your Computer	149
Using the Caplio Software to Download Images.....	150
Downloading Images in Mass Storage Mode.....	151
Disconnecting the Camera from Your Computer.....	153

8 Using the Bluetooth® Function 154

About the Bluetooth® Function	154
Expanded Settings Menu	155
Using the Expanded Settings Menu.....	155
Sending Still Images to a Printer (PRINT).....	157
Printing One or All Still Images	157
Printing Several Still Images	159
Entering an Authentication Passkey for a Destination Device	162
Sending Still Images to Your Computer (FILE SEND)	166
Sending One or All Still Images	167
Sending Several Still Images	169
Sending Images in Shooting Mode (QUICK SEND MODE).....	171
Setting Up Quick Review Send (QUICK SEND MODE)	171
Using Quick Review Send	172

Making Advanced Bluetooth® Settings.....	175
Registering an Authentication Passkey for a Device (PASS KEY)	175
Changing the Number of Discoverable Devices (SEARCH COUNT)	176
Connecting to Several Devices at the Same Time (MASTER/SLAVE).....	177
Selecting the Size of Images to Be Sent (IMAGE FILE SIZE)	178
Automatically Deleting Sent Images (AUTO DEL).....	179

9 Using the GPS Function 180

About the GPS Function.....	180
Obtaining GPS Information	181
Manually Connecting to a Device (BT SERIAL).....	181
Automatically Connecting to a Previously Connected Device (BT AUTO CONN)	183
Displaying GPS Information	185
LCD Monitor Display	186
Shooting with GPS Information	187
Playing Back a Still Image with GPS Information	187
Advanced GPS Information Settings.....	188
Setting the Datum (GPS DATUM).....	188
Setting the Display Standard (GPS DISP MODE)	189
Locking the GPS Information (GPS LOCK)	190

10 Using the Wireless LAN Function (Only for Caplio 500SE-W) 191

About the Wireless LAN Function	191
Overview of Transfer Process via a Wireless LAN	192
Selecting the Communication Method (CHANGE COM).....	193
Making Advanced Wireless LAN Settings for Sending Files	194
Detailed Setups Tab Settings	196
Setting Up a Caplio-only FTP Server.....	199
Creating a Communication List and Transferring it to the Camera.....	202
Importing a Communication List from an SD Memory Card (READ COM SETTING)	205
Confirming and Editing the Destination Setting on the Camera.....	207
Sending Still Images, Movies, and Sound Files (FILE SEND).....	209
Sending One or All Files	210
Sending Several Files	212
Sending Files in Shooting Mode (Quick Review Send).....	214
Setting Up Quick Review Send (QUICK SEND MODE)	214
Using Quick Review Send	215

Specifying a Destination on the Camera Beforehand	219
Hiding the [SEND TO] Screen (SEND CONDITION)	219
Specifying a Destination (SEND TO)	220

11 Appendices 221

Troubleshooting	221
Error Messages	221
Camera Troubleshooting	225
Software and Computer Troubleshooting	230
Specifications	232
Number of Images That Can be Stored in Internal Memory/ SD Memory Card	235
Optional Accessories	236
Using a Wide Conversion Lens	236
Using the External Flash	237
Functions Whose Defaults are Restored When Camera is Turned Off	238
About Scene Mode	240
Shooting Setting Menu Items by Scene Mode	240
Using Your Camera Abroad	241
Cautions on Use	242
Care and Storage	244
Warranty and Servicing	246
Index	250

Basic Operations

If you are using the camera for the first time, read this section.


Packing List	12
Names of Parts	14
How to Use the Mode Dial ...	16
LCD Monitor Display	17
Getting Ready	20
Basic Shooting	32
Playing Back Images	46
Deleting Files	51
Changing the Display with the DISP. Button	54

Packing List

Open the package and make sure all the items are included.

Caplio 500SE

The serial number of the camera is provided on the bottom face of the camera.




USB Cable

Used to connect the camera to a computer or Direct Print-compatible printer.




Neck Strap



Note

Attaching the neck strap to the camera

Thread the small end of the strap through the strap eyelet on the camera and loop the ends as shown.




If you are using the camera for the first time, read this section.

Camera User Guide



(This booklet)

Warranty



Safety Precautions



Caplio Software CD-ROM


The provided software and the “Software User Guide” are included on this CD-ROM.




Optional Accessories

AC Adapter (AC-4d)


Used for power supply from a household outlet to the camera. Use this adapter for long periods of playback or when transferring images to a computer.



Rechargeable Battery (DB-43)



Battery Charger (BJ-2e)



Wide Conversion Lens (DW-5)

Soft Case (SC-500)

Rechargeable Battery Set (BS-3e)

Includes the rechargeable battery (DB-43) and battery charger (BJ-2e).

If you are using the camera for the first time, read this section.



Caution

Operations are not guaranteed when using a rechargeable battery or battery charger other than that specified in this manual.



Note


For the latest information about accessories, visit the Ricoh website at <http://www.ricohpmmc.com>.

Names of Parts


Camera

Front View

If you are using the camera for the first time, read this section.



	Item Name	Refer to
1	Shutter Release Button	P.34
2	Mode Dial	P.16
3	Flash	P.39
4	AF Window	-
5	Accessory Shoe	P.237
6	Viewfinder	P.32
7	Terminal Cover	P.99, 149
8	Lens	P.32
9	Flash Compensation	-
10	AF Auxiliary Light	-
11	USB Terminal	P.99, 149
12	AUX Terminal	-

Rear View


If you are using the camera for the first time, read this section.

	Item Name	Refer to
1	LCD Monitor	P.17
2	Auto Focus/Flash Lamp	P.35, 39
3	Viewfinder	P.32
4	Battery/Card Cover	P.25, 27
5	Power Button	P.29
6	[W] (Wide-angle)/[T] (Thumbnail Display) Button	P.37, 48
7	[T] (Telephoto)/[Q] (Enlarged View) Button	P.37, 48
8	[SCENE] Button	P.40
9	[FLASH] (Flash) Button	P.39
10	MENU/OK Button	P.60, 88, 107
11	[MACRO] (Macro) Button	P.38
12	[Q.R.] (Quick Review) Button	P.46
13	[P.] (Playback) Button	P.47
14	ADJ./MEMO Button	P.56
15	[DELETE] (Delete)/[T.S.] (Self-timer) Button	P.51, 45
16	DISP. Button	P.54
17	Tripod Screw Hole	P.232
18	Microphone	P.86
19	Speaker	P.85, 87




How to Use the Mode Dial

Turn the mode dial to the desired mode before shooting or recording.

- 1 Turn the mode dial to the symbol of the function you want to use.





Mode Dial Symbols and Descriptions

Symbol	Function	Description
	Still Image Mode	Allows you to shoot still images.
CALS	CALS Mode	Fixes [PIC QUALITY/SIZE] to [N1280] when shooting construction images.
	Movie Mode	Allows you to shoot movies with sound.
	Voice Memo Mode	Allows you to record sounds.

If you are using the camera for the first time, read this section.

LCD Monitor Display

Example of LCD Monitor Display when Shooting Pictures



Still Image Mode


	Item Name	Refer to		Item Name	Refer to
1	Flash	P.39	15	Color Depth	P.72
2	Macro Shooting	P.38	16	Exposure Compensation	P.78
3	Self-timer	P.45	17	ISO Setting	P.81
4	Mode Types	P.16, 40	18	Date Imprint	P.77
5	Recording Destination	P.22	19	Interval	P.74
6	Remaining Number of Still Images	P.235	20	Time Exposure	P.73
7	Picture Quality	P.61	21	Antiblur	P.63
8	Image Size	P.61	22	Battery Mark	P.19
9	Bluetooth® antenna, Wireless LAN antenna (Only for Caplio 500SE-W)	P.154 P.191	23	Camera Shake Warning Mark	P.33
10	Zoom Bar	P.37	24	Aperture Value	P.232
11	Focus	P.64	25	Shutter Speed	P.232
12	White Balance	P.79	26	Frame Rate	P.84
13	Photometry	P.67	27	Remaining Recording Time	P.235
14	Sharpness	P.68	28	Recording Time	P.235

If you are using the camera for the first time, read this section.

**Note**

- The number of remaining shots available may differ from the actual number of shots, depending on the subject.
- Movie and sound recording time and the maximum number of still pictures may vary depending on the capacity of the recording destination (internal memory or SD memory card), shooting conditions, and the type and manufacturer of the SD memory card.
- When the number of remaining shots is 10,000 or more, "9999" is displayed.

If you are using the camera for the first time, read this section.

Example of LCD Monitor Display During Playback




	Item Name	Refer to		Item Name	Refer to
1	Protect	P.90	8	Picture Quality	P.61
2	DPOF	P.93	9	Image Size	P.61
3	Mode Types	-	10	File No.	-
4	Playback Data Source	P.47	11	Battery Mark	P.19
5	Number of Playback Files	-	12	Date at Shooting	P.77 P.119
6	Total Number of Files	-	13	Recording Time or Lapsed Time	-
7	Setting at Shooting (Recording)	-	14	Indicator	-

**Note**

The LCD monitor may display messages to inform you of operational instructions or the camera's status while in use.





Battery Level Indication

A battery mark appears at the lower right of the LCD monitor to indicate the battery level. Recharge the battery before it is depleted or exchange with new batteries.

Battery Mark	Description
 Green	The battery is sufficiently charged.
	The battery level begins to drop. Recharging is recommended. Recharging the battery or exchanging with new batteries is recommended.
	The battery level is low. Recharge the battery. Recharge the battery or exchange with new batteries.



Caution

- If you are using nickel-hydrogen batteries, depending on the type of batteries and usage conditions,  may not appear, or  or  may instantaneously appear. Check your batteries beforehand.
- If you are using the AC adapter,  may appear. This does not indicate malfunction and you can continue to use the camera.

If you are using the camera for the first time, read this section.


Getting Ready

Turn the power on and get ready to shoot.



Note


- If you have already used this camera, make sure it is turned off before inserting or removing the battery.
- For information on how to turn the camera off, see P.29.



About the Battery

Rechargeable Battery DB-43 (optional)

This is a lithium-ion battery. It is economical because you can recharge it using the battery charger and use it over and over again. The battery lasts a long time, so it is convenient when traveling.



Note

The following types of batteries can also be used.

- **AA Alkaline Batteries (available in stores)**
You can obtain them anywhere, so they are convenient for travel. However, in a low-temperature environment the number of shots you can take will decrease. Warm the batteries before use. It is recommended that you use the rechargeable battery when using the camera for a long time.
- **Nickel-Hydrogen Batteries (available in stores)**
These batteries are economical because you can recharge and use them over and over again. Please use a battery recharger available in stores.

If you are using the camera for the first time, read this section.

**Number of shots you can take** -----

- Approximate number of shots you can take on a single charge

Battery Type	Number of Shots (Normal Mode)
Rechargeable Battery (DB-43)	approx. 400
AA Alkaline Batteries (available in stores)	approx. 80

- Based on CIPA standard (Temperature: 23 degrees Celsius, LCD monitor on, 30 seconds between shots, changing the zoom setting from telephoto to wide-angle or wide-angle to telephoto for each shot, 50% flash usage, turning the power off after each 10 shots).
- Set the camera to synchro-monitor mode to increase the number of shots you can take. (P.54)
- The number of shots is for reference only. If the camera is used for long periods of time for setting and playback, the shooting time (the number of shots) will decrease.

**Caution** -----

- The nickel-hydrogen batteries available in stores are not factory-charged. Charge them before use.
- When using nickel-hydrogen batteries, use only those batteries that have been charged together. Do not mix different types of batteries.
- The nickel-hydrogen batteries may be inert and consequently may not supply power immediately after they are purchased or when left unused for more than a month. In such a case, recharge the batteries two or three times before use. The batteries self-discharge with time even if the camera is not used, so recharge them before use.
- The life of an AA alkaline battery depends on the brand and the storage time from the date of production. In addition, the life of an AA alkaline battery becomes shorter at low temperatures.
- Other batteries, such as manganese dry cell and Ni-Cd, cannot be used.
- The battery may become very hot immediately after operation. Turn the camera off and leave it to cool down sufficiently before removing the battery.
- Please remove the batteries if you are not going to use the camera for a long period of time.
- Use of the rechargeable battery (DB-43) is recommended when using the Bluetooth® function or wireless LAN function (only for Caplio 500SE-W).
- If you want to use a lithium-ion battery, use the rechargeable battery (DB-43) made exclusively for this camera. Do not use a rechargeable battery other than that specified by Ricoh.

If you are using the camera for the first time, read this section.

SD Memory Card (available in stores)

You can store still images you have taken either in the camera's internal memory or on an SD memory card (available in stores). The internal memory capacity is 26 MB.


To record a lot of still images, movies or sounds at high resolutions, use a high-capacity SD memory card.



Where images are recorded


When no SD memory card is loaded, the camera records images to the internal memory; when an SD memory card is loaded, it records images to the SD memory card.

When no SD memory card is loaded



Records to the internal memory

When an SD memory card is loaded



Records to the SD memory card



Caution

- If an SD memory card is loaded, the camera will not record to the internal memory, even if the card is full.
- Take care not to get the contacts of the card dirty.




Write-protecting your images

Move the write-protection switch on the SD memory card to LOCK to prevent your still images from being accidentally erased or the card from being formatted. If you unlock the card (by returning the switch to its original position), it is once again possible to erase images and format the card.

It is recommended to move the write-protection switch to LOCK when you have some important data recorded.

Note that you cannot shoot images on a locked card because no data can be recorded to the card. Unlock the card before shooting.



If you are using the camera for the first time, read this section.



Note

- For information on switching between the SD memory card and internal memory during playback, see P.47.
- Movie and sound recording time and the maximum number of still pictures varies depending on the capacity of the SD memory card. (P.235)
- Before using a new SD memory card, be sure to format it with this camera. (P.109)
- When using an SD memory card previously used with another camera, be sure to back up any necessary data on the card before formatting it.
- An SD High-Capacity (SDHC) memory card cannot be used in this camera.

If you are using the camera for the first time, read this section.

Charging the Rechargeable Battery (sold separately)

The rechargeable battery needs to be charged before use.


If you are using the camera for the first time, read this section.

- 1** Insert the battery, making sure that the \oplus and \ominus markings on the battery match those on the battery charger.

- The battery label should face up.

- Caution** -----
- Be careful not to reverse the \oplus and \ominus sides.

- 2** Connect the electrical power cord to the battery charger and then plug the power cord into an outlet.



- Use the battery charger (BJ-2e) to recharge the battery.
- Charging starts, and the charger lamp indicates the progress, as shown below.
Once charging has finished, unplug the power cable from the power outlet.


Charger Lamp	Description
Lit red	Charging started
Lit green	Charging complete
Flashing	Battery charger or battery may be faulty (unplug the battery charger from the power outlet and remove the battery from the battery charger).


- Depending on the battery level, the charging time differs.

Rechargeable battery charging time	
DB-43	About 220 minutes (25 °C)

Loading the Battery and SD Memory Card


The rechargeable battery (DB-43) can be used to power this camera. This battery is convenient because the battery power lasts long and it can be used over and over again by recharging. If you have already used this camera, make sure it is turned off before loading the battery and card.

- 1** Turn the battery/card cover knob toward the  mark to open the cover.




- 2** Make sure the SD memory card is facing the right way and then push the card all the way in until it clicks.

- The rechargeable battery may be inserted first.




- 3** Insert the rechargeable battery.

- Lift the latch with the battery and insert the battery all the way into the battery compartment.
- When the rechargeable battery is loaded in place, it is locked with the latch.




Loading AA alkaline batteries (available in stores)

- Insert the batteries in the direction shown.
- Insert the top battery while using the battery to lift the latch.



If you are using the camera for the first time, read this section.

4 Close the battery/card cover and turn the knob toward the ⊖ mark.



If you are using the camera for the first time, read this section.

Removing the SD Memory Card

Turn the battery/card cover knob toward the ⊖ mark to open the cover. Push in the SD memory card and gently release to eject it. Pull the card out of the camera.

Removing the Rechargeable Battery

Turn the battery/card cover knob toward the ⊖ mark to open the cover. Press and release the latch. The battery will be ejected. Pull the battery out of the camera. Be careful not to drop the battery when removing it from the camera.

Removing the AA Alkaline Batteries

Turn the battery/card cover knob toward the ⊖ mark to open the cover. Press and release the latch. The batteries will be ejected. Pull the batteries out of the camera. Be careful not to drop the AA alkaline batteries when removing them from the camera.




Caution

- Close the battery/card cover and terminal cover securely. Water and dust may get inside the camera.
- Before opening or closing the battery/card cover or terminal cover, be sure to remove any water, sand or mud adhering to the camera, and avoid opening and closing the cover in places where such contaminants may get inside the camera.
- Remove the batteries if you are not going to use the camera for a long period of time. Store the removed batteries in a dry cool place.
- Make sure that the rechargeable battery and SD memory card are facing the right way when inserted into the camera. Inserting the rechargeable battery or SD memory card in the wrong direction and forcing close the battery/card cover may damage the camera, rechargeable battery or SD memory card.

Using the AC Adapter (sold separately)

When shooting or viewing still images for a long time, or when connecting to your computer, use of the AC adapter (sold separately) is recommended. If you have already used this camera, make sure it is turned off before loading the AC adapter coupler.




1 Turn the battery/card cover knob toward the  mark to open the cover.

2 Lift the latch with the AC adapter coupler and insert the coupler all the way into the battery compartment.

- Insert the AC adapter coupler all the way in until the latch locks.

3 Connect the AC cable to the AC adapter and then plug the power cord into an outlet.



If you are using the camera for the first time, read this section.

If you are using the camera for the first time, read this section.

**Caution**

- Be sure to attach the AC cable and plug the power cord into the outlet firmly.
- When you are not using the camera, unplug the AC adapter from the camera and the power outlet.
- While in use, if you detach the AC adapter or unplug the power plug from the outlet, data may be lost.
- Use the AC adapter with the battery/card cover open.
- When using the AC adapter, the battery level indication may not reach the full area.
- Do not use the AC adapter in a location where it may be exposed to water or lots of dust.

Disconnecting the AC Adapter

Make sure the camera is turned off before disconnecting the AC adapter.

1

Unplug the power plug from the outlet.

2

Press and release the latch. The AC adapter coupler will be ejected. Pull the coupler out of the camera.

3

Close the battery/card cover and turn the knob toward the ⊖ mark.

**Caution**


Before opening or closing the battery/card cover or terminal cover, be sure to remove any water, sand or mud adhering to the camera, and avoid opening and closing the cover in places where such contaminants may get inside the camera.

Turning the Power On/Off


To turn the power on:

1 Press the power button.

- After the start sound, the auto focus/flash lamp blinks for several seconds.




Using the Camera in Playback Mode

- Pressing the  (Playback) button for more than one second turns on the camera in playback mode, allowing you to start playback at once.





To turn the power off:

1 Press the power button.




Caution

- When the camera is turned on with the  (Playback) button, pressing the  (Playback) button again switches playback mode to recording mode.
- After the camera is turned on, it takes longer for the camera to become ready for shooting when using the flash than when not using the flash.



Auto Power Off

- If the camera goes unused for a set period of time, it will automatically turn itself off to save power. (Auto Power Off)
- The Auto Power Off setting can be changed. ( P.113)

If you are using the camera for the first time, read this section.

Setting the Language

When the power is turned on for the first time, the language setting screen appears (for the LCD monitor display language). After setting the language, go on to the date/time setting (for printing the date and time on your photos). You can shoot without these settings. However, be sure to set the language, and the date/time later. Use the SETUP menu for these settings.

If you are using the camera for the first time, read this section.


1 Turn the power on for the first time after purchase.

- The language selection screen appears.
- To skip language setting, press the MENU/OK button.

2 Press the ▲▼ buttons to select a language.

3 Press the MENU/OK button.

- The display language is set, and the date/time setting screen appears.



Note

For how to set the display language and date/time on the SETUP menu, see "Changing the Display Language (LANGUAGE/言語)" (P.120) and "Setting the Date and Time (DATE SETTINGS)" (P.119) in this guide.