


LiberatorMAX Industrial Wireless Headsets CSB-990MAX and CSB-992MAX USERS GUIDE

The LiberatorMAX Headset is used in conjunction with up to 7 additional headsets to form a wireless intercom network system.

The headset can operate on any one of 8 available channels – all headsets must be on the same channel for network intercom operation.

A Portable Radio can be connected to the Headset using a PRAC Cable. The Portable Radio will connect exclusively to that headset – other headsets in the group will not hear the received audio or be able to transmit over the radio.

LiberatorMAX Headset: Controls, Jacks, and LED



Questions or technical issues? Please call:
TECH SUPPORT: 650-965-8020 ext. 703

Setcom®
CORPORATION

3019 Alvin DeVane Blvd.
Ste. 560
Austin, TX 78741
Phone: (650) 965-8020

LiberatorMAX Headset
FRONT VIEW



LiberatorMAX Industrial Wireless Headsets CSB-990MAX and CSB-992MAX USERS GUIDE

LiberatorMAX Headset Operating Instructions

1) Power-Up

- Turn Volume Control clock-wise to turn on headset
- 1 to 3 audible beeps will indicate level of battery charge when headset is powered up (1 beep = low, 3 beeps = high)
- Headset will be on channel last used
- Headset will search for an existing “network” to join, or create its own network if one isn’t found
- LED Status Indicator will start Yellow, then turn Green
- Headset will begin sending/receiving audio within 6 seconds
- There will be a verbal (spoken) indication of the current channel
- Volume Control will adjust received audio volume
- As other headsets on same channel are turned on, they will join the network if on the same channel

2) Mic Mute / Channel Change Button

- To mute the headset microphone, press once on the Mic Mute button on the Right Cup, there will be two audible beeps, press again to un-mute, there will be two different beeps
- To change the current channel, press and hold the Mic Mute button for 5 seconds, the headset will increment the channel and give a verbal indication of the new channel number – continuing to hold down the button will advance the channel once each second
- NOTE: all headsets must be on the same channel to remain connected as a network (unless the operator is intending to join another network)

3) Portable Radio Use

- A Portable Radio can be attached to the headset with a suitable Setcom PRAC cable (determine by radio type)
- With Portable Radio OFF, attach adaptor to accessory port on radio, then plug smaller round connector into the jack on the Left Cup, then turn radio ON
- The radio’s volume control will set the received audio volume in the headset
- To transmit over the radio, press/hold the PTT button on the Left Cup, release it when transmission is completed

Questions or technical issues? Please call:

TECH SUPPORT: 650-965-8020 ext. 703



3019 Alvin DeVane Blvd.
Ste. 560
Austin, TX 78741
Phone: (650) 965-8020

(continued on next page)

LiberatorMAX Industrial Wireless Headsets CSB-990MAX and CSB-992MAX USERS GUIDE

LiberatorMAX Headset Operating Instructions

4) "Sleep" Mode

- After 15 minutes of no movement the headset will enter sleep mode to conserve battery power – the LED will turn off
- When the headset is again moved or picked up it will automatically wake up and resume normal operation
- If the headset is not going to be used for a long period of time, it is recommended to turn it off using the Volume Control knob – turn fully counter-clockwise until a click is heard

5) Charging

- To charge the headset, plug a power source into the Charging Jack on the Left Cup – the power source should provide 5 to 14 VDC, it can be a "wall-wart" power supply, or a cable providing 12V vehicle power (plug type is 5.5mm with a 2.1mm pin)
- While charging, the LED will be Orange, the headset can be used while charging
- A full charge from low battery condition takes approximately 6 hours

6) Operating Notes

- Once a network is established, all users will be able to hear and speak to each other within the operating range
- If one user moves out of range, the other users will not receive a notification, they simply will not be able to speak to or hear that user – if that user then moves back into range, communications with the network will automatically resume
- If a group of users (all on the same channel) splits into 2 groups by some of them moving out of range, they will form a new network, still on the same channel – if they then move back into range they will meld back into the original network
- Two networks can exist simultaneously without interference if they are on separate channels, but they will not be able to communicate with each other

Questions or technical issues? Please call:

TECH SUPPORT: 650-965-8020 ext. 703



3019 Alvin DeVane Blvd.
Ste. 560
Austin, TX 78741
Phone: (650) 965-8020

LiberatorMAX Industrial Wireless Headsets CSB-990MAX and CSB-992MAX USERS GUIDE

WARNINGS/CAUTIONS

Headset Volume

- Before wearing the headset, turn the volume down, then put on the headset and slowly turn the volume up to reach a comfortable level that provides clear communications.
- To prevent possible hearing damage DO NOT operate the headset at full volume for extended periods, the louder a sound is, the less time it takes to cause hearing damage.
- The headset provides hearing protection by attenuating loud sounds, however it is recommended that you do not turn up the volume so high that you cannot hear what is around you such as alarms, sirens, or warning signals.
- If you experience a warming sensation in either earcup, remove the headset immediately and contact Setcom customer service.

Rechargeable Battery Information

- This headset uses an internal Lithium-Ion Polymer Battery Pack – it is not user-serviceable or user-replaceable.
- The battery should not be subjected to temperatures outside these ranges:

Charging	Discharging	Storage
0 to +45°C	-20°C to +60°C	-10°C to +35°C
- The headset should not be left in an environment where high temperatures may be encountered (dashboard of a vehicle, near a heat source such as an engine compartment, heating duct, etc.).
- Care should be taken to not expose the headset to excessive shock, or force that could crush or shatter the ear cups, as this may puncture or rupture the battery.



3019 Alvin DeVane Blvd.
Ste. 560
Austin, TX 78741
Phone: (650) 965-8020

Questions or technical issues? Please call:

TECH SUPPORT: 650-965-8020 ext. 703

LiberatorMAX Industrial Wireless Headsets
CSB-990MAX and CSB-992MAX
USERS GUIDE

REGULATORY NOTICES

FCC Rules

FCC Compliance Statement (Part 15.19)

This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC Warning (Part 15.21)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC Rules

IC RF Exposure Statement / Déclaration d'exposition d'IC RF

This device meets the IC requirements for RF exposure in public or uncontrolled environments.

Cet appareil est conforme aux conditions de la IC en matière de RF dans des environnements publics ou incontrôlée.

The antenna(s) used for this transmitter must be used to provide a separation distance of at least 5 cm from all persons.

La ou les antennes utilisées pour cet émetteur doivent être utilisées de manière à assurer une distance de séparation d'au moins 5 cm de toute personne.

This portable transmitter with its antenna complies with FCC/IC
RF exposure limits for general population / uncontrolled exposure.



3019 Alvin DeVane Blvd.
Ste. 560
Austin, TX 78741
Phone: (650) 965-8020

Questions or technical issues? Please call:

TECH SUPPORT: 650-965-8020 ext. 703

LiberatorMAX Industrial Wireless Headsets
CSB-990MAX and CSB-992MAX
USERS GUIDE

FCC Part 15 Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.



3019 Alvin DeVane Blvd.
Ste. 560
Austin, TX 78741
Phone: (650) 965-8020

Questions or technical issues? Please call:

TECH SUPPORT: 650-965-8020 ext. 703