




User Guide

AirTight Management Console
Version 7.1 Update 5



This page is intentionally left blank

END USER LICENSE AGREEMENT

Please read the End User License Agreement before installing AirTight Management Console/AirTight Wi-Fi/AirTight WIPS. The End User License Agreement is available at the following location <http://www.airtightnetworks.com/fileadmin/pdf/AirTight-EULA.pdf>.

Installing AirTight Management Console/AirTight Wi-Fi/AirTight WIPS constitutes your acceptance of the terms and conditions of the End User License Agreement.

DISCLAIMER

THE INFORMATION IN THIS GUIDE IS SUBJECT TO CHANGE WITHOUT ANY PRIOR NOTICE. AIRTIGHT® NETWORKS, INC. IS NOT LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THIS PRODUCT.

THIS PRODUCT HAS THE CAPABILITY TO BLOCK WIRELESS TRANSMISSIONS FOR THE PURPOSE OF PROTECTING YOUR NETWORK FROM MALICIOUS WIRELESS ACTIVITY. BASED ON THE POLICY SETTINGS, YOU HAVE THE ABILITY TO SELECT WHICH WIRELESS TRANSMISSIONS ARE BLOCKED AND, THEREFORE, THE CAPABILITY TO BLOCK AN EXTERNAL WIRELESS TRANSMISSION. IF IMPROPERLY USED, YOUR USAGE OF THIS PRODUCT MAY VIOLATE US FCC PART 15 AND OTHER LAWS. BUYER ACKNOWLEDGES THE LEGAL RESTRICTIONS ON USAGE AND UNDERSTANDS AND WILL COMPLY WITH US FCC RESTRICTIONS AS WELL AS OTHER GOVERNMENT REGULATIONS. AIRTIGHT IS NOT RESPONSIBLE FOR ANY WIRELESS INTERFERENCE CAUSED BY YOUR USE OF THE PRODUCT. AIRTIGHT NETWORKS, INC. AND ITS AUTHORIZED RESELLERS OR DISTRIBUTORS WILL ASSUME NO LIABILITY FOR ANY DAMAGE OR VIOLATION OF GOVERNMENT REGULATIONS ARISING FROM YOUR USAGE OF THE PRODUCT, EXCEPT AS EXPRESSLY DEFINED IN THE INDEMNITY SECTION OF THIS DOCUMENT.

LIMITATION OF LIABILITY

AirTight Networks will not be liable to customer or any other party for any indirect, incidental, special, consequential, exemplary, or reliance damages arising out of or related to the use of AirTight Wi-Fi, AirTight WIPS, AirTight Cloud Services, and AirTight devices under any legal theory, including but not limited to lost profits, lost data, or business interruption, even if AirTight Networks knows or should have known of the possibility of such damages. Regardless of the cause of action or the form of action, the total cumulative liability of AirTight Networks for actual damages arising out of or related to the use of AirTight Wi-Fi, AirTight WIPS, AirTight Cloud Services or AirTight devices will not exceed the respective price paid for AirTight Wi-Fi, AirTight WIPS, AirTight Cloud Services, or AirTight devices. Copyright © 2013-2015 AirTight® Networks, Inc. All Rights Reserved.

Powered by Marker Packet™, Active Classification™, Live Events™, VLAN Policy Mapping™, Smart Forensics™, WEPGuard™ and WPAGuard™. AirTight Networks and the AirTight Networks logo are trademarks and AirTight is a registered trademark of AirTight Networks, Inc.

This product contains components from Open Source software. These components are governed by the terms and conditions of the GNU Public License. To read these terms and conditions visit <http://www.gnu.org/copyleft/gpl.html>.

Protected by one or more of U.S. patent Nos. 7,002,943; 7,154,874; 7,216,365; 7,333,800; 7,333,481; 7,339,914; 7,406,320; 7,440,434; 7,447,184; 7,496,094; 7,536,723; 7,558,253; 7,710,933; 7,751,393; 7,764,648; 7,804,808; 7,856,209; 7,856,656; 7,970,894; 7,971,253; 8,032,939; and international patents: AU 200429804; GB 2410154; JP 4639195; DE 60 2004 038 621.9; and GB/NL/FR/SE 1976227. More patents pending. For more information on patents, please visit: www.airtightnetworks.com/patents

Table of Contents

About This Guide	1
Intended Audience.....	1
Product and Documentation Updates	1
Contact Information	1
Introduction.....	3
AirTight Management Console Configuration	7
Configure Language Setting.....	7
Set System Language.....	7
Set SSID encoding.....	7
Copy Language Setting to Another Server	8
Configure Time Zone and Tag for Location.....	8
Set Time Zone	8
Edit Time Zone.....	8
Set Location Tag.....	9
User Management	9
Configure Password Policy.....	12
Configure Account Suspension Setting	13
Configure Login Parameters.....	14
User Authentication	16
Configure LDAP Server Parameters.....	16
Configure RADIUS Parameters	18
Configure Parameters for Certificate-based authentication.....	20
Wireless Intrusion Prevention System.....	22
Manage Authorized WLAN Policy.....	23
Configure AP Auto-classification Policy.....	25
Configure Client Auto-classification Policy	26
Intrusion Prevention	30
Activate Intrusion Prevention for Location	32
Import Device List	33
Manage Banned Device List.....	35
Manage Hotspot SSIDs	36
Manage Vulnerable SSIDs	38
Manage Smart Device Types	39
Manage WiFi Access.....	41
Manage SSID Profiles.....	41
Manage Mesh Profiles	82
Configure Event Notification	87

Activate Event Generation for Location	88
Configure Email Recipients	89
Configure Device - Server Communication Settings.....	89
Use Key for Device - Server Communication	89
Use Passphrase for Device - Server Communication	89
Reset Communication Key	89
Manage Policy Templates	90
Add Policy Template	90
Edit Policy Template	91
Search Policy Template	92
Copy Policy Template to Another Location	93
Save Policy Template with a Different Name	93
Print Policy Template List	93
Delete Policy Template	93
Manage Authorized WLAN Policy	94
Configure Authorized WLAN Policy	95
Edit Authorized WLAN Policy	95
View High Availability Status for Server	96
View/Upgrade License Details	97
Manage Look and Feel of Reports	98
Customize Report Header Text	98
Customize Summary Table	98
Customize Section Results.....	99
Restore Default Look and Feel Settings.....	99
Copy Reports Look and Feel Settings to Another Server.....	99
Configure NTP	100
Check Time Drift between AirTight server and NTP server.....	100
Synchronize AirTight Server Time with NTP Server.....	100
Disable NTP	100
Configure RF Propagation Settings.....	100
Restore RF Propagation Defaults.....	102
Copy RF Propagation Setting to Another Server.....	102
Configure Live RF View Setting	103
Restore Default Live RF View Settings.....	103
Copy Live RF View Setting to Another Server.....	103
Configure Location Tracking.....	104
Restore Location Tracking Configuration Defaults	104
Copy Location Tracking Configuration to Another Server	104
Manage Auto Location Tagging	105

Restore Auto Location Tagging Defaults	105
Copy Auto Location Tagging Settings to Another Server	106
Set up and Manage Server Cluster	107
Benefits of Server Cluster	107
Create and Manage Server Cluster	108
Manage Child Servers from Parent Server in Server Cluster	115
Manage Vendor OUIs	119
Add Vendor or MAC Prefix	119
Delete Vendor or MAC Prefix	119
Manage Device Template.....	119
Customize Policy/Device Template for Location	121
Revert to Inherited Device Template	121
Add Device Template.....	122
Edit Device Template.....	128
Search Device Template	128
Copy Device Template.....	128
Print Device Template List for Location	129
Delete Device Template.....	129
Configure SMTP Settings	129
Restore SMTP Configuration Defaults.....	130
Test SMTP Settings	131
Copy SMTP Configuration to Another Server	131
View System Status.....	131
Start/Stop Server	132
Upgrade Server	132
Configure Auto Deletion Settings	133
Copy Auto Deletion Settings to Another Server	134
Manage Audit Log Settings	135
Set Duration for Audit Log Download	135
Download Audit Logs	135
Restore Default User Action Log Download Settings	135
Copy Audit Log Settings to Another Server	136
Configure Integration with Enterprise Security Management Servers	137
Syslog Integration	137
Arcsight Integration	138
SNMP Integration.....	140
Manage WLAN Integration	142
WLAN Integration.....	142
Manage Integration with Aruba Mobility Controllers	142

AirTight Management Console User Guide

Configure Integration with HP MSM Controller	145
Manage Integration with Cisco WLC	148
Manage Integration with Meru	151
Manage AirTight Mobile Clients	152
AirTight Mobile Settings	152
Manage AirTight Mobile Clients	153
Add AirTight Mobile Group Manually	157
Edit AirTight Mobile Group	157
Attach Policy to AirTight Mobile Group	158
Overwrite Existing Policy for AirTight Mobile Group	158
Detach Policy from AirTight Mobile Group	158
View AirTight Mobile Group Policy in HTML Format	158
View AirTight Mobile Group Policy in XML Format	159
Activate Automatic Client Grouping	159
Apply Default Policy to New Groups	159
Print List of AirTight Mobile Groups for Location	159
Delete AirTight Mobile Group	160
Dashboard	161
Add a page to dashboard	161
Delete a page from dashboard	162
Print dashboard page	162
WIPS Widgets	162
Network Widgets	163
Client Widgets	165
Access Point Widgets	165
Devices	167
AirTight Devices	167
Device Properties	168
View Visible LANs	173
View Visible APs	173
View Visible Clients	173
View Active APs	173
View Active Clients	173
View AirTight Device Events	173
View Channel Occupancy	173
View Interference	174
View Mesh Network Links	174
Search AirTight Devices	174
Sort AirTight Devices	174

Change Location.....	174
Print AirTight Device Information for Location	174
Reboot Device	175
Troubleshoot Device	175
Upgrade or Repair Device	178
Enable Pagination for AirTight Device Listing and Set Page Size	178
Disable Pagination for AirTight Device Listing.....	180
Add Custom Filter	180
Edit Custom Filter	180
Delete Custom Filter	181
Delete Device.....	181
Monitor Clients.....	181
View Client Properties.....	183
View Recently Associated APs/Ad hoc networks	185
View Events related to Client.....	185
View Client Retransmission Rate Trend.....	185
View Devices Seeing Client.....	185
View Client Average Data Rate	186
View Client Traffic.....	186
Change Client Location.....	186
Quarantine Client	186
Disable Auto Quarantine/Exclude Device from Intrusion Prevention Policy.....	186
Add to banned list	187
Classify / Declassify as Smart Device	187
Change Client Category.....	187
Reset Data Transmitted by Client.....	187
Locate Client	187
View Recently Probed SSIDs	187
Troubleshoot Client.....	188
Debug Client Connection Problems.....	191
Download Connection Log.....	192
Delete Connection Log History	193
Enable Pagination for Client Listing and Set Page Size.....	194
Disable Pagination for Client Listing	194
Add Custom Filter	194
Edit Custom Filter	195
Delete Custom Filter	195
Print Client List for Location	195
Delete Client	196

Spectrogram	196
Monitor Access Points (APs)	196
View AP Properties	198
View Recently Associated Clients	201
View AP Utilization	201
View AP Associated Clients	202
View AP Traffic	202
View AP Average Data Rate	202
View Devices Seeing AP	202
View AP Events	202
Change AP Location	202
Locate AP	203
Quarantine an AP	203
Change AP Category	203
Disable Auto Quarantine	203
Add to banned list	203
Sort APs	203
Filter AP Details	204
Search APs	204
Enable Pagination for AP Listing and Set Page Size	204
Disable Pagination for AP Listing	205
Add Custom Filter	205
Edit Custom Filter	205
Delete Custom Filter	206
Print AP List for Location	206
Merge APs	206
Split AP	207
Troubleshoot AP	207
Delete AP	210
Monitor Networks	211
Manage Locations and Location Layout	215
Define Location Tree	215
Add Location	217
Edit Location	217
Move Location	218
Delete Location	218
Search Locations	218
Add Layout	218
Edit Layout	219

Delete Layout	220
Show / Hide Location List	220
Show/Hide Devices on Location Layout	220
Place Devices/Locations on Location Layout	220
Remove Devices/Locations from Location Layout	221
View RF Coverage / Heat Maps	221
View AP Coverage	222
View AP Coverage by RSSI Value	222
View Sensor Coverage	222
View AP Link Speed	223
View AP Channel Coverage	223
Calibrate RF Views	223
Zoom in / Zoom out Layout	224
Adjust the Layout Opacity	224
Add Note	224
Edit Note	225
Move Note	225
Hide Notes	225
Show Notes	225
View Mesh Topology	226
Hide Mesh Topology	226
View and Manage Events	227
View Events for Location	228
View Deleted Events for Location	228
Change Event Location	228
Acknowledge Event	229
Turn on Vulnerability Status for Event	229
Turn off Vulnerability Status for Event	229
Mark Event as Read	229
Mark Event for Deletion	229
Enable Pagination for Event Listing and Set Page Size	230
Disable Pagination for Event Listing	230
Add Custom Filter	230
Edit Custom Filter	231
Delete Custom Filter	231
Print Event List for Location	231
Forensics	233
View AP based /Client based Threat Details	233
View Event Summary	234

AirTight Management Console User Guide

View Participating Devices and Quarantine Status	234
Locate Participating Device	235
View Administration Action Logs for Event	236
Acknowledge Event	236
Change Location of the Event	236
Turn Vulnerability On/Off	237
Print Event List for Location	237
Mark Event for Deletion	237
Mark Event as Read	237
Show/Hide Deleted Events	238
Reports	239
Analytics	248
Manage Report Archive	250
Fetch Archived Report	251
Rename Archived Report	251
Print Archived Report List for Location	251
Delete Archived Report	251
Schedule Report Generation	251
Send report by e-mail	255
Archive report	255
View Report Schedules	255
Glossary of Icons	257

About This Guide

The *AirTight Management Console User Guide* explains how to configure and manage the AirTight Management Console .

Important! Please read the EULA before installing AirTight WIPS or AirTight Wi-Fi. Installing AirTight WIPS or AirTight Wi-Fi constitutes your acceptance of the terms and conditions of the EULA mentioned above in this document.

Intended Audience

This guide is intended for anyone who wants to configure and use AirTight WIPS or AirTight Wi-Fi or use AirTight Cloud Services.

Product and Documentation Updates

To receive important news on product updates, please visit our website at <http://www.airtightnetworks.com>.

We continuously enhance our product documentation based on customer feedback. To obtain a latest copy of this document, visit <http://www.airtightnetworks.com/home/support.html>.

Contact Information

AirTight® Networks, Inc.
339 N, Bernardo Avenue, Suite #200,
Mountain View, CA 94043
Tel: (650) 961-1111
Fax: (650) 963-3388

For technical support, send an email to support@airtightnetworks.com

Introduction

AirTight Management Console is a HTML 5 based user interface using which you can configure and monitor AirTight WIPS and/or AirTight Wi-Fi server to access the AirTight Cloud Services.





HTML 5 makes AirTight Management Console compatible with most browsers and operating systems.

AirTight Management Console is intuitive and easy to use. It can be configured with ease to suit your WIPS and/or Wi-Fi needs.

The Console is divided into 7 sections - Dashboard, Locations, Devices, Events, Forensics, Configuration, and Reports.

AirTight Management Console can be configured from the **Configuration** section. You can define and manage users, configure and manage WIPS settings, Wi-Fi access settings, integration settings for WLAN, integration settings for enterprise security management servers etc from the configuration section.

The **Dashboard** section provides a graphical view of the WIPS and/or Wi-Fi implementation. It offers you the flexibility to choose from a good number of graphs related to the access points, clients on your wireless network, as well as the networks detected by WIPS sensors. Details of wireless threats to the network can be seen on the WIPS widgets.

Apart from the pie chart or bar graph representation, the widget data can be viewed as a tabular representation by clicking the  icon present on the top of widgets. You can alternate between tabular view and pie chart/bar graph view. This means that if you are in the pie/graph view, you will see the  icon. If you are in the table view, you will see the  or  icon, depending on whether the alternate view is represented as a pie chart or bar graph. The widget data is presented in the last-viewed format when you log in to AirTight Management Console the next time.

AirTight Management Console facilitates the creation of locations. These locations could be various buildings in your campus or the different floors or levels in your office space. You can create and manage your retail or office locations using the **Locations** section. You can attach a layout to each floor in the office space. You can then define WIPS / Wi-Fi policies specific to these locations.

All APs, AirTight devices, sensors, smart devices are seen under the **Devices** section. Apart from the actual devices, the devices section also displays a list of networks detected by the WIPS sensors.

The **Events** section displays the events detected by the WIPS implementation.

The **Forensics** section lists AP-based threats and client-based threats in a user friendly format. You can drill down into the wireless threats using the forensics section.

The **Reports** section facilitates generation of various built-in and custom reports. These reports comprise various compliance reports and reports related to devices in the network and events occurring in the network. You can schedule reports and generate analytics data using the Reports section.

Following are the salient features of the AirTight Management Console.

- **Intuitive, portable and easy-to-use HTML5 UI**

HTML5 makes AirTight Management Console compatible with most browsers and operating systems. It can be operated using tablets and other smart devices as well. The interface is intuitive and can be used and configured without much effort.

- **Fully user-customizable dashboards and screens**

The dashboard offers you the flexibility to choose from a good number of graphs displaying access point, client, network, and WIPS statistics.

Graphs are seen in widgets. You can have multiple dashboards on the console. Each dashboard can have multiple widgets based on your requirement, with widget repetition allowed.

The widget classification is very intuitive. The widgets are classified as network widgets, access point widgets, client widgets and WIPS widgets.

In all other sections of the UI, you can filter the information or columns visible in the respective section, based on your requirement.

You also have the option to view information in various text and graphical format in some of the sections. For example, the Forensics section displays information in text and pie chart formats. In the Reports section, you can customize the reports as required. Standard compliance reports are also available.

You can customize filters on device and event listings under **Devices** and **Events** respectively. You can add, edit and delete custom filters on device and event listings. You can define multiple filters on devices and events listings and save them. These will be retained until you delete them. When you apply a filter to device or event listing during a login session, the filtered list is retained till the end of the session.

- **Innovative drill down with navigation trail on any event, chart or device**

AirTight Management Console provides a unique feature with which you can delve deeper or drill down to events or devices from any section of the console where they are visible. The devices and events are seen as links across AirTight Management Console. You can click on the link to view the details of the respective event or device and the related devices or events. You can also take the required actions if you have the privilege to take those actions. Thus, you can hop across different sections by clicking the links for devices and events. When you navigate across pages in this way, a navigation trail is displayed at the top of the currently viewed page or screen. This is extremely useful for you to understand the path you have taken to drill down to the desired page. The navigation trail also makes it convenient for you to navigate back to one of the screens or pages in the navigation trail.

See the image below for a sample drill down with a navigation trail.

The screenshot displays the 'Details' view of an event in the AirTight Management Console. At the top, a navigation trail shows the relationship between entities: 'AirTight_41:50:70' (Observed by) and 'AirTigh_0:51:80' (Has Event), leading to 'ID: 6068'. A callout indicates this line 'indicates the relation between the related entities'. Below this, the event details for AP [AirTight0_0A2:28:20] are shown, including MAC address, protocol, channel, SSID, security setting, vendor, location, severity level, and start/end times. A 'Recommended Action' section is highlighted with a red box and a callout 'Take a required action'. Below the details is a table of 'Sub-events' with columns for 'Sub-events', 'Time', and 'Devices in Selected Sub-event'. The first row shows 'Event Started.' at 'Oct 03, 2013 07:06:40 PM' with device 'AirTighA1112:28:201'. A callout points to this device ID with the text 'click a related link to drill down further'. Other devices in the event include 'AirTigh_0:51:80'. A 'Close' button is at the bottom.

- **Rich Visualization of Heat maps**

You can view radio frequency heat maps in various views. The AP coverage view is useful to find out the available signal strength at each point. The sensor coverage view enables you to view the detection and prevention zones of visibility for selected sensors. The color-coding scheme used enhances the readability of the heat maps.

- **Hierarchical management architecture ideal for geographically distributed sites**

AirTight Management Console provides for hierarchical management of geographically distributed sites. You can create a hierarchy of locations or a location tree. Each location folder could represent a country and a child location folder could represent a state. These location folders could then have city locations as child location folders. One of more buildings in the city office campus can be represented as child location folders under the respective city location folders. Individual floors or levels in the office space can be represented by location floors under the location folders that represent buildings.

You can then define Wi-Fi/WIPS policies specific to each location. You can apply a common policy to the location folders. These policies are automatically inherited by the child locations. This makes management of related locations easy and convenient at the click of a button.

- **Role-based administration and extensible configuration framework**

The administration and operation of the Wi-Fi or WIPS solution through AirTight Management Console is role-based. A user has restricted access to one or more locations that he is associated with. He is able to view information and configure the console related to these locations only. Information from other locations are not visible to him. A user is able to perform operations based on his role. AirTight Management Console provides four distinct user roles-superuser, administrator, operator and viewer.

- **Configuration Wizard**

When a user logs in to AirTight Management Console, and navigates to Dashboard or Events for the first time, a configuration wizard guides the user on how to use these functionalities. The wizard is functional only during the first time view.

AirTight Management Console Configuration

AirTight Management Console needs to be configured appropriately for use, before it can start monitoring and/or protecting the network. Click **Configuration** to view the various options to configure in AirTight Management Console.

The Configuration page displays various categories - **Device Configuration, WIPS, User Accounts, Events** and **System Settings, AirTight Mobile, ESM Integration**.

Device Configuration: Configure and manage the SSID profiles using **Device Configuration>SSID Profiles**. The SSID profiles can then be attached to the device templates. Configure and manage the device templates using **Device Configuration>Device Template**. These device templates can then be applied to various devices.

WIPS: Configure and manage the wireless intrusion prevention parameters using **WIPS**.

User Accounts: User management, password management, LDAP, RADIUS configuration, certificate configuration, account suspension management is done using **User Accounts**.

Events: Configure and manage event related settings, e-mail notification on occurrence of certain critical events using **Events**.

System Settings: Configure and manage AirTight server-related settings using **System Settings**.

AirTight Mobile: Configure AirTight Mobile integration settings using AirTight Mobile.

ESM Integration: Configure settings for integration with Enterprise Security Management software using **ESM Integration**. AirTight Management Console integrates with SNMP, Syslog and Arcsight.

Configure Language Setting

Define the system language and the SSID encoding using the **Configuration>Language Setting** option. This setting is used to set the language for email communication, Syslog messages etc. You can copy language setting from one server to another when the servers are part of the same server cluster.

Set System Language

The system language is the default language that the system will use to communicate via emails, syslog messages etc. If you want to use a language other than English as the system language for AirTight Management Console, the language of your choice should be defined under Language Setting. The default value for **System Language Preference** is English.

Set SSID encoding

Parameters like SSID, when configured on the AP using page encoding (either non-English native window or using a language pack), appear garbled if the page encoding does not match the encoding selected here.

Select the appropriate SSID encoding commonly used in your region, in order to correctly see the local language SSIDs in the system.

The default value for **SSID encoding** is UTF-8. To select a different SSID encoding, do the following.

1. Go to **Configuration>System Settings>Language Setting**.
2. Under **SSID Encoding**, select the required SSID encoding.
3. Click **Save** to save the new SSID encoding.

Copy Language Setting to Another Server

You can copy the language setting from one server to another server when both servers are part of the same server cluster. You can copy language setting from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy language settings, do the following.

1. Go to **Configuration>System Settings>Language Setting** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which language setting is to be copied.
4. Select the server to which the ;language setting is to be copied.
5. Click **OK** to copy the language setting,

Configure Time Zone and Tag for Location

Set the appropriate time zone for the selected location using the **Configuration>System Settings>Location Specific Attributes** page. The time zone settings are specific to individual locations and cannot be inherited from the parent location. You need administrator privileges to configure the location time zone for a location.

The time zone settings help in accurate analytics. Make sure to select the correct time zone for the selected location.

Note that you cannot set a time zone for a location floor because a location floor represents a floor location in the organization premises. The time zone set for the immediate parent location folder of a location floor applies to the location floor.

In case you do not set the time zone for a location folder, the analytics data will show the server time zone in the fields where local time zone is shown.

Set Time Zone

To set the time zone for a location, do the following.

1. Go to **Configuration>System Settings>Location Specific Attributes**.
2. Select the location for which you want to set the time zone.
3. Select the time zone.
4. Click **Save** to save the new time zone. Alternatively, if you want to cancel the operation, click **Cancel**.

Edit Time Zone

To edit the time zone for a location, do the following.

1. Go to **Configuration>System Settings>Location Specific Attributes**.
2. Select the location for which you want to edit the time zone.
3. Select the new time zone.

4. Click **Save** to save the new time zone. The changed time zone is applied recursively to all the child location folders.

Set Location Tag

A location tag is the location identifier that could be appended to the circuit ID when DHCP Option 82 is enabled for an SSID profile configured for this location.

If '%l' is used in the circuit ID, the AP replaces it with the location tag.

To set the location tag for a location, do the following.

1. Go to **Configuration>System Settings>Location Specific Attributes**.
2. Select the location for which you want to set the location tag.
3. Enter the location tag.
4. Click **Save** to save the changes.

User Management

There are four types of users in AirTight Wi-Fi/AirTight WIPS. They are Superuser, Administrator, Operator and Viewer.

You can manage user-related operations through Configuration>User Accounts>Users. You can add, edit, and delete users. You can search users, and print a list of users defined at a location.

You need administrator privileges to manage users in AirTight Management Console.

The following table details the role-wise rights in AirTight Management Console.

Operations	User Roles			
	Superuser	Administrator	Operator	Viewer
User account management				
Set or modify identification and authentication option (Password only, Certificate only, Certificate and Password, Certificate or Password)	Yes	No	No	No
Add and delete users	Yes	No	No	No
View and modify properties of any user (User Management screens)	Yes	No	No	No
Define password strength, account locking policy, maximum concurrent sessions for all users	Yes	No	No	No
View and modify User Preferences (email, password, session timeout)	Yes (self only)	Yes (self only)	Yes (self only)	Yes (self only)
User actions audit				
Download user actions audit log	Yes	No	No	No
Modify user actions audit lifetime	Yes	No	No	No
System settings and operating policies				
Modify system settings and operating policies (all settings under Configuration tab other than User Management, Logs, Login configuration)	Yes	Yes	No	No
Events, devices and locations				
View generated events	Yes	Yes	Yes	Yes
Modify and delete generated events	Yes	Yes	Yes	No

AirTight Management Console User Guide

View devices	Yes	Yes	Yes	Yes
Add, delete, and modify devices (APs, Clients, Sensors)	Yes	Yes	Yes	No
View locations	Yes	Yes	Yes	Yes
Add, delete, and modify locations	Yes	Yes	Yes	No
Calibrate location tracking	Yes	Yes	Yes	No

Reports

Add, delete, modify Shared Report	Yes (all)	Yes (only self created)	Yes (only self created)	No
Generate Shared Report	Yes	Yes	Yes	Yes
Schedule Shared Report	Yes	Yes	Yes	No
Add, delete, modify, generate, schedule My Report	Yes (only self created)	Yes (only self created)	Yes (only self created)	No

Add User

To add a user, do the following.

1. Go to **Configuration>User Accounts>Users**.
2. Select the location for which you want to add the user.
3. Click the **Add User** hyperlink. The **Add New User** dialog box appears.

The following table describes the fields on the **Add New User** page.

Field	Description
User Type	Specifies the type of user.
Login ID	Specifies the login id of the user.
Role	Specifies the role assigned to the user. Choose from Viewer, Operator, Administrator and Super User.
First Name	Specifies the first name of the user.
Last Name	Specifies the last name of the user.
Password	Specifies the password of the user. Password should be a combination of letters, numerals and special characters.
Confirm Password	Specifies the same password as typed in the password field to confirm the password.
Email	Specifies the e-mail id of the user.
Allowed Locations	Specifies the locations for which the user can operate. Click Change hyperlink to modify the list of allowed locations. A user can operate on one or more locations. For instance, an administrator user could have rights to multiple locations.
Password Expiry	Specifies if the password expires or does not expire. By default, the password never expires. Click Change hyperlink to set an expiry for the password.
Password Expiry Duration	Specifies the duration in days from the time of change of the password after which the password expires.
Password Expiry Warning	Specifies the time in days before the password expiry to prompt the user to change the password.
Session Timeout	Specifies the idle time interval after which the user's User

	Interface (UI) session should be timed out. Two options are available. Select Never Expires , if you don't want the session to time out. Select Expires After and specify the time in minutes (between 10 and 120 minutes) after which the session should time out.
Time Zone	Specifies the time zone in which the user operates.
Language Preference	Specifies the language in which the user wants to view the UI text. The default value is English.
Multi lingual	Specifies if the UI should support multi-lingual font support.

4. Click **Save** to save the changes.

Edit User

To edit a user, do the following.

1. Go to **Configuration>User Accounts>Users**.
2. Select the location for which you want to edit the user.
3. Click the login id hyperlink for the user that you want to edit. The **Edit User Details** dialog box appears.
4. Edit the user details.
5. Click **Save** to save the changes.

Print User List for Location

You can print a list of users defined for a location.

To print a user list for a location, do the following.

1. Go to **Configuration>User Accounts>Users**.
2. Select the location for which you want to print the user list.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the print icon. The print preview of the user list appears.
5. Click **Print** to print the list.

Search User

You can search users using the login ID or name of the user.

To delete a user, do the following.

1. Go to **Configuration>User Accounts>Users**.
2. Select the location for which you want to search user.
3. Enter the login ID string or the name string in the Quick Search box.
4. Press Enter key.
5. The users with login IDs or names matching the search string are displayed. The search string could be a substring of the login ID or name of the user.

Delete User

To delete a user, do the following.

1. Go to **Configuration>User Accounts>Users**.
2. Select the location for which you want to delete the user. The user list appears.
3. Click the **Delete** hyperlink for the user to delete. A message to confirm delete appears.
4. Click **Yes** to confirm deletion of user.

Configure Password Policy

The Password Policy determines the minimum requirements for system passwords. This policy applies to all user roles - super user, administrator, operator, and viewer. If you change this policy, older passwords are not affected. Only passwords created after a policy change are subject to the new policy. This setting applies only to local authentication and does not apply to LDAP and RADIUS authentication.

You can copy password policy from one server to another when the servers are part of the same server cluster.

To configure password settings or password policy, do the following.

1. Go to **Configuration>User Accounts>Password Policy**.
2. Specify the number of characters required for the password. Minimum number of characters is 4, maximum number of characters is 15.
3. If you want the password to contain at least one numerical character, select the At least one numerical character required check box.
4. If you want the password to contain at least one special character, select the At least one special character required check box.
5. Click **Save** to save the changes made to the page.

Restore Default Password Policy

The default password policy is as follows.

The password length as 6 characters and no numeric or special characters are required in the password.

To configure password settings or password policy, do the following.

1. Go to **Configuration>User Accounts>Password Policy**.
2. Click **Restore Defaults** to restore default password policy.
3. Click **Save** to save the changes.

Copy Password Policy to Another Server

You can copy the password policy from one server to another server when both servers are part of the same server cluster. You can copy password policy from child server to child server, parent server to child server, or child server to parent server.

You must be a superuser or an administrator to copy policies from one server to another.

To copy password policy, do the following.

1. Go to **Configuration>User Account>Password Policy** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the password policy is to be copied.

4. Select the server to which the password policy is to be copied.
5. Click **OK** to copy the password policy,

Configure Account Suspension Setting


Account suspension protects the system from spurious logins through dictionary attacks. Define the account suspension policy using the **Configuration>User Accounts>Account Suspension** option. There are four roles available in the system- super user, administrator, viewer and operator. You can configure different policies for each of these user roles. Configure the suspension time in minutes and the number of failed login attempts during a specific time duration.

You can copy account suspension setting from one server to another when the servers are part of the same server cluster.

To configure Account Suspension Setting for a user role, do the following.

1. Go to **Configuration>User Accounts>Account Suspension**.
1. Specify a suspension time between 5 minutes and 30 minutes, during which the consecutive failed login attempts happen.
2. Specify the number of failed login attempts between 3 and 10.
3. Click **Save** to save the changes made to the page.

The following diagrammatic representation explains the account suspension settings.



Account Suspension Settings

This policy is applicable on the root location only.

Copy Account Suspension Settings to Another Server

You can copy the account suspension settings from one server to another server when both servers are part of the same server cluster. You can copy account suspension settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy account suspension settings, do the following.

1. Go to **Configuration>User Accounts>Account Suspension** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the account suspension settings are to be copied.
4. Select the server to which the account suspension settings are to be copied.
5. Click **OK** to copy the account suspension settings,

Configure Login Parameters

You can specify the number of concurrent console logins that a user can have, along with the welcome message that the user would see on logging on to AirTight Management Console. The user can have up to 5 concurrent console logins.

You must have administrator privileges to configure login parameters.

You can copy the login configuration from one server to another server when both servers are part of the same server cluster.

To configure login parameters, do the following.

1. Go to **Configuration>System Settings>Login Configuration**,
2. Enter the message that the user would see on the login screen, in **Configure Login Message**.
3. To display the message on the login screen, select the **Enable Login Message** check box.
4. Specify the number of concurrent sessions per user.
5. Click **Save** to save the settings.

Restore Defaults for Login Configuration

To restore default settings for login configuration, do the following.

1. Go to **Configuration>System Settings>Login Configuration**,
2. Click **Restore Defaults**. Default settings are restored.
3. Click **Save** to save the changes.

Copy Login Configuration to Another Server

You can copy the login configuration from one server to another server when both servers are part of the same server cluster. You can copy login configuration from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy login configuration, do the following.

1. Go to **Configuration>System Settings>Login Configuration** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the login configuration is to be copied.
4. Select the server to which the login configuration is to be copied.
5. Click **OK** to copy the login configuration,

User Authentication

Configure LDAP Server Parameters

AirTight Management Console enables you to configure an LDAP server for user authentication. After an LDAP server is configured, users or groups defined in the LDAP server can login to AirTight Management Console.

In LDAP configuration, you can configure the following details.

- LDAP Configuration parameters to be able to access the LDAP compliant directory
- LDAP authentication details to search records on the LDAP server
- Privileges for LDAP users- Here you specify the default role and the default locations assigned when new LDAP users log in, for the case where the role and locations attributes are not provided by the LDAP server. Note that the default values here apply to all users authenticated via LDAP. If the LDAP server provides user role and locations attribute at the time of authentication, the attributes provided by the LDAP server will override the default role and locations attributes.

You must have administrator privileges to configure the LDAP server access parameters.

Configure LDAP Server Access Parameters

To configure LDAP server access parameters, do the following.

1. Go to **Configuration>User Accounts>LDAP Configuration** option.
2. Select **Enable LDAP** to enable user authentication using an LDAP compliant directory. All the fields related to LDAP are enabled on selecting this check box.
3. Enter the connection details as described in the following table.

Field	Description
Primary Server IP Address/Hostname	The primary server IP address/Hostname of the LDAP server.
(Primary Server) Port	The primary server port number of the LDAP server.(Default:389).
Backup Server IP Address/Hostname	The backup server IP address/Hostname of the LDAP server.
(Backup Server) Port	The backup server port number of the LDAP server.
Enforce Use of SSL/TLS	When this option is checked, only the SSL/TLS connection to the LDAP server is allowed. When it is not checked, either of the Open or SSL/TLS connection to the LDAP server is allowed.
Verify LDAP Server's Certificate	When this option is selected, the connection to the LDAP server is not allowed unless the certificate check passes. When this option is not selected, the connection to the LDAP server is allowed without verifying the LDAP server certificate.

4. If you have selected **Verify LDAP Server's Certificate**, you must add a certificate. Click **Add Certificate** to add trusted root CA Certificate(s) for the LDAP server and choose the certificate.
5. Enter the LDAP configuration details as described in the following table.

Field	Description
Base Distinguished Name	The base distinguished name of the directory to which you want to connect, for example, o=democorp, c=au. Distinguished Name is a unique identifier of an entry in the Directory Information Tree (DIT). The name is the concatenation of Relative Distinguished Names (RDNs) from the top of the DIT down to the entry in question.
Filter String	<p>This is a mandatory argument. It is a string specifying the attributes (existing or new) that the LDAP server uses to filter users. For example, lsUser=A. By specifying a filter string you can allow or disallow login access to a particular OU or Group of user defined in the AD.</p> <p>You can specify a DN (Distinguish Name) of any particular group to allow access to only those who are member of that group. For example, memberOf=DC=GroupName,DC=com. You can include members from multiple groups by using an OR condition. For example, to allow access to users under Base DN who are member of any of the two groups, Airtight Admins OR Airtight Reviewer, you must include the following filter string: ((memberOf=CN=Airtight Admins,DC=Airtight,DC=Com)(memberOf=CN=Airtight Reviewer,DC=Airtight,DC=Com))</p> <p>Similarly, to allow access to users under Base DN who are member of both Airtight Admins AND Airtight Reviewer groups, you must include the following filter string: (&(memberOf=CN=Airtight Admins,DC=Airtight,DC=Com)(memberOf=CN=Airtight Reviewer,DC=Airtight,DC=Com))</p> <p>You can have alternative configurations in AD such as, adding a new attribute, say ATNWIFI, to the users in AD that are granted access and then set filter string to allow users with that attribute only. For example, filter string = ATNWIFI</p> <p>You can also create a new group of users in AD with access granted and include the group in filter string.</p> <p>The most general filter string you can use is 'objectClass=*'. You can use this string when you do not want to filter out any LDAP entry.</p>
User ID Attribute	The string defined in the LDAP schema that the system uses to identify the user.(Default: cn)

6. If the directory does not allow an anonymous search, you must configure user credentials to search the LDAP compliant directory. Configure the user credentials as described in the following table.

Field	Description
Admin User DN	The DN of the admin user to be used to authenticate in to the LDAP server.
Append User DN	Select this option if the base DN specified in the LDAP Configuration Details must be appended to the admin user DN
Password	The password for the admin user.

-
- 7. Click **Test Settings** to test the authentication options.
- 8. Configure the default role and locations for new LDAP users. They are described in the following table.

Field	Description
User Role Attribute	The user role attribute string that the system uses to identify a user's role, as defined in the LDAP schema.
User Role	The default role for the new LDAP users. You can select one of the following four options- superuser, administrator, operator, viewer.
User Location Attribute	The user location attribute string that the system uses to identify the locations where the user is allowed access, as defined in your LDAP schema.
Locations	The location to which a new LDAP user has access rights. You can select another location by clicking Change .

- 9. Click **Save** to save the changes.

Edit LDAP Server Access Parameters

To configure LDAP server access parameters, do the following.

1. Go to **Configuration>User Accounts>LDAP Configuration** option.
2. Make the required changes.
3. If you have made changes to the connection settings or the configuration settings, click **Test Settings** to ensure that the new details are valid.
4. Click **Save** to save the changes.

Copy LDAP Configuration to Another Server

You can copy the LDAP configuration from one server to another server when both servers are part of the same server cluster. You can copy LDAP configuration from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

Note: When an LDAP configuration is copied to another server, the value of the **Locations** field in the replicated policy on the destination server is set to 'root' (location).

To copy LDAP configuration, do the following.

1. Go to **Configuration>User Accounts>LDAP Configuration** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the LDAP configuration is to be copied.
4. Select the server to which the LDAP configuration is to be copied.
5. Click **OK** to copy the LDAP configuration.

Configure RADIUS Parameters

AirTight Management Console can use a RADIUS server to facilitate user authentication. Configure the RADIUS server access parameters using the **Configuration->User Accounts->RADIUS Configuration** option.

Select the **Enable RADIUS Authentication** check box to activate RADIUS authentication of users. You can configure the Authentication, Accounting, and Advanced Settings after selecting this check box. Click the respective option to view and edit the fields for the individual sections.

Configure Authentication Parameters

Configure access parameters for the RADIUS Authentication server using the **Authentication** section.

To configure access parameters for RADIUS authentication server, do the following.

1. Go to **Configuration->User Accounts->RADIUS Configuration**.
2. Specify the IP address/ hostname, port number and shared secret for the primary and/or secondary RADIUS servers.
3. Click **Test** to test the connection to the RADIUS servers.
4. Select **Enable RADIUS Integration for CLI login** to enable CLI user authentication using RADIUS.
5. Select **Enable RADIUS Integration for GUI login** to enable GUI user authentication using RADIUS.
6. Select vendor specific attributes as appropriate. These are used when vendor specific attributes are not defined for RADIUS server.
7. Click **Save** to save the changes.

Configure Accounting Parameters

Configure accounting parameters for the RADIUS Accounting server under the **Accounting** section.

To configure accounting parameters for RADIUS authentication server, do the following.

1. Go to **Configuration->User Accounts->RADIUS Configuration**.
2. Select the **Enable RADIUS Accounting** check box to enable RADIUS accounting.
3. Specify the IP address/ hostname, port number and shared secret for the primary and/or secondary RADIUS accounting servers.
4. Click **Save** to save the changes.

Configure Advanced Settings

Configure the realm (domain) for the CLI and GUI users using the **Advanced Settings** section. You can also specify how the real name is to be appended to the user name (prefix notation or postfix notation). Select the **Use Prefix Notation** check box to use a prefix notation. Postfix notation is used when this check box is not selected.

To configure advanced settings, do the following.

1. Go to **Configuration->User Accounts->RADIUS Configuration**.
2. Enter the realm for CLI users in CLI..
3. Enter the realm for GUI users in GUI.
4. Select the **Use Prefix Notation** check box to use a prefix notation. Postfix notation is used when this check box is not selected.
5. Click **Save** to save the changes made.

Restore Default Settings

By default, RADIUS authentication is disabled. To restore this default setting, do the following.

1. Go to **Configuration->User Accounts->RADIUS Configuration**.

2. Click **Restore Defaults**.
3. Click **Save** to save the changes.

Copy RADIUS Configuration to Another Server

You can copy the RADIUS configuration from one server to another server when both servers are part of the same server cluster. You can copy RADIUS configuration from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

Note: When a RADIUS configuration is copied to another server, the value of the **Locations** field in the replicated policy on the destination server is set to 'root' (location).

To copy RADIUS configuration, do the following.

1. Go to **Configuration>User Accounts>RADIUS Configuration** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the RADIUS configuration is to be copied.
4. Select the server to which the RADIUS configuration is to be copied.
5. Click **OK** to copy the RADIUS configuration.

Configure Parameters for Certificate-based authentication

AirTight Management Console supports user authentication using digital certificates. Configure the settings for user authentication using the **Configuration>User Accounts>Certificate Configuration** option.

There are four ways to authenticate users - password only, certificate only, certificate and password and certificate or password.

Password only: In this option, the user authentication is performed using the password. The user has to enter the user name and the password at the login prompt. The password may be locally verified by the system or may be verified using the external LDAP or RADIUS authentication service, as appropriate.

Certificate only: In this option, the user authentication is performed using the client certificate (such as smart card). The user has to insert a smart card containing the client certificate in a reader attached to the computer from where the console is accessed and then press the **Login** button. The system then verifies the client certificate and obtains user identity (user name) from the certificate. Other attributes for the user are retrieved either locally or from the external authentication services such as LDAP or RADIUS, as appropriate. When this authentication option is set, the login screen appears as follows:

Certificate and Password: In this option, both the client certificate and the password are required for the user authentication. The user has to insert a smart card containing the client certificate in a reader attached to the computer from where the console is accessed, as well as enter the password at the login prompt. The system verifies the password locally or using the external LDAP or RADIUS authentication service, as appropriate. When this authentication option is set, the login screen appears as follows:

Certificate or Password: In this option, the user authentication is permitted either using the password or using the client certificate. This option is appropriate for organizations which have only partially migrated to using smart cards for authentication. At login prompt, the user can select certificate authentication by checking the **Use certificate for login** box or continue with password authentication by entering login name and password. When this authentication option is set, the login screen appears as follows:

The required authentication option can be activated based on the various combinations of the **Enable certificate based authentication** box, **Allow access without certificate** box, and **Users must provide password along with certificate** box.

The following table describes the activation of the authentication options based on the check boxes selected by the user.

Authentication option to activate	Check box to be selected		
	<i>Enable certificate based authentication</i>	<i>Allow access without certificate</i>	<i>Users must provide password along with certificate</i>
Password only	No	-	-
Certificate only	Yes	No	No
Certificate and password	Yes	No	Yes
Certificate or password	Yes	Yes	No

Note: In order to use certificate based authentication, it is necessary that the GUI host is able to access the server at TCP port 4433. If there is a firewall between the GUI host and the server, port 4433 must be opened from the host to the server.

When either *Certificate only*, *Certificate and Password*, or *Certificate or Password* option is activated, the additional details should be provided as follows

- The field in the client certificate from which user identity can be retrieved by AirTight Management Console.
- Root CA certificates to facilitate the verification of the client certificate.
- Preferred method to check for certificate revocation.

Restore Certificate Configuration Defaults

By default, certificate-based authentication is disabled.

To restore this default value, do the following.

1. Go to **Configuration>User Accounts>Certificate Configuration**.
2. Click **Restore Defaults**.
3. Click **Save** to save the changes.

Copy Certificate Configuration to Another Server

You can copy the Certificate configuration from one server to another server when both servers are part of the same server cluster. You can copy Certificate configuration from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy Certificate configuration, do the following.

1. Go to **Configuration>User Accounts>Certificate Configuration** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the certificate configuration is to be copied.
4. Select the server to which the certificate configuration is to be copied.
5. Click **OK** to copy the certificate configuration,

Wireless Intrusion Prevention System

A Wi-Fi network is easy to set up by way of access points. Small plug-and-play devices can act as access points. Smart phones and tablets that are now widely used, are also Wi-Fi enabled. They can act as mobile hotspots. Wireless clients can connect to any such access points and easily access a network that is not adequately protected against such wireless threats. Thus, a network can become vulnerable to wireless attacks. It is therefore important to understand and control the authorized and unauthorized access to networks.

A proper wireless intrusion prevention (WIPS) policy needs to be in place to prevent unauthorized access to a network. The rules for wireless intrusion prevention into the network can be configured using **Configuration>WIPS**.

You can set the rules for WIPS using the options seen under **Configuration>WIPS**.

AirTight Management Console provides you the flexibility to set a generic WIPS policy for all locations in the organization, or a location-wise WIPS policy for individual locations. You can have WIPS activated at some locations and deactivated at others.

Make sure that you have defined your location tree before you can proceed with WIPS configuration. You must have administrator privileges to do the WIPS settings.

Specify the authorized WLAN policy templates to identify authorized APs, using **Configuration>WIPS>Authorized WLAN Policy**. This is inherited, by default, from the parent location. It can also be customized for a location.

Configure the policy to auto-classify the APs detected by AirTight WIPS, using **Configuration>WIPS>AP auto-classification**. This is inherited, by default, from the parent location. It can also be customized for a location.

Configure the policy to auto-classify clients detected by AirTight WIPS, using **Configuration>WIPS>Client auto-classification**. This is inherited, by default, from the parent location. It can also be customized for a location.

Define the intrusion prevention policy, using **Configuration>WIPS>Intrusion Prevention**. This is inherited, by default, from the parent location. It can also be customized for a location.

Activate or deactivate intrusion prevention for the selected location, using **Configuration>WIPS>Intrusion Prevention Activation**. This is location specific. You need to first select the desired location from the location tree. Then you use the **Intrusion Prevention Activation** option to activate or deactivate intrusion prevention for this location.

Import device lists that can be referred to for AP/Client classification, using **Configuration>WIPS>Import Devices**. This is location specific. You need to first select the desired location from the location tree. Then you use the **Import Devices** option to import devices for this location.

You can manage banned device list with the **Configuration>WIPS>Banned Device List** option.

You can manage hotspot SSID list with the **Configuration>WIPS>Hotspot SSIDs** option.

You can manage hotspot SSID list with the **Configuration>WIPS>Vulnerable SSIDs** option.

You can manage the smart device types used in smart device detection with the **Configuration>WIPS>Smart Device Types** option.

You can lock the list of authorized AP and/or clients for a location using the **Configuration>WIPS>Device List Locking** option.

Manage Authorized WLAN Policy

Specify the Authorized WLAN policy templates for the selected location in the location hierarchy using **Configuration>WIPS>Authorized WLAN Policy**.

Authorized WLAN policy for a location includes a set of one or more policy templates that define the properties of one or more authorized wireless networks. A policy template is a collection of different network related settings such as wireless network protocols, encryption protocol used, allowed network SSIDs, security settings, authentication type used, allowed networks and so on. An authorized WLAN policy also specifies what networks are restricted from having Wi-Fi APs on them. Apart from this, you can also specify what APs to categorize as rogue or authorized APs based on their RSSI signal strength. All these parameters together constitute an authorized WLAN policy.

The RSSI of a device is statistical parameter. Using the RSSI feature can cause legitimate neighborhood APs to be classified as Rogues and subjected to containment if automatic prevention is enabled. This will cause neighbor Wi-Fi disruption since clients, including the legitimate neighborhood clients, will NOT be able to connect to the Rogue AP under containment.

Even if the intention is to use RSSI to identify APs that are within the facility, it will not always work since low power APs such as soft APs, hotspot APs running on smart phones, USB APs, etc. or APs which are away from RSSI measurement point will still not get classified as Rogue APs due to not meeting the RSSI threshold.

Policy templates aid in the classification of APs. A new AP or an existing Authorized AP is compared against the templates to determine if it is a rogue or misconfigured AP. Any AP at a location that does not comply with the WLAN policy attached to that location, is not considered to be an authorized AP.

You must apply the templates from the available list for the WLAN policy at that location.

Authorized policy templates are used to identify authorized APs and constantly check that the actual Wi-Fi access parameters provisioned on the authorized APs meet the security policy. You can define multiple WLAN policy templates and assign them to each location. Any new AP that is added to a location is verified on the basis of the WLAN policy templates attached to that location. Any mismatch is used to detect misconfiguration of the Wi-Fi access network.

The system uses the details of the authorized Wi-Fi setup at a particular location to detect the presence of misconfigured or rogue APs in your network.

An AP is considered as being compliant to the Authorized WLAN Policy if:

- It is not connected to a No Wi-Fi network for its location
- Its SSID matches with one of the templates attached at that location
- Is connected to one of the networks specified in that template
- Conforms to the other settings in that template (except the Authentication Framework, as this setting is not a property of the AP itself but of the backend authentication system).

Note: If the template specifies certain allowed AP capabilities (such as Turbo, 802.11n, and so on), the AP may or may not have those capabilities. However, if a capability is not selected, the AP must not have that capability to be considered as compliant.

With location-based policies, you can apply different sets of policy templates for different locations. However, you cannot attach more than one template with the same SSID at any one location.

Only the policy templates that are applied to a location are used for AP classification at that location. Other templates that are configured but not applied to the location, will not be used for AP classification, as they are not a part of the WLAN policy for that location.

The authorized policy templates created at other locations can be applied to a selected location but cannot be edited or deleted. The edit and delete operations are possible only at the location where the template is created.

A child location automatically inherits the authorized WLAN policy from its parent. You can customize the WLAN policy for a child location. You can also switch back to an inherited policy in case you have created a customized policy.

Configure Authorized WLAN Policy

To configure an authorized WLAN policy for a location, do the following.

1. Select the location from the location tree.
2. Go to **Configuration>WIPS>Authorized WLAN Policy**.
3. If Wi-Fi has been deployed at the location, select the **Wi-Fi is deployed at this location** check box. The **Policy Template** and **Select "No Wi-Fi" Networks** sections on this page are enabled on selecting this check box.
4. If you want to use an existing policy template, click the Applied icon for the existing policy template to be applied to the location. Alternatively, Click **Add New Policy Template** if no policy template exists, and add a new policy template. Refer to the Add Device Template or Edit Device Template subsection in the [Manage Policy Templates](#) section for details on how to add or edit a policy template.
5. If there are any networks at the location that are not allowed to have APs connected to them,
 - a) Scroll down to the **Select "No Wi-Fi" Networks** section
 - b) Click **Add**. The **Add Networks** dialog box appears.
 - c) Enter the SSID or IP address of the network to add.
6. Define RSSI based classification, if the WIPS is intended for use in an isolated environment without much of a neighborhood activity like defense and military facilities. It is recommended to skip this section altogether in case of commercial or business district environments. Either of the following two mechanisms must be switched on to classify the APs.
 - a) Enter the threshold RSSI value to use for preclassification of APs with signal strength stronger than this value as rogue or unauthorized APs.
 - b) Select the Preclassify APs connected to monitored subnets as Rogue or Authorized APs to preclassify the APs connected to monitored subnets as rogue or authorized APs.
7. Click **Save** to save the changes.

Edit Authorized WLAN Policy

To edit an authorized WLAN policy for a location, do the following.

1. Select the location from the location tree.
 - 1 Go to **Configuration>WIPS>Authorized WLAN Policy**.
2. If you want to apply an existing policy, click the Applied icon for that policy in the policy template list.
3. If you want to make changes to the policy template, click the policy template link in the policy template list. If you want to add a new policy template click **Add New Policy Template**, and add a new policy template. Refer to the Add Device Template or Edit Device Template subsections in the [Manage Policy Templates](#) section for details on how to add or edit a policy template.
4. If there are any networks at the location that are not allowed to have APs connected to them,
 - a) Scroll down to the **Select "No Wi-Fi" Networks** section
 - b) Click **Add**. The **Add Networks** dialog box appears.
 - c) Enter the SSID or IP address of the network to add.
5. Define RSSI based classification, if the WIPS is intended for use in an isolated environment without much of a neighborhood activity like defense and military facilities. It is recommended to skip this

section altogether in case of commercial or business district environments. Either of the following two mechanisms must be switched on to classify the APs.

a) Enter the threshold RSSI value to use for preclassification of APs with signal strength stronger than this value as rogue or unauthorized APs.

b) Select the Preclassify APs connected to monitored subnets as Rogue or Authorized APs to preclassify the APs connected to monitored subnets as rogue or authorized APs.

6. Click **Save** to save the changes.


Configure AP Auto-classification Policy

The AP Auto-Classification policy function enables you to specify the AP classification policy for different AP categories.

It is important to know about the authenticity of APs in the network as unauthorized APs can cause irreparable damage to your network and business.

AP classification is of prime importance in WIPS implementation.

A diagrammatic representation of AP classification is shown below.



AP classification


Under External APs, AirTight recommends that you select Automatically move Potentially External APs in the Uncategorized list to the External Folder. The system automatically removes an AP from the External folder and moves it to an appropriate AP folder if it later detects that the AP is wired to the enterprise network.

Under Rogue APs, AirTight recommends that you select Automatically move Potentially External APs in the Uncategorized list to the Rogue folder.

Note: Once you move an AP to the Rogue folder, the system never automatically removes it from the Rogue folder, even if it later detects that the AP is unwired from the enterprise network or its security settings have changed.

Configure Client Auto-classification Policy

The client auto-classification policy determines how clients are classified upon initial discovery and subsequent associations with APs.



Client auto classification

Define how the system should automatically classify the detected wireless clients at the selected location based on their initial discovery and subsequent AP associations. This policy is automatically inherited by child locations of the selected location. The intrusion prevention actions enforced on the wireless clients are based on their classification in the system.


If a client is ever manually classified, then it is never automatically classified by the system until it is deleted from the system and rediscovered.

Under **Initial Classification**, select the **Automatically classify newly discovered Clients at this location as** check box and specify if newly discovered clients at a particular location, which are Uncategorized by default should be classified as External, Authorized or Guest.

Under Automatic Client Classification, select one or more options to enable the system automatically re-classify Uncategorized and Unauthorized Clients based on their associations with APs. You can categorize the following types of clients.

- Clients running AirTight Mobile
 - All External Clients running AirTight Mobile are classified as Authorized
 - All Uncategorized Clients running AirTight Mobile are classified as Authorized
 - All Rogue Clients running AirTight Mobile are classified as Authorized


- All Guest Clients running AirTight Mobile are classified as Authorized
 - Clients connecting to Authorized APs
 - All External Clients that connect to an Authorized AP are re-classified as Authorized
 - All Uncategorized Clients that connect to an Authorized AP are reclassified as Authorized
 - All Guest Clients that connect to an Authorized AP are reclassified as Authorized
- You can select the following exceptions.
- Do not reclassify a Client connecting to a Misconfigured AP as Authorized
 - Do not reclassify a Client if its wireless data packets are not detected on the wired network (except if the connection is reported by WLAN controller).



Classification for clients connecting to Authorized APs

Click **Advanced** to configure the auto classification settings for clients connecting to guest APs and external APs.

- Clients connecting to Guest APs
 - All External Clients that connect to a Guest AP are reclassified as Guest
 - All Uncategorized Clients that connect to a Guest AP are reclassified as Guest
- You can select the following exceptions
- Do not re-classify a Client connecting to a Mis-configured AP as Guest
 - Do not re-classify a Client as Guest if its wireless data packets are not detected on the wired network (except if the connection is reported by WLAN controller)




Classification for Clients connecting to Guest APs

- Clients connecting to External APs
 - All Uncategorized Clients that connect to an External AP are reclassified as External
 - All Uncategorized Clients that connect to a Potentially External AP are classified as External
 - All Guest Clients that connect to an External AP are re-classified as External
 - All Guest Clients that connect to a Potentially External AP are re-classified as External

Information: Client Auto-classification based on Association to External AP

Described below is how the system automatically re-classifies Clients that connect to External APs.




Classification of Clients connecting to External APs

- Clients connecting to Rogue APs
 - All Clients other than Authorized Clients that connect to a Rogue AP are (re)classified as Rogue
 - All Clients other than Authorized Clients that connect to a Potentially Rogue AP are classified as Rogue

Information: Client Auto-classification based on Association to Rogue AP


Described below is how the system automatically re-classifies Clients that connect to Rogue APs.



Classification of Clients connecting to Rogue APs

- Bridging to the Corporate Network
 - Classify any non-authorized Client as Rogue if it is detected as bridging Wi-Fi to the corporate network
- RSSI Based Classification

You can enable RSSI based client classification for uncategorized clients and/or external clients and configure RSSI based classification for them. Specify a RSSI threshold and the category for such clients.



Classification of Clients bridging to corporate network and RSSI based classification

Intrusion Prevention

The Intrusion Prevention Policy determines the wireless threats against which the system protects the network automatically. The system automatically moves such threat-posing APs and Clients to quarantine. The system can protect against multiple threats simultaneously based on the selected Intrusion Prevention level.

If the server quarantines an AP or Client based on the Intrusion Prevention policy, the Disable Auto-quarantine option ensures that the system will not automatically quarantine this AP or Client (regardless of the specified Intrusion Prevention policies).

AirTight Management Console can prevent any unwanted communication in your 802.11 network. It provides you various levels of prevention-blocking mechanisms of varying effectiveness. Intrusion

Prevention Level enables you to specify a trade-off between the desired level of prevention and the desired number of multiple simultaneous preventions across radio channels.

The greater the number of channels across which simultaneous prevention is desired, the lesser is the effectiveness of prevention in inhibiting unwanted communication. Scanning for new devices continues regardless of the chosen prevention level.

You can select from the following intrusion prevention levels:

- **Block:** A single sensor can block unwanted communication on any one channel in the 802.11b/g band and any one channel in the 802.11a band.
- **Disrupt:** A single sensor can disrupt unwanted communication on any two channels in the 802.11b/g band and any two channels in the 802.11a band.
- **Interrupt:** A single sensor can interrupt unwanted communication on any three channels in the 802.11b/g band and any three channels in the 802.11a band.
- **Degrade:** A single sensor can degrade the performance of unwanted communication on any four channels in 802.11b/g band and any four channels in the 802.11a band.

Block is the most powerful prevention level, that is, it can severely block almost all popular Internet applications including ping, SSH, Telnet, FTP, HTTP, and the like. However, at this level, a single sensor can simultaneously prevent unwanted communication on only one channel in the 802.11b/g band and one channel in the 802.11a band. If you want the sensor to prevent unwanted communication on multiple channels simultaneously in the 802.11 b/g and/or the 802.11a band, you must select other prevention levels.

Note: Prevention Type determines the blocking strength to prevent communication from unwanted APs and Clients. The system can prevent multiple APs and Clients on each channel. Prevention Type is not applicable for Denial of Service (DoS) attacks or ad hoc networks. You must select a lower blocking level to prevent devices on more channels. Choosing a lower blocking level means that some packets from the blocked device may go through.

You can enable intrusion prevention against the following threats

- **Rogue APs:** APs connected to your network but not authorized by the administrator; an attacker can gain access to your network through the Rogue APs. You can also automatically quarantine uncategorized, indeterminate and banned APs connected to the network.
- **Misconfigured APs:** APs authorized by the administrator but do not conform to the security policy; an attacker can gain access to your network through misconfigured APs. This could happen if the APs are reset, tampered with, or if there is a change in the security policy.
- **Client Misassociations:** Authorized Clients that connect to rogue or external (neighboring) APs; corporate data on the authorized client is under threat due to such connections. AirTight recommends that you provide automatic intrusion prevention against authorized clients that connect to rogue or external APs.

There is a special intrusion prevention policy for the smart devices that are not approved. Even if a current client policy restricts authorized clients from connecting to a guest AP, an unapproved smart device can still be allowed to do so. One needs to explicitly allow or restrict unapproved smart devices from connecting to a guest AP.

Click **Special Handling for Smart Devices** to enable special handling for unapproved smart devices.


You can allow the unapproved smart device to connect to a guest AP only. To do this,

1. Select **Enable Special Handling for Unapproved Smart Devices**.
2. Select **Allow connection to Guest AP, but not Authorized AP**.

To disallow the unapproved smart device from connecting to both a guest AP as well as an authorized AP, select **Do not allow connection to Guest AP and Authorized AP**.

Wireless Threats

Following is a diagrammatic representation of the various wireless threats.




Wireless Threats

Non-authorized Associations: Non-authorized and Banned Clients that connect to Authorized APs; an attacker can gain access to your network through Authorized APs if the security mechanisms are weak. Non-authorized or Uncategorized Client connections to an Authorized AP using a Guest SSID are not treated as unauthorized associations.

- Associations to Guest APs: External and Uncategorized Clients that connect to Guest APs are classified as Guest Clients. The Clients connected to a wired network or a MisConfigured AP can be specified as exceptions to this policy.
- Ad hoc Connections: Peer-to-peer connections between Clients; corporate data on the Authorized Client is under threat if it is involved in an ad hoc connection.
- MAC Spoofing: An AP that spoofs the wireless MAC address of an Authorized AP; an attacker can launch an attack through a MAC spoofing AP.
- Honeypot/Evil Twin APs: Neighboring APs that have the same SSID as an Authorized AP; Authorized Clients can connect to Honeypot/Evil Twin APs. Corporate data on these Authorized Clients is under threat due to such connections.
- Denial of Service (DoS) Attacks: DoS attacks degrade the performance of an official WLAN.
- WEPGuard™: Active WEP cracking tools allow attackers to crack the WEP key and gain access to confidential data in a matter of minutes or even seconds. Compromised WEP keys are used to gain entry into the authorized WLAN by spoofing the MAC address of an inactive Authorized Client.
- Client Bridging/ICS: A Client with packet forwarding enabled between wired and wireless interfaces. An authorized Client bridging and unauthorized/uncategorized bridging Client connected to enterprise subnet is a serious security threat.

Activate Intrusion Prevention for Location

Activate intrusion prevention for a location using the **Configuration>WIPS>Intrusion Prevention Activation** option. The following figure explains intrusion prevention activation.



Intrusion Prevention Activation

The intrusion prevention policy is a location specific policy - it cannot be inherited from the parent location.

Authorized APs should be in the **Authorized** folder before activating intrusion prevention. Their network connectivity icon may show the status as Wired, Unwired, or Indeterminate. If you deploy new Authorized APs later, you do not have to deactivate intrusion prevention. However, you need to ensure that the newly deployed APs are moved to the **Authorized** folder.

AirTight recommends that you select the **Activate Intrusion Prevention for <location>** check box for the selected location only after the deployment is stable and fully configured. If you are modifying a deployment, clear the **Activate Intrusion Prevention for <location>** check box to avoid spurious activity during the transient phase.

Click **Save** to the change. Click **Cancel** to cancel the change. Click **Restore Defaults** to restore the default value.

Import Device List

Importing an authorized AP List and an authorized or unauthorized client list is an efficient alternative to manual movement of these devices into the authorized / unauthorized bins. After successfully importing these lists, the system automatically classifies the APs and Clients in the respective lists as authorized or unauthorized.

This is a location specific property and cannot be inherited from the parent location folder. You need administrator rights to import a device list.

You can import authorized AP list, authorized client list, guest client list, rogue client list, and AirTight device list into AirTight Management Console using the **Configuration>WIPS>Import Devices** option.

Format of the .txt or.csv file containing the AP/Client data

Each line has comma separated list of MAC Address, IP Address, Device Name. For example,

```
11:11:11:11:11:11,192.168.8.1,name1
11:11:11:11:11:12,192.168.8.2,name2
11:11:11:11:11:13,192.168.8.3,name3
11:11:11:11:11:14,192.168.8.4,name4
11:11:11:11:11:15,192.168.8.5,name5
11:11:11:11:11:16,192.168.8.6,name6
11:11:11:11:11:17,192.168.8.7,name7
```

Format of.txt or .csv file containing the AirTight Device data

Each line has comma separated list of MAC Address, Device Name. For example,

```
44:77:11:22:44:77, name1
44:77:11:22:11:12, name2
44:77:11:22:11:13, name3
44:77:11:22:11:14, name4
44:77:11:22:11:15, name5
```

Points to remember

- Once you move an AP to the **Authorized** folder, AirTight Management Console never removes it from the **Authorized** folder automatically, even if the AP is unwired from the enterprise network.
- When you import APs from the list, policy settings in the Setup Wizard do not affect these APs.
- When you import sensors from the list, you can delete these sensors only from the **Devices** page.
- When you import clients from the list, policy settings in the Setup Wizard do not affect these clients.

To import devices, do the following.

1. Select the appropriate option from the **Import** list box, depending on whether you want to import an authorized AP list, an authorized client list, a guest client list, a rogue client list, or a sensor list. The text on the command button below the device list changes based on your selection. For instance, if you select the option **Import Authorized Client List** from the list box, the text on the command button changes to **Import Authorized Client List**.
2. Under the **Auto Tag Devices** area, select **Auto tag Devices** to automatically tag the device(s) to the selected location. Select **Manually Tag Devices to**, to manually tag the device(s) to the selected location.
3. Enter the MAC address, IP address and name of the AP or client. If the device is a sensor, enter the MAC address and the name of the sensor. Alternatively, you can specify a filename containing the AP/client/sensor data. Click **Autofill using File**, and select the .txt or .csv file containing the AP/client/sensor data.
4. Click **Import Authorized AP List** to import the list of authorized APs. Click **Import Authorized Client List** to import the list of authorized clients. Click **Import Guest Client List** to import the list of guest

clients. Click **Import Rogue Client List** to import the lists of rogue clients. Click **Import Sensor List** to import the list of sensors. The file has to be a text file or a csv file. Refer to the subsequent sections for the text and csv file formats for the AP, client and sensor lists.

Once imported successfully, the devices are seen under their respective tabs on the **Devices** page. The **Dashboard** page also reflects the activity of the newly imported sensors, APs, and clients.

Delete device details from device list

To delete the device details from the device list, do the following.

1. Select the AP/client/sensor row and click the corresponding **Delete** hyperlink.
2. Click **Yes** when asked to confirm deletion.

Manage Banned Device List

You can create and manage a list of banned APs and banned clients using the **Configuration>WIPS>Banned Device List** option. If the devices from this list are detected, they are not classified as rogue devices.

Create banned AP list

You can add the wireless MAC addresses of APs that are blacklisted in your organization. If APs with these MAC addresses become visible, AirTight Management Console generates an alert.

You can either enter individual AP MAC addresses or to import a list of banned APs in to the database.

To add an individual AP MAC address, do the following.

1. Go to **Configuration>WIPS>Banned Device List**.
2. Click to expand **Banned AP List**.
3. Click **Add MAC Address**. The **Add to Banned List** dialog box appears.
4. Click **Add MAC Address** under Banned AP list and enter the MAC Address of a banned AP. You can add one or more banned AP MAC addresses in this manner.

You can also import a list of AP MAC addresses from a file. The file containing the list of AP MAC addresses must be a CSV file.

To import a file containing a list of AP MAC addresses, do the following.

1. Go to **Configuration>WIPS>Banned Device List**
2. Click to expand **Banned AP List**.
3. Click **Add MAC Address**. The **Add to Banned List** dialog box appears.
4. Click **File Upload**.
5. Click **Choose File** to choose the file and then click **Upload** to upload the selected file.
6. Click **Add** to add the imported AP MAC addresses to the banned device list.

Create banned Client list

You define the wireless MAC addresses of Clients that are blacklisted in your organization. For example, such MAC addresses could belong to laptops of employees who are no longer with the organization. If APs with these MAC addresses become visible, AirTight Management Console generates an alert.

You can either enter individual client MAC addresses or to import a list of banned clients to the database.

To add an individual client MAC address, do the following.

1. Go to **Configuration>WIPS>Banned Device List**.
2. Click to expand **Banned Client List**.
3. Click **Add MAC Address**. The **Add to Banned List** dialog box appears.
4. Click **Add Device** link to add a MAC address manually.
5. Enter the MAC address to add. You can add one or more banned client MAC addresses in this manner.
6. Click **Add** to add the devices to the banned device list.

You can also import a list of client MAC addresses. The file containing the list of client MAC addresses must be a CSV file.

To import a file containing a list of client MAC addresses, do the following.

1. Go to **Configuration>WIPS>Banned Device List**.
2. Click to expand **Banned Client List**.
3. Click **Add MAC Address**. The **Add to Banned List** dialog box appears.
4. Click **File Upload**.
5. Click **Choose File** to choose the file and then click **Upload** to upload the selected file.
6. Click **Add** to add the imported client MAC addresses to the banned device list.

Delete Banned Device

1. Go to **Configuration>WIPS>Banned Device List**.
2. Click the **Delete** link for the device to be deleted. A confirmation message is displayed to confirm deletion.
3. Click **Yes** to confirm deletion

Copy Banned Device List to Another Server

You can copy the banned device list from one server to another server when both servers are part of the same server cluster. You can copy banned device list from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy banned device list, do the following.

1. **Go to Configuration>WIPS>Banned Device List** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the banned device list is to be copied.
4. Select the server to which the banned device list to be copied.
5. Click **OK** to copy the banned device list,

Manage Hotspot SSIDs

Configure and manage a list of hotspot SSIDs using the **Configuration->WIPS-> Advanced Settings->Hotspot SSIDs** option.

It is highly likely that hotspot APs are present in the enterprise neighborhood. If enterprise Client probes for well known hotspot SSID, it is at risk of connecting to the hotspot AP without the user necessarily knowing about it. Also if enterprise AP uses hotspot SSID on it, such an AP may attract undesirable Clients to connect to it.

If you consider an SSID to be vulnerable to hackers, you can open the Hotspot SSIDs screen and enter the SSID under SSID (ASCII character string).

Add Hotspot SSIDs

The system lists commonly known SSIDs by default. To enter a blank SSID: that is, with no string, click <Add> without entering any text. The list shows the SSID as NULL.

To add a hotspot SSID, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Hotspot SSID**.
2. Click **Add New Hotspot SSID**. The Add New Hotspot SSID dialog box appears.
3. Enter a new hotspot SSID and click OK. If an AP with a hotspot SSID is detected, the system generates an event.

Search Hotspot SSIDs

To search for hotspot IDs, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Hotspot SSID**.
2. Type in the search string in the search SSID box and press the Enter key. A list of hotspot SSIDs matching the search criteria appears.

To clear the search string, click the x icon next to the search SSID box.

Delete Hotspot SSID

To delete hotspot SSIDs, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Hotspot SSID**.
2. click Delete link for the SSID to be deleted.
3. Click Yes on the confirmation message to confirm the deletion of the hotspot SSID.

Restore Default Hotspot SSID list

To restore the default hotspot SSID list, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Hotspot SSIDs**
2. Click **Restore Defaults**. A confirmation message prompting you to confirm the operation appears.
3. Click Yes. The default hotspot SSID list is restored.

Copy Hotspot SSID List to Another Server

You can copy the list of hotspot SSIDs from one server to another server when both servers are part of the same server cluster. You can copy a list of hotspot SSIDs from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy a list of hotspot SSIDs, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Hotspot SSIDs** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the list of hotspot SSIDs is to be copied.

4. Select the server to which the list of hotspot SSIDs is to be copied.
5. Click **OK** to copy the list of hotspot SSIDs.

Manage Vulnerable SSIDs

Configure and manage a list of vulnerable SSIDs using the **Configuration>WIPS>Advanced Settings>Vulnerable SSIDs** option.

APs have well known default SSIDs and many users may not change these SSIDs when deploying the APs. Therefore it is highly likely that APs using default SSIDs are present in the enterprise neighborhood. If an enterprise Client probes for a default SSID, it is at risk of connecting to the neighborhood AP without the user necessarily knowing about it. Also if an enterprise AP uses a default SSID, such an AP may attract undesirable clients to connect to it.

Add Vulnerable SSID

If you consider an SSID to be vulnerable to hackers, you can add the SSID to the Vulnerable SSIDs list.

To add a vulnerable SSID, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Vulnerable SSIDs**.
2. Click **Add New Vulnerable SSID**.
3. Enter the SSID and click OK to add it to the list of vulnerable SSIDs. If an AP point with a vulnerable SSID is detected, the system generates an event.

Note: Commonly known SSIDs are listed by default. To enter a blank SSID: no string, click Add without entering any text. The list shows the SSID as NULL.

Search Vulnerable SSID

To search a vulnerable SSID, do the following.

1. Go to **Configuration->WIPS-> Advanced Settings->Vulnerable SSIDs**
2. Type in the search string in the search SSID box and press the Enter key. A list of vulnerable SSIDs matching the search criteria is displayed.

To clear the search string, click the x icon next to the search SSID box.

Delete Vulnerable SSID

To delete a vulnerable SSID, do the following.

1. Go to **Configuration->WIPS-> Advanced Settings->Vulnerable SSIDs**
2. Click Delete link for the SSID to be deleted.
3. Click Yes on the confirmation message to confirm the deletion of the vulnerable SSID.

Restore Default Vulnerable SSID list

To restore the default vulnerable SSID list, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Vulnerable SSIDs**
2. Click **Restore Defaults**. A confirmation message prompting you to confirm the operation appears.

3. Click Yes. The default vulnerable SSID list is restored.

Copy Vulnerable SSID List to Another Server

You can copy the list of vulnerable SSIDs from one server to another server when both servers are part of the same server cluster. You can copy a list of vulnerable SSIDs from child server to child server, parent server to child server, or child server to parent server.

You must be a superuser or an administrator to copy policies from one server to another.

To copy a list of vulnerable SSIDs, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Vulnerable SSIDs** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the list of vulnerable SSIDs is to be copied.
4. Select the server to which the list of vulnerable SSIDs is to be copied.
5. Click **OK** to copy the list of vulnerable SSIDs.

Manage Smart Device Types

You can view, add, and delete the smart device types using the **Configuration->WIPS-> Advanced Settings->Smart Device Type** option.

The **Smart Device Type** page shows the system-defined smart device types, and the user-defined smart device types, if any.

Add Smart Device Type

You can add to the list of predefined smart device types.

To add a new smart device type, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Smart Device Type**.
2. Click **Add new smart device type**. The Add new smart device type dialog box appears.
3. Enter the Smart Device Type.
4. Click **OK** to add the smart device type to the existing list of smart device types.

Delete Smart Device Type

You can delete only the smart device types that have been manually added. You cannot delete the system-defined smart device types.

To delete a user-defined smart device type, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Smart Device Type**
2. Select the smart device type and click **Delete**. A message appears prompting you to confirm the deletion.
3. Click **Yes** to confirm the deletion.

Copy Smart Device Types List to Another Server

You can copy the list of smart device types from one server to another server when both servers are part of the same server cluster. You can copy a list of smart device types from child server to child server,

parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy a list of smart device types, do the following.

1. Go to **Configuration>WIPS>Advanced Settings>Smart Device Type** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the list of smart device types is to be copied.
4. Select the server to which the list of smart device types is to be copied.
5. Click **OK** to copy the list of smart device types.

Manage WiFi Access

Wi-Fi profiles are used to define the Wi-Fi configuration of an AirTight Device in access point (AP) mode. Wi-Fi Profiles are applied onto a radio of a device. The radio and the device must support access point configuration.

Wi-Fi Profiles can be created on any location.

Wi-Fi profile is a Wi-Fi network profile. The profile is a set of configuration parameters related to a wireless or Wi-Fi network. It consists of security, network, captive portal, firewall, traffic shaping, QoS and BYOD settings. A single Wi-Fi profile represents a VLAN. Multiple VLANs can be configured for a single AP. Thus, you can have different VLANs to provide different services using a single AP.

Manage SSID Profiles

When an AirTight device is configured as an access point (AP), you can use the access point to provide various services, in parallel. This means that you can divide a physical AP into multiple virtual APs. Each virtual AP can provide a service independently, without interfering with the services provided by other virtual APs on the same physical AP.

An AirTight device operating as an AP supports multiple VLANs created on the wired side.

A Wi-Fi Profile (or SSID profile) is a set of network properties that are configured on a virtual AP. One or more Wi-Fi profiles could represent or map to a single VLAN.

Let us consider an example. You could have different VLANs configured on the wired side, of which one is serving the general corporate network and the other is provisioning network access for guests. Using the AirTight device that is configured to function as an AP, you can define 2 or more virtual APs mapping to the properties of the VLANs on the wired side. The wireless clients wanting to connect to the corporate network would use the Wi-Fi profile mapping to the corporate VLAN and the wireless clients wanting to connect to the guest network would use the Wi-Fi profile mapping to the guest VLAN.

A virtual AP has the following features:

- Supports Open, WPA (TKIP), WPA2 (CCMP), WPA/WPA2 (TKIP+CCMP) or 802.1x security. Distinct virtual APs can have different security modes.
- Can be used to provide distinct services that are independent of each other.
- Maps wireless traffic from virtual AP to a specific VLAN so that data transmitted and received by wireless client will be seen on only the specified VLAN. It will not appear on other VLANs.

Starting with AirTight Management Console 7.1 U2, AirTight APs support Hotspot 2.0 Release 1. Configuring the Hotspot 2.0 settings on an AirTight AP enables Passpoint-certified mobile devices to seamlessly connect to the AirTight AP without the need for authentication.

Configure Wi-Fi Profiles using **Configuration>Device Configuration>SSID Profiles**.

Important: You cannot configure BYOD settings and captive portal settings on the same Wi-Fi profile. Each should be configured on independent Wi-Fi profiles.

Add Wi-Fi Profile

You can add multiple Wi-Fi profiles for an AirTight device operating in the AP mode. When in AP mode, a single physical AP device can be logically split up into multiple virtual APs. Each wireless profile represents the configuration settings of a virtual AP. Multiple virtual APs can be configured on a single radio. Up to 8 such virtual APs can be configured using the **Add/Edit Wi-Fi Profiles** dialog box.

Each Wi-Fi profile has a set of WLAN settings. Configure the WLAN settings for an AP in the **WLAN** tab.

You can configure the following settings for a Wi-Fi profile.

- **Security Settings:** Security settings specify the type of security used by the AP to authenticate wireless clients. For details on configuring security settings, refer to the [Security Settings](#) section.
- **Network Settings:** The VLAN and DHCP settings for the Wi-Fi profile are configured under network settings. For details on configuring network settings, refer to the [Network Settings](#) section.
- **Captive Portal Settings:** To enable captive portal on the Wi-Fi profile for guest login, you must configure the captive portal settings. These settings comprise splash page configuration, walled garden settings, external portal parameters etc. For details on configuring captive portal settings, refer to the [Captive Portal Settings](#) section.
- **Firewall Settings:** Firewall rules for the Wi-Fi profile are configured under the firewall settings. The incoming and outgoing traffic through a virtual AP can be controlled by defining firewall rules. For details on configuring the firewall rules, refer to the [Firewall Settings](#) section.
- **SSID Scheduling Settings:** If you want to limit the duration for which the SSID is active, you can define a schedule for the SSID. You can also specify if an SSID is to be permanently active or valid for only a limited time duration. For details on SSID scheduling, refer to the SSID Scheduling section.
- **Traffic Shaping & QoS Settings:** Effective utilization of network bandwidth can be achieved by setting an upload and download limit for the network, restricting the number of client association, band steering and defining QoS parameters. You can configure these settings under traffic shaping and QoS settings. For details on configuring these settings, refer to the [Traffic Shaping and QoS Settings](#) section.
- **BYOD- Device Onboarding Settings:** These settings govern whether the wireless clients can connect to APs in a corporate network. For instance, if the employees get their own smart devices to office, the SSID profile can be configured to allow or disallow such devices from connecting to the corporate network. You can also restrict access for such devices with the device onboarding settings. For details on configuring these settings, refer to [BYOD-Device Onboarding](#) section.
- **Hotspot 2.0 Settings:** If you want to deploy the AP in a Hotspot 2.0 operator's network such that the AP functions as a Hotspot 2.0 AP, you must configure the Hotspot 2.0 settings as well. These are configured in the **Hotspot 2.0** tab. The Hotspot 2.0 settings are required only if you want to enable hotspot 2.0 support on the AP; otherwise configuration of WLAN settings alone is sufficient. For details, on configuring these settings, refer to the [Hotspot 2.0 Settings](#) section

You can choose to collect analytics data for reporting purpose about the client-AP association.

Association analytics and content analytics can be collected if you enable the collection of these analytics in the Wi-Fi profile.

Association Analytics comprises the data related to the client - AP communication. The following data is collected as association analytics.

- Client MAC address
- Protocol
- SSID of the network to which the client connects
- Location of the client
- Start time of client association with the AP (GMT)
- End time of client association with the AP (GMT)
- Start time of client association with the AP according to local time of the user
- End time of client association with the AP according to local time at the user
- Session duration

- Data transfer from client device in bytes
- Data transfer to client device in bytes
- Data rate in Kbps
- Smart device type
- Local Time Zone

The following information is present for each internet domain as content analytics information.

- Domain name
- Data transferred to the domain (in bytes)
- Data received from the domain (in bytes)

To add a Wi-Fi profile, do the following.

1. Go to **Configuration>Device Configuration>SSID Profiles**.
2. Select the location for which the Wi-Fi profile is to be created.
3. Click **Add New Wi-Fi Profile**. The **WLAN** and **Hotspot 2.0** tabs are displayed.
4. Enter the following details on the **WLAN** tab.

Field	Description
Profile Name	Name of the Wi-Fi profile
SSID	SSID or network name of the Wi-Fi profile. This would be the SSID of the wired network that the wireless user would connect to.
Broadcast SSID	Enables or disables broadcast of SSID in the wireless packet. Select the check box to broadcast the SSID with the wireless packets. Leave it clear or deselect the check box if you do not want to broadcast the SSID with the wireless packets.
Association Analytics	Enables or disables association analytics in reports. Select the check box to enable association analytics in reports. Leave it clear or deselect the check box if you do not want association analytics data in reports.
Content Analytics	Enables or disables content analytics in reports. This check box is visible only if you have selected the Association Analytics check box. Content analytics capture information related to the Internet domains or IP addresses accessed by the client associated with the AirTight APs. Select the check box to collect internet domain access information as a part of association analytics. This information is present in the CSV file downloaded through Reports>Analytics . Leave it clear or deselect the check box if you do not want content analytics data in reports.

5. Fill in the other details based on how you want to configure the Wi-Fi profile. Refer to individual sections on [network settings](#), [security settings](#), [firewall settings](#), [traffic shaping and QoS settings](#), [schedule SSID](#), [captive portal settings](#), [BYOD onboarding settings](#), [Hotspot 2.0 Settings](#) to configure the respective settings.
6. Click **Save** to save and add the new Wi-Fi profile.

Replicate Wi-Fi Profile

If you have already created a Wi-Fi profile, you can create a similar Wi-Fi profile with minor changes. To make a copy of an existing Wi-Fi profile with minor changes, do the following

1. Go to **Configuration>Device Configuration>SSID Profiles**.
2. Select the location.
3. Open the Wi-Fi profile to replicate.
4. Enter a new name for the Wi-Fi profile.

5. Make the required changes to this profile.
6. Click **Save As**. A Wi-Fi profile is created with the new name.

Edit Wi-Fi Profile

The Wi-Fi profile can be edited only at the location where it has been created. To edit a Wi-Fi profile, do the following

1. Go to **Configuration>Device Configuration>SSID Profiles**.
2. Select the location for which the Wi-Fi profile has been created.
3. Click the Wi-Fi profile name hyperlink to edit.
4. Make the required changes.
5. Click **Save** to save the changes to the Wi-Fi profile.

Copy Wi-Fi profile to another location

To make a copy of an existing Wi-Fi profile to another location, do the following.

1. Go to **Configuration>Device Configuration>SSID Profiles**.
2. Select the location for which the Wi-Fi profile has been created.
3. On the SSID Profile page, select the check box for the SSID profile to copy to another location.
4. Click the Copy to location icon. The Select Location dialog box appears.
5. Select the location to which the Wi-Fi profile is to be copied. A copy of the selected Wi-Fi profile is created at the selected location.

Delete Wi-Fi Profile

You cannot delete a Wi-Fi profile, if it is used in a device template. You can delete a Wi-Fi profile at a selected location, only if you have defined the Wi-Fi profile at that location.

To delete a Wi-Fi profile, do the following.

1. Go to **Configuration>Device Configuration>SSID Profiles**.
2. Select the location for which the Wi-Fi profile has been created.
3. Click the **Delete** icon for the Wi-Fi profile. A message to confirm deletion appears.
4. Click **Yes** to confirm the deletion of the Wi-Fi profile.

Print List of Wi-Fi Profiles for Location

You can print a list of Wi-Fi profiles that have been defined for a location.

To print a list of Wi-Fi profiles at a location, do the following.

1. Go to **Configuration>Device Configuration>SSID Profiles**.
2. Click the Wi-Fi Profiles tab.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the Print icon. A print preview of the list appears.
5. Click **Print** to print the list.

Security Settings

The security settings for a virtual AP could be either of the following:

- **Open**: Open means no security settings are to be applied. This is the default security setting.
- **WEP**: WEP stands for Wireless Equivalent Privacy. WEP is a deprecated security algorithm for IEEE 802.11 networks. This has been provided for backward compatibility purpose only.

- **WPA2:** WPA2 is the latest and more robust security protocol. It fully implements the IEEE 802.11i standard.
- **WPA and WPA2 mixed mode:** This stands for a mix of the WPA and WPA2 protocols.

PSK or Personal Shared key is generally used for small office networks.

In case of bigger enterprise networks, RADIUS authentication is used. Large enterprises, sometimes, use RADIUS attributes to propagate network policies across multiple points of access. Users are divided into groups and policies are applied to each group to effectively control access to network resources. Each user group is redirected to a different VLAN based on the policies applicable to that user group. For instance, sales personnel would have access to a VLAN that is different from the VLAN accessed by HR personnel.

An AirTight AP can retrieve the VLAN associated with the RADIUS user from the RADIUS server. This option is available only for WPA2, and WPA and WPA2 mixed mode when 802.1x is enabled on the Wi-Fi profile.

Based on the VLAN returned by the RADIUS server, the AirTight AP dynamically redirects the network traffic of a RADIUS-authenticated user to the VLAN that is associated with the group to which the user belongs. Until the RADIUS server authenticates the user, the EAP packets will pass through the default VLAN.

Note: The VLAN ID that is set in the Wi-Fi profile network settings is used as the default VLAN.

To enable RADIUS-based assignment of VLANs, you must enable dynamic VLANs on the Wi-Fi profile and specify a list of dynamic VLANs that RADIUS users can be redirected to. If the VLAN specific to the user group is not present, the default VLAN is used.

The following RADIUS attributes must be set on the RADIUS side for each user group for the RADIUS server and AirTight AP communication.

Attribute	Value
Tunnel Type	Set this to VLAN.
Tunnel Medium Type	Set this to 802.
Tunnel Private Group ID	Enter the VLAN ID to be assigned to the user group.

The following image illustrates security settings.

▼ Security

Security Mode:

PSK 802.1X

Fast Handoff Support: Opportunistic Key Caching (OKC) Pre-Authentication

Dynamic VLANs: Enable dynamic VLANs

0 - 4094 [0: Indicates untagged VLAN in the switch port where the device is connected, irrespective of its VLAN number on the switch.]

■ RADIUS Authentication:

Primary Authentication Server	Secondary Authentication Server
Server IP <input type="text"/>	Server IP <input type="text"/>
Port Number <input type="text" value="1812"/>	Port Number <input type="text" value="1812"/>
Shared Secret <input type="text"/> <input type="checkbox"/>	Shared Secret <input type="text"/> <input type="checkbox"/>

▶ RADIUS Accounting

The following table explains the fields present on the **Add/Edit Wi-Fi profile** and in the **Security Settings**. Click **Security Settings** to view fields under **Security Settings**.

Field	Description
Profile Name	This field specifies the name of the profile.
SSID	This field specifies the SSID of the wireless profile. This is a mandatory field.
Broadcast SSID	This check box indicates whether the SSID is to be broadcast or not for this Virtual AP, in the beacon frames. If selected, the beacon for this Virtual AP carries the SSID.
Client Isolation	This check box indicates whether communication between 2 wireless clients of this virtual AP is enabled or disabled. If selected, wireless client communication is disabled for the virtual AP.
Enable P2P Cross Connection	Select this check box to enable to P2P cross connection bit. When a client is connected to a Wi-Fi direct network and to an AirTight AP in an infrastructure network it is possible to bridge these two networks. When you enable the P2P cross connection bit, the Wi-Fi Direct network and the infrastructure network can be bridged by the client. Otherwise, the AP instructs the client not to cross-connect the infrastructure network to the Wi-Fi Direct network, thus enhancing the security of the wireless network. The P2P cross connection is disabled, by default.

Limit number of associations	This field specifies the maximum number of clients that can associate with the AP. You can select the check box and then specify the number of clients.
Security Mode	This specifies the security mode applied to the virtual AP. The possible values are Open, WEP, WPA, WPA2, WPA and WPA2 mixed mode.
Fields related to security mode WEP	
Authentication Type	Select Open if the type of authentication is open. In case of open authentication, the key is used for encryption only. Select Shared if the authentication type is shared key. In case of shared key authentication, the same key is used for both encryption and authentication.
WEP Type	Select WEP40 if 40-bit WEP security is used. Select WEP104 if 104-bit WEP security is used.
Key Type	Select ASCII option if you are comfortable with ASCII format and want to enter WEP key in that format. The Sensor/AP combo converts it to hexadecimal internally. Select HEX option if you are comfortable with hexadecimal format and want to enter WEP key in that format.
Key	WEP key is a sequence of hexadecimal digits. If WEP Type is WEP40, enter the key as a 5 character ASCII key or a 10 digit hexadecimal key, depending on the Key Type selected by you. If WEP Type is WEP104, enter the key as a 13 character ASCII key or a 26 digit hexadecimal key, depending on the Key Type selected by you.
Show Key	Select this check box to see the actual key on the screen. If this check box is cleared, the key is masked.
Fields related to security mode WPA/WPA2/WPA and WPA2 Mixed Mode	
PSK	Select the PSK option if you want to use a personal shared key. The Pass phrase field is enabled when this option is selected.
Pass Phrase	Specify the shared key of length 8-63 ASCII characters for PSK authentication
Show Key	Select this check box to see the actual pass phrase on the screen. If this check box is cleared, the key is masked.
802.1x	Select 802.1x option if you want to use a RADIUS server for authentication. The fields on the Authentication and Accounting tabs are enabled on selecting this check box. You can enable dynamic VLANs after selecting this check box.

Opportunistic Key Caching	Select the check box to enable client fast handoffs using opportunistic key caching method. Note that the key caching works within the same subnet only and not across subnets.
Pre-authentication	Select the Pre-Authentication check box to enable client fast handoffs using the Pre-Authentication method.
NAS ID	<p>This field is used when a network access server (NAS) serves as a single point to access network resources. Generally, a NAS supports hundreds of simultaneous users. When a RADIUS client connects to a NAS, the NAS sends access request packets to the RADIUS server. These packets must contain either the NAS IP address or the NAS identifier. The NAS ID or the NAS-Identifier is used to authenticate RADIUS clients with the RADIUS server.</p> <p>You can specify a string for the NAS ID. The default value is %m-%s, where %m represents the Ethernet MAC address of the AP and %s represents the SSID of the WLAN. This corresponds to the NAS-Identifier attribute on the RADIUS server. The attribute ID for the NAS-Identifier RADIUS attribute is 32.</p> <p>Ensure that the NAS ID is not the same as the shared secret configured for the RADIUS server in the RADIUS Authentication section.</p>
Enable dynamic VLANs	<p>Select the check box to enable the AP to accept the VLAN for the current user from the RADIUS server. When dynamic VLANs are enabled, BYOD, firewall, portal and NAT features are disabled for the Wi-Fi profile.</p> <p>When the check box is selected, you can enter a list of dynamic VLANs in the box adjoining this check box. The list of dynamic VLANs must be a comma-separated list of VLAN IDs. If the RADIUS server does not return a VLAN ID or returns a VLAN ID that is not in the list of dynamic VLANs configured in the Wi-Fi profile, the AirTight AP redirects the user traffic to the default VLAN (that is, the VLAN ID specified in the Wi-Fi profile network settings).</p>
Fields in the Authentication Tab-Primary RADIUS Server area	
Server IP	Enter the IP Address of the primary RADIUS server here.
Port Number	Enter the port number at which primary RADIUS server listens for client requests.
Shared Secret	Enter the secret shared between the primary RADIUS server and the AP.
Fields in the Authentication Tab- Secondary RADIUS Server area	
Server IP	Enter the IP Address of the secondary RADIUS server here.
Port Number	Enter the port number at which secondary RADIUS server listens for client requests.
Shared Secret	Enter the secret shared between the secondary RADIUS server and the AP.
Field in the Accounting Tab	

Enable RADIUS Accounting	Select this check box to enable RADIUS Accounting. The other fields on the Accounting tab are enabled on selecting this check box. Define the primary RADIUS Server, and optionally secondary RADIUS Accounting server in the Accounting tab.
Fields in the Accounting Tab- Primary Accounting Server area	
Server IP	Enter the IP Address of the primary accounting server here.
Port Number	Enter the port number at which primary accounting server listens for client requests.
Shared Secret	Enter the secret shared between the primary accounting server and the AP.
Fields in the Accounting Tab- Secondary Accounting Server area	
Server IP	Enter the IP Address of the secondary accounting server here.
Port Number	Enter the port number at which secondary accounting server listens for client requests.
Shared Secret	Enter the secret shared between the secondary accounting server and the AP.

Configure Network Settings for Wi-Fi Profile

Configure the VLAN and DHCP settings, to be used by the SSID profile, using the **Network** section. The following image illustrates network settings

▼ **Network**

VLAN ID: 0 - 4094 [0: Indicates untagged VLAN in the switch port where the device is connected, irrespective of the device's configuration]

Enable Layer 2 Traffic Inspection and Filtering: Enabling this setting overrides the client isolation settings.

Enable Proxy ARP setting:

Disable DGAF:

NAT Bridged

Start IP Address:

End IP Address:

Local IP Address:

Subnet Mask:

Lease Time: mins [30 - 1440]

Enable Wired Extension:

DNS Servers

8.8.8.8 x

Use comma, space, tab or Enter key as separator for one or more entries.

GRE

Network Settings

A bridged network is used when the AP and the clients associating with the AP can be in the same subnet.

Similarly, network Address Translation (NAT) must be used when you want to have the clients in a separate subnet and the AP is in a separate subnet. With NAT, the clients can have a private IP address pool and it is easier to add more clients to the network as they do not require a public IP address.

A wireless LAN, on which NAT is enabled, can be extended to the wired side using the second Ethernet port present on the Access Point device. Create an isolated wired LAN with one or more wired devices connected through layer-2 switches and connect the second Ethernet port of the Access Point to this wired subnet. The wired LAN will be an extension of the wireless LAN of this SSID profile with NAT enabled. All network settings like NAT and portal, configured on this SSID profile, are also applicable to the wired devices.

Note: The second Ethernet port is available on some specific AirTight device models only.

When you are configuring NAT parameters, you must specify at least one DNS server. On successful association, wireless clients will get the specified DNS servers. You can specify up to three such DNS server IP addresses.

Generic Routing Encapsulation (GRE) is useful when you want to route network traffic from and to a single end point and apply policies on this end point.

IMPORTANT: GRE works only when NAT is enabled.

To configure network address translation settings, do the following.

1. Specify the VLAN ID for which the bridging or NAT settings would be applicable.
2. Select the NAT check box if you want to enable NAT.
3. Specify the following NAT related settings if you have enabled NAT.

Field	Description
NAT	Select this check box to enable NAT (network address translation). Enable NAT if you want to enable wired extension.
Start IP address	The starting IP address of the DHCP address pool in the selected network ID.
End IP address	The end IP address of the DHCP address pool in the selected network ID.
Local IP address	An IP address in selected network ID outside of the DHCP address pool. This address is used as the gateway address for the guest wireless network.
Subnet Mask	The net mask for the selected network ID.
Lease Time	The DHCP lease time in minutes. Minimum value is 30 minutes, maximum value is 1440 minutes.
DNS Servers	The DNS servers that the wireless clients can make DNS queries to. You can specify upto 3 DNS servers.
Enable Wired Extension	Select this check box to extend this wireless LAN to the wired side using the second Ethernet port present on AirTight device functioning as an access point.

4. Select GRE if you want to enable Generic Routing Encapsulation (GRE).

The following table describes the Generic Routing Encapsulation related fields

Field	Description
GRE	Select this check box to enable Generic Routing Encapsulation and to

	be able to define the GRE related parameters present on this page.
Tunnel IP Address	IP address of the GRE tunnel interface on the access point. This IP address should not conflict with any other network setting in the access point.
Remote Endpoint IP Address	IP address of the remote endpoint of the GRE tunnel.
Key	Key in the GRE header. If configured, key should be same at both ends of the tunnel. Key is not mandatory to be configured in GRE tunnel.
Exempted Host/Network List	List of comma separated network and/or IP addresses that are exempted from using the GRE tunnel.

5. Click **Save** to save the changes to the network settings.

Edit Network Settings

To edit network address translation settings, do the following.

1. Specify the VLAN ID for which the NAT settings would be applicable.
2. Deselect the **NAT** check box if you want to disable NAT and have a bridged network instead. In case you want to continue using NAT and only want to edit NAT settings, edit them as required.

Field	Description
NAT	Select this check box to enable NAT (network address translation).
Start IP address	The starting IP address of the DHCP address pool in the selected network ID.
End IP address	The end IP address of the DHCP address pool in the selected network ID.
Local IP address	An IP address in selected network ID outside of the DHCP address pool. This address is used as the gateway address for the guest wireless network.
Subnet Mask	The net mask for the selected network ID.
Lease Time	The DHCP lease time in minutes. Minimum value is 30 minutes, maximum value is 1440 minutes.
DNS Servers	The DNS servers that the guest clients can make DNS queries to.
Enable Wired Extension	Select this check box to extend this wireless LAN to the wired side using the second Ethernet port present on AirTight device functioning as an access point.

3. Select the **GRE** check box if you want to enable Generic Routing Encapsulation (GRE). The following table describes the Generic Routing Encapsulation related fields.

Field	Description
GRE	Select this check box to enable Generic Routing Encapsulation and to be able to define the GRE related parameters present on this page.
Tunnel IP Address	IP address of the GRE tunnel interface on the access point. This IP address should not conflict with any other network setting in the access point.
Remote Endpoint	IP address of the remote endpoint of the GRE tunnel.

IP Address	
Key	Key in the GRE header. If configured, key should be same at both ends of the tunnel. Key is not mandatory to be configured in GRE tunnel.
Exempted Host/Network List	List of comma separated network and/or IP addresses that are exempted from using the GRE tunnel.

In case you do not want to use GRE, disable the GRE check box.

4. Click **Save** to save the changes to the network settings.

Enable Layer 2 inspection and Filtering

L2 inspection and filtering prevents frames exchanged between two mobile devices from being delivered by the Wi-Fi access network without first being inspected and filtered in either the hotspot operator network or the Service Provider core network. Such processing provides some protection for mobile devices against attack. The inspection and filtering mechanism is out of the scope of the Wi-Fi profile settings,

If you want to inspect the packets exchanged between two clients in a Wi-Fi network on a wired side host, do the following.

1. Select the **Enable Layer 2 Traffic Inspection and Filtering** check box.
2. Click **Save** to save the changes. You can use a packet capture tool to view the packets on the wired side.

Inspection of layer 2 packets by AirTight AP is not supported.

Disable Downstream Group Addressed Forwarding

The purpose of the Downstream Group Addressed Forwarding (DGAF) Disable feature is to mitigate a "hole-196" attack. By IEEE 802.11i design, all STAs in a BSS use the same GTK so forgery of group-addressed frames is always possible. However, in some hotspots multicast service using group-addressed frames is needed; in these cases, the DGAF Disable bit would be set to 0. You must enable the proxy ARP setting to disable DGAF.

To disable DGAF and mitigate a hole-196 attack, do the following.

1. Select the **Enable Proxy ARP Setting** check box. The **Disable DGAF** check box is enabled.
2. Select the **Disable DGAF** check box to ensure future attacks that exploit the GTK can be mitigated.
3. Click **Save** to save the changes.

Enable/Disable DHCP Option 82

DHCP Option 82 is generally used in a distributed DHCP server environment where an AP inserts additional information to identify the client point of attachment. The circuit ID represents the client point of attachment. The DHCP Option 82 is available for a bridged SSID only.

When the DHCP option 82 is enabled and the AP receives DHCP packets from the client, a circuit ID is appended by the AP to the DHCP packets from the client. It then forwards this DHCP request to the DHCP server. Based on the circuit ID in the DHCP request, the DHCP server makes a decision on the IP pool from which to assign an IP address to the client. When the DHCP assigns the IP address and passes it to the AP, the AP passes it on to the client after stripping the circuit ID.

To enable DHCP Option 82 while creating or editing a Wi-Fi profile, do the following.

1. Under **Network Settings**, select the **Bridged** option.


2. Select the **DHCP Option 82** check box.
3. Enter the **Circuit ID**.
You can use special formats %s, %m and %l.
%s is replaced by AP with the SSID.
%m is replaced by AP with the AP MAC address.
%l is replaced by AP with the location tag configured for the location to which the AP is assigned.
The location tag can be configured from Configuration>System Settings>Location Specific Attributes.
4. Click **Save** to save the changes.

The following image presents a sample DHCP Option 82 configuration in a Wi-Fi profile. Here the circuit ID is constructed by replacing %s with the SSID and %l with the respective location tag.

The following image illustrates DHCP Option 82 related configuration.

▼ **Network**

VLAN ID: 0 - 4094 [0: Indicates

Enable Layer 2 Traffic Inspection and Filtering:  Enabling this set

Enable Proxy ARP setting:

Disable DGAF:

NAT Bridged

■ DHCP Option 82

Circuit ID:

■ Remote Bridging

To disable DHCP option 82, do the following.

1. Under **Network Settings** for a Wi-Fi profile, deselect the **DHCP Option 82** check box.
2. Click **Save** to save the changes.

Enable/Disable Remote Bridging

To channelize all wireless traffic to a remote endpoint or gateway through a tunnel, you must enable remote bridging. The remote endpoint or gateway aggregates wireless frames from different access points and forwards them to the appropriate network.

You must configure a network interface profile before you enable remote bridging so that you can assign the network interface profile to the SSID profile. When you enable remote bridging and assign a network interface profile to the SSID profile, the wireless traffic from the AP is bridged to the remote endpoint configured in the network interface profile. The traffic is rerouted to the appropriate network from this remote endpoint.

When you disable remote bridging, the AP stops diverting the wireless traffic to the remote endpoint configured in the network interface profile that was selected when remote bridging was enabled.

Remote bridging does not work with NAT.

To enable remote bridging, do the following.

1. Under **Network Settings** for a Wi-Fi profile, select the **Bridged** option.
2. Select the **Remote Bridging** check box.
3. Select a network interface profile from the **Network Interface Profile**.drop-down box.

4. Click **Save** to save the changes.

The figure below shows the remote bridging enabled and wireless traffic being diverted to a network interface profile by the name 'remote_us_nw'.

▼ Network

VLAN ID: 0 - 4094 [0: Indicates untagged VLAN in the switch port whi

Enable Layer 2 Traffic Inspection and Filtering: Enabling this setting overrides the client isolation settir

Enable Proxy ARP setting:

Disable DGAF:

NAT Bridged

DHCP Option 82

Remote Bridging

Network Interface Profile:

To disable remote bridging, do the following.

1. Under **Network Settings** for a Wi-Fi profile, deselect the **Remote Bridging** check box.
2. Click **Save** to save the changes.

Captive Portal Settings

A captive portal is a web page that a client on the network is directed to when the client wants to access the Internet.

The client is authenticated on this page and is able to access the Internet after successful authentication.

A wireless profile can be configured to serve as a guest network to provide restricted wireless connectivity (e.g., Internet only) to guest wireless clients. Multiple such guest networks are supported in AirTight Wi-Fi.

Supported Captive Portal Types

The following three types of captive portals are supported in AirTight Wi-Fi or AirTight WIPS.

1. AP hosted splash page with click through
2. External splash page for sign-in or click through
3. External splash page with RADIUS authentication

These are explained in detail below.


1. **AP hosted splash page with click through:** A 'click-through' splash page is a splash page where authentication is not supported. The portal pages are hosted and served by the AP. The portal page can be used to display the terms and conditions of accessing the guest network as well as any other information as needed.

Steps involved in this type of access are as follows.

- (a) Wi-Fi user connects to the guest SSID and opens a URL from any web browser using the HTTP protocol.
- (b) AirTight AP intercepts this request and throws a portal page hosted on AP to guest user.
- (c) Guest user will accept terms and condition and submits on portal page.
- (d) AP will open gate for the client and client will be redirected to redirect URL (if any) or original requested URL.


Following is a pictorial representation of AP hosted splash page with click through.

AP Hosted Splash Page with Click-through



2. **External Splash Page for Sign-In/Click-through:** The portal is hosted on an external server. The portal is either click-through without any authentication or has its own authentication mechanism in place. Steps involved in this type of access are as follows.
 - (a) Wi-Fi user connects to the guest SSID and opens a URL from any web browser using the HTTP protocol.
 - (b) AirTight AP intercepts this request and redirects the browser to the configured external portal page along with the request parameters as the GET parameters of the redirected URL.
 - (c) Portal will authenticate guest user by prompting sign-in or click-through splash page on wireless user.
 - (d) After authentication, portal will redirect client to AP with success or failure reply. If AP and portal is configured with shared secret. Portal will send validation code using which AP will validate reply from Portal. Using shared secret between AP and portal would avoid fake user to get access using spoofing attack.
 - (e) After successful validation AP will open gate for the client and client will be redirected to redirect URL (if any) or original requested URL.


Following is a pictorial representation of External splash page for Sign-in/click-through



3. **External Splash Page with RADIUS Authentication:** The guest user is redirected to a portal hosted on an external server. The guest user is authenticated by a RADIUS server, when he logs in to the external portal.
- Steps involved in this type of access are as follows
- (a) Wi-Fi user connects to the guest SSID and opens a URL from any web browser using the HTTP protocol
 - (b) AirTight AP intercepts this request and redirects the browser to the configured external portal page along with the request parameters as the GET parameters of the redirected URL.
 - (c) Portal will prompt the user with the splash page to enter username and password.
 - (d) User will submit username and password.
 - (e) Portal will redirect guest user to AP with username and encoded password using shared secret.
 - (f) Airtight AP will authenticate guest user by RADIUS server using username and decoded password.
 - (g) RADIUS server will reply with Access Accept or Reject message for guest user.
 - (h) Airtight AP will open the Internet access for the client and redirect client to Redirect URL (if any) or original requested URL.

Following is a pictorial representation of External splash page with RADIUS authentication.

External Splash Page with RADIUS authentication



Set up Walled Garden

A walled garden is a method to provide restricted access to the Internet. Walled garden destination(s) can be accessed at the specified port numbers without displaying the splash page. Domain (e.g. domain.com) also covers its subdomains (e.g. subdomain.domain.com).

Configure a list of exempted domains, subdomains, IP address ranges and port numbers. (E.g. 192.168.1.0/24) . Services on these IP addresses can be accessed without redirection to the portal page. If some part of the portal page (e.g., images) is placed on a web server, the web server's IP address must be included in this list for the content to be successfully displayed.

If the mode of authentication is External Splash page for Sign-in/Click-through, you can restrict access to walled garden destinations unless the guest user accepts the terms and conditions specified on the splash page.

Do the following to set up a walled garden.

1. Click **Add**. The **Add Destination** dialog opens.
2. Enter the details.

Field	Description
Destination	domain name, sub domain name, host name, subnet or IP address to which the rule applies. You can provide a comma-separated list of more than one host names here. For example, 192.168.8.173, www.facebook.com,192.168.121.0/24.
Port	port number. You can provide a comma-separated list of port numbers or port ranges here. For example, 20-22, 81, 443.

3. To delete an exempted destination, select the entry and click **Remove**.


Configure Captive Portal Settings

To configure captive portal settings, do the following.

1. Select the **Enable Captive Portal** check box to display a portal page to be shown to the client on using the guest network.
2. Select the mode of access to the Internet through the captive portal. Do one of the following:
 - (a) Select the AP Hosted Splash Page with click through option. You must create a .zip file of the portal page along with any other files like images, style sheets etc and upload this file. The zip file must satisfy the following requirements for the portal to work correctly.
 - a. The zip file should have a file with the name "index.html" at the root level (i.e., outside of any other folder). This is the main portal page. It can have other files and folders, (and folder within folders) at the root level that are referenced by the index.html file.
 - b. The total unzipped size of the files in the bundle should be less than 100 KB. In case, large images or other content is to be displayed on the page, this content can be placed on an external web server with references from the index.html file. In this case, the IP address of the external web server must be included in the list of exempt hosts (see below).
 - c. The index.html file must contain the following HTML tags for the portal to work correctly:
 - A form element with the exact starting tag: `<form method="POST" action="$action">`
 - A submit button inside the above form element with the name "mode_login". For example: `<input type="image" name="mode_login" src="images/login.gif">`The exact tag: `<input type="hidden" name="redirect" value="$redirect">` inside the above form element.

You can download the factory default portal bundle file and use it as a template to create a custom portal bundle. Click **Download Sample** to download the factory default portal bundle file.

Upload the portal bundle (default or custom). Click **Choose File** following **Upload Bundle** to upload the bundle.



Click Open to upload the portal bundle.

To restore the portal bundle to factory default file, click **Restore Default**.

- (b) Select the **External Splash Page for Sign-in/Click-through** option. Specify **Splash Page URL**, using which wireless user will be redirected to external portal. This portal will prompt wireless user to enter username and password. You must select the check box for the shared secret, if applicable, and specify the shared secret for SSID-external portal communication.

If you want the guest user to accept the terms and conditions on the splash page before being able to access walled garden destinations, select the Restrict access to Walled Garden check box. If this check box is not selected, the guest user is able to access the walled garden destinations without accepting the terms and conditions on the splash page.

- (c) Select **External Splash Page with RADIUS Authentication**.

In this case, you also need to specify the following fields

Splash Page URL, using which wireless user will be redirected to external portal. You must enter a shared secret for SSID-external portal communication. Click RADIUS settings hyperlink to configure RADIUS server settings, using which the AP will actually authenticate the wireless user.

Specify the primary and optionally, secondary authentication server details.

Field	Description
Called station ID	a free form text parameter that the AP passes to the RADIUS server in the standard RADIUS parameter, 'Called-Station-Id', during the authentication process. The special format specifier '%m' can be specified which will be expanded to the Ethernet MAC address of the AP.
NAS ID	This field is used when a network access server (NAS) serves as a single point to access network resources. Generally, a NAS supports hundreds of simultaneous users. When a RADIUS client connects to a NAS, the NAS sends access request packets to the RADIUS server. These packets must contain either the NAS IP address or the NAS identifier. The NAS ID or the NAS-Identifier is used to authenticate RADIUS clients with the RADIUS server. You can specify a string for the NAS ID. The default value is %m-%s, where %m represents the Ethernet MAC address of the AP and %s represents the SSID of the WLAN. This corresponds to the NAS-Identifier attribute on the RADIUS server. The attribute ID for the NAS-Identifier RADIUS attribute is 32. Ensure that the NAS ID is not the same as the shared secret configured for the RADIUS server in the RADIUS Authentication section.
Primary Authentication server details	
Server IP	IP address of primary authentication server.
Port Number	port number of primary authentication server listens for client requests.
Shared Secret	shared secret between the AP and primary authentication server.
Secondary authentication server details	
Server IP	IP address of secondary authentication server.
Port Number	port number of secondary authentication server listens for client requests.
Shared Secret	shared secret between the AP and secondary authentication server.

If you want RADIUS accounting to be enabled, select the accounting check box and specify the accounting details, using which AP will actually authenticate wireless user. In RADIUS Server Settings specify **Server IP** and **Port** on which RADIUS server is running.

Field	Description
Interval	Accounting interval, in minutes. Minimum interval can be 1 minute, and maximum interval can be 60 minutes.
Primary accounting server details	
Server IP	IP address of primary accounting server
Port Number	Port number of primary accounting server listens for client requests.
Shared Secret	Shared secret between the AP and primary accounting server.
Secondary accounting server details	
Server IP	IP address of secondary accounting server.
Port Number	Port number of secondary accounting server listens for client requests.
Shared Secret	Shared secret between the AP and secondary accounting server.

3. Configure the External Portal parameters. Refer to [Configure External Portal Parameters](#) below for details.
4. Select the **Roaming** check box, if you don't want the Wi-Fi clients to see the splash page when they roam from one AP to another.
5. Select the **Enable Internet Connectivity Detection** check box, if you want to check the internet connectivity and display a portal error page in case of loss of Internet connectivity.
The 'Enable Internet Connectivity Detection' feature can be used to provide feedback to guests when Internet is temporarily unavailable on the guest SSID. When the access point detects that Internet connectivity is not available from the guest VLAN, it automatically redirects all HTTP requests of the guest users to a splash page with a message that Internet is temporarily unavailable. When using the **AP Hosted Splash Page for Click-through** option, a customized splash page included in the bundle with the name "NoInternet.html" is displayed when Internet is down. If this page is not included in the bundle or if external splash page options have been configured, the AP displays a factory default splash page when internet is down.
Note that when Internet is down, guest users will not be able to access local HTTP services as well if the **Enable Internet Connectivity Detection** feature is enabled.
The **Enable Internet Connectivity Detection** feature will not work for a SSID profile configured with GRE.
6. Specify **Login Timeout**, in minutes, for which a wireless user can access the guest network after submitting the portal page.
After the timeout, access to guest network is stopped and the portal page is displayed again. The user has to submit the portal page to regain access to the guest network. If the user disconnects and reconnects to the guest network before his session times out, he does not have to enter his credentials on the splash page. If you are using AirTight Guest Manager and you have specified a login timeout in AirTight Guest Manager, this login timeout overrides the **Login Timeout** setting in the SSID profile.
7. Specify **Blackout Time**, in minutes. This is the time for which a user is not allowed to login after his previous successful session was timed out.
For example, if the session time-out is 1 hour and the blackout time is 30 mins, a user will be timed out one hour after a successful login. Now after this point, the user will not be able to login again for 30 minutes. At the end of 30 minutes, the user can login again.
8. Specify the **Redirect URL**. The browser is redirected to this URL after the user clicks the submit button on the portal page.
If left empty, the browser is redirected to the original URL accessed from the browser for which the portal page was displayed.
9. Specify the value of the **Service Identifier** that you have defined in **Advanced Parameters**. This is a free form parameter that can be passed to the external portal.

This parameter can be used by the external portal to implement SSID profile specific functionality. For example, each SSID can have a separate portal page.

10. Click **Save** to save the settings.

Configure External Portal Parameters

You must configure the external portal parameters if you want to redirect users to a portal page hosted on an external server.

All request and response attributes that are marked with an asterisk are mandatory. The request parameters/attributes are sent from the AP to the external portal. The response parameters are sent from the external portal to the AP. These parameters are used in the name - value pairs in the redirection URL. The following table explains the request and response attributes in detail.

Request Attributes	Description
Request Type	field name for request type field.
Challenge	field name for random text used for authentication.
Client MAC	field name for the MAC address of the client.
AP MAC Address	field name for MAC address of the access point that is communicating with the external portal.
AP IP Address	field name for the IP address of the access point that is communicating with the external portal. This should match the field name used by the external portal.
AP Port Number	field name for the AP port number on which the AP and external server communicate.
Failure Count	field name for the count of the number of failed login attempts.
Requested URL	field name for the requested URL that is the URL requested by the client through the AP, to the external server.
Login URL	field name for the login URL.
Logoff URL	field name for the logoff URL.
Remaining Blackout Time	field name for the remaining blackout time.
Service Identifier	name of the portal parameter that is used to pass the service identifier value to the external portal. The service identifier value is specified in the Captive Portal section of the SSID Profile. This parameter can be used by the external portal to implement SSID profile specific functionality like different portals for different SSIDs etc.
Response Attributes	Description
Challenge	field name for the challenge
Response Type	field name for the response type.
Challenge Response	field name for the challenge response.
Redirect URL	field name for the redirect URL
Login Timeout	field name for login timeout.

User name	field name for user name.
Password	field name for password.
<p>Note: The individual field names used by the AP should match the corresponding field names used by the external server hosting the portal. The AP and the external server may not be able to communicate if the name of the same parameter is different on either side. The fields in External Portal Parameters facilitate the field name change on the AirTight Wi-Fi / AirTight WIPS side.</p>	


Edit Captive Portal Settings

To edit captive portal settings, do the following.

1. Select the **Enable Captive Portal** check box to display a portal page to be shown to the client on using the guest network.
2. Select the mode of access to the Internet through the captive portal. Do one of the following:
 - (a) Select the AP Hosted Splash Page with click through option. You must create a .zip file of the portal page along with any other files like images, style sheets etc and upload this file. The zip file must satisfy the following requirements for the portal to work correctly.
 - a. The zip file should have a file with the name "index.html" at the root level (i.e., outside of any other folder). This is the main portal page. It can have other files and folders, (and folder within folders) at the root level that are referenced by the index.html file.
 - b. The total unzipped size of the files in the bundle should be less than 100 KB. In case, large images or other content is to be displayed on the page, this content can be placed on an external web server with references from the index.html file. In this case, the IP address of the external web server must be included in the list of exempt hosts (see below).
 - c. The index.html file must contain the following HTML tags for the portal to work correctly:
 - A form element with the exact starting tag: `<form method="POST" action="$action">`
 - A submit button inside the above form element with the name "mode_login". For example: `<input type="image" name="mode_login" src="images/login.gif">`The exact tag: `<input type="hidden" name="redirect" value="$redirect">` inside the above form element.

You can download the factory default portal bundle file and use it as a template to create a custom portal bundle. Click **Download Sample** to download the factory default portal bundle file.

Upload the portal bundle (default or custom). Click **Choose File** following **Upload Bundle** to upload the bundle.



Click Open to upload the portal bundle.

To restore the portal bundle to factory default file, click **Restore Default**.

- (b) Select the **External Splash Page for Sign-in/Click-through** option. Specify **Splash Page URL**, using which wireless user will be redirected to external portal. This portal will prompt wireless user to enter username and password. You must select the check box for the shared secret, if applicable, and specify the shared secret for SSID-external portal communication.
- (c) Select **External Splash Page with RADIUS Authentication**.
 In this case, you also need to specify the following fields
Splash Page URL, using which wireless user will be redirected to external portal. You must enter a shared secret for SSID-external portal communication. Click RADIUS settings hyperlink to configure RADIUS server settings, using which the AP will actually authenticate the wireless user.
 Specify the primary and optionally, secondary authentication server details.

Field	Description
Called station id	a free form text parameter that the AP passes to the RADIUS server in the standard RADIUS parameter, 'Called-Station-Id', during the authentication process. The special format specifier '%m' can be specified which will be expanded to the Ethernet MAC address of the AP.
Primary Authentication server details	
Server IP	IP address of primary authentication server.
Port Number	port number of primary authentication server listens for client requests.
Shared Secret	shared secret between the AP and primary authentication server.

Secondary authentication server details	
Server IP	IP address of secondary authentication server.
Port Number	port number of secondary authentication server listens for client requests.
Shared Secret	shared secret between the AP and secondary authentication server.

If you want RADIUS accounting to be enabled, select the accounting check box and specify the accounting details, using which AP will actually authenticate wireless user. In RADIUS Server Settings specify **Server IP** and **Port** on which RADIUS server is running.

Field	Description
Interval	accounting interval, in minutes. Minimum interval can be 1 minute, and maximum interval can be 60 minutes.
Primary accounting server details	
Server IP	IP address of primary accounting server.
Port Number	port number of primary accounting server listens for client requests.
Shared Secret	shared secret between the AP and primary accounting server.
Secondary accounting server details	
Server IP	IP address of secondary accounting server.
Port Number	port number of secondary accounting server listens for client requests.
Shared Secret	shared secret between the AP and secondary accounting server.

- Configure the External Portal parameters. Refer to [Configure External Portal Parameters](#) below for details.
- Select the **Roaming** check box, if you don't want the Wi-Fi clients to see the splash page when they roam from one AP to another.
- Select the **Enable Internet Connectivity Detection** check box, if you want to check the internet connectivity and display a portal error page in case of loss of Internet connectivity. The 'Enable Internet Connectivity Detection' feature can be used to provide feedback to guests when Internet is temporarily unavailable on the guest SSID. When the access point detects that Internet connectivity is not available from the guest VLAN, it automatically redirects all HTTP requests of the guest users to a splash page with a message that Internet is temporarily unavailable. When using the **AP Hosted Splash Page for Click-through** option, a customized splash page included in the bundle with the name "NoInternet.html" is displayed when Internet is down. If this page is not included in the bundle or if external splash page options have been configured, the AP displays a factory default splash page when internet is down. Note that when Internet is down, guest users will not be able to access local HTTP services as well if the **Enable Internet Connectivity Detection** feature is enabled. The **Enable Internet Connectivity Detection** feature will not work for a SSID profile configured with GRE.
- Specify **Login Timeout**, in minutes, for which a wireless user can access the guest network after submitting the portal page. After the timeout, access to guest network is stopped and the portal page is displayed again. The user has to submit the portal page to regain access to the guest network. If the user disconnects and reconnects to the guest network before his session times out, he does not have to enter his credentials on the splash page. If you are using AirTight Guest Manager and you have specified a login timeout in AirTight Guest Manager, this login timeout overrides the **Login Timeout** setting in the SSID profile.

7. Specify **Blackout Time**, in minutes. This is the time for which a user is not allowed to login after his previous successful session was timed out.
For example, if the session time-out is 1 hour and the blackout time is 30 mins, a user will be timed out one hour after a successful login. Now after this point, the user will not be able to login again for 30 minutes. At the end of 30 minutes, the user can login again.
8. Specify the **Redirect URL**. The browser is redirected to this URL after the user clicks the submit button on the portal page.
If left empty, the browser is redirected to the original URL accessed from the browser for which the portal page was displayed.
9. Specify the value of the **Service Identifier** that you have defined in **Advanced Parameters**. This is a free form parameter that can be passed to the external portal.
This parameter can be used by the external portal to implement SSID profile specific functionality. For example, each SSID can have a separate portal page.
10. Click **Save** to save the settings.

Disable Captive Portal

Deselect the **Enable Captive Portal** check box to disable captive portal settings.

Firewall Settings

A firewall controls the incoming and outgoing network traffic, based on a set of defined rules. Click **Firewall** on the **Add SSID Profile** page to configure firewall settings for the SSID profile. You can add, modify, reorder, and delete firewall rules from the **Firewall** section.

The firewall rules defined for the SSID profile are evaluated in a top down manner. That is, the first rule is evaluated first, followed by the next rule, and so on, till a match is found for the respective host name and direction.

When you create a SSID profile, you will notice that the default rule has been set to block all incoming and outgoing requests from any host or domain. Define the default rule by selecting **Allow** or **Block** to allow or block any type of requests from IP addresses, host names, subdomain names or domain names for which no specific firewall rules have been defined.

To enable firewall for the SSID profile, select the **Enable Firewall** check box. If it has been previously selected and you want to disable firewall for the SSID profile, deselect the **Enable Firewall** check box.

Add New Firewall Rule

Do the following to add a firewall rule.

1. Click **Add New Rule**.
2. If one or more rules have already been defined, select **Above the selected rule** or **Below the selected rule** to insert the new rule above or below the selected rule, depending on how you want to prioritize the rules.
3. Enter the rule details as specified in the following table.

Field	Description
Rule Name	name of the rule
Host	domain name, sub domain name, host name, subnet or IP address to which the rule applies. You can provide a comma-separated list of more than one host names


	here. For example, 192.168.8.173, www.facebook.com,192.168.121.0/24.
Port	port number. You can provide a comma-separated list of port numbers or port ranges here. For example, 20-22, 80, 443.
Action	if you want to block the traffic to or from the host option, select block . if you want to allow traffic to or from the host, select allow .
Protocol	network protocol. The following options are available. TCP : If the rule is for TCP-based communication, select the TCP option. UDP : If the rule is for UDP-based communication, select the UDP option. Other : If the rule is for a communication based on a protocol other than TCP and UDP, select Other . You must specify the protocol number in this case. Any : If the rule is for communication that is not protocol specific, select the Any option.
Protocol No.	protocol number. This field appears only when the selected protocol is Other
Direction	direction of network traffic. The following options are available. Outgoing : If the rule is to be applied to data going out of your network, that is, from wireless to wired, then select the Outgoing option. Incoming : If the rule is to be applied to data coming into your network, that is, from wired to wireless, select the Incoming option. Any : If the rule is to be applied to both outgoing and incoming traffic, select the Any option. For instance, if you want to allow or prevent users of your wireless network from accessing certain websites or domains, you can define the respective rule with direction as Outgoing . Similarly, if you want prevent certain hosts from accessing your wireless network, you can define the rule specific to this host name or domain name with direction as Incoming .

For example, if you want to allow all incoming and outgoing TCP requests from and to the host 'mail.google.com', ports 80, 25, 110, 465, 995, you will specify the rule details as follows. Click **Add New Rule** to add the rule.

Specify an appropriate name for the rule in **Rule Name**.

Specify **Host Name** as 'mail.google.com', **Port** as 80, 25,110, 465, 995 **Action** as **Allow**, **Protocol** as **TCP**, **Direction** as **Any**. See the image below for the rule.

Firewall Rule



The screenshot shows a 'Firewall Rule' configuration form with the following fields:

- Rule Name: allow_gmail
- Host: mail.google.com
- Port: 80, 25, 110, 465, 995
- Action: Allow
- Protocol: TCP
- Direction: Any

4. Click **Save** to save the rule.

Reorder Firewall Rules

If you have more than 1 firewall rules defined, you can reorder them.

Do the following to reorder the rules.

1. Click the rule to move.
2. Hold the mouse down and drag the rule to the desired position, for instance between 2 other rules.
3. Release the mouse. The rule is placed at the new position.
4. Click **Save** to save the rule reordering.

Edit Firewall Rule

Do the following to add a firewall rule.

1. Click the radio button for the rule to edit.
2. Edit the rule details as specified in the following table.

Field	Description
Rule Name	name of the rule
Host	domain name, sub domain name, hostname or IP address to which the rule applies. You can provide a comma-separated list of more than one host names here. For example, 192.168.8.173, www.facebook.com, 192.168.121.0/24.
Port	port number. You can provide a comma-separated list of port numbers or port ranges here. For example, 20-22, 80, 443.
Action	if you want to block the traffic to or from the host option, select block. if you want to allow traffic to or from the host, select the allow option.
Protocol	network protocol. The following options are available. TCP : If the rule is for TCP-based communication, select the TCP option. UDP : If the rule is for UDP-based communication, select the UDP option. Other : If the rule is for a communication based on a protocol other than TCP and UDP, select Other . You must specify the protocol number in this case. Any : If the rule is for communication that is not protocol specific, select the Any option.
Protocol No.	protocol number. This field appears only when the selected protocol is 'other'
Direction	direction of network traffic. The following options are available. Outgoing : If the rule is to be applied to data going out of your network, that is, from wireless to wired, then select the Outgoing option. Incoming : If the rule is to be applied to data coming into your network, that is, from wired to wireless, select the Incoming option. Any : If the rule is to be applied to both outgoing and incoming traffic, select the Any option. For instance, if you want to allow or prevent users of your wireless network from accessing certain websites or domains, you can define the respective rule with direction as Outgoing . Similarly, if you want prevent certain hosts from accessing your wireless network, you can define the rule specific to this host name or domain name with direction as Incoming .

Delete Firewall Rule

Do the following to delete a rule.

1. Click the **Delete** hyperlink for a rule to delete the rule.
2. Click **Yes** on the message that appears, to confirm the delete operation. To cancel the delete operation click **No**.

3. Click **Save** to save changes to the set of firewall rules.

Traffic Shaping & QoS

Effective utilization of network bandwidth can be achieved in various ways.

Some of the ways in which you can do this is by setting an upload and download limit for the network, restricting the number of client association, band steering and defining QoS parameters. You can opt for one or more of these ways depending on the network traffic, the applications used on the SSID, and the AirTight device model in use.

Band Steering

When an SSID is configured in both 2.4 GHz and 5 GHz bands, clients that are capable of both bands (b/g/n and a/n) and are operating in one of the bands, can be steered towards the other band to balance the load on the AirTight AP.

This load balancing feature is called band steering. It is available in dual-radio access point models.

It helps in evenly distributing the Wi-Fi clients between the two bands.

Band steering works in a bi-directional manner, steering clients from 2.4 GHz to 5 GHz radio or from 5 GHz to 2.4 GHz radio, to balance the load on the AirTight AP.

Clients connecting to an AP will be steered from 2.4 GHz to 5 GHz or 5 GHz to 2.4 GHz when all the following conditions are satisfied.

- Band steering is enabled on the SSID profile that the client is associated with.
- Client RSSI is equal to and above the RSSI threshold mentioned in **Traffic Shaping and QoS** settings for SSID profile.
- The number of clients on one radio are not more than clients on the other radio plus the Spectrum Load Balancing threshold defined in the device template (under **Radio Advanced Settings**) applied to the AP, counted among all SSIDs associated with the AP.

When you enable band steering, you need to specify the RSSI threshold of the clients. This is required due to the fact that clients with weak signal strength cannot operate effectively in the 5 GHz band and hence should not be steered even if they are capable of operating in 5 GHz.

To configure band steering, do the following.

1. Select the **Enable Band Steering** check box.
2. Specify the **RSSI Threshold** of the client.
3. Click **Save** to save the changes.

Traffic shaping

You can limit the upload and/or download bandwidth on an SSID.

To restrict the upload bandwidth on the SSID, do the following.

1. Select **Restrict upload bandwidth on this SSID to** check box and enter a data rate, from 0 through 1024 Kbps, to restrict the upload bandwidth for the SSID to the value specified here.
2. Click **Save** to save the changes.

To restrict the download bandwidth on the SSID, do the following.

1. Select **Restrict download bandwidth on this SSID to** check box and enter a data rate, from 0 through 1024 Kbps, to restrict the download bandwidth for the SSID to the value specified here.
2. Click **Save** to save the changes.

Large enterprises, sometimes, use RADIUS attributes to propagate network policies across multiple points of access. Users are divided into groups, and policies are applied to each group to effectively control access to network resources. Each user group is assigned an upload bandwidth and a download bandwidth, based on the need of that user group. For instance, the Sales user group would be assigned upload and download bandwidths that differ from the upload and download bandwidths assigned to the HR user group.

In case of clients authenticated using a RADIUS server, you can configure the AirTight AP to retrieve and use the bandwidth control settings defined by the RADIUS server. The unit for bandwidth is Kbps.

Based on the values returned by the RADIUS server, the AirTight AP dynamically sets the upload and download bandwidths for the RADIUS-authenticated user. If the RADIUS server does not return a value for the bandwidths, the default upload and download bandwidth defined in the Traffic Shaping and QoS settings are used. If a user has more than one devices, the bandwidth limit is applied separately on each of these devices. This means that if a user uses 2 devices, and the bandwidth for the user or the user group is 4 Mbps, 4 Mbps is the bandwidth limit applied to each of these devices.

User-specific bandwidth values can come from one or more of the following.

- From portal with external RADIUS authentication server.
- From GAMS portal.
- From the RADIUS server, if SSID is configured with 802.1x security.
- From AirTight server- If no value is returned by either of the above, the default value defined by AirTight server is used.

If bandwidth values are returned by more than one of the above-mentioned sources, the order of precedence to identify the bandwidth limit to apply is the same as mentioned above. That is, external RADIUS authentication server has the highest priority followed by GAMS portal, and then RADIUS server used for 802.1x authentication.

The default AirTight server bandwidth value is used only if none of the other sources return a bandwidth value.

To enable RADIUS-based assignment of bandwidth based on the user group of the RADIUS user, do the following.

1. Navigate to **Configuration>Device Configuration>SSID Profile**.
2. On the Wi-Fi profile tab, add or edit a Wi-Fi profile.
3. Click **Traffic Shaping & QoS**. The section expands.
4. Select the **Enable per User Traffic Control** check box. The fields for **Restrict user upload bandwidth to** and **Restrict client down load bandwidth to** appear.
5. To specify a default bandwidth value for upload bandwidth, select the check box for **Restrict user upload bandwidth to** and specify a value between 0 and 1024 Kbps. This is used when no upload bandwidth is returned by the RADIUS server for the RADIUS user.
6. To specify a default bandwidth value for download bandwidth, select the check box for **Restrict user download bandwidth to** and specify a value between 0 and 1024 Kbps. This is used when no download bandwidth is returned by the RADIUS server for the RADIUS user.

The RADIUS user attributes used to set per user bandwidth fall under vendor specific attributes-IETF ID :26. The vendor ID for AirTight is 16901.

The following table shows the mapping of the AirTight attributes with the RADIUS attributes.

AirTight attribute	RADIUS attribute ID
AirTight Per User Download Limit	5

AirTight Per User Upload Limit	6
---------------------------------------	---

Limit Clients associating with the AP

You can limit the number of clients associating with the AP to restrict the network bandwidth. To limit the number of clients associating with the AP, do the following.

1. Select the **Limit number of associations** check box if you want to specify the maximum number of clients that can associate with the AP.
2. Specify the maximum number of clients in the field next to the **Limit number of associations** check box.
3. Click **Save** to save the changes.

Define Minimum Data Rate

You can specify the minimum data rate for the AP-client communication. Data rates greater than the specified data rate are used to communicate with clients. To specify a minimum data rate, do the following.

1. Select the **Minimum data rate** check box.
2. Specify the minimum data rate for communication in the field adjacent to the **Minimum data rate** check box.
3. Click **Save** to save the changes.

Quality of Service (QoS)

The priority of various types of traffic is defined in QoS. QoS stands for quality of service. The service guarantee is imperative in case of streaming multimedia applications, for example, voice over IP, video, online games etc. It is necessary to define the priority when the network bandwidth is shared for such applications. You must define the QoS parameters if you are using the SSID for such applications. QoS ensures that applications or traffic requiring higher priority gets the required priority. The service guarantee for the service being provided is met by allocating adequate bandwidth based on the QoS priority.

If you configure the radio in 11N mode, WMM (Wi-Fi multimedia) will always be enabled, because WMM is mandatory in 11N mode.

In 11N mode, if the **QoS** check box is not selected, the system uses the default QoS parameters.

The default QoS settings are as follows.

- o SSID priority is voice.
- o Priority type is ceiling.
- o Downstream marking is DSCP.
- o Upstream marking is enabled and the value is 802.1p marking.

The system uses the user-configured QoS settings if the **QoS** check box is selected.

To configure QoS settings, do the following.

1. Select the **QoS** check box and define your own QoS settings for Wi-Fi multimedia on the SSID profile.
2. Specify voice, video, best effort or background as the **SSID Priority** depending on your requirement.
3. Select **Priority Type** as **Fixed** if all traffic of this SSID has to be transmitted at the selected priority irrespective of the priority indicated in the 802.1p or IP header. Select **Priority Type** as **Ceiling** if traffic of this SSID can be transmitted at priorities equal to or lower than the selected priority.
4. Select the **Downstream mapping** option if **Priority Type** is selected as **Ceiling**. The priority is extracted from the selected field (802.1p, DSCP or TOS) and mapped to the wireless access category for the downstream traffic subject to a maximum of the selected SSID Priority. For the downstream mappings, the mapping depends on the first 3 bits (Class selector) of the DSCP value,

TOS value or 802.1p access category. The only exception will be DSCP value 46 which will be mapped to WMM access category 'Voice'.

5. Select the **Upstream marking** option as per the requirement. The incoming wireless access category is mapped to a priority subject to a maximum of the selected SSID priority and set in the 802.1p header and the IP header as selected.
6. Click **Save** to save the changes.

Refer to the following table for downstream mapping.

802.1p Class of Service	802.11e/WMM access category
0 (Background)	1 (Background)
1 (Best Effort)	0 (Best Effort)
2 (Excellent Effort)	3 (Best Effort)
3 (Critical Apps)	4 (Video)
4 (Video)	5 (Video)
5 (Voice)	6 (Voice)
6 (Internetwork Ctrl)	7 (Voice)
7 (Network Ctrl)	7 (Voice)

Refer to the following table for the priority, 802.11e/WMM access category and the corresponding 802.1p Class of Service and DSCP value, used for upstream marking. If 802.1p marking is enabled, the 802.11e/WMM access category maps to the corresponding 802.1p Class of Service. If DSCP/TOS marking is enabled, the 802.11e access category maps to the corresponding DSCP value.

802.11e/WMM access category	802.1p Class of Service	DSCP
0	1	0
1	0	10
2	0	18
3	2	0
4	3	26
5	4	34
6	5	46
7	6	48

BYOD - Device Onboarding

Device onboarding is a technique in which unapproved clients that are quarantined by the system are redirected to a configured splash page URL upon making any web access while all other communication is blocked. This technique can be enabled for all clients or selectively for smart clients, that is, smartphones and tablets only.

AirTight Management Console User Guide

▼ BYOD - Device Onboarding

In Device Onboarding, new clients can be restricted from accessing the network until they are approved. Clients under restriction can be redirected to a portal while all other network access for these clients is blocked. The portal can facilitate self-service or IT personnel-driven client approval. This technique is applicable only to clients connecting to AirTight APs.

■ Enable BYOD - Device Onboarding

Client type: Smartphones/Tablets only All Clients

Redirect to URL:

■ Walled Garden

[Add](#) [Remove](#)

Allow access to these sites when quarantined.

BYOD - Device Onboarding

To configure BYOD device onboarding, do the following.

1. Select the **Enable Device Onboarding** check box to enable BYOD device onboarding.
2. Select **Smartphones/Tablets Only** if you want this technique to be enabled for unapproved smart clients only, and not for other wireless clients (like laptops etc.). Alternatively, select **All Clients** if you want to enable this technique for all types of unapproved wireless clients.
3. Specify the URL of the splash page in **Redirect to URL**. Wireless clients will be redirected to this URL upon making any web request. The IP address or hostname of the splash page host must be added to the walled garden settings for the redirection to work.
4. Configure walled garden settings. Click **Add** to add IP addresses or hostnames to the walled garden. Click **Remove** to remove IP addresses or hostnames from the walled garden. Any other hostname or IP address that needs to be exempted from redirection, can also be added here.
5. Click **Save** to save the changes.

Hotspot 2.0 Settings

Hotspot 2.0 provides automatic network discovery and selection with little or no user intervention. It facilitates cellular offload and Wi-Fi roaming, without the overhead to sign in to the Wi-Fi network manually. The handoff is automatic and is transparent to the mobile user using a Wi-Fi Alliance Passpoint-certified mobile device such as laptop, handheld device, smart phone etc.

Passpoint-certified mobile devices can seamlessly connect to an AirTight AP, if the Wi-Fi profile applied on the AP has Hotspot 2.0 enabled and the corresponding settings configured in it. After Hotspot 2.0 settings configured Wi-Fi profile is applied on the AirTight AP deployed at the operator location, the AP can advertise available network services enabling Passpoint-certified mobile devices to automatically discover and select a Wi-Fi network.

A mobile device can request a Hotspot 2.0 AP for information related to the capabilities and services provided by the AP, without associating with the AP. Based on the information received from the AP, it can decide whether it wants to connect to the AP or not. This communication between the AP and the mobile devices takes place using the Access Network Query Protocol (ANQP).

The Hotspot 2.0 settings for the AP correspond to the ANQP elements sent to a querying mobile device by the Hotspot 2.0 AP to which the Wi-Fi profile is applied.

IMPORTANT! Hotspot 2.0 works only with WPA2 802.1x enterprise security. If you want to configure Hotspot 2.0 functionality, you must first set the value in the security mode field (under Security Settings in the Wi-Fi profile) as WPA2 and ensure that the 802.1x option is selected.

The Hotspot 2.0 settings for an AirTight AP are divided into general settings, roaming consortium list, venue settings, domain name list, 3GPP Cellular network info list, NAI realm list, WAN metrics, Operator Friendly Name List, connection capability.

General Settings

The General Settings refer to the network configuration. It includes the network access type, network authentication type element, IP address type etc.

The network type is a predefined list and can have one of the following values.

- **Private network**- Unauthorized users are not permitted on this network. Examples of this access network type are home networks and enterprise networks, which may employ user accounts.
- **Private network with guest access**- The network is a private network offering guest access. An example of this access network type is an enterprise network with guest access.
- **Chargeable public network**- A public network that is available to everyone for a charge. An example of this access network type is a hotel offering in-room Internet access service for a fee.
- **Free public network**- A public network that is available to everyone for free. An example of this access network type is an airport hotspot.
- **Personal device network** - A network of personal devices such as a camera connecting to a printer thereby forming a network to print pictures.
- **Emergency services only network**- The network is dedicated and limited to accessing emergency services only.
- **Test or experimental**- The network is a test or experimental network only.
- **Wildcard**- Wildcard access network type. Select this option if you want the AP to reply to the client (mobile device) irrespective of the access network type requested for in the client query.

The **network authentication element** refers to the list of authentication types. This element is related to captive portal based authentication systems. A redirect URL can be specified in the General Settings to redirect the mobile user to the appropriate URL on connecting to the AP.

The network authentication element is a predefined list and can have one of the following values.

- **Acceptance of terms and conditions**- Select this option if the network requires the user to accept a set of terms and conditions. You can provide a URL that points to the terms and conditions page in the **Redirect URL** field. Providing redirect URL is optional.
- **Online enrollment**- Select this option if online enrolment is supported by the network.
- **http/https redirection**- Select this option if the network infrastructure perform http/https redirection. You can optionally provide a redirect URL for http/https redirection.
- **DNS redirection**- Select this option if the network supports DNS redirection.
- **Not configured**- Select this option if you don't want to provide specific information when the client queries about network authorization type.

The **Homogenous ESSID** (HESSID) is a MAC address that is the same for all APs belonging to the same network. APs with the same HESSID have the same Hotspot 2.0 configuration.

IPv4 address type and IPv6 address type are specified under General Settings.

Roaming Consortiums Element

The roaming consortiums element is configured under Roaming Consortium List. The network could be member of a roaming consortium or could support service providers. The element consists of one or more organization identifiers that are unique hexadecimal strings. If this element contains multiple organization identifiers, it means the network supports multiple service providers or consortia.

Venue Settings

The Venue Settings specify the configuration of the venue details where the AP is to be deployed. You can configure zero or more venues. The venue settings consist of venue groups and venue types. The venue group is selected from a predefined list of values. The venue type is dependent on the venue group and the list of values for the venue type is populated based on the venue type selected. You can select a venue type for the venue group from the list of relevant values for the selected venue group.

The available venue groups are as follows.

- **Assembly:** An arena or an amusement park is a place where a group of people assemble together. Select this venue group if the AP is deployed at such a location.
- **Business:** If the AP is deployed on business premises such as a bank or an office, select this venue group.
- **Educational:** If the AP is deployed at an educational institution such as a school or a university, select this venue group.
- **Factory and Industrial:** If the AP is deployed at a factory or industrial location, select this venue group.
- **Institutional:** If the AP is deployed at a venue hospital or a rehabilitation center, select this venue group.
- **Mercantile:** If the AP is deployed at a mercantile venue such as a gas station or a shopping mall, select this venue group.
- **Residential:** If the AP is deployed at a residential location such as a hotel or a private residence, select this venue group.
- **Storage:** If the AP is deployed at a storage facility, select this venue group.
- **Utility and Miscellaneous:** If AP is deployed at a utility or miscellaneous location, select this venue group.
- **Vehicular:** If the AP is deployed on a vehicle such as a train or a boat, select this venue group.
- **Outdoor:** If the AP is deployed at an outdoor location such as a kiosk or a bus stop, select this venue group.

Domain Name List

The Domain Name List provides a list of the Hotspot 2.0 operator domain names.

3GPP Cellular Network Info List

The list of mobile networks supported by the AP can be configured under 3GPP Cellular Network Info List.

NAI Realm List

The NAI Realm List corresponds to the NAI realm element. The NAI realm element provides a list of network access identifier (NAI) realms corresponding to service providers or other entities whose networks or services are accessible through the AP. A list of one or more EAP Methods is optionally included for each NAI realm.

WAN Metrics

Under WAN metrics, you can specify details of the WAN connection available through the WLAN. The link status and the uplink and downlink speeds can be specified under WAN metrics. Under operator friendly name list, you can enter a list of operator friendly names along with the language code in which they are provided to AirTight Management Console.

Connection Capability

Under connection capability, you can specify the protocols supported by the network connection and the corresponding port numbers and whether the port is open or closed. These settings signify the capabilities of the wired network that the AP is connected to. They provide information on the connection status of the most commonly used communication protocols and ports within the hotspot.

Configure Hotspot 2.0 Settings

To configure Hotspot 2.0 Settings, do the following.

1. Select the **Hotspot 2.0** tab in the **Add Wi-Fi Profile** or **Edit Wi-Fi Profile** dialog box.
2. Configure the **General Settings**.

Field	Description
Network Type	Select the appropriate network type that the AP is a part of, from the list of available options.
Network Auth Type	Select the network authentication type from the list of available options.
IPv4 Address	Select the appropriate IPv4 address type from the available options. The following options are available. Address type not available Public IPv4 address available Port-restricted IPv4 address available Single NATed private IPv4 address available Double NATed private IPv4 address available Port-restricted IPv4 address and single NATed private IPv4 address available Port-restricted IPv4 address and double NATed private IPv4 address available For NAT related options, NAT must be enabled on the Wi-Fi profile.
Internet Access	Select this check box if the network provides Internet access to the client through the AP.
HESSID	Homogenous Extended Service Set Identifier. This is an optional field used to identify hotspot APs. APs with the same HESSID have the same Hotspot 2.0 configuration.
Redirect URL	URL to which the user is to be redirected on connecting to the AP. This field is used in conjunction with network authentication type.
IPv6 Address	Select the appropriate IPv6 address type from the available options. The following options are available Address type not available Address type available Availability of address type not known

3. Enter the roaming consortium list using hex characters. The first 3 roaming consortium from the list are advertised in the beacon. Up to 32 roaming consortiums can be added here. The length of the roaming consortium string must be 3 or 5 bytes, that is 6 or 10 hex characters.
4. Enter the venue details as described in the following table and click **Add** for each venue information that you add.

Field	Description
Venue Group	Select the appropriate venue group from the available options.
Venue Type	Select the type of venue at which the AP is installed. Different options are presented based on the venue group selected. For example, when you select the venue group as Educational, the

Field	Description
	options available for Venue type are unspecified Educational; School, Primary; School, Secondary; and University or College
Venue Name	Name of the venue. Maximum length is 252 bytes. Up to 32 venue names can be added.
Language Code	The language code in which the service is to be provided. Refer to the ISO 639.2 standard for the language codes.

- Enter domain name of the Hotspot 2.0 operator. Click **Add** to add it. You can enter multiple domain names in this manner. A maximum of 32 domains can be added. The size of the domain name must not exceed 255 bytes.
- Under 3GPP Cellular Network Info List, enter the 3 digit mobile country code, the 2-3 digit mobile network code and click **Add** to add to the list. You can add up to 32 entries here.
- Enter the NAI Realm and click **Add**. You can add upto 32 such realms, each with length upto 255 bytes.
- Select the EAP method for that realm and click **Add**. You can add upto four EAP methods for one realm. You can see the EAP methods specified for a particular realm when you click the **EAP Settings** link for that Realm in the **Realm** box. The EAP methods must be added in the sequence of preference. The most preferred EAP method must be added first, followed by the second preferred method and so on.
- Enter the WAN metrics as described the table below.

Field	Description
Link Status	Select the appropriate option. The following options are available. Link up - Select this option if the link is up. Link down - Select this option if the link is down. Link in test - Select this option if the link is under test. Not Configured - Select this option when the link status is not configured.
Symmetric Link Status	Select the Same option if the uplink and downlink speeds are the same. Select the Different option if the uplink and the downlink speeds are different.
Downlink Speed	Downlink speed, in Kbps or Mbps. Select the appropriate unit of measurement of the speed after entering the value for the downlink speed.
Uplink Speed	Uplink speed, in Kbps or Mbps. Select the appropriate unit of measurement of the speed after entering the value for the downlink speed.

- Enter the operator friendly name list details. You can have up to 32 entries in the list.

Field	Description
Name	The operator friendly name of the Hotspot 2.0 operator in different languages. The maximum length must not be more than 252 bytes.
Language Code	The language code in which the operator friendly name has been specified. Refer to the ISO 639.2 standard for the language codes.

- Enter the connection capability details for the network to which the mobile device connects or requests information from. Based on the port configuration, ensure that you have configured an appropriate firewall rule in the firewall settings of the Wi-Fi profile. Refer to the following screenshots for an example of the connection capability and the corresponding rule under firewall settings. In the connection capability, the port is closed for ICMP requests. The complementary firewall rule prevents ICMP requests that might result in a denial-of-service attack. The protocol number 1 in the firewall rule refers to ICMP.

▼ Connection Capability

IP Protocol: ICMP Port Number: ICMP/ESP(IPSec-VPN) (0) Port Status: Closed [Add](#)

IP Protocol	Port Number	Port Status	
ICMP	ICMP/ESP(IPSec-VPN) (0)	Closed	

▼ Firewall

Enable Firewall [Add New Rule](#)

Rule Name: icmp_block Host: Port: [Delete](#)

Action: Block Protocol: Other Direction: Any

Protocol No.: 1

Default Rule: Allow

- Rules are compared top to bottom till the first match. Drag rules to reorder. Last rule is the default rule.
- Host field in the rule can be domain (e.g. domain.com), IP address, subnet (e.g. 192.168.0.0/16) or hostname. Domain (e.g. domain.com) also covers its subdomains
- Outgoing direction in the rule means wireless to wire and vice versa.

12. Click **Save**. The Wi-Fi profile with the Hotspot 2.0 settings is saved.

The following image is an example of the Hotspot 2.0 configuration.

It describes a Hotspot 2.0 AP that is a part of a free public educational network at the Aalto University. It is accessible on acceptance of certain terms and conditions. It provides Internet access and the mobile device is redirected to the URL www.example.com/index.html when it connects to the AP and the mobile user attempts to access the Internet. The domain names for the operator are exampleoperator.com and exampleoperator.org. The other settings are as mentioned in the image.

▼ General Settings

Network Type: Free public network HESSID: FF:FF:FF:FF:FF:FF

Network Auth Type: Acceptance of terms and conditions Redirect URL: http://www.example.com/index.html

IPv4 Address: Single NATed private IPv6 Address: Unknown

Internet Access:

AirTight Management Console User Guide

▼ Roaming Consortium List

Roaming Consortium: [Add](#)

 Only first 3 Roaming Consortia will be advertised in a beacon.

Roaming Consortium	
001187	
88d5fd510a	

▼ Venue Settings

Venue Group:

Venue Type:

Venue Name:

Language code: [Add](#)

Venue Name	Language code	
Aalto University	eng	



▼ Domain Name List

Domain name: [Add](#)

Domain name	
exampleoperator.com	
exampleoperator.org	

▼ 3GPP Cellular Network Info List

Mobile country code: Mobile network code: [Add](#)

Mobile country code	Mobile network code	
091	03	
001	10	

▼ NAI Realm List

Realm: [Add](#) EAP method: [Add](#)

Realm		EAP method	
cellularop.co.in	EAP Settings	TLS	
maildir.com	EAP Settings	TTLS_MSCHAPv2	

▼ WAN Metrics

Link Status:

Symmetric Link Status:

Downlink Speed: [0 - 4294967296]

Uplink Speed: [0 - 4294967296]

Manage Network Interface Profiles

A network interface profile represents the tunnel through which network traffic from the configured SSIDs can be routed to a remote endpoint. The remote endpoint then reroutes this traffic to their respective path or destination. A network interface profile is used to configure Ethernet over GRE (EoGRE) settings. Generic Routing Encapsulation (GRE) is a tunneling protocol that can encapsulate a variety of network layer protocols inside virtual point-to-point links over an IP internetwork. EoGRE provides the ability to setup one or more tunnels from the access point to an aggregating device. Traffic from one or multiple SSIDs can be channeled through such tunnels. Multiple such tunnels can be configured.

When you configure network interface profiles, you can specify a primary endpoint and a secondary endpoint. The wireless traffic is bridged to the secondary endpoint if the primary endpoint fails. The secondary endpoint is optional and is functional only if you enable a secondary endpoint and configure the host name and local endpoint VLAN for the secondary endpoint. The secondary endpoint checks for the availability of the primary endpoint and transfers control to the primary endpoint once it is up and running.

A network interface profile must be attached to an SSID profile when you enable remote bridging on the SSID profile.

Add Network Interface Profile

To add a network interface profile, do the following.

1. Go to **Configuration>Device Configuration>Network Interfaces**.
2. Enter the values for the network interface profile fields.

Field	Description
Profile Name	Name of the network interface profile. It can have a maximum length of 260 bytes.
Tunnel Type	Select Tunnel Type as Ethernet over GRE.
Basic Parameters (or Primary Endpoint Parameters)	

Field	Description
Remote Endpoint(IP Address)	The IP address of the primary remote server or endpoint. It can be left blank, if you want to use NTP server IP (from DHCP option 42) as the remote endpoint.
Local Endpoint VLAN	The VLAN ID through which AP will form tunnel to the remote endpoint. . A value between 0 and 4094 should be entered here. Remote Endpoint must be reachable through this VLAN.
Secondary Endpoint Related Parameters	
Enable Secondary Endpoint	Secondary endpoint is remote endpoint to which the wireless traffic is diverted if the primary endpoint goes down. Select this check box if you want to enable a secondary endpoint.
Remote Endpoint(IP Address)	The IP address of the secondary remote server or endpoint. It can be left blank, if you want to use NTP server IP (from DHCP option 42) as the remote endpoint.
Local Endpoint VLAN	The secondary VLAN ID through which the wireless network traffic is to be routed. A value between 0 and 4094 should be entered here. Remote Endpoint must be reachable through this VLAN.
Network Probe Interval	The interval, in seconds, after which the AP checks connectivity with remote endpoint by sending a ping request packet. This can have a value between 10 and 3600. The interval must be a multiple of 10.
Network Ping Retry Count	Count of ping request packets that the AP sends to the remote endpoint. The default value is 3.
Network Ping Timeout	Time, in seconds, till which the AP waits for a ping reply. The default value is 60 seconds.
Prefer Primary Tunnel over Secondary Tunnel	Select the check box if you want the AP to check for the availability of the primary tunnel. If the check box is not selected and the primary tunnel is down, the AP continues to operate on the secondary tunnel.
Ethernet over GRE	
GRE Primary Key	Key in the primary endpoint GRE header. If configured, key should be same at both ends of the tunnel. Key is not mandatory to be configured in GRE tunnel
GRE Secondary Key	Key in the secondary endpoint GRE header. If configured, key should be same at both ends of the tunnel. Key is not mandatory to be configured in GRE tunnel

3. Click Save to save the network interface profile.

Edit Network Interface Profile

To edit a network interface profile, do the following.

1. Go to **Configuration>Device Configuration>Network Interfaces**.
2. Make the necessary changes.

Field	Description
Profile Name	Name of the network interface profile. It can have a maximum length of 260 bytes.
Tunnel Type	Select Tunnel Type as Ethernet over GRE.
Basic Parameters (or Primary Endpoint Parameters)	

Field	Description
Remote Endpoint(IP Address)	The IP address of the primary remote server or endpoint. It can be left blank, if you want to use NTP server IP (from DHCP option 42) as the remote endpoint.
Local Endpoint VLAN	The VLAN ID through which AP will form tunnel to the remote endpoint. A value between 0 and 4094 should be entered here. Remote Endpoint must be reachable through this vlanVLAN.
Secondary Endpoint Related Parameters	
Enable Secondary Endpoint	Secondary endpoint is remote endpoint to which the wireless traffic is diverted if the primary endpoint goes down. Select this check box if you want to enable a secondary endpoint.
Remote Endpoint(IP Address)	The IP address of the secondary remote server or endpoint. It can be left blank, if you want to use NTP server IP (from DHCP option 42) as the remote endpoint.
Local Endpoint VLAN	The secondary VLAN ID through which the wireless network traffic is to be routed. A value between 0 and 4094 should be entered here. Remote Endpoint must be reachable through this VLAN.
Network Probe Interval	The interval, in seconds, after which the AP checks connectivity with remote endpoint by sending a ping request packet. This can have a value between 10 and 3600. The interval must be a multiple of 10.
Network Ping Retry Count	Count of ping request packets that the AP sends to the remote endpoint.
Network Ping Timeout	Time, in seconds, till which the AP waits for a ping reply.
Prefer Primary Tunnel over Secondary Tunnel	Select the check box if you want the AP to check for the availability of the primary tunnel. If the check box is not selected and the primary tunnel is down, the AP continues to operate on the secondary tunnel.
Ethernet over GRE	
GRE Primary Key	Key in the primary endpoint GRE header. If configured, key should be same at both ends of the tunnel. Key is not mandatory to be configured in GRE tunnel
GRE Secondary Key	Key in the secondary endpoint GRE header. If configured, key should be same at both ends of the tunnel. Key is not mandatory to be configured in GRE tunnel

3. Click Save to save the changes.

Change Location for Network Interface Profile

To move the network interface profile to another location, do the following.

1. Go to **Configuration>Device Configuration>Network Interfaces**.
2. Select the location at which the network interface profile has been defined.
3. Select the check box for the network interface that you want to move to another location.
4. Click the change location icon. The Select Location dialog box appears.
5. Select the new location and click OK. The network interface is moved to the new location.

Print Network Interface Profile

You can print all the information seen for all network interface profiles. You can choose the columns to be viewed on the UI by selecting them.

To print the network interface profiles' list for a location, do the following.

1. Go to **Configuration>Device Configuration>Network Interfaces**.
2. Select the location for which you want to print the network interface profiles' list.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the print icon. The print preview of the network interface profiles' list appears.
5. Click **Print** to print the list.

Filter/Search Network Interface Profiles

You can filter the network interface profiles' list based on the profile name or tunnel type.

To filter a network interfaces profiles' list, do the following.

1. Go to **Configuration>Device Configuration>Network Interfaces**.
2. Enter the search/filter criteria in the Quick Search box. You may enter the profile name or the tunnel type to filter the network interface profile data.
3. Press the Enter key. The network interface profiles matching the search/filter criteria are seen in the list.

To select the columns to be made visible on the Network Interfaces page, do the following.

1. Go to **Configuration>Device Configuration>Network Interfaces**.
2. Click a column heading. A down arrow appears at the right of this column.
3. Click the down arrow.
4. Select **Columns** option from the menu that appears.
5. Select the check boxes for the individual columns that are to be made visible on the Network Interfaces page.

Delete Network Interface Profile

You can delete one or more network interface profiles at the same location at a time.

To delete a network interface profile, do the following.

1. Go to **Configuration>Device Configuration>Network Interfaces**.
2. Select the location for which you want to delete the network interface profile.
3. Select one or more network interface profiles to delete and click the bin icon the toolbar. A message asking to confirm deletion of network interface profile appears.
4. Click **Yes** to confirm the deletion.

Manage Mesh Profiles

A wireless mesh network is a network where multiple access points (APs) interconnect and communicate with each other over a wireless link to replace most of the wired connections. The communication between the APs and routing of network data takes place through the AP radios. The APs that form the wireless mesh network are the mesh APs.

Wireless mesh networks are used indoors or outdoors where laying a wired network may not be a cost-effective option. They can be used in specific areas where there is a need to be connected to the network while moving around in the specified area. They can be used in stadiums, schools, military establishments etc.

The source mesh AP communicates with the destination mesh APs in the same mesh directly or through a series of hops from one mesh AP to another until the destination mesh AP is reached. The communication between wireless clients and APs, and communication between APs takes place through wireless or wired networks.

AirTight devices with AP capability support creation of a wireless mesh network. A wireless mesh network, created using AirTight devices, consists of root and non-root APs.

A root AP is an AP that is directly connected to the wired network. A non-root AP is an AP that is not directly connected to the wired network. It connects to the wired network through the root AP. A non-root AP can communicate with the root AP directly, or through another non-root AP. There could be one or more than one root APs and multiple non-root APs in the wireless mesh network.

The root AP connects to a AirTight Wi-Fi/WIPS server through the wired network. All the clients and other non-root mesh APs talk to the AirTight Wi-Fi/WIPS server through the root AP.

AirTight device models with two radios that are capable of operating in AP mode, that is, SS-300-AT-C-55, SS-300-AT-C-55-E, SS-300-AT-C-60, SS-300-AT-O-70, C-75, C-75-E and C-65 support mesh networking. One radio is used as a dedicated mesh radio and the other radio is used to offer Wi-Fi access to wireless clients. This also means that mesh networking is currently supported for a/n and b/g/n platforms, but not supported on the 802.11ac platform.

A mesh network created using AirTight devices is logically implemented as a tree topology. In a tree topology, there is a parent node and there are multiple child nodes. The child node is referred to as a downlink in the mesh profile configuration. The parent node of a child is referred to as an uplink.

Set up a Mesh Network

To set up a wireless mesh network, you must first identify the APs that would behave as mesh APs. The APs could be a combination of different AirTight device models supporting mesh networking, or multiple devices of a single AirTight device model.

You must define a mesh profile on the AirTight Wi-Fi server if you wish to set up a wireless mesh network. A mesh profile represents the mesh network parameters. You can add, edit and delete mesh profiles. The mesh profile defined for the wireless mesh network must be applied to one of the radios of the mesh APs. This radio acts as the dedicated radio to communicate with the other APs on the mesh network. You must apply a device template with per device configuration enabled, to all the mesh APs. Then, you must specify which of the mesh APs are root APs. The other APs in the mesh will be treated as non-root APs, by default.

Once you have defined the mesh parameters and overridden the device template settings for the mesh AP, you will be able to see a pictorial representation of the mesh network topology in the Locations section on the AirTight Management Console. For details on viewing the mesh network topology, refer to the 'View Mesh Topology' section in [Manage Location Layout](#).

IMPORTANT! You cannot create a wireless mesh network that is a combination of AirTight APs and APs from vendors other than AirTight. The mesh network must consist of AirTight APs only.

To set up a wireless mesh network for a location, do the following.

1. Select a location from the location tree.

2. Go to **Configuration>Device Configuration>SSID Profiles>Mesh Profiles**.
3. Configure a mesh profile. Refer to the [Add Mesh Profile](#) given below for adding a mesh profiles.
4. Go to **Configuration>Device Configuration>Device Template**.
5. Define a device template for the AirTight device models that are to function as mesh APs. Refer to [Manage Device Templates](#) for details. Remember to enable the device-specific configuration for this device template. Ensure that the channel on which the mesh APs are to communicate with each other is the same for all the AirTight device models that are a part of the wireless mesh network. You must select the channel manually.
6. Go to **Radio Settings** under **Device Template**. Select the mesh profile configured in one of the previous steps mentioned in this procedure.
7. Configure other device template details and click **Save** to save the device template.
8. Connect all the AirTight devices that are to function as mesh APs to the wired network. You must connect all Airtight devices irrespective of whether they are root or non-root APs.
9. Apply the device template to all the devices that are to function as mesh APs.
10. Disconnect the non-root APs from the wired network. Keep the root APs connected to the wired network.
11. Go to **Devices>AirTight Devices**. Specify the root AP or APs in the wireless mesh network. For further details on specifying the root and non-root APs, refer to [Override Device Template Settings](#) section. You are done with configuring the mesh network.

Add Mesh Profile

IMPORTANT!: Configuration of mesh profile on both radios is not supported. Configuration of mesh profile on one radio and WIPS mode on another radio of an AirTight device is not supported. DFS channels are not available when you manually select channels on the radio on which mesh profile is configured.

To add a mesh profile, do the following.

1. Go to **Configuration>Device Configuration>SSID Profiles>Mesh Profiles**.
2. Select a location from the location tree. A list of mesh profiles available at the location, if any, is seen in **Mesh Profiles**.
3. Click **Add New Mesh Profile**.
4. Specify the mesh profile parameters.

Field	Description
Profile Name	Name of the mesh profile.
SSID	SSID of the mesh profile. This is the network name of the mesh network.
Max Hop Count	Maximum number of hops in which the wired network can be reached. For instance, the number of hops for a root AP would be 0 as it is directly connected to the wired network. Similarly, the hops for a non-root AP directly communicating with the root AP it is 1.
Max downlinks	Maximum number of mesh APs that can directly connect to a non-root or root AP in the mesh network. This indicates the maximum number of child nodes that a parent node can have in the mesh tree topology. You can enter a value between 0 and 5.
Min RSSI	Minimum RSSI for an AP to connect to another AP in the mesh. An AP requesting to connect to another AP should have the specified RSSI to be able to connect to the other AP. You can enter a value between -100 and 0 dbm.

5. Click **Save** to save the newly added mesh profile.

Edit Mesh Profile

To edit a mesh profile, do the following.

1. Go to **Configuration>Device Configuration>SSID Profiles>Mesh Profiles**.
2. Select the location of the mesh profile to be edited, from the location tree. A list of mesh profiles available at the location is seen in **Mesh Profiles**.
3. Click the name of the mesh profile to edit.
4. Edit the mesh profile parameters.

Field	Description
Profile Name	Name of the mesh profile.
SSID	SSID of the mesh profile. This is the network name of the mesh network.
Max Hop Count	Maximum number of hops in which the wired network can be reached. For instance, the maximum number of hops for a root AP would be 0 as it is directly connected to the wired network. Similarly, the maximum hops for a non-root AP directly communicating with the root AP it is 1.
Max downlinks	Maximum number of mesh APs that can directly connect to a non-root or root AP in the mesh network. This indicates the maximum number of child nodes that a parent node can have in the mesh tree topology. You can enter a value between 0 and 5.
Min RSSI	Minimum RSSI for an AP to connect to another AP in the mesh. An AP requesting to connect to another AP should have the specified RSSI to be able to connect to the other AP. You can enter a value between -100 and 0 dbm.

5. Click **Save** to save the changes to the mesh profile.

Create Copy of Mesh Profile

You can create a copy of a mesh profile and use it as a distinct mesh profile by making minor modifications to it.

To create a copy of a mesh profile, do the following.

1. Go to **Configuration>Device Configuration>SSID Profiles>Mesh Profiles**.
2. Select the location of the mesh profile from the location tree. A list of mesh profiles available at the location is seen in **Mesh Profiles**.
3. Click the name of the mesh profile to save with another name.
4. Change the name of the mesh profile. Change any other parameters as required.

Field	Description
SSID	SSID of the mesh profile. This is the network name of the mesh network.
Max Hop Count	Maximum number of hops in which the wired network can be reached. For instance, the maximum number of hops for a root AP would be 0 as it is directly connected to the wired network. Similarly, the maximum hops for a non-root AP directly communicating with the root AP it is 1.
Max downlinks	Maximum number of mesh APs that can directly connect to a non-root or root AP in the mesh network. This indicates the maximum number of child nodes that a

	parent node can have in the mesh tree topology. You can enter a value between 0 and 5.
Min RSSI	Minimum RSSI for an AP to connect to another AP in the mesh. An AP requesting to connect to another AP should have the specified RSSI to be able to connect to the other AP. You can enter a value between -100 and 0 dbm.

5. Click **Save** to save the changes to the mesh profile.

Copy Mesh Profile to Another Location

To copy a mesh profile from one location to another, do the following.

1. Go to **Configuration>Device Configuration>SSID Profiles>Mesh Profiles**.
2. Select the location at which the mesh file to copy has been created. A list of mesh profiles at the location is displayed.
3. Select the mesh profile to be copied to another location.
4. Click the Copy to location icon. The Select Location dialog box appears.
5. Select the location to which you want to copy the mesh profile.
6. Click OK. A copy of the selected mesh profile is created at the selected location.

Print List of Mesh Profiles for Location

You can print a list of mesh profiles that have been defined for a location.

To print a list of mesh profiles at a location, do the following.

1. Go to **Device Configuration>SSID Profiles>Mesh Profiles** tab.
2. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
3. Click the Print icon. A print preview of the list appears.
4. Click **Print** to print the list.

Delete Mesh Profile

You cannot delete a mesh profile that is in use.

To delete a mesh profile, do the following.

1. Go to **Configuration>Device Configuration>SSID Profiles>Mesh Profiles**.
2. Select the location at which the mesh file to delete has been created. A list of mesh profiles at the location is displayed.
3. Select the mesh profile to be deleted.
4. Click the Delete icon. A message asking to confirm deletion of the mesh profile appears.
5. Select **Yes** to confirm deletion and delete the mesh profile.

Configure Event Notification

The occurrence of certain events needs to be notified to external entities like Syslog, SNMP, Arcsight and OPSEC. This configuration is done using the **Configuration->Events->Configuration** option.

Different types of events occur when the WLAN is functional. These are classified as security, performance and system events by AirTight Management Console. Each of these types is listed in the respective tab on the **Configuration** page.

Security events indicate security vulnerability or breach in your network. Security events are further classified as follows.

- Misconfigured AP events
- DoS events
- Reconnaissance events
- Rogue AP events
- Man-in-the-middle events
- Ad hoc events
- Cracking events
- MAC spoofing events
- Misbehaving clients events
- Prevention events

Performance events indicate problems in the wireless network. Performance events are further classified as follows.

- Coverage events
- Configuration events
- Bandwidth events
- Interference events

System events indicate the system health. System events are further classified as follows.

- Troubleshooting events
- Sensor events
- Server events

There are multiple events under each of the security, performance and system event sub-categories.

Some events need to be displayed on the console when they occur. Users or administrators need to be notified by email when certain events occur. Configure the settings for the events occurring in AirTight Management Console using the **Configuration** page.

Do either or all of the following to configure settings for individual events in either of the tabs **Security**, **Performance**, and **System**, based on your requirement.

- Select the **Display** check box that corresponds to the event that you want to appear on the **Events** page.
- Select the **Email** check box that corresponds to the event for which you want to send e-mail notifications to users configured under **Configuration->Events->Email Recipients**.
- Select the **Notify** check box that corresponds to the event for which you want notifications sent to external agents such as SNMP, Syslog, ArcSight, and OPSEC.
- Select the **Vulnerability** check box that corresponds to the event that makes the WLAN vulnerable. If any of these events occur, the **Security Status** widget on the **Dashboard** displays the status as **Vulnerable**.
- Select the option **High**, **Medium**, or **Low** based on the severity of each event.

Note: The event 'Client RF Signature Anomaly Detected' that is visible under Security>MAC Spoofing option is available in specific deployments only.


Activate Event Generation for Location

Activate event generation for the selected location using the **Configuration>Events>Event Activation** option.

Activation Switch defines the high level administrative settings for the selected location. It takes precedence over any conflicting policies.

Event generation does not happen unless you select the **Activate Event Generation for Location <selected location>** check box.

The following figure explains event generation activation.



Activate Event Generation

IMPORTANT: This policy cannot be inherited from the parent- it is specific to the location.

It is recommended that the deployment be stable and fully configured before you select the **Activate Event Generation for Location <selected location>** check box.

Click **Save** to save the changes made to the page. Click **Cancel** to cancel the unsaved changes on the page. Click **Restore Defaults** to restore the default values of the fields on the page.

Configure Email Recipients

Specify the e-mail addresses of the users that need to be notified on occurrence of certain events at the selected location. The events for which e-mail is to be sent are configured under **Configuration->Events->Email Recipients**.

You can use the e-mail addresses available in the system or add an e-mail address that is not available in the system.

Separate all the e-mail addresses using a comma or a space, or press **Tab** or **Enter**. Click **Save** to save the changes made to the page. Click **Cancel** to cancel the unsaved changes on the page. Click **Restore Defaults** to restore the default values of the fields on the page.

Configure Device - Server Communication Settings

Go to **Configuration>System>Advanced Settings>Device Communication Key**, to set or reset the communication key used for the communication between the AirTight devices and the AirTight Management Console server. The communication key is also used to encrypt the communication between the AirTight devices and server. The communication can happen either using a key or using a pass phrase.

Use Key for Device - Server Communication

You can set the key for the communication between AirTight devices and the AirTight server directly in hexadecimals. Select this option if you are comfortable working with hexadecimals.

To set a hexadecimal key for device-server communication, do the following.

1. Go to **Configuration>System>Advanced Settings>Device Communication Key**.
- 1 Select the **Key** option to use a key for the communication.
- 2 Enter a 32 digit hexadecimal key in **Enter Key**.
- 3 Enter the same key again in **Confirm Key**.
- 4 Click **Set** to save the changes.

Use Passphrase for Device - Server Communication

You can set an alphanumeric passphrase for the communication between AirTight devices and the AirTight server. Select the Passphrase option if you are not comfortable working with hexadecimals.

To set an alphanumeric passphrase for device-server communication, do the following.

2. Go to **Configuration>System>Advanced Settings>Device Communication Key**.
- 5 Select the **Passphrase** option to use a key for the communication.
- 6 Enter an alphanumeric passphrase in **Enter Passphrase**.
- 7 Enter the same passphrase again in **Confirm Passphrase**.
- 8 Click **Set** to save the changes.

Reset Communication Key

Click **Restore Defaults** to reset the communication key.

Manage Policy Templates

Policy templates form a part of the authorized WLAN policy for a location. A policy template comprises properties of the authorized SSIDs or networks. It is a collection of different network related settings such as wireless network protocols, encryption protocol used, allowed network SSIDs, security settings, authentication type used, allowed networks, and so on. You can have multiple such templates based on the number of authorized networks in the organization.

Policy templates aid in the classification of APs. Policy templates are used to identify authorized APs and constantly check that the actual Wi-Fi access parameters provisioned on the authorized APs meet the security policy. Any new AP that is added to a location is verified on the basis of the WLAN policy templates attached to that location.

You can define multiple WLAN policy templates and assign them to each location.

You can add, edit, search, and delete policy templates. You can save a policy template with a different name and then make minor changes to suit your need. You can copy a policy template to another location. The following sections explain these operations in detail.

Add Policy Template

You can add a new policy template and then apply it to a location.

To add a new policy template, do the following.

1. Go to **Configuration>WIPS>Authorized WLAN Policy**.
2. Select a location from the location tree.
3. Select the **Wi-Fi is deployed at this location** check box. The **Policy Template** and **Select "No Wi-Fi" Networks** sections on this page are enabled on selecting this check box.
4. Click **Add New Policy Template** to add a new policy template. The **Add New Policy Template** dialog box appears. Refer to the following table to define the properties of the policy templates related to authorized SSIDs.

Field	Description
Authorized SSID	Name of the existing or new authorized SSID or network name. The existing SSID template list is built using the data received from sensors. You can also enter a new name.
Template Name	Name of the authorized policy template.
Description	Short description to identify the policy template.
This is Guest SSID	Select this check box if this SSID is a guest SSID.
Network Protocol	The network protocol of the SSID. 'Any' is the default value. You can select one or more protocols from 802.11a, 802.11b, and 802.11b/g after deselecting 'Any'.
Security Settings	Security protocol for the SSID. 'Any' is the default value. You can select one or more protocols from 802.11i, Open, WPA, WEP after deselecting 'Any'.
Encryption Protocol	Encryption protocol for the SSID. This field is enabled only when the security protocol for the SSID is WPA or 802.11i.
Authentication Framework	Authentication protocols for the SSID. This field is enabled only when the security protocol for the SSID is WPA or 802.11i.

Authentication Type	Higher layer authentication types that clients can use while connecting to the SSID. Authentication types do not determine the classification of APs, but are used to raise an event if a client uses non-allowed authentication type. The system raises this event only if the system sees authentication protocol handshake frames. 'Any' is the default value. You can select one or more options from PEAP, EAP-TLS, LEAP, EAP-TTLS, EAP-FAST, and EAP-SIM after deselecting 'Any'.
AP Capabilities	Additional capabilities of the APs. If you select any of these advanced capabilities, the classification logic allows APs with and without these capabilities. 'Any' is the default value. You can select one or more Turbo/Super techniques used by Atheros to get higher throughputs—Turbo, 802.11n, and SuperAG, after deselecting 'Any'.
MFP/802.11w	Indicates whether MFP/802.11w is enabled or disabled on the SSID. 'Any' is the default value. You can select an option from MFP/802.11w enabled or MFP/802.11 disabled, after deselecting 'Any'.
Allowed Networks	Select the network(s) where wireless traffic on the SSID is to be mapped through Authorized APs. Select Any to allow wireless traffic on this SSID to be mapped to any network. Alternatively, you can deselect Any and choose from networks that are discovered automatically by the system or add new networks that are not yet discovered by the system.
Allowed AP Vendors	Allowed AP vendors whose APs are allowed to be connected to the SSID or network. 'Any' is the default value. You can select one or more vendors from a predefined list of AP vendors. Deselect 'Any' to be able to select specific vendors.
Apply this Policy Template to current location	Select the check box to apply the policy template to the selected location. Unless this check box is selected, the WLAN will not be evaluated against this policy template.

5. Click **Save**.

Edit Policy Template

You can edit a policy template only at a location where the policy template has been defined.

To edit a policy template, do the following.

1. Go to **Configuration>WIPS>Authorized WLAN Policy**.
2. Select the location from the location tree where the policy template has been defined.
3. Click the link for the policy template in the policy list. The **Edit Template for an Authorized 802.11 SSID** dialog box appears. Make changes to the fields on this dialog box as required. Refer to the following table to define the properties of the policy templates related to authorized SSIDs.

Field	Description
Authorized SSID	Name of the existing or new authorized SSID or network name. The existing SSID template list is built using the data received from sensors.
Template Name	Name of the authorized policy template.
Description	Short description to identify the policy template.
This is Guest SSID	Select this check box if this SSID is a guest SSID.
Network	The network protocol of the SSID. 'Any' is the default value. You can

Protocol	select one or more protocols from 802.11a, 802.11b, and 802.11b/g after deselecting 'Any'.
Security Settings	Security protocol for the SSID. 'Any' is the default value. You can select one or more protocols from 802.11i, Open, WPA, WEP after deselecting 'Any'.
Encryption Protocol	Encryption protocol for the SSID. This field is enabled only when the security protocol for the SSID is WPA or 802.11i.
Authentication Framework	Authentication protocols for the SSID. This field is enabled only when the security protocol for the SSID is WPA or 802.11i.
Authentication Type	Higher layer authentication types that clients can use while connecting to the SSID. Authentication types do not determine the classification of APs, but are used to raise an event if a client uses non-allowed authentication type. The system raises this event only if the system sees authentication protocol handshake frames. 'Any' is the default value. You can select one or more options from PEAP, EAP-TLS, LEAP, EAP-TTLS, EAP-FAST, and EAP-SIM after deselecting 'Any'.
AP Capabilities	Additional capabilities of the APs. If you select any of these advanced capabilities, the classification logic allows APs with and without these capabilities. 'Any' is the default value. You can select one or more Turbo/Super techniques used by Atheros to get higher throughputs—Turbo, 802.11n, and SuperAG, after deselecting 'Any'.
MFP/802.11w	Indicates whether MFP/802.11w is enabled or disabled on the SSID. 'Any' is the default value. You can select an option from MFP/802.11w enabled or MFP/802.11 disabled, after deselecting 'Any'.
Allowed Networks	Select the network(s) where wireless traffic on the SSID is to be mapped through Authorized APs. Select Any to allow wireless traffic on this SSID to be mapped to any network. Alternatively, you can deselect Any and choose from networks that are discovered automatically by the system or add new networks that are not yet discovered by the system.
Allowed AP Vendors	Allowed AP vendors whose APs are allowed to be connected to the SSID or network. 'Any' is the default value. You can select one or more vendors from a predefined list of AP vendors. Deselect 'Any' to be able to select specific vendors.
Apply this Policy Template to current location	Select the check box to apply the policy template to the selected location. Unless this check box is selected, the WLAN will not be evaluated against this policy template.

4. Click **Save**.

Search Policy Template

You can search for policy templates from the policy template list based on their name or SSID. The policy templates list is filtered on the basis of the search string.

To search a policy template, do the following.

1. Select a location from the location tree.
2. Navigate to **Configuration>WIPS>Authorized WLAN Policy**.
3. Enter the SSID or the policy template name in the Quick Search box seen on the left hand corner above the policy templates list.
4. Press the **Enter** key.

5. The policy templates containing the search string as the SSID or policy template name are displayed in the policy template. The search utility also returns the policy templates having the search string as a substring in the SSID or policy template name.

Copy Policy Template to Another Location

To copy an authorized WLAN policy created at a location to another location, do the following.

1. Select the location at which the policy to be copied exists.
2. Go to **Configuration>WIPS>Authorized WLAN Policy**.
3. Select the check box for the WLAN policy to be copied.
4. Click the Copy to icon seen below the policy list. The **Select Locations** dialog box appears.
5. Select the location to which you want to copy the selected policy and click **OK**. The WLAN policy is copied to the selected location.

Save Policy Template with a Different Name

If you want to create a new policy template that has almost the same settings as that of an existing policy template, you can make a copy of an existing policy template, and then tweak it.

To make a copy of a policy template or save an existing policy template with a different name, do the following.

1. Go to **Configuration>WIPS>Authorized WLAN Policy**.
2. Select the location at which you have created the policy template.
3. Click the link for the policy template in the policy template list. The **Edit Template for an Authorized 802.11 SSID** dialog box appears.
4. Edit the template name and, if required, make changes to other fields.
5. Click **Save As**. The policy template is saved with the new name, and modified values, if any.

Print Policy Template List

You can print a list of policy templates that have been defined for an authorized WLAN policy for a location.

To print a list of policy templates for an authorized WLAN policy at a location, do the following.

1. Go to **Configuration>WIPS>Authorized WLAN Policy**.
2. Select the location for which you want to print the policy template list. If the selected location is not the root location, The print icon is enabled only if the authorized WLAN policy is customized for the selected location.
3. Click the print icon. A print preview of the policy template list appears.
4. Click **Print** to print the list of policy templates for the location.

Delete Policy Template

This option is enabled only at the location where the template was created, and only if the template is not applied at any other child locations of the location where it was created.

To delete a policy template, do the following.

1. Go to **Configuration>WIPS>Authorized WLAN Policy**.
2. Select the location at which the policy template has been created.
3. Select the check box for the policy template to be deleted, from the policy template list.
4. Click the Delete icon to delete the policy template. A confirmation message appears.
5. Click **Yes** to delete the policy template. The policy template is deleted from the policy list.

Manage Authorized WLAN Policy

Specify the Authorized WLAN policy templates for the selected location in the location hierarchy using **Configuration>WIPS>Authorized WLAN Policy**.

Authorized WLAN policy for a location includes a set of one or more policy templates that define the properties of one or more authorized wireless networks. A policy template is a collection of different network related settings such as wireless network protocols, encryption protocol used, allowed network SSIDs, security settings, authentication type used, allowed networks and so on. An authorized WLAN policy also specifies what networks are restricted from having Wi-Fi APs on them. Apart from this, you can also specify what APs to categorize as rogue or authorized APs based on their RSSI signal strength. All these parameters together constitute an authorized WLAN policy.

The RSSI of a device is statistical parameter. Using the RSSI feature can cause legitimate neighborhood APs to be classified as Rogues and subjected to containment if automatic prevention is enabled. This will cause neighbor Wi-Fi disruption since clients, including the legitimate neighborhood clients, will NOT be able to connect to the Rogue AP under containment.

Even if the intention is to use RSSI to identify APs that are within the facility, it will not always work since low power APs such as soft APs, hotspot APs running on smart phones, USB APs, etc. or APs which are away from RSSI measurement point will still not get classified as Rogue APs due to not meeting the RSSI threshold.

Policy templates aid in the classification of APs. A new AP or an existing Authorized AP is compared against the templates to determine if it is a rogue or misconfigured AP. Any AP at a location that does not comply with the WLAN policy attached to that location, is not considered to be an authorized AP.

You must apply the templates from the available list for the WLAN policy at that location.

Authorized policy templates are used to identify authorized APs and constantly check that the actual Wi-Fi access parameters provisioned on the authorized APs meet the security policy. You can define multiple WLAN policy templates and assign them to each location. Any new AP that is added to a location is verified on the basis of the WLAN policy templates attached to that location. Any mismatch is used to detect misconfiguration of the Wi-Fi access network.

The system uses the details of the authorized Wi-Fi setup at a particular location to detect the presence of misconfigured or rogue APs in your network.

An AP is considered as being compliant to the Authorized WLAN Policy if:

- It is not connected to a No Wi-Fi network for its location
- Its SSID matches with one of the templates attached at that location
- Is connected to one of the networks specified in that template
- Conforms to the other settings in that template (except the Authentication Framework, as this setting is not a property of the AP itself but of the backend authentication system).

Note: If the template specifies certain allowed AP capabilities (such as Turbo, 802.11n, and so on), the AP may or may not have those capabilities. However, if a capability is not selected, the AP must not have that capability to be considered as compliant.

With location-based policies, you can apply different sets of policy templates for different locations. However, you cannot attach more than one template with the same SSID at any one location.

Only the policy templates that are applied to a location are used for AP classification at that location. Other templates that are configured but not applied to the location, will not be used for AP classification, as they are not a part of the WLAN policy for that location.

The authorized policy templates created at other locations can be applied to a selected location but cannot be edited or deleted. The edit and delete operations are possible only at the location where the template is created.

A child location automatically inherits the authorized WLAN policy from its parent. You can customize the WLAN policy for a child location. You can also switch back to an inherited policy in case you have created a customized policy.

Configure Authorized WLAN Policy

To configure an authorized WLAN policy for a location, do the following.

1. Select the location from the location tree.
2. Go to **Configuration>WIPS>Authorized WLAN Policy**.
3. If Wi-Fi has been deployed at the location, select the **Wi-Fi is deployed at this location** check box. The **Policy Template** and **Select "No Wi-Fi" Networks** sections on this page are enabled on selecting this check box.
4. If you want to use an existing policy template, click the Applied icon for the existing policy template to be applied to the location. Alternatively, Click **Add New Policy Template** if no policy template exists, and add a new policy template. Refer to the Add Device Template or Edit Device Template subsection in the [Manage Policy Templates](#) section for details on how to add or edit a policy template.
5. If there are any networks at the location that are not allowed to have APs connected to them,
 - a) Scroll down to the **Select "No Wi-Fi" Networks** section
 - b) Click **Add**. The **Add Networks** dialog box appears.
 - c) Enter the SSID or IP address of the network to add.
6. Define RSSI based classification, if the WIPS is intended for use in an isolated environment without much of a neighborhood activity like defense and military facilities. It is recommended to skip this section altogether in case of commercial or business district environments. Either of the following two mechanisms must be switched on to classify the APs.
 - a) Enter the threshold RSSI value to use for preclassification of APs with signal strength stronger than this value as rogue or unauthorized APs.
 - b) Select the Preclassify APs connected to monitored subnets as Rogue or Authorized APs to preclassify the APs connected to monitored subnets as rogue or authorized APs.
7. Click **Save** to save the changes.

Edit Authorized WLAN Policy

To edit an authorized WLAN policy for a location, do the following.

1. Select the location from the location tree.
- 1 Go to **Configuration>WIPS>Authorized WLAN Policy**.
2. If you want to apply an existing policy, click the Applied icon for that policy in the policy template list.
3. If you want to make changes to the policy template, click the policy template link in the policy template list. If you want to add a new policy template click **Add New Policy Template**, and add a new policy template. Refer to the Add Device Template or Edit Device Template subsections in the [Manage Policy Templates](#) section for details on how to add or edit a policy template.
4. If there are any networks at the location that are not allowed to have APs connected to them,
 - a) Scroll down to the **Select "No Wi-Fi" Networks** section
 - b) Click **Add**. The **Add Networks** dialog box appears.

- c) Enter the SSID or IP address of the network to add.
- 5. Define RSSI based classification, if the WIPS is intended for use in an isolated environment without much of a neighborhood activity like defense and military facilities. It is recommended to skip this section altogether in case of commercial or business district environments. Either of the following two mechanisms must be switched on to classify the APs.
 - a) Enter the threshold RSSI value to use for preclassification of APs with signal strength stronger than this value as rogue or unauthorized APs.
 - b) Select the Preclassify APs connected to monitored subnets as Rogue or Authorized APs to preclassify the APs connected to monitored subnets as rogue or authorized APs.
- 6. Click **Save** to save the changes.

View High Availability Status for Server

View the high availability status using the **Configuration>System>HA Status** page. High Availability (HA) mode allows two servers to be connected in a redundant configuration to form an HA cluster. One server acts as the Active server, while the other as a Standby server. If the Active server fails, the Standby server takes over. This screen shows the status of the servers in HA cluster.

The HA Status page displays information about the high availability. This is read-only information.

The following table describes the fields seen on the HA Status Page.

Field	Description
HA Status	<p>Specifies the high availability status. It has the following possible values.</p> <p>Standalone: This state indicates that the server is in Standalone mode.</p> <p>Up: This state indicates that the HA Cluster is up and running.</p> <p>Other Server Not Reachable: This state indicates that the Standby server is not reachable over the HA interface link. Check whether the HA interfaces of both the servers are securely connected using a crossover Ethernet cable.</p> <p>Temporarily In Transition: This is an intermediate state. You need to wait for up to 30 minutes and then check the HA Status again. If this state persists, contact Technical Support.</p> <p>HA Setup In Progress: This state indicates that an HA setup is in progress using Config Shell or an earlier HA setup session was abnormally terminated. If you are sure HA setup is not in progress, reboot both the servers. After reboot, both the servers come up in the 'Standalone' mode. You need to wait for five minutes after the reboot and then login to these servers.</p> <p>Server Upgrade In Progress: This state indicates that server Upgrade is in progress or an earlier server Upgrade session was abnormally terminated. If you are sure server Upgrade is not in progress, reboot the server. After reboot, the server will come up in the 'Standalone' mode. You need to wait for five minutes after the reboot and then login to the server.</p> <p>Database Operation In Progress: This state indicates that some database operation is in progress. If you are sure no database operation is in progress, please contact Technical Support.</p> <p>Internal System Recovery In Progress: This state indicates that internal system recovery is in progress. If the same state persists for more than 30 minutes, please ensure that both the HA servers are up and the HA interfaces of these servers are securely connected using a crossover Ethernet cable. If the same state persists even after the above checks, please contact Technical Support.</p> <p>Error: This state indicates an error in HA state. Contact Technical Support.</p>
Cluster IP Address	This IP Address can be used by the Console and Sensors to connect to the HA cluster. This is a virtual IP Address used to connect to the HA cluster. Cluster IP address is optional. It can not be used in Layer3 HA configuration.
Data Sync State	Displays the state of data synchronization from Active Server to Standby Server after enabling HA Service or after database operation such as database restore.
Data Sync Link	Data sync link is the link which carries data from the Active Server to Standby. HA

	interface or Network Interface can be used as 'Data Sync Link' between the servers. During HA setup, user can skip use of HA interface. This field indicates whether two servers are reachable over 'Data Sync Link' interface.
HA Failover Mode	This field Indicates whether the HA failover mode is automatic or manual.
Active Server- Network IP Address	This is the IP Address of the network interface of the Active server.
Active Server- HA IP Address	This is the IP Address of the HA interface of the Active server.
Standby Server- Network IP Address	This is the IP Address of the network interface of the standby server.
Standby Server- HA IP Address	This is the IP Address of the HA interface of the standby server.

View/Upgrade License Details

The **Configuration>System Settings>License** page displays information about the license, the list of licensed features enabled on the server.

You can upgrade your current version to enable or disable features using a new license.

To upgrade your license, do the following.

1. Go to **Configuration>System Settings> License**.
2. Under **Change License**, click **Choose File** under **Change License**, and select the path of the new license file.
3. Click **Apply License** to apply the new license. To apply the license effectively, log out and log on to the console.

Current License Information displays the features available in AirTight Management Console through the currently applied license. The following table explains the fields seen on the License page under **Current License Information**.

Field	Description
Expiry Date	Expiry date of the AirTight Management Console license.
Maximum AirTight devices allowed	Maximum number of AirTight devices allowed per the current license.
Allowable Conversions to AP	Maximum number of AirTight devices that are allowed to be converted to function as access point, per the current license.
Reports	Specifies whether the Reports feature is available in the license.
AirTight Mobile	Specifies whether integration with AirTight Mobile is available in the license.
Number of AirTight Mobile devices licensed	The number of AirTight Mobile devices licensed, if AirTight Mobile integration is enabled.
Performance Monitoring	Specifies whether the performance monitoring feature is available in the license or not.
Prevention	Specifies whether the prevention feature is available in the license or not.
Analytics	Specifies whether the analytics feature is available in the license or not.

Forensics	Specifies whether the forensics feature is available in the license or not.
------------------	---

Manage Look and Feel of Reports

You can customize the look and feel of the AirTight Management Console reports, using the **Configuration>System>Advanced Settings>Reports Look and Feel** option.

A report is divided into different sections such as header text, report summary and report sections specifying the details.

You can customize each of these components.

You can customize the text that is seen in various sections in the report.

You can copy the look and feel settings from one server to another server when the source and destination server belong to the same server cluster.

Customize Report Header Text

You can customize the appearance of the header text, title text, report generation information and report description text in a report.

To customize the appearance of the report header text, do the following.

1. Go to **Configuration>System>Advanced Settings>Reports Look and Feel**.
2. Select the **use custom look and feel** check box if you want to customize the reports look and feel.
3. To change the Left Aligned Header Text, enter a new value for the field.
4. To change the Right Aligned Header Text, enter a new value for the field.
5. To change the Title Text, enter a new value for the field.
6. To display the report generation information in a report, select the **Display Report Generation Information** check box.
7. To display the report description in a report, select the **Display Report Description Text** check box.
8. Click **Save** to save the changes.

Customize Summary Table

To customize the appearance of the summary table text, do the following.

1. Go to **Configuration>System>Advanced Settings>Reports Look and Feel**.
2. Select the **use custom look and feel** check box if you want to customize the reports look and feel.
3. To display summary information in a report, select the **Report Summary** check box.
4. To change **Report Summary** text in a report, enter a new value for the field.
5. To include sections with no results in a report, select the **include section with zero results** check box present under **Summary Table**.
6. To display the report summary table in a report, select the **Display report summary table** check box present under **Summary Table Column Header Definition**.
7. To display the section name in a report, select the **Display section name** check box present under **Summary Table Column Header Definition**. To display a different text instead of section name in the report, enter the changed text in **Section Name**.
8. To display the section description in a report, select the **Display section description** check box present under **Summary Table Column Header Definition**. To display a different text instead of section description in the report, enter the changed text in **Section Description**.

9. To display the section query type in a report, select the **Display Query Type** check box present under **Summary Table Column Header Definition**. To display a different text instead of section query type in the report, enter the changed text in **Section Query Type**.
10. To display the result count in a report, select the **Result Count** check box present under **Summary Table Column Header Definition**. To display a different text instead of result count in the report, enter the changed text in **Result Count**.
11. To display the jump to hyperlink in a report, select the **Jump to** check box present under **Summary Table Column Header Definition**. To display a different text instead of jump to in the report, enter changed text in **Jump To**.
12. To display the report data in form of a pie chart or a bar chart in a report, select the appropriate option under **Summary Charts**. If you do not want any charts displayed in the report, select the **Don't display charts** option under **Summary Charts**.
13. Click **Save** to save the changes.

Customize Section Results

To customize the appearance of the section results text, do the following.

1. Go to **Configuration>System>Advanced Settings>Reports Look and Feel**.
2. Select the **use custom look and feel** check box if you want to customize the reports look and feel.
3. To change Section Name Title text in a report, enter a new value for the field.
4. To display section description text in a report, select the Display section description check box.
5. To display section query in a report, select the Display section query check box.
6. Click **Save** to save the changes.

Restore Default Look and Feel Settings

There is no customization for report look and feel, by default look and feel. The reports are structured according to the predefined AirTight Settings.

To revert back to the default look and feel settings for reports, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>Reports Look and Feel**
2. Click **Restore Defaults**.
3. Click **Save** to save the changes.

Copy Reports Look and Feel Settings to Another Server

You can copy the report look and feel settings from one server to another server when both servers are part of the same server cluster. You can copy report look and feel settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy reports look and feel settings, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>Reports Look and Feel** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the report look and feel settings is to be copied.
4. Select the server to which the report look and feel settings is to be copied.
5. Click **OK** to copy the report look and feel settings.

Configure NTP

NTP stands for network time protocol and is used for clock synchronization between computer systems. You can synchronize the AirTight server clock with an NTP server.

You must be a super user to synchronize the server with an NTP server.

You can specify an NTP server and find the time drift between the AirTight server and the NTP server.

Check Time Drift between AirTight server and NTP server

Before synchronizing the AirTight server clock with an NTP server, you check the time drift between the two servers.

To synchronize with an NTP server, do the following.

1. Select the root location (topmost location) in the location tree.
2. Go to **Admin>System Settings>NTP Configuration**.
3. Select the **Enable NTP** check box.
4. Enter the server IP or the host name of the NTP server in NTP server.
5. Click **Check Drift**. The drift details are displayed in the text box adjacent to **Check Drift**.

Synchronize AirTight Server Time with NTP Server

Synchronization with NTP requires the web server on the AirTight server to restart.

To synchronize with an NTP server, do the following.

1. Select the root location (topmost location) in the location tree.
2. Go to **Admin>System Settings>NTP Configuration**.
3. Select the **Enable NTP** check box.
4. Enter the server IP or the host name of the NTP server in NTP server.
5. Click **Sync and Save**. You are prompted to confirm restart of web server.
6. Click **Yes** to synchronize time and save. An appropriate message is displayed in the box adjacent to **Sync and Save** and you are logged out of AirTight Management Console. The AirTight server clock is synchronized with the NTP server.

Disable NTP

If you have enabled NTP and want to disable it, do the following.

1. Select the root location (topmost location) in the location tree.
2. Go to **Admin>System Settings>NTP Configuration**.
3. Deselect the **Enable NTP** check box. Alternatively, click **Restore Defaults**.
4. Click **Save**.

Configure RF Propagation Settings

Set the default AP, Client, and Sensor antenna gain values using the **Configuration>System>Advanced Settings>RF Propagation** option.

Default RF Propagation Settings contains the following options:

- **Default Antenna Gain Values:** Antenna gain is a characteristic of an antenna used for transmitting or receiving signal, defined as gain in power when signal is received (or transmitted) using the antenna.

Note: If better antennas are used, you should increase the gain.

- **Transmitter Losses:** Select the transmitter signal loss value suited to your environment.
 - If your environment has metal or concrete walls, select a higher signal value.
 - If your environment has large spaces where the signal can propagate without much obstruction, select a lower signal loss value

When a device transmits, some loss in power occurs due to antenna connectors, electromagnetic, and environmental factors. This loss might be different in different frequency bands. You can also specify the approximate loss in each band.

- **Signal Decay Values:** Signal propagation depends heavily on environment. The obstacles present in environment might impede signal propagation, limiting its range. It is very difficult to accurately model signal propagation in all kinds of environment, but by fine-tuning the following four constants, you can more or less characterize your environment for signal propagation.

Note: The system uses the first set of parameters when the Planner file is imported; the second set for blank, gif, or jpeg files.

- **Minimum and Maximum Signal Decay Constants** specify the range for the decay exponent, that is, the exponent at which signal decays with distance. **Signal Decay Slope (Beta)** and **Signal Decay Inflection (Alpha)** control how the decay exponent changes from its minimum value to maximum value.
- For Nodes with imported AirTight Planner file you can specify the following:
 - Minimum Signal Decay Constant
 - Maximum Signal Decay Constant
 - Signal Decay Slope (Beta)
 - Signal Decay Inflection (Alpha)
- For Nodes with GIF, JPEG or Blank layout, you can specify the following:
 - Minimum Signal Decay Constant
 - Maximum Signal Decay Constant
 - Signal Decay Slope (Beta)
 - Signal Decay Inflection (Alpha)

Note: Planner models most significant objects; therefore Maximum Signal Decay Constant should be close to 2.0.

To configure RF propagation, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>RF Propagation**.
2. Specify the default sensor, AP, and Client antenna gain values.

Field	Description
Sensor Antenna Gain (db)	gain of antenna attached to the sensor
AP Antenna Gain (db)	gain of antenna attached to the AP
Client Antenna Gain (db)	gain of antenna attached to the client

3. Select the transmitter signal loss value suited to your environment.
4. Specify the loss at Source for 802.11a Transmitter (db)
5. Specify the loss at Source for 802.11b/g Transmitter (db)

6. Specify the following for nodes imported with AirTight Planner- Minimum Signal Decay Constant, Maximum Signal Decay Constant, signal decay slope(beta), signal decay slope(alpha).
7. Specify the following for nodes with GIF, JPEG or blank layout- Minimum Signal Decay Constant, Maximum Signal Decay Constant, signal decay slope(beta), signal decay slope(alpha).
8. Click **Save** to save the changes.

Restore RF Propagation Defaults

You can restore the RF propagation fields to their default values. The default values for the RF propagation related fields are as mentioned in the following table.

Sensor Antenna Gain	2.3 db
AP Antenna Gain	2.3 db
Client Antenna Gain	0 db
Loss at Source for 802.11a Transmitter	10 db
Loss at Source for 802.11b/g Transmitter	10 db
For Nodes imported with AirTight Planner	
Minimum Signal Decay Constant	2
Maximum Signal Decay Constant	2
Signal Decay Slope(Beta)	0.08
Signal Decay Slope(Alpha)	-4
For Nodes with GIF, JPEG or blank layout	
Minimum Signal Decay Constant	2
Maximum Signal Decay Constant	2.5
Signal Decay Slope(Beta)	0.08
Signal Decay Slope(Alpha)	-4

To restore RF propagation settings, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>RF Propagation**.
2. Click **Restore Defaults**. The fields are populated with their default values.
3. Click **Save** to save the changes.

Copy RF Propagation Setting to Another Server

You can copy the RF propagation settings from one server to another server when both servers are part of the same server cluster. You can copy RF propagation settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy RF propagation settings settings, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>RF Propagation Setting** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the RF propagation settings is to be copied.
4. Select the server to which the RF propagation settings is to be copied.
5. Click **OK** to copy the RF propagation settings.

Configure Live RF View Setting

Define the parameters that are used in live RF views using **Configuration>System>Advanced Settings>Live RF View Setting** option. These parameters are specific to each environment. Tuning the parameters enables you to see more accurate views.

Under Intrusion Detection and Prevention Regions, specify the dbm values for which the system shows the intrusion detection and prevention regions in the sensor coverage views.

Detection range is the area over which sensors can reliably detect wireless activity. **Intrusion Detection Display Threshold** determines the threshold for this range.

Prevention range is the area over which sensors can prevent unauthorized wireless activity. **Intrusion Prevention Display Threshold** determines the threshold for this range.

Both the detection and prevention ranges are affected by parameters in the RF Propagation section.

Note: The reliability of the prevention also depends on the Intrusion Prevention Level selected on the **Configuration>WIPS >Intrusion Prevention** page.

To configure live RF view setting, do the following.

1. Go to **Configuration>System>Advanced Settings>Live RF View Setting**.
2. Specify the **Intrusion Detection Display Threshold**.
3. Specify the **Intrusion Prevention Display Threshold**.
4. Click **Save** to save the changes.

Restore Default Live RF View Settings

The default value for intrusion detection display threshold is -85 dbm. The default value for intrusion prevention display threshold is -75 dbm.

To restore default Live RF view settings, do the following.

1. Go to **Configuration>System>Advanced Settings>Live RF View Setting**.
2. Click **Restore Defaults**.
3. Click **Save** to save the changes.

Copy Live RF View Setting to Another Server

You can copy the live RF view settings from one server to another server when both servers are part of the same server cluster. You can copy live RF view settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy live RF view settings settings, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>Live RF View Setting** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the live RF view settings is to be copied.
4. Select the server to which the live RF view settings is to be copied.
5. Click **OK** to copy the live RF view settings.

Configure Location Tracking

The location of a particular device can be tracked using the **Configuration->System->Advanced Settings->Location Tracking** option. The system needs at least three sensors to perform location tracking. The Location Tracking screen enables you to define the parameters that control location tracking.

Default Location Tracking Parameters contains the following options.

- **Maximum number of monitoring devices to use for location tracking:** Select the maximum number of sensors used for location tracking. Sensors track down the location of a device and the system uses sensors that see the maximum values. A higher value is likely to give better results. (Minimum: 3; Maximum: 10; Default: 4)
- **Default Transmit Power of AP (mW):** Location tracking needs as input the transmit power of the AP being located. When transmit power is unknown, the default value set here is used. (Minimum: 1 mW/0 dbm; Maximum: 100 mW/20 dbm; Default: 30 mW/15 dbm)
- **Default Transmit Power of Client (mW):** Location tracking needs as input the transmit power of the Client being located. When transmit power is unknown, the default value set here is used. (Minimum: 1 mW/0 dbm; Maximum: 100 mW/20 dbm; Default: 10 mW/ dbm)
- **Signal Strength Monitoring Devices:** Location tracking is based on the signal strength of the monitoring devices. This value can deviate from the actual values because of subtle variations in the RF environment. You can specify APs, AirTight Devices, and AirTight Devices and/or APs to be used to control location tracking. Using the system's Application Programming Interface (API), APs can be reported as a source of signal strength. Information from these APs can be used for location tracking.

Restore Location Tracking Configuration Defaults

The default values for location tracking configuration are as follows.

Maximum number of devices to use for location tracking	4
Default Transmit power of AP	30
Default Transmit power of Client	10
Signal Strength Monitoring Devices	AirTight devices and/or APs

To restore location tracking configuration defaults, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>Location Tracking Configuration**.
2. Click **Restore Defaults** to restore the default values of the location tracking configuration fields on the page.
3. Click **Save** to save the changes.

Copy Location Tracking Configuration to Another Server

You can copy the location tracking configuration from one server to another server when both servers are part of the same server cluster. You can copy location tracking configuration from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy location tracking configuration, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>Location Tracking Configuration** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the location tracking configuration is to be copied.
4. Select the server to which the location tracking configuration is to be copied.
5. Click **OK** to copy the location tracking configuration,

Manage Auto Location Tagging

The **Configuration>System>Advanced Settings>Auto Location Tagging** page enables you to configure the settings for automatic tagging of devices discovered by AirTight Management Console and events generated by AirTight Management Console.

A location tag that is attached to a device or an event helps identify the location of that event or device. AirTight Management Console automatically tags the devices and events to the locations where they have been detected.

Auto Location Tagging Configuration contains the following options

- **Devices:** Based on the initial location of the device, the APs and Clients are auto-tagged immediately upon discovery. You can select how the system should compute the initial location tag of the APs or Clients. The system never auto-tags an AP or Client, if it is tagged manually. To enable auto location tagging for a device, you must delete the device and let the system rediscover it. You must manually tag sensors. You can do one of the following
 - Choose the location tag of the sensor that sees the highest RSSI value for that device.
 - Choose the location tag of the selected number of sensors that see the highest RSSI values for that device.
 (Minimum: 2; Maximum: 10; Default: 2)

You can also discard the sensors that see a lower RSSI after comparing the value with a sensor that reports a higher RSSI.

(Minimum: 20 dB; Maximum: 40 dB; Default: 30 dB)

- **Events:** The system tags events based on the location of the devices that participate in the events. The system initially identifies a primary device - AP, Client, or Sensor for each event. The system automatically tags the location of events based on the tag for the primary device associated with the event.

Note: The system never tags an event more than once. You can tag the location of an event manually on the Events page by clicking the Change Location icon.

Restore Auto Location Tagging Defaults

The default values for auto location tagging are as follows.

- Choose location tag that encompasses top 2 AirTight Devices that see the highest RSSI value for the device.
- Discard AirTight Devices that see RSSI that is 30 db below the AirTight Device that sees the highest RSSI.

To restore auto location tagging defaults, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>Auto Location Tagging**.
2. Click **Restore Defaults** to restore the default values of the auto location tagging fields on the page.
3. Click **Save** to save the changes.

Copy Auto Location Tagging Settings to Another Server

You can copy the auto location tagging settings from one server to another server when both servers are part of the same server cluster. You can copy auto location tagging settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.


To copy location tracking configuration, do the following.

1. Go to **Configuration>System Settings>Advanced Settings>Auto Location Tagging** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the auto location tagging settings are to be copied.
4. Select the server to which the auto location tagging settings are to be copied.
5. Click **OK** to copy the auto location tagging settings,

Set up and Manage Server Cluster

A server cluster consists of 2 or more AirTight servers grouped together. One of these servers is the managing server and it manages one or more AirTight servers. Thus, multiple servers can be managed from a single server console in a server cluster.

The managing server is called the **parent server** and the servers that are managed from the parent server are called the **child servers**. The parent server retrieves aggregated data from multiple child servers in the cluster and displays it on AirTight Management Console along with the parent server data.



Benefits of Server Cluster

Following are the benefits of server cluster vis-à-vis SpectraGuard Manager.

- **Eliminates the need for a separate product to manage multiple servers:** SpectraGuard Manager is a separate product used to manage multiple servers. With the incorporation of the server cluster functionality in AirTight server, it is a lot easier to manage multiple servers using a single console without the need for a separate product. The server cluster is accessible through AirTight Management Console. Various templates and policies can be pushed to child server from the parent server location tree.
- **HTML 5 based product:** AirTight Management Console is a HTML5 based console. Hence, it is possible to access it from any device that has an HTML5 compatible browser.
- **Connects with AirTight devices:** AirTight Devices can connect to the AirTight Wi-Fi/AirTight WIPS server that acts as the parent server in the server cluster.
- **Ready availability of all AirTight Wi-Fi/AirTight WIPS features:** All the AirTight Wi-Fi/AirTight WIPS features are available even when a server is a part of a server cluster.
- **Eliminates the need for certificate-based communication:** There is no need to download a certificate for SGM and AMC communication as the functionality to manage multiple servers in a server cluster is provided in the same product.
- **Automatic synchronization of policies:** There is no need to manually synchronize policies on child server if the child server is not available when the policies are being synchronized from a parent server. This is done automatically when the child server comes up the next time.

- **Replication of policies from one server to another server in server cluster:** Replication of most policies from one server to another server in a server cluster is possible. This is regardless of whether the policies are being copied from parent server to child server or child server to parent server.
- **Aggregation of data in dashboard widgets:** The number of dashboard widgets available in AirTight Management Console is a lot higher than those available on SpectraGuard Manager. Aggregated data from all active servers in the server cluster is seen in most of the dashboard widgets on AirTight Management Console.

Create and Manage Server Cluster

The creation of a server cluster and management of servers in the server cluster is done using the server command line interface (CLI). Viewing of the aggregated server cluster data and management of policies on the child servers from the parent server is done through AirTight Management Console of parent server.

Following are the prerequisites to create a server cluster.

- The AirTight Wi-Fi/AirTight WIPS servers that form a cluster must have the same software version and build installed.
- A valid license must have been applied to all child servers to be added to the server cluster.
- The child server must not be a part of any other server cluster.
- If a firewall is active on the network, TCP port 22 and UDP port 1194 must be open on the firewall for cluster formation and parent-child communication. TCP port 22 is for incoming connections to child servers and UDP port 1194 is for incoming connections to parent server.


You can perform five cluster-related operations from the server command line interface. They are as follows.

1. Set up a server cluster/assign parent server to a server cluster.
2. Add a child server to a server cluster.
3. Delete or remove a child server from a server cluster.
4. Delete an entire server cluster.
5. Check the status of servers in a cluster or check if a server is part of a cluster.

The servers in a server cluster are assigned IDs when they become a part of the server cluster. A parent server is assigned 1 as ID in the cluster. As and when the child servers are added, they are assigned sequentially incrementing IDs. The child server added first is assigned 2 as ID, the next one is assigned 3 as ID and so on.

After creating the cluster, you must mount the child servers on the parent server location tree, to be able to view aggregated server data on the UI or push policies from parent server to child server.

The following figure illustrates the mapping of an existing location tree with child servers in a server cluster.



Limitations of Server Cluster

Following are the limitation of a server cluster.

- A server (parent server or child server) can be a part of only one cluster at any given point.
- A child server cannot be the parent of any other server in the cluster.

Server Cluster related Commands

You can set up a cluster comprising one parent and multiple child servers through the server command line interface.

Following is the subset of server config shell commands that are specific to creation and management of server cluster.

Command	Description
<code>cluster set</code>	Sets a server as a parent server in a server cluster. This command must be executed on the server to be set as the parent server.
<code>cluster reset</code>	Deletes a server cluster or a child server from a cluster. When executed on a parent server, the entire cluster is destroyed and all servers in the cluster behave as standalone servers. This command can be executed on parent server or child server. When executed on a child server, it eliminates the relationship between the child server and the parent server. The rest of the cluster remains intact. IMPORTANT! It is recommended to execute this command on parent server only. It can be executed on a child server ONLY when there is no other way to remove the child from a server cluster.
<code>cluster add child</code>	Adds a child to a server cluster. This command must be executed on

	the parent server in the server cluster.
<code>cluster delete child</code>	Deletes or removes a child from a server cluster. This command must be executed on the parent server in the server cluster.
<code>cluster show status</code>	Displays the status of a server cluster. Using this command you can check whether a server is in a cluster and/or the status of a server in a cluster. This command can be executed on any server regardless of whether it is in a server cluster or not.

Set up Server Cluster

Before setting up a server cluster, the parent or child servers can be in a standalone mode or in an HA pair configuration with other servers. Once a server cluster is set up, the HA mode can be enabled on the parent or child servers as and when required.

The `cluster set` command is used to set up a cluster. This command must be executed on the command line interface of the server that you want to assign as the parent server in the server cluster.

You can, optionally, choose to run the server cluster setup wizard to add child servers to the server cluster.

You can check the status of the server by executing the `cluster show status` command.

To set up a cluster, do the following.

1. Login to the server command line interface of the server that you want to set up as the parent server in a server cluster. Login to the server with 'config' user credentials.
2. Execute the command `cluster set` on the command line. The server is set as the parent server in the server cluster.
3. If you want to add child servers right away, enter 'y' when prompted to add child servers. Enter the name for the child server, IP address of the child server and password for the config user of the child server, to add a child server. Repeat this step to add more child servers.

Note: If a parent server or child server is in HA mode, the active server is added to the server cluster. The standby HA server cannot be added to the server cluster. Before setting up a server cluster, a parent server or a child server can be in standalone mode or in HA pair configuration with other servers. Once the server cluster is set up, HA mode can be enabled at a later point on the parent server or child server, if required.

Refer to the screenshot below for the `cluster set` command.

```
[config]$ cluster set
Sets server cluster.

Do you want to continue with server cluster Setup Wizard? (y/[n]): y

Creating server cluster database...           [ OK ]
Generating CA certificate and key...         [ OK ]
Creating server cluster config files...     [ OK ]
Starting server cluster service...         [ OK ]

Server cluster setup successfully.

Do you want to add any child servers? ([y]/n): n

You can add child servers using "cluster add child" command.
```

Add Child Server to Server Cluster

There are two ways to add a child server to a server cluster.

1. Use the server cluster setup wizard available after executing the `cluster set` command. This has been explained in the Set up Server Cluster section.
2. Execute `cluster add child` command. This command must be executed on the command line of the parent server. This is explained below.

To add a child server to a server cluster using the `cluster add child` command, do the following.

1. Login to the server command line interface of the parent server with "config" user credentials.
2. Execute the command `cluster add child` on the command line. You are prompted to enter the name for the child server to be added to the server cluster.
3. Enter a suitable name for the child server. You are prompted to enter the hostname or IP address of the child server.
4. Enter the hostname or IP address of the child server. You are prompted to enter the "config" user password for the child server.
5. Enter the "config" user password. If all the data entered is correct, the server having the specified hostname/IP address is added as a child server in the server cluster.

Refer to the screenshot below for the `cluster add child` command.

```
[config]$ cluster add child
Adds new child server to server cluster.

Enter name for the child server: child_1
Enter IP address / Hostname of the child server: 172.31.1.47
Enter 'config' user password of the child server:

Adding new child server to server cluster may take upto 5 minutes. Please wait..
.

Checking for connectivity and password validity on the child server [172.31.1.47
] ...
[ OK ]

Checking server compatibility...
[ OK ]

Checking HA mode of child server...
[ OK ]

Setting up pre-authentication between parent and child servers...
[ OK ]

Copying CA certificate to child server...
[ OK ]

Generating CSR file on child server...
[ OK ]

Copying CSR file from child server...
[ OK ]

Signing CSR...
[ OK ]

Copying child server's certificate to child server...
[ OK ]

Child server [child_1] with IP/Hostname [172.31.1.47] added successfully to the server cluster.
```

Delete Child Server from Server Cluster

A child server can be deleted from a server cluster using the `cluster delete child` command. When you delete a child server from a server cluster, the link between the parent server and the child server is broken. The rest of the server cluster continues to function as a cluster.

To delete a child server from a server cluster, do the following.

1. Login to the server command line interface of the parent server with "config" user credentials.
2. Execute the command `cluster delete child` on the command line. You are prompted to enter the ID of the child server to delete from the server cluster.
3. Enter the ID of the child server to delete. You are prompted to confirm the deletion of the child server from the server cluster.
4. Enter `y` to delete the child server from the server cluster. The child server is deleted from the server cluster.

Refer to the screenshot below for the `cluster delete child` command.

```
[config]$ cluster delete child
Deletes an existing child server from server cluster.

-----
Status of child servers is
ID |      NAME      |   STATUS   | CHILD VERSION |  CHILD IP / Hostname
2  | child_4       | Connected  | 7.0.24        | 172.31.1.4
-----

Enter ID of the child server to be deleted: 2

Do you want to delete child server[child_4]? ([y]/n): y

Deleting child server[child_4].

Deleting child server from server cluster may take upto 5 minutes. Please wait...
Deleting config files from child server...           [ OK ]
Stopping server cluster service on child server...  [ OK ]
Revoking child server's certificate...              [ OK ]
Deleted child server[child_4] successfully.
[config]$ █
```

Delete Server Cluster

A server cluster can be deleted using the `cluster reset` command. This command must be executed on the parent server command line to delete the entire cluster.

Note: When the `cluster reset` command is executed on a child server command line, it removes the child from the cluster. This action, however, is NOT recommended unless there is no other way to remove the child server from the cluster.

Use the `cluster delete child` command to delete a child server from a server cluster.

To delete a server cluster, do the following.

1. Login to the server command line interface of the parent server with "config" user credentials.
2. Execute the command `cluster reset` on the command line. You are prompted to confirm cluster reset.
3. Enter `y` to confirm cluster reset or deletion of the server cluster. The cluster is deleted.

Refer to the screenshot below for the `cluster reset` command.

```
[config]$ cluster reset
Resets server cluster.

Do you want to reset server cluster? (y/[n]):y

Server cluster reset successfully.
```

Check Server Status with respect to Server Cluster

You can check if a server is part of a server cluster using the `cluster show status` command. When a server is part of a server cluster, you can find out whether a server is a parent server or a child server using the `cluster show status` command.

You can execute this command on a server that may or may not be in a server cluster, that is, you can execute this command on any active server.

To check the status of a server, do the following.

1. Login to the server command line interface of the server with "config" user credentials
2. Execute the command `cluster show status` on the command line. The status of the server is returned by the command.

Refer to the screenshots below for different server statuses.

The following is a screenshot of the command executed on a child server.

```
[config]$ cluster show status
Shows status of server cluster.

-----
State of this server: Child
Parent server's IP/Hostname: 172.31.1.5
```

The following is a screenshot of the command executed on a parent server.

```
[config]$ cluster show status
Shows status of server cluster.

-----
State of this server: Parent
-----

List of child servers present in this server cluster:
-----
Status of child servers is
ID | NAME | STATUS | CHILD VERSION | CHILD IP / Hostname
2 | child_1 | Connected | 7.0.24 | 172.31.1.47
-----
```

For instructions on mounting the child servers and managing them from AirTight Management Console of the parent server, refer to [Manage Child Servers from Parent Server in Server Cluster](#).

Inherit Policy from Parent Server

When a server cluster is created and a child server is mounted on a mount point, the child server retains the policies that were previously applied to it. It does not inherit the parent server policies, by default. If you want to apply the parent server policies to child servers, you must navigate to the individual policy and inherit the policy from the parent server.

The following policies are location specific and they cannot be inherited.

- Intrusion Prevention Activation
- Location Time Zone

- Event Activation
- Device List Locking

However, if you make changes these policies at the mount point of a child server and save these changes to be applied recursively, the changes are pushed to all the locations present directly under the mount point.

To inherit a policy from the parent server, do the following.

1. Select the location on the child server where you want to inherit policies from the parent server.
2. Navigate to the policy to inherit.
3. Click the **Inherit Policy** link. A message asking for confirmation to inherit policies appears.
4. Click **Yes** on the confirmation message. The parent server policy is applied to the selected location on the child server.

Manage Child Servers from Parent Server in Server Cluster

A server cluster is a group of servers. A server cluster comprises a parent server and one or more child servers.

A server cluster is created to manage multiple servers using a single server. This managing server is called the parent server and the servers that are managed from the parent server are called the child servers. The parent server retrieves aggregated data from multiple child servers in the cluster and displays it on the AirTight Management Console along with the parent server data. You can also push common policies onto multiple child servers from a parent server.

A server (parent server or child server) can be a part of only one cluster at any given point. A child server cannot be the parent of any other server in the cluster.

The creation of a server cluster and management of servers in the server cluster is done using the server command line console. Refer to the 'Set up and Manage Server Cluster' chapter for details on setting up server cluster and to 'Server Config Shell Commands' chapter for the server cluster commands, in the respective server installation guide .

Viewing of the aggregated server cluster data and management of policies on the child servers from the parent server in the cluster is done through AirTight Management Console. You must be a superuser to be able to view server cluster related options and manage server cluster data and policies through AirTight Management Console.

Once you are done with assigning a parent server to a server cluster and adding child servers to the server cluster, you can login to AirTight Management Console of the parent server, and then navigate to **Configuration>System>Server Cluster**. Create one or more locations, if they are not already present, to mount the child servers on the parent server location tree. If the locations have already been added, mount the child servers on to these locations.

You can mount the child servers and also copy policies from one server to another server in the same server cluster.

You can print a list of child servers in the server cluster. You can search for servers in the list.

Mount Child Server on Parent Server Location tree

You must mount the individual child servers on the parent server location tree to be able to manage policies on the child server through the parent server or to view the aggregated server data for the entire server cluster. A valid license must be applied on the child server before you can mount it on the parent server location tree.

You cannot mount a child server on a parent server location tree in the following situations

- If the parent server in an existing server cluster has been upgraded, and the parent server and child server versions do not match. Refer to [Fix Version Mismatch between Parent Server and Child Server](#) section to fix the version mismatch.
- If a valid license has not been applied on the child server or the license on the child server has expired. Refer to [Fix Invalid License State on Child Server](#) section to fix the license error state.

When a child server is mounted, the parent server policies are not inherited by the child server automatically. The child server continues to use the policies applied to it before being added to the server cluster. Individual policies on the child server can be inherited from parent servers. For details, refer to [Inherit Policy from Parent Server](#)

To mount a child server on the parent server, do the following.

1. Go to **Configuration>System>Server Cluster**.
2. Select the root location of the parent server. The child servers are displayed.
3. Click the **Not Mounted** link for the child server to mount. The **Select Locations** dialog box is displayed.
4. Select an appropriate location to mount the child server. If the location has not been created, create the location first.
5. Click **Save** to mount the child server on the selected location.

Change Mount Point of Child Server

You can change the mount point of a child server whenever you want to. You cannot change the mount point of a child server if the license has not been applied on the child server or the license on the child server has expired. To change the mount point of a child server on a parent server location tree, do the following.

1. Go to **Configuration>System>Server Cluster**.
2. Select the root location of the parent server. The child servers are displayed.
3. Click the mount point link for the child server to mount. A message prompting you to change mount point, unmount server appears.
4. Click **Change mount point**.
5. Select an appropriate location to mount the child server. If the location has not been created, create the location first.
6. Click **Save** to mount the child server on the selected location.

Unmount Server from Parent Location Tree

You can unmount a child server from the parent location tree.

To unmount a child server from a parent server location tree, do the following.

1. Go to **Configuration>System>Server Cluster**.
2. Select the root location of the parent server. The child servers are displayed.
3. Click the mount point link for the child server to mount. A message prompting you to change mount point, unmount server appears.
4. Click **Unmount**.
5. Click **Save** to unmount the child server from the parent location tree.

Fix Version Mismatch between Parent Server and Child Server

The parent server and the child servers in a server cluster must have the same software version numbers installed on them to function correctly when communicating with each other. If you have upgraded the

parent server and there is a version mismatch between the parent server and a mounted child server, you are not allowed to access the child server locations from the parent server location tree. You must fix the version mismatch to be able to access the child server locations from the parent server location tree.

When there is a version mismatch, the **Fix version mismatch** link is enabled. You can click this link to fix the version mismatch of the child server. The child server restarts after applying the upgrade.

You must download the upgrade bundle from the AirTight support website before proceeding with fixing the version mismatch.

To fix the version mismatch between a parent server and a child server, do the following.

1. Select the root location of the parent server. The child servers are displayed.
2. Go to **Configuration>System>Server Cluster**. The Fix link is enabled for the child server that has a version mismatch with the parent server.
3. Click the Fix link. The **Fix version mismatch** dialog box appears.
4. Click the **Select File** link and select the upgrade bundle file from the location at which it has been downloaded.
5. Click **Upload and Upgrade** to upload the upgrade bundle and upgrade the child server with the version mismatch.

Fix Invalid License State of Child Server

After a server cluster is created using the command line, a valid license must be applied to the child servers. This can be done from the parent server in the cluster.

A child server is in an invalid license state when a valid license is yet to be applied on the child server or when the license has expired.

To fix the invalid license state of a child server, do the following.

1. Select the root location of the parent server. The child servers are displayed.
2. Go to **Configuration>System>Server Cluster**. The **Fix license** link is enabled for the child server that has an invalid license.
3. Click the **Select File** link and select the license file from the location at which it has been downloaded.
4. Click **Apply License** to apply the license on the child server. The child server restarts on successful application of the license on it.

Copy Policy Settings

You can copy policy settings from one server to another in a server cluster. You can copy policy settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser to copy policies from one server to another. Policy settings related to the following can be copied.

- Account Suspension
- Password Policy
- Login Configuration
- Language Setting
- Audit Logs
- Vendor OUIs
- RF Propagation
- Auto Location Tagging
- Auto Deletion
- SMTP Configuration

- RADIUS Configuration
- Smart Device Type
- Certificate Configuration
- LDAP Configuration
- Location Tracking Configuration
- ArcSight Integration
- Banned Device List - AP
- Banned Device List - Client
- Live RF View Settings
- AirTight Mobile Settings
- Reports Look and Feel
- HotSpot SSIDs
- Vulnerable SSIDs
- Syslog Integration
- SNMP

To copy one or more policies from one server to another, do the following.

1. Go to **Configuration>System>Server Cluster**.
2. Click **Copy**. The Copy Policies dialog box appears.
3. Select the server from which policy settings are to be copied.
4. Select the server to which the policy settings are to be copied.
5. Select the policy settings to be copied. Click **>**. To copy all available policy settings, click **>>**. If you want to remove any policy from the list of policy settings to copy, select the policy in the right hand box and click **Remove**.
6. Click **OK** to copy the policy settings.

Search Child Server

You can search for child servers by server name or server IP address.

To search a child server, do the following.

1. Select the root location
2. Go to **Configuration>System>Server Cluster**.
3. Enter the server name or the server IP address in the Quick Search box.
4. Press Enter key.
5. ">The servers with name or IP address matching the search string are displayed. The search string could be a substring of the name or the IP address.

Print Child Server List

You can print a list of child servers in a server cluster.

To print a child server list for the root location of a parent server, do the following.

1. Go to **Configuration>System>Server Cluster**.
2. Select the root location of the parent server.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the print icon. The print preview of the child server list appears.
5. >Click **Print** to print the child server list.

Manage Vendor OUIs

A list of popular vendors along with the individual MAC prefix can be seen and managed using the **Configuration>System>Vendor OUIs** option. A 3-byte MAC prefix identifies the vendor for any given 802.11 device.

Add Vendor or MAC Prefix

Click **Add Vendor/MAC Prefix** to add a new vendor-MAC prefix pair or a new prefix to an existing vendor name. Select an existing vendor and add a new MAC address for the vendor. Similarly, you can also add a new vendor and one or more MAC addresses corresponding to that vendor.

Delete Vendor or MAC Prefix

Click the respective **Delete** hyperlink for a MAC prefix, to delete it.

Manage Device Template

An AirTight device can operate as an AP or as a sensor or both AP and sensor (one radio configured as an AP and the other as a sensor), depending on the device model used.

W-68 is a 2x2 802.11a/b/g/n/ac access point/sensor.

C-65 is a dual radio access point/sensor with one 2x2 b/g/n radio and one 2x2 a/n/ac radio.

C-75 is a dual-band, dual-radio 3x3 802.11a/b/g/n/ac device. You can configure C-75 to function either as an AP or as a WIPS sensor. At a given time, both radios must be configured either in the AP mode so that the device functions as an AP, or in the sensor mode so that the device functions as a sensor.

C-75-E is a dual-band, dual-radio 3x3 802.11a/b/g/n/ac device. You can configure C-75-E to function either as an AP or as a WIPS sensor. At a given time, both radios must be configured either in the AP mode so that the device functions as an AP, or in the sensor mode so that the device functions as a sensor.

SS-300-AT-O-70 is a dual-band dual-radio 3x3 802.11 b/g/n device that can be deployed outdoors. You can configure both radios to function either in AP mode or in WIPS sensor mode at any given point in time.

SS-300-AT-C-60 is a concurrent dual-band, dual-radio 3x3 802.11 a/b/g/n device that supports multiple modes of operation for Wi-Fi access and WIPS. You can separately configure the 2 radios, Radio 1 and Radio 2. You can configure SS-300-AT-C-60 and to function either as AP with or without background scanning, or as a WIPS sensor. When it functions as an AP with background scanning (dual mode), one radio is configured as an AP and the other is configured as WIPS sensor.

SS-300-AT-C-50 is a dual-band, single radio 2x3 802.11 a/b/g/n device that can operate exclusively as an AP or as a WIPS sensor at any given point in time.

SS-300-AT-C-55 is a dual radio a/b/g/n device. Both the radios need to be configured to function either in AP mode only or in WIPS sensor mode only. You cannot configure one radio as an AP and the other as a sensor.


SS-300-AT-C-55-E is a dual radio a/b/g/n device. Both the radios need to be configured to function either in AP mode only or in WIPS sensor mode only. You cannot configure one radio as an AP and the other as a sensor.

SS-300-AT-C-10 is an 802.11a/b/g/n device. SS-200-AT-01 is an 802.11a/b/g device. SS-300-AT-C-10 and SS-200-AT-01 function as WIPS sensors only. They cannot be configured to function as APs.

A device template is a set of configuration parameters such as settings for radio, channels to monitor, VLANs to monitor, offline sensor configuration, antenna selection and port assignment. This template can be applied to one or more AirTight devices. When you have multiple devices deployed in your organization, configuring each individual device could be monotonous, tedious and time-consuming. A device template is a convenient way of applying a standard set of Wi-Fi and/or WIPS settings on multiple AirTight devices simultaneously, thereby saving time and effort, and ensuring consistency. You can have a common device template for all the devices deployed at a location, by configuring the template as the default device template. See the image below for a graphical representation of the use of device templates.

Manage device templates using the **Configuration>Device Templates**. You need administrator privileges to manage device templates.

Device Template



The server stores the default device configuration in a predefined template called **System Template**. The **System Template** can be modified. Whenever an AirTight device is added or discovered, AirTight Wi-Fi AirTight WIPS server automatically assigns the configuration settings in this template to the device. You can edit the default configuration settings in **System Template** to suit your need.

You can configure a template as the default template for a location. This template will be applied to any new device tagged to that location.

When you delete a user-defined device template, **System Template** is applied to all the devices associated with that template. You can manually override the template applied to an AirTight device from the **Devices > AirTight Devices** tab. If you customize the settings in the template, the new settings are applied to the AirTight devices to which this template is applied. To apply the customized settings, you need to push the new settings on to the AirTight device.

Customize Policy/Device Template for Location

A policy is a set of rules applicable to a location. This set of rules is represented by a device template.

When you create a new location folder, it inherits the default policy or device template from the parent location folder. Location floors inherit the default device template from their immediate parent location folder. This means that all AirTight devices that connect to this location will use this default template.

You can define your own device template and make it the default template for a location folder. This is called customizing the policy or device template at the selected location.

You can customize the policy or device template at the location folder level. This customization is not available at the location floor level.

When you change the device template at a location, all the AirTight devices connecting to the location after the change will use the newly applied device template. You can choose whether or not you want the devices existing at the location to use the changed device template or continue using the previous default device template. This can be done when you confirm the change in the default device template at the location.

The **Device Templates** page lists the device templates that are available at all locations. For the selected location, you must apply a device template from the available list to create the WLAN policy at that location. This means that you must make the device template as the default template for the location. A new AP or an existing authorized AP is compared against the applied device template to determine if it is a rogue or misconfigured AP. Other templates could be available to be attached, but they are not part of the WLAN policy. Therefore, they will not be used for AP classification.

To customize the policy at the selected location, do the following.

1. Click **Customize at this location?** link seen at the bottom of the Device Templates page. The **Make default** link is enabled for user-defined device templates in the Device Templates list seen under **Configuration > Device Templates**.
2. To change the default template for a location, click the **Make Default** link of the device template that you want to set as the default template. A confirmation message is displayed.
3. If you want to apply the new device template to existing devices at the location click **Yes**. If you want the existing devices to continue using the old default device template, click **No**.

Revert to Inherited Device Template

If you have defined a custom device template for a location and wish to inherit the parent device template, do the following.

1. Click the **Inherit from parent location?** link seen at the bottom of the **Device Templates** page.
2. Click **Yes** on the message that asks you to confirm that you want to inherit from parent location. Another confirmation message is displayed.

3. If you want to apply the inherited device template to existing devices at the location click **Yes**. If you want the existing devices to continue using the customized default device template, click **No**.

Add Device Template

When adding a device template, you can specify the name and description of the device template and save the template. When the template is defined in this manner, without defining device settings and radio settings, and applied to a device, the device functions as a WIPS sensor.

To add a new device template, do the following.

1. Click **Add Device Template** seen under **Configuration>Device Configuration>Device Templates**, to add a new device template.
2. Specify the following values.

Field	Description
Template Name	A unique name of the device template. The name can contain a maximum of 40 characters.
Description	A brief description of the device template. The description should not exceed 500 characters in length.
Allow Device Specific Customization	Select this check box to override the settings done through device template. Refer to Override Device Template Settings for further details.
Operating Region	Region or country of operation of the AirTight device.

3. Specify the device password under **Device Settings > Device Password** on the **Add Device Template** dialog box.
4. Click **Save** to save the device template settings.

To configure the device settings for the device template, click **Device Settings** on the **Add Device Template** screen. Device settings are sensor-related settings. They are relevant to devices functioning as WIPS sensors, or APs with background scanning enabled on them. Refer to [Device Settings](#) explained below, for further details on configuring device settings for a device template.

To configure the radio settings for the device template, click **Radio Settings** on the **Add Device Template** dialog box. Refer to [Radio Settings](#) explained below, for further details on configuring radio settings for a device template.

Device Settings

Device Settings are further sub-divided into VLAN monitoring, Device Password, Device Access Logs, Offline Configuration, Third Party Analytics Integration, and Channel Settings. Each of these is explained below.

VLAN Monitoring

VLAN monitoring is essential for the wired-side connection status detection, host name detection, smart device detection, rogue AP detection, and so on. Select **Enable Additional VLAN Monitoring** check box to enable the device to monitor additional VLANs. Include all the additional VLANs to be monitored as a comma-separated list. The VLAN used by the device to communicate with the server is always monitored and need not be specified here. The additional VLANs to be monitored must be configured on the switch port where the device is connected and must be DHCP enabled. A VLAN ID '0' indicates untagged VLAN on the switch port where the device is connected, irrespective of the actual VLAN number on the switch.

IMPORTANT: If a VLAN is configured with a static IP address, then configure the VLAN from the CLI.

If you want to customize the VLANs to be monitored for one or more specific devices to which a device template is applied, you can do it using the **Devices > Device Properties**. In order to override the additionally monitored VLANs, you must select the **Allow Device Specific Customization** check box.

Device Password

You can manage the password for the AirTight device Command Line Interface (CLI) user 'config' from the device template. By defining a password in the device template, you can manage the password for a group of devices without having to change it on each device separately. The password should be at least 6 characters long and it cannot contain spaces or your login ID.

You must specify the new password for the 'config' user. Confirm the new password before saving. The new password is applied on all the devices associated with the device template.

Device Access Logs

AirTight Management Console provides you with a functionality to send the sensor access logs to the Syslog server. This functionality is useful for audit purposes and can be enabled or disabled for a device template. If enabled, specify **Syslog server IP/Hostname** to which the access logs are to be sent.

Offline Configuration

This feature provides some security coverage even when there is no connectivity between an AirTight device and the server. The feature is relevant to an AirTight device functioning as a sensor. The sensor provides some device classification and prevention capabilities when it is disconnected from the server. The sensor also raises events, stores them, and pushes them back to the server on reconnection. To enable this feature select **Enable offline mode**.

In the time after which, if the sensor does not receive any communication from the Server and Enable offline Sensor mode is enabled, the sensor switches to the offline mode.(Minimum: 5 minutes; Maximum: 60 minutes; Default: 15 minutes)

There are three sub-sections under Offline Configuration

1. **AirTight Device Parameters:** In AirTight Device Parameters section, you can specify the following.
 - Number of APs to be stored:** Maximum number of AP identities that the device will store in the Offline mode (Default: 128).
 - Number of Clients to be stored:** Maximum number of client identities that the device will store in the Offline mode (Default: 256).
 - Number of events to be stored:** Maximum number of raised events that the device will buffer in the Offline mode (Default: 256). This is maintained as a cyclic buffer. That is, if the events raised exceed this limit, the oldest events are overwritten. The buffered events are transferred to the console when the device reconnects to the server.
 - Number of intrusion prevention records:**Maximum number of prevention records that the sensor will buffer in Offline mode (Default:256). This is maintained as cyclic buffer. If the records exceed this limit, the oldest records are overwritten. The buffered records are transferred to the console when the device reconnects to the server.
2. **Device Classification Policy:** Specify how the sensor should classify APs and client devices when it is not connected to the server.
 - Configure the AP classification policy the following way.
 - If you want to classify networked APs as rogue APs, select the **Move networked APs** to check box and select the **Rogue** option from the drop-down list next to this check box.

- If you want to classify networked APs as authorized APs, select the **Move networked APs to** check box and select the **Authorized** option from the drop-down list next to this check box.
 - If you want to classify non-networked APs as external APs, select the **Move non-networked APs to the External Folder** check box.
3. **Intrusion Prevention Policy:** Specify the threats for which intrusion prevention is to be enabled on the sensor when it is not connected to the server.
- Select one or more check boxes for the threats that you want the sensor to prevent when in offline mode.
- The sensor can exercise intrusion prevention against the following threats: rogue APs, uncategorized APs connected to the network, APs categorized as authorized using no security mechanism, APs categorized as authorized using weak security mechanism, authorized client connection to external APs, unauthorized client connection to authorized APs, uncategorized client connection to authorized APs, authorized client participating in ad hoc network, and honey pot or evil twin APs.

Third Party Analytics Integration

This feature enables integration of AirTight Wi-Fi/AirTight WIPS with a third-party external server, and send the visibility analytics data to the third-party external server.

To enable integration with third-party external server, do the following.

1. Select the **Enable** check box.
2. Enter the third-party external server URL or IP address in **Server URL**.
3. Enter the key for the AirTight device to authenticate with the third-party external server in **Authorization Key**.
4. Specify in **Send Interval** the time interval at which the AirTight device should send the client RSSI values to the third-party external server.

Channel Settings

Select the channel for the sensor to monitor from the list of available channels. These channels will differ according to your country of operation. Refer to the following table for the channel number, its protocol and respective frequency.

Channel	Protocol	Frequency (GHz)	Channel	Protocol	Frequency (GHz)	Channel	Protocol	Frequency (GHz)
1	b/g/n	2.412	34	a/n/ac	5.17	116	a/n/ac	5.58
2	b/g/n	2.417	36	a/n/ac	5.18	120	a/n/ac	5.6
3	b/g/n	2.422	38	a/n/ac	5.19	124	a/n/ac	5.62
4	b/g/n	2.427	40	a/n/ac	5.2	104	a/n/ac	5.52
5	b/g/n	2.432	40	a/n/ac	5.2	108	a/n/ac	5.54
6	b/g/n	2.437	42	a/n/ac	5.21	112	a/n/ac	5.56
6	b/g/n	2.437	42	a/n/ac	5.21	116	a/n/ac	5.58
7	b/g/n	2.442	44	a/n/ac	5.22	120	a/n/ac	5.6
8	b/g/n	2.447	46	a/n/ac	5.23	124	a/n/ac	5.62
9	b/g/n	2.452	48	a/n/ac	5.24	128	a/n/ac	5.64

10	b/g/n	2.457	48	a/n/ac	5.24	132	a/n/ac	5.66
11	b/g/n	2.462	50	a/n/ac	5.25	136	a/n/ac	5.68
12	b/g/n	2.467	52	a/n/ac	5.26	140	a/n/ac	5.7
13	b/g/n	2.472	56	a/n/ac	5.28	149	a/n/ac	5.745
14	b/g/n	2.487	56	a/n/ac	5.28	152	a/n/ac	5.76
184	a/n/ac	4.92	58	a/n/ac	5.29	153	a/n/ac	5.765
188	a/n/ac	4.94	60	a/n/ac	5.3	153	a/n/ac	5.765
192	a/n/ac	4.96	64	a/n/ac	5.32	157	a/n/ac	5.785
196	a/n/ac	4.98	100	a/n/ac	5.5	160	a/n/ac	5.8
208	a/n/ac	5.04	104	a/n/ac	5.52	161	a/n/ac	5.805
212	a/n/ac	5.06	108	a/n/ac	5.54	161	a/n/ac	5.805
216	a/n/ac	5.08	112	a/n/ac	5.56	165	a/n/ac	5.825

Radio Settings

SS-300-AT-C-50, SS-300-AT-C-55, SS-300-AT-C-60 and SS-300-AT-O-70, C-75 and C-65 devices can function in access point mode as well as in sensor mode.

When in AP mode, a single physical AP device can be logically split up into multiple virtual APs. You can configure the radio settings and specify one or more Wi-Fi profiles if you configure the AirTight device to function as an AP. Each SSID profile corresponds to and represents the configuration settings of one virtual AP. You can configure up to 8 virtual APs on one radio.

If you want the AirTight device to function as a mesh AP, you must define and add a mesh profile to the device template. Dual-radio AirTight device models like SS-300-AT-C-55, SS-300-AT-C-55-E, SS-300-AT-C-60, SS-300-AT-O-70, C-75, C-75-E, and C-65 are capable of functioning as mesh APs. An AirTight device that functions as a mesh AP cannot function in WIPS mode. Therefore, at a given point, a device can have one or more Wi-Fi profiles attached to it or a single mesh profile attached to it. Both Wi-Fi profile and mesh profile cannot be attached to a radio at the same time.

To operate the device in the AP mode, you must configure the radio settings, and add Wi-Fi profiles to indicate which wired network the AP should connect to. To operate the device in the WIPS sensor mode, all you need to do is select the device model. In every model, the available radios are configured to function as WIPS sensors. This means that on any AirTight device model, the WIPS sensor option is selected, by default, for all available radios.

To configure radio settings for access point mode, do the following.

1. Go to **Configuration>Device Configuration>Device Templates**.
2. Click **Radio Settings** on the **Add Device Template** dialog box or the **Edit Device Template** dialog box, as applicable.
3. Click **Define settings for model** link. A drop down list of available AirTight device models appears.
4. Select the appropriate model. The details for the model appear. To configure radio settings for the SS-300-AT-C-55-E device, select the SS-300-AT-C-55 option. To configure radio settings for the C-75-E device, select the C-75 option.
5. Select the **Operation Mode** for the desired radio as **Access Point**.
6. Configure the radio settings.

Field	Description
Frequency Band	The radio frequency band. The possible values are 2.4 GHz and 5 GHz. Default value is 2.4 GHz.
Channel Width	The channel width for the radio. Possible values are 20 MHz or 20 MHz /40 MHz. In case of a/n/ac devices, the 20/40/80 MHz option is available. The options are enabled for 2.4 GHz and 5 GHz modes.
Operating Channel	The operating channel for the radio. By default, the AP automatically selects the operating channel automatically (Auto). User can manually set the channel if desired. Select Manual , to set the operating channel. Based on the location selected in the left pane, a list of channel numbers presented for manual channel selection, is presented. If the manually selected channel is not present in the country of operation selected for the device in the applied AP template, the AP automatically reverts to Auto mode and selects a channel.
Selection Interval	This field is visible only when the Operating Channel is set to Auto . This field specifies the time interval, in hours, at which the channel selection happens. You can enter any value from 1 through 48.
Channel Number	This field is visible only when the Operating Channel set to Manual . This field specifies the operating channel number. The channel numbers seen in this box depend on the operating region selected. If you are defining channel number for APs in the mesh network, make sure that the channel number is the same for all the AirTight device models functioning as mesh APs.
Background Scanning	Select this check box to enable background scanning by the AP. IMPORTANT: Do not enable background scanning if the radio is being used for Voice over IP (VoIP).
Radio Advanced Settings	
Custom Transmit Power	This field enables you to control the transmission power of the AP. Select the custom transmit power check box and specify the transmission power of the AP in dbm. If the custom transmit check box is deselected, the maximum allowed transmit power allowed for the country of operation is set for the AP.
Fragmentation Threshold	The fragmentation threshold, in bytes. Permissible value for this field is from 256 through 2346 bytes. This field is applicable to 5 GHz and 2.4 GHz modes.
RTS Threshold	The threshold for Request to Send (RTS) in bytes. It specifies the threshold for the size of frame above which the AP should use Request to Send (RTS)/Clear to Send (CTS) handshake for transmission. This field is applicable to 5 GHz and 2.4 GHz modes. Note: If the threshold is set to very small value the wireless channel is not efficiently utilized. This threshold is meant to be used for large frames to avoid losing them due to collisions and causing channel resource wastage.
Beacon Interval	The time interval, in milliseconds, between AP beacon transmissions. The value is set to 100 milliseconds. It is not editable.
DTIM Period	DTIM (Delivery Traffic Indication Message) period is the time period after which clients connected to the AP should check for buffered data waiting on the AP.
802.11n/ac Guard Interval	A time period at the end of each OFDM symbol to allow the signal to dissipate prior to transmitting the next signal. This prevents overlaps between two consecutive symbols. Legacy 802.11 a/b/g devices use 800ns GI. GI of 400ns is optional for 802.11n. This field is 802.11n/ac specific. Half guard interval is not supported for SS-300-AT-C-50 when channel width is 20 MHz.
Enable Frame Aggregation	This field specifies the enabling or disabling of MAC protocol Data Unit (MPDU) aggregation. This field is 802.11n/ac specific. In case of 802.11 ac radio, frame aggregation is enabled, by default, and it cannot be disabled.

Spectrum Load Balancing Threshold	The load balancing parameter that is useful for tuning the load distribution between 2.4 GHz and 5 GHz bands. If the difference between the number of clients associated in 5 GHz and 2.4 GHz exceeds this threshold, band steering to 5 GHz is not performed (as the load on 5 GHz is more) until the difference comes below the threshold again. This field is 802.11n specific.
Antenna Settings	
Selection	This field has 2 values-internal and external. If you want to work with internal antennas, select Internal . If you want to work with external antennas, select External . This field is 802.11n specific.

7. Click **Add Wi-Fi Profile** and select the relevant Wi-Fi profile for the AP, from the available list. Repeat this step if you want to add more than one Wi-Fi profiles to the AP. Similarly, you can add a mesh profile to the device template if you want to apply the template to AirTight devices that would function as mesh APs.

To configure radio settings for WIPS sensor mode, do the following.

1. Click **Define settings for model** link. A drop down list of available AirTight device models appears.
2. Select the appropriate model. The details for the model appear. By default, all the available radios are configured in WIPS sensor mode.
3. Click **Antenna Settings**. By default, **Internal** is selected. Select the **External** option if you are using external antennas.

To remove the settings for a device model from the device template, do the following.

1. Click the respective device template link to view the details of the template.
2. Click **Radio Settings**.
3. Click the model name. The model configuration appears.
4. Click the **Remove Model** link on the top right of the model configuration.
5. Click **Save** to save the changes.

In case you have removed a model and want to add it back again, do the following

1. Click **Add Model** and select a model for which you want to define the configuration settings.
2. Define the configuration settings for the device model.
3. Click **Save** to save the changes.

Override Device Template Settings

A device template can be applied on to multiple AirTight devices. However, for some specific reasons, you might want to change the transmit power, channel or additional monitored VLANs for a few APs to which the device template has been applied. You can achieve this with the Allow Device Specific Customization feature.

Transmit power, channel, or additional monitored VLANs are the fields that can be customized and overridden.

You can override the device template settings at the device level by performing the following tasks.

1. Go to **Configuration>Device Configuration>Device Templates**.
2. Edit a device template.
3. Select the **Allow Device Specific Customization** check box in the device template that has been applied to the AirTight device. You can override the radio settings parameters Channel and transmit power, and the additional monitored VLANs.
4. Go to **Devices** page and select the AirTight device for which you want to override the settings.

5. Change the required settings and save the changes. Refer to [Customize Device Template Settings](#) for details on customizing these settings.

Note: You can specify the customized settings at a later point, even if you enable per device configuration in the device template.

Edit Device Template

To edit a device template, do the following.

1. Go to **Configuration>Device Configuration>Device Templates**.
2. Click the link with the device template name.
3. Change one or more of the following values.

Field	Description
Template Name	A unique name of the device template. The name can contain a maximum of 40 characters.
Description	A brief description of the device template. The description should not exceed 500 characters in length.
Allow Device Specific Customization	Select this check box to override the settings done through device template. Refer to Override Device Template Settings for further details.
Operating Region	Region or country of operation of the AirTight device.

4. Click **Device Settings** to make changes, if any, to device settings. Refer to [Device Settings](#) for further details.
5. Click **Radio Settings** to make changes, if any, to radio settings. Refer to [Radio Settings](#) for further details.
6. Click **Save** to save the device template settings.

IMPORTANT: You can edit a device template at a selected location, only if you have defined the device template at that location.

Search Device Template

You can search for device templates based on the template name.

To search for a device template, do the following

1. Go to **Configuration>Device Configuration>Device Templates**.
2. On the Device Templates page, type in the keyword or search string for the template name **Quick Search** box on the top right corner.
3. Press **Enter** to filter the list of templates based on the keyword or the search string. The device templates matching the search criteria appear in the device template listing.

Copy Device Template

You can copy a device template to another location. A copied device template is editable at the new location.

To copy a device template from one location to another, do the following.

1. Go to **Configuration>Device Configuration>Device Templates**.
2. Select the device template.
3. Click the Move to icon. The Select Location dialog box appears.
4. Select the location where you want to copy the device template.
5. Click OK.

Print Device Template List for Location

You can print the list of device templates for a location.

To print a list of device templates for a location, do the following.

1. Go to **Configuration>Device Configuration>Device Templates**.
2. Select the location for which you want to print the list of device templates.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the print icon. The print preview of the device template list appears.
5. Click **Print** to print the list.

Delete Device Template

You can delete a device template at a selected location, only if you have defined the device template at that location.

Deletion of a template results in assigning default device template to the AirTight Devices associated with this template.

You cannot delete the **System Template**.

To delete a device template, do the following

1. Go to **Configuration>Device Configuration>Device Templates**.
2. Select the location for which you want to delete the device template.
3. Select the check box for the device template you want to delete.
4. Click the delete icon. A confirmation message for deletion appears
5. Click **Yes** to confirm deletion of the device template.

Configure SMTP Settings

Configure the Simple Mail Transfer Protocol (SMTP) settings to send e-mails when events occur, using the **Configuration>System Settings>SMTP Configuration** option. You must have administrator privileges to configure SMTP settings.

The fields on the SMTP Configuration page and their description is as follows.

To configure SMTP settings, do the following.

1. Go to **Configuration>System Settings>SMTP Configuration**.
2. Enter the details. The following table describes the fields related to SMTP.

Field	Description
SMTP Server IP Address/Hostname	IP Address or the host name of the SMTP server used by the system for sending e-mail alerts. The default value is 127.0.0.1:25. Following are the authentication protocols for SMTP server

	<ul style="list-style-type: none"> • PLAIN (For sendmail 8.10 and above) • LOGIN (For sendmail 8.10 and above) • NTLM (Windows proprietary authentication method)
Port	Port number of the SMTP server used by the system for sending e-mail alerts.
Email Address in From field	source address from which e-mail alerts are sent
Enforce use of StartTLS (TLSv1)	STARTTLS is an extension to plain text communication protocols like SMTP that offers a way to upgrade a plain text connection to an encrypted (TLS or SSL) connection instead of using a separate port for encrypted communication. Select this check box if you want to enforce the use of STARTTLS to send e-mails in an encrypted format.
Verify SMTP Server's Certificate	Select this check box to verify SMTP server's certificate against built-in well-known CA certificates or uploaded CA certificate. When this check box is selected, an e-mail is not sent out if the certificate match fails.
Set Certificate	If an SMTP server's CA certificate is not present in the built-in well-known CA certificates packaged in the AirTight appliance, the test SMTP operation fails. In such cases, you can upload a private CA certificate of the SMTP server. Click this button and then click Choose to add a private CA certificate file to be used for SMTP server authentication. If a private certificate is uploaded only this certificate is used for authentication; the built-in certificates will not be used. If the uploaded file contains multiple entries only the first entry is used for verification. To delete a certificate, click Delete for the certificate and confirm deletion. Note that the server application is restarted after private certificate upload or delete operation.
Authentication Required	Select this check box to enable SMTP authentication.
Username	user name for SMTP server authentication, when SMTP server authentication is enabled.
Password	password for SMTP server authentication, when SMTP server authentication is enabled.

3. Change the server access URL, if required.
4. Click **Save** to save the changes

Restore SMTP Configuration Defaults

The default values for SMTP configuration are as follows.

SMTP Server IP Address/Hostname	127.0.0.1
Port	25
Email Address in From field	server@localhost.localdomain
Authentication Required	not selected
Server Access URL	https://wifi-security-server

To restore SMTP configuration defaults, do the following.

1. Go to **Configuration>System Settings>SMTP Configuration**.
2. Click **Restore Defaults** to restore the default values of the SMTP configuration fields .
3. Click **Save** to save the changes.

Test SMTP Settings

To test SMTP settings, you can send a test email. The SMTP configuration settings are used for this mail.

The settings used for this mail are the SMTP settings specified by you. Make sure you have configured SMTP correctly before testing the settings.

To test SMTP settings, do the following.

1. Go to **Configuration>System Settings>SMTP Configuration**.
2. To send a test e-mail, click **Test SMTP Settings**. An email is sent if the configuration is correct.

Copy SMTP Configuration to Another Server

You can copy the SMTP configuration from one server to another server when both servers are part of the same server cluster. You can copy SMTP configuration from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy SMTP configuration, do the following.

1. Go to **Configuration>System Settings>SMTP Configuration** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the SMTP configuration is to be copied.
4. Select the server to which the SMTP configuration is to be copied.
5. Click **OK** to copy the SMTP configuration.

View System Status

The **Configuration>System>System Status** page displays information about the AirTight Wi-Fi / AirTight WIPS server.

All the static server information is available under **System Information**.

The current status of the server is displayed under Server Information.

Information about backup files stored on the server is displayed under Backup Files stored on the server.

The file name,

The following table describes the static information seen on the **System Status** page.

Field	Description
Server ID	Specifies the unique identifier for the server appliance. If you have installed a single server appliance, then retain the default server ID, that is, 1.
AirTight Device Communication Port	Specifies the AirTight device port number on which the AirTight Management Console server communicates with the device.
Serial Number	Specifies the hardware serial number of the AirTight Management

	Console server.
Maximum AirTight Devices Allowed	Specifies the maximum number of AirTight devices allowed on the license.
Allowable Conversions to AP	Specifies the maximum number of AirTight devices that are allowed to be converted to function as access point, per the current license.
Software Version	Specifies the version number of the AirTight Management Console software.
Software Build	Specifies the build number of the AirTight Management Console software.
License Expiry Date	Specifies the expiry date of the license.
IPV6 Status	Specifies whether IPV6 protocol is enabled or disabled on the server.

Start/Stop Server

Live information about the status of the system can be seen under **Server Information**. You can find out if the server is running, stopped, or is in error state.

You can stop the server from this page. If the server is stopped, you can start the server.

To stop the server, click **Stop Server** under **Server Information**. To start the server, click **Start Server** under **Server Information**. The text of the button under **Server Information** alternates between **Stop Server** and **Start Server** depending on whether the server is running or has stopped.

To stop the server, do the following.

1. Go to **Configuration>System>System Status**.
2. Click **Stop Server** to stop the server.

To start the server, do the following.

1. Go to **Configuration>System>System Status**.
2. Click **Start Server** to start the server.

Upgrade Server

You can upgrade to the latest version of the AirTight Management Console, using the **Configuration->System->Upgrade Server** option. Only users in a 'super user' role can initiate a server upgrade.

Prerequisites for Upgrade

Following things need to be taken care of before upgrading to a newer version of AirTight Management Console.

- Popup blockers on the computer from which the Console is accessed must allow popup windows from the server.
- If there is a firewall between the computer from which the Console is accessed and the server, TCP port 8080 of the server must be accessible from that computer.

Recommended: To upgrade the server to a newer version, ensure that you access the Console using a computer whose IP address has not been changed by Network Address Translation (NAT). If you access the Console, using a NATed IP, upgrade will continue in the background but you cannot view the upgrade progress messages.

Upgrade Process

1. Click **Browse** to select the Upgrade Bundle.
2. Click **Upgrade Now** to transfer the Upgrade Bundle to the server.
3. On the Confirm Upgrade dialog, click **Yes** to proceed with the upgrade.
4. The Uploading Upgrade Bundle message with the progress bar appears.
5. You can cancel the upgrade by clicking **Cancel** anytime while the Upgrade Bundle upload is in progress.
6. After the Server Upgrade Bundle upload is complete, Server Upgrade starts automatically.
7. Close the current browser window. A new window, Server Upgrade Progress, is launched which displays the status of the Server Upgrade process. Follow the instructions displayed on the Server Upgrade Progress window.
8. After the server upgrade is successful, the server reboots automatically.
9. After you have read all instructions on the Server Upgrade Progress window, close all the Web browser windows including the Server Upgrade Progress window.
10. Wait for five minutes for the server to reboot. After this, you can access the server again.

Note: You cannot abort or cancel the Server Upgrade process once the Server Upgrade Progress window is launched. Additionally, the Server Upgrade process continues even if the Server Upgrade Progress window is closed.

Configure Auto Deletion Settings

AirTight Management Console stores historical information about the devices visible to it and the events related to these devices. The rate of growth of this information is dependent on the volatility of the wireless environment at the deployed location. It is necessary to delete this information periodically, as it becomes obsolete after some time. This is done using the **Configuration->System->Auto Deletion** option.

Based on the event-related configuration done by you, the system also raises and stores a number of events. If the configuration is such that there are significant number of events generated and stored, the stored event data size grows significantly faster. This event data also requires regular cleanup. Auto deletion allows you to specify values of various auto deletion parameters to control the frequency of deletion of information. The system generates an event for tracking the action of auto deletion. This event gives information only about device deletion. There is no event separately generated that indicates event deletion.

The auto-deletion parameters are related to access point, client, network events. These are explained in detail below.

Access Point Deletion Parameters: The available AP categories are **Uncategorized, Rogue, External, Authorized** APs are not deleting automatically from the system. If you want to delete inactive authorized APs, you have to delete them manually.

Note: The control for some AP categories is available in specific deployments only.

Select the AP categories for which you want to set the auto-delete duration. Specify the number of days of inactivity after which the AP related information is to be automatically deleted for the respective

category. The minimum number of days of inactivity is 1 and the maximum number of days of inactivity is 30.

Client Deletion Parameters: The available client categories are **Uncategorized, Authorized, External, Rogue, Guest.**

Select the client categories for which you want to set the auto-delete duration. Select the appropriate check box and specify the number of days of inactivity after which the client-related information is to be automatically deleted for the respective category. The minimum number of days of inactivity is 1 and the maximum number of days of inactivity is 30.

Network Deletion Parameters: Select the **No. of days to retain exposed Networks** check box and specify the duration, in days, for which the exposed networks are to be retained on the server. The default value is 30 days for this field. The minimum value for retention in the system is 1 day, and the maximum value is 90 days.

Events Deletion Parameters: Specify the maximum number of security, performance and system events that should be retained on the server.

The following table shows the event type along with the default, minimum, and maximum values.

Event Type	Default number of events	Minimum number of events to store	Maximum number of events to store	Note
Security	50,000	20,000	80,000	The maximum number of security events that can be retained for the SA-350 appliance is 0.7 million.
Performance	10,000	5000	40000	The maximum number of performance events that can be retained for the SA-350 appliance is 0.25 million.
System	1000	500	2000	The maximum number of system events that can be retained by can be retained by the SA-350 is 0.05million.

Specify how long the events should be retained in the database: The default value is 30 days for this field. The minimum number of days to retain events is 1 day, and the maximum number of days to retain events is 365 days. Events older than the period specified will be purged from the database.

You can track auto-deletion of inactive APs, Clients, and events, by monitoring the special event generated by the system. The system generates an event containing the summary of the actions performed during the auto-deletion operation, if and only if any physical deletion of information has actually taken place.

Copy Auto Deletion Settings to Another Server

You can copy the auto deletion settings from one server to another server when both servers are part of the same server cluster. You can copy auto deletion settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy auto deletion settings, do the following.

1. Go to **Configuration>System Settings>Auto Deletion** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the auto deletion settings are to be copied.

4. Select the server to which the auto deletion settings are to be copied.
5. Click **OK** to copy the auto deletion settings,

Manage Audit Log Settings

AirTight Management Console keeps a track of the user activity. The user action logs can be downloaded from the server for viewing purpose. This is done using the **Configuration>System Settings>Audit Logs** option. Only a super user has the privilege to download the user action logs. Audit logs are also called user action logs.

Set Duration for Audit Log Download

You can specify a time duration, using the **From** and **To** fields that indicate duration between the date from which and date up to which you want to download the user action logs. Alternatively, you can specify a duration indicating the number of lapsed hours for which you want to download the user action logs. You can select the type of log entries that can be downloaded. Use the **For** field to specify this. By default, records of all types are included in the downloaded log file. You can sort the log on the date and time, module, host address, user role, login name, type and status of the login attempt. Use the **Ordered by** field to select the sort field. The default sorting of log entries is done on date and time.

To configure settings for user action logs to download, do the following.

1. Go to **Configuration>System Settings>Audit Logs**.
2. Select the type of action log to download.
3. Select the **From** and **To** date for which the user action log is to be downloaded. Alternatively, you can select **Last** and specify the number of elapsed days, months or years for which you want to download the user action logs.
4. Click **Save** to save the changes.

Download Audit Logs

You can download the user action logs after having set the duration and type of user action logs for the download.

To download, do the following.

1. Go to **Configuration>System Settings>Audit Logs**.
2. Click **Download**. The user action log is downloaded as a CSV file. The contents of the log depends on the type of action log downloaded.

Note: If the server is a parent server in a server cluster, the downloaded log is an aggregation of the parent server and child server log data. This means that the child server logs are also included in the parent server logs. In this case, the audit log contains an additional column 'Cluster Server'. For parent server log entries, the value in this column is 'Cluster Parent' and for child server log entries, the value in this column is the name of the child server itself.

Restore Default User Action Log Download Settings

1. Go to **Configuration>System Settings>Audit Logs**.
2. Click **Restore Defaults** to restore the default values.
3. Click **Save** to save the changes.

Copy Audit Log Settings to Another Server

You can copy the audit log settings from one server to another server when both servers are part of the same server cluster. You can copy audit log settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy audit log settings, do the following.

1. Go to **Configuration>System Settings>Audit Logs** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the audit log settings are to be copied.
4. Select the server to which the audit log settings are to be copied.
5. Click **OK** to copy the audit log settings.

Configure Integration with Enterprise Security Management Servers

You can configure AirTight Management Console to integrate with various enterprise security management (ESM) servers using the **Configuration->ESM Integration** page.

AirTight Management Console integrates with ESM servers that collect, analyze, and display events. AirTight Management Console sends security events related information to these servers.

AirTight Management Console integrates with SNMP, Syslog and Arcsight servers.

To configure the integration settings for SNMP, see [SNMP Integration](#).

To configure the integration settings for Syslog, see [Syslog Integration](#).

To configure the integration settings for Arcsight, see [Arcsight Integration](#).

Syslog Integration

You can configure the integration settings with communication with Syslog servers for AirTight WIPS to communicate and send log messages to Syslog servers.

If Syslog integration is enabled, the system sends messages to the configured Syslog servers. Otherwise, Syslog integration services are shut off. Apart from events, you can also send audit logs from AirTight WIPS to a Syslog server. You must enable integration with Syslog for AirTight WIPS to send messages and audit logs to Syslog servers. Select the **Enable Syslog Integration** check box to enable integration of AirTight Management Console/AirTight WIPS with Syslog server.

Current Status indicates the status of the Syslog server. It could be **Running**, **Stopped** or **Error**, depending on the state of the Syslog server. **Error** status is shown if the System server is stopped, if the hostname of an enabled syslog server cannot be resolved, or if an internal error occurs. In case of occurrence of an internal error, you need to contact Airtight Technical Support.

Adding a Syslog Server

To add a syslog server, do the following.

1. Go to **Configuration>ESM Integration>Syslog Integration**.
2. Under **Manage Syslog Servers**, click **Add Syslog Server** to add Syslog server details.
3. Specify the Syslog Server IP Address or Hostname to which the events should be sent.
4. Specify the port number of the Syslog server to which the system sends events. The default port number is 514.
5. Specify the format in which the event is sent, which is Intrusion Detection Message Exchange Format (IDMEF) or Plain text. the default format is plain text).
6. Select the **Enabled** check box if you want the events and/or audit logs to be sent to this Syslog server. It is enabled by default.
7. Select the Append BOM header check box if you want to append the byte order mark to the syslog server entry. This is relevant in case of plain text files.
8. Select the **Forward Events** check box to send events to the Syslog server.
9. Select the **Forward Audit Logs** check box to send audit logs to the Syslog server. You can forward audit logs in plain text format only.
10. Click **OK** to add the details for a new Syslog server.

Edit Syslog Server

To edit syslog server settings for a syslog server, do the following.

1. Go to **Configuration>ESM Integration>Syslog Integration**.
2. Click the Syslog server IP address and port hyperlink in the list of Syslog servers.
3. Make the necessary changes.
4. Click **OK** to save the changes.

Delete a Syslog Server

You can delete a syslog server from the list of syslog servers, Once deleted from the list, the entries will not be sent to this server.

To delete a syslog server, do the following.

1. Go to **Configuration>ESM Integration>Syslog Integration**.
2. Click the **Delete** hyperlink for the Syslog server to delete the Syslog server.

Copy Syslog Server Settings to Another Server

You can copy the Syslog server settings from one server to another server when both servers are part of the same server cluster. You can copy syslog server settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.


To copy syslog server settings, do the following.

1. Go to **Configuration>ESM Integration>Syslog Integration** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the syslog server settings are to be copied.
4. Select the server to which the syslog server settings are to be copied.
5. Click **OK** to copy the syslog server settings,

Arcsight Integration

Go to **Configuration>ESM Integration>Arcsight Integration** to configure the integration settings for communication with Arcsight server

AirTight Management Console integrates with ArcSight's Enterprise Security Management (ESM) infrastructure by sending events to the designated ArcSight server. The ArcSight server is configured to accept syslog messages having detailed event information in ArcSight's Common Event Format (CEF). The system needs the IP Address or the hostname and the port on which the ArcSight server receives events. You can add more than one Arcsight servers to receive events from AirTight Management Console. Apart from events, you can also send audit logs from AirTight Management Console to an Arcsight server. Refer to the following figure for a graphical representation of Arcsight integration.



Arcsight Integration

Add Arcsight Server

To add an Arcsight server, do the following.

1. Go to **Configuration>ESM Integration>Arcsight Integration**.
2. Click the **Add Arcsight Server** hyperlink.
3. Enter the Arcsight IP address, port number.
4. Select the **Enabled** check box if you want to enable sending CEF messages and/or audit logs generated by AirTight Wi-Fi/AirTight WIPS to this server.
5. Select the **Forward Events** check box to send CEF messages to the Arcsight server.
6. Select the **Forward Audit Logs** check box to send audit logs to the Arcsight server.
7. Click **OK** to save the changes.

Edit Arcsight Server

To edit Arcsight server details, do the following.

1. Go to **Configuration>ESM Integration>Arcsight Integration**.
2. Click the Arcsight server IP address and port hyperlink in the list of Arcsight servers.
3. Make the necessary changes.
4. Click **OK** to save the changes.

Delete Arcsight Server

To edit Arcsight server details, do the following.

1. Go to **Configuration>ESM Integration>Arcsight Integration**.

2. Click the **Delete** hyperlink for the Arcsight server IP address and port to delete the Arcsight server. Once deleted from the list, the CEF messages will not be sent to this server.

Copy Arcsight Server Settings to Another Server

You can copy the Arcsight server settings from one server to another server when both servers are part of the same server cluster. You can copy Arcsight server settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy Arcsight server settings, do the following.

1. Go to **Configuration>ESM Integration>Arcsight Integration** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the Arcsight server settings are to be copied.
4. Select the server to which the Arcsight server settings are to be copied.
5. Click **OK** to copy the Arcsight server settings,

SNMP Integration

Go to **Configuration->ESM Integration->SNMP** to configure the integration settings for communication with SNMP server

The **SNMP** page enables the sending of events from AirTight Management Console, as SNMP traps to designated SNMP trap receivers. It also enables SNMP managers to query server operating parameters using IF-MIB, MIB-II, and Host Resources MIB.

Select **Enable SNMP Integration** check box to enable the integration with SNMP servers. When SNMP integration is enabled, the system sends SNMP traps to the configured SNMP servers. Other systems can request for information about network entities from the SNMP server. Otherwise, SNMP integration services are shut off.

Current Status displays the current status of the SNMP server. This can be **Running** or **Stopped** or **Error**, depending on the state of the SNMP server. **Error** status is shown if the System server is stopped or if an internal error occurs. In case of occurrence of an internal error, you need to contact Airtight Technical Support.

Under **SNMP Settings**, configure SNMP Gets or Traps.

Configure SNMP Get and SNMP Traps

Select the **SNMP Gets Enabled** check box to allow SNMP managers to query server-operating parameters enlisted in IF-MIB, MIB-II, and Host Resources MIB. Deselect this check box to block queries related to all the MIBs.

Alternatively, select **SNMP v3 Parameters** check box to configure SNMP v3 Get parameters, that is Username, Authentication Password, Privacy Password, Authentication Protocol and Privacy Protocol. (Default Username is admin; default Authentication Password is password, default Privacy Password is password, default Authentication Protocol is MD5 and default Privacy Protocol is DES.) Select the **Show Key** check box to display the password as is, without masking it.

Select the **SNMP Traps Enabled** check box to allow SNMP traps to be sent to configured SNMP servers. Additionally, select the SNMP versions to be enabled and configure the relevant settings. The SNMP agent residing on the server uses the SNMP version parameters to deliver traps to the SNMP Trap receivers.

Select **SNMP v1,v2** check box to send traps to all Trap receivers accepting traps using SNMP v1, v2 protocol. You can change the **Community String** for the SNMP agent. All SNMP v1, v2 Trap receivers configured, should use this community string to receive traps.(Default: public).

Select the **SNMP v3** check box, to send traps to all Trap receivers accepting traps using SNMP v3 protocol. You can configure the individual parameters that is, **Username, Authentication Password, Privacy Password, Authentication Protocol** and **Privacy Protocol**, while adding the trap receivers/destinations. All SNMP v3 Trap receivers configured, should use these parameters to receive traps.

Engine ID is not editable.

Default Username is admin; default Authentication Password is password, default Privacy Password is password, default Authentication Protocol is MD5 and default Privacy Protocol is DES.

Under **SNMP MIBs**, you can choose to query by enabling or disabling the following SNMP MIBs individually.

- IF MIB
- Host Resources MIB
- AirTight-MIB: If selected, the system enables the external SNMP Trap receivers to receive traps.
- MIB-II: If selected, configure the System Contact, System Name, and System Location.
(Default System Name: Wi-Fi Security Server).

Starting with version 6.7.U5, MIB-II 'System Description (sysDescr)' has been changed to 'AirTight SpectraGuard Enterprise, Version xxx' and MIB-2 'System Object ID (sysOID)' has been changed to '.1.3.6.1.4.1.16901.1.1.1'.

Apart from this, with version 6.7 U5, SNMP traps are generated whenever any monitoring service crashes, and this service is restarted successfully by the health-check daemon. Please refer to AirTight MIB for more details.

IF MIB, Host Resources MIB, and MIB II are standard MIBs that you can download from the Internet. For AirTight-MIB, contact AirTight Technical Support.

Add SNMP Trap Destination Server

Under SNMP Trap Destination Servers, click Add to open SNMP Configuration dialog where you can add SNMP server details.

Destination Server (IP Address/Hostname): Specifies the IP address or the hostname of the SNMP server to which events should be sent.

SNMP Protocol Version: Specifies the SNMP protocol version for the SNMP agent. (Default: SNMP v3)

Port Number: Specifies the port number on the receiving system to which the SNMP trap is sent. (Default: 162)

Enabled?: Specifies if the SNMP server is enabled to receive SNMP traps. (Default: Enabled)

User name: Specifies if the SNMP v3 user name. (Default:admin)>

Authentication Password: Specifies if the SNMP v3 authentication password. (Default: password)

Privacy Password: Specifies if the SNMP v3 privacy password. (Default: password)

Authentication Protocol: Specifies if the SNMP v3 authentication protocol. (Default: MD5)

Privacy Protocol: Specifies if the SNMP v3 privacy protocol. (Default: DES)

Note: You must specify a different port number if another application uses the default port. For every combination of authentication and privacy protocol, you must specify a different user name for v3 get/trap parameter.

Click Add to add the details for a new SNMP server.

Edit SNMP Trap Destination Server

Click the SNMP trap destination server IP address and port hyperlink in the list of SNMP trap destination servers. Make the necessary changes. Click **OK** to save the changes.

Delete SNMP Trap Destination Server

Click the **Delete** hyperlink for the SNMP trap destination server to delete the server. Once deleted from the list, the events will not be sent to this server.

Copy SNMP Settings to Another Server

You can copy the SNMP settings from one server to another server when both servers are part of the same server cluster. You can copy SNMP settings from child server to child server, parent server to child server, or child server to parent server. You must be a superuser or an administrator to copy policies from one server to another.

To copy SNMP settings, do the following.

1. Go to **Configuration>ESM Integration>SNMP** on the parent server.
2. Click **Copy Policy**. The **Copy Policies** dialog box appears.
3. Select the server from which the SNMP settings are to be copied.
4. Select the server to which the SNMP settings are to be copied.
5. Click **OK** to copy the SNMP settings,

Manage WLAN Integration

WLAN Integration

AirTight WIPS integrates with the underlying WLAN infrastructure. It supports integration with controller devices from Aruba, Cisco, Meru and HP.

You must configure the integration parameters for the appropriate vendor so that AirTight WIPS is able to provide effective wireless intrusion prevention.

On successful configuration, AirTight WIPS server fetches data from the configured controllers. This data includes list of managed and unauthorized devices (APs and Clients) and their association and RSSI values detected and maintained by the controllers.

To enable integration with HP MSM and provide the parameters for integration with HP MSM controller, see [Manage Integration with HP MSM Controller](#).

To configure the parameters for integration with Cisco WLC, see [Manage Integration with Cisco WLC](#).

To configure the parameters for integration with Aruba Mobility Controllers, see [Manage Integration with Aruba Mobility Controllers](#)

To configure the parameters for integration with Meru, see [Manage Integration with Meru](#)

Manage Integration with Aruba Mobility Controllers

You can configure AirTight Management Console to integrate with Aruba Mobility Controllers to fetch wireless device details and RSSI information from the Aruba Mobility Controllers and help to manage the WLAN infrastructure. This is done using the **Configuration>WIPS>WLAN Integration>Aruba** option.

The Aruba WLAN architecture consists of Aruba Mobility Controllers and APs. At any time, the Aruba Mobility Controller has all the information about the APs and devices seen/associated with these APs.

Integration with Aruba allows the system to fetch this information from Aruba Mobility Controller. Using this information the system can automatically classify devices managed by Aruba Mobility Controllers, and do location tracking of devices seen by Aruba APs in sensor-less or sensor and AP mixed environment.

Select **Aruba Integration Enabled** check box to integrate AirTight Management Console to obtain data from the configured mobility controllers, which are individually enabled.

When you select the Aruba Integration Enabled check box, you can configure Automatic Synchronization Settings. The system disables a mobility controller, by default. However, automatically enables Aruba integration when you add a new Aruba Mobility Controller.

Current Status displays the current status of the Aruba - Running, In Process or Stopped. An Error status is shown in one of the following cases.

- One of the configured and enabled Aruba Mobility Controllers has a hostname, which cannot be resolved.
- One of the configured and enabled Aruba Mobility Controllers is not reachable.
- System server is stopped.
- Internal error, in which case you need to contact Technical Support.

The **Imported APs** percentage indicates total number of APs imported from enabled Aruba mobility controllers as a fraction of maximum allowed. The maximum allowed depends on type of appliance. The status displayed is as of the last synchronization event. It is recommended that the utilization remains below 80%. If the utilization exceeds 80%, the system performance may degrade and result in side effects such as sluggish UI and sensor disconnections.

Under Automatic Synchronization Settings, select the System-Aruba Mobility Controller **Synchronization Interval**.

Synchronization Interval (Minutes) specifies the interval for which the server synchronizes with the enabled Aruba mobility controllers.

(Minimum: 15 minutes; Maximum: 60 minutes; Default: 30 minutes)

Click **Restore Defaults** to restore the default values for the fields on the Aruba Integration dialog.

Add Aruba Mobility Controller

You can add one or more Aruba Mobility Controllers. AirTight WIPS communicates with these controllers and fetches wireless device details from them.

To add an Aruba Mobility Controller, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>Aruba**.
2. Select the location for which you want to add an Aruba Mobility Controller.
3. Click Add Controller. Enter the details as described in the table below.

Field	Description
Controller (IP Address/Hostname)	IP address or hostname of the Aruba Mobility Controller with which AirTight WIPS communicates.
Port Number	Port number of the Aruba Mobility Controller from which data is imported.

SNMP Version	SNMP version. Select SNMPv2 if the v2 is the SNMP version. Select SNMPv3 if the v3 is the SNMP version.
Community String	User-defined community string using which AirTight WIPS communicates with Aruba Mobility Controller. Default value is 'public'.
Data Import Enabled?	Select the check box to enable import of data from Aruba Mobility Controller.
Import Managed APs	Select this check box to import managed APs from Aruba Mobility Controller.
Import Managed Clients	Select this check box to import clients associated with APs managed by Aruba Mobility Controller.
Import Managed Client Associations	Select this check box to import information related to AP-client association for APs managed by the Aruba Mobility Controller.
Import Unmanaged APs	Select this check box to import APs not managed by the Aruba Mobility Controller.
Import Unmanaged Clients	Select this check box to import clients associated with APs not managed by Aruba Mobility Controller.
Import Unmanaged Client Associations	Select this check box to import information related to AP-client association for APs not managed by the Aruba Mobility Controller.
Import Signal Strength Information	Select this check box to import APs not managed by the Aruba Mobility Controller. Note: Location Tracking results may vary depending on the Aruba AP models used in the network.

4. Click **Save** to save the changes.

Edit Aruba Mobility Controller settings

You can edit Aruba mobility Controller settings.

To edit Aruba Mobility Controller settings, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>Aruba**.
2. Select the location for which you want to edit the Aruba Mobility Controller.
3. Select the check box for the Aruba Mobility Controller to edit.
4. Click the edit icon.
5. Make the required changes.
6. Click **Save** to save the changes.

Delete Aruba Mobility Controller

You can delete the details of an Aruba Mobility Controller. Once deleted, AirTight WIPS will not retrieve any details from this Aruba Mobility Controller.

To delete Aruba Mobility Controller details, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>Aruba**.
2. Select the location for which you want to delete the Aruba Mobility Controller list.
3. Select the check box for the Aruba Mobility Controller to delete.
4. Click the delete icon to delete details of the Aruba mobility controller.

Print Aruba Mobility Controller List for Location

You can print a list of Aruba Mobility Controllers for a location.

To print a list of Aruba Mobility Controllers, do the following.

5. Go to **Configuration>WIPS>WLAN Integration>Aruba**.
6. Select the location for which you want to print the Aruba Mobility Controller list.
7. Click the print icon to print the list of Aruba Mobility Controllers. A print preview appears.
8. Click **Print** to print the list.

Configure Integration with HP MSM Controller

The HP MSM Controller manages a collection of thin APs. Configure integration with HP MSM Controller using the **Configuration>WIPS>WLAN Integration>HP MSM Controller** option.

The HP MSM architecture consists of MSM Controllers and the APs that are managed by these controllers. Integration with HP MSM Controller allows the AirTight WIPS server to fetch information about Synchronized APs. Using this information, the AirTight WIPS server automatically classifies these devices.

Select the **HP MSM Integration Enabled** check box to enable integration for all configured controllers. Enabling the MSM Controller integration allows the system to obtain data from the configured controllers. Enabling / Disabling individual controllers is also possible.

The **Current Status** displays **Running** if integration is enabled, and it displays **Stopped** if controller integration is switched off.

The **Status** for each individual controller displays **Error** if

- One of the configured and enabled MSM Controllers has a hostname which cannot be resolved
- One of the configured and enabled MSM Controllers is not reachable
- System server is stopped
- Internal error (Contact Technical Support)

Configure Automatic Synchronization Settings

Under **Automatic Synchronization Settings**, select the **Synchronization Interval**. The **Synchronization Interval** specifies the interval after which the server synchronizes with the HP MSM Controller. The default value is 15 minutes. A maximum value that can be specified here is 60 minutes.

Manage Client Certificate

When the MSM Controller is configured to communicate with client programs using Secure HTTP and Client Authentication, a client certificate is uploaded into the MSM Controller's Trusted CA Certificate Store. Click **Download Client Certificate** to download a pre-generated client certificate for AirTight Management Console.

Note: To customize the client certificate refer to the CLI commands: get msmcontroller cert, get msmcontroller certreq, and set msmcontroller cert as described in Config Shell Commands in the Installation guide.

Add HP MSM Controller

You can add multiple HP MSM controllers to integrate with AirTight WIPS.

To add a HP MSM controller, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>HP MSM Controller**.
1. Select the location for which you want to add a HP MSM Controller.
2. Click **Add Controller**. The MSM Controller dialog box appears.
3. Configure the fields in the MSM Controller dialog box as described in the table below.

Field	Description
Controller Name	Controller Name or IP address of the HP MSM Controller with which AirTight WIPS communicates.
Port Number	Port number of the HP MSM Controller from which data is imported.
Authentication	Type of authentication for MSM Controller. Select the Secure HTTP (SSL/TLS) option if the MSM Controller is configured to use HTTPS for authentication. Select the HTTP Authentication if HP MSM Controller requires HTTP authentication.
Username	User name for HP MSM Controller HTTP authentication. This field appears only when authentication is selected.
Password	Password for HP MSM Controller HTTP authentication. This field appears only when authentication is selected.
Using Client Certificate	Select this check box if client certificate is used. This field is valid only if secure HTTP authentication is selected. Note: If the MSM Controller is setup to use client authentication, ensure that the AirTight WIPS client certificate is uploaded into the HP MSM Controller's trusted CA certificate store.
Data import enabled	Select this check box to enable the import of data from HP MSM controller.

4. Click **Save** to save the details for the new HP MSM Controller.

Check Connectivity with HP MSM Controller

Once you have added the details for HP MSM Controllers, you can test connectivity of AirTight WIPS with each of these Controllers. Apart from this, you can check this connectivity at any time.

To test connectivity with an HP MSM controller, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>HP MSM Controller**.
2. Select the location for which you have added HP MSM Controller and want to test the connectivity.
3. Select the check box for the Controller for which you want to test the connectivity.
4. Click the Test Connectivity icon. The System will return Pass status if the HP MSM Controller has been correctly configured. The System will return Fail status if the HP MSM Controller has been not been correctly configured.

Edit HP MSM Controller

To edit a HP MSM controller, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>HP MSM Controller**.
2. Select the location for which you want to edit the HP MSM Controller details.
3. Select the check box for the Controller to edit.
4. Click the edit icon in the toolbar. The MSM Controller dialog box appears.
5. Change the fields in the MSM Controller dialog box as described in the table below.

Field	Description
Controller Name	Controller Name or IP address of the HP MSM Controller with

	which AirTight WIPS communicates.
Port Number	Port number of the HP MSM Controller from which data is imported.
Authentication	Type of authentication for MSM Controller. Select the Secure HTTP (SSL/TLS) option if the MSM Controller is configured to use HTTPS for authentication. Select the HTTP Authentication if HP MSM Controller requires HTTP authentication.
Username	User name for HP MSM Controller HTTP authentication. This field appears only when authentication is selected.
Password	Password for HP MSM Controller HTTP authentication. This field appears only when authentication is selected.
Using Client Certificate	Select this check box if client certificate is used. This field is valid only if secure HTTP authentication is selected. Note: If the MSM Controller is setup to use client authentication, ensure that the AirTight WIPS client certificate is uploaded into the HP MSM Controller's trusted CA certificate store.
Data import enabled	Select this check box to enable the import of data from HP MSM controller.

6. Click **Save** to save the changes.

Print HP MSM Controller List for Location

You can print a list of HP MSM Controllers for a location.

1. To print the HP MSM controller, do the following.
2. Go to **Configuration>WIPS>WLAN Integration>HP MSM Controller**.
3. Select the location for which you want to print the list of HP MSM controllers.
4. Click the print icon in the toolbar. The print preview of the list of HP MSM controllers appears.
5. Click **Print** to print the list of HP MSM Controllers for the selected location.

Delete HP MSM Controller

To delete the HP MSM controller, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>HP MSM Controller**.
2. Select the location for which you want to delete the list of HP MSM controllers.
3. Select the check box for the HP MSM Controller you want to delete.
4. Click the delete icon in the toolbar. A message asking to confirm deletion appears.
5. Click **Yes** to confirm deletion.

Enable Integration with HP MSM Controllers

To enable an HP MSM Controller, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>HP MSM Controller**.
2. Select the location for which you want to enable integration with HP MSM Controllers.
3. Select the **HP MSM Integration Enabled** check box to enable integration with HP MSM Controllers.
4. Click **Save** to save the changes.

Disable Integration with HP MSM Controllers

To disable integration with HP MSM Controller, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>HP MSM Controller**.
2. Select the location for which you want to disable integration with the HP MSM Controllers.
3. Select the **HP MSM Integration Enabled** check box to enable integration with HP MSM Controllers.
4. Click **Save** to save the changes.

Manage Integration with Cisco WLC

Configure integration with Cisco wireless LAN Controller (WLC) using the **Configuration>WIPS>WLAN Integration>Cisco WLC Integration** option.

The WLC governs a collection of thin AP. LWAPP defines the network protocol between the APs and WLC. The advantages of this solution are as follows.

- Increased scalability
- Simplified, centralized management
- Zero-touch AP deployment and configuration
- Network-wide monitoring

The Cisco Unified WLAN architecture consists of Wireless LAN Controllers (WLC) and APs. The APs are managed using Light Weight Access Point Protocol (LWAPP). At any time, the WLC has all the information about the APs and devices seen or associated with these APs.

Integration with Cisco WLC allows the system to fetch this information from WLC. Using this information the system can automatically classify devices managed by WLC and do location tracking of devices seen by LWAPP APs in sensor-less or sensor and AP mixed environment.

Important! Currently, the system supports the following managed APs: Cisco Aironet 1000 Series, Cisco Aironet 1100 Series, Cisco Aironet 1130 Series, Cisco Aironet 1140 Series, Cisco Aironet 1200 Series, Cisco Aironet 1230 AG Series, Cisco Aironet 1240 AG Series, Cisco Aironet 1250 Series, and Cisco Aironet 1300 Series. The system supports WLC version 4.2.x to 8.0.

Select the **WLC Integration enabled** check box to enable AirTight Management Console to obtain data from the configured WLCs, which are individually enabled.

If you select **WLC Integration Enabled** check box, you can configure **Automatic Synchronization Settings**. AirTight WIPS disables WLC by default. However, automatically enables WLC Integration when you add a new WLC.

Current Status displays the Current Status of the WLC that is whether it is **Running** or **Stopped**.

An **Error** status is shown in one of the following cases.

- One of the configured and enabled WLCs has a hostname, which cannot be resolved.
- One of the configured and enabled WLCs is not reachable.
- System server is stopped.
- Internal error, in which case you need to contact Technical Support.

The **Imported APs** percentage indicates total number of APs imported from WLC(s) as a fraction of maximum allowed. The maximum allowed depends on type of appliance. The status displayed is as of the last synchronization event. It is recommended that the utilization remains below 80%. If the utilization

exceeds 80%, the system performance may degrade and result in side effects such as sluggish UI and sensor disconnections.

Under **Automatic Synchronization Settings**, specify the AirTight Management Console-WLC **Synchronization Interval**, in minutes.

(Minimum: 15 minutes; Maximum: 60 minutes; Default: 30 minutes)

If the customer has some Lightweight Access Points (LAPs) whose type (like ap1030, ap1130) is not supported by AirTight Management Console, then these LAPs can be supported by importing the WLC configuration bundle received from the AirTight Support on request. After the bundle is received, select Use Custom WLC Configuration and click Upload Custom Configuration File. The Import Custom WLC Configuration File dialog appears. Choose the file and upload it. The custom WLC configuration file from this bundle is used for all future WLC synchronization. The bundle is imported as .tgz.

If the file is not imported for some reason or if the file is corrupted, an error message is displayed.

Note: Only the superuser is allowed to import WLC configuration file. All other users, including the administrator has only the viewing rights.

Add WLAN Controller

Under Wireless LAN Controllers, click **Add Controller** to open WLAN Controller dialog where you can add WLC details.

You can add multiple WLCs to integrate with AirTight WIPS.

To add a Cisco WLC, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>Cisco WLC**
1. Select the location for which you want to add a WLC
2. Click **Add Controller**. The Wireless LAN Controller dialog box appears.
3. Configure the fields in the Wireless LAN Controller dialog box as described in the table below.

Field	Description
Controller (IP Address/Hostname)	IP address or hostname of the Cisco WLC with which AirTight WIPS communicates.
Port Number	Port number of the WLC from which data is imported.
SNMP Version	SNMP version. Select SNMPv2 if the v2 is the SNMP version. Select SNMPv3 if the v3 is the SNMP version.
Community String	User-defined community string using which AirTight WIPS communicates with WLC. Default value is 'public'.
Data Import Enabled?	Select the check box to enable import of data from WLC.
Import Managed APs	Select this check box to import managed APs from WLC.
Import Managed Clients	Select this check box to import clients associated with APs managed by WLC.
Import Signal Strength Information	Select this check box to import signal strength information of managed devices from WLC.

4. Click **Save** to add the details for a new WLC.

Edit WLAN Controller

To edit the details of a WLC, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>Cisco WLC**
2. Select the location for which you want to edit a WLC
3. Select the check box for the WLC to edit.
4. Click the edit icon.
5. Make the required changes.
6. Click **Save** to save the changes.

Delete WLAN Controller

1. Go to **Configuration>WIPS>WLAN Integration>Cisco WLC**
2. Select the location for which you want to delete a WLC
3. Select the check box for the WLC to delete.
4. Click the delete icon. A delete confirmation message is seen.
5. Click Yes on the confirmation message to delete WLAN Controller.

Test connectivity with Cisco WLC

You can test the connectivity of the Cisco WLC configured under Cisco WLC.

1. Go to **Configuration>WIPS>WLAN Integration>Cisco WLC.**
2. Select the location.
3. Select the check box for the WLC for which you want to check the connectivity.
4. Click the Test icon to confirm the validity of IP Address/Hostname, SNMP settings, and version compatibility of the selected WLC.

Print WLC list for Location

You can print the list of WLC configured for a location.

To print the WLC list, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>Cisco WLC.**
2. Select the location for which you want to print the WLC list.
3. Click the print icon to print the list of WLCs. A print preview appears.
4. Click **Print** to print the WLC list.

Set WLC Configuration File

You can configure whether the default WLC configuration file should be used or a custom WLC configuration file should be used by AirTight WIPS.

The custom WLC configuration file is provided by AirTight support.

To configure the WLC configuration file to be used, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>Cisco WLC.**
2. Select the location.
3. Select the **Use default WLC configuration** option to use the default WLC configuration file.
4. Select the **Use custom WLC configuration** option to use a custom WLC configuration file. Click Upload custom configuration file and choose the custom WLC configuration file provided by AirTight support.

Manage Integration with Meru

Meru Integration enables the system to use Virtual Cell and Virtual Port Architecture for reporting accurate AP inventory. System also detects the physical APs to which the Clients are associated. This helps the user for accurate location tracking and to protect against advanced threats.

Configure integration with Meru using the **Configuration>WIPS>WLAN Integration>Meru** option.

To activate integration with Meru, do the following.

1. Go to **Configuration>WIPS>WLAN Integration>Meru**.
2. Select the **Enable Virtual Cell and Virtual Port Support** check box to activate support for Meru Virtual Cell and Virtual Port architecture.
3. Click **Save**. On saving the server restarts to activate the changes.

Manage AirTight Mobile Clients

AirTight Mobile provides wireless security for mobile computers. It protects the sensitive data on laptops, computers and smart phones, and protects against wireless attacks.

AirTight Mobile integrates with AirTight Management Console. With this integration, it is possible to centrally manage AirTight Mobile users. You can create client groups and apply common policies to them. You can also have a centralized risk level management of the mobile computers and centralized audit of wireless activity on mobile computers.

To configure the settings for AirTight Mobile - AirTight Management Console communication, see [Settings](#).

To manage AirTight Mobile groups through AirTight Management Console, see [AirTight Mobile groups](#).

To manage AirTight Mobile clients through AirTight Management Console, see [Manage AirTight Mobile Clients](#).

AirTight Mobile Settings

Define the AirTight Mobile configuration parameters using the **Configuration-> AirTight Mobile->Settings** option.

A shared key is used for authentication of clients running AirTight Mobile. AirTight Mobile cannot connect to the server for synchronization without a shared key. This shared key should be distributed to all the users of wireless clients running AirTight Mobile.

Change Shared Key

Under **Shared Key Authentication**, select **Change Shared Key** check box to change the existing shared key.

Enter the Shared Key manually or click **Generate Random Key** to automatically generate a shared key of up to 10 alphanumeric characters. AirTight Mobile clients connect to AirTight Management Console with this key.

IMPORTANT: You need to be very careful about changing the Shared Key if it has already been circulated to existing AirTight Mobile Clients. This is because, if you change the Shared Key, existing AirTight Mobile users will not be able to connect to the server unless they reactivate their AirTight Mobile Clients using the new Shared Key.

Configure Activity Parameters

Under Activity Parameters, specify the following.

Keep-alive Interval: Indicates the duration at which AirTight Mobile sends a heartbeat to AirTight Management Console indicating that it is active.

(Minimum: 1 minute; Maximum: 30 minutes; Default: 2 minutes)

Keep-alive Heartbeat: Indicates the number of consecutive heartbeat packets missed by AirTight Management Console before it declares that AirTight Mobile instance as inactive.

(Minimum: 2 heartbeats; Maximum: 10 heartbeats; Default: 5 heartbeats)

Synchronization Interval: Defines the minimum period at which AirTight Mobile synchronizes with the server.

(Minimum: 30 minutes; Maximum: 300 minutes; Default: 60 minutes)

License File Path: The path to the AirTight Mobile license file. You can change the path by clicking Choose file and choosing a new path.

Manage AirTight Mobile Clients

You can centrally manage the AirTight Mobile clients using the **Configuration>AirTight Mobile->Manage AirTight Mobile** clients option. You can change the group for AirTight Mobile clients, fetch a report from an active AirTight Mobile client, schedule a report on an inactive AirTight Mobile client, delete AirTight Mobile clients. To do these operations, you can filter or search AirTight Mobile clients on the client name or the client group.

The following table describes the information about AirTight Mobile clients presented on the **Manage AirTight Mobile Clients** page.

Field	Description
AirTight Mobile Status	Indicates whether the AirTight Mobile client is active or inactive.
AirTight Mobile Risk Level Icon	Identifies the AirTight Mobile risk level – High, Medium, or Low.
AirTight Mobile Report Status	Indicates one of the following -Report available, Report not available, or Report Scheduled.
Name	Specifies the first name and last name and / or host name of the client.
Wireless MAC	Specifies the first detected wireless MAC address of the Client in case of multiple wireless interfaces.
Wired MAC	Specifies the first detected wired MAC address of the Client in case of multiple wired interfaces.
Version	Specifies the build and version number of the software loaded in the Client.
Group	Specifies the group name as defined through Group Management. The asterisk before a group name indicates that the group has been manually changed for the client, from a AirTight Mobile reported group to manually created group.
AirTight Mobile Reported Group	Specifies the AirTight Mobile reported group to which the Client belongs. , “AirTight Mobile Reported Group” column displays information about the domain name and group name (OU Hierarchy) reported by AirTight Mobile Client as “<Domain Name>/<Group Name (OU Hierarchy)>”.
Email	Specifies the e-mail address of the AirTight Mobile user using the AirTight Mobile client.
Last Synch	Specifies the time when the AirTight Mobile Client last synchronized with the system.
Activation	Specifies the date and time when the AirTight Mobile Client was activated.
Last Available Report	Specifies the time when a report was last generated for the selected AirTight Mobile Client.

If the server is a parent server in a server cluster, the AirTight Mobile client listing is an aggregation of AirTight Mobile clients on the parent server and child servers in the server cluster . This means that the Airtight Mobile clients on the child servers are also included in the parent server AirTight Mobile listing.

The AirTight Management Console servers with version 6.7, 6.7 Update 1, 6.7 Update 2, 6.7 Update 3 and 6.7 Update 4 are compatible with AirTight Mobile versions 2.5 and 2.7, 3.0 and 3.1.

Fetch Report from AirTight Mobile Client

This option is available for an active AirTight Mobile Client.

To fetch report from an active AirTight Mobile client, do the following.

1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Select an active AirTight Mobile client.
3. Click the Fetch Report icon to fetch a fresh report from the AirTight Mobile Client.

Schedule Report on AirTight Mobile Client

This option is available for an inactive AirTight Mobile client.

Do the following to schedule a report on an inactive AirTight Mobile client.

1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Select the client on which you want to schedule a report.
3. Click the Schedule Report icon to schedule a report for the selected AirTight Mobile Client. A fresh report is generated for the client when it becomes active.

View available AirTight Mobile report in AirTight Management Console

This option is available for a AirTight Mobile Client for which a report has been fetched earlier. This option enables you to view various reports generated earlier for the selected AirTight Mobile Client. Each time the system generates a AirTight Mobile report, it updates the Last Available Report column on the Manage AirTight Mobile Clients screen.

Do the following to view an available report.

1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Select the client for which you want to view the already available report.
3. Click the View Available Report icon to view the available report once again.

Change AirTight Mobile Group

You can change the group to which the client belongs. The new group can be any group except the group currently associated with the selected client. After the clients group changes, the policy applicable to this client is applied to the AirTight Mobile client.

Do the following to change the existing client group.

1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Select one or more clients for which you want to change the group.
3. Click the Change AirTight Mobile Group icon and select the new group from the list of groups displayed.

Delete AirTight Mobile Client

Do the following to delete an AirTight Mobile client.

1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Select one or more clients to delete.
3. Click the Delete AirTight Mobile Client icon to delete an Airtight Mobile client. Confirm the deletion by clicking OK.

Filter/Search AirTight Mobile Clients

You can filter the AirTight Mobile Client List based on the Name, Group, or AirTight Mobile Reported Group.

Do the following to filter AirTight Mobile Client list.

1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Enter the search/filter criteria in the Quick Search box. You may enter the name, the group or the AirTight Mobile group to filter the AirTight Mobile client data.
3. Press the Enter key. The AirTight Mobile clients matching the search/filter criteria are seen in the list.

You can also select the columns to be seen on the Manage AirTight Mobile Clients page. The available columns are

- AirTight Mobile Status
- AirTight Mobile Risk Level
- AirTight Mobile Report Status
- Last Available Report
- Name
- Wired MAC
- Wireless MAC
- Version
- Group
- AirTight Mobile Reported Group
- Email
- Last Synch
- Activation

Do the following to select the columns to be made visible on the Manage AirTight Mobile Clients page.

1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Click a column heading. A down arrow appears at the right of this column.
3. Click the down arrow.
4. Select **Columns** option from the menu that appears.
5. Select the check boxes for the individual columns that are to be made visible on the Manage AirTight Mobile Clients page.

Print List of AirTight Mobile Clients for Location

You can print a list of AirTight Mobile clients for a location.

To print the AirTight Mobile clients' list, do the following.


1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Select the location for which you want to print the existing list of AirTight Mobile clients.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the Print icon. A print preview of the list appears.
5. Click **Print** seen on top of the list.

6. Select the printer.
7. Click **Print**.


Enable Pagination for AirTight Mobile Client Listing and Set Page Size



By default, the AirTight Mobile client listing is presented in a grid. You can scroll down to the last AirTight Mobile row without having to browse across pages. A paginated view is also available if you want to view a page-wise list of AirTight Mobile clients. You can enable pagination for the AirTight Mobile clients that are visible to you and configure the number of rows on each page.

To enable pagination, do the following.

1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Click the  icon seen on the right side of the tool bar. A message to confirm pagination for all grids/listings on the UI appears.
3. Click **OK**. The pagination for AirTight Mobile client listing is enabled. The pagination for all other grids such as AirTight devices, clients, networks, APs and events is enabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

To set the page size, do the following.


1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. On the tool bar, click the down arrow next to the number of rows displayed to the left of the  icon. The options **First Page** and **Set page size** appear.
3. Click **Set Page Size** and enter the number of rows to be visible on each page.
4. Click **OK**.

You can browse through the paginated AirTight Mobile clients listing by clicking the  (next page) and  (previous page) icons. To go to the first page, click the down arrow next to the number of rows on the page and select the **First page** option.

Disable Pagination for AirTight Mobile Client Listing

If you have enabled pagination and want to disable it, you can restore the default view of having a complete listing of all AirTight Mobile clients on a single page.

To disable pagination, do the following.

1. Go to **Configuration>AirTight Mobile>Manage AirTight Mobile Clients**.
2. Click the  icon seen on the right side of the tool bar. A message to confirm disabling of pagination for all grids/listings on the UI appears.
3. Click **OK**. The pagination for AirTight Mobile client listing is disabled. The pagination for all other grids such as AirTight devices, clients, networks, APs and events is disabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

You can set up and manage groups for wireless clients running AirTight Mobile, using the **Configuration>AirTight Mobile>AirTight Mobile Groups** page.

Group Management allows the user to manage AirTight Mobile policy groups. AirTight Mobile groups can be created manually. AirTight Management Console can also be configured to create AirTight Mobile groups automatically from the users' domain and logged in group as reported by AirTight Mobile.

Each group can have an AirTight Mobile policy attached to it. The AirTight Mobile policies are created using an AirTight Mobile Client. The policy configuration is then imported in AirTight Management Console in XML format.

If no policy is attached to a group, the server does not push any policy to the Clients in that group. The Clients retain the previous policy. When you do not attach a policy or you detach a policy from an AirTight Mobile group, AirTight Management Console does not send the Activity Parameter information such as Keep-alive Interval, Keep-alive Timeout, and Synchronization Interval to the Clients belonging to that AirTight Mobile group.

You can categorize AirTight Mobile into groups automatically or manually. Automatic movement of AirTight Mobile Client is based on the AirTight Mobile user's domain and group name information. Manual assignment of AirTight Mobile Clients to a group overrides any automatic assignment.

Note: For automatically created groups, "AirTight Mobile Reported Group" column displays information about the domain name and group name (OU Hierarchy) reported by AirTight Mobile Client as "<Domain Name>/<Group Name (OU Hierarchy)>". For Manually created groups, it displays " - -".

Add AirTight Mobile Group Manually

To add the an AirTight Mobile groups, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which you want to add an AirTight Mobile group.
3. Click the **Add New AirTight Mobile Group** hyperlink.
4. Specify the following details for the new AirTight Mobile group in the **Add AirTight Mobile Group** dialog.

Field Name	Description
Name	Name of the AirTight Mobile group.
Description	Brief description of the AirTight Mobile group.
Is Policy Attached?	Indicates whether or not a policy is attached to the newly defined group.

5. To attach a policy to the new group, see [Attach Policy to AirTight Mobile Group](#).
6. Click **Save** to save the changes.

Note: Duplicate group names are allowed for manually defined groups. The group name of an AirTight Mobile reported group and manually created group can be the same.

Edit AirTight Mobile Group

To edit an AirTight Mobile group, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which you want to edit the AirTight Mobile group.
3. Click the group name hyperlink for the group to edit. The **Edit AirTight Mobile Group** dialog box appears.
4. To attach a policy to a group, see [Attach Policy to AirTight Mobile Group](#).
5. To overwrite an existing policy, see [Overwrite Existing Policy for AirTight Mobile Group](#).
6. To detach a policy from a group, see [Detach Policy from AirTight Mobile Group](#).
7. Edit the name and description if required.
8. Click **Save** to save the changes.

Attach Policy to AirTight Mobile Group

Use the following steps to attach a policy to a new or existing AirTight Mobile group.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which the policy is to be attached.
3. If you are adding a new group, click **Add AirTight Mobile Group** hyperlink on the **AirTight Mobile Groups** page. If you are editing an existing group, click **Edit** on the **AirTight Mobile Groups** page for the AirTight Mobile group to which you want to attach a policy.
4. Click the **Attach Policy** hyperlink to navigate to the path where the AirTight Mobile Configuration file is saved. A confirmation dialog appears. Click **Yes** on this dialog.
5. Click **Choose File** and specify the path of the AirTight Mobile configuration file (.XML format) and click **Open**.
6. Click **Save** to attach the policy to the AirTight Mobile group.

Overwrite Existing Policy for AirTight Mobile Group

To overwrite or replace an existing policy for an AirTight Mobile group, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which the policy is to be overwritten.
3. Click the group name hyperlink for the group to edit. The **Edit AirTight Mobile Group** dialog box appears.
4. Click the **Overwrite Policy** hyperlink to navigate to the path for the new policy file. A confirmation dialog appears
5. Click **Yes** on this dialog.
6. Click **Choose File** and specify the path for the new AirTight Mobile configuration file (.XML format) and click **Open**.
7. Click **Save** to attach the policy to the AirTight Mobile group.

Detach Policy from AirTight Mobile Group

To overwrite or replace an existing policy for an AirTight Mobile group, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which the policy is to be overwritten.
3. Click the group name hyperlink for the group to edit. The **Edit AirTight Mobile Group** dialog box appears.
4. Click the **Detach Policy** hyperlink to navigate to the path for the new policy file. A confirmation dialog appears
5. Click **Yes** on this dialog.
6. Click **Save** to attach the policy to the AirTight Mobile group.

View AirTight Mobile Group Policy in HTML Format

To view a policy from the AirTight Mobile group list in HTML format, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which the policy is to be viewed.
3. Under the AirTight Mobile Group List, select the check box for the policy to be viewed.
4. Click the View HTML icon for the policy on the AirTight Mobile Group Management page. The policy is displayed in HTML format.

If you have defined a default policy, you can view it in HTML format.

To view the default policy in HTML format, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which the policy is to be viewed.
3. Scroll down to the **Default Policy Setting** section.
4. Click the **View HTML** hyperlink for the policy to view the policy in HTML format.

View AirTight Mobile Group Policy in XML Format

To view a policy in the XML format, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which the policy is to be viewed.
3. Click **View XML** hyperlink for a policy on the AirTight Mobile Group Management page. The policy is displayed in XML format.

If you have defined a default policy, you can view it in XML format.

To view the default policy in XML format, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which the policy is to be viewed.
3. Scroll down to the **Default Policy Setting** section.
4. Click the **View XML** hyperlink for the policy to view the policy in XML format.

Activate Automatic Client Grouping

AirTight Mobile clients can be grouped automatically based on the group detected by AirTight Mobile.

New groups can be automatically created on the server when reported by clients running AirTight Mobile.

To activate automatic client grouping, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which the policy is to be configured.
3. Scroll down to the **Activate Client Grouping** section.
4. Select the **Enable Client Grouping based on group reported by AirTight Mobile** check box.
5. Click **Save** to save the change.

Apply Default Policy to New Groups

A default policy can be applied to any new AirTight Mobile group created manually or automatically. If you have already applied a default policy, and you change the default policy, it does not apply to groups that have been added before changing the default policy.

To apply default policy to new AirTight Mobile groups, do the following.

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which the policy is to be configured.
3. Scroll down to the **Default Policy Setting** section.
4. Select the **Apply default policy to new groups** check box.
5. Click **Choose File**. The **Open** dialog box appears.
6. Select a file and click **Open**.

Print List of AirTight Mobile Groups for Location

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which you want to print the existing list of AirTight Mobile groups.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the **Print** icon. A print preview of the list appears.

5. Click **Print** seen on top of the list.
6. Select the printer.
7. Click **Print**.

Delete AirTight Mobile Group

When a group is deleted, all clients belonging to the deleted group are assigned to the 'Default' group. Do the following to delete an AirTight Mobile group

1. Go to **Configuration>AirTight Mobile>AirTight Mobile Groups**.
2. Select the location for which you want to delete an AirTight Mobile group. A list of Airtight Mobile groups appears.
3. Select the check box for the AirTight Mobile group to delete.
4. click the Delete icon for the group to be deleted.
5. The Delete Group confirmation message appears.
6. Click **Yes** to confirm deletion.


Dashboard

The dashboard is a snapshot of the wireless LAN performance. AirTight Management Console provides an easy-to-use dashboard that can be configured by the user. The user can select from a predefined collection of widgets and add them to the dashboard. The dashboard widgets are categorized as access point widgets, client widgets, network widgets and WIPS widgets. The widgets are a graphical representation of various AP, client, network, and wireless intrusion prevention related activities in the WLAN managed by AirTight Management Console.

If you are viewing the trend charts for a parent server location in a server cluster, you will see aggregated data in the trend charts.

Click **Dashboard** to view the dashboard.

The dashboard comprises one or more pages. On each page you can have multiple widgets from the available widget categories, that is, access point widgets, client widgets, network widgets and WIPS widgets.



Click  to view the widget categories and the widgets in these categories.

Click **Access Point** to view the access point widgets. Click **Client** to view the client widgets. Click **Network** to view the network widgets. Click **WIPS** to view the WIPS (wireless intrusion prevention system) widgets. Scroll through the widgets using  and .

Click the page number to view the respective dashboard page. Each page has a default name that is a combination of the text 'dashboard' and the page number. For instance, page 1 of dashboard has the default name 'Dashboard 1'. This is displayed to the left of the page numbers. You can rename each of the dashboard pages. To do this, go to the page where you want to change the name. Click inside the name box, change the name, and click outside the name box to save the change.

Add a page to dashboard

The dashboard can accommodate up to five pages. Each page can have up to 9 widgets on it. You have the flexibility to add pages to the dashboard, based on your need. You can also define the number of widgets you can have on each page. You can have widgets from different widget categories on the same page. You can add the same widget more than once to the same page. To add a widget to a page, scroll to the desired widget and click it.


Click  to add a new page to the dashboard. The new page is appended after the existing pages on the dashboard. After you click  to add a new page, drag the mouse and select the number of widgets and their layout to be seen on the page. The selected number of widgets indicates the maximum number of widgets that can be added to this page.


The following selection allows for the addition of four widgets on the new page. These widgets are arranged as two at the top of the page, and the remaining two arranged below the first two widgets.



Number of widgets and their layout on the new page

Delete a page from dashboard

Click  to delete the current page from the dashboard.

To delete a particular page, click the page number to go to the page. Now click  to delete it.

Print dashboard page

You can print a dashboard page. All the widgets seen on the dashboard page are printed when you print the page.

The page must be printed in landscape mode only. It is rendered best by the Google Chrome browser.

To print a dashboard page, go to the respective dashboard page and click the  icon.

WIPS Widgets

You can see widgets related to wireless intrusion prevention by clicking **WIPS** on the dashboard. The WIPS widgets on the dashboard are as follows.

- **Security Status**

This widget displays the Security Status of the network. Events which contribute to the security status are displayed upon clicking the widget. the following figure explains the 'Secure' status and 'Vulnerable' status.



Security Status

- AirTight Devices**

This chart presents the AirTight devices and their operating modes. Use the status filter to view, all, active or inactive devices.
- AP Classification**

This chart presents the Access Points based on their categories. Use the status filter to view, all, active or inactive APs.
- Client Classification**



This chart presents the clients based on their categories. Use the status filter to view, all, active or inactive clients.
- Latest Security Events**

This table lists the last events observed at this location. Use the Time, Severity and Number filters to respectively view the events occurred during a specific period of time, of a desired severity, and the number of events.
- Devices in Quarantine**

This chart presents the Access Points and clients in various states of quarantine.
- Top Security Event Categories**

This chart presents the number of events by categories. Use the time filter to filter events occurred during a specific period of time.
- Activation Switches**

The Activation Switches widget displays the status of the event activation and intrusion prevention policies. You can make changes to these policies from this widget. Click the Event Activation or the Intrusion Prevention switch on the widget to navigate to the respective page and then activate or deactivate the event activation or wireless intrusion prevention.

Click  to refresh the data on the widget. Click  to close the widget.

Network Widgets

You can see widgets related to network by clicking **Network** on the dashboard. The network widgets on the dashboard are as follows.

- **Location Map**

This widget displays your network locations along with the number of managed APs, the number of associations and the number of associated smart phones and tablets at each location. To use this widget, upload an appropriate map for each location folder and a floor plan for each location floor in the location tree. Drag and place your managed APs at the correct locations on the floor plan corresponding to their physical deployment.
- **Locations by APs**

This widget displays up to five locations with the most number of APs. You can view active or inactive APs for the selected location by selecting the appropriate option at the top of the widget. You can also view both active and inactive APs for the selected location, by selecting **All**. You can filter the content by selecting a SSID available in the widget.
- **Active APs Trend**

This widget trends the number of active APs over time. Use the SSID and status filters to respectively view the statistics for a specific Wi-Fi network and during a specific period.
- **Associations Trend**

This widget trends the number of association clients over time. Use the SSID and status filters to respectively view the statistics for a specific Wi-Fi network and active/inactive APs.
- **AP Data Transfer Trend**

This chart trends the average data rate across all managed APs at the selected location over time. Use the SSID and Time filters to respectively view the statistics for a specific Wi-Fi network and during a specific period.
- **Smart Device Associations by SSID**

This widget displays the currently active number of smartphones and tablets associated per SSID at the selected location.
- **Data transfer by SSID**




This chart displays the top SSIDs by data transfer. The SSIDs should be configured on managed APs. Use the Number and Time filters to respectively view the number of top SSIDs and during a specified period.
- **Average Association by SSID**

This chart displays the average number of associations per SSID over time.
- **Locations by Associations**

This chart displays the locations based on the number of associations. Use the SSID, Time, Top/Bottom and the Number filters to respectively view the Statistics for a specific Wi-Fi network, during a specific period, top or bottom and the number of locations.
- **Latest Performance Events**

This chart displays the latest performance events for the location. Use the Time, Severity and Number filters to respectively view the events occurred during a specific period of time, of a desired severity, and the number of events.
- **Average Data Transfer**




This chart displays the locations based on average data transfer. Data transfer includes both uplink and downlink. It is only for Access Points managed through AirTight Management Console. Use the SSID, Time, Top/Bottom and the Number filters to respectively view the Statistics for a specific Wi-Fi network, during a specific period, top or bottom and the number of APs.

In general, click  , wherever available, to refresh the data on the widget. Click  to view a description of the widget functionality. Click  to close the widget.

Client Widgets



You can see widgets related to clients by clicking **Clients** on the dashboard. The client widgets on the dashboard are as follows.

- **Smart Devices Distribution**
This chart displays the number of smart phones and tablets on your Wi-Fi network. Use the SSID and Time filters to respectively view the statistics for a specific Wi-Fi network and during a specific period.
- **Client Protocol Distribution**
This chart displays the number of associated clients according to the Wi-Fi protocol they are using: 802.11a, 802.11bg, 802.11an and 802.11bgn. You can filter the data by using the SSID to filter the statistics for a specific Wi-Fi network.
- **Clients by Traffic**
This chart displays clients based on the amount of traffic generated. Traffic includes both uplink and downlink data transferred. Use the Time, Top/Bottom and the Number filters to respectively view the Statistics during a specific period, top or bottom and the number of clients.
- **Clients by Data Rate**
This chart displays clients based on the average data rate. Clients experiencing very low data rate may be in the fringe areas of your Wi-Fi network or they may be low speed legacy devices (e.g., 802.11b). In either case, such clients are likely to impact the net capacity of the Wi-Fi network. Use the Time, Top/Bottom and the Number filters to respectively view the Statistics during a specific period, top or bottom and the number of clients.

In general, click  , wherever available, to refresh the data on the widget. Click  to view a description of the widget functionality. Click  to close the widget.

Access Point Widgets


You can see widgets related to access points (AP) by clicking **Access Point** on the dashboard. The AP widgets are as follows.

- **APs by Association**
This chart displays upto 10 APs with the most or least number of associated clients.
Click  and select **Chart type** as **Top** (to view APs with most number of associated clients) or **Bottom** (to view APs with least number of associated clients). Enter the maximum number of APs to view on the widget, and click **Save**.
Use the SSID and Time filters to respectively view the statistics for a specific Wi-Fi network and during a specific period.
- **APs by Traffic**
This chart displays upto 10 APs with the most or least traffic, including downlink and uplink. Click  and select **Chart type** as **Top** (to view APs with most traffic) or **Bottom** (to view APs with least traffic). Enter the maximum number of APs to view on the widget, and click **Save**.

Use the SSID and Time filters to respectively view the statistics for a specific Wi-Fi network and during a specific period.


- **APs by Utilization**

This Chart displays the APs which utilize the channel the maximum. AP channel utilization is defined as the act of the AP either transmitting or receiving any frames. Data and management frames are considered for this calculation.

Click  and select **Chart type** as **Top** (to view APs with most utilization) or **Bottom** (to view APs with least utilization). Enter the maximum number of APs to view on the widget, and click **Save**.

- **APs by Data Rate**

This chart displays APs based on average data rate. Data Rate includes both downlink and uplink. Very low data rate at an AP may indicate coverage issues or the presence of low speed legacy devices (e.g., 802.11b) in the network and is likely to impact the net capacity of the AP.




Click  and select **Chart type** as **Top** (to view top APs by data rate) or **Bottom** (to view bottom APs by data rate). Enter the maximum number of APs to view on the widget, and click **Save**. Use the SSID, Time, Top/Bottom and the Number filters to respectively view the Statistics for a specific Wi-Fi network, during a specific period, top or bottom and the number of APs.

- **AP Security Distribution**

This chart displays the live number of APs by their security settings: Open, WEP, WPA, 802.11i (WPA2). Use the SSID filter to view the statistics for a specific Wi-Fi network.

- **AP Protocol Distribution**

This chart displays the live number of APs by their Wi-Fi protocol settings: 802.11a, 802.11bg, 802.11an and 802.11bgn. Use the SSID filter to view the statistics for a specific Wi-Fi network.

In general, click , wherever available, to refresh the data on the widget. Click  to learn more about the widget functionality. Click  to close the widget.

Devices

The **Devices** page provides information about APs, clients, and AirTight devices visible to the system. You can view device properties, sort the display based on their properties, and change the device template used. You can view the APs, clients, networks associated with the devices.

Select a location to view devices at that location.

The **AirTight Devices** tab displays a list of AirTight devices associated with the selected location.

The **APs** tab displays a list of access points associated with the selected location.

The **Clients** tab displays a list of clients associated with the selected location.

The **Networks** tab displays a list of networks detected at the selected location.


AirTight Devices

The **Devices>AirTight Devices** tab displays all the AirTight devices associated with the selected location. AirTight devices are the access point/sensor devices from AirTight.

Select an AirTight device to view the list of APs, clients and VLANs visible to the AirTight device.


The **AirTight Devices** tab is divided into two panes. The upper pane shows a list of AirTight devices for the selected location. On selecting a device on the upper pane, the device properties related to the selected device are displayed in the lower pane. In the lower pane, you can view a list of VLANs, APs, and clients visible to the selected device. You can also view in the lower pane, a list of active APs, active clients visible to the selected device, and the interference experienced by the device during the past 12 hours.


A toolbar is seen between the two panes as shown in the figure below. You can perform various operations related to the AirTight devices using the options present on the toolbar. To perform any operation facilitated by the toolbar, you need to select an AirTight device row in the upper pane.



1-Change Location 2-Change device template 3-Upgrade software 4-Additional options 5-Print

Note: The options available to perform various operations depend on the role of the user that has logged in.

A  (plus sign) is located on the left most corner of each device row in the upper pane.

Click the  to view the a brief description of the AirTight device. The description indicates whether the device is operating as a sensor or as an AP, and provides information about the radios being used. If the device is operating as an AP, the frequency band, channel and background scanning information is also displayed.

If you want to customize the device template settings for a specific device, you can do it through device properties.

The following table provides a description of the fields seen in the upper pane of the **AirTight Devices** tab.

Field	Description
Active Status	Indicates whether the AirTight device is currently active or not.
Upgrade Status	Indicates if the AirTight device has been successfully upgraded.
Troubleshoot Status	Indicates the troubleshoot status of the AirTight device. The possible values are 'Troubleshooting on', 'Troubleshooting off'.
Quarantine Status	Indicates if the device is quarantined.
Name	A user-defined name of the AirTight device.
MAC Address	The unique 48-bit address of the AP/ 802.11 PHY modes used by the AP.
IP Address	The IP address of the AirTight device.
Model	The AirTight device model number.
Device Template	The device template applied to the AirTight device.
AP Mode	Indicates whether AP mode is enabled or disabled.
Capability	The 802.11 protocol used – 802.11a, 802.11b only, 802.11b/g, or 802.11a/b/g, with or without 802.11n capability.
Location	The location of the AirTight device.
Build	The firmware build number
Up/Down Since	Date and time since the AirTight device is up or down.
Monitored VLANs	Number of VLANs being currently monitored of the total number of VLANs to monitor.
Configuration Status	Indicates the configuration status of the AirTight device. The possible values are 'Allowed and Configured', 'Not Allowed and Configured', 'Allowed and Not Configured', 'Not Allowed and Not Configured'.
Operating Mode	Current mode of operation of the AirTight device.
Mesh Mode	Indicates whether mesh mode is enabled or disabled.

Device Properties

Each operating region has its own laws governing the use of the unlicensed frequency spectrum for 802.11 communications and Turbo mode. When you select an operating region, the system automatically selects the channels that are allowed by the regulatory domain in selected region.

Certain Atheros Chipset based devices use wider frequency bands on certain channels in 802.11 b/g and 802.11a band of channels. The system is capable of monitoring channels that support Turbo Mode of operation and detecting any unauthorized communication on these channels. You can select specific or all channels to monitor wireless activity on Turbo channels. There are ten Turbo channels in a-mode. These channels are 40, 42, 48, 50, 56, 58, 152, 153, 160, and 161. There is only one Turbo channel in b/g-mode, that is 6.

AirTight devices functioning as sensors scan WLAN traffic on specific channels, and defend the network against various WLAN threats on these channels. These channels are dependent on the operating region of the AirTight device operating in sensor mode.

The following table describes the device properties.

Field	Description
Currently Active?	State of the AirTight device. Yes indicates that the device is active, and No indicates that the device is inactive.
Name	Name of the AirTight device.
MAC Address	A unique 48-bit address of the AirTight device/ 802.11 PHY modes used by the AirTight device.
Device Tag	Text that provides additional information about the AirTight device.
Country of Operation	Country in which the AirTight device operates.
Model	AirTight device model number.
IP Address	IP address of the AirTight device.
Device Template	Device template applied to the AirTight device.
Location	Location of the AirTight device.
Placed on Floor map?	Specifies whether the AirTight device has been placed on the floor map layout for the location.
Up/Down Since	Date and time since the AirTight device is up or down.
Channel Scan Capability (a)	802.11a channels that the AirTight device is configured to scan. This field is populated based on the country of operation of the AirTight device.
Channel Defend Capability (a)	802.11 a channels that the AirTight device is configured to defend. This field is populated based on the country of operation of the AirTight device.
Channel Scan Capability (b/g)	802.11 b/g channels that the AirTight device is configured to scan. This field is populated based on the country of operation of the AirTight device.
Channel Defend Capability (b/g)	802.11 b/g channels that the AirTight device is configured to defend. This field is populated based on the country of operation of the AirTight device.
Channel Scan Capability (Turbo a)	Turbo 802.11a channels that the AirTight device is configured to scan. This field is populated based on the country of operation of the AirTight device.
Channel Scan Capability (Turbo b/g)	Turbo 802.11b/g channels that the AirTight device is configured to scan. This field is populated based on the country of operation of the AirTight device.
Software Build	Build number of the software on the device.
First Detected At	Date and time when the AirTight device was first detected by the server.
Operating Mode	Mode in which the device is currently operating. The AirTight device could operate either as an AP or as a sensor, depending on the device template applied to it.
Capability	802.11 protocol used by the AirTight device – 802.11a, 802.11b only, 802.11b/g, or 802.11a/b/g, with or without 802.11n capability.
SSIDs configured	SSIDs configured for the AirTight device on a radio. This field repeats for each radio.
Device Specific Customization	This field is visible only if the Airtight device is in an exclusively AP mode or in AP mode with background scanning enabled. You can override the device template settings if the per device configuration is enabled on the device template applied to the AP, and customize the settings. Double-click here to customize theradio settings such as Operating Channel, Custom Transmit Power, and the mesh node settings for the AP Refer to Customize Device

	Template Settings for more details.
Additional VLAN Monitoring	Customized additional VLAN monitoring settings. You can customize the additional VLANs monitored and override the additional VLANs monitored by the device and customize the settings. Double-click here to customize the additionally monitored VLANs. Refer to Customize Device Template Settings for more details.
Is Mesh Root Node (Radio <number>)?	Indicates whether or not radio 1 for the AP is in a mesh wireless network and the AP is a root node . 'Yes' indicates that the AP is a root node. You can edit this field only if the device template applied to this device has per device customization enabled on it. You can select 'Yes' only if the radio has a mesh profile attached to it. 'No' indicates that the AP is a non-root node.

Edit Device Properties

Some device properties are editable, others are not. To edit a device property, double-click it, edit it and save the new value.

Customize Device Template Settings

You can customize and override some settings for a device applied through the device template, if you have selected the **Allow Device Specific Customization** check box when defining the device template. You can customize the radio settings and the additional VLANs monitored in the device properties of the device.

You can customize the radio settings for an AirTight device operating in the AP mode, by modifying the radio settings in the **Device Properties**.

These settings override the settings done through the device template applied to the AirTight device.

To customize the radio settings, do the following.

1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Go to **Device Properties**.
4. Double-click the **Radio Settings** in **Device Properties**. You can customize the operating channel and/or the transmit power of the radio.

Radio settings [MAC Address : 00:11:74:47:5D:CF, Radio 1] ✕

Customize Operating Channel

Operating Channel Auto Manual

Selection Interval: Hour(s) [1-48]

Customize Transmit Power

Custom Transmit Power: [0 - 30] dBm

The value taken into effect is the lowest of

- The value of this parameter
- The maximum allowed by the regulatory authority in the region and band selected
- The maximum power supported by the Radio

Customize Radio Settings for an AirTight Device

To customize the operating channel, do the following.

1. Select the **Customize Operating Channel** check box.
2. If you want an auto selection of channel, select **Auto** and specify the channel selection interval, in hours, in the **Selection Interval**.
3. If you want to manually set the channel, select **Manual** and select the **Channel Number**.

Note: You are not allowed to change the operating channel for a mesh radio.

To customize the transmit power, do the following.

1. Select the **Customize Transmit Power** check box.
2. Select the check box next to **Custom Transmit Power** and specify the value. If you do not select the check box next to **Custom Transmit Power**, the value is set to maximum permissible transmit power for the country of operation for the AP.

To customize the additional VLANs monitored, do the following.

1. Select the device for which you want to customize the additional monitored VLANs.
2. Click the Additional VLAN Monitoring properties in **Device Properties**. The **Device Specific Customization for Additional VLAN Monitoring** dialog box appears.

✕
Device Specific Customization for Additional VLAN Monitoring

Customize Additional VLANs to Monitor
 Monitor Additional VLANs: 0 - 4094
[0:Untagged]
 Communication VLAN: ▼

^ Advanced

VLAN	Static/DHCP		
1	DHCP	Edit	Re-push
2	Static	Edit	Re-push
Untagged	DHCP	Edit	Re-push
4	DHCP	Delete	
19	DHCP	Delete	

Current communication VLAN: 2

💡 VLAN used by the device to communicate with the server and VLANs to which SSIDs deployed on the device are mapped are always monitored for Rogue APs and do not need to be added here. Specify here additional VLANs to be monitored for Rogue APs. Additional VLANs must be configured in the switch port where the device is connected.

3. Select the **Customize Additional VLANs to monitor** check box.
4. Specify the additional VLANs to be monitored as a comma-separated list.
5. Change the communication VLAN, if needed. 0 is the communication VLAN. However, you can specify another number as the communication VLAN. Before the 6.7 Update 5 release, the communication VLAN was set from the CLI only with the `set vlan config` command.

Note: Prior to the 6.7 Update 5 release, the communication VLAN could be only set from the CLI. From the 6.7 Update 5 release, it can be done from the AirTight Management Console.


IMPORTANT: After the communication VLAN has been set from the UI, it cannot be modified from the CLI. If you have set an incorrect communication VLAN from the UI, and want to change it, you have to first do a factory reset of the AirTight device, and then set the correct communication VLAN.
6. Click **Advanced** to do advanced operations such as editing the VLAN properties of the additionally monitored VLANs and to re-push the IP settings of these VLANs on to the AP or WIPS sensor.
 - a) To edit the VLAN properties of the VLANs, click **Edit**. Change the addressing mechanism to static or DHCP as required and save the change.
 - b) To re-push the revised IP settings of the additionally monitored VLANs on to the AirTight device, click **Repush** and then **Save**. If you want to cancel the repush, click **Cancel** before you click **Save**. The text on the link changes to repush pending until an acknowledgement is received from the AirTight device.

- c) You might see a few VLANs with the **Delete** link under **Advanced**. These are the previously monitored additional VLANs that are no longer relevant. You must delete these from the monitored list.
7. Click **Save** below **Additional VLAN monitoring** on **Device Properties** to save the customization to the additional monitored VLANs for the device.


View Visible LANs

Under the **Visible LANs** section, you can view a list of LANs that are visible to the selected AirTight device if it is operating as a WIPS sensor. VLAN details such as VLAN ID, IP Address, Net Mask, and Status are displayed. The VLAN over which the sensor communicates with the server is marked with an asterisk(*).

View Visible APs

Click  located below the device listing to view the Visible APs section. Under the **Visible APs** section, you can view a list of APs that are visible to the selected AirTight device if the device is operating as a WIPS sensor. AP details, such as name and RSSI received by the sensor, are displayed in the rows.

View Visible Clients

Click  located below the device listing to view the Visible Clients section. Under the **Visible Clients** section, you can view a list of clients that are associated with or seen by the selected AirTight device. Client details such as Name and RSSI received by the sensor are displayed in the rows.

View Active APs

Under the **Active APs** section, you can select a channel number to view a graphical representation of the active APs over the past 12 hours on that channel. The APs visible to the AirTight device selected in the upper pane are seen here.

View Active Clients

Under the **Active Clients** section, you can select a channel number to view a graphical representation of the active clients over the past 12 hours on that channel. The clients visible to the AirTight device selected in the upper pane are seen here.

View AirTight Device Events

Under the Events section, you can see the events related to the AirTight device.

View Channel Occupancy


Under the Channel Occupancy section, you can view a graphical representation of the active APs and active clients on various channels based on the time selected by you. Click the time duration hyperlink to select the number of hours for which you want to see the channel occupancy. Click Channel Map to view the channel map based on the selected band and time in the form of a bar graph.

View Interference

Under the **Interference** section, you can select a channel number to view a graphical representation of the interference experienced over that channel in the past 12 hours. The interference seen here is visible to the AirTight device selected in the upper pane.

View Mesh Network Links

This is relevant only if the selected AirTight device is part of a mesh wireless network.

1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Click  located below the device listing to view the mesh network links with respect to the selected AirTight device.
4. The AirTight AP that is the immediate parent of the selected AirTight (AP) device in the mesh network topology is seen in **Up Link**. The device name and the RSSI of the parent of the selected device is seen in **Up Link**. The AirTight APs that are connected to the selected AirTight AP as child nodes in the mesh network topology are seen in **Down Links**. The device name and the RSSI of the child nodes of the selected device are seen in **Down Links**.


Search AirTight Devices

You can search for an AirTight device using name or MAC address in the search string. All the AirTight devices having the search string or substring in their name or MAC address are displayed.

To search for one or more than one AirTight devices, do the following.

1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Enter the name or MAC address in **Quick Search** box at the top right corner.
4. Press the Enter key. The search result displaying the AirTight devices matching the search string appears.

Sort AirTight Devices

You can sort the columns in the tab in ascending or descending order, and can choose the columns to be displayed. Point to a column in the device list and click  to sort on the column or choose the columns to be viewed.

Change Location

To change the location of a device, do the following.

1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Select the AirTight device from the list of devices.
4. Click the Change location icon. The select location dialog box appears.
5. Select the new location for the AirTight device.
6. Click OK. The device is moved to the new location.

Print AirTight Device Information for Location

You can print all the information seen for all AirTight devices in the upper pane. You can choose the columns to be viewed on the UI by selecting them. The information seen in the upper pane is the information that will be seen in the printout.

If pagination is enabled, the list of AirTight devices on the current page are printed. To print a list of all AirTight devices for a location, you must go to each page and print the individual pages.

If pagination is disabled, only the list of AirTight devices visible on the UI is printed. This means that if there are 25 records of which only the first five have been presented on the UI, these five records are printed.

You must enable or disable pagination before you print.

To print the AirTight devices list for a location, do the following.

1. Click **Devices** and then click the **AirTight Devices** tab.
2. Select the location.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the print icon. The print preview of the AirTight devices list appears.
5. Click **Print** to print the list.

Change Device Template

To change the device template for an AirTight device, do the following.

1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Select the AirTight device.
4. Click the Change device template icon present on the toolbar. The **Change Device Template** dialog box appears.
5. Select a device template from the available list of device templates
6. Click **Save** to save the changes.

Reboot Device

To reboot an AirTight device do the following.

1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Select the AirTight device from the device list.
4. Click the More>Reboot device icon present on the toolbar. A reboot confirmation message is seen.
5. Click **Yes** to reboot the device. Click **No** if you do not wish to reboot the device.

Troubleshoot Device

An active AirTight device can troubleshoot itself. For active AirTight devices, you can troubleshoot in the packet level mode.

When you initiate troubleshooting, you must ensure that the AirTight device is reachable from the computer used to launch the AirTight Management Console.

You can troubleshoot using packet capture tools like Wireshark or any other tool available to you.

Alternatively, you can save the packet trace history to the AirTight server and download the history file to save it for future reference. The packet trace history is saved as a .pcap file. This can also be viewed using Wireshark.

A troubleshooting session automatically times out or terminates after the specified timeout irrespective of the activity. Refer to the 'Stop Troubleshooting' sub-section in this section to manually terminate a troubleshooting session.

If you are an AirTight Cloud Services user, you can upload the packet capture file directly into WizShark. You can then use WizShark to analyze the packet capture or trace files. Following are the prerequisites to successfully upload the file to WizShark.

- You must have subscribed to the WizShark service.
- You must have upload privileges in WizShark.
- The file size must not exceed the maximum file size prescribed by WizShark.
- When the file is uploaded, the total storage quota for your account must not be exceeded.

Troubleshoot AirTight Device using Wireshark on Local Machine

To troubleshoot an AirTight device, do the following.

1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Select the check box for the AirTight device to troubleshoot.
4. Click the **More>Packet Capture** option on the tool bar.
5. Select the **Live Packet Capture** option under **Troubleshooting Mode**. The Troubleshoot AP dialog box appears.
6. Select **Streaming option** as **Wireshark** on local machine.
7. Specify the time-out interval in **Timeout**. The default time-out for packet level troubleshooting mode is 5 minutes. Minimum allowed value is 1 minute and maximum is 720 minutes for the time-out.
8. Select the packet type. If you want to capture all packets, select the **All** option. If you want to capture only specific packet types, select the filter option and then select the required data frames and/or management frames to capture while troubleshooting.
9. In the **Protocol and Channel Selection** section, select the protocols and channel for which you want to troubleshoot. If you want to select a single channel, select the **Select Channel** option and specify the channel number and **Width** (channel offset). By default, the protocol and channels are displayed based on the device template applied to the troubleshooting sensor. You can select a different protocol and/or channel, if required. Alternatively, you can select the **Rotate on all Channels** option, to troubleshoot on all available channels.
10. Click **Start Troubleshooting** to start the troubleshooting. The sensor is enabled to capture live packets.
11. Select an appropriate tool for live packet capture. If you don't have the tools already installed, you can download Wireshark or any other tool.
12. To view the packet capture, open the command line interface of the operating system installed on your computer and execute the command shown under Wireshark depending on the tool you use. The **Troubleshooting in Packet Level Mode** dialog box gives a guideline to the command to execute for Wireshark.

Troubleshoot AirTight Device to upload Packet History to AirTight server

To troubleshoot an AirTight device, do the following.

1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Select the check box for the AirTight device to troubleshoot.
4. Click the **More>Packet Capture** option on the tool bar.
5. Select the **Live Packet Capture** option under **Troubleshooting Mode**. The Troubleshoot AP dialog box appears.
6. Select **Upload to Server** as **Streaming option**.

7. Enter a suitable prefix for the file name in **Filename Prefix**. This helps you identify the troubleshooting files when you download the packet history.
8. Specify the time-out interval in **Timeout**. The default time-out for packet level troubleshooting mode is 5 minutes. Minimum allowed value is 1 minute and maximum is 720 minutes for the time-out.
9. Select the packet type. If you want to capture all packets, select the **All** option. If you want to capture only specific packet types, select the filter option and then select the required data frames and/or management frames to capture while troubleshooting.
10. In the **Protocol and Channel Selection** section, select the protocols and channel for which you want to troubleshoot. If you want to select a single channel, select the **Select Channel** option and specify the channel number and **Width** (channel offset). By default, the protocol and channels are displayed based on the device template applied to the troubleshooting sensor. You can select a different protocol and/or channel, if required. Alternatively, you can select the **Rotate on all Channels** option, to troubleshoot on all available channels.
11. Click **Start Troubleshooting** to start the troubleshooting. The sensor is enabled to capture live packets.

Stop Troubleshooting

A troubleshooting session automatically times out or terminates after the specified timeout irrespective of the activity. You can manually terminate a troubleshooting session.

To stop an active troubleshooting session manually, do the following.

1. Click the Notifications icon at the top right corner. The active troubleshooting sessions are displayed along with other notifications, if any.
2. Click the notification for active troubleshooting sessions. A list of sensor troubleshooting sessions is displayed.
3. Select the check box for the troubleshooting session to terminate.
4. Click **Stop**. The troubleshooting session is terminated and a message indicating the termination of the troubleshooting session is displayed. If the **Upload to Server** option has been selected as **Streaming option** under **Troubleshooting Mode**, the packet trace history is uploaded to the AirTight server.

Download Packet Capture

AirTight server maintains a packet capture history for the troubleshooting instances for a period of 30 minutes, after you stop troubleshooting.

You can download this history and save them for future reference. The packet traces are available in .pcap format.

To download a packet trace file, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **AirTight Devices** tab.
4. Click the **More>Previous Packet Captures** option on the tool bar. The **Packet Capture** dialog box appears. The list of files is displayed with the file name, file size in KB, troubleshooting start time and troubleshooting stop time.
5. Click the **Download** link for the packet trace to download and select the path to store the packet trace. The packet trace file is saved to the specified location.


If you are an AirTight Cloud Services user, and wish to upload the packet capture file to WizShark from AirTight Management Console, click the **View in WizShark** link. The file is directly uploaded to WizShark

and WizShark opens up in a separate browser tab or browser window. You can then analyze the packet capture file using WizShark.

Delete Packet Capture File

AirTight server maintains a packet capture history for the troubleshooting instances for a period of 30 minutes, after you stop troubleshooting. You can delete this packet capture history from the server. The packet capture files are available in .pcap format.

To delete a packet capture file, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **AirTight Devices** tab.
4. Click the **More>Previous Packet Captures** option on the tool bar. The **Previous Packet Capture** dialog box appears. The list of files is displayed with the file name, file size in KB, troubleshooting start time and troubleshooting stop time.
5. Select the check box for the log file to delete. You can select multiple files to delete at a time.
6. Click the  icon. A message to confirm the deletion appears
7. Click **Yes** to confirm deletion of selected files.

Upgrade or Repair Device

To upgrade or repair a device, do the following.


1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Select one or more devices operating in the same mode.
4. Click the Upgrade software icon present on the toolbar.
5. Select the appropriate option from **Upgrade, Repair, Cancel Upgrade, Cancel Repair, Cancel Upgrade/Repair**.

Option	Description
Upgrade	Upgrade to a newer software version for the device.
Cancel Upgrade	Cancel the upgrade after you have initiated it and the upgrade operation is still in progress.
Repair	Fix the problem in the device software without change in software version like applying a patch.
Cancel Repair	Cancel the repair after you have initiated it and the repair operation is still in progress.
Cancel Upgrade/Repair	Cancel upgrade or repair as applicable while the operation is still in progress.


Enable Pagination for AirTight Device Listing and Set Page Size



By default, the AirTight device listing in the upper pane is presented in a grid. You can scroll down to the last AirTight device row in the upper pane without having to browse across pages. A paginated view is also available if you want to view a page-wise list of AirTight devices. You can enable pagination for the AirTight devices that are visible to you and configure the number of rows on each page in the upper pane.

To enable pagination, do the following.

1. Go to **Devices>AirTight Devices** tab.
2. Click the  icon seen on the right side of the tool bar. A message to confirm pagination for all grids/listings on the UI appears.
3. Click **OK**. The pagination for AirTight device listing is enabled. The pagination for all other grids such as clients, APs, networks, events and AirTight Mobile clients is enabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

To set the page size, do the following.


1. Go to **Devices>AirTight Devices** tab.
2. On the tool bar, click the down arrow next to the number of rows displayed to the left of the  icon. The options **First Page** and **Set page size** appear.
3. Click **Set Page Size** and enter the number of rows to be visible on each page.
4. Click **OK**.

You can browse through the paginated AirTight device listing by clicking the  (next page) and  (previous page) icons. To go to the first page, click the down arrow next to the number of rows on the page and select the **First page** option.

Disable Pagination for AirTight Device Listing

If you have enabled pagination and want to disable it, you can restore the default view of having a complete listing of all AirTight devices on a single page.

To disable pagination, do the following.

1. Go to **Devices>AirTight Devices** tab.
2. Click the  icon seen on the right side of the tool bar. A message to confirm disabling of pagination for all grids/listings on the UI appears.
3. Click OK. The pagination for AirTight device listing is disabled. The pagination for all other grids such as clients, APs, networks, events and AirTight Mobile clients is disabled as well. Note that this setting is restricted to your login only and is not applicable to other users.



Add Custom Filter

You can create custom filters and save them with the name of your choice. You can select the columns to be viewed and can, optionally, set a filter on the data in the columns seen on AirTight Management Console. You can save this filter with a name and can create multiple filters in this manner.

Note the following points when working with custom filters.




- Preferences for visibility of columns and sorting of column data are not saved in a custom filter. Only the filter criteria is saved.
- Custom filters are user-specific. They are saved for the user who has defined the custom filter and is not visible to any other user.
- An unsaved filter is indicated by an asterisk next to the filter name seen next to **Filter** on the tool bar.
- An unsaved filter is not saved if the user logs out without saving the filter.

To create a custom filter, do the following.

1. Go to **Devices>AirTight Devices**.
2. Click the  icon next to a column header. A list of options is displayed.
3. Point the mouse at the **Filters** option and enter the filter text for the column.
4. Click the  icon next to **Filter** on the tool bar and click **Save as**. The **Save as** dialog box appears.
5. Enter the name of the filter and click **OK**. The custom filter is saved.



Edit Custom Filter

To edit a custom filter, do the following.

1. Go to **Devices>AirTight Devices**.
2. Click the  icon next to **Filter** on the tool bar and select the required filter.
3. Click the  icon next to a column header. A list of options is displayed.
4. Point the mouse at the **Filters** option and enter the filter text for the column or make changes to the filter criteria as required.
5. Click the  icon next to **Filter** on the tool bar and click **Save**. The modified custom filter is saved.

Delete Custom Filter

To delete a custom filter, do the following.

1. Go to **Devices>AirTight Devices**.
2. Click the  icon next to **Filter** on the tool bar and click the  icon for the filter to delete. A message asking you to confirm delete appears.
3. Click **Yes** to confirm deletion of the custom filter.

Delete Device

To delete an AirTight device, do the following.

1. Click **Devices**.
2. Select the **AirTight Devices** tab.
3. Select the AirTight device to be deleted.
4. On the toolbar, click the Delete icon.
5. Click **Yes** to confirm the deletion.

Monitor Clients

The **Devices>Clients** tab displays all the clients associated with the selected location.


Select from category **Authorized, Rogue, External, Uncategorized** to view the list of authorized, rogue, external or uncategorized clients. You can choose one or more of these categories at a time. Select **All** to view clients from all categories.

The **Clients** tab is divided horizontally into two panes. The upper pane shows a list of clients for the selected location. The lower pane shows the client properties related to the client you select in the upper pane of the **Clients** tab. You can view a list of APs or ad hoc networks recently associated with the selected client, in case of authorized, rogue, external and uncategorized clients.

Both active and inactive clients are visible in the Clients tab. Inactive clients of some categories are visible in specific deployments only.

In case of authorized clients, you can also view client traffic, client average data rate in the lower pane.



You can perform various operations related to the clients using the options present on the toolbar as shown in the image below.



To perform any operation facilitated by the tool bar, you need to select a client row in the upper pane. You can select multiple clients for some operations like delete.

Note: The options available to perform various operations depend on the role of the user that has logged in.

Station virtual APs of the non-root mesh APs that are connected to uplink mesh APs in a wireless mesh network are seen as clients. These are categorized as Authorized, by default. You cannot change the category of these clients. You cannot quarantine or automatically ban such clients. Hence the options under More in the toolbar are disabled for such clients.

You can sort the client information based on the columns in the upper pane of the **Clients** tab in ascending or descending order, and can choose the columns to be displayed. Point to a column and click  to sort on the column, choose the columns to be viewed, or filter the data to be viewed based on filter text matching the text in the selected column. For example, if you want to view only the clients at location 'Texas', point to **Location** click  and enter *Texas* as the filter text. Press the **Enter** key.

Note: Sorting on the columns AirTight Mobile Status, AirTight Mobile Risk Level and AirTight Mobile Groups is available in specific deployments only.

You can search for a client by entering the name, MAC address or SSID in **Quick Search** box at the top right corner.

The following table provides a description of the fields seen in the upper pane of the **Clients** tab.

Field	Description
Active Status	Indicates if the client is active or inactive. The status is indicated with the help of different icons.
Smart Device	Indicates if the client is a smart device.
Quarantine Status	Displays the quarantine status of the client. Possible values are Quarantine Active, Quarantine Pending, Quarantine Stopped.
RSSI	Displays the observed RSSI (Received Signal Strength Indicator) value for the client .
Name	Specifies the user-defined name of the client.
MAC Address	Specifies the unique 48-bit IEEE format address of the client assigned to the network adapter by the manufacturer.
Associated AP	Specifies the AP with which a Client is associated. This is the AP through which the Client communicates with other Clients and other networked devices.
SSID	Specifies the operating SSID of the AP with which the Client is associated.
Manually Classified	Indicates if the client has been manually classified.
Tag	Device tag. Additional information about the client. To be entered by a user.
Is Banned	Indicates if the client is banned.
AirTight Mobile Status	Indicates if the client is an AirTight Mobile client, that is if the client has AirTight Mobile installed on it.
AirTight Mobile Risk Level	Indicates the risk level of the AirTight Mobile client. This is applicable only if AirTight Mobile is installed on the client.
AirTight Mobile Group	AirTight Mobile group of the client. This is applicable only if AirTight Mobile is installed on the client.
Smart Device	Category of smart device indicated by icon if the device is a smart device. The field is blank if the device is not a smart device.
Smart Device Type	Type of smart device.
Vendor	Client manufacturer. The vendor name is inferred from the first three bytes of the MAC address.

Location	Location of the client.
Protocol	802.11 protocol (with or without 802.11 n or 802.11 ac capability) used by the AP with which the Client is associated.
Up/Down Since	Date and time since the AP is up or down.
Cell ID	ID for clients in ad hoc mode. The Cell ID is common for all the Clients that form a single ad hoc connection.
Troubleshooting	Indicates if troubleshooting is in progress for the client. Possible values are Yes, No.
First Detected At	Date and time at which the client was first detected.
IP Address	IP address of the client.
User name	User ID of the user logged on to the client.
Is Misbehaving	'Yes' indicates that the authorized client is misbehaving. 'No' indicates that the authorized client is not misbehaving. A '--' indicates that the field is not applicable as the client is unauthorized.

View Client Properties

Some client properties are editable, others are not. A pencil icon is seen to the right of the client properties value indicating that the property is editable. To edit a client property, double-click it, edit it and save the new value.

The following table provides a field-wise description of the client properties.

Field	Description
Currently Active?	Indicates if the client is currently active. 'Yes' means that the client is active. 'No' means that the client is inactive.
Client Name	Host name of the client.
User Name	User ID of the user logged on to the client.
Classification	Indicates whether the client is categorized as Authorized, External, or Rogue. Uncategorized indicates that the client has not been categorized.
Device Tag	Additional information about the client.
MAC address	MAC address of the client.
Location	Client location.
Up Since	Date and time since when the client is up.
Is Smart Device	Indicates if the client is a smart device. Yes indicates that the client is a smart device. No indicates that the client is not a smart device
Smart Device Type	Indicates the type of smart device, if the client is a smart device. The field is visible only if the client is a smart device.
Mode of Operation	Specifies whether the Client is connected to an AP or to a peer-to-peer network Infrastructure mode indicates that the client is connected to an AP. Ad hoc mode indicates that the client connected to a peer-to-peer network.
Ad hoc Cell ID	Unique ID of the ad hoc network connection of which the selected Client is a member.

IP Address	IP address of the client.
Vendor	Name of the Client manufacturer. The vendor name is inferred from the first three bytes of the MAC address.
Protocol	802.11 protocol in which the client is currently operating.
Channel	Channel number that the client operates on.
Security	Security standard applied to the AP. This is derived from the template applied to the AP.
Network	Additional information about the IP Address and subnet that identifies the network on which the Client is located.
Associated to AP	BSSID of the AP that the client is associated with.
First Detected at	Date and time when the client was first detected by the system.
Quarantine Status	Indicates if the client is in quarantine.
Defending Sensor Name	Name of the defending sensor.
Quarantine Pending Reason	Specifies the reason if quarantine is pending.
Bridging/ICS Mode	Indicates if the client is in bridging/ICS mode. 'Yes' indicates that the client is in bridging/ICS mode. 'No' indicates that the client is not in bridging/ICS mode.
Running Soft AP?	Indicates if a soft AP is running on the client. 'Yes' indicates that a soft AP is running on the client. 'No' indicates that a soft AP is not running on the client.
WDS Mode	Indicates if Wireless Distribution System (WDS) is enabled. This is applicable only if the client is an AP, and has connected to a WDS AP.
Tx STBC 802.11n	Indicates support for transmission of PPDU's using STBC for active 802.11n client. 'Yes' indicates that transmission of PPDU's using STBC is supported for active 802.11n client. 'No' indicates that transmission of PPDU's using STBC is not supported for active 802.11n client. This field is visible for active 802.11n clients only.
Rx STBC 802.11n	Indicates support for reception of PPDU's using STBC for active 802.11n client. If this reception is supported, the number of spatial streams supported are indicated. Upto 3 spatial streams are supported for the 802.11n protocol. If this reception is not supported, the value of this field is 'Not supported'. This field is visible for active 802.11n clients only.
802.11ac Capability	This field is visible for active 802.11ac clients only. It indicates if the client has built-in support for 802.11ac protocol. 'Yes' indicates that the client is 802.11ac capable.
Tx STBC 802.11ac	Indicates support for transmission of PPDU's using STBC for the active 802.11ac client. 'Yes' indicates that transmission of PPDU's using STBC is supported for the active 802.11ac client. 'No' indicates that transmission of PPDU's using STBC is not supported for the active 802.11ac client. This field is visible for active 802.11ac clients only.
Rx STBC 802.11ac	Indicates support for reception of PPDU's using STBC for active 802.11ac client.

	<p>If this reception is supported, the number of spatial streams supported is indicated. Upto 4 spatial streams are supported for the 802.11ac protocol.</p> <p>If this reception is not supported, the value of this field is 'Not supported'.</p> <p>This field is visible for active 802.11ac clients only.</p>
MU Beamformer Capability	<p>Indicates support for operation as a multiuser beamformer.</p> <p>'Yes' indicates that the operation as a multiuser beamformer is supported.</p> <p>'No' indicates that the operation as a multiuser beamformer is not supported.</p> <p>This field is visible for active 802.11ac clients only.</p>
MU Beamformee Capability	<p>Indicates support for operation as multiuser beamformee.</p> <p>'Yes' indicates that the operation as a multiuser beamformee is supported.</p> <p>'No' indicates that the operation as a multiuser beamformee is not supported.</p> <p>This field is visible for active 802.11ac clients only.</p>

View Recently Associated APs/Ad hoc networks

Under **Recently Associated APs/Ad hoc Networks**, you can view a list of APs/Ad hoc networks to which the Client was associated. APs/Ad hoc network details such as AP Name/Ad hoc ID, BSSID, SSID, Last Detected At are displayed in the widget. The criterion for Recent Association is either 12 hours or the total number of APs/Ad hoc Networks (this is the total number of associations in the system and not per device). The total number of associations maintained by AirTight Management Console depends upon the number of AirTight devices connected to the AirTight server.

Note: Information related to recently associated APs is available in specific deployments only.

View Events related to Client

Under Events, you can see all the events related to the client. The Event ID, event description, event start time and event stop time are displayed.

View Client Retransmission Rate Trend

This widget is seen for authorized clients only. You can select the time duration and view a graphical representation of the client retransmission rate trend over the selected time duration.

View Devices Seeing Client

Under **Devices Seeing Client**, you can view the active devices that have detected the selected client. The name of the device and the RSSI of the device are seen in this section. This section is populated for all types of clients.

View Client Average Data Rate

Client Average Data Rate section is seen only for authorized clients. AirTight device seeing the client keep track of the transmission rates of the data frames in the AP's BSS and reports weighted average transmission rate over every 15 minutes.

View Client Traffic

Client Traffic section is seen only for authorized clients. AirTight device seeing the client reports data traffic sent and received by the client every 15 minutes. The channel rotating AirTight device spends only a percentage of the total time on any given channel. Hence this parameter typically underestimates the actual traffic by a factor equal to the total number of channels scanned by the device radio. For example, if the AirTight device scans 30 channels in all, the measured traffic would be 1/30th of the actual traffic. However, if the traffic is bursty in nature, such straightforward scaling cannot be applied.

Change Client Location

You can change the client location for a selected client.

To change the client location, do the following.

1. Go to **Devices**.
2. Select the **Clients** tab.
3. Select the client for which the location has to be changed.
4. Click the Change location icon. The Select New Location dialog box appears.
5. Select the new location for the client.
6. Click OK. The client is moved to the newly selected location.

Quarantine Client

To quarantine a client, do the following.

1. Go to **Devices**
2. Select the **Clients** tab.
3. Select the client to be quarantined.
4. Click the Move to Quarantine icon. You are prompted to confirm the quarantine.
5. Click Yes to quarantine the selected client.

Disable Auto Quarantine/Exclude Device from Intrusion Prevention Policy

You can exclude a device from the intrusion prevention policy by disabling auto-quarantine for the device.

To disable auto-quarantine, do the following.

1. Go to **Devices**
2. Select the **Clients** tab.
3. Select the client for which auto-quarantine is to be disabled.
4. Click More present on the toolbar.
5. Click the Disable auto-quarantine icon present under More, to disable auto-quarantine. A message to confirm disable auto-quarantine appears.
6. Click Yes to confirm the disabling of auto-quarantine for the device.

Add to banned list

To add a client to the banned client list, do the following.

1. Go to **Devices**
2. Select the **Clients** tab.
3. Select the client.
4. Click the Add to banned list icon present on the toolbar. The client is added to the banned list.

Classify / Declassify as Smart Device

To classify a client as a smart device, do the following.

1. Go to **Devices**
2. Select the **Clients** tab.
3. Select the client.
4. Click the smart device icon present on the toolbar, to classify or declassify the client as a smart device. If the client has already been marked as a smart device, you can specify whether it is an approved or unapproved smart device.
5. To classify the client as a smart device, select **Is a Smart Device** option. To declassify a smart device, select **Not a Smart Device** option.

Change Client Category

To change the client category, do the following.

1. Go to **Devices**
2. Select the **Clients** tab.
3. Select the client.
4. Click the Client category icon present on the toolbar, to change the existing client category.
5. Select the desired category from **Authorized**, **External**, **Rogue**, **Guest**, as the case may be.

Reset Data Transmitted by Client

Note: The Reset RF Fingerprint option is available in specific deployments only.

To reset the data transmitted by a client, do the following.

1. Go to **Devices**
2. Select the **Clients** tab.
3. Select the client for which you want to reset the data.
4. Click the Reset RF Fingerprint icon present on the toolbar, to reset the data transmitted by the client.

Locate Client

To locate a client on the floor map, do the following.

1. Go to **Devices>Clients** tab.
2. Click the Locate icon to locate the client on the floor map.

View Recently Probed SSIDs

To view recently probed SSIDs, do the following.

1. Go to **Devices>Clients** tab.
2. Select a client.
3. Go to Recently Probed SSIDs widget in the lower pane to view the recently probed SSIDs and its details for the selected client.

Troubleshoot Client

You can troubleshoot clients using an AirTight device operating in sensor mode.

When you initiate troubleshooting, you must ensure that the AirTight device (sensor) is reachable from the computer used to launch the AirTight Management Console. If the AirTight device is busy in quarantine or busy in troubleshooting, it will be not be able to troubleshoot the selected client.

You can have an AirTight device (sensor) troubleshoot the client in packet level mode or event level mode. This sensor can troubleshoot in packet level mode using packet capture tools like Wireshark or any other tool available to you.

A troubleshooting session automatically times out or terminates after the specified timeout irrespective of the activity.

Note: When a troubleshooting session is in progress, a notification regarding the active troubleshooting session can be seen under Notifications (top right corner of the AirTight Management Console).

IMPORTANT: Once the packet capture based troubleshooting session begins from the Console and the packet capture tool is either interrupted or terminated (gracefully or abruptly), you have to first stop the ongoing troubleshooting session from the Console either manually (if it is still going on) or ensure that the session has indeed ended before you can start another packet capture session. Refer to the 'Stop Troubleshooting' sub-section in this section to manually terminate a troubleshooting session.

You can then restart the fresh troubleshooting session from the Console.

If a troubleshooting session is in progress with a chosen tool (Wireshark or user specified tool), another capture from the command prompt, using user specified capture parameters (viz. rpcap://sensor-ip/iface) will not succeed from the same or another computer.

If you are an AirTight Cloud Services user, you can upload the packet capture file directly into WizShark. You can then use WizShark to analyze the packet capture or trace files. Following are the prerequisites to successfully upload the file to WizShark.

- You must have subscribed to the WizShark service.
- You must have upload privileges in WizShark.
- The file size must not exceed the maximum file size prescribed by WizShark.
- When the file is uploaded, the total storage quota for your account must not be exceeded.

Troubleshoot Client in Packet Level Mode

To troubleshoot a client in packet level mode, do the following.

1. Click **Devices**.
2. Select the **Clients** tab.
3. Select the check box for the client to troubleshoot.
4. Click the **More>Packet Capture** option on the toolbar. The Troubleshoot on Client device dialog box appears.

5. Select the **Live Packet Capture** option.
6. Specify the timeout interval in **Timeout**. The default timeout for packet level troubleshooting mode is 5 mins. Minimum allowed value is 1 minute and maximum is 720 minutes for the timeout.
7. Select the type of packets you want to see while troubleshooting under **Traffic Selection**. If you want to view all packets visible to the troubleshooting sensor, select the **All packets on the channel** option. If you want to view only packets from the client visible to the troubleshooting sensor, select the **Only packets for the selected client <client MAC>** option.
8. Select the check box for the sensor using which you want to do the troubleshooting, from the list of AirTight devices operating as sensors. The sensors seeing the device are sorted based on their availability and signal strength.
9. In the **Protocol and Channel Selection** section, select the protocols and channel for which you want to troubleshoot. If you want to select a single channel, select the **Select Channel** option and specify the channel number and **Width** (channel offset). By default, the protocol and channels are displayed based on the device template applied to the troubleshooting sensor. You can select a different protocol and/or channel, if required. Alternatively, you can select the **Rotate on all Channels** option, to troubleshoot on all available channels.
10. Click **Start Troubleshooting** to start the troubleshooting. The sensor is enabled to capture live packets.
11. Select an appropriate tool for live packet capture. If you don't have the tools already installed, you can download Wireshark or any other tool.
12. To view the packet capture, open the command line interface of the operating system installed on your computer, and execute the command shown under Wireshark depending on the tool you use. The **Troubleshooting in Packet Level Mode** dialog box gives a guideline to the command to execute for Wireshark.

Troubleshoot Client in Event Level Mode

To troubleshoot a client in event level mode, do the following.

1. Click **Devices**.
2. Select the **Clients** tab.
3. Select the check box for the client to troubleshoot.
4. Click the **More>Packet Capture** option on the toolbar. The Troubleshoot on Client device dialog box appears.
5. Select the **Generate additional events for the device** option.
6. Specify the timeout interval in **Timeout**. The default timeout for event level troubleshooting mode is 2 mins. Minimum allowed value is 1 minute and maximum is 5 minutes for the timeout.
7. Select the check box for the sensor using which you want to do the troubleshooting, from the list of AirTight devices operating as sensors.
8. In the **Protocol and Channel Selection** section, select the protocols and channel for which you want to troubleshoot. If you want to select a single channel, select the **Select Channel** option and specify the channel number and **Width** (channel offset). By default, the protocol and channels are displayed based on the device template applied to the troubleshooting sensor. You can select a different protocol and/or channel, if required. Alternatively, you can select the **Rotate on all Channels** option, to troubleshoot on all available channels.
9. Click **Start Troubleshooting** to start the troubleshooting. The sensor generates events while troubleshooting and these can be viewed under device listing as the latest events for the sensor.

Stop Troubleshooting

A troubleshooting session automatically times out or terminates after the specified time-out irrespective of the activity. You can manually terminate a troubleshooting session.

To stop an active troubleshooting session manually, do the following.

1. Click the Notifications icon at the top right corner. The active troubleshooting sessions are displayed along with other notifications, if any.
2. Click the notification for active troubleshooting sessions. A list of sensor troubleshooting sessions is displayed.
3. Select the check box for the troubleshooting session to terminate.
4. Click **Stop**. The troubleshooting session is terminated and a message indicating the termination of the troubleshooting session is displayed.

Download Packet Capture

AirTight server maintains a packet capture history for the troubleshooting instances for a period of 30 minutes, after you stop troubleshooting.

You can download this history and save them for future reference. The packet captures are available in .pcap format.

To download a packet capture file, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **Clients** tab.
4. Click the **More>Previous Packet Captures** option on the tool bar. The **Packet Capture** dialog box appears. The list of files is displayed with the file name, file size in KB, troubleshooting start time and troubleshooting stop time.

5. Click the **Download** link for the packet capture file to download and select the path to store it. The packet capture file is saved to the specified location.


If you are an AirTight Cloud Services user, and wish to upload the packet capture file to WizShark from AirTight Management Console, click the **View in WizShark** link. The file is directly uploaded to WizShark and WizShark opens up in a separate browser tab or browser window. You can then analyze the packet capture file using WizShark.

Delete Packet Capture File

AirTight server maintains a packet capture history for the troubleshooting instances for a period of 30 minutes, after you stop troubleshooting.

You can delete this packet capture history from the server. The packet capture files are available in .pcap format.

To delete a packet capture file, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **Clients** tab.
4. Click the **More>Previous Packet Captures** option on the tool bar. The **Previous Packet Capture** dialog box appears. The list of files is displayed with the file name, file size in KB, troubleshooting start time and troubleshooting stop time.
5. Select the check box for the log file to delete. You can select multiple files to delete at a time.
6. Click the  icon. A message to confirm the deletion appears
7. Click **Yes** to confirm deletion of selected files.

Debug Client Connection Problems

When you have problems connecting to an AirTight AP, you can troubleshoot the client connection to find the root cause of the problem. The Connection Troubleshooting option on the tool bar enables you to debug the connection problems encountered by your wireless client.

A client is detected and is visible in AirTight Management Console under **Devices>Clients** when one or more AirTight devices or other similar devices in the vicinity of the client operate in background scanning mode or sensor mode.

A client is not visible in AirTight Management Console when background scanning is disabled for the AirTight devices or other similar devices operating in the vicinity of the client or when no sensors are present in the vicinity of the client.

In either case, you can debug a client irrespective of whether or not it is visible in the client listing under **Devices>Clients**.

When the client is visible under the client listing in AirTight Management Console, you can select this client and debug the connection problem. Otherwise, you can manually enter the MAC address of the client and debug the connection problem for this client.

You can troubleshoot more than one clients at a time, that is, while connection troubleshooting is in progress for one client you can start troubleshooting session for another client. There is no limit on the number of concurrent client troubleshooting sessions.

When troubleshooting is in progress connection logs are displayed on AirTight Management Console. This helps you find the exact cause of the problem instantly. It complements packet capture tools like Wireshark,

Once you stop troubleshooting, you can download the connection log history for future reference. It is saved as a text (.txt) file. For details on downloading the connection log history, refer to [Download Connection Log](#)

To troubleshoot a device visible under **Devices>Clients**, do the following.

1. Select the required location on the location tree.
2. Click **Devices**.
3. Select the **Clients** tab.
4. Select the check box for the client to troubleshoot.
5. Click the **More>Connection Logs** option on the toolbar. The **Connection Logs** dialog box appears.
6. Change a time-out if you want a different one. The default is 5 minutes.
7. Enter an SSID in SSID List. You can enter more than one SSIDs as a comma-separated list.
8. Click **Select AP**. A list of APs is displayed.
9. Select the AP with which the client is attempting to connect.
10. Click **Start Troubleshooting**. Connection logs are displayed.
11. Click **Stop Troubleshooting** when you are done with the troubleshooting. You can download the connection log file from the connection log history after you stop troubleshooting.

To troubleshoot a device not visible under **Devices>Clients**, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **Clients** tab.
4. Click the **More>Connection Logs** option on the toolbar. The **Connection Logs** dialog box appears.
5. Enter the MAC address of the client in **Client MAC**.
6. Change a time-out if you want a different one. The default is 5 minutes.
7. Enter an SSID in SSID List. You can enter more than one SSIDs as a comma-separated list.
8. Click **Select AP**. A list of APs is displayed.
9. Select the AP with which the client is wanting to connect.
10. Click **Start Troubleshooting**. Connection logs are displayed.
11. Click **Stop Troubleshooting** when you are done with the troubleshooting. You can download the connection log file from the connection log history after you stop troubleshooting.

Download Connection Log

AirTight server maintains a log history for all the client connection troubleshooting instances for a period of 30 minutes, after you stop troubleshooting.

You can download this debug log history and save them for future reference. The connection logs are available in .txt format.

To download the connection logs for a client visible under **Devices>Clients**, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **Clients** tab.
4. Select the check box for the client for which you want to download the connection log history.
5. Click the **More>Previous Connection Logs** option on the toolbar. The **Connection Log History** dialog box appears.
6. Click **Get History**. The list of connection logs for this client stored on the AirTight server are displayed. The file names are displayed with the troubleshooting start time and troubleshooting stop time.
7. Click the Download link for the connection log to download and select the path to store the connection log. The connection log is saved to the specified location.

To download the connection logs for a client not visible under **Devices>Clients**, do the following.


1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **Clients** tab.
4. Click the **More>Connection Log History** option on the toolbar. The **Previous Connection Logs** dialog box appears.
5. Enter the MAC address of the client in **MAC Address**.
6. Click **Get History**. The list of connection logs for this client stored on the AirTight server are displayed. The file names are displayed with the troubleshooting start time and troubleshooting stop time.
7. Click the Download link for the connection log to download and select the path to store the connection log. The connection log is saved to the specified location.

Delete Connection Log History


AirTight server maintains a log history for all the client connection troubleshooting instances for a period of 30 minutes, after you stop troubleshooting.

You can delete this connection log history from the server. The connection logs are available in .txt format.

To delete the connection logs for a client visible under **Devices>Clients**, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **Clients** tab.
4. Select the client for which you want to download the connection log history.
5. Click the **More>Previous Connection Logs** option on the tool bar. The **Previous Connection Logs** dialog box appears.
6. Click **Get History**. The list of connection logs for this client stored on the AirTight server are displayed. The list of files is displayed with the file name, file size in KB, troubleshooting start time and troubleshooting stop time.
7. Select the check box for the log file to delete. You can select multiple log files to delete.
8. Click the  icon. A message to confirm the deletion appears
9. Click **Yes** to confirm deletion of selected log files.


To delete the connection logs for a client not visible under **Devices>Clients**, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **Clients** tab.
4. Click the **More>Previous Connection Logs** option on the tool bar. The **Previous Connection Logs** dialog box appears.
5. Enter the MAC address of the client in MAC Address.
6. Click **Get History**. The list of connection logs for this client stored on the AirTight server are displayed. The list of files is displayed with the file name, file size in KB, troubleshooting start time and troubleshooting stop time.
7. Select the check box for the log file to delete. You can select multiple log files to delete.
8. Click the  icon. A message to confirm the deletion appears
9. Click **Yes** to confirm deletion of selected log files.


Enable Pagination for Client Listing and Set Page Size



By default, the client listing in the upper pane is presented in a grid. You can scroll down to the last client row in the upper pane without having to browse across pages. A paginated view is also available if you want to view a page-wise list of clients. You can enable pagination for the clients that are visible to you and configure the number of rows on each page in the upper pane.

To enable pagination, do the following.

1. Go to **Devices>Clients** tab.
2. Click the  icon seen on the right side of the tool bar. A message to confirm pagination for all grids/listings on the UI appears.
3. Click **OK**. The pagination for client listing is enabled. The pagination for all other grids such as AirTight devices, APs, networks, events and AirTight Mobile clients is enabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

To set the page size, do the following.


1. Go to **Devices>Clients** tab.
2. On the tool bar, click the down arrow next to the number of rows displayed to the left of the  icon. The options **First Page** and **Set page size** appear.
3. Click **Set Page Size** and enter the number of rows to be visible on each page.
4. Click **OK**.

You can browse through the paginated client listing by clicking the  (next page) and  (previous page) icons. To go to the first page, click the down arrow next to the number of rows on the page and select the **First page** option.

Disable Pagination for Client Listing

If you have enabled pagination and want to disable it, you can restore the default view of having a complete listing of all clients on a single page.

To disable pagination, do the following.

1. Go to **Devices>Clients** tab.
2. Click the  icon seen on the right side of the tool bar. A message to confirm disabling of pagination for all grids/listings on the UI appears.
3. Click **OK**. The pagination for client listing is disabled. The pagination for all other grids such as AirTight devices, APs, networks, events and AirTight Mobile clients is disabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

Add Custom Filter



You can create custom filters and save them with the name of your choice. You can select the columns to be viewed and can, optionally, set a filter on the data in the columns seen on AirTight Management Console. You can save this filter with a name and can create multiple filters in this manner.

Note the following points when working with custom filters.

- Preferences for visibility of columns and sorting of column data are not saved in a custom filter. Only the filter criteria is saved.
- Custom filters are user-specific. They are saved for the user who has defined the custom filter and is not visible to any other user.




- An unsaved filter is indicated by an asterisk next to the filter name seen next to **Filter** on the tool bar.
- An unsaved filter is not saved if the user logs out without saving the filter

To create a custom filter, do the following.

1. Go to **Devices>Clients**.
2. Click the  icon next to a column header. A list of options is displayed.
3. Point the mouse at the **Filters** option and enter the filter text for the column.
4. Click the  icon next to **Filter** on the tool bar and click **Save as**. The **Save as** dialog box appears.
5. Enter the name of the filter and click **OK**. The custom filter is saved.



Edit Custom Filter

To edit a custom filter, do the following.

1. Go to **Devices>Clients**.
2. Click the  icon next to **Filter** on the tool bar and select the required filter.
3. Click the  icon next to a column header. A list of options is displayed.
4. Point the mouse at the **Filters** option and enter the filter text for the column or make changes to the filter criteria as required.
5. Click the  icon next to **Filter** on the tool bar and click **Save**. The modified custom filter is saved.

Delete Custom Filter

To delete a custom filter, do the following.

1. Go to **Devices>Clients**.
2. Click the  icon next to **Filter** on the tool bar and click the  icon for the filter to delete. A message asking you to confirm delete appears.
3. Click **Yes** to confirm deletion of the custom filter.

Print Client List for Location

You can print all the information seen for all clients in the upper pane. You can choose the columns to be viewed on the UI by selecting them. The information seen in the upper pane is the information that will be seen in the printout. If pagination is enabled, the list of clients on the current page are printed. To print a list of all clients for a location, you must go to each page and print the individual pages.

If pagination is disabled, only the list of clients visible on the UI is printed. This means that if there are 25 records of which only the first five have been presented on the UI, these five records are printed.

You must enable or disable pagination before you print.

To print a list of clients for a location, do the following.

1. Go to **Devices>Clients** tab.
2. Select the location for which you want to print the clients' list.
3. Select the type of clients for which you want to print the list.
4. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
5. Click the print icon. The print preview of the client list appears.
6. Click **Print** to print the list.

Delete Client

To delete a client, do the following.

1. Go to **Devices**
2. Select the **Clients** tab.
3. Select the client.
4. Click the Delete client icon present on the toolbar, to initiate the delete operation for the client.
5. To delete, click **Yes** when asked to confirm the deletion. Active clients that are deleted may be rediscovered by sensors and would be visible once again in the client list. Inactive clients will disappear from the client list on deletion.

Spectrogram

On **Devices->AirTight Devices** tab, view the spectrogram for the selected AirTight device. Go to page 5 and click the **Spectrogram** hyperlink present on the **Interference** widget on this page.

Spectrogram is a graphical representation of interference for the selected radio and time frame of the AirTight device.

Monitor Access Points (APs)

The **Devices>APs** tab displays all the APs associated with the selected location. This includes AirTight APs, too.

Access points (APs) are hardware devices that transmit and receive radio signals in a wireless network. Clients like laptops and smart phones connect to an access point to access data on the network that the access point associates with or is connected to. Access points are, sometimes, used to extend a wired network.

AirTight Management Console classifies APs into four types

Uncategorized AP - When an AP is first detected by a WIPS sensor, it is treated as an uncategorized AP.

Authorized AP - This AP is authorized by a network administrator to access the wired/wireless network and network resources.

Rogue AP - This AP is not authorized to access the network or network resources. It is an AP that is installed in an unauthorized manner, without the knowledge of or without authorization from a network administrator. It can be used for malicious activity such as causing damage to your network or stealing sensitive data from network resources. It is essential to protect your network from rogue APs and subsequently from the clients that associate with these APs.

External AP - This AP is not connected to your network, but it is detected by a WIPS sensor on your network due to spillage of the AP radio signal.

Each type of AP is represented with a different color.

Select from category **Authorized, Misconfigured, Rogue, External, Uncategorized** to view the list of authorized, misconfigured, rogue, external or uncategorized APs for the selected location. You can choose one or more of these categories at a time. Select **All** to view APs from all categories.


AirTight APs that form a wireless mesh network will always be categorized as Authorized APs only. You cannot change the category of such AirTight APs. If APs from vendors other than AirTight are part of the mesh network, you are allowed to change the category of these APs from authorized to any other category.

The **APs** tab is divided horizontally into two panes. The upper pane shows a list of APs for the selected location. The lower pane shows the AP properties related to the AP you select in the upper pane of the **APs** tab. You can view a list of recently associated clients associated with the selected AP, in case of authorized, rogue, external and uncategorized APs. In case of authorized APs, you can also view AP utilization, AP associated clients, AP traffic, AP average data rate in the lower pane.

Both active and inactive APs are visible in the APs tab. Inactive APs of some categories are visible in specific deployments only.

A toolbar is seen between the two panes as shown in the figure below. You can perform various operations related to the APs using the options present on the toolbar.

To perform any operation facilitated by the toolbar, you need to select an AP row in the upper pane.



1-Change Location 2-Locate AP 3-Change Category
4-Quarantine 5-Additional options 6-Print

Note: The options available to perform various operations depend on the role of the user that has logged in.

Mesh APs are categorized as Authorized, by default. You cannot change the category of the mesh APs if they are Airtight APs. You cannot quarantine, automatically ban these APs. Hence the options under More in the toolbar are disabled for mesh APs.

You can change the category of mesh APs if the APs are provided by a vendor other than AirTight.

The following table provides a description of the fields seen in the upper pane of the **APs** tab.

Field	Description
Active Status	Indicates whether the AP is active or inactive.
RSSI	Observed RSSI (Received Signal Strength Indicator) value for the AP .
Name	User-defined name of the AP.
MAC Address	Unique 48-bit address of the AP/ 802.11 PHY modes used by the AP.
Channel	Channel number on which the AP operates. The channel is shown as Dual for AP that operates on both 802.11a and 802.11b/g simultaneously.
Protocol	802.11 protocol used – 802.11a, 802.11b only, 802.11b/g, or 802.11a/b/g, with or without 802.11n or 802.11ac capability.
Clients	Number of active clients associated with the AP.
SSID	For an AP, it specifies the operating SSID, which is the unique identity that prospective Clients use to recognize the network. When several WLANs operate in the same space, SSID helps Clients in deciding which one to join. However, SSID alone does not provide any meaningful security.

Security	Security standard such as Open, WEP, WPA, 802.11i, or Unknown, applied to the AP. This is derived from the template applied to the AP.
Location	Location of the AP.
Network	Network to which AP is connected.
Up/Down Since	Date and time since which the AP is up or down.
Networked Status	Indicates whether or not the AP is in the network.
Vendor	Name of the AP vendor.
Is Banned	Indicates if the AP is a banned AP.
Quarantine Status	Indicates if the AP is quarantined.
First Detected At	Date and time on which the AP was first detected.
Encryption	Encryption protocol used by the AP.
Troubleshooting	Indicates if troubleshooting is in progress for the AP.
MFP/11w	Indicates if MFP/11w is enabled on the AP.
Authentication	Authentication Protocol used by AP.
Classification	Classification of the AP.
Manually Classified	Indicates if the AP is manually classified.

View AP Properties

Select an AP and view its properties. Some AP properties are editable, others are not. To edit an AP property, double-click it, edit it and save the new value.

The following table provides a field-wise description of the AP properties.

Field	Description
Name	Name of the AP.
Classification	Specifies whether the AP is categorized as Authorized, External, or Rogue. Uncategorized indicates that the AP has not been categorized.
Location	AP location.
Is Placed	Specifies whether the AP has been placed on a layout for a location.
MAC Address	Unique 48-bit address of the AP/ 802.11 PHY modes used by the AP.
Protocol	Wireless protocol version used by the AP to provide wireless connectivity.
Capability	Operation mode capabilities of the device like 802.11n, 802.11ac, Super AG, Turbo etc
SSID	SSID of the WLAN to which the AP is connected.
Is Guest	Specifies whether the AP is a guest AP or not.
Device Tag	Text that provides additional information about the AP; for example, Hawaii Conference Room, Bldg 15 – Cubicle G2.
IP Address	IP address if the AP is authorized. The field is blank if the AP is rogue or external.
Network	Network tag of the network to which the AP is connected. This value is blank if the AP is not connected to a network.
Vendor Name	Name of the AP vendor.
First Detected At	Date and time when the AP was first detected by the system.
Up Since	Date and time since which the AP is up.
Channel	Channel number on which the AP operates.

Basic Link Rates (Mbps)	Comma-separated list of link rates supported by the AP.
Security	Security standard applied to the AP. This is derived from the template applied to the AP.
Authentication	Procedure used by APs to verify the identity of a client.
Pairwise Encryption	Encryption used for unicast communication between the AP and a Client. MULTIPLE is displayed, if 'For All BSSIDs' is selected in the MAC/Protocol field.
Groupwise Encryption	Specifies the encryption used for broadcast or multicast communication from the AP. MULTIPLE is displayed, if For All BSSIDs is selected in the MAC/Protocol field.
Beacon Interval	time interval, in millisecond,s between successive beacons of the AP.
802.11n Capability	This field is visible only if the selected AP is an 802.11n AP. 802.11n capability of the AP. The field provides information about whether the AP is compliant with early or standard implementations of the 802.11n standard.
Channel Width	This field is visible only if the selected AP is an 802.11n AP or a 802.11ac AP. It specifies whether an 802.11n AP is operating on 20 MHz or 40 MHz channel width. 802.11n allows for the use of standard channel width of 20 MHz or double channel width of 40 MHz. 40 MHz channel width is achieved by using two adjacent channels to send data simultaneously. In case of 802.11ac capable AP, the possible values are 20 MHz, 40 MHz, 80 MHz, 160 MHz or 80+80 MHz.
Channel offset	This field is visible only if the selected AP is an 802.11n AP. It specifies whether the adjacent channel used in 40 MHz operation is above or below the primary channel for the selected 802.11n AP.
Data Rate	This field is visible only if the selected AP is an 802.11n AP or an 802.11ac AP. It specifies the highest 802.11n data rate or the highest 802.11ac data rate of the selected active 802.11n AP or 802.11ac AP with which it communicates with the client.
GI for 20 MHz	This field is visible only if the selected AP is an 802.11n AP. It specifies if the AP is capable of using short guard interval for 20 MHz. The possible values are 400 nanoseconds and 800 nanoseconds.
GI for 40 MHz	This field is visible only if the selected AP is an 802.11n AP. It specifies if the AP is capable of using short guard interval for 40 MHz. The possible values are 400 nanoseconds and 800 nanoseconds. This field is applicable only if the channel width is 40 MHz or more.
802.11n MCS supported	This field is visible only if the selected AP is an 802.11n AP. It specifies the various Modulation and Coding Schemes (MCS) supported for 802.11n. The 802.11n standard defines a total of 77 MCS. Each MCS is a combination of a certain modulation (for example, BPSK, QPSK, 64-QAM), coding rate (for example, 1/2, 3/4), guard interval (800 or 400 ns), and number of spatial streams. Support for MCS 0-15 is mandatory for 802.11n APs and support for MCS 0-7 is mandatory for 802.11n Clients.
Greenfield Mode	This field is visible only if the selected AP is an 802.11n AP. It specifies if the AP is capable of working in the Greenfield mode. Greenfield mode is an optional high-throughput mode in the 802.11n standard, which is not backward compatible with legacy (802.11a/b/g) protocols and is expected to provide maximum performance benefits of 802.11n.
802.11n Beam forming Capability	This field is visible only if the selected AP is an 802.11n AP. It specifies if the AP is capable of Beamforming. Beamforming is an RF transmission method that helps in focusing the radiated RF energy directly at a

	receiving Client. This improves signal reception at the client and consequently the throughput.
MFP/802.11w	Indicates if MFP/802.11w is enabled on the selected AP.
Quarantine Status	Quarantine status of the selected AP. Possible values are Not in Quarantine, Quarantine Active, Quarantine Pending, DoS Quarantine on, DoS Quarantine pending, Quarantine disabled.
Defending Sensor Name	Name of defending sensor.
Quarantine Pending Reason	Reason if quarantine is pending. Possible values are Device Inactive, Device(s) outside the prevention range of all <device name> devices., Prevention capacity full at all <device name> within the prevention range, Device operating Channel unknown, Quarantined Client currently not a security threat, Error in selecting <device name> for prevention, No suitable <device name> found for prevention, device channel not in defend list of any <device name>, Wired side identity of the device not available, waiting for <device name> acknowledgement, Unknown.
Tx STBC 802.11n	This field is visible only if the selected AP is an 802.11n AP. It indicates support for transmission of PLCP protocol data units (PPDUs) using space time block code (STBC). 'Yes' indicates that transmission of PPDUs using STBC is supported. 'No' indicates that transmission of PPDUs using STBC is not supported.
Rx STBC 802.11n	This field is visible only if the selected AP is an 802.11n AP. It indicates support for reception of PLCP protocol data units (PPDUs) using space time block code (STBC). If this reception is supported, the number of spatial streams supported is indicated. Upto 3 spatial streams are supported for the 802.11n protocol.
802.11ac capability	This field is visible only if the selected AP is an 802.11ac AP. It indicates whether the selected AP is 802.11ac capable. 'Yes' indicates that the AP is 802.11ac capable.
Supported Channel width	This field is visible only if the selected AP is an 802.11ac AP. It indicates the 160 and 80+80 MHz operation capability of the selected 802.11ac AP. Possible values are 80 MHz, 160 MHz, or 160 MHz and 80+80 MHz.
GI (80MHz)	This field is visible only if the selected AP is an 802.11ac AP. It indicates if the 802.11ac AP is capable of using short guard interval for 80 MHz. The possible values are 400 nanoseconds and 800 nanoseconds. This field is applicable only if the channel width is 80 MHz or more.
GI (160 MHz and 80+80 MHz)	This field is visible only if the selected AP is an 802.11ac AP. It indicates if the 802.11ac AP is capable of using short guard interval for 160 MHz and 80+80 MHz. The possible values are 400 nanoseconds and 800 nanoseconds. This field is applicable only if the channel width is 160 MHz or 80+80 MHz.
Tx STBC 802.11ac	This field is visible only if the selected AP is an 802.11ac AP. It indicates support for the transmission of at least 2x1 STBC. This field is specific to 802.11ac. 'Yes' indicates that the transmission of at least 2x1 STBC is supported. 'No' indicates that the transmission of at least 2x1 STBC is not supported.
Rx STBC 802.11ac	This field is visible only if the selected AP is an 802.11ac AP. It indicates support for the reception of PLCP protocol data units (PPDUs) using space time block code (STBC). If this reception is supported, the number of spatial streams supported is indicated. Upto 4 spatial streams are supported for the 802.11ac protocol.
SU Beamformer	This field is visible only if the selected AP is an 802.11ac AP. It indicates

Capability	support for operation as a single user beamformer. 'Yes' indicates that the operation as a single user beamformer is supported. 'No' indicates that the operation as a single user beamformer is not supported.
SU Beamformee Capability	This field is visible only if the selected AP is an 802.11ac AP. It indicates support for operation as a single user beamformee. 'Yes' indicates that the operation as a single user beamformee is supported. 'No' indicates that the operation as a single user beamformee is not supported.
MU Beamformer Capability	This field is visible only if the selected AP is an 802.11ac AP. It indicates support for operation as a multiuser beamformer. 'Yes' indicates that the operation as a multiuser beamformer is supported. 'No' indicates that the operation as a multiuser beamformer is not supported.
MU Beamformee Capability	This field is visible only if the selected AP is an 802.11ac AP. It indicates support for operation as a multiuser beamformee. 'Yes' indicates that the operation as a multiuser beamformee is supported. 'No' indicates that the operation as a multiuser beamformee is not supported.
802.11ac MCS for each Stream	This field is visible only if the selected AP is an 802.11ac AP. It specifies the maximum 802.11ac Modulation and Coding Schemes (MCS) supported for each supported Tx stream.
Number of Spatial Streams	This field is visible only if the selected AP is an 802.11ac AP. It specifies the number of Tx and Rx spatial streams supported by the AP.
Channel List	This field is visible only if the selected AP is an 802.11ac AP. It specifies the list of channels in the operating band of the 802.11ac AP.
Mesh mode	Indicates whether mesh mode is enabled or disabled for the selected AP.

View Recently Associated Clients

Under **Recently Associated Clients**, you can view a list of clients that are recently associated to the selected AP. The criterion for recent association is either 12 hours or the total number of clients (this is the total number of associations in the system and not per device). The total number of associations maintained by AirTight Management Console depends upon the number of AirTight devices connected to the AirTight server. Client details such as Client Name, RSSI, IP address and Last Detected At are displayed in the widget.

Note: Information related to recently associated clients is available in specific deployments only.

View AP Utilization

Under **AP Utilization** section, you can see a graphical representation of the percentage of AP utilization over the last 12 hours. **AP Utilization** section is seen only for authorized APs. The Airtight device keeps a track of the cumulative time occupancy as a percentage of the total scan time of the channel every 15 minutes.

View AP Associated Clients

Under **AP Associated Clients** section, you can see a graphical representation of the clients associated with the AP, over the last 12 hours. The AirTight device samples the number of client associations with the AP every 15 minutes.

View AP Traffic

Under the AP traffic section, you can see a graphical representation of the AP traffic over the last 12 hours. AP Traffic section is seen only for authorized clients. AirTight device seeing the AP reports data traffic sent and received by the AP every 15 minutes. The channel rotating AirTight device spends only a percentage of the total time on any given channel. Hence this parameter typically underestimates the actual traffic by a factor equal to the total number of channels scanned by the device radio. For example, if the AirTight device scans 30 channels in all, the measured traffic would be 1/30th of the actual traffic. However, if the traffic is bursty in nature, such straightforward scaling cannot be applied.

View AP Average Data Rate

Under **AP Average Data Rate** section, you can see a graphical representation of the average data rate in Mbps of the AP, over the last 12 hours. **AP Average Data Rate** section is seen only for authorized APs. AirTight device seeing the client keep track of the transmission rates of the data frames in the AP's BSS and reports weighted average transmission rate over every 15 minutes.

View Devices Seeing AP

The Devices Seeing APs widget shows the AirTight devices in sensor mode that have detected the AP selected in the upper pane.

To view the AirTight devices seeing the AP, do the following.

1. Go to **Devices>APs** tab.
2. Select the location.
3. Select the AP.
4. In the lower pane, navigate to the page with the **Devices seeing AP** widget to view a list of AirTight devices seeing the selected AP.

View AP Events

To view the current AP events for the AP selected in the upper pane, do the following.

1. Go to **Devices>APs** tab.
2. Select the location.
3. Select the AP.
4. In the lower pane, navigate to the page with the **Events** widget to view a list of active events for the selected AP.

Change AP Location

To change the location of an AP on the floor map, do the following.

1. Go to **Devices>APs** tab.
2. Select the location.
3. Select the AP whose location you want to change.

4. Click the Change location icon. The Select New Location dialog box appears.
5. Select the new location for the AP.
6. Click OK.

Locate AP

To locate an AP on the floor map, do the following.

1. Go to **Devices>APs** tab.
2. Select the location at which the AP is placed.
3. Select the AP.
4. Click the Locate icon to locate the AP on the location floor map.

Quarantine an AP

To quarantine an AP, do the following.

1. Go to **Devices>APs** tab.
2. Select the location at which the AP to quarantine exists.
3. Select the AP to quarantine.
4. Click the Move to Quarantine icon, and click Yes on the confirmation message to quarantine the AP.

Change AP Category

To change the AP category, do the following.

1. Go to **Devices>APs** tab.
2. Select the location where you want to change the AP category.
3. Select the check box for the AP whose category you want to change.
4. Click the Change category icon present on the toolbar.
5. Select the desired category from **Authorized, External, Rogue**, as the case may be.

Disable Auto Quarantine

1. Go to **Devices>APs** tab.
2. Select the location at which the AP is placed.
3. Select the AP and click **More** on the toolbar.
4. Click the Disable auto quarantine option, to disable auto quarantining of APs.


Add to banned list

To add an AP to the banned list, do the following.

1. Go to **Devices>APs** tab.
2. Select the location at which the AP is placed.
3. Select the AP and click **More** on the toolbar.
4. Click the Add to banned list option to add the AP to the banned list.

Sort APs

You can sort AP details on the columns in the upper pane of the **APs** tab. You can sort the APs in the ascending or descending order.

1. Go to **Devices>APs** tab.
2. **Select** the location.
3. Point to the column in the upper pane on which you want to sort and click .
4. You can click the arrow again to reverse the sort order. The icon could be an up arrow or a down arrow based on the current sort order.


Filter AP Details

You can choose the columns to be viewed or filter the AP information to be displayed on the UI based on filter text matching the text in the selected column.

For example, if you want to view only the APs with WPA security, do the following.

1. Go to **Devices>APs** tab.
2. **Select** the location.
3. Point to **Security** in the upper pane, click  and enter 'WPA' as the filter text.
4. Press the **Enter** key to view the APs with WPA security.

To choose the columns to be viewed, do the following.

1. Go to **Devices>APs** tab.
2. **Select** the location.
3. Point to any column name in the upper pane, click . A menu appears.
4. Point to **Columns** option in the menu and select the check boxes for the columns to be made visible on the UI. Deselect the check boxes, if they are already selected, for the columns that you don't want to view on the UI.

Search APs

You can search for an AP using the name of the AP, MAC address of the AP or SSID of the AP.


To search for an AP or APs, do the following.

1. Go to **Devices>APs** tab.
2. **Select** the location where you want to search APs.
3. Enter the name, MAC address or SSID of the AP in **Quick Search** box at the top right corner.
4. Press the Enter key. The AP or APs that match the search criteria is displayed in the upper pane.

Enable Pagination for AP Listing and Set Page Size


By default, the AP listing in the upper pane is presented in a grid. You can scroll down to the last AP row in the upper pane without having to browse across pages. A paginated view is also available if you want to view a page-wise list of APs. You can enable pagination for the APs that are visible to you and configure the number of rows on each page in the upper pane.



To enable pagination, do the following.

1. Go to **Devices>APs** tab.
2. Click the  icon seen on the right side of the tool bar. A message to confirm pagination for all grids/listings on the UI appears.

3. Click **OK**. The pagination for AP listing is enabled. The pagination for all other grids such as AirTight devices, clients, networks, events and AirTight Mobile clients is enabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

To set the page size, do the following.


1. Go to **Devices>APs** tab.
2. On the tool bar, click the down arrow next to the number of rows displayed to the left of the  icon. The options **First Page** and **Set page size** appear.
3. Click **Set Page Size** and enter the number of rows to be visible on each page.
4. Click **OK**.

You can browse through the paginated AP listing by clicking the  (next page) and  (previous page) icons. To go to the first page, click the down arrow next to the number of rows on the page and select the **First page** option.

Disable Pagination for AP Listing

If you have enabled pagination and want to disable it, you can restore the default view of having a complete listing of all APs on a single page.

To disable pagination, do the following.

1. Go to **Devices>APs** tab.
2. Click the  icon seen on the right side of the tool bar. A message to confirm disabling of pagination for all grids/listings on the UI appears.
3. Click **OK**. The pagination for AP listing is disabled. The pagination for all other grids such as AirTight devices, clients, networks, events and AirTight Mobile clients is disabled as well. Note that this setting is restricted to your login only and is not applicable to other users.



Add Custom Filter

You can create custom filters and save them with the name of your choice. You can select the columns to be viewed and can, optionally, set a filter on the data in the columns seen on AirTight Management Console. You can save this filter with a name and can create multiple filters in this manner.

Note the following points when working with custom filters.




- Preferences for visibility of columns and sorting of column data are not saved in a custom filter. Only the filter criteria is saved.
- Custom filters are user-specific. They are saved for the user who has defined the custom filter and is not visible to any other user.
- An unsaved filter is indicated by an asterisk next to the filter name seen next to **Filter** on the tool bar.
- An unsaved filter is not saved if the user logs out without saving the filter.

To create a custom filter, do the following.

1. Go to **Devices>APs**.
2. Click the  icon next to a column header. A list of options is displayed.
3. Point the mouse at the **Filters** option and enter the filter text for the column.
4. Click the  icon next to **Filter** on the tool bar and click **Save as**. The **Save as** dialog box appears.
5. Enter the name of the filter and click **OK**. The custom filter is saved.



Edit Custom Filter

To edit a custom filter, do the following.

1. Go to **Devices>APs**.
2. Click the  icon next to **Filter** on the tool bar and select the required filter.
3. Click the  icon next to a column header. A list of options is displayed.
4. Point the mouse at the **Filters** option and enter the filter text for the column or make changes to the filter criteria as required.
5. Click the  icon next to **Filter** on the tool bar and click **Save**. The modified custom filter is saved.

Delete Custom Filter

To delete a custom filter, do the following.

1. Go to **Devices>APs**.
2. Click the  icon next to **Filter** on the tool bar and click the  icon for the filter to delete. A message asking you to confirm delete appears.
3. Click **Yes** to confirm deletion of the custom filter.

Print AP List for Location

You can print all the information seen for all APs in the upper pane. You can choose the columns to be viewed on the UI by selecting them. The information seen in the upper pane is the information that will be seen in the printout.

If pagination is enabled, the list of APs on the current page are printed. To print a list of all APs for a location, you must go to each page and print the individual pages.

If pagination is disabled, only the list of APs visible on the UI is printed. This means that if there are 25 records of which only the first five have been presented on the UI, these five records are printed.

You must enable or disable pagination before you print.

To print the AP list for a location, do the following.

1. Go to **Devices>APs** tab.
2. Select the location for which you want to print the APs' list.
3. Select the type of APs for which you want to print the list.
4. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
5. Click the print icon. The print preview of the AP list appears.
6. Click **Print** to print the list.

Merge APs

The APs seen in the APs tab could be either a virtual AP or a physical AP. One or more virtual APs could actually be a single physical entity. You can merge such virtual APs into a single AP through the APs tab for better management. You can merge authorized APs only.

To merge authorized APs, do the following.

1. Go to **Devices>APs** tab.
2. Select the location for which you want to merge the APs.
3. Select two or more authorized APs to merge and click **More** on the toolbar.
4. Click the Merge option to merge the APs.

Split AP

One or more virtual APs that have been merged to form a single AP can be split back to the original number of APs. The split option is available only if you select merged APs. As merging is available for authorized APs only, the split AP option is also available for authorized APs only.

To split an authorized AP, do the following.

1. Go to **Devices>APs** tab.
2. Select the location for which you want to split a merged AP.
3. Select the merged AP to split and click **More** on the toolbar.
4. Click the Split option to split the APs.

Troubleshoot AP

You can troubleshoot APs using an AirTight device operating in sensor mode.

When you initiate troubleshooting, you must ensure that the AirTight device is reachable from the computer used to launch the AirTight Management Console. If the AirTight device is busy in quarantine or busy in troubleshooting, it will be not be able to troubleshoot the selected AP.

You can have an AirTight device (sensor) troubleshoot the AP in packet level mode or event level mode. This sensor can troubleshoot in packet level mode using packet capture tools like Wireshark or any other tool available to you.

You have two packet capture tool options – Wireshark and 'Other'. Wireshark is available for free on the Internet.

Alternatively, you can save the packet capture history to the AirTight server and download the history file to save it for future reference. The packet capture history is saved as a .pcap file. This can also be viewed using Wireshark or any other packet capture tool.

You cannot troubleshoot a merged AP with multiple BSSIDs. Troubleshooting of a single BSSID of a merged AP can be done.

When a troubleshooting session is in progress, a notification regarding the active troubleshooting session can be seen under Notifications (top right corner of the AirTight Management Console).

A troubleshooting session automatically times out or terminates after the specified timeout irrespective of the activity.

IMPORTANT: Once the packet capture based troubleshooting session begins from the Console and the packet capture tool is either interrupted or terminated (gracefully or abruptly), you have to first stop the ongoing troubleshooting session from the Console either manually (if it is still going on) or ensure that the session has indeed ended before you can start another packet capture session. Refer to the 'Stop Troubleshooting' sub-section in this section to manually terminate a troubleshooting session.

You can then restart the fresh troubleshooting session from the Console.

If a troubleshooting session is in progress with a chosen tool (Wireshark or user specified tool), another capture from the command prompt, using user specified capture parameters (viz. `rpcap://sensor-ip/iface`) will not succeed from the same or another computer.

If you are an AirTight Cloud Services user, you can upload the packet capture file directly into WizShark. You can then use WizShark to analyze the packet capture or trace files. Following are the prerequisites to successfully upload the file to WizShark.

- You must have subscribed to the WizShark service.
- You must have upload privileges in WizShark.

- The file size must not exceed the maximum file size prescribed by WizShark.
- When the file is uploaded, the total storage quota for your account must not be exceeded.

Troubleshoot AP in Packet Level Mode with Wireshark on local machine

To troubleshoot an AP in packet level mode, do the following.

1. Click **Devices**.
2. Select the **APs** tab.
3. Select the check box for the AP to troubleshoot.
4. Click the **More>Packet Capture** option on the tool bar. The Troubleshoot AP dialog box appears.
5. Select the check box for the sensor from the list of AirTight devices operating as sensors, using which you want to troubleshoot the AP. The sensors seeing the device are sorted based on their availability and signal strength.
6. Select the **Live Packet Capture** option under **Troubleshooting Mode**.
7. Select **Streaming option as Wireshark** on local machine.
8. Specify the time-out interval in **Timeout**. The default time-out for packet level troubleshooting mode is 5 mins. Minimum allowed value is 1 minute and maximum is 720 minutes for the time-out.
9. Select the type of packets you want to see while troubleshooting under **Traffic Selection**. If you want to capture all packets visible to the troubleshooting AirTight device, select the **All packets on the channel** option. If you want to view only packets from the AP visible to the troubleshooting sensor, select the **Only packets for the selected BSSID <BSSID value>** option.
10. In the **Protocol and Channel Selection** section, select the protocols and channel for which you want to troubleshoot. If you want to select a single channel, select the **Select Channel** option and specify the channel number and **Width** (channel offset). By default, the protocol and channels are displayed based on the device template applied to the troubleshooting sensor. You can select a different protocol and/or channel, if required. Alternatively, you can select the **Rotate on all Channels** option, to troubleshoot on all available channels.
11. Click **Start Troubleshooting** to start the troubleshooting. The sensor is enabled to capture live packets.
12. Select an appropriate tool for live packet capture. If you don't have the tools already installed, you can download Wireshark or any other tool.
13. To view the packet capture, open the command line interface of the operating system installed on your computer and execute the command shown under Wireshark or any other packet capture tool. The **Troubleshooting in Packet Level Mode** dialog box gives a guideline to the command to execute for Wireshark..

Troubleshoot AP in Packet Level Mode to upload Packet History to AirTight server

To troubleshoot an AP in packet level mode, do the following.

1. Click **Devices**.
2. Select the **APs** tab.
3. Select the check box for the AP to troubleshoot.
4. Click the **More>Packet Capture** option on the tool bar. The Troubleshoot AP dialog box appears.
5. Select the check box for the sensor from the list of AirTight devices operating as sensors, using which you want to troubleshoot the AP. The sensors seeing the device are sorted based on their availability and signal strength.
6. Select the **Live Packet Capture** option under **Troubleshooting Mode**.
7. Select **Streaming option as Upload to Server**.
8. Enter a suitable prefix for the file name in **Filename Prefix**. This helps you identify the troubleshooting files when you download the packet history.

9. Specify the time-out interval in **Timeout**. The default time-out for packet level troubleshooting mode is 5 minutes. Minimum allowed value is 1 minute and maximum is 720 minutes for the time-out.
10. Select the packets you want to capture while troubleshooting, under **Traffic Selection**. If you want to capture packets for all BSSIDs on the AirTight AP visible to the troubleshooting AirTight device, select the **Packets of all BSSID on this AirTight AP** option. If you want to capture only the packets from the AP visible to the troubleshooting sensor, select the **Only packets for the selected BSSID <AP MAC address>** option.
11. Select the packet type. If you want to capture all packets, select the **All** option. If you want to capture only specific packet types, select the filter option and then select the required data frames and/or management frames to capture while troubleshooting.
12. In the **Protocol and Channel Selection** section, select the protocols and channel for which you want to troubleshoot. If you want to select a single channel, select the **Select Channel** option and specify the channel number and **Width** (channel offset). By default, the protocol and channels are displayed based on the device template applied to the troubleshooting sensor. You can select a different protocol and/or channel, if required. Alternatively, you can select the **Rotate on all Channels** option, to troubleshoot on all available channels.
13. Click **Start Troubleshooting** to start the troubleshooting. The sensor is enabled to capture live packets.

Troubleshoot AP in Event Level Mode

To troubleshoot an AP in event level mode, do the following.

1. Click **Devices**.
2. Select the **APs** tab.
3. Select the check box for the AP to troubleshoot.
4. Click the **More>Packet Capture** option on the toolbar. The Troubleshoot AP dialog box appears.
5. Select the check box for the sensor from the list of AirTight devices operating as sensors, using which you want to troubleshoot the AP. The sensors seeing the device are sorted based on their availability and signal strength.
6. Select the **Generates Additional Events for the device** option under **Troubleshooting Mode**.
7. Specify the timeout interval in **Timeout**. The default timeout for event level troubleshooting mode is 2 mins. Minimum allowed value is 1 minute and maximum is 5 minutes for the timeout.
8. Select the packets you want to capture while troubleshooting, under **Traffic Selection**. If you want to capture packets for all BSSIDs on the AirTight AP visible to the troubleshooting AirTight device, select the **Packets of all BSSID on this AirTight AP** option. If you want to capture only the packets from the AP visible to the troubleshooting sensor, select the **Only packets for the selected BSSID <AP MAC address>** option.
9. In the **Protocol and Channel Selection** section, select the protocols and channel for which you want to troubleshoot. If you want to select a single channel, select the **Select Channel** option and specify the channel number and **Width** (channel offset). By default, the protocol and channels are displayed based on the device template applied to the troubleshooting sensor. You can select a different protocol and/or channel, if required. Alternatively, you can select the **Rotate on all Channels** option, to troubleshoot on all available channels.
10. Click **Start Troubleshooting** to start the troubleshooting. The sensor generates events while troubleshooting and these can be viewed under device listing as the latest events for the sensor.

Stop Troubleshooting

A troubleshooting session automatically times out or terminates after the specified timeout irrespective of the activity. You can manually terminate a troubleshooting session.

To stop an active troubleshooting session manually, do the following.

1. Click the Notifications icon at the top right corner. The active troubleshooting sessions are displayed along with other notifications, if any.
2. Click the notification for active troubleshooting sessions. A list of sensor troubleshooting sessions is displayed.
3. Select the check box for the troubleshooting session to terminate.
4. Click **Stop**. The troubleshooting session is terminated and a message indicating the termination of the troubleshooting session is displayed. If the **Upload to Server** option has been selected as **Streaming option** under **Troubleshooting Mode**, the packet capture history is uploaded to the AirTight server.

Download Packet Capture

AirTight server maintains a packet capture history for the troubleshooting instances for a period of 30 minutes, after you stop troubleshooting.

You can download this history and save them for future reference. The packet captures are available in .pcap format.

To download a packet capture file, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **APs** tab.
4. Click the **More>Previous Packet Captures** option on the tool bar. The **Packet Capture** dialog box appears. The list of files is displayed with the file name, file size in KB, troubleshooting start time and troubleshooting stop time.
5. Click the **Download** link for the packet capture file to download and select the path to store it. The packet capture file is saved to the specified location.


If you are an AirTight Cloud Services user, and wish to upload the packet capture file to WizShark from AirTight Management Console, click the **View in WizShark** link. The file is directly uploaded to WizShark and WizShark opens up in a separate browser tab or browser window. You can then analyze the packet capture file using WizShark.

Delete Packet Capture

AirTight server maintains a packet capture history for the troubleshooting instances for a period of 30 minutes, after you stop troubleshooting.

You can delete this packet capture history from the server. The packet capture files are available in .pcap format.

To delete a packet capture file, do the following.

1. Select the required location from the location tree.
2. Click **Devices**.
3. Select the **APs** tab.
4. Click the **More>Previous Packet Captures** option on the tool bar. The **Previous Packet Capture** dialog box appears. The list of files is displayed with the file name, file size in KB, troubleshooting start time and troubleshooting stop time.
5. Select the check box for the log file to delete. You can select multiple files to delete at a time.
6. Click the  icon. A message to confirm the deletion appears
7. Click **Yes** to confirm deletion of selected files.

Delete AP

You can delete one or more APs at the same location at a time. Active APs could be rediscovered by the AirTight devices configured as sensors, and could reappear in the APs tab under the relevant category based on the AP classification policy.

Inactive APs will be deleted and might not be visible until they are active.

To delete an AP, do the following.

1. Go to **Devices>APs** tab.
2. Select the location for which you want to delete the AP.
3. Select one or more APs to delete and click **More** on the toolbar.
4. Click the Delete option to initiate the delete operation for the AP. A message asking to confirm deletion of AP appears.
5. Click **Yes** to confirm the deletion.

Monitor Networks

The Networks tab displays the list of networks, and the APs and sensors associated with these networks.

The **Networks** tab is divided horizontally into two panes.

A toolbar is seen between the upper and lower panes. This toolbar has icons to perform various operations on the network selected in the upper pane.

The upper pane shows a list of networks detected at the selected location. The lower pane shows the network properties related to the APs and sensors in the network selected in the upper pane of the **Networks** tab.

The **Network Properties: APs** section is seen on page 1 of the lower pane in the **Networks** tab.

All APs associated with the network, and with the location including the sub locations under that location, are seen in **Network Properties: APs** section.

The fields in the APs tab are the same as seen in **Devices->APs** tab. You can filter the APs seen based on the AP categories, Authorized, Rogue, External, and Uncategorized. To see all types of APs, you can select the All check box.

You can see a toolbar below the list of APs. Using this toolbar, you can perform all the operations related to these APs similar to the operations you can perform in Devices>APs tab. To perform any operation on the APs in the selected network, select the AP on which you want to perform the operation and click the respective icon.

The **Network Properties: Sensors** section is seen on page 2 in the lower pane of the **Networks** tab.

The fields in the Sensors tab are the same as seen in **Devices>AirTight devices** tab.

Only currently active sensors in the network are seen in this section.

The following table provides description of the fields are seen on the **Networks** tab.

Field	Description
Name	Network name
Network Address	IP address of the network.
Location	Network Location
Monitoring sensor	Sensor monitoring the network
Gateway MAC	Gateway MAC address

Exposed Since	Date and time since which the network is exposed.
----------------------	---

Change location of network

Location of a network is same as location of the Sensor that reported the network first. If there are multiple sensors connected to a network, location of such network is the nearest common location of all reporting sensors.

To change the location of a network, do the following.

1. Go to **Devices**
2. Select the **Networks** tab.
3. Select the location at which the network has been detected.
4. Select the check box for the network whose location you want to change.
5. Click the Change location icon.
6. Select the new location on the Select New Location dialog that appears.
7. Click OK to move the network to the new location.

On selecting a new location, the network is seen under the new location.

Rename network


To rename a network, do the following.

1. Go to **Devices**
2. Select the **Networks** tab.
3. Select the check box for the network whose location you want to change.
4. Click the Rename Network icon.
5. Enter a new name in the Rename dialog that appears.
6. Click OK to rename the selected network. On selecting a new location, the network is seen under the new location.


Enable Pagination for Network Listing and Set Page Size



By default, the network listing in the upper pane is presented in a grid. You can scroll down to the last network row in the upper pane without having to browse across pages. A paginated view is also available if you want to view a page-wise list of networks. You can enable pagination for the networks that are visible to you and configure the number of rows on each page in the upper pane.

To enable pagination, do the following.

1. Go to **Devices>Networks** tab.
2. Click the  icon seen on the right side of the tool bar. A message to confirm pagination for all grids/listings on the UI appears.
3. Click OK. The pagination for network listing is enabled. The pagination for all other grids such as AirTight devices, APs, clients, events and AirTight Mobile clients is enabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

To set the page size, do the following.


1. Go to **Devices>Networks** tab.
2. On the tool bar, click the down arrow next to the number of rows displayed to the left of the  icon. The options **First Page** and **Set page size** appear.
3. Click **Set Page Size** and enter the number of rows to be visible on each page.
4. Click OK.

You can browse through the paginated network listing by clicking the  (next page) and  (previous page) icons. To go to the first page, click the down arrow next to the number of rows on the page and select the **First page** option.

Disable Pagination for Network Listing

If you have enabled pagination and want to disable it, you can restore the default view of having a complete listing of all networks on a single page.




To disable pagination, do the following.

1. Go to **Devices>Networks** tab.
2. Click the  icon seen on the right side of the tool bar. A message to confirm disabling of pagination for all grids/listings on the UI appears.
3. Click OK. The pagination for network listing is disabled. The pagination for all other grids such as AirTight devices, APs, clients, events and AirTight Mobile clients is disabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

Add Custom Filter



You can create custom filters and save them with the name of your choice. You can select the columns to be viewed and can, optionally, set a filter on the data in the columns seen on AirTight Management Console. You can save this filter with a name and can create multiple filters in this manner.

To create a custom filter, do the following.

1. Go to **Devices>Networks**.
2. Select the location for which you want to create the custom filter.
3. Click the  icon next to a column name. A list of options is displayed.
4. Point the mouse at the **Columns** option and select the check boxes for the columns to view.
5. Click the column name and select **Sort Ascending** option or **Sort Descending** option if you want to sort the column data.
6. If you want to filter the data seen in the columns, click the  icon next to a column name, select the check box for the **Filters** option. Now enter the filter text for the column.
7. Click the  icon next to **Filter** on the tool bar and click **Save as**. The Save as dialog box appears.
8. Enter the name of the filter and click **OK**. The custom filter is saved.



Edit Custom Filter

To edit a custom filter, do the following.

1. Go to **Devices>Networks**.
2. Select the location for which you want to edit the custom filter.
3. Click the  icon next to **Filter** and select the required filter.
4. Make changes to the filter as required.
5. Click the  icon next to **Filter** and click **Save**. The modified custom filter is saved.

Delete Custom Filter

To delete a custom filter, do the following.

1. Go to **Devices>Networks**.
2. Select the location for which you want to delete the custom filter.
3. Click the  icon next to **Filter** and click the  icon for the filter to delete. A message asking you to confirm delete appears.

4. Click **Yes** to confirm deletion of the custom filter.

Print Network List for Location

You can print all the information seen for all networks in the upper pane for the selected location. You can choose the columns to be viewed on the UI by selecting them. The information seen in the upper pane is the information that will be seen in the printout.

If pagination is enabled, the list of networks on the current page is printed. To print a list of all networks for a location, you must go to each page and print the individual pages.

If pagination is disabled, only the list of networks visible on the UI is printed. This means that if there are 25 records of which only the first five have been presented on the UI, these five records are printed.

You must enable or disable pagination before you print.

To print the AirTight devices list for a location, do the following.

1. Click **Devices** and then click the **Networks** tab.
2. Select the location for which you want to print the networks list.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the print icon. The print preview of the networks list appears.
5. Click **Print** to print the networks list.


Change Network Type

When you upgrade to release 7.1 Update 3 of the AirTight Management Console, all the networks are marked as Cardholder Data Environment (CDE) networks, by default. If a network displayed in the Networks tab does not possess or transmit credit card data, you can change the network type to non-CDE.

Similarly, you can change a non-CDE network to a CDE network.

You can select multiple networks of the same type at a time and mark them as non-CDE or CDE, as required.

To change the network type of a network, do the following.

1. Go to **Devices**
2. Select the **Networks** tab.
3. Select the check box for the network you want to mark as CDE or non-CDE.
4. Click the down arrow next to the  icon on the toolbar. Select CDE or non-CDE as the case may be. A confirmation message appears.
5. Click **Yes** on the confirmation message to change the network type.

The network type is changed and the new network type appears under the Network type column.

Delete Network

To delete a network from the Networks tab, do the following.

1. Go to **Devices**
2. Select the **Networks** tab.
3. Select the check box for the network you want to delete.
4. Click the Delete Network icon.
5. Click **Yes** on the Confirm dialog that appears on clicking the Delete Network icon.

Manage Locations and Location Layout

In AirTight Management Console, you can have a graphical representation of the placement of locations and devices with respect to one another for the given location. This is called a location layout. Layout for a location floor represents a floor plan. Similarly, the layout for a location folder could represent the geographical placement of the sub-locations.

By looking at a location layout, you will also be able to figure out the placement of each device on the floor plan, and the placement of related locations with respect to one another. You can pan across the location layout to have a better view of the entire location layout.

Navigate to **Locations** page to manage layouts for the selected location. You can have a layout defined for each location folder and location floor. You can then place the sub-locations, that is, the location folders on the layouts for the location folders. Similarly, you can place devices on the layouts for the location floors.

Define Location Tree

Click **Locations** to view the Locations page.

The location tree is seen on the left of the page. The layout is configured on the right side of the page.


The location tree comprises location folders and location floors.

Location folders represent organizational components such as buildings, cities, or countries.

Location floors represent component details such as a floor in a building. For example, Hawaii Conference Room, Bldg 15–Cubicle G2, or Executive Area.

The default location folder of the root location is the **Unknown** folder. You can rename the **Unknown** folder. You cannot create, delete, move, or add a location to the **Unknown** folder. When the location tag of a location-aware device is not known or cannot be determined, it is tagged to the **Unknown** folder. By default, the **Unknown** folder inherits all the policies except the Device Classification and Prevention Policies from the root location. You can customize these policies.

The following figure shows the location tree. Click the various buttons as indicated in the 'Manage Locations' figure below, to add, rename, move and delete locations.



You can select a location folder or a location floor and add a layout to it. A layout for a location folder could be a geographical map, while a layout for a location floor could be a floor map. You can add location folders and location floors to the layout for a location folder. You can add devices, configured to work with AirTight Management Console, to the layout for location floors. You can add notes to the locations and devices on layouts to further explain the location or device placement or any other matter related to the location layout.

You can also view a pictorial representation of the mesh wireless network topology in the locations layout. You must be logged in as an administrator to make add or make changes to the location layout for a location folder or location node.

If you are logged in to the parent server of a server cluster as a superuser, you can change the layout of any of the locations or servers in the server cluster.

Add Location

You can represent buildings, geographical locations using location folders. You can represent floors or levels in a building using a location floor. You can add one or more location folders under the root location or under other location folders. You can add one or more location floors under a location folder. You cannot add a location folder or a location floor to the **Unknown** folder. You cannot add a location floor under a location floor.

To add a location folder, do the following.

1. Go to **Locations**. In the location tree, you will see the root location labelled **Locations** with the sub-folder **Unknown**.
2. Select the location under which you want to add the location folder.
3. Click the add icon (plus sign) seen below the location tree. The **Add New Location** dialog box appears.
4. Select **Location Type** as **Folder**
5. Enter the name of the location in **Location Name**.
6. Select the appropriate time zone for the location from **Time Zone**. Selecting the correct time zone is essential for accurate analytics generation.
7. Click **OK**. The location folder is added under the selected location.

To add a location floor, do the following.

1. Go to **Locations**. In the location tree, you will see the root location labelled **Locations** with the sub-folder **Unknown**.
2. Select the location under which you want to add the location floor.
3. Click the add icon (plus sign) seen below the location tree. The **Add New Location** dialog box appears.
4. Select **Location Type** as **Floor**.
5. Enter the name of the location in **Location Name**.
6. Click **OK**. The location floor is added under the selected location folder.

Edit Location

To edit a location folder or location floor, do the following.

1. Go to **Locations**.
2. Select the location folder or location floor to edit.
3. Click the edit icon (letter 'A') seen below the location tree. The **Edit Location** dialog box appears.

4. Make the required changes.
5. Click **OK**.

Move Location

To move a location folder or location floor from one location to another, do the following.

1. Go to **Locations**.
2. Select the location folder or location floor to move.
3. Click the move icon (cross arrows) seen below the location tree. The **Select Destination Location** dialog box appears.
4. Select the destination location.
5. Click **OK**. The location folder or location floor is moved to the new destination.

Delete Location

To delete a location folder or a location floor from the location tree, do the following.

1. Go to **Locations**.
2. Select the location folder or location floor to delete.
3. Click the delete icon (delete symbol) seen below the location tree. A message to confirm deletion appears.
4. Click **Yes** to confirm deletion.

Search Locations

To search for a location, do the following.

1. Go to **Locations**.
2. Enter the text substring matching the name of the location folder or location floor in **Search Locations**, seen above the location tree.
3. Press the Enter key to view all the location folders and location floors containing this search criterion. The matching locations are seen with their location hierarchy in the location tree when searched using the text string or substring.

To clear the location search, click the x seen next to **Search Locations**.

Add Layout

When there are no layouts defined for the selected location, you will see a **Configure Location Layout** hyperlink on the **Locations** tab with a notification that no layouts are present for the location. Once the layout image is added, you can add locations, notes to the layout image for a location folder. Similarly, you can add devices and notes to the layout image for a location floor.

You can show the location list and hide the location list by clicking the **Show Location List** and **Hide Location List** links respectively.

You can select a location from the location list and drag it to place on the desired position on the layout. Similarly, you can select the location on the layout and drag it back on the location list to remove the location from the layout.

IMPORTANT: Ensure that you have defined the location tree before you add location layouts. Without this, you will not have any locations to place on the layout for location folders.

To add a layout to a location folder, do the following.

1. Go to **Locations**.
2. From the location tree, select the location folder for which you want to add a layout. When no layout is attached to a location, a message indicating this is seen, along with the **Configure Location Layout** link.
3. Click **Configure Location Layout** link.
4. Click the **Add Layout** link.
5. Click **Choose File**. The file open dialog box is displayed.
6. Browse to the desired layout image path to be added and click **Open**. The image is attached to the location. You will be able to see the list of locations.
7. Drag and drop locations from the location list to the desired position on the layout. If the location list is not visible, click **Show Location List** to view a list of available locations.
8. Click **Save** to save the layout.

For individual floors in a location, you can add either a layout image with its dimensions to a location floor or a .spm file that has been exported from AirTight Mobile. In case you specify a layout image, you must also specify the dimensions of the image, that is the width, length and unit of measurement.

To add a layout using a layout image to a location floor, do the following.

1. Go to **Locations**.
2. From the location tree, select the location floor for which you want to add a layout. When no layout is attached to a location, a message indicating this is seen, along with the **Add Layout** link.
3. Click the **Add Layout** link. The **Add Layout** dialog box appears.
4. Click **Choose File** seen next to **Layout Image**. The file open dialog box is displayed.
5. Browse to the desired layout image path to be added and click **Open**. The image is attached to the location.
6. Select the unit of measurement of the dimensions in **Unit**.
7. Specify the width of the layout image in **Width**.
8. Specify the length of the layout image in **Length**.
9. Drag and drop devices from the device list to the desired position to place them on the layout. If the device list is not visible, click **Show Device List** to view a list of available devices.
10. Click **Save** to save the layout.

To add a layout using a .spm file to a location floor, do the following.

1. Go to **Locations**.
2. From the location tree, select the location floor for which you want to add a layout. When no layout is attached to a location, a message indicating this is seen, along with the **Add Layout** link.
3. Click the **Add Layout** link. The **Add Layout** dialog box appears.
4. Click **Choose File** seen next to **Layout SPM**. The file open dialog box is displayed.
5. Browse to the desired layout image path to be added and click **Open**. The image is attached to the location.
6. Drag and drop devices from the device list to the desired position to place them on the layout. If the device list is not visible, click **Show Device List** to view a list of available devices.
7. Click **Save** to save the layout.

Edit Layout

You can replace the layout image for a location folder or a location floor. You must then place the locations or devices again on the new layout image. You can also rearrange the locations or devices on a location layout without changing the layout image or .spm file attached to the location folder or location floor.

To edit a layout, do the following.

1. Go to **Locations**.
2. From the location tree, select the location folder or floor for which you want to edit the layout.
3. Click the **Edit Layout** link.
4. Make the necessary changes.
5. Click **Save** to save the changes to the layout.

Delete Layout

You can delete a location layout attached to a location folder or a location node. When you delete a layout, all the device placement is undone.

To delete a location layout attached to a location folder or a location floor, do the following.

1. Go to **Locations**.
2. From the location tree, select the location folder or floor for which you want to delete the layout.
3. Click the **Delete Layout** link. You will be asked to confirm the deletion of the layout.
4. Click **Yes** to confirm deletion of layout. The layout is deleted and no devices are seen.

Show / Hide Location List

The label of the hyperlink toggles between **Hide Location List** and **Show Location List**, depending on whether the location list is visible on the layout or not visible on the layout.

To show/hide location list, do the following.

1. Go to **Locations**.
2. From the location tree, select the location folder or location floor.
3. Click the **Show Location List** hyperlink that appears above the layout, to show the location list on the layout. If the location list is already visible and you want to hide it, click the **Hide Location List** hyperlink.

Show/Hide Devices on Location Layout

To view the list of devices for a location, do the following.

1. Go to **Locations**.
2. From the location tree, select the location folder or location floor. The label of the hyperlink toggles between **Hide Device List** and **Show Device List**, depending on whether the device list is visible on the layout or not visible on the layout.
3. To show the device list, click **Show Device List** link. To hide the device list, click the **Hide Device List** link.

Place Devices/Locations on Location Layout

Locations can be placed on the layout for a location folder. Devices can be placed on the layout for a location floor.

You must add a layout to a location folder to be able to place locations on to the layout for the location folder. Similarly, you must add a layout to a location floor to be able to place devices on to the layout for the location floor.

You cannot place a server on location layouts in case you are logged in to and working on a parent server in a server cluster.

To place a location on the layout for a location folder, do the following.

1. Go to **Locations**.
2. From the location tree, select the location folder.
3. Select a location from the locations list, and drag and drop the location to the desired position on the location layout.
4. Click **Save** to save the placement of locations on the location layout.

To place a device on the layout for a location floor, do the following.

1. Go to **Locations**.
2. From the location tree, select the location floor. The location layout for the location floor is seen with the locations placed on it.
3. Select the device from the device list, and drag and drop it to the desired place on the location layout.
4. Click **Save** to save the placement of devices on the location layout.

Remove Devices/Locations from Location Layout

You can remove one or more locations placed on a layout for a location folder. Similarly, you can remove one or more devices placed on a layout for a location floor.

To remove a location from the layout for a location folder, do the following.

1. Go to **Locations**.
2. From the location tree, select the location folder. The location layout is seen with the locations placed on it.
3. Hover the mouse on the location to be deleted from the location layout. A bin icon appears to the right of the device.
4. Click the bin icon to remove the device from the location layout.
5. Click **Save** to save the changes.

To remove a device from the layout for a location floor, do the following.

1. Go to **Locations**.
2. From the location tree, select the location floor. The location layout is seen with the devices placed on it.
3. Hover the mouse on the device to be deleted from the location layout. A bin icon appears to the right of the device.
4. Click the bin icon to remove the device from the location layout.
5. Click **Save** to save the changes.

View RF Coverage / Heat Maps

You can view the heat map or RF coverage for a location floor by selecting AP Coverage or Sensor Coverage option available under Heat Map View.

- AP Coverage View
- Sensor Coverage View
- AP Link Speed
- AP Channel Coverage

The AP Coverage View enables you to view an 802.11 RF coverage map based on the dbm at each point on the layout. This information is useful to find out available signal strength at each point.

The Sensor Coverage View enables you to view the detection and prevention zones of visibility for selected Sensors. Detection Range is the area over which Sensors can reliably detect wireless activity of devices operating at a power level greater than the value set in the Transmit Power slider. The Intrusion Detection Display Threshold determines the threshold for this range. Prevention Range is the area over which Sensors can prevent unauthorized wireless activity. The Intrusion Prevention Display Threshold determines the threshold for this range.

The AP Channel View enables you to view all the 802.11 channels available for connection at each point on the floor. It helps in preventing potential channel interference scenarios.

The AP Link Speed View enables you to view the maximum downlink rate with which a Client at a particular point can connect to an AP on the floor.

The color-coding scheme used enhances the readability of the map.

To view a live RF coverage map for a location floor, Authorized APs and Sensors must be placed on the location layout of the location floor.

View AP Coverage

To view AP coverage , do the following.

1. Go to **Locations**.
2. From the location tree, select the location floor for which you want to see the AP coverage view.
3. Place devices on the location layout if they are not already placed.
4. Click the **AP Coverage** link under **Heatmap Views**.
5. Select 802.11a if you want to view APs operating in 802.11a mode.
6. Select 802.11b/g if you want to view APs operating in 802.11b/g mode.
7. Select the appropriate resolution in **Resolution**. You can see the AP coverage view.

View AP Coverage by RSSI Value

You can select the RSSI value to view the AP coverage provided by all authorized APs placed on the location map. It helps you understand the boundaries of RSSI coverage with different threshold values.

To view AP coverage by RSSI value, do the following.

1. Go to **Locations**.
2. From the location tree, select the location floor for which you want to see the AP coverage view.
3. Place devices on the location layout if they have not already been placed.
4. Click the **AP Coverage** link under **Heatmap Views**.
5. Select 802.11a if you want to view APs operating in 802.11a mode.
6. Select 802.11b/g if you want to view APs operating in 802.11b/g mode.
7. Select the RSSI value check box and move the slider to the right or left to the required RSSI value. The area covered by the AP for the selected RSSI is seen on the location map.

View Sensor Coverage

To view sensor coverage view, do the following.

1. Go to **Locations**.
2. From the location tree, select the location floor for which you want to see the Sensor coverage view.
3. Place devices on the location layout if they are not already placed.
4. Click the **Sensor Coverage** link under **Heatmap Views**.
5. Select 802.11a if you want to view APs operating in 802.11a mode.
6. Select 802.11b/g if you want to view APs operating in 802.11b/g mode.
7. Select the appropriate resolution in **Resolution**. You can see the sensor coverage view.
8. Select **Detection** if you want to view the detection zone of visibility of the AirTight devices functioning as sensors.
9. Select **Prevention** if you want to view the prevention zone of the AirTight devices functioning as sensors.
10. Select the transmit power. You can see the sensor coverage view.

View AP Link Speed

To view AP link speed, do the following.

1. Go to **Locations**.
2. From the location tree, select the location floor for which you want to see the AP coverage view.
3. Place the devices on the location layout if they are not already placed.
4. Click the **AP Link Speed** link under **Heatmap Views**.
5. Select 802.11a if you want to view APs operating in 802.11a mode.
6. Select 802.11b/g if you want to view APs operating in 802.11b/g mode.
7. Select the appropriate resolution in **Resolution**. You can see the AP link speed.

View AP Channel Coverage

To view AP channel coverage , do the following.

1. Go to **Locations**.
2. From the location tree, select the location floor for which you want to see the AP coverage view.
3. Place the devices on the location layout if they are not already placed.
4. Click the **AP Channel Coverage** link under **Heatmap Views**.
5. Select 802.11a if you want to view APs operating in 802.11a mode.
6. Select 802.11b/g if you want to view APs operating in 802.11b/g mode.
7. Select the appropriate resolution in **Resolution**. You can see the AP channel coverage.

Calibrate RF Views

Calibration helps in tuning RF parameters used by AirTight WIPS to compare the AP and Sensor predictions with the actual observations. You can view a graph of the Predicted vs. Observed Signal Strengths when you calibrate an RF view.

AirTight WIPS has a robust calibration technique that also allows manual intervention in case of discrepancy. To improve predictions, you can fine tune the minimum signal decay exponent and maximum signal decay exponent.

Minimum signal decay exponent specifies the amount of signal loss that is acceptable for regions close to the transmitter (Sensor). Maximum signal decay exponent specifies the amount of signal loss that is acceptable for regions away from the transmitter. Signal loss is directly proportional to the signal decay exponents.

IMPORTANT: The Predicted value curve should overlap the Observed value curve as much as possible.

When you change the Minimum Signal Decay exponent, Maximum Signal Decay exponent, Signal Decay Slope (Beta), and Signal Decay Inflection (Alpha) the RF view and location tracking for unobstructed regions is affected. In the obstructed regions, only Location Tracking is affected, RF view is not affected. When you calibrate manually, the graph is automatically updated.

To calibrate RF views automatically, do the following.

1. Go to **Locations**.
2. From the location tree, select the location for which you want to calibrate RF views.
3. Generate the RF Coverage/heatmap using the steps explained in the [View RF Coverage/Heat Maps](#) section
4. Clicking the **Calibration** link. The Calibration dialog box appears.
5. To calibrate automatically, click **Calibrate** under **Automatic Calibration**. The graph is updated when you click Calibrate.
6. To calibrate manually, change the values of the Signal Decay Slope (Beta) and the Signal Decay Inflection (Alpha). The system uses these parameters when computing the RF and defines the region around the transmitter that is unobstructed.
7. Adjust the confidence.
8. Click **OK** or **Apply** to complete calibration if you have adjusted the parameters manually such that the two curves are parallel (but not coinciding).

Note: You can change the intrusion detection display threshold and the intrusion prevention display threshold from **Configuration>System>Advanced Settings>Live RF View Settings**.

Zoom in / Zoom out Layout

The **Zoom** slider is to the left of the **Locations** page. Move the **Zoom** slider up, to zoom in the layout. Move the **Zoom** slider down, to zoom out the layout.

Select an appropriate resolution for rendering of heat maps. A lower resolution would mean a much faster rendering, although with a high pixelization effect. High resolution would mean a much slower rendering due to a large number of pixel cells for which values are being calculated. You can zoom in to a maximum of 400% of the actual size. You can zoom out to a minimum of 25% of the actual size of the layout image.

Adjust the Layout Opacity

Move the **Opacity** slider to the right and left to adjust the opacity of the layout. This slider is on the top right side of the **Locations** page.

- Decrease the image opacity to comprehend the RF coverage in a better way.
- Increase the image opacity to pinpoint exact device placement information.

Add Note

You can add notes to the location layout. These notes could be additional explanatory text or comments related to the devices or the layout, in general.

To add a note to a location layout, do the following.

1. Go to **Locations**.
2. Select the desired location. Ensure that the layout has been added. If the layout is not added, add a layout first.

3. Click the **Add Note** link.
4. Enter the name of the note.
5. Enter the description of the note.
6. Click **OK**. A note is created. The note moves with the mouse.
7. Point the mouse to the desired position on the layout.
8. Click the mouse to place the note at that position on the layout.

Edit Note

To edit a note placed on the location layout, do the following.

1. Go to **Locations**.
2. Select the location where the note to be edited exists.
3. Hover the mouse over the note to be edited. You will see a pencil icon.
4. Click the pencil icon to edit the note.
5. Make the required changes in the name and/or description.
6. Click **OK** to save the changes.

Move Note

You can move an existing note to another position on the location layout.

To move a note from one position on a layout to another position the same layout, do the following.

1. Go to **Locations**.
2. Select the location on which the notes to move have been placed.
3. Drag and drop the note using the mouse to the required position on the location layout. The note is moved to the new position.

Hide Notes

You can hide existing notes that have been placed on a location layout.

To hide existing notes, do the following.

1. Go to **Locations**.
2. Select the desired location on which the notes are placed.
3. Click **Hide Notes** link to hide the notes.

Show Notes

You can bring back the hidden notes on to a location layout.

To show existing notes, do the following.

1. Go to **Locations**.
2. Select the desired location on which the notes are placed.
3. Click **Show Notes** link to hide the notes.

View Mesh Topology

On the **Locations** page, you can see a pictorial representation of the active AirTight devices functioning as mesh APs. You can view the placement of the root and non-root mesh APs connected to each other to form a wireless mesh network.

To view mesh topology, do the following.

1. Go to **Locations**.
2. Click the **View Mesh Topology** link. The mesh wireless network of APs is seen.

Note: It is the responsibility of the system/network administrator to ensure that mesh APs have been properly configured. The **Locations** page merely displays the mesh topology based on the configuration of the AirTight devices as mesh APs.

Hide Mesh Topology

You can hide the mesh topology after taking a look at it on the location layout.

To view mesh topology, do the following.

1. Go to **Locations**.
2. Click the **Hide Mesh Topology** link. The graphical representation of mesh wireless network of APs is hidden when the link is clicked.

View and Manage Events

The **Events** page provides information about events generated in the system. On this page, you can view, filter, locate, acknowledge, mark as read or unread, and toggle the state of the event's participation in vulnerability computation. You can also print the list of events seen at a location.

AirTight WIPS classifies events into the following types - Security, System, and Performance. Security events are related to wireless security threats. For instance, if a rogue AP tries to access the network, a security event is generated.

Security events are further categorized based on the wireless security threats. The categories of security events are as follows.

- Events generated by rogue APs.
- Events generated by misconfigured APs.
- Events generated by misbehaving clients.
- Events generated by ad hoc networks.
- Events generated due to man-in-the-middle attacks.
- Events generated due to DoS (denial of service) attacks.
- Events generated due to MAC spoofing.
- Events generated due to prevention.
- Events generated due to wireless reconnaissance.
- Events generated due to cracking of the wireless network.

System events indicate the health of the system. They are further categorized as based on the events generated by the sensor, the AirTight WIPS server and troubleshooting events.

Performance events indicate wireless network performance problems. They are further categorized on the basis of bandwidth, configuration, coverage, and interference. These can be used to understand problems related to the wireless network performance.

The **Events** page is divided into two panes. The upper pane shows a list of events for the selected location. The lower pane shows the details of the sub-events, devices in the event and sub-event that are related to the event you select in the upper pane of the **Events** page. A maximum of 50 sub-events per event are presented in specific deployments. Some deployments can present only upto 25 sub-events for an event.

When you click a device in the Devices in Selected sub-event widget, you can get more information about the device. This device information is available in specific deployments only.

There is a toolbar between the upper pane and the lower pane. It contains icons to perform various event-related operations such as change location of events, change vulnerability status of events, delete events, print events etc.

The following table describes the event-related fields seen in the upper pane of the **Events** page.

Field	Description
ID	System generated Event ID for the event.
Event Severity	Severity of the event indicated by icons. Severity could be high, medium or low.
Event Activity Status	Event status indicated by icons. The possible values are live, instantaneous, updated, expired.
Details	Event description.

Category	Event category.
Location	Location at which event has occurred.
Start Time	Time at which the event has started.
Event Read Status	Indicates if the event is read, unread, acknowledged or unacknowledged.
Event Vulnerability Status	Indicates the event vulnerability.
Event Type	Type of event. The type is indicated by icons. The possible values are security, system, performance.
Stop Time	Time at which the event has stopped.

View Events for Location

You can view the events at the selected location (and its child locations) based on their category. You can filter out the events based on their category and sub-category.

To view events for a location, do the following.

1. Go to **Events**.
2. Select the location for which you want to view events.
3. Select the **Security** check box to view events that indicate security vulnerability or breach in your network. You can view or filter out the security events by selecting or deselecting the check boxes for the respective security events. Click the down arrow adjacent to the text 'Security' to show a list of security events.
4. Select the **System** check box to view the events that indicate system health. You view or filter out the system events based on its type, by selecting or deselecting the check boxes for the respective system events. Click the down arrow adjacent to the text 'System' to show a list of system events.
5. Select the **Performance** check box to view the events that indicate wireless network performance problems. You view or filter out performance events based on its type, by selecting or deselecting the check boxes for the respective performance events. Click the down arrow adjacent to the text 'Performance' to show a list of performance event types.

Note: If you are viewing the root location on a parent server in a server cluster, you are presented with an aggregation of all events on the child and parent servers. Currently, there is no mechanism in place to view the events belonging solely to the parent server.

View Deleted Events for Location

To mark an event for deletion, do the following.

1. Go to **Events**.
2. Select the location for which you want to view deleted events.
3. Click **More** in the toolbar and select the **Show deleted events** option. The event is marked for deletion.

Change Event Location

To change the location of an event, do the following.

1. Go to **Events**.
2. Select the location at which the event has occurred.

3. Select the check box for the event for which you want to change the location.
4. Click the change location icon. The Select Location dialog box appears.
5. Select the new location and click OK. The event is moved to the new location.

Acknowledge Event

To acknowledge an event, do the following.

1. Go to **Events**.
2. Select the location for which you want to acknowledge an event.
3. Select the check box for the event for which you want to turn off the vulnerability status.
4. Click the turn off vulnerability icon to turn off the vulnerability of an event.

Turn on Vulnerability Status for Event

To turn on the vulnerability status for an event, do the following.

1. Go to **Events**.
2. Select the location for which you want to change the event vulnerability status.
3. Select the check box for the event for which you want to turn on the vulnerability status.
4. Click the turn on vulnerability icon to turn on the vulnerability of an event.

Turn off Vulnerability Status for Event

To turn off the vulnerability status for an event, do the following.

1. Go to **Events**.
2. Select the location for which you want to change the event vulnerability status.
3. Select the check box for the event for which you want to turn off the vulnerability status.
4. Click the turn off vulnerability icon to turn off the vulnerability of an event.

Mark Event as Read

To mark an event as read, do the following.

1. Go to **Events**.
2. Select the location for which you want to mark an event as read.
3. Select the check box for the event to mark as read.
4. Click **More** in the toolbar and select the **Mark as read** option. The event is marked as read.

Mark Event for Deletion


To mark an event for deletion, do the following.

1. Go to **Events**.
2. Select the location for which you want to delete an event.
3. Select the check box for the event to mark for deletion.
4. Click **More** in the toolbar and select the **Mark for delete** option. The event is marked for deletion.


Enable Pagination for Event Listing and Set Page Size



By default, the event listing in the upper pane is presented in a grid. You can scroll down to the last event row in the upper pane without having to browse across pages. A paginated view is also available if you want to view a page-wise list of events. You can enable pagination for the events that are visible to you and configure the number of rows on each page in the upper pane.

To enable pagination, do the following.

1. Go to **Events**.
2. Click the  icon seen on the right side of the tool bar. A message to confirm pagination for all grids/listings on the UI appears.
3. Click **OK**. The pagination for event listing is enabled. The pagination for all other grids such as AirTight devices, APs, clients, networks and AirTight Mobile clients is enabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

To set the page size, do the following.


1. Go to **Events**.
2. On the tool bar, click the down arrow next to the number of rows displayed to the left of the  icon. The options **First Page** and **Set page size** appear.
3. Click **Set Page Size** and enter the number of rows to be visible on each page.
4. Click **OK**.

You can browse through the paginated event listing by clicking the  (next page) and  (previous page) icons. To go to the first page, click the down arrow next to the number of rows on the page and select the **First page** option.

Disable Pagination for Event Listing

If you have enabled pagination and want to disable it, you can restore the default view of having a complete listing of all events on a single page.

To disable pagination, do the following.

1. Go to **Events**.
2. Click the  icon seen on the right side of the tool bar. A message to confirm disabling of pagination for all grids/listings on the UI appears.
3. Click **OK**. The pagination for event listing is disabled. The pagination for all other grids such as AirTight devices, APs, clients, networks, and AirTight Mobile clients is disabled as well. Note that this setting is restricted to your login only and is not applicable to other users.

Add Custom Filter



You can create custom filters and save them with the name of your choice. You can set a filter criteria for the data in the columns seen on AirTight Management Console. You can save this filter with a name and can create multiple filters in this manner.

Note the following points when working with custom filters.

- Preferences for visibility of columns and sorting of column data are not saved in a custom filter. Only the filter criteria is saved.




- Custom filters are user-specific. They are saved for the user who has defined the custom filter and is not visible to any other user.
- An unsaved filter is indicated by an asterisk next to the filter name seen next to **Filter** on the tool bar.
- An unsaved filter is not saved if the user logs out without saving the filter.

To create a custom filter, do the following.

1. Go to **Events**.
2. Click the  icon next to a column header. A list of options is displayed.
3. Point to mouse to the **Filters** option, enter the filter text for the column and press **Enter** key.
4. Click the  icon next to **Filter** on the tool bar and click **Save as**. The **Save as** dialog box appears.
5. Enter the name of the custom filter and click **OK**. The custom filter is saved.



Edit Custom Filter

To edit a custom filter, do the following.

1. Go to **Events**.
2. Click the  icon next to **Filter** and select the required filter.
3. Click the  icon next to a column header. A list of options is displayed.
4. Point the mouse at the **Filters** option and enter the filter text for the column or make changes to the filter criteria as required.
5. Click the  icon next to **Filter** on the tool bar and click **Save**. The modified custom filter is saved.

Delete Custom Filter

To delete a custom filter, do the following.

1. Go to **Events**.
2. Click the  icon next to **Filter** on the tool bar and click the  icon for the filter to delete. A message asking you to confirm delete appears.
3. Click **Yes** to confirm deletion of the custom filter.

Print Event List for Location

You can print a list of events that are generated at a location. If pagination is enabled, a list of all the events for the selected location is printed. If pagination is disabled, a list of only the events displayed on the currently viewed page is printed. You must enable or disable pagination before you print.

To print a list of events at a location, do the following.

1. Go to **Events**.
2. Select the location for which you want to print the events' list.
3. Select the columns that you want in the printed list. Click any column name in the upper pane to select or deselect columns.
4. Click the Print icon. A print preview of the list of events for the location appears.
5. Click **Print** to print the list.

Forensics

You can drill down into forensic data about wireless threats detected in the network, using the **Forensics** page.

AirTight Management Console captures important details about the detected threats and presents them in an easy-to-understand format on the **Forensics** page. You can review details such as device identities and configurations, connection records, device locations, system responses, and administrator actions about the detected wireless threats under Forensics.

Note: The Forensics feature is available in specific deployments only.

The **Forensics** page shows the AP based threats and client based threats that have occurred at the selected location. These threats for the selected location are displayed as lists and as pie charts. The lists and the pie charts are displayed side by side. The list of AP based threats and their pie chart representation are seen at the top. The list of client based threats and their pie chart representation are seen at the bottom.

The pie charts display summary information about the threats.

AP Based Threats: These are threats where the main participating/effected device is an AP. AP based threats are further categorized as follows.

- Rogue AP
- Misconfigured AP
- Honeypot AP
- Banned AP
- DoS

Client Based Threats: These are threats where the main participating/effected device is a client. Client based threats are further categorized as follows.

- Unauthorized Association
- Misassociation
- Bridging Client
- Banned Client
- Ad hoc Networks

Click **Devices** at the top on the right side, to see a pie chart representation based on the AP types or client types. 'Device' specifies the number of unique primary devices that were involved in a threat type. Click **Instances** at the top on the right side, to view a pie chart representation based on the event types. 'Instance' specifies the number of threats of the respective type in the given time frame.

You can filter the threats based on the time elapsed. To do this, select Last 4 Hours, Last 12 Hours, Last 24 Hours, or Last 48 Hours from the **Select Duration** drop-down list. To view the threats based on a custom time period, select **Custom** from **Select Duration** and choose a **From** date and **To** date and click **Apply**.

View AP based /Client based Threat Details

When you click a threat type in the list of AP/client based threats, you can see all events that fall under this threat type, and the list of devices participating in the respective events. This helps you drill down into the details of the threat type and determine the actions taken after the AP based /client based threat was detected.

The threat details or the events are seen in the upper half of the page. The lower half of the page displays the details of the participating device, and the administrator action logs. The middle of the page contains the toolbar using which you can perform various operations related to the events seen in the upper half of the page.

To view the threats for a location, do the following.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed. The following table describes the fields seen in threat details

Field	Description
ID	Event ID.
Event Severity	Indicates severity of the event. It is indicated using icons. Possible values are high, medium, low.
Details	Event description.
Start Time	Event start time.
Stop Time.	Event stop time.
Event Read Status	Indicates if the event has been read.
Event Vulnerability Status	Indicates if the event contributes to the vulnerability of the location. It is indicated using icons
Location	Event location
Event Category	Category of the event.
Event Type	Type of event. It indicates using icons. possible values are security, performance

View Event Summary

To view the threats for a location, do the following.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the + icon to the left of the event row to view the AP or client details. You can also view the **recommended action** and the **acknowledgement trail** here, by clicking the respective hyperlinks. Recommended action describes the nature of the threat, the impact of the threat, and the action to be taken to mitigate the impact. Acknowledgement trail specifies whether or not this threat has been acknowledged. If the event has been acknowledged, or if the vulnerability has been turned on/off, it will show a trail of the comments for this activity.

View Participating Devices and Quarantine Status

In case of AP based threats, AP is the primary device. In case of client based threats, AP is the device that is associated with the primary device (client).

In case of AP based threats, client is the device that is associated with the primary device (AP). In case of Client based threats, client is the primary device.

When you select an event seen under Forensics, you can view the details of the devices participating in the event. You can also view the quarantine status of these devices

To view the participating device details and quarantine status, do the following.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Select an event row and view the participating devices in the participating devices section seen below the event list. The following fields are seen under Participating Devices.

Field	Description
AP	AP name
Client	Client name
Association Start Time	Start time when the primary device associates with the participating device.
Association End Time	Time of end of association of primary device with the participating device.
Quarantine Status	Indicates if the device has been quarantined. Quarantined indicates that the device is quarantined. Not quarantined indicates that the device is not quarantined. Quarantine status is a hyperlink. Depending on the status, you can see the quarantine details or the reason for not being quarantined on clicking the status hyperlink.

Locate Participating Device

You can locate the participating devices for which the AP related or client related threats have occurred.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Select an event row and view the participating devices in the participating devices section seen below the event list.
6. Under **Participating Devices**, click the **Locate** hyperlink for the device to locate. The location of the selected device at the selected time is displayed in the Map View. This means that the device is shown on the floor map that is attached to the location where the threat has been detected. Click the **Switch to Proximity View** hyperlink to view the distance of the located device from the locating device. This link toggles between **Switch to Map View** and **Switch to Proximity View** depending on what view is currently visible to you.

View Administration Action Logs for Event

The Administrator Action Logs show all the administrator actions taken on the AP between the start time and end time of an event.

To view administrator action logs for an event, do the following.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Click 2 in the lower half of the page to view Administrator Action logs for the event. The following table describes the fields seen in the administrator action log

Field	Description
User	Name of the user who has taken action on the threat.
Action	Details of the corrective action taken by the user.
Time	Time at which the user has taken the corrective action on the threat.

Acknowledge Event

To acknowledge an event, do the following.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Select the check box for the event you want to acknowledge.
6. Click the Acknowledge icon.
7. Enter a note and click OK.

Change Location of the Event

To change the location of one or more events, do the following.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Select the check box for event that you want to move to another location.
6. Click the Change Location icon. The Select New Location dialog box appears.
7. Select a new location and click OK, to move the events to the new location.

Turn Vulnerability On/Off

To turn the vulnerability on/off for an event, do the following.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Select the check box for the event for which you want to turn the vulnerability on or off.
6. Click the Turn on Vulnerability Status icon if you want to turn on the vulnerability for the event. Click the Turn off Vulnerability Status icon if you want to turn off the vulnerability for the event. When you turn the vulnerability on, the event summary shows the status for **Contributes to Vulnerability** as **Yes**. When you turn the vulnerability off, the event summary shows the status for **Contributes to Vulnerability** as **No**.

Print Event List for Location

You can print a list of events for a specific type of threat for a location.

To print an event list, do the following.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Click the print icon to print the list of the events that are displayed. A print preview of the event list appears.
6. Click **Print** to print the list.

Mark Event for Deletion

You can mark events for deletion. These are retained in the database even if they are marked for deletion.

To mark an event for deletion, do the following.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Select the check box for event that you want to mark for deletion.
6. Click **More** and select the Mark as deleted option.

Mark Event as Read

To mark an event as read, do the following.

1. Go to **Forensics**.

2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Select the check box for event that you want to mark as read.
6. Click **More** and select the Mark as read option.

Show/Hide Deleted Events

You can show and hide the events marked for deletion seen in the threat details on a device.

1. Go to **Forensics**.
2. Select the location for which you want to view the threats. The AP and client based threats for the selected location are displayed.
3. Click the time hyperlink next to **Select duration** to define the time duration for which you want to view the threats. The AP related threats and client related threats for this duration are displayed.
4. Click the type of threat under AP related threats or client related threats. All events falling under this threat category that have occurred during the selected time duration are displayed.
5. Click the show deleted events icon or the hide deleted events icon as the case may be, to show or hide deleted events.

Reports

The **Reports** page enables you to generate pre-defined and customized reports. The system provides pre-defined compliance reports: Health Insurance Portability and Accountability Act (HIPAA), Sarbanes-Oxley (SOX), Gramm-Leach-Bliley (GLBA), Payment Card Industry (PCI) Standard, and so on. Additionally, information about devices and events is also available in the form of readymade reports. You can generate the reports PDF, HTML and XML formats. At a time, you can generate the report in one of these formats. You can archive the reports for future reference. The reports can also be e-mailed to specified e-mail address.

The pre-defined reports are categorized as follows:

- Compliance Reports
- Device Inventory Reports
- Performance Reports

These reports are shared reports and they can be viewed by all users.

You can define reports in AirTight Management Console.

Similarly, you can view reports and categorize reports into **My Reports**.

You can design reports based on your need. These reports are **Custom** reports.

Custom reports can be created in AirTight Management Console. Click the **Import Report** link to import a report. Browse to a desired path and import the report into AirTight Management Console.

You can export these reports from AirTight Management Console in a .zip file format. The .zip files can be imported into AirTight Management Console in the **Custom** tab and **My Reports** tab.

My Reports contains reports available only to those users who have defined them.

Scheduled Reports consist of **Schedules by Me** reports and **Schedules for Me** reports.

Schedules by Me are shared reports scheduled by the current user. These reports may be scheduled for another user.

Schedules for Me are shared reports scheduled for the current user. These reports may be scheduled for the current user by another user.

The reports are categorized into the following categories.

- Assessment
- Compliance
- Incident
- Device Inventory
- Performance
- SAFE Client
- Custom
- My Reports

Assessment Reports

AirTight Management Console provides assessment reports related to the wireless devices in the airspace, and assessment reports related to wireless vulnerability management.

Compliance Reports

AirTight Management Console provides various compliance reports related to wireless security vulnerabilities, mandated by federal agencies, and other regulatory agencies. You can generate the following reports using **Reports** in AirTight Management Console.

- **DoD Directive 8100.2 Compliance Report** - The sections of this report list the wireless vulnerabilities detected in your network and the severity of security risk caused by these vulnerabilities.
- **GLBA Wireless Compliance Report** - The 'Gramm-Leach Biley Act' (GLBA) of 1999, mandates that financial institutions protect the security and confidentiality of the personally identifiable financial information of their customers.
Section 501 (Title V, Subtitle A) of the GLBA seeks to control leakage of customer financial data to unauthorized users. Federal Trade Commission (FTC) safeguards Rule 16 CFR Part 314.4 specifically describes the elements that every financial institution must include in its information security program. This report assesses the wireless security posture of the organization and identifies wireless vulnerabilities that may expose your organization to leakage of customer financial data.
 1. Part 314.4(a): This section requires the institution to designate employee(s) to coordinate its information security program. This report establishes that employees are designated to prevent customer financial data leakage through wireless.
 2. Part 314.4(b): This section requires the institution to identify risks to the confidentiality and integrity of customer information that could result in its unauthorized disclosure. Periodic generation and archival of this GLBA report establishes that your organization has the capabilities to assess the risk of customer financial data leakage through wireless.
 3. Part 314.4(c): This section requires the institution to design information safeguards and regularly monitor the effectiveness of such safeguards. Periodic generation and archival of this GLBA report establishes that your organization has safeguards to prevent financial data leakage through wireless.
- **HIPAA wireless compliance report**- The Health Insurance Portability and Accountability Act (HIPAA) of 1996 by the Department of Health and Human Services (DHHS), mandates that healthcare organizations must safeguard the privacy and security of patient health information transmitted electronically.
HIPAA Security Rule 45 CFR seeks to control leakage of patient health data to unauthorized users. This report assesses the wireless security posture of the organization and identifies wireless vulnerabilities that may expose your organization to leakage of patient health data.
 1. Section 164.308(a)(1): This section requires a security management process to be set up for risk assessment and management. This HIPAA report is the first step in establishing a security management process to assess and manage the risk of patient health data leakage through wireless.
 2. Section 164.308(a)(6): This section requires formal documentation and response procedures to be set up to handle wireless security incidents promptly. Periodic generation and archival of this HIPAA report establishes that your organization has a formal documentation and rapid response program to handle incidents related to patient health data leakage through wireless.
 3. Section 164.312(e)(1): This section requires patient health data transmitted over wireless networks to be guarded against unauthorized access. Periodic generation and archival of this HIPAA report establishes that your organization has the capabilities to monitor, detect and safeguard against patient health data leakage through wireless.Since wireless environments change dynamically, it is recommended that you conduct a HIPAA wireless vulnerability assessment at least once every 15 days. Archive the HIPAA Wireless Compliance reports. Establish an ongoing wireless security program to fix the top vulnerabilities and to minimize your wireless security exposure.
The sections of this report list the wireless vulnerabilities detected in your network and the severity of security risk caused by these vulnerabilities.

- **MITS wireless compliance report** - The Management of Information Technology Security (MITS) is an operational security standard established by Treasury Board of Canada Secretariat. This standard (established in 2004) defines baseline security requirements that Canadian federal departments must fulfill to ensure the security of information and information technology (IT) assets under their control.

MITS seeks to protect the confidentiality, integrity, and availability of information and IT assets.

This report assesses the wireless security posture of the organization and identifies wireless vulnerabilities that may compromise the confidentiality of information and IT assets.

The following sections from MITS are relevant to wireless deployments.

Part I, Section 4: This section makes senior managers in each department responsible for establishing and maintaining internal controls to high level of IT security. This MITS report is the first step in establishing internal controls to protect confidential information and IT assets against wireless exposure.

Part II, Section 10: This section requires each department shall establish an IT security policy. This MITS report establishes the existence of a wireless security policy.

Part II, Section 12.11.2: This section requires internal audits to be carried out for all security risks. This MITS report can be used as an audit document describing wireless security risks.

Part III, Section 16: This section requires the establishment of safeguards to protect the confidentiality, integrity, and availability of information and IT assets. Periodic generation and archival of this MITS report establishes that your organization has the safeguards to protect confidential information and IT assets against wireless exposure.

Part III, Section 17: This section requires monitoring and detection of security incidents. Periodic generation and archival of this MITS report establishes that your organization has the capabilities to monitor and detect of wireless security incidents.

Since wireless environments change dynamically, it is recommended that you conduct a MITS wireless vulnerability assessment at least once every 15 days. Archive the MITS Wireless Compliance reports. Establish an ongoing wireless security program to fix the top vulnerabilities and to minimize your wireless security exposure.

The sections of this report list the wireless vulnerabilities detected in your network and the severity of security risk caused by these vulnerabilities.

- **PCI DSS 3.0 Wireless Compliance Report**

Payment Card Industry Data Security Standard (PCI DSS) Version 3.0 published in November 2013 defined recommended security controls for protecting cardholder data. PCI DSS was defined by a consortium of credit card companies, including VISA and Mastercard. The requirements of the PCI standard apply to all members, merchants, and service providers that store, process and transmit cardholder data.

The following sections from PCI DSS, Version 3.0 are relevant from the perspective of protecting cardholder data from unauthorized wireless access. This report is intended to be simply an aide to review PCI DSS 3.0 compliance of WLAN deployments. It is not meant to automatically fulfill PCI DSS 3.0 requirements related to your WLAN network. Consult a PCI Qualified Security Auditor (QSA) for obtaining compliance certification.

1. Requirement 1.2: Deny traffic from 'untrusted' networks and hosts, except for protocols necessary in the cardholder's data environment. This report provides a list of rogue or misconfigured wireless access points detected during the report interval. Unauthorized cardholder data access is possible through these access points.

2. Requirement 2.1.1: Change vendor-supplied defaults for wireless equipment. For wireless equipment, default password, SSID, WEP key and security settings should be changed. WPA or WPA2 should be used wherever possible. This report provides a list of wireless access points using default SSID or security configurations.

3. Requirement 4.1.1: Verify that wireless networks transmitting cardholder data use appropriate encryption methods. Reliance on WEP (Wired Equivalent Privacy) for cardholder data protection should be avoided. This report provides a list of wireless access points and clients communicating using open or insecure encryption methods.

4. Requirement 6.2: Establishing a process to identify newly discovered vulnerabilities and updating configuration standards to address the new vulnerability issues. Generate and review contents of this report periodically so that newly discovered vulnerabilities can be identified and acted upon.

5. Requirement 10.5.4: Copy logs for wireless networks onto a centralized internal log server or media that is difficult to alter. The report generation engine maintains logs of all wireless activity for archival purposes.

6. Requirement 11.1: Use a wireless analyzer at least quarterly to identify all wireless devices in use. This report provides a list of all wireless devices in use. In addition, scanners continuously monitor all wireless devices in use and automatically update the list of wireless devices maintained at the server.

7. Requirement 11.2: Run network vulnerability scans quarterly and after any significant change in the network. This report provides a list of wireless vulnerabilities discovered during the report generation interval. This report can be generated on demand or at scheduled intervals.

8. Requirement 11.4: Use of network intrusion detection and prevention system to monitor network traffic and alert personnel of suspected compromises. Intrusions can also happen through wireless. Wireless scanners continuously monitor, log and (optionally) alert and block wireless intrusion attempts.

9. Requirement 12.10: Implement an incident response plan. Be prepared to respond immediately to a system breach (including those happening through wireless back doors). Wireless scanners monitor airwaves 24/7 and instantly detect any unauthorized wireless activity. Incident response can be done either manually or automatically using wireless scanners.

Since wireless environments change dynamically, it is recommended that you conduct a PCI Wireless Compliance assessment at least once every 15 days. Archive the PCI wireless compliance reports.

Establish an ongoing wireless security program to fix the top vulnerabilities and to minimize your wireless security exposure.

The sections of this report list the wireless vulnerabilities detected in your network and the severity of security risk caused by these vulnerabilities.

• PCI DSS 3.0 Wireless Compliance Internal Audit Report

PCI DSS 3.0 Wireless Compliance Report is relevant for only those VLANs that process or store credit card data; these VLANs are commonly known as cardholder data environment (CDE). Violations reported in the PCI DSS 3.0 Wireless Compliance Report are based on wireless security incidents that occur on a CDE network. Occasionally, if the system is not able to determine if the network where a security incident has occurred, is a CDE network or not, then the incidents are classified as a Potential Violation. PCI DSS 3.0 Wireless Compliance Internal Audit Report includes all sections which belong to PCI DSS 3.0 Wireless Compliance Report and, in addition, it contains Potential Violation sections for networks not confirmed to be a part of the CDE.

The following sections from PCI DSS 3.0 Wireless Compliance Internal Audit Report, are relevant from the perspective of protecting cardholder data from unauthorized wireless access. This report is intended to be simply an aide to review PCI DSS 3.0 compliance of WLAN deployments. It is not meant to automatically fulfill PCI DSS 3.0 requirements related to your WLAN network. Consult a PCI Qualified Security Auditor (QSA) for obtaining compliance certification.

1. Requirement 1.2: Deny traffic from 'untrusted' networks and hosts, except for protocols necessary in the cardholder's data environment. This report provides a list of rogue or misconfigured wireless access points detected during the report interval. Unauthorized cardholder data access is possible through these access points.

2. Requirement 2.1.1: Change vendor-supplied defaults for wireless equipment. For wireless equipment, default password, SSID, WEP key and security settings should be changed. WPA or WPA2 should be used wherever possible. This report provides a list of wireless access points using default SSID or security configurations.

3. Requirement 4.1.1: Verify that wireless networks transmitting cardholder data use appropriate encryption methods. Reliance on WEP (Wired Equivalent Privacy) for cardholder data protection should be avoided. This report provides a list of wireless access points and clients communicating using open or insecure encryption methods.

4. Requirement 6.2: Establishing a process to identify newly discovered vulnerabilities and updating configuration standards to address the new vulnerability issues. Generate and review contents of this report periodically so that newly discovered vulnerabilities can be identified and acted upon.

5. Requirement 10.5.4: Copy logs for wireless networks onto a centralized internal log server or media that is difficult to alter. The report generation engine maintains logs of all wireless activity for archival purposes.

6. Requirement 11.1: Use a wireless analyzer at least quarterly to identify all wireless devices in use. This report provides a list of all wireless devices in use. In addition, scanners continuously monitor all wireless devices in use and automatically update the list of wireless devices maintained at the server.

7. Requirement 11.2: Run network vulnerability scans quarterly and after any significant change in the network. This report provides a list of wireless vulnerabilities discovered during the report generation interval. This report can be generated on demand or at scheduled intervals.

8. Requirement 11.4: Use of network intrusion detection and prevention system to monitor network traffic and alert personnel of suspected compromises. Intrusions can also happen through wireless. Wireless scanners continuously monitor, log and (optionally) alert and block wireless intrusion attempts.

9. Requirement 12.10: Implement an incident response plan. Be prepared to respond immediately to a system breach (including those happening through wireless back doors). Wireless scanners monitor airwaves 24/7 and instantly detect any unauthorized wireless activity. Incident response can be done either manually or automatically using wireless scanners.

10. Requirement 2.1.1 (Potential Violations): Change vendor-supplied defaults for wireless equipment. For wireless equipment, default password, SSID, WEP key and security settings should be changed. WPA or WPA2 should be used wherever possible. This report provides a list of wireless access points using default SSID or security configurations.

11. Requirement 4.1.1 (Potential Violations): Verify that wireless networks transmitting cardholder data use appropriate encryption methods. Reliance on WEP (Wired Equivalent Privacy) for cardholder data protection should be avoided. This report provides a list of wireless access points and clients communicating using open or insecure encryption methods.

12. Requirement 11.1 (Potential Violations): Use a wireless analyzer at least quarterly to identify all wireless devices in use. This report provides a list of all wireless devices in use. In addition, scanners continuously monitor all wireless devices in use and automatically update the list of wireless devices maintained at the server.

Note: For all potential violation sections, It is not confirmed whether or not these wireless security incidents occurred inside a cardholder data environment (CDE) network. Hence, the incidents have been classified as a Potential Violation of the PCI DSS.

- PCI DSS 2.0 Wireless Compliance Report** - Payment Card Industry Data Security Standard (PCI DSS) Version 2.0 published in October 2010 defined recommended security controls for protecting cardholder data. PCI DSS was defined by a consortium of credit card companies, including VISA and Master Card. The requirements of the PCI standard apply to all members, merchants, and service providers that store, process and transmit card holder data. The following sections from PCI DSS, Version 2.0 are relevant from the perspective of protecting cardholder data from unauthorized wireless access. This report is intended to be simply an aide to review PCI DSS 2.0 compliance of WLAN deployments. It is not meant to automatically fulfill PCI DSS 2.0 requirements related to your WLAN network. Consult a PCI Qualified Security Auditor (QSA) for obtaining compliance certification.

1. Requirement 1.2: Deny traffic from 'untrusted' networks and hosts, except for protocols necessary in the cardholder's data environment. This report provides a list of rogue or

misconfigured wireless access points detected during the report interval. Unauthorized cardholder data access is possible through these access points.

2. Requirement 2.1.1: Change vendor-supplied defaults for wireless equipment. For wireless equipment, default password, SSID, WEP key and security settings should be changed. WPA or WPA2 should be used wherever possible. This report provides a list of wireless access points using default SSID or security configurations.

3. Requirement 4.1.1: Verify that wireless networks transmitting cardholder data use appropriate encryption methods. Reliance on WEP (Wired Equivalent Privacy) for cardholder data protection should be avoided. This report provides a list of wireless access points and clients communicating using open or insecure encryption methods.

4. Requirement 6.2: Establishing a process to identify newly discovered vulnerabilities and updating configuration standards to address the new vulnerability issues. Generate and review contents of this report periodically so that newly discovered vulnerabilities can be identified and acted upon.

5. Requirement 10.5.4: Copy logs for wireless networks onto a centralized internal log server or media that is difficult to alter. The report generation engine maintains logs of all wireless activity for archival purposes.

6. Requirement 11.1: Use a wireless analyzer at least quarterly to identify all wireless devices in use. This report provides a list of all wireless devices in use. In addition, scanners continuously monitor all wireless devices in use and automatically update the list of wireless devices maintained at the server.

7. Requirement 11.2: Run network vulnerability scans quarterly and after any significant change in the network. This report provides a list of wireless vulnerabilities discovered during the report generation interval. This report can be generated on demand or at scheduled intervals.

8. Requirement 11.4: Use of network intrusion detection and prevention system to monitor network traffic and alert personnel of suspected compromises. Intrusions can also happen through wireless. Wireless scanners continuously monitor, log and (optionally) alert and block wireless intrusion attempts.

9. Requirement 12.9: Implement an incident response plan. Be prepared to respond immediately to a system breach (including those happening through wireless back doors). Wireless scanners monitor airwaves 24/7 and instantly detect any unauthorized wireless activity. Incident response can be done either manually or automatically using wireless scanners.

Since wireless environments change dynamically, it is recommended that you conduct a PCI Wireless Compliance assessment at least once every 15 days. Archive the PCI wireless compliance reports. Establish an ongoing wireless security program to fix the top vulnerabilities and to minimize your wireless security exposure.

The sections of this report list the wireless vulnerabilities detected in your network and the severity of security risk caused by these vulnerabilities.

- **PCI DSS 1.2 Wireless Compliance Report** - Payment Card Industry Data Security Standard (PCI DSS) Version 1.2 published in October 2008 defines recommended security controls for protecting cardholder data. PCI DSS was defined by a consortium of credit card companies, including VISA and Master Card. The requirements of the PCI standard apply to all members, merchants and service providers that store, process and transmit cardholder data.

The following sections from PCI DSS, Version 1.2 are relevant from the perspective of protecting cardholder data from unauthorized wireless access. This report is intended to be simply an aide to review PCI DSS 1.2 compliance of WLAN deployments. It is not meant to automatically fulfill PCI DSS 1.2 requirements related to your WLAN network. Consult a PCI Qualified Security Auditor (QSA) for obtaining compliance certification.

1. Requirement 1.2: Deny traffic from 'untrusted' networks and hosts, except for protocols necessary in the cardholder's data environment. This report provides a list of rogue or misconfigured wireless access points detected during the report interval. Unauthorized cardholder data access is possible through these access points.

2. Requirement 2.1.1: Change vendor-supplied defaults for wireless equipment. For wireless equipment, default password, SSID, WEP key and security settings should be changed. WPA and

WPA2 should be used wherever possible. This report provides a list of wireless access points using default SSID or security configurations.

3. Requirement 2.2: Develop configuration standards of all system components (including any wireless access points and clients). It also requires the institution to assure that these standards address all known security vulnerabilities and are consistent with industry-accepted system hardening procedures. This report provides a list of wireless access points and clients whose current configuration is vulnerable vis-a-vis newly discovered and known vulnerabilities.

4. Requirement 4.1.1: Verify that wireless networks transmitting cardholder data use appropriate encryption methods. Reliance on WEP (Wired Equivalent Privacy) for cardholder data protection should be avoided. This report provides a list of wireless access points and clients communicating using open or insecure encryption methods.

5. Requirement 6.2: Establishing a process to identify newly discovered vulnerabilities and updating configuration standards to address the new vulnerability issues. Generate and review contents of this report periodically so that newly discovered vulnerabilities can be identified and acted upon.

6. Requirement 10.5.4: Copy logs for wireless networks onto a centralized internal log server or media that is difficult to alter. The report generation engine maintains logs of all wireless activity for archival purposes.

7. Requirement 11.1: Use a wireless analyzer at least quarterly to identify all wireless devices in use. This report provides a list of all wireless devices in use. In addition, scanners continuously monitor all wireless devices in use and automatically update the list of wireless devices maintained at the server.

8. Requirement 11.2: Run network vulnerability scans quarterly and after any significant change in the network. This report provides a list of wireless vulnerabilities discovered during the report generation interval. This report can be generated on demand or at scheduled intervals.

9. Requirement 11.4: Use of network intrusion detection and prevention system to monitor network traffic and alert personnel of suspected compromises. Intrusions can also happen through wireless. Wireless scanners continuously monitor, log and (optionally) alert and block wireless intrusion attempts.

10. Requirement 12.9: Implement an incident response plan. Be prepared to respond immediately to a system breach (including those happening through wireless back doors). Wireless scanners monitor airwaves 24/7 and instantly detect for any unauthorized wireless activity. Incident response can be done either manually or automatically using wireless scanners.

Since wireless environments change dynamically, it is recommended that you conduct a PCI wireless vulnerability assessment at least once every 15 days. Archive the PCI Wireless Compliance reports. Establish an ongoing wireless security program to fix top vulnerabilities and to minimize your wireless security exposure.

The sections of this report list the wireless vulnerabilities detected in your network and the severity of security risk caused by these vulnerabilities.

- **PCI DSS 1.1 Wireless Compliance Report** - Payment Card Industry Data Security Standard (PCI DSS) Version 1.1, published in September 2006, defines recommended security controls for protecting cardholder data. PCI DSS was defined by a consortium of credit card companies, including VISA and Master Card. The requirements of the PCI standard apply to all members, merchants and service providers that store, process and transmit cardholder data. The following sections from PCI DSS, Version 1.1 are relevant from the perspective of protecting cardholder data from unauthorized wireless access. This report is intended to be simply an aide to review PCI DSS 1.1 compliance of WLAN deployments. It is not meant to automatically fulfill PCI DSS 1.1 requirements related to your WLAN network. Consult a PCI Qualified Security Auditor (QSA) for obtaining compliance certification.
 1. Requirement 1.2: Deny traffic from 'untrusted' networks and hosts, except for protocols necessary in the cardholder's data environment. This report provides a list of rogue or misconfigured wireless access points detected during the report interval. Unauthorized cardholder data access is possible through these access points.
 2. Requirement 2.1.1: Change vendor-supplied defaults for wireless equipment. For wireless equipment, default password, SSID, WEP key and security settings should be changed. WPA and

WPA2 should be used wherever possible. This report provides a list of wireless access points using default SSID or security configurations.

3. Requirement 2.2: Develop configuration standards of all system components (including any wireless access points and clients). It also requires the institution to assure that these standards address all known security vulnerabilities and are consistent with industry-accepted system hardening procedures. This report provides a list of wireless access points and clients whose current configuration is vulnerable vis-a-vis newly discovered and known vulnerabilities.

4. Requirement 4.1.1: Verify that wireless networks transmitting cardholder data use appropriate encryption methods. Reliance on WEP (Wired Equivalent Privacy) for cardholder data protection should be avoided. This report provides a list of wireless access points and clients communicating using open or insecure encryption methods.

5. Requirement 6.2: Establishing a process to identify newly discovered vulnerabilities and updating configuration standards to address the new vulnerability issues. Generate and review contents of this report periodically so that newly discovered vulnerabilities can be identified and acted upon.

6. Requirement 10.5.4: Copy logs for wireless networks onto a centralized internal log server or media that is difficult to alter. The report generation engine maintains logs of all wireless activity for archival purposes.

7. Requirement 11.1: Use a wireless analyzer at least quarterly to identify all wireless devices in use. This report provides a list of all wireless devices in use. In addition, scanners continuously monitor all wireless devices in use and automatically update the list of wireless devices maintained at the server.

8. Requirement 11.2: Run network vulnerability scans quarterly and after any significant change in the network. This report provides a list of wireless vulnerabilities discovered during the report generation interval. This report can be generated on demand or at scheduled intervals.

9. Requirement 11.4: Use of network intrusion detection and prevention system to monitor network traffic and alert personnel of suspected compromises. Intrusions can also happen through wireless. Wireless scanners continuously monitor, log and (optionally) alert and block wireless intrusion attempts.

10. Requirement 12.9: Implement an incident response plan. Be prepared to respond immediately to a system breach (including those happening through wireless back doors). Wireless scanners monitor airwaves 24/7 and instantly detect for any unauthorized wireless activity. Incident response can be done either manually or automatically using wireless scanners.

Note: PCI Compliance reports list potential violations if the network is a card holder data environment (CDE) network.

- **SOX Wireless Compliance Report** - The Sarbanes-Oxley (SOX) Act of 2002 was passed by the US Congress in 2002, as a comprehensive legislation to reform the accounting practices, financial disclosures, and corporate governance of public companies. SOX applied to all companies that are publicly traded in the United States and regulated by the Security and Exchange Commission (SEC).

Section 302, 404, and 409 of SOX seek to control leakage of non-public data to unauthorized users. This report assesses the wireless security posture of the organization and identifies wireless vulnerabilities that may expose your organization to such non-public data leakage.

1. Section 302: This section makes the CEO and CFO responsible for establishing and maintaining and periodically reviewing internal controls to protect non-public information from leaking out. This report is the first step in establishing internal controls to prevent non-public data leakage through wireless.

2. Section 404: This section requires that the company has capabilities to monitor, detect and record electronic information disclosures of non-public data. Periodic generation and archival of this SOX report establishes that your organization has the capabilities to monitor, detect and record instances of non-public data leakage through wireless.

3. Section 409: This section requires a rapid response and exposure assessment program, if non-public information is inappropriately disclosed on your network. Periodic generation and archival of

this SOX report establishes that your organization has a rapid response and exposure assessment program if non-public information leaks through wireless.

Since wireless environments change dynamically, it is recommended that you conduct a SOX wireless vulnerability assessment at least once every 15 days. Archive the SOX Wireless Compliance reports. Establish an ongoing wireless security program to fix the top vulnerabilities and to minimize your wireless security exposure.

The sections of this report list the wireless vulnerabilities detected in your network and the severity of security risk caused by these vulnerabilities.

Performance related reports

- **Bandwidth audit report** - This report summarizes bandwidth-related performance problems detected in the wireless network. These performance problems can cause wireless network to operate below its full potential. Remedial action to remove these problems should be considered.
- **Configuration audit report** - This report summarizes configuration settings detected in wireless network, which may cause the wireless network to operate below its full potential. Rectification of these configuration settings should be considered.
- **RF audit report**-This report summarizes RF problems detected in the wireless network. These performance problems can cause wireless network to operate below its full potential. Remedial action to remove these problems should be considered.

Device Inventory reports

- **All Device Listing** - Complete inventory of all APs, clients and sensors detected by the system is listed in this report. Information about APs, clients and sensors is further split into various sections based on device folders.
- **Bring Your Own Device (BYOD)** - This report provides information about smart phones and tablets accessing the enterprise network over Wi-Fi. It also provides information about soft APs and mobile Wi-Fi hotspots that may be operating in enterprise premises without authorization.
- **Detailed AP Listing** - Complete inventory of all APs detected by the system is listed in this report. Information about APs is further split into various sections based on AP folders.
- **Detailed Client Listing** - Complete inventory of all clients detected by the product is listed in this report. Information about clients is further split into various sections based on client folders.
- **Detailed Sensor Listing** - Complete inventory of all sensors detected by the product is listed in this report.

Custom Reports

You can design reports based on your need. These reports are **Custom** reports. Custom reports can be created in AirTight Management Console. You can export reports from AirTight Management Console in a .zip file format and import the .zip file back into AirTight Management Console.

Click **Import Report** and specify the path and filename of the report to be imported. You can change the report name while importing it. You will not be able to import a file that has not been generated through AirTight Management Console.

My Reports

Unlike the shared reports like compliance reports, **My Reports** are visible only to those users who have created them.

You can fetch My Reports. You can also rename and delete these reports.

Analytics

Analytics data is available with respect to the Wi-Fi clients that are visible to AirTight sensors, and the Wi-Fi clients that associate with AirTight APs.

Visibility analytics presents information about clients in the vicinity of AirTight devices.

Association analytics presents information about the clients that connect to or associate with the AirTight APs.


Content analytics captures information about the internet domains accessed by the clients associated with the AirTight APs. This information is present in the association analytics file that can be downloaded from Reports>Analytics.

You need administrator privileges to generate Analytics reports.

The analytics data can be used in various ways. For instance, if AirTight Management Console has been deployed at a retail store, you can find the number of clients in and around the retail store by using visibility analytics. Similarly, using association analytics, you can have an insight into the activity of the authorized clients, the guest clients, and the SSIDs being used by these clients. Using association and visibility analytics, you can establish network usage patterns, including but not limited to visitors to the store, the number of visitors in the store at various times of the day.

A sample association analytics graph below shows the number of daily users per the time slot during breakfast, lunch, dinner and other hours. These metrics are obtained using the association and visibility analytics engine.

The analytics are currently provided in a raw comma separated value (.csv) file. The data in the .csv file can be crunched and meaningful customer trends can be obtained using tools like Microsoft (MS) Excel. This graph has been generated from the .csv file data using an MS Excel macro.



Daily Users by Time Slot derived from Analytics data

Sample macros would be available on request.

Analytics is a license-based feature. The Analytics tab in the Reports page would be enabled and displayed, only after applying the Analytics license to the server. Contact support@airtightnetworks.com for further details to procure the license for analytics and for the sample macros.

Download Analytics Data

Do the following to download visibility analytics data.

1. Select the **Visibility Analytics** option.
2. Enter the number of previous days for which you want to download this data.
3. Click **Download**.

The visibility analytics data is downloaded as a comma separated file (.CSV). Ensure that pop-ups are enabled in your browser when you download the data.

The .csv file is typically saved to the 'Downloads' folder. It contains the following data

- Client MAC address
- Location of the client
- Best received signal strength indication (RSSI)
- MAC address of the sensor reporting best RSSI
- Client session duration
- Activity stop time (GMT)
- Activity stop time per the local time zone of the user-When the analytics data pertains to a location floor, the local time zone set for its immediate parent location folder is considered. If the time zone for the location folder has not been set, this field shows the activity stop time based on the server time zone. Similarly, when the analytics data pertains to a location folder, the local time zone set for the location folder is considered. If the time zone for the location folder has not been set, this field shows the activity stop time based on the server time zone.
- Local Time Zone-When the analytics data pertains to a location floor, the local time zone set for its immediate parent location folder is considered. If the time zone for the location folder has not been set, this field shows the server time zone. Similarly, when the analytics data pertains to a location folder, the local time zone set for the location folder is considered. If the time zone for the location folder has not been set, this field shows the server time zone.

Note: The client may be visible to multiple sensors; the sensor reporting the best RSSI is recorded in the .CSV file.

Do the following to download association analytics data.

1. Select the **Association Analytics** option.
2. Enter the from date and to date for which you want to download this data.
3. Click **Download**.

IMPORTANT: Edit the SSID profile associated with the AirTight APs to select the **Association Analytics** check box. If this check box is not selected, the data related to AirTight APs associated with the respective SSID will not appear in the .CSV file containing the Association Analytics data.

The association analytics data is downloaded as a comma separated file (.csv). Ensure that pop-ups are enabled in your browser when you download the data.

The file is typically saved to the 'Downloads' folder.

The .csv file contains the following data

- Client MAC address

- Protocol
- SSID
- Location
- Association start time (GMT) of the client
- Association end time (GMT)
- Association start time of the client per the local time zone of the user- When the analytics data pertains to a location floor, the local time zone set for its immediate parent location folder is considered. If the time zone for the location folder has not been set, this field shows the client association start time the server time zone. Similarly, when the analytics data pertains to a location folder, the local time zone set for the location folder is considered. If the time zone for the location folder has not been set, this field shows client association start time based on the server time zone.
- Association end time of the client per the local time zone of the user- When the analytics data pertains to a location floor, the local time zone set for its immediate parent location folder is considered. If the time zone for the location folder has not been set, this field shows the client association end time based on the server time zone. Similarly, when the analytics data pertains to a location folder, the local time zone set for the location folder is considered. If the time zone for the location folder has not been set, this field shows the client association end time based on the server time zone.
- Session duration
- Data transfer from client device in bytes
- Data transfer to client device in bytes
- Data rate in Kbps
- Smart device type
- Local Time Zone
- Location ID
- Domains Accessed

Top domains based on the data exchange are presented in the Domains accessed column of the CSV file. The data in the Domains Accessed column is seen in the following format:<Domain name> (<data transferred to the domain>/<data received from the domain>). Multiple domains are separated by a | sign.

Important: Internet domain related information is collected only if you select the **Content Analytics** check box while configuring the SSID profile. Otherwise, the domains accessed column will be blank in the CSV file.

The session duration could be less than the difference between the association end time and the association start time, as it is calculated as the duration for which the client has actively accessed network resources through the AirTight APs.

Back up Analytics data

You can backup Analytics data by executing the `set db backup info` or `db backup` command, whenever you want to take a backup. Note that the size of the backed up database might be large if Analytics data is backed up.

Manage Report Archive

The **Archives** tab allows you to view saved or archived reports generated by the AirTight Management Console server. These reports are useful for trend analysis. An archived report is visible to a user who has previously generated this report. A super user can see all archived reports.

Archived reports are not location specific. It depends on the privileges or rights of the user that has logged in to AirTight Management Console. A superuser is able to see all archived reports. A poweruser is able to see all archived reports for the customer account managed by him or her. An administrator, operator and viewer are able to see self-archived reports only.

If you are logged in to the parent server of a server cluster, based on your role, you can see an aggregated set of archived reports from the parent and child servers,

You can fetch, rename, and delete archived reports. You can also print a list of archived reports for a location.

If an archived report has been generated on the parent server of a server cluster, it shows aggregated data from the parent and child servers.

Fetch Archived Report

To fetch and view an archived report, do the following.

1. Go to **Reports>Archives** tab.
2. Select the location at which the report has been archived.
3. Select the check box for the report from the list of archived reports.
4. Click the fetch icon to fetch the report.

Rename Archived Report

To rename an archived report, do the following.

1. Go to **Reports>Archives** tab.
2. Select the location at which the report has been archived.
3. Select the check box for the report from the list of archived reports.
4. Click the rename icon and enter new name for the report.

Print Archived Report List for Location

To print a list of archived reports, do the following.

1. Go to **Reports>Archives** tab.
2. Select the location for which you want to print the list of archived reports.
3. Select the columns that you want in the printed list. Click any column name to select or deselect columns.
4. Click the print icon. The print preview of the list of archived reports appears.
5. Click **Print** to print the list.

Delete Archived Report

To delete an archived report, do the following.

1. Go to **Reports>Archives** tab.
2. Select the location at which the report has been archived.
3. Select the check box for the report from the list of archived reports.
4. Click the delete icon. A message to confirm deletion appears.
5. Click **Yes** to confirm deletion of the archived report.

Schedule Report Generation

You can schedule a report for one-time generation, or a recurring generation. You can schedule to e-mail a report. While scheduling the report generation, you can also specify report archival details. Once the report generation schedule has been defined, it is seen under **Reports Scheduled by Me** reports for the user who has scheduled the report.

Important: *Scheduled reports are e-mailed at incorrect times if incorrect time zone settings are configured in the Server Initialization and Configuration Wizard from the Server Config shell. Choose the correct time zone for proper delivery.*

Note: When a server is a parent server in a server cluster and there are child servers mounted in the parent server location tree, you will not be able to schedule reports on the child servers. Scheduling is allowed only on reports local to the parent server. In general, scheduling reports on remote locations is not allowed.

To schedule report generation, do the following.

1. Under Reports, select the appropriate report category.
2. Click the **Add Schedule** hyperlink following the report you want to schedule.
3. **Add Schedule** is displayed as seen in the images shown below.
4. Select the **Report Format**. The available options are pdf, html and xml.

If you want to schedule the report for one time generation, specify the details under the **One Time Generation** tab.

Add Schedule
✕

Selected Report DoD Directive 8100.2 Compliance Report

Selected Location U3 Demo Server

Report Format PDF ▼

Language User Language (English) ▼

Frequency One Time Recurring

Generate report at 00 : 00 HH:MM

Report Time Period Fixed Custom

Last 1 ▼ Hour(s) ▼

Email Report

Zip before email

Please type name or email address

John Doe<jdoe@atn.com> x

Use comma, space, tab, or enter as separators between names/email addresses.

Archive Report

Never Delete

Delete After 10 ▼ [1-360] Day(s)

Save
Cancel

Add Schedule - One time Generation

The following table describes the fields present on the **One Time Generation** tab.

Field	Description
Generate Report at	Click the calendar icon to specify the date of report generation. Also specify the time of the report generation.
Report Time Period	Select the Last option to specify the time period preceding the report delivery date and time. Specify the number of preceding hours, days or months for which you want to generate the report. Select the Customize option to specify a date-wise duration for which you want the report. Specify the From date and time and To date and time.

If you want to schedule the report for recurring generation, specify the details under the **Recurring Generation** tab.

Add Schedule
✕

Selected Report DoD Directive 8100.2 Compliance Report

Selected Location U3 Demo Server

Report Format ▼

Language ▼

Frequency One Time Recurring

Generate report every ▼ Hour(s) ▼

From : HH:MM

To : HH:MM

For the last ▼ Hour(s) ▼

Email Report

Zip before email

Please type name or email address

John Doe<jdoe@atn.com> x

Use comma, space, tab, or enter as separators between names/email addresses.

Archive Report

Never Delete

Delete After [1-360] Day(s)

Add Schedule - Recurring Generation

The following table describes the fields present on the **Recurring Generation** tab.

Field	Description
Generate Report every	Specify the frequency in number of hours, days, or months for report generation.
Start Date	Select the start date and time for which you want to generate the report.
End Date	Select the end date and time for which you want to generate the report.

Report Time Period	Select the time period in number of hours, days, or months for which the report is to be generated.
--------------------	---

Send report by e-mail

If you want to email the report on generation, select the **Email Report** check box. If you want to zip the report before sending it in an email, select the **Zip before email** check box.

If your email id is mentioned in the schedule, you will be able to see the report under **Reports Scheduled for Me** section in the **Schedules** tab. If you have added the schedule, you will be able to see the report under the **Reports Scheduled by Me** section in the **Schedules** tab.

Archive report

To archive a report, select the Archive Report check box. If you want to permanently retain the archived report, select the **Never Delete** option. To retain the archived report for a fixed duration, select the **Delete After** option and specify the duration in days, after which the archived report is to be deleted from the system. The minimum and maximum durations to retain the archived report is 1 day and 360 days respectively.

View Report Schedules

You can view the report schedules defined by you and for you under the **Report Schedules** tab. If your email id is mentioned in the schedule, you will be able to see the report under **Schedules For Me** section in the **Report Schedules** tab. If you have added the schedule, you will be able to see the report under the **Schedules by Me** section in the **Report Schedules** tab.

Click **Schedules By Me** to view a list of report schedules defined by you.

In the **Schedules By Me** section, you will see the report name, schedule information, next report delivery date and time, the location for which the report is being generated and the duration for which the report has been generated in this section.


























Click **Schedules For Me** to view a list of reports scheduled for you.










In the **Schedules For Me** section, you will see the report name, schedule information, next report delivery date and time, the location for which the report is being generated and the duration for which the report has been generated, and the name of the user who has defined the report schedule.

Glossary of Icons














Following is a list of the device related icons seen on AirTight Management Console.

Icon	Description
	Rogue AP-Active: This icon shows that a Rogue AP is active and visible to Sensor(s).
	Authorized AP: This icon shows that the AP is an authorized AP
	Authorized AP-Active: This icon shows that an authorized AP is active and visible to Sensor(s).
	Authorized AP-Inactive: This icon shows that an Authorized AP that was earlier visible to Sensor(s) is inactive.
	External AP-Active: This icon shows that an External AP is active and visible to Sensor(s).
	Quarantine Pending: This icon shows that the AP/Client needs to be quarantined, but quarantine is pending.
	Quarantined: This icon shows that the AP/Client has been quarantined.
	Quarantine Error: This icon shows that some error has occurred while quarantining a device.
	DoS Quarantine: This icon shows that the quarantine against DoS attack on this device is in progress.
	DoS Quarantine Pending: This icon shows that the quarantine against DoS attack on this device is pending.
	Banned Device: This icon shows that the AP/Client is a banned device.
	Remove from Banned List: This icon shows that the AP/Client has been removed from the Banned List.
	Troubleshooting: This icon shows that troubleshooting is in progress on a device.
	Authorized Client-Active: This icon shows that an Authorized Client is active and visible to Sensor(s).
	Authorized Client-Inactive: This icon shows that an Authorized Client that was earlier visible to Sensor(s) is inactive.
	Rogue Client-Active: This icon shows that a Rogue Client is active and visible to Sensor(s).
	Rogue Client-Inactive: This icon shows that a Rogue Client that was earlier visible to Sensor(s) is inactive.
	External Client-Active: This icon shows that an External Client is active and visible to Sensor(s).
	External Client-Inactive: This icon shows that an External Client that was earlier visible to Sensor(s) is inactive.
	Guest Client-Active: This icon shows that a Guest Client is active and visible to Sensor(s).
	Guest Client-Inactive: This icon shows that a Guest Client that was earlier visible to Sensor(s) is inactive.
	Uncategorized Client-Active: This icon shows that an Uncategorized Client is active and visible to Sensor(s).


	Uncategorized Client-Inactive: This icon shows that an Uncategorized Client that was earlier visible to Sensor(s) is inactive.
	DoS Attacker: This icon shows the device from which the DoS attack is being launched.
	Client in Adhoc Mode-Active: This icon shows that a Client in adhoc mode is active and visible to Sensor(s).
	Client in Adhoc Mode-Inactive: This icon shows that a Client that was earlier in adhoc mode and visible to Sensor(s) is inactive.
	AirTight Mobile Installed-Active: This icon shows that AirTight Mobile is installed and active on the Client.
	AirTight Mobile Installed-Inactive: This icon shows that AirTight Mobile is installed but is inactive on the Client.
	AirTight Mobile Risk Level-High: This icon shows that AirTight Mobile is installed on the Client and the risk level on that Client is high.
	AirTight Mobile Risk Level-Medium: This icon shows that AirTight Mobile is installed on the Client and the risk level on that Client is medium.
	AirTight Mobile Risk Level-Low: This icon shows that AirTight Mobile is installed on the Client and the risk level on that Client is low.
	AirTight Mobile Report Available: This icon indicates that a AirTight Mobile report generated earlier is available for the selected Client.
	AirTight Mobile Report Not Available: This icon indicates that a AirTight Mobile report is never generated for the selected Client.
	AirTight Mobile Report Scheduled: This icon indicates that a SAFE report will be generated for the selected Client when it become active.
	Sensor-Active: This icon shows that the Sensor is connected to the Server and is actively monitoring the network. This Sensor has the latest software version and does not need to be upgraded.
	Sensor-Inactive: This icon shows that the Sensor is not connected to the Server and is currently not monitoring the network. This Sensor has the latest software version and does not need to be upgraded
	Sensor Upgrade In Progress: This icon shows that Sensor Upgrade is in progress.
	Sensor Upgrade Required: This icon shows that the Sensor needs to be upgraded to a new version.
	Sensor Upgrade Failed: This icon shows that the Sensor upgrade to a new version has failed.
	Sensor Indeterminate: This icon shows that the Sensor is in an indeterminate or irrecoverable state.
	Network Detector-Active: This icon shows that the ND is connected to the Server and is currently contributing into wired detection of APs.
	Network Detector-Inactive: This icon shows that the ND is not connected to the Server and is currently not contributing into wired detection of APs.
	AP/Sensor Combo-Active: This icon indicates that the AP/Sensor combo device is connected to the Server and is monitoring the network.
	AP/Sensor Combo-Inactive: This icon indicates that the AP/Sensor combo device is connected to the Server and is inactive.
	RSSI Level 0: This icon shows very low signal available.
	RSSI Level 1: This icon shows low signal strength.
	RSSI Level 2: This icon shows medium signal strength.

	RSSI level 3: This icon shows strong signal strength
	RSSI Level 4: This icon shows very strong signal strength.
	Display Columns: Most fields in the table can be selected for display or optionally hidden. This button allows selection and configuration of parameters to show and hide in the table.
	Monitored Network: This icon indicates that the network is being monitored by a sensor.
	Unmonitored Network: This icon indicates that the network is not being monitored by a sensor.
	Approved Smart Device: This icon indicates that the authorized client is an approved smart device.
	Unapproved Smart Device: This icon indicates that the authorized client is an unapproved smart device.
	Change Device Type: This icon indicates a change in the smart device type.
	Smart Device: This icon indicates that the guest client is a smart device.












Following is a list of the event related icons seen on AirTight Management Console.

Icon	Description
	High: This icon indicates an event with high severity.
	Medium: This icon indicates an event with medium severity.
	Low: This icon indicates an event with low severity.
	New: This icon indicates an event that is neither read nor acknowledged.
	Read: This icon indicates that the event has been read.
	Acknowledged: This icon indicates that the event has been read and acknowledged.
	Live: This icon indicates a live event in which the triggers that raised the event are operational or continue to exist; this event has a valid start time stamp.
	Live and Updated: This icon indicates a live event that has been updated, that is, some activity has occurred since the event was last read.
	Instantaneous: This icon indicates an instantaneous event that are triggered based on a trigger that do not have continuity.
	Expired: This icon indicates an expired event in which the triggers that raised the event are not operational or have ceased to exist; this event has a valid start and stop time stamp.
	Secure: This icon indicates an event that does not contribute to the vulnerability status of the system.
	Vulnerable: This icon indicates an event that contributes to the vulnerability status of the system.
	Interference device/jammer icon: This icon shows the device which is RF Jammer or source of non-Wi Fi interference.

Following is a list of the location related icons seen on AirTight Management Console.

Icon	Description
	This icon indicates a location folder.

AirTight Management Console User Guide

	This icon indicates a location floor.
	This icon indicates an unknown location floor.
	This icon indicates root location.
	This icon indicates a secure location floor.
	This icon indicates a vulnerable location floor.
	This icon indicates a secure location folder.
	This icon indicates a vulnerable location folder.
	This icon indicates a vulnerable root location.
	This icon indicates a secure root location.
	This icon indicates a vulnerable unknown location floor.
	This icon indicates a secure unknown location floor.

Industry Canada Statement

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-210 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

Caution:

(i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

(ii) high-power radars are allocated as primary users (i.e. priority users) of the bands 5250-5350 MHz and 5650-5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

Avertissement:

(i) les dispositifs fonctionnant dans la bande 5 150-5 250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;

(ii) De plus, les utilisateurs devraient aussi être avisés que les utilisateurs de radars de haute puissance sont désignés utilisateurs principaux (c.-à-d., qu'ils ont la priorité) pour les bandes 5 250-5 350 MHz et 5 650-5 850 MHz et que ces radars pourraient causer du brouillage et/ou des dommages aux dispositifs LAN-EL.

FOR MOBILE DEVICE USAGE (>20cm/low power)

Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator and your body.

Declaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

For operation within 5.15 ~ 5.25GHz / 5.47 ~ 5.725GHz frequency range, it is restricted to indoor environment. The band from 5600-5650MHz will be disabled by the software during the manufacturing and cannot be changed by the end user. This device meets all the other requirements specified in Part 15E, Section 15.407 of the FCC Rules.

FOR MOBILE DEVICE USAGE (>20cm/low power)

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

FOR COUNTRY CODE SELECTION USAGE (WLAN DEVICES)

Note: The country code selection is for non-US models only and is not available to all US models. Per FCC regulations, all Wi-Fi products marketed in the US must be fixed to US operation channels only.

