



Zinwave 3000 Distributed Antenna System Tune-up Guide

3000_DAS_TG_v-08



© Zinwave Ltd. 2008

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Zinwave Ltd. as governed by United Kingdom and international copyright laws.

Edition

Issue 3000_DAS_TG_v-08, October 2008

Warranty

The material contained in this document is provided “as is,” and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Zinwave disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Zinwave shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Zinwave and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

Technology licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Trademark acknowledgements

All trademarks are the property of their respective holders.

1.1 Detailed Hub configuration

This guide explains how to:

- Configure the Hub from the standalone PC (don't forget to change the standalone PC's IP address to be on the same subnet)
- Connect the Hub to your LAN and access the web configuration GUI from any network-attached PC.

1.1.1 Log in to the web configuration GUI

- 1 Knowing the Hub's IP address, log back into the web configuration GUI.
- 2 For example:
 - If you gave the Primary Hub the static IP address 10.10.10.5, you log in from the URL <https://10.10.10.5>
 - If you changed the Hub to be a DHCP client, you need to discover its IP address from the lookup table on your DHCP server (you'll need to know the Hub's MAC address). DHCP server instructions are beyond the scope of this manual.
- 3 For now, log in as the *advanced* user with the default password (supervisor).

1.1.2 Set the date, time and passwords

- 1 In the web configuration GUI, display the Hub Setup page.
- 2 Set the date and time and click **Update**.
- 3 Change the default passwords for basic and advanced users and click **Set Password**.

Hub Setup

Date and Time

Time: 11:26:11
Date: 24/7/2008
Click to update: Update

Password

User: advanced
Enter basic password: _____
Re-enter basic password: _____
Enter advanced password: _____
Re-enter advanced password: _____
Click to update: Set Password

1.1.3 Set up the operating parameters and switching matrix

- 1 Display the System Setup page.

This shows the switching matrix for your system (which Service inputs are connected to which outputs on the Primary Hub. Lower down the page there are configuration options for the Secondary Hub and any RUs. Initially, all settings are defaults.

zINWAVE Series 3000 Connected to Primary Hub 'Primary'

System Setup

PH

	A	B	C	D	
Module Type:	Service	Empty	Service	Empty	
Module State:	Enabled		Disabled		
Input power (dBm):	0		0		
Overload margin (dB):	20		20		
Relative Power per Service:	0		16		
Uplink/Downlink Balance:	0		0		
Label:	Test port		DCS 1800 Opt		
Carrier:	1		1		
	Q		Q		Enabled SH1
					Empty
					Empty
					Empty
					Empty
					Empty
					Empty
Hub label:	Primary				

Load Primary Hub Settings

- 2 Tell the system which of the available Service inputs you want it to use by setting them to **Enabled**.
- 3 For each Service, select the Input power in dBm. This is the value that you know you should be getting from the donor Service. We assume 0dB, but change this if necessary.

Caution: The Input power must not exceed the safe operating limit of +25dBm.



- 4 Set the Overload margin.

This is in effect an alarm threshold for input power. If, for example, you had your system all set up then added another Service, your input power might rise by 3dB. You might set the Overload margin to 3dB to flag this. Alternatively, you might want to know whenever the input power level changed, for any reason, in which case you'd set the Overload margin to a very low threshold.
- 5 Set the Relative Power per Service.

Here you are setting the relative power level for each Service, based on values you should have calculated as part of your system design. This should take into account all Service inputs that contribute to the composite power level.

The maximum that all Services can add up to is 18dBm in Europe and 20dBm in the USA & Canada (the maximum power that an RU can handle). The maximum EIRP is 20dBm for WLAN in Europe and 28dBm for all approved services in USA & Canada. This corresponds to antenna gains of 2dBi for WLAN in Europe and 8dBi for USA & Canada.
- 6 Set the Uplink/Downlink balance.

Set the relative gain according to your system design parameters.
- 7 Enter a label (name) for each Service (e.g. Tetra, or DCS 1800).
- 8 Set the number of carriers for each Service.
- 9 Enable or disable the links to the Secondary Hub as appropriate.
- 10 Click to tick (enable) boxes in the switching matrix. This is where you tell the system which Services are output on which link.
- 11 Enter a label (name) for the Primary Hub.
- 12 Click **Load Primary Hub Settings** below the Primary Hub table to make your settings take effect.

1.1.4

Set up the Secondary Hubs

Note: You'll need to follow the steps in this section for each Secondary Hub in turn.

- 1 On the System Setup page, scroll to the Secondary Hub table.

SH1

	A	B	C	D		
Module Type:	Empty	Enabled	Empty	Empty		
Module State:		Enabled				
Label:					Enabled	RU11
	■	■	■	■	Empty	
	■	■	■	■	Empty	
	■	■	■	■	Empty	
	■	■	■	■	Empty	
	■	■	■	■	Empty	
Hub label:						

Load Secondary Hub Settings

- 2 Enter a label (name) for the Secondary Hub.
- 3 Set up your switching matrix (which Optical Link Modules are connected to which RU Drive Module).
- 4 Enter a label (name) for the Secondary Hub.
- 5 Click **Load Secondary Hub Settings** below the Secondary Hub table to make your settings take effect.
- 6 Repeat steps 1 through 5 for other Secondary Hubs (each will have their own table).

1.1.5

Set up the RUs

- 1 On the System Setup page, scroll to the RU table.

There is one row per RU in this table. Set up all the RUs before loading the settings.

RU Table

Label	Downlink Power	Uplink Power	RU Tx State
RU11	0	0	Enabled

Load Remote Units Settings

- 2 Enter a label (name) for the RU.
- 3 Set the Downlink power.
- 4 Set the upper limit for the Uplink power.
This value should come from your system design. It limits the power back from the RU, and is also an alarm threshold.
- 5 Set the RU Tx state (Enabled or Disabled).
- 6 If necessary, repeat steps 2 through 5 for other RUs in the table.
- 7 Click **Load Remote Unit Settings** below the RU table to make your settings take effect.

1.1.6

Run Autosetup

So far, we have applied configuration changes to the Hubs, but the system has not made any automatic gain calculations or 'switched on' the RF.

- 1 At the bottom of the System Setup page, click **Validate**.

Autosetup
[Click to validate settings:](#) [Validate](#)

The system will automatically make gain calculations, based on the values you've supplied. It will take into account any path losses due to cable lengths.

- 2 When you calculations are complete, you'll see the downlink power available to each RU.

Name	Downlink Power
RU11	0

Go back Apply

- 3 If there are no errors, click **Apply**.

If there are errors, click **Go Back** to return to the System Setup page and check the settings. Click **Validate** again once you're sure they're OK.

Once the settings have been applied and there are no errors, the System Setup page will redisplay. Note that, now the settings are correct, you can't edit them (as the system is operational, with those values in operation):

Series 3000
 ZINWAVE Connected to Primary Hub 'Primary'

System Setup

System Operational with Validated Settings

Click to make changes: [Change system setup](#)

User: advanced

	A	B	C	D
Module Type:	Service	Empty	Service	Empty
Module State:	Enabled		Disabled	
Input power (dBm):	0		0	
Overload margin (dB):	20		20	
Relative Power per Service:	0		16	
Uplink/Downlink Balance:	0		0	
Label:	Test port		DCS 1800 Opt	
Carrier:	1		1	

- 4 Once you've finished, take a look at the System Status page. Click on the links to see detailed status information for a particular unit.

Series 3000
 ZINWAVE Connected to Primary Hub 'Primary'

System Status

Module Status

Type: Optical
 Slot: 1
 SW Version: 2.03
 HW Version: 0.00
 Serial Number:
 Label:
 Alarm Count: 0
 Comms: Yes
 Uplink Optical Power (uW): 3948
 Downlink Optical Power (uW): 359
 Uplink CAL (dB): -6.0
 Downlink CAL (dB): -6.0
 Current I (mA): 1
 Voltage 1 (mV): 3264
 Temperature (Celsius): 23.0
 Alarms: None
 Module State: [Open]
 Uplink Gain (dB): 6
 Downlink Gain (dB): -8
 Click to update: [Update](#)

1.1.7

Changing the System Setup

Once you've clicked **Validate** and made your settings active, they are not immediately editable in the System Setup page. If you want to make more changes, you can do so by clicking the **Change System Setup** button at the top of the System Setup page.

System Setup

System Operational with Validated Settings

Click to make changes: [Change system setup.](#)

PH

	A	B	C	D
Module Type:	Enabled	Empty	Enabled	Empty
Module State:	Enabled	Disabled	Disabled	Disabled
Input power (dBm):	0		0	
Overload margin (dB):	20		20	
Relative Power per Resource:	0		16	

