

Advanced Features

Pandora

Brief introduction

Pandora is a personalized radio service that streams music on your TV. Just start with the name of one of your favorite artists, songs, comedians, or composers and Pandora will create a custom station that plays similar tracks. Pandora features hundreds of music and comedy genre stations. Create up to 100 stations so you can easily switch between favorites.

For enjoying more movies, please register and log in to your account.

Operation introduction

1. Press the [HiSmart] button to display home menu.
2. Press [Left/Right] button to select the Pandora icon and press [ENTER] to enter it.
3. Input Email and Password in following window to sign in. (Refer to "How to Input the Email Address" on page 23)
4. Press [Up/Down/Left/Right] button to move the cursor to select service items in the Pandora home page, and [ENTER] button to confirm.
5. Press [RETURN] button to return the upper menu, or press [EXIT] button to close the menu.

NOTE

Pandora is available in select countries.

Twitter

Operation introduction

1. Press the [HiSmart] button to display the home menu.
2. Press [Left/Right] button to select the Twitter icon and press [ENTER] to enter it.
3. Input Email and password in the following window to sign in.
4. Press [Up/Down/Left/Right] button to move the cursor to select service items in the Twitter home page, and [ENTER] button to confirm.
5. Press [RETURN] button to return the upper menu, or press [EXIT] button to close the menu.

Picasa

Brief introduction

With Picasa you can explore featured photos in Google Picasa Web Album, also you can search your favorite photos in Google Picasa Web Album. If you have already had a Google Picasa account, you can enjoy your private photos stored in Google Picasa Web Album.

Operation introduction

1. Press the [HiSmart] button to display home menu.
2. Press [Left/Right] button to select the Picasa icon and press [ENTER] to enter it.



3. Press [Up/Down/Left/Right] button to move the cursor to select service items in Picasa screen and [ENTER] button to confirm.
4. To use other features, press the button showed in the help bar.

5. Press [RETURN] button to return to the upper menu, or [EXIT] button to close the App.



Advanced Features

Digital Media Player (HiMedia)

Please note that Hisense does not assume any responsibility for any lost data and cannot guarantee perfect compatibility with all mass storage devices. Be sure to insert the USB disk with standard USB2.0 port or to connect the TV with other digital devices via DLNA (Menu >Network >Applications >DLNA) or SugarSync.

- Press the [INPUT] button to display the Source menu, press the [Up/Down] buttons to highlight the HiMedia source, then press the [ENTER] button to confirm. (If you want to exit HiMedia, you can press the [INPUT] button to switch to other sources).



- Press the [HiMedia] button to enter the HiMedia mode directly. Or press the [HiSmart] button to enter.
- In the HiMedia screen you can press the [Left/Right] select the Picture/Video/Music option, then press [ENTER] to enter/play the folder/file.

NOTE

The first play the SugarSync option file .you need to register <http://www.sugarsync.com> and login successfully.

- Press [RETURN] to return to the previous directory.
1. Press the [Up/Down] buttons to switch the media type.
 2. Press the [YELLOW / BLUE] buttons to turn to the previous / next page.
 3. Press the [Up/Down/Left/Right] buttons to select the folder/file you want to open and then press the [ENTER] button to enter/play the folder/file.
 4. Press the [RETURN] button to return to the previous directory.

Playable format list

Files Format	Playable format
Photo	.jpg
Music	.avi (mp3,mpeg,ac3) ,.mp4 ,.rm
Video	.avi (H.264, MPEG, Divx) ,.mkv (H.264, MPEG) ,.flv ,.mpeg ,.wmv (Divx, XviD)

NOTE

We can not promise that this unit will support all the formats listed above, as the programming tools are different.

Browse Pictures


1. Press the [Left] button to switch to All or Picture.
2. Press the [Up/Down/Left/Right] buttons to select the picture you want to view.
3. Press the [ENTER] button to display picture.
4. Press the [Left/RETURN] buttons to exit or return to the previous directory.

When browsing the pictures.

- Press the [DISPLAY] button to display/exit the picture control bar.
- Press the [Left/Right] buttons to select the function icon and then press the [ENTER] button to confirm.



1. Browse the previous picture. You can also press the [Left/Right] buttons in the remote control directly when no control bar displays on the screen.
2. Browse the next picture. Press the [Right/Left] buttons directly in the remote control when no control bar displays on the screen.
3. Rotate the picture 90 degrees clockwise.
4. Rotate the picture 90 degrees anticlockwise.
5. Play/pause. Press the [Play/Pause] button directly when no control bar displays on the screen.
6. Stop browsing the picture. You can press the [Left] button directly in the remote control when no control bar on the screen.
7. Zoom in the picture.
8. Zoom out the picture.
9. Option Set. Press the [Up/Down] buttons to select the options and press the [Left/Right] buttons to set them.



- Speed - Allows you to browse the picture at different speed, such as Fast, Slow, and Medium.
- Effect - Select transition effects between images, such as: random, Box in, Box out, Wipe right, Wipe left, Wipe up, Wipe down, Dissolve, and None.

10. Picture info. Displays information about the pictures.

Advanced Features


Enjoy Video Files

1. Press the [Left] button to switch to All or Video.
2. Press the [Up/Down/Left/Right] buttons to select the video you want to view.
3. Press the [ENTER] button to play the video.
4. Press the [Left/RETURN] buttons to exit and return to the previous directory.
5. Press the [DISPLAY] button to display/exit the video control bar.
6. Press the [Left/Right] buttons to select the function icon and then press the [ENTER] button to confirm.

Function of icons:



1. The progress bar when playing.
2. Play/Pause. You can press the [Play/Pause] button directly to play/pause when there is no control bar on the screen.
3. Play the previous video. You can press the [Left] button directly to achieve the function when no control bar displayed on the screen.
4. Play the next video. You can press the [Right] button to achieve the function when no control bar displayed on the screen.
5. Fast backward. Then press the [ENTER] button to select the backward speed. You can press the [Left] button to achieve the function.
6. Fast forward. Then press the [ENTER] button to select the forward speed. You can press the [Right] button to achieve the function.
7. Select time to play
 - Press the [Left/Right] buttons to select the position you want to set.
 - Press the [0-9] buttons to set the time and press the [Up/Down/Left/Right] buttons to adjust it.
- Press the [ENTER] button to confirm and the video will to play at the time you have set or press the [RETURN] button to exit.
8. Play list
 - Press the [YELLOW/BLUE] buttons to page up/page down and press the [Up/Down] buttons to select the video.
 - Press the [ENTER] button to confirm.
9. Options



- Press the [Up/Down] buttons to select the options in the menu.
- Press the [Left/Right] buttons to select the settings.
- Press the [ENTER] button to confirm.

1. Program info
 - Allows you to view the program information.
2. Stop playback

NOTE

You can press the [ASPECT] button to change the aspect ratio (Normal, Full Screen, Original Size) while playing the video.

Enjoy Music Files

1. Press the [Left] button to switch to All or Music.
2. Press the [Up/Down/Left/Right] buttons to select the music you want to view.
3. Press the [ENTER] button to play the music.
4. All the music is listed on the left. Press the [Up/Down] buttons to select the music and press the [Right] button to mark it. You can press the [YELLOW/BLUE] buttons to turn to the previous/next page. Press the [GREEN] button to select the Mode: Mark / All / Single.
5. Press the [RETURN] button to exit the music playback interface.

Other Information

Troubleshooting

If you experience difficulties while using the TV, please check the table below for possible solutions.

SYMPTOMS	POSSIBLE SOLUTIONS
No sound or picture.	<ul style="list-style-type: none"> • Check if the power cord is in the AC outlet and if it has electricity. • Check if you have pressed [POWER] button on the TV or [POWER] button on the remote control.
I have connected an external source to my TV and I get no picture and/or sound.	<ul style="list-style-type: none"> • Check for the correct output connection on the external source and for the correct input connection on the TV. • Make sure you have made the correct selection for the input mode for the incoming signal.
When I turn on my television, there is a few second delay before the picture appears. Is this normal?	Yes, this is normal. That is the TV searching for previous setting information and initializing the TV.
Picture is normal, but no sound.	<ul style="list-style-type: none"> • Check the volume settings. • Check if Mute mode is set "on".
Sound but no picture or black and white picture.	<ul style="list-style-type: none"> • If black and white picture first unplug TV from AC outlet and replug after 60 seconds. • Check Color Setting if picture is black and white.
Sound and picture distorted or appear wavy.	<ul style="list-style-type: none"> • An electrical appliance may be affecting TV set. Turn off any appliances, if interference goes away, move appliance farther away from TV. • Insert the power plug of the TV set into another power outlet.
Sound and picture is blurry or cuts out momentarily.	<ul style="list-style-type: none"> • If using an external antenna, check the direction, position and connection of the antenna. • Adjust the direction of your antenna or reset or fine tune the channel.
Horizontal/vertical stripe on picture or picture is shaking.	Check if there is interfering source nearby, such as appliance or electric tool.
The plastic cabinet makes a "clicking" type of sound.	"Click" sound can be caused when the room temperature changes. This change causes the television cabinet to inflate or contract, which makes the sound. This is normal and TV is OK.
Black square appears in the center of my television screen?	The Closed Caption function is set in the text mode. To remove it, access Closed Caption from the menu screen and change the Mode setting from text to either CC1 or off .
On some channels getting another language or sometimes no sound at all.	<ul style="list-style-type: none"> • That would indicate that the MTS mode on your unit is set to SAP mode. We suggest setting the MTS mode to either Stereo or Mono . For further instruction, please see Audio Adjust or MTS/SAP in your user manual. • SAP is Second Audio Program. It's a second audio channel that is usually used for a second language or descriptive audio for the visually impaired. • MTS stands for Multichannel Television Sound, a standard that allows the encoding of 3 channels of audio within a standard NTSC (analog) video signal to a television. A television that is able to receive MTS Stereo allows you to watch television with stereo sound.

Other Information

SYMPTOMS	POSSIBLE SOLUTIONS
<p>Not getting all of my cable channels on the television or I'm only getting 13 channels.</p>	<ul style="list-style-type: none"> ⦿ Check the cable connection for an incoming signal. Make sure the signal is coming OK. Best way to confirm signal is to use another TV and/or contact your cable company. ⦿ Reprogram your channels. Press [MENU] button on your TV remote control, change Input Source setting to "Cable", then use "Auto Channels Search" to reprogram your channels.
<p>[CH \wedge / V] don't work when I set the Channel to Cable? They work with the Air setting?</p>	<p>After switching to Cable, please auto program the channels. The TV will "remember" all the channels then the TV will allow you to surf the channels with [CH \wedge / V] buttons.</p>
<p>Remote control does not work.</p>	<ul style="list-style-type: none"> ⦿ Confirm that TV still has power and is operational. ⦿ Change the batteries in the remote control. ⦿ Check if the batteries are correctly installed. ⦿ Clean the front of the remote control (LED window). ⦿ If using a universal remote, be sure to select the TV mode on the remote. ⦿ If the remote still does not work: <ul style="list-style-type: none"> • Remove and reinstall the batteries correctly to reset the remote or install new batteries. • Press the Power button to turn on the TV. With a universal remote if you have reset or changed the batteries you will need to reprogram the remote for the other units. ⦿ Check if there is obstruction between the remote control and the TV. <p>TIP: If you have a digital camera / camera phone, you can aim the front of the remote at camera lenses (at this time, the camera should set on camera mode, not play mode). Observe the camera screen while pressing a button on the remote control; you should see flashing light on the screen. If there is no light observed, the remote control is not working. You need to repair or replace the remote control.</p>