



# CASTLES TECHNOLOGY

*MP200 Mobile POS*

---

*Book 2*

***User Manual***

**Confidential**

*Version 2.4*

*Aug 2018*

**Castles Technology Co., Ltd.**

6F, No. 207-5, Sec. 3, Beixin Rd., Xindian District,  
New Taipei City 23143, Taiwan R.O.C.

<http://www.castech.com.tw>

# WARNING

Information in this document is subject to change without prior notice.

No part of this publication may be reproduced, transmitted, stored in a retrieval system, nor translated into any human or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of **Castles Technology Co., Ltd.**

All trademarks mentioned are proprietary of their respective owners.

## Revision History

<i>Version</i>	<i>Date</i>	<i>Descriptions</i>
1.0	Sep 10, 2014	Initial creation.
2.0	Dec 19, 2014	<ol style="list-style-type: none"> <li>1. Add "Key Injection" on "System Menu" page</li> <li>2. UI arrangement on "SYSTEM INFO" page</li> <li>3. Add "BT DIRECT ACCESS", "Halt Timeout", "PWM Auto", "PWM Mode", "PWM Time" on "SYS SETTINGS" page</li> <li>4. UI arrangement on "Test Utility" page</li> </ol>
2.1	Feb 12, 2015	<ol style="list-style-type: none"> <li>1. Add the description of Environment.</li> <li>2. Add the description of Power.</li> <li>3. Add the UL caution of battery.</li> </ol>
2.2	Sep 06, 2016	<ol style="list-style-type: none"> <li>1. Add "2.4. Wireless communication".</li> </ol>
2.3	Mar 06, 2018	<ol style="list-style-type: none"> <li>1. Add warnings to "2.3 Power".</li> </ol>
2.4	Aug 08, 2018	<ol style="list-style-type: none"> <li>1. Remove "GPRS" and "UMTS" from 2.4 Wireless communication.</li> <li>2. Modify the description of RF Exposure Warning form "20 centimeters" to "5 centimeters".</li> </ol>

# Contents

<b>1. Introduction</b> .....	<b>6</b>
<b>2. Hardware Setup</b> .....	<b>7</b>
2.1. Parts of the Surface .....	7
2.2. Environment .....	9
2.3. Power .....	9
2.4. Wireless communication .....	9
<b>3. Basic Operation</b> .....	<b>10</b>
3.1. Program Manager.....	10
3.2. Download AP .....	12
3.3. System Info.....	13
3.4. Memory Status .....	14
3.5. System Settings.....	15
3.6. Test Utility.....	18
3.7. Factory Reset .....	20
3.8. Power Off .....	21
3.9. Function Key Password Change.....	22
3.10. Share Object Management .....	23
3.11. Castles TMS.....	24
3.12. Font Mng .....	25
3.13. Debug Tools .....	26
3.14. ULD Key Hash.....	27
3.15. Plug-in Mng .....	28
3.16. Key Injection.....	29
<b>4. Secure File Loading</b> .....	<b>30</b>
4.1. ULD Key System .....	30
4.1.1. ULD Manufacturer Key.....	30
4.1.2. ULD User Key .....	32
4.1.3. Key Change .....	32
4.2. File Signing.....	33
4.2.1. Signing Kernel Module .....	33
4.2.2. Signing User Files .....	35
4.3. File Loading .....	39
4.3.1. Download by User Loader.....	39

4.4.	Changing ULD User Key.....	42
<b>5.</b>	<b>Font Management .....</b>	<b>49</b>
5.1.	Loading New Font.....	49
5.2.	Custom Font.....	52
5.3.	Using TrueType Font (TTF) .....	60
<b>6.</b>	<b>FCC Warning .....</b>	<b>62</b>
	FCC Caution.....	62
	RF Exposure Warning.....	62

# 1. Introduction

This document provides a guideline on operating and configuring Castles MP200 Mobile POS.

The scope of this document includes setting up the terminal, basic operation, application life cycle, and some advance features.

## 2. Hardware Setup

### 2.1. Parts of the Surface


Front Side



MP200

- |   |                   |
|---|-------------------|
| 1. LCD Display (Mono Color)                   | 6. Power Key      |
| 2. Keyboard                                   | 7. Up Key         |
| 3. Cancel Key                                 | 8. Down Key       |
| 4. 0 / Funtion Key                            | 9. OK / Enter Key |
| 5. Contactless Card Landing<br>Zone Enter Key | 10. Clear Key     |

Rear Side



**11. Machine's Label**

Up Side



**12. MSR**  
**13. SCR**

bottom Side





Side



- 14. Power LED (Charging: Orange light, Fully charged: Green light)
- 15. Micro USB Socket

## 2.2. Environment

**Operating Temperature :** 0°C to 50°C

**Storage Temperature :** -20°C to 70°C

**Operating Humidity :** 5% to 90% non-condensing

**Storage Humidity :** 5% to 95% non-condensing

## 2.3. Power

Input : 5V, 1A

This product is intended to be supplied by a Listed Power Adapter rated output 5Vdc, min. 1A, Tma is 40 degree C minimum.

## 2.4. Wireless communication

1. WiFi 802.11 bg / WiFi 802.11 n
2. Contactless Reader (NFC) Working Frequency 13.56MHz.
3. Bluetooth

**CAUTION**

**RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.**

**DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS**

## 3. Basic Operation

### 3.1. Program Manager

Upon power on, terminal will enter Program Manager if not default application selected. All user applications are list in Program Manager. User may select an application and run the application or view the application info, delete the application or set to default run upon power on. User may enter System Menu to configure terminal settings.

#### Program Manager

```
Program Manager
-----01/02
1.App1
2.App2

0:Download
```

- Press [0] button to enter System Menu.
- Press [1] button to toggle default application selection.
- Press [2] button to delete application.
- Press [3] button to view application info.
- Press [OK] button to run application.
- Press [↑] or [↓] to select application.


#### System Menu

*Page 1*

```
System Menu
1.Download AP
2.System Info
3.Memory Status
4.Sys Settings
5.Test Utility
6.Factory Reset
7.Power Off
```


- Press [↓] button to page 2.

*Page 2*



- Press [↑] button to page 1.
- Press [↓] button to page 3.

*Page 3*



- Press [↑] button to page 2.

## 3.2. Download AP

Download user application or kernel modules firmware.

### System Menu

```
System Menu
1.Download AP
2.System Info
3.Memory Status
4.Sys Settings
5.Test Utility
6.Factory Reset
7.Power Off
```

- Press [1] button to enter Download AP menu.

### Download AP Menu

```
Download EX
1.RS232 or USB
2.USB Disk
3.SD Card

Select DW Source
```

Select download source:

- Press [1] button to select source as RS232 or USB connection and enter ULD download mode.
- Press [2] button to select source as USB disk.
- Press [3] button to select source as SD card.

### 3.3. System Info

View kernel module firmware information.

#### System Menu

```

System Menu
1.Download AP
2.System Info
3.Memory Status
4.Sys Settings
5.Test Utility
6.Factory Reset
7.Power Off
    
```

- Press [2] button to enter System Info menu.

#### System Info Menu

Page 1

```

SYSTEM INFO
---Kernel Ver---
BIOS      :VR0010
SULD      :VRF810
LINUXKNL  :VR0019
ROOTFS    :VR9201
    
```

Page 2

```

SYSTEM INFO
--- KO Ver ---
SECURITY  :VR0025
KMS       :VR0024
DRV       :VR0039
USB       : N/A
SAM       :VR0028
CL        :VR0018
    
```

Page 3

```

SYSTEM INFO
--- KO Ver2 ---
SC        :VR0011
    
```

- Press [↓] button to next page.

Page 4

```

SYSTEM INFO
--- SO Ver ---
UART      :VR0014
USBH      :VR0011
MODEM     :VR0014
ETHERNET  :VR0029
FONT      :VR0025
LCD       :VR0034
    
```

Page 5

```

SYSTEM INFO
--- SO Ver2 ---
PRT       :VR0020
RTC       :VR0013
ULDPM     :VR0022
PPP MODEM:VR0026
KMS       :VR0022
FS        :VR0015
    
```

Page 6

```

SYSTEM INFO
--- SO Ver3 ---
GSM       :VR0018
BARCODE   :VR0013
TMS       :VR0013
TLS       :VR0011
CLVW     :VR0018
CTOSAPI   :VR9029
    
```

Page 8

```

SYSTEM INFO
--- HWM Ver ---
CRDL/ETHE:ONCHIP
CLM-MP    : N/A
--- AP Ver ---
ULDPM     :VR0026
    
```

Page 9

```

SYSTEM INFO
HUSB ID:0CA6A050
CUSBID    : N/A
--Factory S/N---
FFFFFFFFFFFFFFFF
    
```

Page 10

```

SYSTEM INFO
--EXT SO Ver P.1--
CACLMDL   :VRg103
CACLENTRY :VRg103
CAMPP     :VR0302
CAVPW     :VR0014
CAEMVL2   :VR9113
CAEMVL2AP :VR0005
    
```

## 3.4. Memory Status

View terminal flash memory and RAM information.

### System Menu

```
System Menu
1.Download AP
2.System Info
3.Memory Status
4.Sys Settings
5.Test Utility
6.Factory Reset
7.Power Off
```

- Press [3] button to enter Memory Status menu.

### Memory Status Menu

```
MEMORY STATUS
--FLASH Memory--
Total: 130688KB
Used : 96648KB

--SDRAM Memory--
Total: 65408KB
Used : 32148KB
```

## 3.5. System Settings

View or change terminal system settings.

<b>Setting</b>	<b>Descriptions</b>
Key Sound	Enable (Y) or disable (N) the beep sound when pressing any key.
Exec DFLT AP	Enable (Y) or disable (N) execution of default selected application.
USB CDC Mode	Enable (Y) or disable (N) USB CDC mode.
FunKey PWD	Enable (Y) or disable (N) password protection to access function key (0 ~ 3) in Program Manager.
PMEnter PWD	Enable (Y) or disable (N) password protection to enter Program Manager.
SET USB Host	Enable (Y) or disable (N) USB host mode.
Base USB CDC	Enable (Y) or disable (N) USB CDC mode in base unit. [Portable model only]
List SHR Lib	Enable (Y) or disable (N) to list all shared libraries in Program Manager.
Key MNG Mode	<TBC>
BAT Threshld	Battery charging threshold value. [Portable model only]
Null Cradle	Enable (Y) if base is Type A cradle. [Portable model only]
Debug Mode	Enable (Y) or disable (N) console debug mode.
Debug Port	Serial port for console debug.
Mobil AutoON	Enable (Y) or disable (N) to auto turn on GSM module after start up the terminal.
Bklit Auto Off	Enable (Y) or disable (N) Auto Off LCD Backlight
Bklit Off Time	Threshold of Auto Off LCD Backlight
PWR KEY OFF	Power key function, power off (Y) or reboot(N)
GDB Mode	Enable (Y) or disable (N) GDB mode.
GDB Timeout	GDB connection timeout.
GDB Channel	GDB connection channel.
ETHER IP/PORT	GDB Ethernet connection setting.
RTC Time Zone	Set Time Zone of Real Time Clock.
NTP Enable	Enable (Y) or disable (N) Network Time Protocol.

NTP Update Freq	Frequency of Network Time Protocol updating.
BT DIRECT ACCESS	Enable (Y) or disable (N) Bluetooth direct access mode.
Halt Timeout	Set timeout for AP to back to Program Manager whenever AP is in halt state.
PWM Auto	Enable (Y) or disable (N) power saving mode.
PWM Mode	Select (STB) standby mode or (SLP) sleep mode for power saving mode.
PWM Time	Set time period by which to make terminal getting into power saving mode from idle state.

### System Menu

<b>System Menu</b>
1.Download AP
2.System Info
3.Memory Status
4.Sys Settings
5.Test Utility
6.Factory Reset
7.Power Off

- Press [4] button to enter System Settings menu.

### System Settings Menu

#### *Page 1*

<b>SYS SETTINGS</b>	
Key Sound	: Y
Exec DFLT AP	: Y
-Default AP Name	
USB CDC Mode	: Y
FunKeyPWD	: N
PMEnterPWD	: N
2: Next Page	

#### *Page 2*

<b>SYS SETTINGS</b>	
SET USB Host	: N
Base USB CDC	: X
List SHR Lib	: N
Key MNG Mode	: 0
Bat Threshld	: X
Null Cradle	: X
1: Prev	2: Next

#### *Page 3*

<b>SYS SETTINGS</b>	
Debug Mode	: N
Debug Port	: X
Mobil AutoON	: N
Bklit Auto Off	: N
Bklit Off Time	: X
PWR KEY OFF	: N
1: Prev	2: Next

#### *Page 4*

<b>SYS SETTINGS</b>	
GDB Mode	: N
GDB Timeout	: X
GDB Channel	: X
ETHER IP/PORT	
1: Prev	2: Next



*Page 5*

SYS SETTINGS	
RTC Time Zon	:GMT
NTP Enable	: N
NTP Update F	: X
1: Prev	2: Next

*Page 6*

SYS SETTINGS	
BT DIRECT ACCESS	:X
Halt Timeout	:999
PWM Auto	: N
PWM Mode	: X
PWM Time	: X
1: Prev Page	

- Press [↑] or [↓] button to select setting.
- Press [OK] button to change the setting value.
- Press [↔] button to toggle Y ⇌ N ⇌ Y.
- Press [1] button to previous page.
- Press [2] button to next page.

## 3.6. Test Utility

Perform terminal hardware components diagnosis.

### System Menu

```
System Menu
1.Download AP
2.System Info
3.Memory Status
4.Sys Settings
5.Test Utility
6.Factory Reset
7.Power Off
```

- Press [5] button to enter Test Utility menu.


### Test Utility Menu

Page 1

```
Main Menu 9122
1.LCD      2.KBD
3.FLASH    4.SCM
5.Light    6.MSR
7.LED      8.RTC
9.FONT     10.USB
11.BT      12.Power
->                1/2
```

- Press [1] and [OK] to diagnose LCD.
- Press [2] and [OK] to diagnose keyboard.
- Press [3] and [OK] to diagnose flash memory.
- Press [4] and [OK] to diagnose smart card module.
- Press [5] and [OK] to diagnose backlight.
- Press [6] and [OK] to diagnose magnetic stripe card reader.
- Press [7] and [OK] to diagnose LED.
- Press [8] and [OK] to diagnose RTC.
- Press [9] and [OK] to check FONT file in MP200.
- Press [10] and [OK] to diagnose USB.
- Press [11] and [OK] to check Bluetooth chip address and name.
- Press [12] and [OK] to test functionality of power saving.
- Press [↓] button to page 2.

*Page 2*



- Press [13] and [OK] to diagnose contactless card reader.
- Press [14] and [OK] to diagnose WiFi.
- Press [↑] button to page 1.

## 3.7. Factory Reset

Perform factory reset, all user application, fonts and data will be deleted.

### System Menu

```
System Menu
1.Download AP
2.System Info
3.Memory Status
4.Sys Settings
5.Test Utility
6.Factory Reset
7.Power Off
```

- Press [6] button to enter Factory Reset menu.

### Factory Reset Menu

```
Factory Reset

OK to reset ?
```

- Press [OK] button to perform factory reset.

```
Factory Reset

Password :
****
```

- Enter factory reset password. **Default password: 8418**

## 3.8. Power Off

Power off terminal.

### System Menu

```
System Menu
1.Download AP
2.System Info
3.Memory Status
4.Sys Settings
5.Test Utility
6.Factory Reset
7.Power Off
```

- Press [7] button to power off terminal.

### 3.9. Function Key Password Change

Change function key access password.

#### System Menu (Page 2)

```
System Menu
1.FK PWD Change
2.Share obj Mng
3.Castles TMS
4.Font Mng
5.Debug Tools
6.ULD KEY HASH
7.Plug-in Mng
```

- Press [1] button to enter FunKey Password menu.

#### FunKey Password Menu

```
FunKey Password
Enter Password:
****
```

- Enter current password. (*Default password is "0000"*)

```
FunKey Password
New Password:
****
Confirm Password
****
```

- Enter new password.
- Enter new password again to confirm.

```
FunKey Password
New Password:
****
Confirm Password
****
PWD Changed OK
```

## 3.10. Share Object Management

View share object in terminal.

### System Menu (Page 2)

```
System Menu
1.FK PWD Change
2.Share obj Mng
3.Castles TMS
4.Font Mng
5.Debug Tools
6.ULD KEY HASH
7.Plug-in Mng
```

- Press [2] button to enter Share Object Management menu.

### Share Object Management Menu

```
Share objMng
1.Share LIB
2.Share File
```

- Press [1] button to view shared library.
- Press [2] button to view shared file.

## 3.11.Castles TMS

Connect to TMS (Terminal Management Software) server, set or delete TMS configuration.

### System Menu (Page 2)

```
System Menu
1.FK PWD Change
2.Share obj Mng
3.Castles TMS
4.Font Mng
5.Debug Tools
6.ULD KEY HASH
7.Plug-in Mng
```

- Press [3] button to enter Castles TMS menu.

### Castles TMS Menu

```
CASTLES TMS
1.Connect Server
2.SetConfig
3.DelConfig
```


- Press [1] button to connect to TMS server.
- Press [2] button to set TMS configuration.
- Press [3] button to delete TMS configuration.



## 3.12.Font Mng


View Font Management.

### System Menu (Page 2)



- Press [4] button to view Font Management.

### FontManagment




- Press [1] button to view FNT Font list.
- Press [2] button to view TTF Font list.

## 3.13.Debug Tools


Perform the Debug Tools.

### System Menu (Page 2)




- Press [5] go to the Debug Tools Menu.

### Debug Tools



- Press [1] go get the Core Dump error from terminal.
- Press [2] go to the Debug Log Menu.

### Debug Log



- Press [1] move the Debug Log from the memory of terminal to SD card.
- Press [2] clean all the Debug Log in MP200.

### 3.14.ULD Key Hash

View ULD user key hash value.

#### System Menu (Page 2)

```
System Menu
1.FK PWD Change
2.Share obj Mng
3.Castles TMS
4.Font Mng
5.Debug Tools
6.ULD KEY HASH
7.Plug-in Mng
```


- Press [6] button to view hash value.

```
USER ENV KEY
DA9C91FE668DF4B6D637
CDBCCEC201444AA2C7FF
USER SIGN KEY
D52F36A1B569B5ABBA4F
EAEFB34BEC000101D58C
```


### 3.15.Plug-in Mng

View Plug-in Management.

#### System Menu (Page 2)



- Press [7] button to view Plug-in Management.




- Press [↑] or [↓]button to select item.
- Press [1] button to get item information.
- Press [2] button to delete item.


## 3.16.Key Injection

View Key Injection.

### System Menu (Page 3)



- Press [1] button to view Key Injection.



- Press [1] to select COM 1.
- Press [2] to select COM 2.
- Press [3] to select USB.
- Press [OK] to set port.
- Press [X] to exit.

## 4. Secure File Loading

Castles implemented an interface in terminal named User Loader(ULD) to provide secure file loading to system memory. Loading of user application, kernel firmware, font and others must use User Loader.

The loading process is secure by signing the files using ULD Key System.

### 4.1. ULD Key System

The ULD Key System uses two key sets for securely managing the kernel updating and application downloading. Each key set contains two RSA key pairs. One is used for key encryption and the other is used for signature. These two key sets are specified as below:

#### **ULD Manufacturer Key Set**

- ULD Manufacturer Key Encryption Key (RSA)
- ULD Manufacturer Signature Key (RSA)

#### **ULD User Key Set**

- ULD User Key Encryption Key (RSA)
- ULD User Signature Key (RSA)

*For MP200, the RSA key length is 2048bits.*

#### 4.1.1. ULD Manufacturer Key


The system consists of several kernel modules. These kernel modules are provided by the Manufacturer, and released in CAP format file with encryption and signing via ULD Manufacturer Keys.

The ULD Manufacturer keys are managed and maintained by the manufacturer. The manufacturer uses these keys to generate kernel CAP files for updating the system. However, the system is not permitted to be updated with these kernel CAP files directly generated by the manufacturer. This is because only the user can have the privilege to decide whether the system is to be updated. Therefore, before system

updating, the kernel CAP files must be “signed” via ULD User Key to get the user permission. For simple expression, we call the kernel CAP files generated by the manufacturer as “unsigned kernel CAP(s)” and call the kernel CAP files “signed” by the user later as “signed kernel CAP(s)”.

Notes:


1. The kernel modules are encrypted by a random-generated 3DES key, which is retrieved from the Key Encryption Block of the CAP by ULD Manufacturer Key Encryption Key, not directly encrypted by ULD RSA Key.
2. The “sign” action via ULD User Keys actually is done by “the second encryption”. “The second encryption” is done by using the random-generated 3DES key, which is encrypted by ULD User Key Encryption Key, to perform Triple DES encryption again on the cipher data segment of the kernel CAP files. This ensures that the system cannot retrieve the correct data from the kernel CAPs without the user permission.



### 4.1.2. ULD User Key


ULD User Key are used to encrypt and sign the user/shared applications. In addition, they are as goalkeepers to prevent the system updating without user permission. This is done by the kernel CAPs which are encrypted and signed by the manufacturer having to perform the “signed” action via ULD User Keys.

*Notes: Applications are encrypted by a random-generated 3DES key, which is retrieved from the Key Encryption Block of the CAP by ULD User Key Encryption Key, not directly encrypted by ULD RSA Key.*



### 4.1.3. Key Change

The ULD RSA Keys are able to be changed. The system uses a special CAP file, KEY CAP, for the manufacturer and user to change their own keys. The KEY CAP contains a new set of ULD keys (Key Encryption Key and Signature Key). These new keys are encrypted and signed via the original keys. In other words, if the user would like to change the ULD User Keys, they have to use their original ULD User Keys with the new ULD User Keys to generate a KEY CAP.





## 4.2. File Signing

### 4.2.1. Signing Kernel Module


Castles will release new version of kernel module in “unsigned” form. This files required to sign with ULD User Key before it can load to terminal.

Castles Technology provideds a tool named “CAP Signing Tool” to perform this task.

The CAP Signing Tool is located at:


C:\Program Files\Castles\MP200\tools\Signing Tool

- Run CAP Signing Tool




(MP200)


- Insert Key Card and select smart card reader



- Enter Key Card PIN



- CAP Signing Tool is ready, press "Select MCI File" button to browse the file.



- Output file will be located in "signed" folder.

## 4.2.2. Signing User Files

Following files are required to sign before load to terminal. This is to ensure the application data and codes confidential and integrity. The output file will be “CAP” file which is file format defined by Castles.


- User application
- User application data files
- User application library
- Font file
- Share library
- Share files
- System setting
- Key CAP (Manufacturer ULD Key Set)

Castles Technology provided a tool named “CAP Generator” to perform this task.


The CAP Generator is located at:

C:\Program Files\Castles\MP200\tools\CAPG (KeyCard)


- Run CAP Generator




- Insert Key Card and select smart card reader




- Enter Key Card PIN




- CAP Generator is ready, select the correct Type from the list.



- Press “Step 1: Select AP Executable File” to select file to sign. This is valid for all the files to sign.



- Enter file details and press “Step 2: Sign Application” to sign the file. This is valid for all the files to sign.



- The output file will be in a set. A “mci” file with one or more “CAP” files. CAP file contains the signed file binaries, where MCI file contains the list of CAP files.



Note: If user would like to load multiple set of signed file, create a new file with extension of “mmci”. Then put the mmci file contents with the list of mci file.



## 4.3. File Loading

There are several ways of loading file to MP200.

- Download by User Loader
- Download by user application
- Download by Castles TMS

User Loader is a tool provided by Castles Technology. It's the formal way to download file to terminal.

User may implement their own ways of updating application or files using CTOS API provided, **CTOS\_UpdateFromMMCI()**.

Castles TMS (CTMS or CASTLES Terminal Management System) is provided by Castles Technology. It's use to perform remote download via Ethernet, GPRS/UMTS or modem.


### 4.3.1. Download by User Loader

The User Loader works for MP200.


The Loader is located at:

C:\Program Files\Castles\MP200\tools\Loader


- Run User Loader



- Select COM port




- Browse and select mci file or mmci file



- Setup terminal to enter download mode
  - Press [0] button in Program Manager (PM)
  - Press [1] button to select "1. Download AP"
  - Press [1] button again to select download via RS232 or USB



- Press "Download" button to start.




*Note: To download using USB cable, terminal must enable CDC mode.  
Set USB CDC Mode to Y.*

```
SYS SETTINGS
Key Sound      : Y
Exec DFLT AP: Y
-AP Name
USB CDC Mode: Y
FunKeyPWD     : N
PMEnterPWD    : N
2: Next Page
```


## 4.4. Changing ULD User Key

User may change their ULD User Key Set stored in Key Card. Castles Technology provided a tool named “Secure Key Generator” to perform this task.


- Run Secure Key Generator




- Insert Key Card and select smart card reader




- Enter Key Card PIN, default PIN is “1234”.




- To change Key Card PIN, press “Update PIN” button. If not, please skip this steps.




- Enter new PIN, enter new PIN again to confirm, then press [Enter] button to change PIN in Key Card.




- To view current key set hash value, goto “Option” and select key.







- To generate new user key set
  - Please generate the RSA key by yourself, the length of the RSA key set should be 2048 (bits).
  - Copy RSA key components to RSA Key for Kenc in Secure Key Generator.




- Generate second RSA key set for Signature.




- Click [Get Hash] button to calculate the hash value for key sets.




- Please copy down all the values into a text file and keep in a safe place. You will need this if you need to create duplicate Key Card.
- To generate the key CAP for the newly generated user key set, press [Make Key CAP File] button.



- The output file will be located in the Secure Key Generator folder.



- To update the newly generated key set to Key Card, press [Save to Card] button to write the key set to Key Card.






# 5. Font Management


## 5.1. Loading New Font

- Run FontManager.exe




Located at C:\Program Files\Castles\Font Manager


- Select font to download




- Press [Setting] button to configure terminal type.




- Select **VEGA5000**, press [Save] button to save and return font manager.




- Press [Generate] to create the font file.



- Output file “Font.FNT” will be located at sub-directory named “Font” in “Font Manager” folder.



- Sign the file using CAP Generator, the type must set to “11 – Linux Font”.



- Lastly, download the signed file (CAP file) to terminal using Loader.

## 5.2. Custom Font

User may create font they preferred for displaying or printing on terminal.


There are two zone defined:

Zone 0x00 ~ 0x7F – ASCII characters, you may replace with the font type preferred or your own language character set.


Zone 0x80 ~ 0xFF – Free to use, you may use for symbols.

### **Following steps demonstrate how to create a 12x24 font.**


- Run GLCD Font Creator




- Select [File] ⇒ [New Font] ⇒ [Import An Existing System Font]




- Select the font needed, simply choose a font size. The final value of font size should be determine by the minimum pixel width. You may need to repeat this steps few times to find the best fit font size.




- Set the import range from 0 to 127.




- Check the minimum pixel width and height.




- If the pixel width of the font size is larger than expected, then you have to repeat the previous steps to import font with smaller size.
- Use the following buttons to adjust the font size to match with expected font size.




- After adjust font size, select [File] ⇒ [Export for MikroElektronika].




- Select output format as [mikroC].




- Remove comment “// Code for char ” from offset 0x00 to 0x1F. Remove empty line if found. Then click [Save] button to save to file.



- Run Font Manager Tool.




- Click [Setting] button







- Enter the file name, font id, and select the size.




- Click [Create] button, and select the C file previously created using GLCD Font Generator.



- Select [Font Manager] tab and tick the newly created font, and press [Generate] button to export to FNT file.



- Use CAP Generator to convert the FNT file to CAP.  
Set type to [11 – Linux Font], press [Step 1] button select the FNT file. Then press [Step 2] to generate CAP file.



- Download the font CAP file to terminal.
- In terminal application, add following code to display message using the newly created font.

```
CTOS_LanguageConfig(0xA000,d_FONT_12x24,0,d_FALSE);
CTOS_LanguageLCDSelectASCII(0xA000);
CTOS_LCDTPrintXY(1, 1, "ABCDEFGH");
```

Or print message using the newly created font.


```
CTOS_LanguagePrinterSelectASCII(0xA000);
CTOS_PrinterPutString("ABCDEFGH");
```

### 5.3. Using TrueType Font (TTF)


TrueType Font (TTF) is supported in MP200. You may download the TrueType font preferred to terminal for displaying or printing.

**Following steps demonstrate how to use “Cooper Black” TrueType font.**

- Copy the TTF file needed to a empty folder.



- Use CAP Generator to convert the TTF file to CAP.  
Set type to [11 – Linux Font], press [Step 1] button select the TTF file.  
Then press [Step 2] to generate CAP file.



- Download the font CAP file to terminal.

- In terminal application, add following code to display message using the newly added font.

```
CTOS_LCDTTFSelect("COOPBL.TTF", 0);  
CTOS_LCDFontSelectMode(d_FONT_TTF_MODE);  
CTOS_LCDTSelectFontSize(0x203C); // 32x60  
CTOS_LCDTClearDisplay();  
CTOS_LCDTPrintXY(1, 1, "Hello World");
```

Or print message using the newly added font.

```
CTOS_PrinterTTFSelect("COOPBL.TTF", 0);  
CTOS_PrinterFontSelectMode(d_FONT_TTF_MODE);  
CTOS_LanguagePrinterFontSize(0x203C, 0, 0); // 32x60  
CTOS_PrinterPutString("Hello World");
```

## 6. FCC Warning

Federal Communication Commission interference statement. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

### FCC Caution

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference and
- (2) this device must accept any interference received, including interference that may cause undesired operation

### RF Exposure Warning

The equipment complies with RF exposure limits set forth for an uncontrolled environment. The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This equipment should be installed and operated with a minimum distance of 5 centimeters between the radiator and your body.

~ END ~