

AVVIO 199 and 299 USER MANUAL

VERSION:

1.0.0

2012-03-09

Important Notice

COPYRIGHT NOTICE

Copyright © 2012, Brightstar Corp all rights reserved.

TRADEMARKS

Brightstar and AVVIO logos are trademarks or registered trademarks of Brightstar. Other companies and product names mentioned herein may be trademarks or trade names of their respective owners, and the mention is subject to compulsory citation purpose.

WARRANTY DISCLAIMER

Brightstar makes no representations or warranties, either expressed or implied, by or with respect to anything in this document, and shall not be liable for any implied warranties of merchantability or fitness for a particular purpose or for any indirect, special or consequential damages.

CONFIDENTIALITY STATEMENT

The contents of this document (including any accessory) are confidential. The receiver should be aware of the confidentiality of the document and will neither use it for any other purpose except for the purposes specified nor disclose the document to any third party.

CONTENT

1. OVERVIEW	1 -
2. WARNINGS	2 -
3. APPEARANCE	3 -
4. KEYPAD DEFINITIONS	3 -
5. GETTING STARTED	4 -
5.1 SIM CARD INSTALLATION	4 -
5.2 BATTERY INSTALLATION	4 -
5.3 CHARGING THE BATTERY	4 -
6. YOUR PHONE	4 -
6.1 POWER ON	4 -
6.2 MAKING A CALL	5 -
6.3 REJECTING A CALL	5 -
6.4 ANSWERING A CALL	5 -
6.5 VOLUME SETTINGS	5 -
6.6 ENDING CALLS	5 -
6.7 EMERGENCY SERVICE	5 -
6.8 EXTENSION CALL/QUICK DIAL	5 -
6.9 MISSED/ DIALED CALL	6 -
6.10 CALL DIVERT	6 -
6.11 CALL BARRING	6 -
6.12 T-FLASH CARD	6 -
6.13 USB CABLE	6 -
6.14 POWER OFF	6 -
7. STANDBY SCREEN	6 -
8. LIST OF MAIN MENUS AND SUBMENUS	7 -
9. CALL LOGS	8 -
9.1 MISSED CALLS	8 -
9.2 DIALED CALLS	8 -
9.3 RECEIVED CALLS	8 -
9.4 ALL CALLS	8 -

9.5 CLEAR LOGS	8 -
9.6 SMS COUNTER	9 -
10. PHONEBOOK	9 -
11. ALARM	9 -
12. MULTIMEDIA	9 -
12.1 FM RADIO	9 -
12.2 AUDIO PLAYER	9 -
12.3 SOUND RECORDER	10 -
12.4 CAMERA	10 -
12.5 VIDEO RECORDER	10 -
12.6 VIDEO PLAYER	10 -
12.7 ALBUM	10 -
13. MESSAGES	11 -
13.1 WRITE MESSAGE	11 -
13.2 INBOX	11 -
13.3 OUTBOX	11 -
13.4 SMS BACKUP	12 -
13.5 SIGNATURE	12 -
13.6 SETTINGS	12 -
13.7 MEMORY STATUS	12 -
13.8 VOICE MAIL	12 -
13.9 BROADCAST MESSAGES	12 -
13.10 BLACK LIST	12 -
14. ORGANIZER	12 -
14.1 CALENDAR	12 -
14.2 TASK LIST	13 -
14.3 CALCULATOR	13 -
14.4 STK	13 -
15. TOOLS & GAMES	13 -
15.1 GAMES	13 -
16. FILE MANAGER	13 -
17. SETTINGS	13 -

17.1 PROFILES	- 13 -
17.2 DATE AND TIME	- 13 -
17.3 DISPLAY	- 14 -
17.4 PHONE SETTINGS	- 14 -
17.5 CALL SETTINGS	- 14 -
17.6 NETWORK SETTINGS	- 14 -
17.7 NETWORK STATUS	- 14 -
17.8 SECURITY SETTINGS	- 14 -
17.9 RESTORE FACTORY SETTINGS	- 15 -
18. ENTRY MODE	- 15 -
19. ACCESSORIES	- 15 -
20. CARE AND MAINTENANCE	- 15 -
21. TECHNICAL INFORMATION	- 17 -

1. Overview

Thank you for purchasing a AVVIO mobile phone.

2. Warnings

Not following these simple guidelines may be dangerous or illegal. Read the complete user guide for further information.

TURN ON SAFELY

Do not turn on the phone when wireless phone is prohibited or when it may cause interference or danger.

ROAD SAFETY

Obey all road safety laws. Always use both of your hands to operate the vehicle while driving.

INTERFERENCE

All wireless phones may be sensitive to interference, which may affect performance.

TURN OFF IN HOSPITALS

Follow all restrictions. Turn off the phone near medical equipment.

TURN OFF ON AIRCRAFTS

Follow all restrictions. Wireless devices can cause interference on aircrafts.

TURN OFF WHEN REFUELING

Do not use the phone at/near refueling stations. Do not use near fuel or chemicals.

USE SENSIBLY

Only qualified personnel may install or repair this product.

ENHANCEMENTS AND BATTERIES

Use only appropriate enhancements and batteries. Do not connect incompatible products.

WATER-RESISTANCE

Your phone is not water-resistant. Keep it dry.

BACKUP COPIES

Remember to make back-up copies or keep a written record of all important information stored in your phone.

CONNECTING TO OTHER DEVICES

When connecting to any external device, read its user guide for detailed safety instructions. Do not connect with incompatible products.

3. Appearance



4. Keypad Definitions

Key	Definitions
Left Soft key/Right Soft key	<ol style="list-style-type: none"> 1. Execute functions that the left-down/right-down corner indicator shows. 2. In the standby mode, press Left Soft key to access Menu, Right Soft key to access Names.
Navigation key	<ol style="list-style-type: none"> 1. In other modes, it is used as the navigation/direction key except for some special functions. 2. In the standby mode, press navigation keys to enter corresponding shortcut function.
OK key	<ol style="list-style-type: none"> 1. In the standby mode, press this key to enter main menu. 2. After inputting numbers, press this key to select Preferred storage to save the number.
End key	<ol style="list-style-type: none"> 1. Mainly used as power on/off. 2. Press to return to standby screen in any interface. 3. End calls or reject incoming calls.
Dial key	<ol style="list-style-type: none"> 1. Press this key to dial or receive an incoming call. 2. When in the standby mode, press this key to access Call logs.
* Key	<ol style="list-style-type: none"> 1. After inputting phone number, quick press * key twice, then the symbol "p" appears and input the extension number. You can make an extension call. 2. In standby mode, press left soft key/OK key and * key to

	lock keypad. 3. In standby mode, long press * key to activate or deactivate Silent mode.
# Key	1. In text editing interface, press "#" key to switch the text input method. 2. When the keypad is locked, press left soft key and # key to unlock.

5. Getting Started

5.1 SIM Card Installation

When you subscribe to a cellular network, you will receive a plug-in SIM card complete with your subscription details, such as your PIN, and available optional services.

Caution: Do not bend or scratch your SIM card. Avoid exposing your SIM card to static electricity, water, or dirt.

Tips: Face the gold color contact point of SIM card towards the cell phone and push the SIM card into the slot.

5.2 Battery Installation

Caution: Install according to the illustration above to avoid breaking the battery connectors.

5.3 Charging the Battery

Insert the charger; the flash symbol on the charger plug must face upwards.

Connect the charger to a standard wall outlet and the battery power icon in the up-right corner of the screen will start scrolling. When the battery bar stops scrolling, the battery charge is complete. Press the two sides of the charger plug and disconnect the charger from the phone.

- When the battery is low, a "low battery" message will display across the screen and the battery icon will seem empty. If the battery level is insufficient, the phone will turn off automatically. Do not use your phone under low battery state for an extended period of time or it may cause battery damage.

6. Your Phone

6.1 Power On

- Press and hold end key to turn on your phone, light the backlight, and display power on animation.

- If you do not insert a SIM card, or the SIM card has incomplete connection, your phone will show "Insert SIM". In this condition, you can only access part of the menu and only permission using some urgent calling.

- If the PIN code is blocked, the alert message for inputting PUK code will display on the screen before power on.

- The phone will search the network automatically after power on.

If your phone registers to network correctly, the name of the network and signal strength will

display; if your phone can't register or can't register correctly, you can only access emergency calls and other functions that do not rely on the network.

6.2 Making a Call

In standby mode, press numerical keys to input phone number to dial phone number. When you finish inputting phone number, press the dial key to select SIM card to make a call. If you're making a long distance call, add the area code preceding the telephone number.

Press left soft key to access Options.

- Call: Press number keys enter the call number and press dial key to make a call.
- Save: Save the number to SIM or Phone
- Send message: Send message to a certain number

6.3 Rejecting a Call

Press end key to reject an incoming call.

6.4 Answering a Call

When you receive a call, the phone will ring or vibrate and will display an incoming call indicator. Press the dial key or press OK key, left soft key to select "Answer" to answer.

Press left soft key to access Options:

- Hold
- End
- New call
- Phonebook
- Call logs
- Messages
- Mute
- DTMF

6.5 Volume Settings

During a call, press left/right navigation keys to adjust the volume.

6.6 Ending Calls

Press the end key to end or cancel a call.

6.7 Emergency Service

You can dial an emergency call without the SIM card.

Contact your service provider to get the emergency call number.

6.8 Extension Call/Quick Dial

After inputting phone number, quickly press key (*) twice until the symbol "p" appears, then input the extra number.

6.9 Missed/ Dialed Call

Enter main menu->Call logs -> check Missed/Dialed calls.

In standby mode, press dial key to enter Call logs.

6.10 Call Divert

When the call divert is activated, incoming calls will be diverted to voice mail or other phone numbers according to the call divert settings.

6.11 Call Barring

When the call barring activated, some of the calls will be barred according to the call barring setting condition. Contact your service provider to sign up for call barring.

6.12 T-flash Card

Insert the T-Flash card into phone from the slot. This will expand the Flash memory of the phone.

6.13 USB Cable

You can transfer and store files, such as MP3, MP4 and pictures from PC, through USB cable, to the mass storage in phone or identified SD card that is inserted. This USB cable with a mini 8pin usb port another port is USB A plug connector. This mobile phone support usb 1.1; the Full-Speed is 12Mbps.

The operating method is as follows:

—Connect: Plug the IO port of the cable into your phone, and the USB port into the PC.

Read & write mode:

T-Flash card: Install the T-Flash card, and connect the phone set to PC, if the phone set is power off, it can be charged or used as a mass storage.

—File transfer

•File folder instruction: Find the mobile memory (T-FLASH card) in "my computer", double click it, and you will find the folders as follows:

"Photos" is used to store the picture.

"My Music" is used to store the MP3 music file.

"Videos" is used to store the video file.

These folders is preset by the system, don't change the folders' name.

•Read &Write: You can copy the files in T-Flash to PC hard disk, or copy the files in PC hard disk to the folder of the T-Flash card.

—Quit: On the PC side, select taskbar->delete hardware safely, exit the T-Flash card identified states, stop the T-Flash card, and pull out the USB cable.

6.14 Power Off

In standby mode, press and hold end key to turn off phone.

7. Standby Screen

Press and hold end key to turn on your phone, phone will light the backlight and display power on animation.

On the screen, icons indicate the network name, signal strength, battery levels, time and date, and phone configure information. Refer to icons information in standby screen.

8. List of Main Menus and Submenus

In standby screen, press left key to access the main menu. The main menu includes items: (1) Call logs (2) Phonebook (3) Alarm (4) Multimedia (5) Messages (6) Organizer (7) Tool & Games (8) File Manager (9) Settings, all together 9 items.

List of main menus and sub menus as below

Call logs SIM call logs

Phonebook Contacts
 Add new contact
 Delete all
 Copy all
 Owner number
 Memory status
 Speed dial
 Phonebook backup

Alarm

Multimedia FM radio
 Audio player
 Sound recorder
 Camera
 Video recorder
 Video player
 Album

Messages Write Message
 Inbox
 Outbox
 SMS Backup
 Signature
 Settings
 Memory status
 Voice mail
 Broadcast messages
 Black list

Organizer Calendar
 Task list

Calculator
STK

Tool & Games

Games

File manager

Settings Profiles
 Date and time
 Display
 Phone settings
 Call settings
 Network settings
 Network status
 Security settings
 Restore factory settings

9. Call Logs

The Avvio 199/299 GSM Mobile phone supports Single SIM cards, and the call logs will be recorded. Select call logs to enter:

9.1 Missed Calls

Display the latest Missed calls list.

Press OK key to view the Detail, or press left soft key to access Options:

- View: To check detail information of Number, Date, Time, and Count
- Call: To call the number
- Save: Save the number to Phone/SIM
- Delete: Delete the number.
- Delete All: Delete all numbers
- Edit before call: Edit the number before calling
- Send message: Send message to the number

9.2 Dialed Calls

Refer to "Missed Calls"

9.3 Received Calls

Refer to "Missed Calls"

9.4 All Calls

Refer to "Missed Calls"

9.5 Clear Logs

Enter the menu and select to clear Missed calls, Dialed calls, Received call, or Clear all.

9.6 SMS Counter

You can check all messages Sent or Received in this menu.

10. Phonebook

You can store contacts' personal information and numbers while also search for previously stored contacts.

Enter the menu and select:

- Contacts: Enter Contacts list to check contacts, and you can input first letter or contacts' name to search.
- Add new contact: Add new contact to SIM or Phone
- Delete all: Delete all contacts From SIM From or From Phone
- Copy all: Copy contacts among SIM cards and Phone
- Owner number: To set and save SIM or owner number
- Memory status: Check memory status of SIM or Phone
- Speed dial: To check Status or Set number
- Phonebook backup: Select Phonebook Export or Phonebook Import to backup

11. Alarm

The alarm clock feature sounds an alert or makes a vibration alert at a time you specify. After set Status, Time, Snooze, Repeat, and Alarm tone, press OK key to save or press left soft key to access Options to save.

12. Multimedia

12.1 FM Radio

Enter FM radio, it will search channel list automatically. Press left/right key to change frequency, press "*" key and "#" key to adjust volume.

Press the left soft key to access Options:

- Power on/off
- Tune
- Channel List
- Volume
- Preset auto search

12.2 Audio Player

This function menu is used to store and play the multimedia file.

Press the left soft key or OK key to enter and use the Navigation keys and OK key to operate Audio Player.

Press * key and # key to adjust volume. Press left soft key to access Options:

- All songs: View all audio files on memory card

- Settings: Set parameters for the audio player
- Help: Check help information

12.3 Sound Recorder

You can take a recorder in this function. When enter the recorder, press left soft key to access Options: Record, List, and Settings.

Press OK key to record, press left soft key to pause, press right soft key to stop.

After saved, press left soft key to access Options:

- Record
- Play
- Append
- Rename
- Delete
- List
- Settings
- Set as ringtone

12.4 Camera

Press left soft key or OK key to select the function. The photo can be previewed in the screen; press OK key to shoot and right soft key to back, left soft key to access Options:

- Camera settings: To set parameter for camera
- Image settings: To set Image size, Image quality, and Contrast
- Restore default: Restore all settings to default

12.5 Video Recorder

Press left soft key or OK key to enter video recorder. Press OK key to shoot, press left soft key to pause, press right soft key to stop.

Press left soft key to access Options:

- Settings: Set parameters for video recorder.
- Restore default: Restore all values to default.

12.6 Video Player

Preview the videos. Press * key and # key to adjust volume. Press Left/Right navigation keys and OK key to operate video player. Press left soft key to access to play list, then press left soft key again to access Options:

- Play: Play the video clip selected
- Add: Add video clip to the list
- Remove: Remove the video clip from the list
- Remove all: Remove all video clips from the list
- Refresh list

12.7 Album

In the Album, you can check all photos or pictures saved. Select one photo, press OK key to enter and view, or you can press left soft key to access Options:

- View: To view the photo
- Set as wallpaper: Select and set the photo as wallpaper
- Rename: Rename the photo
- Delete: To delete the photo
- Delete all files: To delete all photos in album

13. Messages

13.1 Write Message

This function can begin a new message.

Press OK key to enter:

- Enter recipient: Enter recipient to send message
- Contacts: Enter Contacts to add numbers
- Call logs: Enter SIM call logs to add numbers

Press left soft key to enter Options:

- Send: Enter recipient, select number for Contacts or Call logs to send the message
- Save: To save the message
- Writing language: To select writing language
- Back

13.2 Inbox

After entering the Inbox, press up/down navigation key to select messages. Press OK key to check the details of message, or press left soft key to access Options:

- View: To check the message
- Reply: Reply message to the sender
- Delete: Delete the message.
- Copy to phone/SIM
- Move to phone/SIM
- Delete all: Delete all messages
- Copy all: Copy all messages From SIM or From phone
- Move all: Move all messages From SIM or From phone
- Mark several: Select one or more messages to mark

13.3 Outbox

Checks the information of unsuccessfully sent message in outbox.

Press left soft key to access to Options:

- View: To check the message
- Delete: Delete the message.
- Copy to phone/SIM
- Move to phone/SIM
- Delete all: Delete all messages
- Copy all: Copy all messages From SIM or From phone
- Move all: Move all messages From SIM or From phone
- Mark several: Select one or more messages to mark

13.4 SMS Backup

Press left soft key or OK key to select and confirm to backup messages.

13.5 Signature

You can edit signature and add it to message. Enter the menu to select:

- Mode: Press left soft key or OK key to turn on/off this mode
- Signature text: Enter and edit signature content

13.6 Settings

Enter and set parameters for SIM. Select SIM settings to select:

- Profile settings: To set msg center, Validity, and Type
- Common settings: To set Delivery report, Reply path, and Save sent message
- Preferred storage: To select SIM or Phone

13.7 Memory Status

To check SIM memory status.

13.8 Voice Mail

Select SIM voice mail. You can select to Edit the number or Connect to voice mail.

This function needs a network supply. Please contact with your service provider for more information.

13.9 Broadcast Messages

Select SIM broadcast message

- Receive mode: Turn on/off the receive mode
- Channels: Select Add, Edit or Delete channels in the list

13.10 Black List

- Mode: Turn on/off black list
- Black list numbers: Edit and add numbers to the list

14. Organizer

14.1 Calendar

You can use this feature to view the year, date and term easily. Use navigation keys to navigate other date. Press left soft key to do options:

- View tasks: To check tasks saved
- Jump to date: Enter the date you want to check
- Go to today
- Week starts on: Select Sunday or Monday as the first day of a week
- Panchangam
- Festival list: To check all festivals
- Onscreen display: To select None or Hindu

14.2 Task List

To check tasks. Press left soft key to select Add and edit new task. Select one task and press left soft key to access:

- Add: Add new task
- Edit: Edit the task
- Delete: Delete the task
- Delete all: Delete all tasks

14.3 Calculator

This feature can use your phone as a calculator for simple calculations.

Press keypad to enter the numbers. Use following direction keys to calculate:

Up, down, left, right key: +, -, ×, /

OK key: Show the calculation result.

Key: Decimal point

14.4 STK

If your SIM card supports STK function, the phone can display different first level menu according to different STK card. This function needs the network provider support. If user finds STK function can't operate normally, please contact the network provider. If the network provider does not support this function, we do not claim any responsibility whatsoever.

15. Tools & Games

15.1 Games

Your phone supplies built-in game, you can play it whenever you want. Select Game settings to set Audio.

16. File Manager

You can check all files and folders stored on memory card. Select one folder or files and press left soft key to access Options to operate. The operations of folders may different from those of files. Please refer to your actual phone.

17. Settings

17.1 Profiles

Your phone supplies several profiles. Select one file and press OK key or left soft key to customize.

17.2 Date and Time

- Set date and time
- Format: To set Time format and Date format

17.3 Display

To set parameters for display

- Wallpaper: Select pictures as wallpaper
- LCD backlight: To set time duration for LCD backlight
- Brightness: Press left/right navigation keys to select, press OK key or left soft key to confirm settings.

17.4 Phone Settings

- Language: To choose several languages under this function
- Shortcuts: Set shortcuts for Dedicated key and My shortcuts
- Auto keypad lock: To select turn on/off auto keypad lock
- Input method settings: To set Writing language and Input method

17.5 Call Settings

- Call settings
 - Caller ID: To select Set by network, Hide ID, or Send ID
 - Call waiting: Set the mode of call waiting, this function need to be activated.
 - Call divert: When the call divert is activated, incoming calls will be diverted to voice mail or other phone numbers according to the call divert settings.
 - Call barring: When the call barring is activated, some of the calls will be barred according to the call barring setting condition. Contact your service provider to sign up for call barring.
 - Line switching: Select Line1 or Line2
- Common call settings
 - Call time reminder
 - Auto Call Recorder
 - Auto redial
 - Black list
 - Answer mode: Select Any key

17.6 Network Settings

Select SIM network to set:

- Network selection
 - New search
 - Select network
 - Selection mode: Manual or Automatic
- Preferred networks

17.7 Network Status

To check SIM network status

17.8 Security Settings

- SIM security
 - SIM lock: Input SIM PIN to turn on/off SIM lock
 - Fixed dial: To set mode or edit fixed dial list. You need to input PIN2 to activate this function.

- Change password: To change PIN or PIN2 password
- Phone security
- Phone lock: When turn on this function, you need to input password every time you power on the phone.
 - Change password: To change phone lock password, the default password is 1234.

17.9 Restore Factory Settings

Input the default password 1234 to restore factory settings.

18. Entry mode

You can use several methods for entering text and numbers. By selecting a Text Entry Mode, the phone provides a few Text Entry Mode for new adding, editing contact records, finding contacts, editing SMS and writing memos.

Select Text Entry Mode:

18.1 Letter entry mode

Press a key once to insert the first letter on the key, twice for the second letter, etc. If you pause briefly, the last letter in the display is accepted and the text awaits the next entry.

For example, press the "2" key continuously, it will appear "a"、"b"、"c"、"2"one by one.

18.2 Number entry mode

Number Entry Mode can input the number in the text, such as telephone number. Tap the proper number and input it.

19. Accessories

You can use accessories approved by our company, the other accessories can be provided by the seller.

Extra battery

We provide several kind of lithium battery with different capacity.

Traveler charger

Super sleek, useful charger can charge the mobile phone very quickly. Plug the charger into the electrical plugs and connects the other side connects to the bottom of the phone.

You can check the charging progress in the screen of the phone, it will not power on automatically when charging.

20. Care and maintenance

Battery care

- Your device is powered by a rechargeable battery. When the power is weak, please charge the battery. In order to extend the lifespan of the battery, use all the battery's power before recharging.
- Unplug the charger from the electrical plug and the device when not in use. Do not leave the

battery connected to a charger more than a week. Overcharging may shorten its lifespan.

- Extreme temperatures can affect the ability of your battery to charge. Battery needs the fit temperature. If the surrounding temperature is over 40°C, the battery cannot be charged.
- Use the battery only for its intended purpose. Never use any charger or battery that is damaged. Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen causes direct connection of the positive (+) and negative (-) terminals of the battery. (These look like metal strips on the battery.) Short-circuiting the terminals may damage the battery or the connecting object.
- Leaving the battery in hot or cold places, such as in a closed car in summer or a freezer in winter conditions, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 59°F and 77°F (15°C and 25°C). A hot or cold battery may not function temporarily, even when the battery is fully charged.
- Battery performance is particularly limited in temperatures below freezing.
- Do not dispose of batteries in a fire! Dispose of batteries according to local regulations. Please recycle when possible. Cellphones are not considered household waste.

Mobile phone maintenance

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, remove the battery and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the device and may violate regulations governing radio devices.

All of the above suggestions apply to your device, battery, charger, or any enhancement. If any device is not working properly, take it to the nearest authorized service facility for service.

21 RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types Avvio 199/299 (FCC ID: WVBAX99) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 1.092W/kg and when properly worn on the body is 0.674W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.5cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.5cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

All pictures are for reference only in the instruction book; please refer to the actual phone.