

Bundesrepublik Deutschland

Federal Republic of Germany

Bundesamt für Seeschifffahrt und Hydrographie

Federal Maritime and Hydrographic Agency



BUNDESAMT FÜR SEESCHIFFFAHRT HYDROGRAPHIE

Conformance test report of an

AIS Class B SO System

Equipment under test:

AMEC

Type:

WideLink B600/B600W

Applying test standards:

IEC 62287-2 Ed.2.0: 2017 [Sections 10, 12, 13]

Test Report No.:

BSH/4542/001/4322986/16-1

Applicant:

Alltek Marine Electronics Corp

14F-2, No.237, Sec.1, Datong Road, Xizhi District

New Taipei City, 22161

TAIWAN

Hamburg, 24 March 2017 For the Federal Maritime and Hydrographic Agency

Heinrich Bartels

Test engineer

Hans-Karl von Arnim

Head of section

Federal Maritime and Hydrographic Agency Bernhard-Nocht-Str. 78

D-20359 Hamburg Germany





Federal Maritime and Hydrographic Agency





Deutsche Akkreditierungsstelle GmbH

Beliehene gemäß § 8 Absatz 1 AkkStelleG i.V.m. § 1 Absatz 1 AkkStelleGBV Unterzeichnerin der Multilateralen Abkommen von EA, ILAC und IAF zur gegenseitigen Anerkennung

Akkreditierung



Die Deutsche Akkreditierungsstelle GmbH bestätigt hiermit, dass das Prüflaboratorium

Bundesamt für Seeschifffahrt und Hydrographie Bundesoberbehörde im Geschäftsbereich des BMVBS Bernhard-Nocht-Straße 78 20359 Hamburg

die Kompetenz nach DIN EN ISO/IEC 17025:2005 besitzt, Prüfungen in folgenden Bereichen durchzuführen:

Schiffsausrüstung (Navigationsausrüstung, Funkausrüstung, Rettungsmittel)

Die Akkreditierungsurkunde gilt nur in Verbindung mit dem Bescheid vom 08.03.2013 mit der Akkreditierungsnummer D-PL-12084-01 und ist gültig bis 07.03.2018. Sie besteht aus diesem Deckblatt, der Rückseite des Deckblatts und der folgenden Anlage mit insgesamt 9 Seiten.

Registrierungsnummer der Urkunde: D-PL-12084-01-01

Frankfurt am Main, 08.03.2013

Siehe Hinweise auf der Rückseit

Im Auftrag Dipl.-log. (FH) Ralf Egner Leiter Abteilung 2




Table of contents:

_		_
1	GENERAL	
	1.1 SUMMARY	
	1.2 EQUIPMENT HISTORY	7
	1.2.1 EUT system no 1	
	1.2.2 EUT system no 2	
	1.2.3 EUT system no 3	
	1.3 TEST ENVIRONMENT	10
	1.4 COMPOSITION	10
	1.5 LEGEND	11
	1.6 GENERAL OBSERVATIONS	
2	9 POWER SUPPLY, ENVIRONMENTAL AND EMC TESTS	
_	2.1 9.5 UNDER VOLTAGE TEST (BROWN OUT)	
	2.2 9.6 UNDER VOLTAGE TEST (SHORT TERM)	
3	10 OPERATIONAL TESTS	
3	3.1 10.1 GENERAL	
	3.1.1 10.1.1 Tests by inspection	
	3.1.3 10.1.3 Additional features	
	3.2.1 10.2.1 Autonomous mode	
	3.2.1.1 10.2.1.1 Transmit position reports	
	3.2.1.2 10.2.1.2 Receive AIS Class A position reports	
	3.2.1.4 10.2.1.4 Receive AIS Class B "CS" position reports	٦٢
	3.2.1.5 10.2.1.5 Receive in time slot adjacent to own transmission	21
	3.2.1.6 10.2.1.6 High VDL loading reception test	
	3.2.2 10.2.2 Single Messages	
	3.2.2.1 10.2.2.1 Transmit an addressed binary message	
	3.2.2.2 10.2.2.2 Transmit an addressed safety related Message 12	
	3.2.2.3 10.2.2.3 Acknowledgement of addressed Messages	
	3.2.2.4 10.2.2.4 Transmit a broadcast binary Message 8	
	3.2.2.5 10.2.2.5 Transmit a broadcast safety related Message 14	
	3.2.2.6 10.2.2.6 ITDMA and RATDMA transmission	
	3.2.3 10.2.3 Polled mode / Interrogation response	
	3.3 10.3 CHANNEL SELECTION	
	3.3.1 10.3.1 Valid channels	
	3.3.2 10.3.2 Invalid channels	
	3.4 10.4 INTERNAL GNSS RECEIVER	
	3.5 10.5 AIS INFORMATION	
	3.5.1 10.5.1 Information content	
	3.5.2 10.5.2 Information update intervals	
	3.5.2.1 10.5.2.1 Autonomous reporting interval	
	3.5.2.2 10.5.2.2 Polite behavior	
	3.5.2.3 10.5.2.3 Static data reporting interval	
	3.6 10.6 INITIALISATION PERIOD	
	3.7 10.7 ALARMS AND INDICATIONS, FALL-BACK ARRANGEMENTS	
	3.7.1 10.7.1 Built in integrity test	
	3.7.2 10.7.2 Transceiver protection	
	3.7.3 10.7.3 Transmitter shutdown procedure	
	3.7.4 10.7.4 Position sensor fallback conditions	
	3.8 10.8 USER INTERFACE	53
	3.8.1 10.8.1 Status indication	
	3.8.2 10.8.2 Message display	
	3.8.3 10.8.3 Static data input	
4	11 PHYSICAL TESTS	
5	12 SPECIFIC TESTS OF LINK LAYER	
•	5.1 12.1 TDMA SYNCHRONISATION	
	5.1.1 12.1.1 Synchronisation test using UTC direct and indirect	
	5.1.2 12.1.1 Synchronisation test using OTC direct and indirect	
	5.1.2 12.1.2 Gynomication toot without 010, LOT receiving semaphore	



BUNDESAMT FÜR SEESCHIFFFAHRT UND

		HYDR	ROGRAPH
		12.2 TIME DIVISION (FRAME FORMAT)	
		12.3 SYNCHRONISATION JITTER	
		12.4 Data encoding (bit stuffing)	
		12.5 FRAME CHECK SEQUENCE	
	5.6 1	12.6 SLOT ALLOCATION (CHANNEL ACCESS PROTOCOLS)	
	5.6.		64
	5.6.	/	
	5.6.3		66
	5.6.4	, , , , , , , , , , , , , , , , , , ,	
	5.6.	.5 12.6.5 Assigned operation	
		5.6.5.2 12.6.5.2 Message 16 with rate assignment	
		5.6.5.3 12.6.5.3 Assigned mode using invalid reporting rates	
	5	5.6.5.4 12.6.5.4 Slot assignment to FATDMA reserved slots	73
	5.6.0	-	
		5.6.6.1 12.6.6.1 Entering interval assignment	74
		5.6.6.2 12.6.6.2 Assignment by region	
		5.6.6.3 12.6.6.3 Assignment by station type	
		5.6.6.4 12.6.6.4 Addressing by ship and cargo type	
	5	5.6.6.5 12.6.6.5 Quiet time command	79
	5	5.6.6.6 12.6.6.6 Reverting from interval assignment 5.6.6.7 12.6.6.7 Assignment priority test – Message 16 and 23	80
	<i>E</i>	5.6.6.8 12.6.6.8 Assignment priority test – Message 22 and 23	82
	5.6.		
		12.7 Message formats	
	5.7.		
	5.7.		
6	13 \$	SPECIFIC TESTS OF NETWORK LAYER	90
	6.1 1	13.1 REGIONAL AREA DESIGNATION BY VDL MESSAGE	90
	6.2 1	13.2 CHANNEL MANAGEMENT BY ADDRESSED MESSAGE 22	97
	6.3 1	13.3 INVALID REGIONAL OPERATING AREAS	99
	6.4 1	13.4 CONTINUATION OF AUTONOMOUS MODE REPORTING INTERVAL	99
	6.5 1	13.5 SLOT REUSE AND FATDMA RESERVATIONS	100
		13.6 LONG-RANGE APPLICATION BY BROADCAST	
	6.6.		
	6.6.2		
		13.7 Other features	
7	ANI	NEX D DSC FUNCTIONALITY	108
	7.1 A	A.4 DSC FUNCTIONALITY TESTS	108
	7.1.		
		.2 A.4.4 Regional area designation	
	7.1.3	and the state of t	
	7.1.4		
	7.1.		
	7.1.0 7.1.		
	7.1.		
Δ	NNEX A		
′`		TEST EQUIPMENT SUMMARY	
	A.1.		
	A.1.	•	
	A.1.	3.4.4	
	A.1.		
	A.1.		
	A.1.		
	A.1.	,	
	A.1.		
_		TEST ENVIRONMENT OVERVIEW	
Α	NNEX E		
		EC 61162 TEST SENTENCES	
	B.1.	.1 Messages (ABM, BBM)	120





BUNDESAMT FÜR SEESCHIFFFAHRT UND HYDROGRAPHIE

ANNEX C TEST DIAGRAMS	122
C.1 10.2.1.5 RECEIVING IN ADJACENT SLOTS	122
C.2 10.2.1.6 HIGH VDL LOADING RECEPTION TEST	123
C.3 10.2.2.6 SINGLE ITDMA AND RATDMA TRANSMISSIONS	
C.4 10.5.2.1 AUTONOMOUS REPORTING INTERVAL	
C.4.1 30s – 5 s interval	
C.4.2 3 min – 30 s interval	_
C.5 10.5.2.3 STATIC DATA REPORTING INTERVAL	
C.5.1 Slot allocation at 30 s interval	
C.5.2 Slot allocation at 15 s interval	
C.5.3 Slot allocation at 5 s interval	
C.5.4 Transmission schedule of Message 24	
C.6 12.3 SYNCHRONISATION JITTER	
C.6.1 UTC direct synchronisation	
C.6.2 UTC indirect synchronisation	
C.7 12.6 SLOT ALLOCATION	
C.7.1 12.6.1 Network entry	
C.7.2 12.6.2 Autonomous scheduled tx (SOTDMA)	
C.7.3 12.6.2b Use of free slots at 50% VDL load	
C.7.4 12.6.5 Assigned operation	154
C.7.4.1 12.6.5.1 Message 16 with slot assignment	
C.7.4.2 12.6.5.2 Message 16 with rate assignment	157
C.7.5 Rate assignment 5 s	157
C.7.6 Rate assignment 10 s	
C.7.7 12.6.6 Group assignment	
C.7.7.1 12.6.6.1 Entering group assignment	
C.7.7.2 12.6.6.6 Reverting from group assignment	
C.7.8 12.6.7 Base station reservations	
C.8 13.1 REGIONAL AREA DESIGNATION BY VDL MESSAGE	
C.8.1 a) Area border transition	
C.8.2 c) Tx/Rx mode 1	-
C.9 13.5 SLOT REUSE AND FATDMA RESERVATIONS	
C.10 13.6 LONG RANGE BROADCAST	
ANNEX D PHOTOS OF EQUIPMENT UNDER TEST	
D.1 TRANSPONDER UNIT	181

Federal Maritime and Hydrographic Agency



1 General

1.1 Summary

Applicant: Alltek Marine Electronics Corp, 14F-2, No.237,

Sec.1, Datong Road, Xizhi District, New Taipei

City, 22161, TAIWAN

Equipment under test:

Type: WideLink B600/B600W

Manufacturer: Alltek Marine Electronics Corp, 14F-2, No.237, Sec.1,

Datong Road, Xizhi District, New Taipei City, 22161,

TAIWAN

Place of test: BSH test laboratory Hamburg, Room 916

Start of test: 13 June 2016 End of test: 16 March 2017

Test standards¹:

Recommendation ITU-R M.1371-5 (2014)

Technical characteristics for an automatic identification system using time division multiple access in the VHF maritime mobile band

IEC 62287-2 Ed. 2.0 (2017)

Maritime navigation and radiocommunication equipment and systems – Class B shipborne equipment of the automatic identification systems (AIS) –

Part 2: Self-organising time division multiple access (SOTDMA) techniques -

IEC 61162-1 Ed. 5.0 (2016)

Maritime navigation and radiocommunication equipment and systems - Digital Interfaces -

Part 1: Single talker and multiple listeners

Part 2: Single talker and multiple listeners, high speed transmission

IEC 61162-2 (1998)

Maritime navigation and radiocommunication equipment and systems - Digital Interfaces -

Part 1: Single talker and multiple listeners

Part 2: Single talker and multiple listeners, high speed transmission

Test No.	Reference IEC 61993-2 Ed. 2	Section	Result (passed / not passed / not applicable / not tested)
2	10	Operational tests	Passed
3	11	Physical tests	not included
4	12	Specific tests of link layer	Passed
5	13	Specific tests of network layer	Passed
6	A.4	DSC functionality tests	Passed

¹ Numbers listed in the titles of the test sections of this report refer to the respective sections of IEC 62287-2 if not stated otherwise.

Test Report No. BSH/4542/001/4322986/16-1

Federal Maritime and Hydrographic Agency



1.2 Equipment history

For each transponder unit under test a numbered entry is provided here.

1.2.1 EUT system no 1

<u>Transponder</u>					
Туре	Widelink B600		Part no.		
Delivery date	2016-05-02	2016-05-02		EUT #1	
HW Version:	Delivery date	2016-05-02	Version no		
	Installation date	2016-05-02			
SW Version:	Delivery date	2016-05-02	Version no.	V.1.1.1	
	Installation date	2016-05-02			
SW Version:	Delivery date	2016-05-23	Version no.	V1.1.4.1	
	Installation date	2016-05-23			
SW Version:	Delivery date	2016-06-13	Version no.	V1.1.4.2	
	Installation date	2016-06-13			

GPS antenna				
Туре	ANT-21	Part no.		
Delivery date	2016-05-02	Serial no.	A3K090001	



1.2.2 EUT system no 2

<u>Transponder</u>					
Туре	Widelink B600		Part no.		
Delivery date	2016-06-27		Serial no.	A6K600002	
-					
HW Version:	Delivery date	2016-06-27	Version no.	B600MBV2	
	Installation date	2016-06-27			
SW Version:	Delivery date	2016-06-27	Version no.	V1.1.4.3	
	Installation date	2016-06-27			
SW Version:	Delivery date	2016-07-21	Version no.	V1.1.4.4	
	Installation date	2016-07-21			
SW Version:	Delivery date	2016-07-22	Version no.	V1.1.4.5	
	Installation date	2016-07-22			
SW Version:	Delivery date	2016-08-23	Version no.	V1.1.4.6	
	Installation date	2016-08-23			
SW Version:	Delivery date	2016-08-25	Version no.	V1.1.4.7	
	Installation date	2016-08-26			
SW Version:	Delivery date	2016-09-02	Version no.	V1.1.4.8	
	Installation date	2016-09-02			
SW Version:	Delivery date	2016-09-13	Version no.	V1.1.4.9	
	Installation date	2016-09-13			
SW Version:	Delivery date	2017-02-16	Version no.	V1.1.4.10	
	Installation date	2017-02-16			
SW Version:	Delivery date	2017-02-17	Version no.	V1.1.4.11	
	Installation date	2017-02-17			
SW Version:	Delivery date	2017-02-20	Version no.	V1.1.4.12	
	Installation date	2017-02-20			
SW Version:	Delivery date	2017-02-23	Version no.	V1.1.4.13	
	Installation date	2017-02-23			
SW Version:	Delivery date	2017-03-08	Version no.	V1.1.4.14	
	Installation date	2017-03-08			

GPS antenna				
Туре	ANT-21	Part no.		
Delivery date	2016-05-02	Serial no.	A3K090001	



1.2.3 EUT system no 3

Transponder				
Туре	Widelink B600		Part no.	
Delivery date	2016-06-27		Serial no.	A6K600003
HW Version:	Delivery date	2016-06-27	Version no.	B600MBV2
	Installation date	2016-06-27		
SW Version:	Delivery date	2016-06-27	Version no.	V1.1.4.3
	Installation date	2016-06-27		

GPS antenna				
Туре	ANT-21	Part no.		
Delivery date	2016-05-02	Serial no.	A3K090001	

Federal Maritime and Hydrographic Agency



1.3 Test environment

Here it is intended to record for which time which EUT system is under test. The test environment is completely equipped as described in Annex A.

Room	BSH Room 916 (9 th floor)
Test engineer	H. Bartels
Location	9° 59,103 E 53° 32,822 N
Temperature range	Within the specification of IEC 60945, Section 5.2.1
Humidity	Within the specification of IEC 60945, Section 5.2.1
Air pressure	980 – 1030 mBar

Equipment no.	Start of test	End of test	Test engineer
1	2016-05-13	2016-05-31	Bartels
1	2016-06-01	2016-06-02	Bartels
2	2016-07-01	2016-07-05	Bartels
3	2016-07-06	2016-07-06	Bartels
2	2016-07-21	2016-07-25	Bartels
2	2016-07-23	2016-08-23	Bartels
2	2016-09-05	2016-09-05	Bartels
2	2016-09-19	2016-09-20	Bartels
Documentation	2016-11-29	2016-11-30	Bartels
2	2016-11-30	2016-12-02	Bartels
2	2017-02-16	2017-03-16	Meyszies

Date of test report template: 2016-03-07

1.4 Composition

Minimum Keyboard and	l Display (MKD)	
No display	☐ Internal	☐ Remote
Channel management b ☑ Time sharing	by DSC Dedicated receiver	
Differential GNSS ☐ No differential GNSS	□ Differential GNSS by	Message 17

Federal Maritime and Hydrographic Agency



1.5 Legend

Result marking (in the "result" column):
Passed Item is ok, test was successful

Not passed Test of a required item was not successful, change required

N/T Not tested N/A Not applicable

Specific remarks (in the "remark" column, marked "bold italic"):

REC Recommendation (in terms of IEC17025 "opinion"): an improvement or change

is recommended

Note Note or comment (in terms of IEC17025 "interpretation"): rationale for specific

results or interpretation of requirements as appropriate

1.6 General observations

General observations not specific to any test item of the test standard are listed here:

		General problems	
Date	Item	Remark	Result
2016-05-31	Area settings	Sometimes the area settings are lost. In the first sw edition it happened every 2030 minutes.	
		In the second edition it still happens but not so often.	
		Retest 2016-07-05 Ba:	
		A loss of area settings has not been observed during the current test phase.	Passed
2016-05-31	Rx probability	The Rx probability of receiver A is rather bad, about 70 %.	
		The Rx probability of receiver B is good, about 100 %.	
		See the diagram of Rx probability for details under different Rx conditions.	
		Retest 2016-07-05 Ba:	Passed
		The Rx probability is sufficient (See test 10.2.1.5 and 10.2.1.6)	Passeu
2016-07-05	Alarm 002	The alarm 002 VSWR exceeded is always active on EUT #2.	
		Tested with different cables and dummy load directly on the antenna connector.	
		It is a problem of EUT #2 only. EUT #3 does not show this failure.	
		Retest 2016-07-12 Ba:	Passed
		After an adjustment of the VSWR setting there is no alarm with correct load.	rasseu

Federal Maritime and Hydrographic Agency



2 9 Power supply, environmental and EMC tests

2.1 9.5 Under voltage test (brown out)

9.5.1 Purpose

This test simulates the situation where the nominal supply voltage drops to below acceptable levels and then recovers over a medium time-period.

9.5.2 Method of test

Operate the EUT at the nominal supply voltage as indicated by the manufacturer.

- a) Gradually reduce the supply voltage to 40 % of the nominal supply voltage over 30 s.
- b) Gradually increase the supply voltage back to 80 % of the nominal supply voltage over 30 s.

9.5.3 Required result

Confirm that

- a) the unit shall not enter into any undefined or undesirable state as verified by a performance check,
- b) the EUT shall recover and be fully operational as verified by a performance check.

2016-12-02	Tester: Ba	Test details: Under	Test details: Under voltage test (brown out)		
Test item	-	Check	Remark	Result	
Reduce supply within 30 s to a nominal voltage	40% of the	Run a performance check and observe the EUT	UTC 08:02 40% = 4.8 V At 7.5 Volt the Power LED is switched off and the EUT stops operation	Passed	
Reduce supply within 30 s to 8 nominal voltage	30% of the	Observe the EUT and run a performance check and	At 8 Volt the Power LED is switched on and the EUT starts operation	Passed	
Operate the E the nominal vo		Run a performance check and	The performance check is successful	Passed	

Federal Maritime and Hydrographic Agency



2.2 9.6 Under voltage test (short term)

9.6.1 Purpose

This test simulates the situation where the nominal supply voltage drops to below acceptable levels for a short period and then recovers.

9.6.2 Method of test

Operate the EUT at the nominal supply voltage as indicated by the manufacturer.

- a) Reduce the supply voltage to 40 % of the nominal supply voltage over 1 s.
- b) Increase the supply voltage back to 80 % of the nominal supply voltage over 1 s.

9.6.3 Required result

The following results are required.

- a) The unit shall not enter into any undefined or undesirable state as verified by a performance check.
- b) The EUT shall recover and be fully operational as verified by a performance check.

2016-12-02	Tester: Ba	Test details: Under voltage test (short term)		
Test item		Check	Remark	Result
Reduce supply within 30 s to 4 nominal voltag	40% of the	Run a performance check and observe the EUT	UTC 08:09 40% = 4.8 V At 7.5 Volt the Power LED is switched off and the EUT stops operation	Passed
Reduce supply within 30 s to 8 nominal voltage	30% of the	Observe the EUT and run a performance check and	At 8 Volt the Power LED is switched on and the EUT starts operation	Passed
Operate the E the nominal vo		Run a performance check and	The performance check is successful	Passed

Federal Maritime and Hydrographic Agency



3 10 Operational tests

3.1 10.1 General

3.1.1 10.1.1 Tests by inspection (See 4.1.2, 4.2, 4.3, 6.1)

10.1.1.1 Method of measurement

By inspection of documentation.

10.1.1.2 Required results

The relevant requirements shall be met.

2016-11-29	Tester: Ba	Test details: 7	ests by inspection	
Test item		Check	Remark	Result
4.1.2 Quality a	ssurance			•
Quality control	system	Check the manufacturer's quality control system.	An ISO 9001 certificate from SGS and a Marine Equipment Directive Module D Quality System Certificate from BABT is provided	Passed
4.2 Manuals				
Type of extern	al connectors	Check that information about external connectors is provided, if applicable.	Cables with the external connectors on one end and open wire at the other end are provided.	Passed
			The meaning of the colour of the wires is provided	
Installation		Check that information for correct installation is provided.		Passed
		Check that information for correct positioning of the antennas is provided.		Passed
Compass safe	distance	Check that the Compass safe distance value is provided.	A value of 0.55 m is provided in the manual. Remark: It can be changed to	Passed
			0.30 m based on the CSD measurement	
4.3 Marking and identification (in addition to IEC 60945, 4.9)				
Power supply		Check that details of the power supply are provided.	The power supply voltage is provided on the type label ("12 / 24 V DC")	Passed
Battery replace	ement	If applicable, check that the date for replacement of batteries is provided.	Not applicable because there is no battery which needs replacement	Passed

Federal Maritime and Hydrographic Agency



6.1 Internal processes		
Inspect the documentation that the following internal processes are implemented	A communication processor, capable of operating in the VHF Maritime Mobile Service band	Passed
	One TDMA transmitter	Passed
	Two TDMA receiving processes	Passed
	One DSC receiving process	Passed
	Means for automatic channel switching in the maritime mobile band by Message 22	Passed
	Means for automatic channel switching in the maritime mobile band by DSC	Passed
	Manual channel switching shall not be provided.	Passed
	An internal GNSS position sensor, resolution 1/10 000 minute, using WGS-84 datum only	Passed

3.1.2 10.1.2 Safety of operation (See 4.1.3)

10.1.2.1 Purpose

To ensure the safety of operation.

10.1.2.2 Method of measurement

By inspection.

10.1.2.3 Required result

The requirements of 4.1.3 shall be met.

2016-11-29	Tester: Ba	Test details: Safety of operation		
Test item		Check	Remark	Result
Verify by inspe	ection			
Software modi	ification	It shall not be possible for the operator to augment, amend or erase any program software required for operation in accordance with this equipment standard.	Description in document: WIDELINK B-600 Technical Notes TN-600-001.pdf	Passed
Modification of	f data	Data used during operation and stored in the system shall be protected in such a way that necessary modifications and amendments by the user cannot endanger its integrity and correctness.		Passed

Federal Maritime and Hydrographic Agency



3.1.3 10.1.3 Additional features

(See 4.1.4)

10.1.3.1 Purpose

To ensure that any additional or optional features do not adversely affect operation of the EUT.

10.1.3.2 Method of measurement

Operate the EUT in standard test environment and enable any additional features provided. Repeat tests that might be affected by the additional feature.

10.1.3.3 Required results

The requirements of 4.1.4 shall be met.

2016-11-30	Tester: Ba	Test details: Additional features		
Test item		Check	Remark	Result
	Enable all additional features. Repeat tests that might be affected by the additional features			
Repetition of to performance a load.		Check that the additional features do not degrade the performance of the equipment.	Document: WIDELINK B-600 Technical Notes TN-600-001.pdf The manufacturer has documented that the additional features have not affected the normal operation.	Passed

Federal Maritime and Hydrographic Agency



3.2 10.2 Modes of operation

(See 6.4)

3.2.1 10.2.1 Autonomous mode

3.2.1.1 10.2.1.1 Transmit position reports

10.2.1.1.1 Purpose

The purpose of this test is to ensure that the EUT transmits in the autonomous mode.

10.2.1.1.2 Method of measurement

Set up standard test environment. Record the VDL communication and check for messages transmitted by the EUT.

10.2.1.1.3 Required result

Confirm that the EUT transmits Messages 18 and 24 part A and B following the autonomous continuous schedules, alternating between channels A and B.

Confirm that the EUT transmits Messages 18 and 24 part A and B following the autonomous continuous schedules, alternating between channels A and B and that Message 27 is not transmitted on the long-range channels when the default setting is used.

2016-05-13	Tester: Ba	Test details: Transmission of position reports		
Test item		Check	Remark	Result
Setup standar	d environment			•
Message 18		Check that the Message 18 is transmitted continuously.		Passed
Message 24 A		Check that the Message 24 A is transmitted continuously.		Passed
Message 24 B		Check that the Message 24 B is transmitted continuously.		Passed
Message 27		Check that the Message 27 is not transmitted when the default setting is used		Passed
Channels		Check that the transmissions alternate between channel A and B.		Passed

Federal Maritime and Hydrographic Agency



3.2.1.2 10.2.1.2 Receive AIS Class A position reports

10.2.1.2.1 Purpose

The purpose of this test is to ensure that the EUT receives AIS Class A position reports in the autonomous mode.

10.2.1.2.2 Method of measurement

Set up standard test environment. Perform the tests below and validate the required result for each test.

- Switch on test targets, and then start operation of the EUT.
- Start operation of the EUT, and then switch on test targets.
- Transmit test targets using same time slots on channels A and B.
- Transmit test targets that are not synchronised to time slot boundaries on channels A and B.

Check the VDL communication and external interface of the EUT and, where provided, display.

10.2.1.2.3 Required result

Confirm that the EUT receives continuously under the conditions above and outputs the received messages on the external interface in accordance with IEC 61162 and, where provided, on the display.

2016-05-13	Tester: Ba	Test details: Receive	e Class A position reports	
Test item		Check	Remark	Result
Switch on test	targets, and the	en start operation of EUT.		
Check the follo	owing items on	VDM output of the PI compared with the	ne transmitted values.	
Received targe	ets	Check that the received targets are continuously output as VDM.		Passed
		Check that the VDM sentences are correct according to IEC 61162.		Passed
Optional displa	ay	Check that the targets are displayed on the display.	No display implemented	N/A
Targets on sar and B	me slots on A	Check that both targets which use the same slots on A and B are output as VDM.		Passed
Unsynchronize	ed targets	Check that unsynchronized targets are output as VDM.		Passed
Start operation of EUT, and then switch on test targets.				
Check the following items on VDM output of the PI compared with the transmitted values.				
Received targe	ets	Check that the received targets are continuously output as VDM.		Passed

Federal Maritime and Hydrographic Agency



3.2.1.3 10.2.1.3 Receive AIS Class B "SO" position reports

10.2.1.3.1 Purpose

The purpose of this test is to ensure that the EUT receives AIS Class B "SO" position reports in the autonomous mode.

10.2.1.3.2 Method of measurement

Set up standard test environment. Simulate at least one additional Class B "SO" test target (bit stuffing shall not exceed 4 bits). Perform the tests below and validate the required result for each test.

- Switch on test targets, and then start operation of the EUT.
- Start operation of the EUT, and then switch on test targets.
- Transmit test targets using same time slots on channels A and B.
- Transmit test targets that are not synchronised to time slot boundaries on channels A and B.

Check the VDL communication and external interface of the EUT and, where provided, display.

10.2.1.3.3 Required result

Confirm that the EUT receives continuously under the conditions above and outputs the received messages on the external interface and, where provided, on the display.

2016-05-13	Tester: Ba	Test details: Receive (Class B SO position reports	
Test item		Check	Remark	Result
a) Switch on te	est targets, and	then start operation of the EUT.		
Check the follo	wing items on '	VDM output of the PI compared with the	ne transmitted values.	
Received targe	ets	Check that the received targets are continuously output as VDM.		Passed
		Check that the VDM sentences are correct according to IEC 61162.		Passed
Optional displa	ay	Check that the targets are displayed on the display.	No display implemented	N/A
Targets on sar and B	ne slots on A	Check that both targets which use the same slots on A and B are output as VDM.		Passed
Unsynchronize	ed targets	Check that unsynchronized targets are output as VDM.		Passed
b) Start operation of the EUT, and then switch on test targets.				
Check the following items on VDM output of the PI compared with the transmitted values.				
Received targe	ets	Check that the received targets are continuously output as VDM.		Passed

Federal Maritime and Hydrographic Agency



3.2.1.4 10.2.1.4 Receive AIS Class B "CS" position reports

10.2.1.4.1 Purpose

The purpose of this test is to ensure that the EUT receives AIS Class B "CS" position reports in the autonomous mode.

10.2.1.4.2 Method of measurement

Set up standard test environment. Simulate at least one additional Class B "SO" test target (bit stuffing shall not exceed 4 bits). Perform the tests below and validate the required result for each test.

- Switch on test targets, and then start operation of the EUT.
- Start operation of the EUT, and then switch on test targets.
- Transmit test targets using same time slots on channels A and B.
- Transmit test targets that are not synchronised to time slot boundaries on channels A and B.

Check the VDL communication and external interface of the EUT and, where provided, display.

10.2.1.4.3 Required result

Confirm that the EUT receives continuously under the conditions above and outputs the received messages on the external interface and, where provided, on the display.

2016-05-13	Tester: Ba	Test details: Receive (Class B CS position reports		
Test item		Check	Remark	Result	
a) Switch on te	est targets, and	then start operation of the EUT.			
Check the follo	owing items on	VDM output of the PI compared with the	ne transmitted values.		
Received targe	ets	Check that the received targets are continuously output as VDM.		Passed	
		Check that the VDM sentences are correct according to IEC 61162.		Passed	
Optional displa	ay	Check that the targets are displayed on the display.	No display implemented	N/A	
Targets on sar and B	me slots on A	Check that both targets which use the same slots on A and B are output as VDM.		Passed	
Unsynchronize	ed targets	Check that unsynchronized targets are output as VDM.		Passed	
b) Start operat	b) Start operation of the EUT, and then switch on test targets.				
Check the following items on VDM output of the PI compared with the transmitted values.					
Received targe	ets	Check that the received targets are continuously output as VDM.		Passed	

Federal Maritime and Hydrographic Agency



3.2.1.5 10.2.1.5 Receive in time slot adjacent to own transmission

10.2.1.5.1 Purpose

The purpose of this test is to ensure that the EUT receives position reports in the slot adjacent to own transmission in the autonomous mode.

10.2.1.5.2 Method of measurement

Set up standard test environment. Simulate 80 % VDL loading. The reporting interval of the EUT may be decreased for the purpose of this test.

Check the external Interface of the EUT.

10.2.1.5.3 Required result

Confirm that the EUT continuously receives messages in the slots before and after own transmission with an acceptable loss of 5 %.

2016-05-17	Tester: Ba	Test details: Red	ceive in adjacent slots	
Test item		Check	Remark	Result
Test scenario:	Setup standard environment. Simulate 80% VDL load. Test scenario: The EUT is operated in slot assigned mode. Specific targets are transmitted in the slots before and after the EUT Tx slots. The receiving probability of these targets is evaluated.			
Target transm adjacent to ow	issions in slots n Tx slots	Check that target reports are received in the slot before the own Tx slot with < 5% loss.	Channel A: 36 – 49 % loss Channel B: 1 – 4 % loss Retest 2016-07-01 Ba: Channel A: 0.5 % loss Channel B: 1.1 % loss	Passed
		Check that target reports are received in the slot after the own Tx slot with < 5% loss.	Channel A: 19 - 22 % loss Channel B: 0 - 0.5 % loss Retest 2016-07-01 Ba: Channel A: 1.1 % loss Channel B: 0 % loss	Passed

3.2.1.6 10.2.1.6 High VDL loading reception test

10.2.1.6.1 Purpose

The purpose of this test is to ensure that the EUT receives position reports under high VDL loading in the autonomous mode.

10.2.1.6.2 Method of measurement

Set up standard test environment. Simulate 90 % VDL loading.

Check the external Interface of the EUT.

10.2.1.6.3 Required result

Confirm that the EUT continuously receives messages and outputs the received messages on the external interface with a loss of not more than 2 %.

Federal Maritime and Hydrographic Agency



2016-05-17	Tester: Ba	Test details: High VDL loading test		
Test item	-	Check	Remark	Result
Setup standar	d environment.		•	•
Simulate 90%	VDL load.	Check that target reports are	Channel A: 7.9 % loss	
		received with < 2% loss.	Channel B: 0.3 % loss	
			Retest 2016-06-29 Ba:	
			Channel A: 1.1 % loss	Passed
			Channel B: 0.2 % loss	

3.2.2 10.2.2 Single Messages

3.2.2.1 10.2.2.1 Transmit an addressed binary message

10.2.2.1.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode.

- a) Initiate the transmission of an addressed binary Message 6 by the EUT using an ABM sentence input. An acknowledgement Message 7 shall be applied. Record the transmitted messages.
- b) Repeat the test without acknowledgement.
- c) Repeat test with a Message 6 exceeding 2 slots.
- d) Apply more than 3 ABM sentences with 1 slot Message 6 to the EUT.
- e) Repeat test a) with the addressed unstructured binary Message 25.
- f) Repeat tests a), b) and d) with the addressed structured binary Message 25.
- g) Repeat test a) with a single addressed unstructured binary Message 26.
- h) Repeat tests a), b), c) and d) with a single addressed structured binary Message 26.

10.2.2.1.2 Required results

Check that

- a) the EUT transmits Message 6 as appropriate within 30 s. Check the content of Message 6. Check that the EUT outputs the appropriate ABK sentence.
- b) the EUT transmits Message 6 as appropriate. Check that the EUT outputs the appropriate ABK sentence indicating that no acknowledgment has been received. Check that the EUT does not retransmit Message 6.
- c) the EUT does not transmit Message 6. Check that the EUT outputs the appropriate ABK sentence indicating that the message could not be sent.
- d) the EUT transmits the first 3 Message 6s and does not transmit all following Message 6s within one frame. Check that the EUT outputs the appropriate ABK sentence indicating that the message could not be sent.
- e) the EUT transmits Message 25 as appropriate.
- f) the EUT transmits Message 25 as appropriate.
- g) the EUT transmits Message 26 as appropriate.
- h) the EUT transmits Message 26 as appropriate.



2016-05-18	Tester: Ba	Test details: a) Addressed binar	Test details: a) Addressed binary Message 6 with acknowledgement		
Test item		Check	Remark	Result	
Transmit an add	dressed binary	message 6 by sending an ABM sente	ence to the PI		
PI sentence: Fil	le AIABM_bin.s	sst:			
Apply an ackno	wledgement M	lessage 7 on the VDL			
Transmission		Check that message 6 is transmitted within 30 s.		Passed	
		Check the VDO output on PI for correct format and content.		Passed	
		Check the VDL transmission for correct content.		Passed	
Message seque	ence number	Check that sequence number in VDL message = Sequential message identifier of ABM sentence.		Passed	
Repetition		Check that message 6 is not repeated.		Passed	
AIABK acknow	ledgement	Check AIABK sentence, status = 0.		Passed	

2016-05-18	Tester: Ba	Test details: b) Addressed binary	message 6 without acknowledg	jement
Test item		Check	Remark	Result
PI sentence: F	Transmit an addressed binary message 6 by sending an ABM sentence to the PI PI sentence: File AIABM_bin.sst: No acknowledgement Message 7 on the VDL			
Transmission	gement wessaç	Check that message 6 is transmitted within 30 s.		Passed
Repetition		Check that message 6 is not repeated.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 1.		Passed

2016-05-18	Tester: Ba	Test details: c) Addressed binary message 6 exceeding 2 slots		
Test item		Check	Remark	Result
	Transmit an addressed binary message 6 exceeding 2 slots by ABM to the PI PI sentence: File AIABM long.sst:			
Transmission		Check that message 6 is not transmitted.		Passed
		Check that there is no VDO output on PI.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 2.		Passed



2016-05-18	Tester: Ba	Test details: d) More than 3 Message 6 within one frame		
Test item		Check	Remark	Result
	an 3 ABM sente ile AIABM_mul	ences per frame for transmission of Meti.sst:	essages 6 (1 slot)	
First 3 Messag	ges	Check that the first 3 Messages 6 are transmitted within 30 s after the ABM input.		Passed
		Check AIABK sentence, status = 0.		Passed
Further messa frame	iges within a	Check that the further Messages 6 are not transmitted.		Passed
		Check that there is an AIABK sentence for each ABK, status = 2.		Passed

2016-05-18	Tester: Ba	Test details: e) Addressed unstructured binary message 25			
Test item		Check	Remark	Result	
70 to the PI. N	Transmit an addressed unstructured binary message 25 by sending an ABM sentence with Message type 70 to the PI. No acknowledgement is applied PI sentence: File AIABM_msg70.sst				
Transmission		Check that message 25 is transmitted within 30 s.		Passed	
		Check the VDO output on PI for correct format and content.		Passed	
		Check the VDL transmission for correct content.		Passed	
Repetition		Check that message 25 is not repeated.		Passed	
AIABK acknow	vledgement	Check AIABK sentence, status = 3.	Status = 3	Passed	
		Check that Message sequence number in ABK = Sequential message identifier of ABM sentence.		Passed	

2016-05-18	Tester: Ba	Test details: f) Addressed	structured binary message 25	
Test item	·	Check	Remark	Result
(a, b) Transmi	it an addressed	structured binary message 25 by send	ling an ABM sentence to the PI	-
PI sentence: F	File AIABM_msg	g25.sst		
No acknowled	lgement is appli	ed		
Transmission		Check that message 25 is transmitted within 30 s.		Passed
		Check the VDO output on PI for correct format and content.		Passed
		Check the VDL transmission for correct content		Passed
Repetition		Check that message 25 is not repeated.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 3.		Passed



2016-05-18	Tester: Ba	Test details: f) Addressed structured binary message 25		
Test item		Check	Remark	Result
		Check that Message sequence number in ABK = Sequential message identifier of ABM sentence.		Passed
(d) Apply more than 3 ABM sentences per frame for transmissions of one slot structured Messages 2 PI sentence: File AIABM msg25 multi.sst:			25	
First 3 Messag	ges	Check that the first 3 Messages 25 are transmitted within 30 s after the ABM input.		Passed
		Check AIABK sentence, status = 3		Passed
Further messa frame	iges within a	Check that the further Messages 25 are not transmitted.		Passed
		Check that there is an AIABK sentence for each ABK, status = 2.		Passed

2016-05-18	Tester: Ba	Test details: g) Addressed	unstructured binary message 26	6	
Test item		Check	Remark	Result	
Transmit an ac	Transmit an addressed unstructured binary message 26 by sending an ABM sentence with Message type 71 to the PI.				
PI sentence: F	File AIABM_msg	g71.sst			
Transmission		Check that message 26 is transmitted within 30 s.		Passed	
		Check the VDO output on PI for correct format and content.		Passed	
		Check the VDL transmission for correct content.		Passed	
Repetition		Check that message 26 is not repeated.		Passed	
AIABK acknow	wledgement	Check AIABK sentence, status =3.		Passed	
		Check that Message sequence number in ABK = Sequential message identifier of ABM sentence.		Passed	

Federal Maritime and Hydrographic Agency



2016-05-18 Tester: Ba Test details: h) Addressed structured binary message 26 Test item Check Remark Result (a, b) Transmit an addressed structured binary message 26 by sending an ABM sentence to the PI PI sentence: File AIABM msg26.sst No acknowledgement Check that message 26 is Passed Transmission transmitted within 30 s. Check the VDO output on PI for Passed correct format and content. Check the VDL transmission for Passed correct content. Repetition Check that message 26 is not Passed repeated. AIABK acknowledgement Check AIABK sentence, status = 3. Passed Check that Message sequence Passed number in ABK = Sequential message identifier of ABM sentence. (c) Transmit an addressed binary message 26 exceeding 2 slots by ABM to the PI PI sentence: File AIABM long.sst: Transmission Check that message 26 is not Passed transmitted. Check that there is no VDO output Passed on PI. AIABK acknowledgement Check AIABK sentence, status = 2. Passed (d) Apply more than 3 ABM sentences per frame for transmissions of one slot structured Messages 26 PI sentence: File AIABM msg26 multi.sst: First 3 Messages Check that the first 3 Messages 26 Passed are transmitted within 30 s after the ABM input. Check AIABK sentence, status = 0 Passed Check that the further Messages 26 Passed Further messages within a are not transmitted. frame Check that there is an AIABK Passed

3.2.2.2 10.2.2.2 Transmit an addressed safety related Message 12

sentence for each ABK, status = 2.

10.2.2.2.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode.

Initiate the transmission of an addressed binary Message 12 by the EUT using an ABM sentence input.

10.2.2.2.2 Required results

Check that the EUT does not transmit Message 12.

Federal Maritime and Hydrographic Agency



2016-05-18	Tester: Ba	Test details: c) Addressed safety related Message 12		
Test item	-	Check	Remark	Result
Transmit an addressed safety related text message 2 by ABM to the PI PI sentence: File AIABM bin.sst:				
Transmission		Check that message 12 is not transmitted.		Passed
		Check that there is no VDO output on PI.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 2.		Passed

3.2.2.3 10.2.2.3 Acknowledgement of addressed Messages

10.2.2.3.1 Purpose

The purpose of this test is to ensure that the EUT acknowledges addressed messages in the autonomous mode.

10.2.2.3.2 Method of measurement

Operate standard test environment and the EUT in autonomous mode.

- a) Apply an addressed binary Message 6 with the EUT as destination to the VDL on Channel A. Record transmitted messages on both channels.
- b) Repeat for Message 12.
- c) Repeat the test a) on channel B.

10.2.2.3.3 Required results

Confirm that

- a) the EUT transmits a binary acknowledge Message 7, with the appropriate sequence numbers within 4 s on the channel where the Message 6 was received.
- b) the EUT transmits a binary acknowledge Message 13, with the appropriate sequence numbers within 4 s on the channel where the Message 12 was received.
- c) the EUT transmits a binary acknowledge Message 7 on channel B.

Federal Maritime and Hydrographic Agency



2016-05-18 Tester: Ba Test details: a) Acknowledgement of binary message 6 Test item Check Remark Result Transmit an addressed binary Message 6 with EUT as destination on channel A of the VDL Check by VDM output on PI of EUT Passed RX of messages (VDM) that Message 6 is received. Passed Transmission of ackn. Check transmission of ackn. Message 7 Message 7 by the EUT. Check the content of Message 7. Passed Check that Message 7 is Passed transmitted within 4 s. Sequence numbers Check that sequence number in Passed ackn. = sequence number of R_X message. Ackn. channel Check that ackn. T_X channel = Passed channel A (= Rx channel).

2016-05-18	Tester: Ba	Test details: b) Acknowledgement of safety related Message 12		
Test item		Check	Remark	Result
Transmit an ad	Transmit an addressed safety related Message 12 with EUT as destination on the VDL			
RX of messag	es (VDM)	Check by VDM output on PI of EUT that Message 6 is received.		Passed
Transmission Message 13	of ackn.	Check transmission of ackn Message 13. by the EUT.		Passed
		Check the content of Message 13.		Passed
		Check that Message 13 is transmitted within 4 s.		Passed
Sequence nun	nbers	Check that sequence number in ackn. = sequence number of R_X message.		Passed
Ackn. channel		Check that ackn. T_X channel = channel A (= Rx channel).		Passed

2016-05-18	Tester: Ba	Test details: c) Acknowledgement on channel B		
Test item		Check	Remark	Result
Transmit an ad	Transmit an addressed binary Message 6 with EUT as destination on channel B of the VDL			
RX of messag	es (VDM)	Check by VDM output on PI of EUT that Message 6 is received.		Passed
Transmission Message 7	of ackn.	Check transmission of ackn. Message 7 by the EUT.		Passed
Ackn. channel		Check that ackn. T _x channel = channel B.		Passed

Federal Maritime and Hydrographic Agency



3.2.2.4 10.2.2.4 Transmit a broadcast binary Message 8

10.2.2.4.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode.

- a) Initiate the transmission of a broadcast binary Message 8 by the EUT using a BBM sentence input. Record the transmitted messages.
- b) Repeat test with a Message 8 exceeding 2 slots.
- c) Apply more than 3 BBM sentences with 1 slot Message 8 to the EUT.
- d) Repeat test a) with the broadcast unstructured binary Message 25.
- e) Repeat tests a) and c) with the broadcast structured binary Message 25.
- f) Repeat test a) with a single broadcast unstructured binary Message 26.
- g) Repeat tests a), b) and c) with a single broadcast structured binary Message 26.

10.2.2.4.2 Required results

Check that

- a) the EUT transmits Message 8 as appropriate within 30 s. Check the content of Message 8. Check that the EUT outputs the appropriate ABK sentence.
- b) the EUT does not transmit Message 8. Check that the EUT outputs the appropriate ABK sentence indicating that the message could not be sent.
- c) the EUT transmits the first 3 Message 8s and does not transmit all following Message 8s. Check that the EUT outputs the appropriate ABK sentence indicating that the message could not be sent.
- d) the EUT transmits Message 25 as appropriate.
- e) the EUT transmits Message 25 as appropriate.
- f) the EUT transmits Message 26 as appropriate.
- g) the EUT transmits Message 26 as appropriate.

2016-05-18	Tester: Ba	Test details	s: a) Message 8	
Test item		Check	Remark	Result
Apply a BBM s	sentence with m	nessage type 8 for transmission of a bi	nary message to the PI.	
PI sentence: F	ile AIBBM_bin.	sst:		
Transmission	of Message 8	Check the VDO output on Pl.		Passed
		Check that Message 8 is transmitted within 30 s after BBM input.		Passed
Channel		Check T _X on channel according to BBM.		Passed
AIABK acknow	vledgement	Record and check the AIABK acknowledgement with message type 8, status = 3		Passed
		Check that Message sequence number in ABK = Sequential message identifier of BBM sentence.		Passed
Message cont	ent	Check message content.		Passed



2016-05-18	Tester: Ba	Test details: b) Message 8 exceeding 2 slots		
Test item		Check	Remark	Result
Transmit an broadcast binary message 8 exceeding 2 slots by BBM to the PI PI sentence: File AIBBM_long.sst:				
Transmission		Check that message 8 is not transmitted.		Passed
		Check that there is no VDO output on PI.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 2.		Passed

2016-05-18	Tester: Ba	Test details: c) More than	3 Message 8 within one frame	
Test item		Check	Remark	Result
	an 3 BBM sente ile AIBBM_mul	ences per frame for transmission of Meti.sst:	essages 8 (1 slot)	
First 3 Messag	ges	Check that the first 3 Messages 8 are transmitted within 30 s after the BBM input.		Passed
		Check AIABK sentence, status = 3.		Passed
Further messa frame	iges within a	Check that the further Messages 8 are not transmitted.		Passed
		Check that there is an AIABK sentence for each ABK, status = 2.		Passed

2016-05-18	Tester: Ba	Test details: d) Broadcast	unstructured binary message 25	5
Test item	-	Check	Remark	Result
Transmit a broadcast unstructured binary message 25 by sending a BBM sentence with Message type 70 to the PI. PI sentence: File AIBBM_msg70.sst				
Transmission		Check that message 25 is transmitted within 30 s.		Passed
		Check the VDO output on PI for correct format and content.		Passed
		Check the VDL transmission for correct content.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 0.		Passed
		Check Message type = 70		Passed
		Check that Message sequence number in ABK = Sequential message identifier of BBM sentence.		Passed



2016-05-18	Tester: Ba	Test details: e) Broadcast	t structured binary message 25	
Test item	<u> </u>	Check	Remark	Result
1 1	ile AIABM_ms	ctured binary message 25 by sending g25.sst	an BBM sentence to the PI	
Transmission		Check that message 25 is transmitted within 30 s.		Passed
		Check the VDO output on PI for correct format and content.		Passed
		Check the VDL transmission for correct content.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 3.		Passed
		Check Message type = 25		Passed
		Check that Message sequence number in ABK = Sequential message identifier of ABM sentence.		Passed
(c) Apply more	than 3 ABM s	entences per frame for transmissions of	of structured Messages 25 (1 slo	ot)
PI sentence: F	ile AIABM_ms	g25_multi.sst:		
First 3 Messag	ges	Check that the first 3 Messages 25 are transmitted within 30 s after the ABM input.		Passed
		Check AIABK sentence, status = 3.		Passed
Further messa frame	ages within a	Check that the further Messages 25 are not transmitted.		Passed
		Check that there is an AIABK sentence for each ABK, status = 2.		Passed

2016-05-18	Tester: Ba	Test details: f) Broadcast u	ınstructured binary message 26		
Test item	<u>-</u>	Check	Remark	Result	
the PI.	Transmit a broadcast unstructured binary message 26 by sending a BBM sentence with Message type 71 to the PI. PI sentence: File AIBBM_msg71.sst				
Transmission	אום איים וויים	Check that message 26 is transmitted within 30 s.		Passed	
		Check the VDO output on PI for correct format and content.		Passed	
		Check the VDL transmission for correct content.		Passed	
AIABK acknow	wledgement	Check AIABK sentence, status = 3.		Passed	
		Check Message type = 71		Passed	
		Check that Message sequence number in ABK = Sequential message identifier of ABM sentence.		Passed	

Federal Maritime and Hydrographic Agency



2016-05-18	Tester: Ba	Test details: g) Broadcast	structured binary message 26	
Test item		Check	Remark	Result
` '	broadcasts stru	uctured binary message 26 by sending g26.sst	an BBM sentence to the PI.	
Transmission		Check that message 26 is transmitted within 30 s.		Passed
		Check the VDO output on PI for correct format and content.		Passed
		Check the VDL transmission for correct content.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 3.		Passed
		Check Message type = 26		Passed
		Check that Message sequence number in ABK = Sequential message identifier of BBM sentence.		Passed
` '	M sentence to ile AIBBM_Mso	the PI for a broadcast binary message g26_long.sst:	e 26 exceeding 2 slots.	
Transmission		Check that message 26 is not transmitted.		Passed
		Check that there is no VDO output on PI.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 2.		Passed
	than 3 BBM se ile AIBBM_msg	entences per frame for transmissions og 26_multi.sst:	of structured Messages 26 (1 slo	ot).
First 3 Messag	ges	Check that the first 3 Messages 26 are transmitted within 30 s after the ABM input.		Passed
		Check AIABK sentence, status = 3.		Passed
Further messa frame	ges within a	Check that the further Messages 26 are not transmitted.		Passed
		Check that there is an AIABK sentence for each ABK, status = 2.		Passed

3.2.2.5 10.2.2.5 Transmit a broadcast safety related Message 14

10.2.2.5.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode.

Initiate the transmission of a broadcast binary Message 14by the EUT using an BBM sentence input.

10.2.2.5.2 Required results

Check that the EUT does not transmit Message 14.

Federal Maritime and Hydrographic Agency



2016-05-18	Tester: Ba	Test details: Broadcast safety related Message 14		
Test item		Check	Remark	Result
	sentence to tranfile AIBBM_safe	ismit a broadcast safety related text mety.sst:	essage 14.	
Transmission		Check that message 14 is not transmitted.		Passed
		Check that there is no VDO output on PI.		Passed
AIABK acknow	wledgement	Check AIABK sentence, status = 2.		Passed

3.2.2.6 10.2.2.6 ITDMA and RATDMA transmission

(See 7.3.4.2, 7.6)

10.2.2.6.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode.

- a) Apply a 1 slot binary broadcast message (Message 8) to the PI of the EUT less than 30 s before the next scheduled transmission. Record transmitted messages.
- b) Apply a 1 slot binary broadcast message (Message 8) to the PI of the EUT more than 30 s before the next scheduled transmission. Record transmitted messages.

10.2.2.6.2 Required results

Confirm that

- a) the EUT transmits this Message 8 within 30 s using ITDMA.
- b) the EUT transmits this Message 8 within 30 s using RATDMA.

2016-05-18	Tester: Ba	Test details: ITDMA	and RATDMA transmission	
Test item		Check	Remark	Result
Apply binary broadcast Messages 8 to the PI port of the EUT. File name: AIBBM_bin.sst.				
a) Transmission before next so		Check that Message 8 is transmitted within 30 s.		Passed
position report Reporting inte		Check that ITDMA is used for slot allocation.		Passed
b) Transmission before next so position report	heduled	Check that Message 8 is transmitted within 30 s.	See Note) Message 8 is transmitted with RATDMA within 4 s	Passed
Reporting inte	rval = 3 min	Check that RADMA is used for channel access.		Passed

Note)

With 30s, 15s and 5 s reporting interval the time from the BBM input to the next scheduled Message 18 is always shorter than 30 s.

Therefore test b) has to be performed with 3 minutes reporting interval.

Federal Maritime and Hydrographic Agency



With 3 minutes reporting interval a slot allocation for Message 8 is generally not possible, because Message 18 is already running in ITDMA mode to allocate the next Message 18.

Therefore with 3 minutes reporting interval always RATDMA is used, independent if the BBM is more or less than 30 s before the next scheduled transmission of message 18.

3.2.3 10.2.3 Polled mode / Interrogation response (See 4.1.5, 7.3.4.3.4)

10.2.3.1 Purpose

The purpose of this test is to ensure that the EUT responds to interrogations.

10.2.3.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode. Apply interrogation Message 15 with the EUT as destination:

- a) interrogation for Message 19 with transmission offset = 0;
- b) interrogation for Message 19 with transmission offset = 10;
- c) interrogation for Message 18 with transmission offset = 0;
- d) interrogation for Message 24 with transmission offset = 0.

Record transmitted messages and frame structure.

10.2.3.3 Required results

Confirm that

- a) the EUT transmits the appropriate interrogation response message within 30 s.
- b) the EUT transmits the appropriate interrogation response message as requested after defined transmission offset.
- c) the EUT transmits the appropriate interrogation response Message 18 within 30 s.
- d) the EUT transmits the appropriate interrogation response Messages 24A within 30 s and 24B within 1 min of Message 24A.

Confirm that the EUT transmits the response on the same channel as the interrogation was received.

2016-05-18	Tester: Ba	Test details: Inte	errogation responses	
Test item		Check	Remark	Result
, , , ,	a) Apply an interrogation Message 15 requesting Message 19 with slot offset = 0 on the VDL. The request is transmitted on channel A.			
R _X of request	by EUT	Check that the request message is received by the EUT (VDM).		Passed
T _X of response	e (VDO)	Check that response is transmitted by EUT.		Passed
Response on	VDL	Check that the response is transmitted within 30 s.		Passed
Response cha	ınnel	Check that the response is transmitted on the request channel.		Passed



b) Apply on interrogation	Manage 15 requesting Manages 10 with	riven elet effect 10	
The request is transmitted	Message 15 requesting Message 19 with ເ Lon channel B	given slot offset = 10.	
R _x of request by EUT	Check that the request message is received by the EUT (VDM).		Passed
T _X of response (VDO)	Check that response is transmitted by EUT.		Passed
Response on VDL	Check that the response is transmitted with the defined slot offset.		Passed
Response channel	Check that the response is transmitted on the request channel.		Passed
c) Apply an interrogation N	Message 15 requesting Message 18 with s	slot offset = 0.	
The request is transmitted	l on channel A.		
R _x of request by EUT	Check that the request message is received by the EUT (VDM).		Passed
T _X of response (VDO)	Check that response is transmitted by EUT.		Passed
Response on VDL	Check that the response is transmitted within 30 s.		Passed
Response channel	Check that the response is transmitted on the request channel.		Passed
d) Apply an interrogation I	Message 15 requesting Message 24 with s	slot offset = 0.	
The request is transmitted	l on channel B.		
R _x of request by EUT	Check that the request message is received by the EUT (VDM).		Passed
T _X of response (VDO)	Check that response Message 24 A and 24B is transmitted by EUT.		Passed
Response on VDL	Check that Message 24 A is transmitted within 30 s after the interrogation.		Passed
	Check that Message 24 B is transmitted within 1 min after 24 A		Passed
Response channel	Check that Message 24 A and 24 B are transmitted on the request channel.	Message 24 A and 24 B are always transmitted on channel A, independent of the request channel Retest 2016-06-15 Ba:	
		The response is transmitted on the request channel	Passed

Federal Maritime and Hydrographic Agency



3.3 10.3 Channel selection

(See 6.2)

3.3.1 10.3.1 Valid channels

10.3.1.1 Purpose

The purpose of this test is to ensure that the EUT responds appropriately when given instructions to change to valid channels.

10.3.1.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode. Switch the EUT to different channels within the operating band as specified in 6.2 by transmission of channel management Message 22, broadcast and addressed to the EUT.

Record the VDL Messages on the designated channels and check "band flag" and "Message 22 flag" in Message 18.

10.3.1.3 Required results

Confirm that the EUT switches to the correct channel and uses the correct "band flag" and "Message 22 flag".

Federal Maritime and Hydrographic Agency



2016-05-18	Tester: Ba	Test details	: Valid channels		
Test item		Check	Remark	Result	
	Apply a Message 4 and a broadcast Message 22 with area settings and valid channels to the VDL. Position is inside the channel management area.				
Broadcast Mes	ssage 22	Check that channels are used.		Passed	
		Check that the Band flag in Message 18 = 1 (whole band).		Passed	
		Check that the Message 22 flag in Message 18 = 1 (Message 22 is supported).		Passed	
		Check TXT output at PI.		Passed	
		Check ACA output at PI.		Passed	
Apply a Messa	age 4 and a bro	adcast Message 22 with area settings	and other valid channels to the	VDL.	
Other valid cha	annels	Check that channels are used.		Passed	
		Check TXT output at PI.		Passed	
		Check ACA output at PI.		Passed	
Apply an addre	essed Message	22 with valid channels to the VDL. Po	sition inside a valid area.		
Addressed Me	essage 22	Check that channels are used.	Channels are only used with Message 4		
			See Note)		
			Retest 2016-06-15 Ba:	Passed	
			The channels are changed also without Message 4		
		Check TXT output at PI.	(with Message 4)		
			Retest 2016-06-15 Ba:		
			Without message 4	Passed	
		Check ACA output at PI.	(with Message 4)	Passed	
			Retest 2016-06-15 Ba:		
			Without message 4		

Note)

For an addressed message 22 a Message 4 is not required because the message is addressed explicitly to a specific station. Different to a broadcast message the 120 NM evaluation is not necessary for an addressed messages.

In ITU-R M.1371-5, Annex 8, section 3.20 there are 2 alternatives:

- As a broadcast message, accompanied by a Message 4 for evaluation of the message within 120 NM
- Alternatively as an addressed message. For this alternative Message 4 is not mentioned

Federal Maritime and Hydrographic Agency



3.3.2 10.3.2 Invalid channels

10.3.2.1 Purpose

The purpose of this test is to ensure that the EUT responds appropriately when given instructions to change to invalid channels.

10.3.2.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode. Apply a Message 22 with 25 kHz channels not specified in Recommendation ITU-R M. 1084-5.

Record the VDL messages on the designated channels.

10.3.2.3 Required results

Confirm that the EUT disregards Message 22.

2016-05-18	Tester: Ba	Test details: Invalid channels		
Test item		Check	Remark	Result
Apply an addre	essed Message	22 with invalid channels with 25 kHz	spacing to the VDL.	_
Position is insi	de a valid chani	nel management area.		
Addressed Me Invalid channe	•	Check that channels are not used.	Invalid channels are accepted, the frequencies are set to 0, The Rx malfunction alarm is activated, and the unit does not receive any messages Retest 2016-06-15 Ba: The channels are not used	Passed
		Check that there is no TXT ID 36 output on PI.	There is a TXT output Retest 2016-06-15 Ba: There is a TXT output indicating "Channel A invalid" or "Channel B invalid"	Passed
		Check that there is no ACA output on PI.	Retest 2016-06-15 Ba: There is no ACA output	Passed

3.4 10.4 Internal GNSS receiver

(See 6.3)

The following relevant tests according to the IEC 61108 series shall be performed:

- position accuracy, static;
- position accuracy, dynamic;
- COG/SOG accuracy;
- position update;
- status indications (including RAIM, when implemented);
- differential mode.

The test of the Internal GNSS receiver is not part of this test report.

Federal Maritime and Hydrographic Agency



3.5 10.5 AIS information

3.5.1 10.5.1 Information content

(See 6.5.1)

10.5.1.1 Purpose

The purpose of this test is to ensure that the EUT transmits all parameters in static and dynamic Class B AIS Messages.

10.5.1.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode. Apply all static data to the EUT.

Record all Messages on VDL and check the content of position report Message 18 and static data reports, Messages 24A and 24B.

10.5.1.3 Required results

Confirm that data transmitted by the EUT complies with static data and position sensor data.

2016-05-18	Tester: Ba	Test details: Co	ontent of Message 18	
Test item		Check	Remark	Result
		xternal position/speed sensor inputs. the optional heading input is implemen	nted.	
MMSI		Check MMSI.		Passed
Speed		Check the SOG value.		Passed
Position accur	acy flag	Check PA flag.		Passed
Position		Check the values of LAT and LON.		Passed
Heading		Check that the values of heading.	511 if no heading provided, Otherwise the correct heading	Passed
COG		Check the COG value.	Default with internal GNSS (not moving), Otherwise the correct COG	Passed
Time stamp		Check time stamp.		Passed
Class B unit fla	ag	Check that the Class B unit flag = 0 (Class B SOTDMA).	= 0	Passed
Display flag		Check that the Class B Display flag is according to the composition.	= 0 (no display)	Passed
DSC flag		Check that the DSC flag is set to 1.	= 0 (inactivated	Passed
Band flag		Check that the Band flag is set to 1.	= 1	Passed
Message 22 fl	ag	Check that the Message 22 flag is set to 1.	= 1	Passed
RAIM flag		Check the RAIM flag.	= 1	Passed
Other content		Other content of message 18 like mode flag or comm state are checked in separate tests.		



2016-05-18	Tester: Ba	Test details: Content of Message 24		
Test item		Check	Remark	Result
Content of mes	sage 24 A			
MMSI		Check value in Message 24A.		Passed
Part number		Check part number = 0.		Passed
Name of ship		Check value in Message 24A.		Passed
Content of mes	sage 24 B			
MMSI		Check value in Message 24B.		Passed
Part number		Check part number = 1.		Passed
Type of ship an	d cargo type	Check value in Message 24B.	= 36	Passed
Vendor ID		Check Manufacturer's ID.	AMC	Passed
		Check Unit model code.	0	Passed
		Check Unit serial number.	If the serial number is set to A1K600002 the value 10002 is transmitted in Message 24. "A" and "K60" are fixed parts of the serial number on the label and in VER output. The actual serial number has to be set during production	Passed
Call sign		Check Call sign.		Passed
Dimension of sl	hip/ reference	Check dim/ref A value.		Passed
for position		Check dim/ref B value.		Passed
		Check dim/ref C value.		Passed
		Check dim/ref D value.		Passed
Type of EPFS		Check Type of EPFS.	= 0, should be 15 for internal GNSS	
			(This value is new in ITU-R M.1371-5)	Passed
			Retest 2016-06-15 Ba:	
			Type of EPFS = 15	

Federal Maritime and Hydrographic Agency



3.5.2 10.5.2 Information update intervals (See 6.5.2)

3.5.2.1 10.5.2.1 Autonomous reporting interval

10.5.2.1.1 Purpose

The purpose of this test is to ensure that the EUT adopts the correct reporting interval for its SOG.

10.5.2.1.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode.

- a) Start with own SOG of 1 kn; record all Messages on VDL for at least 30 min and evaluate reporting interval for position report of the EUT by calculating average transmission offset over test period.
- b) Increase speed to 3 kn.
- c) Increase speed to 15 kn.
- d) Increase speed to 24 kn.
- e) Reduce speed to 22 kn.
- f) Reduce speed to 13 kn.
- g) Reduce speed to 1 kn.

Record all messages on VDL and check transmission offset between two consecutive transmissions.

10.5.2.1.3 Required results

Confirm that

- a) the reporting interval is 3 min (\pm 10 s);
- b) the reporting interval is 30 s (\pm 3 s);
- c) the reporting interval is 15 s (\pm 1,5 s);
- d) the reporting interval is 5 s (± 0.5 s);
- e) the reporting interval is 15 s;
- f) the reporting interval is 30 s;
- g) the reporting interval is 3 min.

This test is performed in two steps:

- one test sequence to evaluate the rescheduling to the different reporting intervals
- one test sequence to evaluate the average transmission offset and transmission intervals. In this test the EUT is operated with each reporting interval for at least 30 minutes.



2016-05-19	Tester: Ba	Test details: Change	of reporting rate by speed,	
Test item		Check	Remark	Result
Increase spee	d according to t	he test items.		
a) Speed = 1 k	ĸn	Check that reporting interval is 3 minutes.		Passed
b) Speed = 3 k	ĸn	Check releasing slot of the old reporting interval.		Passed
		Check slot allocation for new reporting interval.		Passed
		Check that reporting interval is 30 s.		Passed
c) Speed = 15	kn	Check releasing slot of the old reporting interval.		Passed
		Check slot allocation for new reporting interval.		Passed
		Check that reporting interval is 15 s.		Passed
d) Speed = 24	kn	Check releasing slot of the old reporting interval.		Passed
		Check slot allocation for new reporting interval.		Passed
		Check that reporting interval is 5 s.		Passed
Decrease spec	ed according to	the test items.		
e) Speed = 22	kn	Check releasing slot of the old reporting interval.		Passed
		Check slot allocation for new reporting interval.		Passed
		Check that reporting interval is 15 s.		Passed
f) Speed = 13	kn	Check releasing slot of the old reporting interval.		Passed
		Check slot allocation for new reporting interval.		Passed
		Check that reporting interval is 30 s.		Passed
g) Speed = 1 k	kn	Check releasing slot of the old reporting interval.		Passed
		Check slot allocation for new reporting interval.	The first message of the 3 minutes interval on channel B is not allocated. Retest 2016-06-16 Ba:	
			The first message of the 3 minutes interval is allocated on both channels.	Passed
		Check that reporting interval is 3 minutes.		Passed



2016-05-19	Tester: Ba	Test details:	: Average values			
Test item		Check	Remark	Result		
	Modify speed to establish the required reporting intervals. Run the test of each reporting interval for at least 30 min.					
a) Speed = 1 k	kn	Check that the average reporting interval is 3 minutes +/- 10s.	Test 2016-05-20	Passed		
		Check that the transmission slots are randomly distributed over the selection interval of 20% of 180 s = 36 s = 1350 slot.		Passed		
		Check that the slot offsets are in a range of 180 s +/- 36s = 6750 +/- 1350 slots = 54008100 slots.		Passed		
b) Speed = 3 k	rn	Check that the average reporting interval is 30 s +/- 3 s.		Passed		
		Check that the transmission slots are randomly distributed over the selection interval 20% of 30s = 6 s = 225 slots.		Passed		
		Check that the slot offsets are in a range of 30 s +/- 6 s = 1125 +/- 450 slots = 9001350 slots.		Passed		
b) Speed = 15	kn	Check that the average reporting interval is 15 s +/- 1.5 s		Passed		
		Check that the transmission slots are randomly distributed over the selection interval 20% of 15s = 3 s = 112.5 slots.		Passed		
		Check that the slot offsets are in a range of 15 s +/- 3 s = 562.5 +/- 112.5 slots = 450675 slots.		Passed		
b) Speed = 24	kn	Check that the average reporting interval is 5 s +/- 0.5 s.		Passed		
		Check that the transmission slots are randomly distributed over the selection interval 20% of 5s = 1 s = 37.5 slots.		Passed		
		Check that the slot offsets are in a range of 5 s +/- 1 s = $178.5 +/- 37.5$ slots = 150225 slots.		Passed		

Federal Maritime and Hydrographic Agency



3.5.2.2 10.5.2.2 Polite behavior

10.5.2.2.1 Purpose

The purpose of this test is to ensure that the EUT adopts the correct reporting interval dependent on VDL loading and SOG.

10.5.2.2.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode. Simulate a VDL loading of 55 %. Record all messages.

- a) Start with own SOG of 1 kn.
- b) Increase speed to 20 kn.
- c) Reduce VDL loading to 40 %.
- d) Reduce VDL loading to 30 %.
- e) Increase VDL loading to 45 %.
- f) Increase VDL loading to 55 %.
- g) Increase speed to 30 kn.
- h) Reduce VDL loading to 40 %.
- i) Reduce VDL loading to 30 %.
- j) Increase VDL loading to 45 %.
- k) Increase VDL loading to 55 %.
- I) Reduce speed to 10 kn.
- m) Reduce VDL loading to 30 %.

Record all messages on the VDL.

10.5.2.2.3 Required results

Confirm that

- a) the reporting interval is 3 min,
- b) the reporting interval of 30 s has been established,
- c) the reporting interval of 30 s is maintained,
- d) the reporting interval decreases to 15 s within 4 min to 5 min,
- e) the reporting interval of 15 s is maintained,
- f) the reporting interval increases to 30 s within 4 min to 5 min,
- g) the reporting interval decreases to 15 s,
- h) the reporting interval of 15 s is maintained,
- i) the reporting interval decreases to 5 s within 4 min to 5 min,
- j) the reporting interval of 5 s is maintained,
- k) the reporting interval increases to 15 s within 4 min to 5 min,
- the reporting interval increases to 30 s,
- m) the reporting interval of 30 s is maintained.



2016	6-05-20	Tester: E	За		Tes	st details: Te	est of polite behaviour	
Appl	y speed	and VDL lo	ad accor	rding to t	he test items.	Check the re	equired reporting interval	
No.	SOG	VDL load		Inter	/al	UTC start	Remark	Result
	(kn)	(%)	Norm.	Redu.	Required			
а	1	55	3 min	3 min	3 min	09:10		Passed
b	20	55	15 s	30 s	30s	09:20		Passed
С	20	40	15 s	30 s	30s	09:30		Passed
d	20	30	15 s	30 s	15 s within 45 min	09:40		Passed
е	20	45	15 s	30 s	15 s	09:50		Passed
f	20	55	15 s	30 s	30 s within 45 min	10:00		Passed
g	30	55	5 s	15 s	15 s	10:10		Passed
h	30	40	5 s	15 s	15 s	11:40	Test 2016-05-24	Passed
i	30	30	5 s	15 s	5 s within 45 min	11:50		Passed
j	30	45	5 s	15 s	5 s	12:00		Passed
k	30	55	5 s	15 s	15 s within 45 min	12:10		Passed
I	10	55	30 s	30 s	30 s	12:20	Within 4 minutes	Passed
m	10	30	30 s	30 s	30 s	12:30		Passed

Federal Maritime and Hydrographic Agency



3.5.2.3 10.5.2.3 Static data reporting interval

10.5.2.3.1 Purpose

The purpose of this test is to ensure that the EUT maintains the static data-reporting interval.

10.5.2.3.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode. Record the transmitted messages and check for static data Messages 24A and 24B.

Repeat the test at an assigned reporting interval of 5 s for Message 18.

10.5.2.3.3 Required results

Confirm that the EUT transmits Messages 24A and 24B every 6 min. Confirm that Message 24B is transmitted within 1 min of transmission of Message 24A, and on the same channel. Transmissions shall alternate between channels A and B, and shall be independent of the Message 18 reporting interval.

2016-05-19	Tester: Ba	Test details: ITDMA tr	ansmission of Message 24			
Test item	<u> </u>	Check	Remark	Result		
	Record the VDL data of at least 30 frames operating with autonomously scheduled transmissions. Set the reporting interval of message 18 to 30 s.					
Reporting inte	rval	Check that the reporting interval of Message 24A and 24B is 6 min.		Passed		
		Check that Message 24B is transmitted within 1 min after 24A.		Passed		
		Check that Message 24B is transmitted on the same channel as 24A.		Passed		
Message type	for allocation	Check that the slots for Message 24A and 24B are allocated by Message 18 with ITDMA comm state.	3 min: no allocation 30s: Part 0 is allocated, Part 2 not 15 and 5 s: Both parts are allocated	Passed		
Number of slo	ts	Check that the number of slots = 1 (value in comm state = 0).	Value in comm state = 1 (2 slots are allocated) Retest 2016-06-16 Ba: Value in comm state = 0	Passed		
Keep flag		Check that the keep flag = 1.		Passed		
Slot allocation		Check that the slots allocated by Message 18 are used for Tx of Message 24A and 24B.		Passed		
Alternating cha	annels	Check that the pairs of Message 24A/24B are transmitted on alternating channels.		Passed		
Independent ti schedule	ransmission	Check that the transmission schedule of Message 24A/24B is independent of the Tx schedule of Message 18.	The distance between the two parts of Message 24 depends on the Message 18 reporting interval. This is necessary for correct slot allocation by Message 18	Passed		



Set the reporting interval of n	nessage 18 by rate assignment to 5 s.	
Reporting interval	Check that the reporting interval of Message 24A and 24B is 6 min.	Passed
	Check that Message 24B is transmitted within 1 min after 24A.	Passed
	Check that Message 24B is transmitted on the same channel as 24A.	Passed
Message type for allocation	Check that the slots for Message 24A and 24B are allocated by Message 18 with ITDMA comm state.	Passed
Number of slots	Check that the number of slots = 1 (value in comm state = 0).	Passed
Keep flag	Check that the keep flag = 1.	Passed
Slot allocation	Check that the slots allocated by Message 18 are used for Tx of Message 24A and 24B.	Passed
Alternating channels	Check that the pairs of Message 24A/24B are transmitted on alternating channels.	Passed
Independent transmission schedule	Check that the transmission schedule of Message 24A/24B is independent of the Tx schedule of Message 18.	Passed

Federal Maritime and Hydrographic Agency



3.6 10.6 Initialisation period

(See 6.5.2, 6.5.4)

10.6.1 Purpose

The purpose of this test is to ensure that the EUT starts to transmit within the permissible initialisation period.

10.6.2 Method of measurement

Set up standard test environment with SOG > 2 kn.

- a) Switch on the EUT from cold (off-time minimum 1 h) with the EUT operating in autonomous mode.
- b) Switch off the EUT for between 15 min to 60 min and switch on again.
- c) Make the GNSS sensor position unavailable.

Record transmitted messages.

10.6.3 Required results

Confirm that the EUT

- a) starts regular transmission of Message 18 within 2 min and valid position within 30 min after switch on,
- b) starts regular transmission of Message 18 within 2 min and valid position within 5 min after switch on,
- c) continues transmission with last known position and time stamp "63" (positioning system inoperative) with a reporting interval of 3 min. Change to default position values (91, 181) after 30 min.

2016-06-13	Tester: Ba	Test details: I	Initialisation period	
Test item		Check	Remark	Result
Power is off fo Apply a speed	r at least 1 hour > 2 kn.			
a) Switch power	er on.	Check that EUT starts transmission of Message 18 within 2 min.	UTC 10:29 1:48	Passed
		Check that EUT has a valid position within 30 min.	< 2 minutes	Passed
b) Switch power 60 min.	er off for 15	Check that EUT starts transmission of Message 18 within 2 min.	Power off: UTC 10:40 Power on: UTC 11:01:00 First msg: UTC 11:02:43	Passed
		Check that EUT has a valid position within 5 min.	< 1 min	Passed
c) Make GNSS unavailable.		Check that EUT continues transmission with last known position.	UTC 11:10	Passed
		Check that time stamp = 63.		Passed
		Check that reporting interval = 3 min.		Passed
After 30 min		Check that position = default.		Passed

Federal Maritime and Hydrographic Agency



3.7 10.7 Alarms and indications, fall-back arrangements (See 6.6)

3.7.1 10.7.1 Built in integrity test

10.7.1.1 Purpose

The purpose of this test is to ensure that the EUT has a BIIT.

10.7.1.2 Method of measurement

Check manufacturer's documentation on BIIT.

10.7.1.3 Required result

Verify that an indication is provided if a malfunction is detected and the appropriate ALR sentence is output on the PI.

2016-07-06	Tester: Ba	Test details: Built in integrity test		
Test item		Check	Remark	Result
Check manufacturer's documentation on BIIT.		Check that a malfunction indication is provided.	Test end documentation check	Passed
		Check that an appropriate ALR sentence is output on the PI if a malfunction is detected.		Passed

3.7.2 10.7.2 Transceiver protection

(See 7.6)

10.7.2.1 Purpose

The purpose of this test is to ensure that the EUT is capable of withstanding open and short circuit to the VHF-antenna terminals.

10.7.2.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode with SOG > 23 kn.

- a) Open circuit VHF-antenna terminals of the EUT for at least 5 min.
- b) Short circuit VHF-antenna terminals of the EUT for at least 5 min.
- c) Reconnect the VHF-antenna.

10.7.2.3 Required results

Check that

- a) an alarm sentence ALR with alarm ID 002 is sent to the PI,
- b) an alarm sentence ALR with alarm ID 002 is sent to the PI,
- c) the EUT shall be operative again after refitting the antenna, without damage to the transceiver and check that an alarm sentence ALR with a deactivated alarm ID 002 is sent to the PI.

Federal Maritime and Hydrographic Agency



2016-07-06	Tester: Ba	Test details: Tra	ansceiver protection	
Test item		Check	Remark	Result
Apply a speed	> 23 kn (5 s re	porting interval).		
a) open circuit the VHF antenna terminal for at least 5 min.		Check that ALR ID 002 is output.	Test has been performed with EUT No. 3 because EUT No. 2 always activates ALR ID 002. UTC 06:48	Passed
		Check that the malfunction indication is activated.		Passed
b) open circuit	the VHF	Check that ALR ID 002 is output.	UTC 06:55	Passed
antenna termir 5 min.	nal for at least	Check that the malfunction indication is activated.		Passed
c) Reconnect tantenna.	he VHF	Check that ALR ID 002 is output indicating the deactivation.	UTC 07:01	Passed
		Check that the EUT is not damaged and continuous normal operation.		Passed
		Check that the malfunction indication is deactivated.		Passed

3.7.3 10.7.3 Transmitter shutdown procedure

10.7.3.1 Purpose

The purpose of this test is to ensure that the EUT has a shutdown procedure that is independent of the operating system software.

10.7.3.2 Method of measurement

Check manufacturer's documentation on transmitter shutdown procedure.

10.7.3.3 Required result

Verify that a transmitter shutdown procedure, independent of the operating software, is provided (see 6.6.2).

2016-11-29	Tester: Ba	Test details: Transm	itter shutdown procedure	
Test item		Check	Remark	Result
Check manufa documentation		Verify the transmitter shutdown procedure.	Description in document: WIDELINK B-600 Technical	Passed
Transmitter sh procedure.	utdown	Verify that the transmitter shutdown procedure is independent of software.	Notes TN-600-001.pdf	Passed

Federal Maritime and Hydrographic Agency



3.7.4 10.7.4 Position sensor fallback conditions

10.7.4.1 Purpose

The purpose of this test is to ensure that the EUT uses position source, position accuracy flag, RAIM flag and position information in accordance with Table 3.

10.7.4.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode.

Apply position sensor data such that the EUT operates as follows:

- internal DGNSS in use (corrected by Message 17);
- internal DGNSS in use (corrected by a beacon), if implemented;
- internal GNSS in use;
- no sensor position in use.

Check the position accuracy and RAIM flag in the VDL Message 18 and, where provided, the ALR sentence.

10.7.4.3 Required result

Verify that the use of position source, position accuracy flag, RAIM flag and position information complies with Table 3.

Verify that the position sensor status is maintained for the next scheduled report and changed for subsequent reports.

Verify that the EUT does not accept Message 17 from a station using a non-base station MMSI.

2016-07-05	Tester: Ba	Test details: Check of pos	ition sensor fall-back conditio	ns
Test item		Check	Remark	Result
Provide GNSS	signal accordi	ng to the test items, changing upwards	3	
No GNSS sigr	nal available	Check that position = default.		Passed
		Check that PA flag = 0.		Passed
		Check the RAIM flag = 0.		Passed
		Check that ALR ID 007 is output.		Passed
		Check that ALR ID 026 is output.		Passed
		Check that ALR ID 029 is output.		Passed
		Check that ALR ID 030 is output.		Passed
Provide a GNS	SS signal	Check that position is correct.		Passed
		Check that PA flag = 0.		Passed
		Check the RAIM flag (0 or 1 if RAIM is optionally implemented).	RAIM = 1	Passed
		Check that ALR ID 026 is output indicating inactivation of alarm.		Passed
		Check that ALR ID 026 is output indicating inactivation of alarm.		Passed
		Check that ALR ID 029 is output indicating inactivation of alarm.		Passed
		Check that ALR ID 030 is output indicating inactivation of alarm.	ALR ID 030 is still active because SOG = 0	Passed

Federal Maritime and Hydrographic Agency



Check that the status is changed See Note) Passed after the next scheduled position report N/A Provide a beacon signal Check that position is correct. Beacon input is not implemented (Optional) N/A Check that PA flag = 1. Check the RAIM flag (0 or 1 if RAIM N/A is optionally implemented). N/A Check that the status is changed Provide Message 17 on VDL Check that position is correct. Passed (Optional) Check that PA flag = 1. Passed Check the RAIM flag (0 or 1 if RAIM Passed is optionally implemented). Check that the status is changed Passed See Note) after the next scheduled position report Provide GNSS signal according to the test items, changing upwards Remove Message 17 on Check that position is correct Passed **VDL** Passed Check that PA flag = 0 (Optional) Check the RAIM flag (0 or 1 if RAIM Passed is optionally implemented). Check that the status is changed See Note) Passed after the next scheduled position report Remove the beacon signal Check that position is correct. N/A (Optional) Check that PA flag = 0. N/A Check the RAIM flag (0 or 1 if RAIM N/A is optionally implemented). Check that the status is changed N/A Remove the GNSS signal Check that time stamp = 63Passed Check that PA flag = 0. Passed Check the RAIM flag = 0. Passed Check that the status is changed Passed See Note) after the next scheduled position report

Note)

In the test with 3 min reporting interval resulting from SOG = 0 in a stationary test the next scheduled position report already represents the new sensor status.

This seems to be appropriate and is therefore accepted.

Federal Maritime and Hydrographic Agency



2016-07-05	Tester: Ba	Test details: Check of Message 17 from an non-base station MMSI		
Test item	-	Check	Remark	Result
Connect sense	Connect sensor inputs and correction data according to the test items.			
	rection data by 17 from a non-	Check that PA flag = 0.	UTC 13:45	Passed

3.8 10.8 User interface

3.8.1 10.8.1 Status indication

(See 6.7.1)

10.8.1.1 Purpose

The purpose of this test is to ensure that the status indicators provided on the EUT function correctly.

10.8.1.2 Method of measurement

Perform the following.

- a) Set up standard test environment and operate the EUT in autonomous mode.
- b) Send Message 23 with a quiet time to EUT.
- c) Disable GNSS reception.

Check status indications.

10.8.1.3 Required results

Check that

- a) power indicator is on and the no transmission indicator is off,
- b) no transmission indicator is on and reverts to off after quiet time elapse,
- c) the error indicator is on.

2016-06-02	Tester: Ba	Test details: Status indication		
Test item	-	Check	Remark	Result
Operate the E	UT according to	the test items.		
a) Operate un	der normal	Check that the power indicator is on.		Passed
conditions in a	utonomous	The "No transmission" indicator is off.		Passed
mode.		Check that the "Error" indicator is off.		Passed
b) Disable trar		Check that the power indicator is on.		Passed
message 23 v	vith quiet time.	The "No transmission" indicator is on.		Passed
		Check that the "Error" indicator is off.		Passed
c) Disable GN	SS reception	Check that the power indicator is on.		Passed
(quiet time is f	inished).	The "No transmission" indicator is off.		Passed
		Check that the "Error" indicator is on.		Passed

Federal Maritime and Hydrographic Agency



3.8.2 10.8.2 Message display

(See 6.7.1)

This test is only applicable if a message display is provided.

10.8.2.1 Purpose

The purpose of this test is to ensure that, if a display is provided, the EUT displays the required information.

10.8.2.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode.

- a) Apply to the VDL Message 12 addressed to EUT.
- b) Apply to the VDL Message 12 not addressed to EUT.
- c) Apply to the VDL Message 14 to EUT.
- d) Apply an active AIS- SART position report to EUT.
- e) Apply a test mode AIS-SART position report to EUT.
- f) Disable VHF antenna.

10.8.2.3 Required results

Verify that

- a) the EUT displays Message 12,
- b) the EUT does not display Message 12,
- c) the EUT displays Message 14,
- d) the EUT displays the AIS- SART position report Message 1, at least ID and position,
- e) the EUT displays the AIS-SART position report Message 1, at least ID and position only if unit set to AIS-SART test mode,
- f) the EUT displays the alarm status and that the error indicator is on.



2016-06-02	Tester: Ba	Test details: Test of or	otional Message display	
Test item	<u>"</u>	Check	Remark	Result
Apply messag	es according to	the test items.		
a) Apply message 12 addressed to the EUT		Check that the message is displayed.	A message display is not provided	N/A
		Check that the content is correct.		N/A
b) Apply mess addressed to	•	Check that the message is not displayed.		N/A
c) Apply message 14		Check that the message is displayed.		N/A
		Check that the content is correct.		N/A
d) Apply an active SART message 1		Check that the SART is displayed.		N/A
		Check that the MMSI is displayed.		N/A
		Check that the position is displayed.		N/A
e) Apply an SART test		Check that the SART is displayed.		N/A
message 1		Check that the MMSI is displayed.		N/A
EUT in SART	test mode	Check that the position is displayed.		N/A
e) Apply an Samessage 1 EUT not in SA	ART test	Check that the SART is not displayed.		N/A
f) Disconnect	VHF antenna	Check that the alarm status is displayed.		N/A
		Check that the error indicator is on.		N/A

Federal Maritime and Hydrographic Agency



3.8.3 10.8.3 Static data input

(See 6.4, 6.7.2)

10.8.3.1 Purpose

The purpose of this test is to ensure that static data can be input to the EUT according to the manufacturer's documentation and the MMSI cannot be changed once input.

10.8.3.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode.

- a) Enter all static data except MMSI.
- b) Enter an MMSI outside the valid range.
- c) Enter an MMSI according to the manufacturer's initialisation procedure.
- d) Enter a new MMSI.
- e) Enter all other static data.

10.8.3.3 Required results

Verify that

- a) the static data is correctly stored according to the manufacturer's initialisation procedure,
- b) the unit does not accept the MMSI,
- c) the unit accepts the MMSI as entered by the user,
- d) the unit does not accept the MMSI as entered by the user,
- e) static data can be changed.

2016-06-02	Tester: Ba	Test details	: Static data input	
Test item	•	Check	Remark	Result
	-	manufacturer's documentation.		
a) Enter all static data		Enter and check ships name.	By SSD input	Passed
except MMSI they are corre	and check that ctly stored.	Enter and check type of ship and cargo.	By VSD input	Passed
		Enter and check call sign.	By SSD input	Passed
		Enter and check dimension of ship/reference for position.	By SSD input	Passed
b) Enter an M the valid range		Check that the MMSI is not accepted.	Using configuration tool	Passed
c) Enter an Mi valid range.	MSI inside the	Check that the MMSI is accepted and correctly stored.	Using configuration tool	Passed
d) Enter a new the valid range		Check that the new MMSI is not accepted.	Using configuration tool	Passed
e) Enter all sta		Enter and check ships name.	With SSD and configuration	Passed
except MMSI and check that hey are correctly stored.	Enter and check type of ship and cargo.	tool	Passed	
		Enter and check call sign.		Passed
		Enter and check dimension of ship/reference for position.		Passed



4 11 Physical tests

The physical radio tests are not part of this test report.

Federal Maritime and Hydrographic Agency



5 12 Specific tests of link layer

5.1 12.1 TDMA synchronisation

5.1.1 12.1.1 Synchronisation test using UTC direct and indirect

12.1.1.1 Purpose

The purpose of this test is to ensure that the EUT can operate UTC direct and indirect.

12.1.1.2 Method of measurement

Set up standard test environment; choose test conditions in a way that the EUT operates in the following synchronisation modes:

- a) UTC direct;
- b) UTC indirect (internal synchronisation source disabled; at least one other station UTC direct synchronised);
- c) BASE direct (internal GNSS disabled; base station with UTC direct synchronisation within range);
- d) UTC indirect (internal GNSS receiver disabled; only Class B SO station UTC direct synchronised).

Check all CommState parameters in position report. Check reporting interval.

12.1.1.3 Required results

Confirm that

- a) the SynchState = 0;
- b) the SynchState = 1;
- c) the SynchState = 1;
- d) the SynchState = 1.

Federal Maritime and Hydrographic Agency



2016-05-23 Tester: Ba Test details: TDMA Synchronisation					
Tes	st item		Check	Remark	Result
Ор	erate the El	UT in an enviro	nment according to the test items and	check the synchronisation state) <u>.</u>
a)	Operate w	rith GPS.	Check that sync state is 0 (UTC direct).		Passed
b)		PS. ne AIS Class A n UTC direct.	Check that sync state is 1 (UTC indirect).		Passed
c)		oled, station with t within range.	Check that sync state is 1 (UTC indirect).		Passed
d)	GPS disab At least or SO station direct.	ne AIS Class B	Check that sync state is 1 (UTC indirect).		Passed

5.1.2 12.1.2 Synchronisation test without UTC, EUT receiving semaphore

12.1.2.1 Purpose

The purpose of this test is to ensure that the EUT can synchronise to a semaphore.

12.1.2.2 Method of measurement

Set up standard test environment; choose test conditions such that the EUT operates with other units acting as follows.

- The EUT is receiving a mobile station that is acting as semaphore with no Base Stations being received.
- b) Introduce a Base Station that is acting as a semaphore with different timing.
- c) Enable internal synchronisation source.

Check all CommState parameters in position report. Check reporting interval.

12.1.2.3 Required results

Confirm that

- a) transmitted SynchState = 3;
- b) the EUT shall change synchronisation source to the Base Station;
- c) synchronisation mode shall revert to UTC direct, SynchState = 0.

Federal Maritime and Hydrographic Agency



201	16-05-23	Tester: Ba	Test details: TD	MA Synchronisation	
Tes	Test item		Check	Remark	Result
Operate the EUT in an enviro		UT in an enviro	ment according to the test items and check the synchronisation state.		
a)			Check that sync state is 3.	UTC 09:10	Passed
			Check that the EUT synchronizes to the Class A station.		Passed
b)	GPS disab	oled,	Check that sync state is 2	Sync mode = 1	
	Class A without UTC and one base station as semaphore, different timing.		(Base direct)	(Sync mode of base station = 3)	
				Retest 2016-06-16 Ba:	Passed
				Sync mode = 2	
			Check that the EUT synchronizes to the base station.	Remark: the EUT does not consider the distance to the base station.	Passed
c)	Enable GF	PS.	Check that sync state is 0	UTC 09:20 Sync state = 0	
			(UTC direct)	There is a timing offset of 1s, resulting in 1/2 slot timing error.	
				See Note)	
				Retest 2016-06-16 Ba:	
				UTC 13:11	
				The problem still exists	Passed
				Retest 2016-07-04 Ba:	. 45564
				The timing is correct after enabling GPS	

Note)

At a start of the EUT (Power on) with valid GPS the timing is correct. If the GPS is applied again after a phase without GPS there is an offset of 1 s (1 s too early, e.g. slot in Message 8 is 376 instead of 413). This seems to be reproducible, it happened in two tests.

5.2 12.2 Time division (frame format)

12.2.1 Purpose

The purpose of this test is to ensure that the EUT uses SOTDMA correctly.

12.2.2 Method of measurement

Set the EUT to maximum reporting interval of 5 s by applying a speed of >23 kn. Record VDL Messages and check for used slots. Check parameter slot number in CommState of position report. Check slot length (transmission time).

12.2.3 Required results

Slot number used and slot number indicated in CommState shall match. Slot number shall not exceed 2249. Slot length shall not exceed 26,67 ms.

Federal Maritime and Hydrographic Agency



2016-05-31	Tester: Ba	Test details: TDMA Synchronisation		
Test item		Check	Remark	Result
Operate the E	Operate the EUT with 5 s reporting interval (SOG > 23 kn).			
Slot number		Check that slot number used and slot number indicated in CommState match.		Passed
Slot count		Check that slot number does not exceed 2249.		Passed
Slot length		Check that slot length does not exceed 26,67 ms.		Passed

5.3 12.3 Synchronisation jitter

12.3.1 Definition

Synchronisation jitter (transmission timing error) is the time between nominal slot start as determined by the UTC synchronisation source and the initiation of the "transmitter on" function.

12.3.2 Purpose

The purpose of this test is to ensure that the synchronisation jitter is within the allowable tolerances.

12.3.3 Method of measurement

Set up standard test environment. Set the EUT to 5 s reporting interval using:

- a) UTC direct synchronisation;
- b) UTC indirect synchronisation by disconnecting the synchronisation source of the EUT.

Record VDL Messages and measure the time between the nominal beginning of the slot (Nominal To) and the start flag and calculate it back to To.

12.3.4 Required results

The synchronisation jitter shall not exceed:

- a) $\pm 104 \,\mu$ s using UTC direct synchronisation;
- b) $\pm 312 \,\mu$ s using UTC indirect synchronisation.

Federal Maritime and Hydrographic Agency



2016-05-24	Tester: Ba	Test details: S	Test details: Synchronisation jitter		
Test item		Check	Remark	Result	
•	Operate the EUT with a reporting interval of 5 s (speed > 23 kn). Record the time T_2 using the VDL analyser and and calculate it back to T_0				
a) UTC direct		Check that T_0 is in the range of +/- $\pm 104~\mu s$.	The timing is about 80 µs too late. Therefore some Messages are outside the limit Retest 2016-06-16 Ba: The timing is correct.	Passed	
b) UTC indirec	ot.	Check that T_0 is in the range of +/- $\pm 312~\mu s$.	The timing is about 300 µs too late. Therefore some Messages are outside the limit Retest 2016-06-16 Ba: The timing is correct.	Passed	

5.4 12.4 Data encoding (bit stuffing)

(See 7.2.3.6)

12.4.1 Purpose

The purpose of this test is to ensure that the EUT conforms to the data encoding requirements.

12.4.2 Method of measurement

Set up standard test environment.

Set ship's name to HEX-Values "7E 3B 3C 3E 7E" so that bit stuffing will be applied and check the VDL (note that this might require that the manufacturer provides means to input this data).

12.4.3 Required results

Confirm that transmitted VDL Messages 24A and 24B conform to data input.

Data in Hex	7E 3B 3C 3E 7E
Binary (Bytes)	01111110 00111010 00111100 00111110 0111111
Binary (6 bit)	011111_100011_101000_111100_001111_100111_1110xx
	_ # (< O ' 8
Name in 6 bit ASCII text (Table	_#(<o'8 ('="27h," (xx="" 0<="" apostrophe)="" bits="" set="" td="" to=""></o'8>
47 of 1371)	
Binary (after 40 bit header)	xxxx01_111110_001110_100011_110000_1111110_011111_10xxxx
	v > S h v O
Coded in 6 bit ASCII in VDM/	XXXXXxv>ShvOx
VDO	
(IEC 61162-1 Table C.1)	

Note: the ship's name does not affect message 24 B. Therefore there is no need to check 24 B.

Federal Maritime and Hydrographic Agency



2016-05-25	Tester: Ba	Test details: Data e	encoding (bit stuffing)	
Test item		Check	Remark	Result
Input name "_:	#(<o'8" e<="" td="" the="" to=""><td>UT.</td><td></td><td>-</td></o'8">	UT.		-
Evaluate Mess	sage 24A	Check that the VDO is according to the ships name (sequence "v>ShvO").	VDO = "v>ShvO"	Passed
		Check that the VDM is according to the ships name (sequence "v>ShvO").		Passed
		Check that receiver shows name as "_#(<o'8".< td=""><td></td><td>Passed</td></o'8".<>		Passed

5.5 12.5 Frame check sequence

12.5.1 Purpose

The purpose of this test is to ensure that the EUT rejects Messages with invalid CRC.

12.5.2 Method of measurement

Apply simulated position report Messages with wrong CRC bit sequence to the VDL.

- a) Check test output; if a display interface is provided, check this.
- b) Repeat test 12.1.2 and check that a station transmitting Messages with wrong CRC are not used for synchronisation.

12.5.3 Required results

Confirm that Messages with invalid CRC are not accepted by the EUT in cases a) and b).

2016-05-25	Tester: Ba	Test details: Frame check sequence		
Test item		Check	Remark	Result
Transmit posit	ion report mess	age from VDL generator.		-
a) Set CRC bit sequence to valid.		Check that the position reports are output as VDM on the PI port.		Passed
		If implemented: Check that the target is displayed on the MKD.	Not implemented	N/A
a) Set CRC bit wrong.	t sequence to	Check that the position reports are not output as VDM on the PI port.		Passed
		If implemented: Check that the target is not displayed on the MKD.	Not implemented	N/A
b) GPS disable One AIS Class		Check that sync state is 3.		Passed
direct, with incorrect CR	orrect CRC	Check that the EUT does not synchronize to the Class A station.		Passed
b) GPS disabled, One Class A without	vithout UTC	Check that sync state is 3.		Passed
and one base semaphore, be incorrect CRC	oth with	Check that the EUT does not synchronize to the Class A station and to the base station.		Passed

Federal Maritime and Hydrographic Agency



5.6 12.6 Slot allocation (Channel access protocols)

5.6.1 12.6.1 Network entry

12.6.1.1 Method of measurement

Set up standard test environment; switch on EUT. Record transmitted scheduled position reports for the first 3 min of transmission after initialisation period. Check CommState for channel access mode.

12.6.1.2 Required results

EUT shall start autonomous transmissions of Message 18 (position report) with ITDMA CommState with Keep Flag set true for first minute of transmission and Message 18 with SOTDMA CommState thereafter.

2016-05-26	Tester: Ba	Test details: Cha	annel access protocol	
Test item	<u>-</u>	Check	Remark	Result
Switch on EU	Γ and record da	ta with VDL analyser.		
Operate the E	UT with 5 s repo	orting interval (speed > 23 kn).		
Initial message	e type	Check that the network entry is done with Message 18 with ITDMA comm state.		Passed
Keep flag		Check that the keep flag is set in the ITDMA comm state.		Passed
Slot offsets		Check that the slot offsets the ITDMA comm state are in the range 375 +/- 37.5= 337.5 412.5.		Passed
Slot use		Check that the allocated slots are used.		Passed
Comm state		Check that the Comm state is changed to SOTDMA after the first frame.		Passed
Timeout		Check that the timeout in the 2 nd frame is between 2 and 6 (Decremented from initial 37).		Passed

Federal Maritime and Hydrographic Agency



5.6.2 12.6.2 Autonomous scheduled transmissions (SOTDMA)

12.6.2.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode.

- a) Record transmitted scheduled position reports Message 18 and check frame structure. Check CommState of transmitted messages for channel access mode and parameters number of received stations, slot timeout, slot number and slot offset.
- b) Repeat the test with 50 % channel loading ensuring there are at least 4 free slots in each SI.

12.6.2.2 Required results

Check that

- a) nominal reporting interval is achieved ±20 % (allocating slots in selection interval SI). Confirm that the EUT allocates new slots NTS within SI after 3 min to 8 min. Check that slot offset indicated in CommState matches slots used for transmission. Check that Class B "CS" are not included in the number of received stations. Check that during DSC monitoring periods there are no time out values of "0";
- b) only free slots are used for transmission.

2016-05-26	Tester: Ba	Test details: Autonomous scheduled transmissions (SOTDMA)		
Test item		Check	Remark	Result
following test is	tems using the	frames operating with autonomously scheduled transmissions. Evaluate the recorded data. eporting rate is 5 s (SOG > 23 kn).		
Reporting rate	ı	Check that the reporting rate is 5 s, 12 messages per frame.		Passed
Nominal increr selection interv		Check that the allocated slots match the nominal and selection interval of 5 s reporting interval.		Passed
Slot interval		Check that the slot intervals are in the range 187.5 +/- 37.5 = 150 225.		Passed
Timeout		Check that the timeout is counting down from 37 to 0.		Passed
Slots used		Check that the slots indicated in CommState match the slots used.		Passed
Slots allocated	at timeout 0	Check that the slots are used in the next frame.		Passed
		Check the slot offset is 2250 +/-SI (2212.52287.5).		Passed
CommState sub message		Check that for timeout 3, 5, 7 the number of received stations is included.		Passed
		Check that Class B CS stations are not counted as received stations.		Passed
		Check that for timeout 2, 4, 6 the correct slot number is included.		Passed
		Check that for timeout 1 the correct value of UTC is included.		Passed
		Check that for timeout 0 the slot increment is included.		Passed

Federal Maritime and Hydrographic Agency



Alternating channels	Check that the position reports are	Passed
	transmitted on alternating channels.	
b) Apply 50 % channel load	on both channels	
Free slots	Check that only free slots are used	Passed
	for transmission	

5.6.3 12.6.3 Autonomous scheduled transmissions (ITDMA)

12.6.3.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode. Set NavStatus of EUT to "at anchor" giving a reporting interval of 3 min. Record transmitted scheduled position reports.

12.6.3.2 Required results

Check that EUT transmits Message 18 with ITDMA CommState and allocates slots using ITDMA and that slot offset indicated in CommState matches slots used for transmission. Check that nominal reporting interval is achieved ±20 %.

2016-05-26	Tester: Ba	Test details: Autonomous scheduled transmissions (ITDMA)		
Test item		Check	Remark	Result
the following to	Record the VDL data of at least 20 frames operating with autonomously scheduled transmissions. Evaluate the following test items using the recorded data.			
Set the conditi	on so that the re	eporting rate is 3 min (SOG < 2 kn).		
Reporting rate		Check that the reporting rate is 3 min.	See test 10.5.2.1	Passed
Message type		Check that ITDMA comm state is used.		Passed
Slot interval		Check that the slot intervals are 3 min +/- 20 %.		Passed
Slot increment		Check that the slot increment = 13500 +/- 10 %.		Passed
Number of slot	ts	Check that the number of slots = 1 (value in comm state = 5).		Passed
Keep flag		Check that the keep flag = 0.		Passed
Alternating cha	annels	Check that the position reports are transmitted on alternating channels.		Passed

Federal Maritime and Hydrographic Agency



5.6.4 12.6.4 Transmission of Messages 24A and 24B (ITDMA)

12.6.4.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode. Record transmitted messages.

12.6.4.2 Required results

Confirm that EUT transmits Messages 24A and 24B using the ITDMA access scheme. The SOTDMA CommState of Messages 18 shall, as far as possible, be changed to ITDMA CommState to allocate slots for Messages 24A and 24B.

2016-05-26	Tester: Ba	Test details: ITDMA transmission of Message 24		
Test item	-	Check	Remark	Result
Record the VI	OL data of at lea	ast 20 frames operating with autonomo	usly scheduled transmissions.	_
Set the conditi	ion so that the r	eporting rate is 30 s.		
Reporting interval		Check that the reporting rate of msg 24A and 24B is 6 min.	See also test 10.5.2.3	Passed
		Check that msg 24A and 24B are transmitted on the same channel.		Passed
Message type for allocation		Check that the comm state of 2 Message 18 are changed to ITDMA to allocate the slots for message 24 A and 24 B.		Passed
Number of slo	ts	Check that the number of slots = 1 (value in commstate = 0).	Number of slots = 2	
			(value in commstate = 1).	
			Retest 2016-06-16 Ba:	
			Number of slots = 1	Passed
			(value in commstate = 0).	
Keep flag		Check that the keep flag = 1.		Passed
Slot allocation		Check that the slots allocated by Message 18 are used for $T_{\underline{X}}$ of Message 24A and 24 B.		Passed
Alternating cha	annels	Check that the pairs of Message 24A and 24B are transmitted on alternating channels.		Passed

Federal Maritime and Hydrographic Agency



5.6.5 12.6.5 Assigned operation

(See 4.1.5, 7.3.4.3.3)

5.6.5.1 12.6.5.1 Message 16 with slot assignment

12.6.5.1.1 Purpose

The purpose of this test is to ensure that the EUT can be assigned to use specific slots.

12.6.5.1.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode (SOG < 2 kn).

- a) Transmit an assigned mode command Message 16 to the EUT with initial slot offset and increment.
- b) Increase speed to 25 kn while still assigned to a reporting interval of 10 s.
- c) Every 3 min send further assignment Messages with the same slot assignment.
- d) Transmit an assigned mode command Message 16 with a non-base station MMSI to the EUT with initial slot offset and increment.
- e) Transmit an assigned mode command Message 16 to an MMSI different to the MMSI of the EUT with initial slot offset and increment.

Record transmitted Messages.

12.6.5.1.3 Required results

Confirm that

- a) the EUT transmits a Message 18 in the designated slots. Check that the assigned mode flag is set to 1.
- b) the EUT stays in assigned mode using the assigned slots,
- the EUT continues in assigned mode when it receives a further assignment commands by Message 16. Verify that the slot timeout value is updated for every received Message 16,
- d) the EUT ignores Message 16 and continues autonomous mode operation,
- e) the EUT ignores Message 16 and continues autonomous mode operation. Confirm that the EUT reverts to autonomous mode with autonomous reporting interval 4 min to 8 min after the last Message 16.



2016-05-26	Tester: Ba	Test details: Slot	offset and increment	
Test item		Check	Remark	Result
a) Operate the EUT with SOG		5 < 2 kn, autonomous reporting interval = 3 min.		
Apply an assignment Message 16 on channel A with offset to first assigned slot = 40 and slot increment parameter = 2 (increment = 375, interval = 10s).				
VDM output		Check VDM output of Message 16.		Passed
First message		Check that the first Message in assigned mode is sent 40 slots after Message 16.		Passed
Assigned mod	le flag	Check that the assigned mode flag is set to 1.		Passed
Initialisation ph (First frame)	nase	Check that EUT continues after the first Message of the assigned mode with the network entry phase.	There is not slot allocation. This is acceptable because the slots are reserved by a	Passed
		Check that an ITDMA comm state is used.	base station	Passed
Alternating cha	annels	Check that position reports are transmitted alternating on channel A and B.		Passed
Increment		Check that the increment is 375 slots.		Passed
Timeout		Check that all slots of the first frame have the same timeout.		Passed
		Check that the timeout is between 3 and 7.		Passed
		Check that the timeout is decremented after 1 min.		Passed
CommState		Check that after the first frame a SOTDMA comm state is used.		Passed
b) Increase S0	OG to 25 kn (au	tonomous reporting interval = 5s)		
Mode		Check that the assigned mode continues.		Passed
c) Repeat Mes	ssage 16 with s	ame assignment every 3 min		
Mode		Check that the assigned mode continues.		Passed
Timeout		Check that the time-out value is updated for every received Message 16.		Passed
c) Stop transm	nission of Mess	age 16		
End of assigne	ed mode	Check that EUT reverts to autonomous mode after time-out (48 min after last received Message 16).		Passed
		Check that the assigned mode flag in autonomous mode is set to 0.		Passed
		Check that the Slot offset of all messages with time-out 0 is set to 0 to release the old slots.		Passed
		Check that EUT initialises autonomous mode like network entry.		Passed

Federal Maritime and Hydrographic Agency



d) Transmit Message 16 with slot assignment from a non-base station MMSI			
Mode Check that the EUT ignores P			
	Message 16.		
e) Transmit Message 16 with slot assignment addressed to an MMSI different to the EUT			
Mode	Check that the EUT ignores		Passed
	Message 16.		

5.6.5.2 12.6.5.2 Message 16 with rate assignment

12.6.5.2.1 Purpose

The purpose of this test is to ensure that the EUT can be assigned reporting intervals.

12.6.5.2.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode (SOG < 2 kn).

- a) Transmit an assigned mode command Message 16 to the EUT with a designated reporting interval of 5 s.
- b) Transmit an assigned mode command Message 16 to the EUT with the assigned reporting interval of 10 s.
- c) Increase speed to 25 kn while still assigned to a reporting interval of 10 s.
- d) Every 3 min send further assignment Messages with a reporting interval of 10 s.
- e) Transmit an assigned mode command Message 16 to the EUT with a non-base station MMSI.

Record transmitted Messages.

12.6.5.2.3 Required results

Confirm that

- a) the EUT transmits with the designated reporting interval of 5 s. Check that the assigned mode flag is set to 1,
- b) the reporting interval is 10 s,
- c) the EUT stays in assigned mode with a reporting interval of 10 s,
- d) the EUT continues in assigned mode when it receives a further assignment commands by Message 16. Verify that the slot timeout value in the CommState is not updated by the received Message 16.
- e) confirm that the EUT ignores Message 16 and continues autonomous mode operation. Confirm that the EUT reverts to autonomous mode with autonomous reporting interval 4 min to 8 min after the last Message 16.

Federal Maritime and Hydrographic Agency



2016-05-26 Tester: Ba Test details: Rate assignment Test item Check Remark Result a) Operate the EUT with SOG < 2 kn, autonomous reporting interval = 3 min. Apply an assignment message 16 with offset = 120 (reporting interval = 5s). VDM output Check VDM output of Message 16. Passed Assigned mode flag Passed Check that the assigned mode flag is set to 1. Initialisation phase Check that EUT starts the assigned Passed mode with a network entry phase. (First frame) Check that an ITDMA comm state is Passed used. Alternating channels Check that position reports are Passed transmitted alternating on channel A and B. Increment Check that the reporting interval is 5 Passed Timeout Check that the timeout of the first Passed frame is between 3 and 7. Check that the timeout is Passed decremented after 1 min. CommState Check that after the first frame a Passed SOTDMA comm state is used. b) Send an assignment message 16 with offset = 60 (reporting interval = 10s) Reporting interval Check that the reporting interval is UTC 12:33 Passed 10 s. c) Increase SOG to 25 kn (autonomous reporting interval = 5s) Mode Check that the assigned mode with Passed 10 s interval continues. d) Repeat Message 16 with same assignment every 3 min Mode Check that the assigned mode Passed continues. Timeout Check that the time-out values are Passed not updated for every received Message 16. d) Stop transmission of Message 16 End of assigned mode Check that reverts to autonomous Passed mode after time-out (4...8 min). Check that the assigned mode flag Passed in autonomous mode is set to 0. Check that the slots of the assigned Passed mode schedule are released with time-out 0 and slot offset = 0. Check that EUT initialises Passed autonomous mode like network entry. e) Transmit Message 16 with rate assignment from a non-base station MMSI Mode Check that the EUT ignores Passed Message 16.

Federal Maritime and Hydrographic Agency



5.6.5.3 12.6.5.3 Assigned mode using invalid reporting rates

12.6.5.3.1 Method of measurement

Operate standard test environment and EUT in autonomous mode. Transmit an assigned mode command Message 16 using a base station MMSI to the EUT with

- a) the number of reports per 10 min which is not a multiple of 20,
- b) the number of reports per 10 min which is higher than 120.

12.6.5.3.2 Required results

Confirm that

- a) the EUT transmits position reports Message 18 at a reporting rate that corresponds to the next highest multiple of 20 reports per 10 min,
- b) the EUT transmits position reports Message 18 at a reporting interval of 5 s.

2016-05-26	Tester: Ba	Test details: Assigned Mode		
Test item	-	Check	Remark	Result
Send a Messa	ige 16 rate assi	gnment with invalid offset values.		
a) Offset value = 110 (not a multiple of 20) EUT = destination ID A		Check that the reporting rate is 120/10min = 12/min = 5 s.	UTC 14:05	Passed
b) Offset value = 300 (> 120 messages/10 min) EUT = destination ID B		Check that the reporting interval is 5 s.	UTC 14:17	Passed

Federal Maritime and Hydrographic Agency



5.6.5.4 12.6.5.4 Slot assignment to FATDMA reserved slots

12.6.5.4.1 Definition

This test checks the operation of Message 16 assignment of slots reserved by Message 20.

12.6.5.4.2 Method of measurement

Set up the standard test environment and operate EUT in autonomous mode. Transmit a Data Link Management message (Message 20) using a base station MMSI to the EUT with slot offset and increment. Transmit an Assigned Mode Command (Message 16) using a base station MMSI to the EUT and command it to use one or more of those FATDMA allocated slots.

Record transmitted messages.

12.6.5.4.3 Required results

Confirm that the EUT uses the slots commanded by Message 16 for own transmissions.

2016-05-26	Tester: Ba	Test details: Slot assignment to FATDMA reserved slots		
Test item		Check	Remark	Result
Offset = 23, sl Apply a Messa	Apply a Message 4 and 20 from VDL Generator with slot offset and increment for slot reservation: Offset = 23, slots = 5, time-out = 7, incr. = 25. Apply a Message 16 from VDL Generator assigning one or more of these reserved slots: Offset = 25, incr. = 5 (= 75 slots).			
R _x of Message	e 4	Check that Message 4 has been received by EUT (VDM output).		Passed
R _x of Message	€ 20	Check that Message 20 has been received by EUT (VDM output).		Passed
Slot use		Check that slots assigned by the Message 16 are used by the EUT.		Passed

Federal Maritime and Hydrographic Agency



5.6.6 12.6.6 Group assignment

NOTE In the tests of the following subclauses use a base station MMSI to transmit Message 23 with a geographic region so that the EUT is inside this region, unless mentioned otherwise.

5.6.6.1 12.6.6.1 Entering interval assignment

12.6.6.1.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode with a reporting interval of 15 s (SOG = 15 kn). Perform the following tests after time-out of the previous test.

- a) Transmit a Group Assignment command (Message 23) to the EUT with a reporting interval of 30 s assigned.
- b) Transmit a Group Assignment command (Message 23) to the EUT with a reporting interval of 5 s assigned.
- c) Using a non-base station MMSI, transmit a Group Assignment command (Message 23) to the EUT with a reporting interval of 5 s assigned.
- d) Transmit a Group Assignment command (Message 23) to the EUT with a reporting interval of 2 s assigned.
- e) Transmit a Group Assignment command (Message 23) to the EUT with a reporting interval field setting 9 (next shorter autonomous reporting interval).
- f) Transmit a Group Assignment command (Message 23) to the EUT with a reporting interval field setting 10 (next longer autonomous reporting interval).

Monitor the VDL.

12.6.6.1.2 Required result

- a) EUT enters assigned operation mode and transmits position report Message 18 with 30 s reporting interval. Verify that EUT builds up the assigned transmission scheduled according to the network entry procedure. Verify that unused slots of the previous reporting schedule are released. Verify that the EUT reverts to autonomous mode after a time out of 4 min to 8 min building up the autonomous transmission schedule according to the network entry procedure and releases unused slots from previous schedule.
- b) EUT enters assigned operation mode and transmits position report Message 18 with 5 s reporting interval. Verify that EUT builds up the assigned transmission scheduled according to network entry procedure. Verify that unused slots of the previous reporting schedule are released. Verify that the EUT reverts to autonomous mode after a time out of 4 min to 8 min building up the autonomous transmission schedule according to the network entry procedure and releases unused slots from the previous schedule.
- c) EUT does not react on Message 23.
- d) EUT does not react on Message 23.
- e) EUT enters assigned operation mode and transmits position report Message 18 with 5 s reporting interval.
- f) EUT enters assigned operation mode and transmits position report Message 18 with 30 s reporting interval.



2016-05-27	Tester: Ba	Test details: Enter	ing interval assignment	
Test item	<u>1</u>	Check	Remark	Result
a) Operate the EUT with an		autonomous reporting interval of 15 s.		•
Apply a gi	roup assignmen	t Message 23 with a reporting interval	of 30 s (value 5).	
VDM output		Check VDM output of Message 23.	UTC 11:25	Passed
Initialisation ph	nase	Check that EUT starts immediately with rescheduling to the new reporting rate.		Passed
Assigned mod	le flag	Check that Assigned mode flag = 1.		Passed
Reporting rate	•	Check that the reporting interval = 30 s.		Passed
Alternating cha	annels	Check that position reports are transmitted alternating on channel A and B.		Passed
Slot deallocati	on	Check that the slot of the autonomous reporting interval are released using time-out = 0 and slot offset = 0.		Passed
Initialisation/ Slot allocation		Check that the slots of the assigned reporting interval are allocated according to the network entry procedure.		Passed
Timeout		Check that the assigned timeout is between 2 and 6 in the next frame.		Passed
End of assigne	ed mode	Check that the EUT reverts to autonomous mode after 48 min.		Passed
b) Apply a gro	up assignment	message 23 with a reporting interval o	f 5 s (value 8).	
VDM output		Check VDM output of Message 23.	UTC 11:44	Passed
Initialisation ph	nase	Check that EUT starts immediately with rescheduling to the new reporting rate.		Passed
Assigned mod	le flag	Check that Assigned mode flag = 1.		Passed
Reporting rate	•	Check that the reporting interval = 5 s.		Passed
Alternating cha	annels	Check that position reports are transmitted alternating on channel A and B.		Passed
Slot deallocati	on	Check that the slot of the autonomous reporting interval are released using time-out = 0 and slot offset = 0.		Passed
Initialisation/ Slot allocation		Check that the slots of the assigned reporting interval are allocated according to the network entry procedure.		Passed
Timeout		Check that the assigned timeout is between 2 and 6 in the next frame.		Passed
End of assigne	ed mode	Check that the reverts to autonomous mode after 48 min.		Passed

Federal Maritime and Hydrographic Agency



c) Apply a group assignment message 23 with a reporting interval of 5 s (value 8) from a non-base station MMSI.			
Mode	Check that the EUT ignores message 23.	UTC 11:40	Passed
d) Apply a group assignment	message 23 with a reporting interval o	f 2 s (value 11).	
Mode	Check that the EUT ignores message 23.	UTC 11:38	Passed
e) Apply a group assignment	message 23 with reporting interval = n	ext shorter interval (value 9).	
VDM output	Check VDM output of Message 23.	UTC 11:56	Passed
Mode	Check that the EUT enters assigned mode.		Passed
Reporting interval	Check that the reporting interval = 5 s.		Passed
f) Apply a group assignment	message 23 with reporting interval = ne	ext longer interval (value 10).	
VDM output	Check VDM output of Message 23.	UTC 12:04	Passed
Mode	Check that the EUT enters assigned mode.		Passed
Reporting interval	Check that the reporting interval = 30 s.		Passed

5.6.6.2 12.6.6.2 Assignment by region

12.6.6.2.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode with a reporting interval of 15 s and use a base station MMSI to transmit Message 23.

- a) Transmit a Group Assignment command (Message 23) to the EUT (define station type 0 and geographic region so that the EUT is inside this region). Set the reporting rate to 5 s and apply message to VDL.
- b) Transmit a Group Assignment command (Message 23) to the EUT (define station type 0 and geographic region so that the EUT is outside this region). Set the reporting rate to 5 s and apply message to VDL.

12.6.6.2.2 Required result

- EUT switches to assigned mode and transmits position reports with 5 s interval. Verify that EUT reverts to normal operation mode after timeout period,
- b) EUT declines Message 23.

Federal Maritime and Hydrographic Agency



2016-05-27	Tester: Ba	Test details: Assignment by region		
Test item		Check	Remark	Result
•		onment and operate EUT in autonomo ting interval is 15 seconds (SOG = 15		•
a) Transmit Me EUT inside reg		Check that Message 23 is received (VDM output).		Passed
(Reporting inte = 5s)	erval value = 8	Check that the EUT enters assigned mode.		Passed
		Check that the reporting interval is changed to 5 s.		Passed
		Verify that EUT reverts to normal operation mode after 4 8 min.		Passed
EUT outside th	ne addressed re	egion		
Transmit Mess	sage 23,	Verify that EUT declines Message		Passed
EUT outside re	egion	23.		
(Reporting inte	erval = 5 s)	Reporting interval = 15 s.		

5.6.6.3 12.6.6.3 Assignment by station type

12.6.6.3.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode with a reporting interval of 15 s and transmit Message 23 with a reporting interval of 5 s.

- a) Transmit a Group Assignment command with a station type to 0 (all stations).
- b) Transmit a Group Assignment command with a station type to 1 (Class A).
- c) Transmit a Group Assignment command with a station type to 2 (All Class B).
- d) Transmit a Group Assignment command with a station type to 3 (SAR aircraft).
- e) Transmit a Group Assignment command with a station type to 4 (Class B SO).
- f) Transmit a Group Assignment command with a station type to 5 (Class B CS).
- g) Transmit a Group Assignment command with a station type to 6 (Inland AIS).

12.6.6.3.2 Required result

- a) EUT switches to assigned mode with 5 s reporting interval,
- b) EUT declines Message 23,
- c) EUT switches to assigned mode with 5 s reporting interval,
- d) EUT declines Message 23,
- e) EUT switches to assigned mode with 5 s reporting interval,
- f) EUT declines Message 23,
- g) EUT declines Message 23.

Federal Maritime and Hydrographic Agency



2016-05-27 Tester: Ba Test details: Assignment by station type Test item Check Remark Result Set up the standard test environment and operate EUT in autonomous mode. Apply sensor information in that way that reporting interval is 15 s (SOG = 15 kn). Transmit Message 23 with different station types according to the test item, Type of ship and cargo = 0, Reporting interval = 5 s, position of EUT inside the addressing area. a) Station type = 0Check that EUT enters assigned Passed mode. Check reporting interval = 5 s. Passed Transmit Message 23 with different station types according to the test item Check that Message 23 is ignored. b) Station type = 1 (Class A), UTC 13:05 Passed Check reporting interval = 15 s. Passed c) Station type = 2 (all types Check that EUT enters assigned UTC 13:07 Passed of Class B mobile stations), mode. Check reporting interval = 5 s. Passed d) Station type = 3 (SAR Check that Message 23 is ignored. Passed airborne mobile station), Check reporting interval = 15 s. Passed e) Station type = 4 (Class B Check that EUT enters assigned UTC 13:19 Passed SO mobile stations only), mode. Check reporting interval = 5 s. Passed f) Station type = 5 (Class B Check that Message 23 is ignored. UTC 13:06 Passed CS mobile stations only), Check reporting interval = 15 s. Passed g) Station type = 6 (Inland Check that Message 23 is ignored. Passed Waterways) Check reporting interval = 15 s. Passed

5.6.6.4 12.6.6.4 Addressing by ship and cargo type

12.6.6.4.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode with a reporting interval of 15 s and use a base station MMSI to transmit Message 23.

- a) Transmit a Group Assignment command (Message 23) to the EUT. Set the reporting interval to 5 s and the ship and cargo value to the value which is configured in the EUT.
- b) Transmit a Group Assignment command (Message 23) to the EUT. Set the reporting interval to 5 s and the ship and cargo value to a value different to the value which is configured in the EUT.
- c) Configure the ship and cargo type of the EUT to 72. Transmit a Group Assignment command (Message 23) to the EUT. Set the reporting interval to 5 s and the ship and cargo type value to 70.

12.6.6.4.2 Required result

- a) EUT switches to assigned mode and transmits position reports with 5 s reporting interval,
- b) EUT declines Message 23,
- c) EUT switches to assigned mode and transmits position reports with 5 s reporting interval.

Federal Maritime and Hydrographic Agency



2016-05-27	Tester: Ba	Test details: Addressing by ship and cargo type		
Test item		Check	Remark	Result
Operate EUT	in autonomous	mode with 15 s reporting interval (SO	G = 15 kn).	_
Set EUT to shi	ip and cargo typ	pe =36.		
Set station typ	e of Message 2	23 = 0, reporting interval = 5s and posit	ion of EUT inside the addressin	g area.
Transmit Mess	sage 23	Check that EUT enters assigned	UTC 13:27	Passed
Ship and cargo	o type = 36	mode.		
		Check reporting interval = 5 s.		Passed
Transmit Mess	sage 23	Check that Message 23 has been	UTC 13:26	Passed
Ship and Carg	o type not 36	received (VDM output).		
		Check that message 23 is ignored and the reporting interval is 15 s.		Passed
Set EUT to shi	Set EUT to ship and cargo type = 72			
Transmit Mess	sage 23	Check that EUT enters assigned	UTC 19:33	Passed
Ship and Cargo type = 70		mode.		
	- ·	Check reporting interval = 5 s.		Passed

5.6.6.5 12.6.6.5 Quiet time command

12.6.6.5.1 Method of measurement

Set up the standard test environment and operate EUT in autonomous mode with 15s reporting interval.

Transmit a Group Assignment message (Message 23) to the EUT with a quiet time command.

Record transmitted messages.

12.6.6.5.2 Required results

Confirm that the EUT continues transmission for one frame to release the allocated slots and then stops transmission. Confirm that the EUT starts transmission after the quiet time according to the network entry procedure. The quiet time period starts with the reception of Message 23.

2016-05-27	Tester: Ba	Test details: Addressing by ship and cargo type		-
Test item	<u> </u>	Check	Remark	Result
Set up the standard test environment and operate EUT in autonomous mode with 15 s reporting interval (SOG = 15 kn).			erval	
Transmit Mess EUT inside are	•	Check that EUT releases all slots with time-out = 0 and Slot offset = 0.	UTC 13:38	Passed
station type = Quiet time = 8		Check that the EUT stops transmission after one frame.		Passed
After end of qu	uiet time	Check that the EUT starts transmission after end of quiet time.	UTC 13:47	Passed
		Check that the EUT starts transmission with a network entry procedure.		Passed

Federal Maritime and Hydrographic Agency



5.6.6.6 12.6.6.6 Reverting from interval assignment

12.6.6.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode. Transmit a Group Assignment command (Message 23) to the EUT with a reporting interval of 5 s assigned. Monitor the VDL until at least 1 min after timeout occurred. Repeat 10 times (transmissions of Message 23 shall not be synchronised to the initial transmission schedule of the EUT).

Measure the time Trev between the reception of Message 23 and the first transmission after timeout.

12.6.6.6.2 Required result

Verify that the time out is randomly distributed between 4 min and 8 min.

2016-05-30	Tester: Ba	Test details: Reverting from interval assignment		
Test item		Check	Remark	Result
-	ndard test envir	onment and operate EUT in autonomo	ous mode with 15 s reporting int	erval.
Transmit Mess EUT inside are station type =	sage 23 ea,	Check that Message 23 has been received. Record R _x time		Passed
Reporting interval = 5 s		Check that EUT transmits position reports with reporting interval of 5 s.		Passed
End of assigne	ed mode	Check that the slots of the assigned reporting interval are released using time-out = 0 and slot offset = 0		Passed
		Check that the slot of the autonomous reporting interval (15 s) are allocated according to the network entry procedure		Passed
After 10 times	After 10 times group assignment			
Time-out		Check that the time-out time is randomly distributed between 4 and 8 minutes	Test 2016-06-01 Ba: 40 group assignments have been evaluated	Passed

Federal Maritime and Hydrographic Agency



5.6.6.7 12.6.6.7 Assignment priority test - Message 16 and 23

12.6.6.7.1 Purpose

The purpose of this test is to ensure that the EUT selects the correct assignment Message when given both addressed and group assignments.

12.6.6.7.2 Method of Measurement

Set up standard test environment and operate the EUT in autonomous mode.

- a) Transmit a Message 23, addressed to the EUT, to assign a reporting interval of 15 s. Check that the EUT reporting interval is 15 s. Transmit a Message 16, addressed to the EUT, assigning a reporting interval of 10 s while still assigned by Message 23.
- b) Transmit a Message 16, addressed to the EUT, to assign a reporting interval of 15 s. Check that the EUT reporting interval is 15 s. Transmit a Message 23, addressed to the EUT, assigning a reporting interval of 10 s while still assigned by Message 16.

12.6.6.7.3 Required result

Confirm that:

- a) the EUT adopts the reporting interval of Message 16;
- b) the EUT continues with the reporting interval of Message 16.

2016-05-30	Tester: Ba	Test details: Assignment	priority – Message 16 and 23	
Test item	-	Check	Remark	Result
a) Operate EU	JT in autonomo	us mode, reporting interval = 30 s		
Transmit Mess reporting inter		Verify that EUT enters assigned mode with 15 s reporting interval.	UTC 06:42	Passed
During assigned mode: Transmit Message 16 with 10 s reporting interval		Check that EUT changes the reporting interval to 10 s.	UTC 06:45	Passed
b) Message 23	3 during Messa	ge 16 assignment		
Transmit Mess reporting inter	•	Verify that EUT enters assigned mode with 15 s reporting interval.	UTC 06:55	Passed
During assigned Transmit Mess 10 s reporting	sage 23 with	Check that EUT continues with 15 s reporting interval.	UTC 06:56	Passed

Federal Maritime and Hydrographic Agency



5.6.6.8 12.6.6.8 Assignment priority test - Message 22 and 23

12.6.6.8.1 Purpose

The purpose of this test is to ensure that the EUT selects the correct assignment Message when given group assignments by Messages 22 and 23.

12.6.6.8.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode. Transmit a Message 22 defining a region with the EUT inside that region Tx/Rx mode = 0.

- a) Transmit an Assigned mode command (Message 23) to the EUT with Tx/Rx mode 1.
- b) Transmit Message 22 to the EUT with regional settings specifying Tx/Rx mode 2.
- c) Transmit an Assigned mode command (Message 23) to the EUT with Tx/Rx mode 1.
- d) During assigned mode transmit a Message 22 to the EUT individually addressed and specifying Tx/Rx mode 2.
- e) Within 10 min transmit a Message 22 with regional area settings specifying Tx/Rx mode 0.
- f) Transmit an Assigned mode command (Message 23) to the EUT with Tx/Rx mode 1 every min for 15 min.
- g) After timeout of the last Message 23 transmit a Message 22 with regional settings specifying Tx/Rx mode 0.

Record transmitted messages.

12.6.6.8.3 Required result

The following results are required.

- a) Check that Tx/Rx mode = 1. The Tx/Rx mode field setting of Message 23 takes precedence over the Tx/Rx mode field setting of Message 22.
- b) Check that Tx/Rx mode = 1. The EUT reverts to the Tx/Rx mode = 2 defined by Message 22 after the timeout of Message 23.
- c) Verify that $Tx/Rx \mod = 1$.
- d) Check that Tx/Rx mode = 2. The Tx/Rx mode field setting of Message 22 takes precedence over the Tx/Rx mode field setting of Message 23.
- e) Check that Tx/Rx mode = 2. The Tx/Rx mode setting of Message 22 are ignored.
- f) Check that the Tx/Rx mode remains at 2 min for 10 min after applying Message 22. Check that the Tx/Rx mode is changed to 1 when receiving Message 23 later than 10 min after Message 22. Check that after timeout of the last Message 23 the Tx/Rx mode reverts to 2 according to the individually addressed Message 22.
- g) Check that Tx/Rx mode = 0. The Tx/Rx mode setting of Message 22 are accepted.



2016-05-30 Tester: Ba	Test details: Assignment	priority – Message 22 and 23			
Test item	Check	Remark	Result		
Operate EUT in autonomous Apply a channel managemen	mode with 15 s reporting interval. t area with Tx/Rx mode = 0.				
	Test for priority of Message 22 to an area				
a) Transmit Message 23 with Tx/Rx mode = 1.	Verify that Message 23 is received and content is correct.	UTC 08:21 Retest 2016-06-16 Ba: UTC 10:55	Passed		
	Check that reporting interval is 15 s on channel A (Tx/Rx mode = 1).		Passed		
b) Transmit Message 22 with Tx/Rx mode = 2.	Verify that Message 22 is received (ACA output).	UTC 08:23 There is a NAK output Note) The Tx/Rx mode 2 shall be accepted and stored but not yet used before time- out of Message 23 group assignment.	Passed		
	Check T_x/R_x mode = 1 as defined by Message 23.	Retest 2016-06-16 Ba: UTC 10:57 Tx/Rx mode = 1	Passed		
Wait for Assigned mode time-out.	Check that reporting rate = autonomous reporting rate.		Passed		
	Check T_x/R_x mode = 2 =mode of Message 22 (T_x on channel B).	Tx/Rx mode = 0 <u>Retest 2016-06-16 Ba:</u> UTC 11:01 Tx/Rx mode = 2	Passed		
Test for priority of Message 2	2 individually addressed				
c) Transmit Message 23 with T_x/R_x mode = 1.	Verify that Message 23 is received and content is correct.		Passed		
	Confirm that EUT transmit position reports on channel A with 15 s reporting interval (Tx/Rx mode = 1).		Passed		
d) Transmit Message 22 individually addressed	Verify that Message 22 is received and content is correct.		Passed		
(MMSI) with T_x/R_x mode = 2.	Check T_x/R_x mode = 2 = mode of Message 22 (T_x on channel B).		Passed		
	After receiving Message 22 all messa by 1 slot (e.g. from 266 to 267). This repetition of the test.				
	Retest 2016-06-16 Ba: The slots are not shifted		Passed		
e) Within 10 min transmit Message 22 to an area with	Verify that Message 22 is received and content is correct.		Passed		
T_x/R_x mode 0.	Check that Tx/Rx mode = 2, the mode of Message 22 is ignored.		Passed		

Federal Maritime and Hydrographic Agency



f) Transmit Message 23 with T _x /R _x mode 1 every minute	Verify that Message 23 is received and content is correct.	Passed
for 15 min.	Check that Message 23 is ignored for the first 10 minute.	Passed
	Confirm that EUT changes to Tx/Rx mode 1 after 10 minutes.	Passed
Wait for Assigned mode time-out.	Check that reporting rate = autonomous reporting rate.	Passed
	Check T_x/R_x mode = 2 = mode of Message 22 (T_x on channel B).	Passed
g) Transmit Message 22 to an area with Tx/Rx mode =	Verify that Message 22 is received (ACA output).	Passed
0.	Check T_x/R_x mode = 0.	Passed
	After receiving Message 22 all messashifted by 1 slot (e.g. from 1180 to 11 reproduced in a repetition of the test.	
	Retest 2016-06-16 Ba: The slots are not shifted	Passed

5.6.7 12.6.7 Base station reservations

12.6.7.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode with 5 s reporting interval (SOG = 25 kn). Apply a Message 4 to the VDL using a base station MMSI.

- a) Transmit a Data Link Management message (Message 20) on Channel A from a Base Station within 120 NM to the EUT with slot offset = 5 and increment = 10. Record transmitted messages.
- b) Repeat the test with a Base Station beyond 120 NM.
- c) Repeat the test without Base Station Report (Message 4).
- d) Repeat the test reserving 100 % of the slots.
- e) Repeat the test with a Base Station within 120 NM and maintain transmission of Message 20. Stop transmission Message 4.
- f) Repeat test a) using a non-base station MMSI.

12.6.7.2 Required results

The following results are required.

- a) For the Base Station within 120 NM, confirm that EUT does not use slots allocated by Message 20 for own transmissions until timeout of 4 min to 8 min. Confirm that the EUT does not use the same slots on Channel B.
- b) For the Base Station beyond 120 NM confirm that the EUT treats the slots as free.
- c) Confirm that the EUT treats the slots as free.
- d) Confirm that the EUT stops transmission.
- e) Confirm that the EUT ignores the slot reservations of a Message 20 which is received after the normal target time-out of Message 4.
- f) Confirm that the EUT treats the slots as free.

Federal Maritime and Hydrographic Agency




Test scenario:

Message 20 is transmitted in slot 0 of each frame

Message 20 parameters:

Offset number 1: 25
Number of slots: 5
Time out 1: 7
Increment: 10

FATDMA reservation:



2016-05-30	Tester: Ba	Test details: FA	TDMA reserved slots	
Test item		Check	Remark	Result
Operate EUT v	with 5 s reportin	g interval (SOG = 25 kn) according to	the description below.	
a) Transmit ba report Messag	e 4 with	Check that the reserved slots on channel B are not used by the EUT.	UTC 09:42	Passed
distance < 120 Transmit Mess frames on cha slot reservation	sage 20 for 5 nnel B with	Check that the reserved slots on channel A are not used because of priority rules.		Passed
After time-out of 20 of 48 min		Check that all slots are used again.		Passed
b) Repeat test station distance		Check that all slots are used.	UTC 10:26	Passed
c) Repeat test Message 4.	without	Check that all slots are used.	UTC 11:13	Passed
d) Repeat test slot reservation		Check that EUT stops transmission.	UTC 11:38 Tx on the reservation channel is stopped	Passed
e) Transmit Medistance < 120 Message 20 wreservation.	NM, and	Check that the reserved slots are not used.		Passed
Stop message Continue Mess	•	Check that messages 20 which are received after normal target time-out of Message 4 are ignored and all slots are used.		Passed
f) Repeat test a non-base station		Check that the reservation is ignored and all slots are used.	UTC 10:59	Passed

Federal Maritime and Hydrographic Agency



5.7 12.7 Message formats

5.7.1 12.7.1 Received messages

(See 7.6)

12.7.1.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode. Apply messages according to Table 8 to the VDL including multiple slot messages up to 5 slots. Record messages output by the PI of EUT.

12.7.1.2 Required results

Confirm that EUT outputs corresponding message with correct field contents and format via the PI or responds as appropriate.

For the VDM frame the following items shall be checked:

Field	Value for single sentence	Values for multi sentences
Number of sentences	1	Number of sentences
Check sentence number	1	1, 2,
Sequential message identifier	Null field	09, counting up for each multi sentence group
Channel	A, B	
Fill bits	Depending on message type, in most cases 0	

2016-05-31	Tester: Ba	Test details: Received messages		
Test item		Check	Remark	Result
Apply all Mess	ages of table 8	to the VDL. Evaluate the VDM output		
Message 1		Check single sentence frame.		Passed
		Check message content.		Passed
Message 2		Check single sentence frame.		Passed
		Check message content.		Passed
Message 3		Check single sentence frame.		Passed
		Check message content.		Passed
Message 4		Check single sentence frame.		Passed
		Check message content.		Passed
Message 5		Check multi (2) sentence frame.		Passed
		Check message content.		Passed
Message 6		Check single sentence frame.		Passed
Addressed to I	EUT	Check message content.		Passed
Message 6		Check that there is no VDM output.		Passed
Addressed to	other station			
Message 7		Check single sentence frame.		Passed
Addressed to I	EUT	Check message content.		Passed
Message 7		Check that there is no VDM output.		Passed
Addressed to	other station			
Message 8		Check single sentence frame.		Passed
		Check message content.		Passed



		i i	HYDROGRAPHIE
Message 9	Check single sentence frame.		Passed
	Check message content.		Passed
Message 10	Check that there is no VDM output.		Passed
Message 11	Check single sentence frame.		Passed
	Check message content.		Passed
Message 12	Check single sentence frame.		Passed
Addressed to EUT	Check message content.		Passed
Message 12	Check that there is no VDM output.		Passed
Addressed to other station			
Message 13	Check single sentence frame.		Passed
Addressed to EUT	Check message content.		Passed
Message 13	Check that there is no VDM output.		Passed
Addressed to other station			
Message 14	Check single sentence frame.		Passed
Single slot	Check message content.		Passed
Message 15	Check single sentence frame.		Passed
EUT as destination	Check message content.		Passed
Message 15	Check that there is no VDM output.	There is a VDM output	Passed
EUT is not destination	, and the second	·	
Message 16	Check single sentence frame.		Passed
Addressed to EUT	Check message content.		Passed
Message 16	Check that there is no VDM output.	There is a VDM output	Passed
Addressed to other station			
Message 17	Check multi (2) sentence frame.		Passed
	Check message content.		Passed
Message 18	Check single sentence frame.		Passed
	Check message content.		Passed
Message 19	Check single sentence frame.		Passed
	Check message content.		Passed
Message 20	Check single sentence frame.		Passed
•	Check message content.		Passed
Message 21	Check single or multi sentence frame.	Single sentence	Passed
	Check message content.		Passed
Message 22	Check single sentence frame.		Passed
for an area	Check message content.		Passed
Message 22	Check single sentence frame.		Passed
Addressed to the EUT	Check message content.		Passed
Message 22	Check that there is no VDM output.	There is a VDM output	Passed
Addressed to other station		'	
Message 23	Check single sentence frame.		Passed
· ·	Check message content.		Passed
Message 24 A	Check single sentence frame.		Passed
· ·	Check message content.		Passed
	<u> </u>	†	

Message 24 B

Check single sentence frame.

Check message content.

Passed Passed

Federal Maritime and Hydrographic Agency



Message 25	Check single sentence frame.		Passed
Broadcast	Check message content.		Passed
Message 25	Check single sentence frame.		Passed
Addressed to EUT	Check message content.		Passed
Message 25	Check that there is no VDM output.	There is a VDM output	
Addressed to other station		Retest 2016-06-16 Ba:	Passed
		There is no VDM	
Message 26	Check single sentence frame.		Passed
Broadcast	Check message content.		Passed
Message 26	Check single sentence frame.		Passed
Addressed to EUT	Check message content.		Passed
Message 26	Check that there is no VDM output.	There is a VDM output	
Addressed to other station		Retest 2016-06-16 Ba:	Passed
		There is no VDM	
Message 26	Check multi sentence frame.	There is no VDM output	
Maximum length (1064 bit)		Retest 2016-06-16 Ba:	Passed
		There is a VDM output	
	Check message content.		Passed
Message 27	Check that there is no VDM output.		Passed
Message of undefined type	Check single sentence frame.		Passed
	Check message content.		Passed

5.7.2 12.7.2 Transmitted messages

12.7.2.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode. Initiate the transmission of messages relevant for a mobile station according to Table 8 by the EUT.

Record transmitted messages.

12.7.2.2 Required results

Confirm that EUT transmits messages with correct field contents and format or responses as defined in Table 8.

For the VDM frame the following items shall be checked:

Field	Value for single sentence	Values for multi sentences
Number of sentences	1	Number of sentences
Check sentence number	1	1, 2,
Sequential message ident.	Null field	09, counting up for each multi sentence group
Channel	A, B	
Fill bits	Depending on message type, in most cases 0	

The messages not listed in the following table cannot be transmitted by a Class B SO.



2016-06-02	Tester: Ba	Test details: Transmitted messages		
Test item	1	Check	Remark	Result
Apply all Mess	sages of table 8	to the VDL. Evaluate the VDM outp	ut	
Message 6		Check single sentence frame.	See test 10.2.2.1	Passed
Apply ABM se	ntence	Check message content.		Passed
Message 7		Check single sentence frame.	See test 10.2.2.3	Passed
Apply Msg 6 to	o VDL	Check message content.		Passed
Message 8		Check single sentence frame.	See test 10.2.2.4	Passed
Apply BBM se	ntence	Check message content.		Passed
Message 13		Check single sentence frame.	See test 10.2.2.3	Passed
Apply Msg 12	to the VDL	Check message content.		Passed
Message 18		Check single sentence frame.	See test 10.2.1.1	Passed
Automatically transmitted		Check message content.		Passed
Message 19		Check multi (2) sentence frame.	Single sentence	Passed
Apply Msg 15	interrogation	Check message content.	See test 10.2.3	Passed
on VDL		Check message content.		Passed
Message 24 A	\	Check single sentence frame.	See test 12.6.4	Passed
Automatically	transmitted	Check message content.		Passed
Message 24 B	3	Check single sentence frame.	See test 12.6.4	Passed
Automatically	transmitted	Check message content.		Passed
Message 25 b	roadcast	Check single sentence frame.	See test 10.2.2.4	Passed
Apply BBM se	ntence	Check message content.		Passed
Message 25 a	ddressed	Check single sentence frame.	See test 10.2.2.1	Passed
Apply ABM se	ntence	Check message content.		Passed
Message 26 b	roadcast	Check single sentence frame.	See test 10.2.2.4	Passed
Apply BBM se	ntence	Check message content.		Passed
Message 26 a	ddressed	Check single sentence frame.	See test 10.2.2.1	Passed
Apply ABM sentence		Check message content.		Passed

Federal Maritime and Hydrographic Agency



6 13 Specific tests of network layer

6.1 13.1 Regional area designation by VDL Message

13.1.1 Purpose

The purpose of this test is to ensure that the EUT transmits on the correct channels when transiting adjacent regional areas.

13.1.2 Method of measurement

Set up the standard test environment.

- a) With no Message 4. Apply channel management messages (Message 22) to the VDL defining two adjacent regional areas, 1 and 2, with different channel assignments for both regions and a transitional zone extending 4 NM either side of the regional boundary,
- b) With a Base Station within 120 NM transmitting Message 4. Apply the same channel management Messages as in a). Make the EUT approach region 1 from outside region 2 more than 5 NM away from the region boundary, transmitting on default channels. Record transmitted Messages on all 6 channels. This can be accomplished by either using a dedicated test input for simulated position information or a GNSS simulator




Figure 11 - Regional transitional zones

Table 14 – Regional area scenario

	Primary channel	Secondary channel
Region 1	CH A 1	CH B 1
Region 2	CH A 2	CH B 2
Default region	AIS 1	AIS 2

Federal Maritime and Hydrographic Agency



- c) Operate the unit in an area with Tx/Rx mode 1.
- d) Operate the unit in an area with Tx/Rx mode 2.
- e) Transmit Message 22 using a non-base station MMSI.

13.1.3 Required results

The following results are required.

- a) Check that the channel management regions are not stored and not used by the EUT.
- b) Check that the EUT transmits and receives on the primary channels assigned for each region, alternating channels and halving the reporting interval when passing through the transitional zones (see Table 15). Check that the EUT reverts to default autonomous operation on the regional channels after leaving the transitional zones. Check that TXT and ACA sentences are output when defining the area, crossing the boundary of the area and on request. The In-use flag shall be set to "1" if the position is inside the area which is defined by the two corner points of the area setting (e.g. the grey area defining region 2 in Figure 11).

Table 15 - Required channels in use

	Area	Channels in use
1	Default region	AIS 1, AIS 2
2	First transitional zone	AIS 1, CH A 2
3	Region 2	CH A 2, CH B 2
4	Second transitional zone	CH A 2, CH A 1
5	Region 1	CH A 1, CH B 1

- c) Check that the EUT transmits on only channel A with the nominal reporting interval (the number of transmissions doubles on the active channel when transmitting on one channel only).
- d) Check that the EUT transmits on channel B only with the nominal reporting rate.
- e) When using a non-base station MMSI, verify that the EUT does not accept the channel management.

2016-05-31 Tester: Ba		Test details: Check of message 22 acceptance		
Test item		Check	Remark	Result
Transmit mess	sage 22 with a r	new area settings for area 1 and 2		
a) Transmit message 22 from a base station not transmitting message 4		Check that the area setting is not stored	UTC 08:15	Passed
Transmit message 22 from a base station transmitting message 4, distance > 120 NM		Check that the area setting is not stored		Passed
e) Transmit message 22 from a base station transmitting message 4, distance < 120 NM MMSI of message 4 and 22 is a non-base station MMSI		Check that the area setting is not stored		Passed

Federal Maritime and Hydrographic Agency



Test b) is performed in 2 parts:

• The first part checks the general behaviour including check of ACA and TXT output, check of the borders of area a transitional zone, check of the correct frequency use.

2016-05-31	Tester: Ba	Test details: b) Part 1 - Channel management by VDL message 22		
Test item		Check	Remark	Result
defining 2 adja		ode transmitting on channel AIS 1/AIS channels A 1, B 1 and A 2, B 2.	2, apply 2 Messages 22 on th	e VDL,
PI output		Check that the Messages 22 are output as VDM on PI.		Passed
		Check ACA and TXT output on PI when the areas are stored.		Passed
		Check ACA and TXT output on PI on request.		Passed
Item 1: Position in high	n sea area	Check that channels AIS 1 and AIS 2 are in use.		Passed
Item 2: Move position	into outer TZ	Check the limit of the TZ (5 NM = 8.8 minutes).	UTC 11:42	Passed
of region 2		Check that channels AIS 1 and A 2 are used.		Passed
		Check that reporting rate is doubled.		Passed
Item 3:		Check ACA and TXT output.	UTC 11:55	Passed
Move position of region 2	into inner TZ	ACA: check in use flag of area 2 = 1.		Passed
(crossing the a	area border)	ACA: check time of in use flag.		Passed
		Check the border of area.		Passed
Item 4: Move position	into region 2	Check the limit of the TZ (4 NM = 7 minutes).		Passed
(out of TZ)	-	Check that channels A 2 and B 2 are used.		Passed
		Check that reporting rate is changed back to normal reporting rate.		Passed
Item 5: Move position	into TZ	Check that channels A 2 and A 1 are used.	UTC 12:09	Passed
between region 1 and 2, inside area 2		Check the limit of the TZ (4 NM = 7 minutes).		Passed
		Check that reporting rate is doubled.		Passed
Item 6:		Check ACA and TXT output.	UTC 12:14	Passed
Move position (inside the TZ) (crossing the a		Check the border of area.		Passed
Item 7: Move position		Check that channels A 1 and B 1 are used.	UTC 12:17	Passed
(out of TZ)		Check the limit of the TZ (4 NM = 7 minutes).		Passed
		Check that reporting rate is changed back to normal reporting rate.		Passed

Federal Maritime and Hydrographic Agency



Passed Item 8: Check that channels A 1 and AIS 1 UTC 12:20 are used. Move position into TZ of Passed region 1 to high sea Check that reporting rate is doubled. Passed Item 9: Check ACA and TXT output. UTC 12:23 Passed Move position out of area 1 Check the border of area. (inside the TZ) (crossing the area border) Passed Move position out of the TZ, Check that channels AIS 1 and AIS UTC 12:25 into high sea 2 are used. Passed ACA: check in use flags of area 1 = 0 and time of in use flag. Passed Check that reporting rate is changed back to normal reporting rate.

• The second part concentrates on the correct slot allocation and usage during a transition from one (high sea) area into another on the different channels.

2016-05-31	Tester: Ba	Test details: b) Part 2 - Channe	el management by VDL messag	e 22
Test item	1000011 24	Check	Remark	Result
The same are	a and moveme	nt is used as in test part 1.		<u> </u>
Item 1: In high sea are	ea	Check that channels AIS 1 and AIS 2 are in use.		Passed
In high sea area Item 2: Move position into transitional area of region 2, first frame after transition		Check that EUT continues T _X on AIS 1 and AIS 2 for 1 frame.	Retest 2016-07-04 The EUT activates Alarm 006 "General failure" and stops transmission after entering the TZ of the area. Therefor the Retest could not be continued. See log file It seems to be a problem of assigning an invalid frequency to the transmitter. Retest 2016-07-22 Ba: The EUT continues transmission on AIS1 and AIS2	Passed
		Check that EUT releases the slots on AIS 2 by Message 1 with time-out 0 and no slot offset.		Passed
		Check that channels AIS 1 and $\bf A 2$ are used for $\bf R_{x.}$		Passed



Item 3:	Check allocation of additional slots	All slots on AIS1 are released	Passed
In outer transitional area of region 2, next frames after transition	on channel A (AIS 1) using ITDMA comm state	and a new transmission schedule with 5 s reporting interval is allocated	. 45554
		This is not appropriate but seems to be acceptable.	
	Check complete slot allocation on channel B (A 2) using ITDMA comm state.		Passed
	Check that channels AIS 1 and A 2 are used for T _x .		Passed
	Check that channels AIS 1 and A 2 are used for R _x .		Passed
	Check that reporting rate is doubled.		Passed
	Check that messages on AIS 1 are output on PI (VDM/VDO) as channel "A" and A 2 as channel "B".		Passed
Item 4:	Check that messages on AIS 1 are	AIS1 is output as A and A2 is	
Move into inner transitional area of region 2, crossing	output on PI (VDM/VDO) as channel "A"	output as B (same as in outer TZ)	
the area border	(channels reverted).	Retest 2016-07-22 Ba:	
		Tx/Rx A: A2	
		Tx/Rx B: 2084 = 161.825 MHz	
		2084 is Channel A of another stored area which has been in use before this test.	
		See Note 2)	
		Retest 2016-08-23 Ba:	Danasal
		The correct channels are used.	Passed
	Check that the usage of slots continues	After crossing the border the messages allocated for AIS1 are transmitted on A2 (channel A of the area 2).	
		The Messages allocated for A2 are not transmitted unless leaving the transitional zone. Then they are transmitted to release the slots.	
		In a third test the behaviour was ok. It requires further evaluation.	
		Retest 2016-07-22 Ba: The Tx continues using the correct slots.	Passed

Federal Maritime and Hydrographic Agency



Item 5: Check that EUT continues T_X on There is only Tx on A2, but AIS 1 and A 2 for 1 frame. for both channels Move position into the area of region 2 (out of TZ), In a third test the behaviour was ok. It requires further first frame after transition evaluation. Retest 2016-07-22 Ba: Passed The EUT continues Tx on AIS1 and A2 Check that EUT releases all slots on No Tx on AIS1, but the slots AIS 1. allocated for A2 are released Retest 2016-07-22 Ba: Passed All slots on AIS1 are released Check that EUT releases every Passed second slot on channel A 2(for reversion to normal reporting rate). Check that channels A 2 and B 2 Passed are used for Rx Item 6: Check allocation of slots on channel Passed B (B 2) using ITDMA comm state. Inside area of region 2, Check that channels A 2 and B 2 Passed next frames after transition are used for T_v Check that channels A 2 and B 2 Passed are used for R_x Check that reporting rate is back to Passed normal reporting rate. Check that messages on A 2 are A2 and B2 are used for Rx. output on PI (VDM/VDO) as The channels in the VDM are channel "A" and B 2 as channel "B". reversed. Messages received on A2 are output as "B" and Messages on B2 are output as "A" Tx messages (VDO) are output correctly Retest 2016-07-22 Ba: Passed The Tx and Rx channels are output correctly in VDM and

Note)

The channels on the diagram are:

Column	Colour	Channel
Left (Channel A)	Black	A2 (channel A of area 2)
Left (Channel A)	Orange	AIS1 (channel A of high sea)
Right (Channel B)	Black	B2 (channel B of area 2)
Right (Channel B)	Orange	AIS2 (channel B of high sea)

VDO



2016-06-02	Tester: Ba	Test details: C	heck of T _x /R _x -Mode	
Test item	-	Check	Remark	Result
Transmit mess	sage 22 to an a	rea with Tx/Rx mode according to the	test item.	-
c) Set T _x /R _x -M		Check that mode is correctly stored.		Passed
Message 22 to	o 1.	Check that channel A only is used for T _{x.}		Passed
		Check that channels A and B are used for R _{x.}		Passed
		Check that the reporting rate is correct.	15 s	Passed
d) Set T _x /R _x -N	lode in	Check that mode is correctly stored.		Passed
Message 22 to	o 2.	Check that channel B only is used for T_{κ}		Passed
		Check that channels A and B are used for R _x .		Passed
		When Message 22 with Tx/Rx mode Tx/Rx mode = 1 or 2) there is for one Message 18 is transmitted in slot 672 A similar problem has been observed	frame an offset of 1 slot (e.g. 2 instead of 671).	
		Retest 2016-07-04 Ba:		
		The same problem now also happens mode 0 to 1 or 2. That means, every changed by Message 22.		
		The problem does not happen when Message 23.	the Tx/Rx mode is changed by	
		Retest 2016-07-25 Ba:		
		There is no slot shift with Message 22	2	Passed

Federal Maritime and Hydrographic Agency



6.2 13.2 Channel management by addressed Message 22

13.2.1 Purpose

The purpose of this test is to ensure that the EUT uses the regional operating settings of an addressed Message 22.

13.2.2 Method of measurement

Set up a standard test environment and operate the EUT in autonomous mode.

- a) Send Message 4 within 120 NM and Message 22 with valid regional operating settings that are different from the default operating settings to the EUT. The regional operating area includes the current position of own station.
- b) Send an addressed Message 22 to the EUT with regional operating settings different from the previous command.
- c) Move the EUT out of the regional operating area defined by the previous addressed command and into an area without regional operating settings.

13.2.3 Required results

Check that

- a) the EUT uses the regional operating settings commanded to it in a),
- b) the EUT uses the regional operating settings commanded to it in b),
- c) the EUT reverts to default.

Federal Maritime and Hydrographic Agency



2016-06-02 Tester: Ba Test details: Test of addressed Message 22 Test item Check Remark Result a) Send a valid Message 22, Check, that the EUT uses the Passed position inside. regional operating settings. b) Send an addressed Check, that the EUT uses the UTC 08:27 Passed message 22 to the EUT with regional operating settings. different regional operating settings. b) Send an addressed Check, that the EUT uses the The addressed Message 22 Message 22, addressed as is not accepted for 10 regional operating settings. ID 2, to the EUT with minutes after the first different regional operating addressed Message 22 settings. See Note) Retest 2016-06-16 Ba: After receiving the addressed Message 22 with new channels the EUT generates an error ID 006 General failure and stops transmission. Remark: the same happens if the channels are changed by Message 22 with an area. Retest 2016-07-04 Ba: UTC 09:18 Passed An addressed Message 22 is accepted also within 10 min after the first addressed Message 22. c) Move the EUT out of the Check, that the EUT reverts to Passed regional operating area default. defined by the previous addressed telecommand.

Note)

The purpose of the 10 minutes protection of an addressed Message 22 is to protect this individual station from being overwritten by a broadcast Message 22 which is normally regularly transmitted every few minutes.

It shall not inhibit an addressed Message 22.

Federal Maritime and Hydrographic Agency



6.3 13.3 Invalid regional operating areas

13.3.1 Purpose

The purpose of this test is to ensure that the EUT rejects invalid regional operating areas (three regional operating areas with same corner).

13.3.2 Method of measurement

Set up standard test environment and operate the EUT in autonomous mode. Perform, after completion of all other tests related to change of regional operating settings, the following.

- a) Send three different valid regional operating settings with adjacent regional operating areas, their corners within 8 NM of each other, to the EUT using Message 22. The current own position of the EUT shall be within the regional operating area of the third regional operating setting.
- b) Move current own position of the EUT consecutively to the regional operating areas of the first two valid regional operating settings.

13.3.3 Required test results

Check that:

- a) the EUT uses the operating settings that were in use prior to receiving the third regional operating setting,
- b) the EUT consecutively uses the regional operating settings of the first two received regional operating areas.

2016-06-02	Tester: Ba	Test details: Test for invalid regional operating areas			
Test item		Check	Remark	Result	
Msg 22 input	Msg 22 input				
a) Send three different valid regional with adjacent corners by message 22, Position inside third area.		Check, that the third area is refused and settings are not used.	UTC 12:20	Passed	
b) Move own p first 2 areas.	position to the	Check, that the EUT uses the operational settings of these areas.		Passed	

6.4 13.4 Continuation of autonomous mode reporting interval

13.4.1 Purpose

The purpose of this test is to ensure that the EUT maintains autonomous reporting interval in a transitional zone.

13.4.2 Method of test

When in the presence of an assigned mode command, and in a transition zone, check that the EUT continues to report at the autonomous reporting interval.

13.4.3 Required result

Ensure that the autonomous reporting interval is maintained.

Federal Maritime and Hydrographic Agency



2016-06-02	Tester: Ba	Test details: Continuation of autonomous mode reporting rate		
Test item	<u>-</u>	Check	Remark	Result
Set the EUT into a transitional zone. Send assignment commands message 16 to the EUT.				
Rate assignment command in a transitional zone.		Check that the rate assignment command is ignored in a transitional zone.		Passed
Slot assignme in a transitional		Check that the slot assignment command is ignored in a transitional zone.		Passed

6.5 13.5 Slot reuse and FATDMA reservations

(See 7.3.2.4)

13.5.1 Method of measurement

Set up standard test environment and operate EUT in autonomous mode. Assure that at test receiver location the signal level received from EUT exceeds the signal level received from test transmitter.

- a) Transmit test targets on channel A with 50 % channel load. Channel B is free. This test covers Rule 0 and 1.
- b) Transmit near and distant test targets with 100 % channel load on channel A in all selection intervals which are under observation. Channel B is free. There shall be enough different targets to allow the EUT to meet the requirement to reuse only one slot of each target per frame.
- c) Transmit near and distant test targets with 100 % channel load on channel B in all selection intervals which are under observation. Channel A is free.
- d) Transmit Message 4 with a position distance < 120 NM and Message 20 with slot reservations on channel A. Transmit near and distant test targets in the unreserved slots on channel A. Channel B is free.

13.5.2 Required results

Confirm that

- a) only free slots are used for transmission on channel A, confirm that only slots which are free on channel A are used for transmissions on channel B,
- b) slots of the most distant test targets are used for transmission on channel A. Check that not more than one slot of a station is reused in a frame,
- for transmission on channel A that the candidate slots on channel A are organized according to the most distance station on channel B,
- d) only unreserved slots are used on channel A. Confirm that slots of the most distant test targets are used for transmission. Confirm that for transmissions on channel B only slots which are not reserved on channel A are used after the next regular time-out 0.



2016-06-02	Tester: Ba	Test deta	ils: Slot reuse	
Test item	11	Check	Remark	Result
Operate the E	UT with 5 s rep	orting interval.		•
	· ·	ney are available.		
 Apply 50% VDL load on channel A. Apply 0% VDL load on channel B. 		Check that only free slots are used on channel A.	All slots are used Retest 2016-07-01 Ba: All slots are used Retest 2016-07-06, EUT#3: Same result, all slots are used Retest 2016-07-21 Ba: Only free slots are used	Passed
		Check that only slots which are free on channel A are used on channel B.	All slots are used Retest 2016-07-01 Ba: All slots are used Retest 2016-07-21 Ba: Only free slots are used	Passed
b) Test for usin	ng slots of most	distant targets		
Apply 100 on channel	% VDL load el A. VDL load on	Check that only the slots of odd numbered targets are used.	All slots are used Retest 2016-07-01 Ba: All slots are used Retest 2016-07-06, EUT#3: Same result, all slots are used Retest 2016-07-21 Ba: Near targets are re-used See Note) Retest 2016-08-23 Ba: In a first test only distant targets are reused. In a repetition of the test after c) and d) also near targets are reused Retest 2016-09-19 Ba: Only distant targets are reused, also after a repetition of the test after test c).	Passed
		Check that the slot of a target is not used twice in a frame on channel A (slot reuse channel).	Test 2016-07-21 Ba: Targets are re-used more than once in a frame Test c) shows the same problem on channel B (slot reuse channel) Retest 2016-08-23 Ba: The targets are reused only once per frame	Passed



201	6-06-02	Tester: Ba	Test details: Slot reuse			
Tes	t item		Check	Remark	Result	
c) T	c) Test for using slots of most distant targets					
•	channel A	% VDL load	Check that only the slots of odd numbered targets are used on channel A.	All slots are used Retest 2016-07-01 Ba: All slots are used Retest 2016-07-21 Ba: Slots of near targets on the other channel are re-used See Note) Retest 2016-08-23 Ba: Slots of near targets on the other channel are re-used Test b) shows the same result, also in the first test See Note) Retest 2016-09-19 Ba: Slots of near targets on the other channel are not re-used	Passed	
d) C	Check for sl	ot reservation b	by message 20 < 120 NM in combinati			
•	slot reserv channel A 4 with dista NM. Transmit r	and message ance < 120 near and t targets in the d slots on	Check that only unreserved slots are used on channel A. Check that the most distant targets are reused on channel A.	All unreserved slots are used Retest 2016-07-01 Ba: Will be retested when a) to c) are ok Retest 2016-07-21 Ba: Near targets are re-used See Note)	Passed	
			Check that on channel B only slots which are not reserved on channel A by Message 20 are selected at time-out 0.	Retest 2016-08-23 Ba: Near targets are re-used Retest 2016-09-19 Ba: Near targets are not reused Test 2016-07-21 Ba: The slots are not re-used Retest 2016-08-23 Ba: Slots which are reserved on channel A are re-used on channel B Retest 2016-09-19 Ba: Slots which are reserved on channel A are not re-used on channel A are not re-used on channel A are not re-used on channel B	Passed Passed Passed	

Federal Maritime and Hydrographic Agency



6.6 13.6 Long-range application by broadcast

(See 7.8)

6.6.1 13.6.1 Long-range broadcast

Method of measurement

Set up standard test environment, enable the EUT to transmit Message 27 and operate EUT in autonomous mode. Use base stations MMSI to transmit Message 4 and Message 23. Record the transmitted messages from the EUT. The designated long-range channels are defined in 8.3.

- a) Do not apply Message 4 and Message 23.
- b) Apply the Message 4 with the long range control bit set to 1 and 0. Place the EUT inside the RF footprint (Message 4 receiving area) of a base station.
- c) Apply the Message 4 with the long range control bit set to 1 and 0. Using the same MMSI as the Message 4, broadcast the Message 23 with station type 10 to define the base station coverage area. Place the EUT inside the RF footprint area, but outside the base station coverage area.
- d) Apply the Message 4 with the long range control bit set to 1 and 0. Using the same MMSI as the Message 4, broadcast the Message 23 with station type 10 to define the base station coverage area. Place the EUT inside the base station coverage area.
- e) Repeat the test d) using different MMSIs for Message 4 and Message 23.
- f) Apply the Message 4 with the long range control bit set to 0. Using the same MMSI as the Message 4, broadcast the Message 23 with station type 10 to define the base station coverage area. Place the EUT inside the base station coverage area. After 6 minutes, remove transmissions of Message 23.
- g) Apply the Message 4 with the long range control bit set to 0. Using the same MMSI as the Message 4, broadcast the Message 23 with station type 10 to define the base station coverage area. Place the EUT inside the base station coverage area. After 6 min. remove transmissions of Message 4.

Required results

Check that EUT transmits the appropriate messages, e.g. in addition to the normal transmission of Messages 1 and 5 with adequate reporting interval on AIS 1 and AIS2, confirm that:

- EUT transmits Message 27 alternating on the designated long-range channels with 3 min reporting interval.
- b) Irrespective of the Message 4 long range control bit status, EUT transmits Message 27 alternating on the designated long-range channels with 3 min reporting interval.
- c) Irrespective of the Message 4 long range control bit status, EUT transmits Message 27 alternating on the designated long-range channels with 3 min reporting interval.
- d) EUT transmits Message 27 alternating on the designated long-range channels with 3 min reporting interval when the Message 4 long-range control bit is set to 1. EUT stops transmitting Message 27 when the Message 4 long-range control bit is set to 0. Verify fields after station type in received Message 23 are ignored.
- e) Irrespective of the Message 4 long range control bit status, EUT transmits Message 27 alternating on the designated long-range channels with 3 min reporting interval.
- f) EUT begins transmission of Message 27 no sooner than 4 minutes and no later than 8 minutes after Message 23 was removed.
- g) EUT begins transmission of Message 27 beyond 3 minutes after Message 4 was removed.



2017-02-23	Tester: Me	Test details: Lo	ong range broadcast		
Test item		Check	Remark	Result	
Set up the stan	dard test envir	onment and operate EUT in autonomo	ous mode.		
Enable the EU	T to transmit M	essage 27, e.g. by configuring the long	g range broadcast channels,		
Message 4 and	Message 4 and 23 in the following test steps are transmitted from the same base station MMSI.				
a) no message message 23	4 and	Check that message 27 is transmitted		Passed	
		Check Tx channels C and D		Passed	
		Check that the transmission is alternating between C and D		Passed	
		Check reporting interval = 3 min		Passed	
		Check message 27 content		Passed	
"Access schem AIS1 and AIS2	een added to v ne" for slot sele	erify that the requirement of ITU-R M. ction are fulfilled considering the slot re			
Apply the chan channel A with		Check that only slots which are free on channel A are used		Passed	
Apply the chan		Check that only slots which are free	Retest 2017-03-09:	Passed	
channel B with		on channel B are used	Only free slots are used		
b) Apply messa	age 4 only with	out message 23			
Apply message range control b		Check that message 27 is transmitted with 3 min interval		Passed	
Apply message range control b		Check that message 27 is transmitted with 3 min interval		Passed	
c) Apply messa EUT outside th		sage 23 with station type 10 (long rangea	ge coverage area),		
Apply message range control b		Check that message 27 is transmitted with 3 min interval		Passed	
Apply message range control b	•	Check that message 27 is transmitted with 3 min interval		Passed	
d) Apply messa EUT inside the	_	sage 23 with station type 10 (long rang ເ	ge coverage area),		
Apply message range control b		Check that EUT stops transmission of message 27		Passed	
		Verify that the information (Tx/Rx mode, Reporting interval) of message 23 after station type is ignored		Passed	
Apply message range control b		Check that message 27 is transmitted with 3 min interval		Passed	
e) Apply messa	age 23 with sta	tion type 10, EUT inside the coverage	area,		
apply message	4 with a different	ent MMSI than message 23			
Apply message range control b		Check that message 27 is transmitted with 3 min interval		Passed	
Apply message range control b	e 4 with long	Check that message 27 is transmitted with 3 min interval		Passed	

Federal Maritime and Hydrographic Agency



f) Apply message 4 and message 23 with station type 10 (long range coverage area),					
Apply message 4 with long range control bit set to 0					
Stop messages 23 after 6 minutes	Check that EUT starts transmission of Message 27 after the time-out of message 23 (4 8 min)		Passed		
g) Apply message 23 with station type 10 (long range coverage area), EUT inside the coverage area					
Apply message 4 with long range control bit set to 0	Check that message 27 is not transmitted		Passed		
Stop message 4 after 6 Check that EUT starts transmission of Message 27 later than 3 minutes after end of message 4					

6.6.2 13.6.2 Multiple assignment operation

Method of measurement

Set up standard test environment, enable the EUT to transmit Message 27 and operate EUT in autonomous mode with a reporting interval of 10 s. Use base stations MMSI to transmit Message 4 and Message 23. Record the transmitted messages from the EUT.

- a) Transmit a Group Assignment command (Message 23) to the EUT (define geographic region so that the EUT is inside this region). Set the reporting interval to 2 s and the station type to 0 (all stations).
- b) Using different MMSIs, apply the Message 4 with long range control bit set to 1 and 0 from multiple base stations partially overlapping their RF footprints. Broadcast the Message 23 from multiple base stations with station type 10 to define the base station coverage areas not overlapping. Place the EUT inside the overlapped RF footprint area.
- c) Using different MMSIs, apply the Message 4 with long range control bit set to 1 and 0 from multiple base stations partially overlapping RF footprints. Broadcast the Message 23 from multiple base stations with station type 10 to define the base station coverage areas partially overlapping the base station coverage areas. Place the EUT inside the overlapped base station coverage area.
- d) Using different MMSIs, apply the Message 4 with long range control bit set to 1 and 0 from multiple base stations partially overlapping RF footprints. Broadcast the Message 23 from one base station with station type 10 to define the base station coverage areas. Do not broadcast Message 23 from other base stations. Place the EUT inside the RF footprint area of base station not broadcasting Message 23.

Required results

- a) EUT switches to assigned mode and transmits position reports with 2 s reporting interval. EUT reverts to autonomous mode after timeout period
- b) Irrespective of the Message 4 long-range control bit status of both base stations, EUT transmits Message 27 alternating on the designated long-range channels with 3 min reporting interval.
- c) EUT transmits Message 27.
- d) Irrespective of the Message 4 long range control bit status of both base stations, EUT transmits Message 27 alternating on the designated long-range channels with 3 min reporting interval.



2017-02-23	Tester: Ba	Test details: Multiple assignments		
Test item	<u>"</u>	Check	Remark	Result
Enable the EU		onment and operate EUT in autonomo essage 27, e.g. by configuring the long al = 10 s		
a) Transmit M EUT inside are station type = Reporting inte	essage 23 ea, 0,	Check that Message 23 is received (VDM output)	See test 12.6.6.1	Passed
Reporting rate		Check that the reporting interval is changed to 5 s		Passed
Message 23 ti	meout	Verify that EUT reverts to normal operation mode after 4 8 min		Passed
base station, t		ith station type 10 (long range coveraç ea not overlapping eas	ge area) from two different	
station 1 is	e control bit of	Check that message 27 is transmitted with 3 min interval	See test 13.6.1 c)	Passed
c) Apply mess base station, t	age 4 and 23 w he coverage are	ith station type 10 (long range coverage eas are overlapping art of the coverage areas	ge area) from two different	
Long rang station 1 is	ge control bit of s set to 0	<u> </u>		Passed
and message	4 from a second	rith station type 10 (long range coveract d base station 23 coverage area of base station 1	ge area) from one base station	
Long rang station 1 isLong rang	ge control bit of s set to 0 ge control bit of		See test 13.6.1 c)	Passed
station 1 is	ge control bit of s set to 1 ge control bit of	Check that message 27 is transmitted with 3 min interval	See test 13.6.1 b)	Passed

Federal Maritime and Hydrographic Agency



6.7 13.7 Other features

(See 4.1.4)

The performance of other features provided shall be self-certified by the manufacturer.

2016-11-30	Tester: Ba	Test details: Other features		
Test item	<u>-</u>	Check	Remark	Result
Performance of features.	of other	Check the manufacturers documentation for the performance of other features	Document: WIDELINK B-600 Technical Notes TN-600-001.pdf The manufacturer has documented the performance of other features	Passed

Federal Maritime and Hydrographic Agency



7 Annex D DSC functionality

(normative)

7.1 A.4 DSC functionality tests

7.1.1 A.4.1 General

For the tests in this subclause, set the EUT into assigned mode using channels AIS 1 and AIS 2 with a reporting interval of 10 s.

A.4.2 Method of measurement

Send a sequence of valid calls consisting of:

- DSC test signal number 2;
- DSC test signal number 3;
- DSC test signal number 2;
- DSC test signal number 4;
- DSC test signal number 2.

A.4.3 Required results

Check that the EUT AIS operation is not affected by the interleaved calls.

2016-07-05	Tester: Ba	Test details: S	Sequence of 5 calls			
Test item	-	Check	Remark	Result		
	Activate DSC function. Set reporting interval by rate assignment to 10 s and record VDL.					
Start DSC transequence.	smission of test	Check that the transmission schedule of the AIS position reports is not affected by the transmission of the DSC calls.	UTC 10:50 / 10:51 UTC 11:05 / 11:06 UTC 11:20 / 11:21 During the DSC reception the Tx slots are shifted by 1 or 2 slots (see diagrams). Retest 2016-07-25 Ba: There is no slot shift during DSC reception.	Passed		

Federal Maritime and Hydrographic Agency



7.1.2 A.4.4 Regional area designation

Perform the following tests using DSC test signal number 2.

Send DSC test signal number 2 to the EUT but with symbol numbers appropriate to the geographical regions and channels specified in the test. Note the transition boundary is 5 NM in this test.

7.1.3 A.4.5 Scheduling

A.4.5.1 General

The purpose of this test is to confirm that the EUT's AIS reporting is not affected during the DSC monitoring times and a response is not transmitted.

A.4.5.2 Method of measurement

Send DSC test signal number 2 to the EUT, with EOS = 127 and another signal with EOS=117 (RQ).

A.4.5.3 Required results

Check that the EUT's AIS reporting is not affected during the DSC monitoring times. Check that the EUT accepts the channel management, but a response is not transmitted in either case of EOS = 127 and 117.

2016-07-05	Tester: Ba	Test detai	Test details: Scheduling								
Test item		Check	Remark	Result							
Set reporting in	nterval to 15 s a	nd record VDL									
Set reporting interval to 15 s ar Send DSC call test signal number 2.		Check that the AIS reporting is not affected during the DSC monitoring times.	During the DSC reception the Tx slots are shifted by 1 or 2 slots (see diagrams). If there are no DSC calls during the DSC reception times the AIS schedule is not affected. Retest 2016-07-25 Ba: There is no slot shift during DSC reception.	Passed							
		Check that no response is transmitted.		Passed							
Send a DSC c EOS=117 (RC		Check that not response is transmitted.		Passed							

Federal Maritime and Hydrographic Agency



7.1.4 A.4.6 DSC flag in Message 18

A.4.6.1 General

The purpose of this test is to confirm that the DSC flag is set properly when DSC functionality is available.

A.4.6.2 Method of measurement

Perform the following:

- a) enable DSC monitoring;
- b) disable DSC monitoring.

A.4.6.3 Required results

Check that

- a) the DSC flag is set to one,
- b) the DSC flag is set to zero.

2016-06-13	Tester: Ba	Test details: DSC flag								
Test item		Check	Remark	Result						
Record Message 18 on VDL										
DSC enabled		Check that the DSC flag is set.		Passed						
DSC disabled		Check that the DSC flag is not set.		Passed						

Federal Maritime and Hydrographic Agency



7.1.5 A.4.7 DSC monitoring time plan

A.4.7.1 General

The purpose of this test is to confirm that DSC commands are received during DSC monitoring times and, if time-sharing is used, are not received outside those times.

A.4.7.2 Method of measurement

Perform the following:

- a) transmit DSC test signal 2 during monitoring time,
- b) transmit DSC test signal 2 outside monitoring time.

A.4.7.3 Required results

Check that

- a) the DSC call is received,
- b) the DSC call is not received.

2016-07-05	Tester: Ba	Test details: DSC	monitoring time plan	
Test item		Check	Remark	Result
Delete all area	settings			-
Send a DSC area setting outside the monitoring time.		If time-sharing is used: Check that the channels are not changed. If time-sharing is not used: Check that the channels are changed according to the area setting.	Time-sharing is implemented	Passed N/A
Send a DSC area setting inside the monitoring time.		Check that the channels are changed according to the area setting.		Passed

Federal Maritime and Hydrographic Agency



7.1.6 A.4.8 Replacement or erasure of dated or remote regional operating settings

A.4.8.1 Method of measurement

Set up standard test environment. Send a valid regional operating setting to the EUT by Message 22 with the regional operating area including the own position of the EUT. Consecutively send a further seven (7) valid regional operating settings to EUT, using both Message 22 and DSC test signal number 2, with regional operating areas not overlapping to the first and to each other. Perform the following in the order shown:

- a) send a ninth Message 22 to the EUT with valid regional operating areas not overlapping with the previous eight regional operating areas;
- b) Step 1: set own position of EUT into any of the regional operating areas defined by the second to the ninth telecommands sent to the EUT previously;
 - Step 2: send a tenth telecommand to the EUT, with a regional operating area which partly overlaps the regional operating area to which the EUT was set by Step 1 but which does not include the own position of the EUT;
- Step 1: move own position of EUT to a distance of more than 500 NM from all regions defined by previous commands;
 - Step 2: consecutively set own position of EUT to within all regions defined by the previous telecommands.

A.4.8.2 Required results

After the initialisation, the EUT shall operate according to the regional operating settings defined by the first Message 22 sent.

- a) Check that the most distant area is removed.
- b) Step 1: check that the EUT changes its operating settings to those of that region which includes own position of the EUT.
 - Step 2: check that the EUT reverts to the default operating settings.

NOTE Since the regional operating settings to which the EUT was set in Step 1 are erased due to Step 2, and since there is no other regional operating setting due to their non-overlapping definition, the EUT returns to default.

- c) Step 1: check that the EUT operates with the default settings.
 - Step 2: check that the EUT operates with the default settings.

Federal Maritime and Hydrographic Agency



2016-07-05 Tester: Ba Test details: Test of replacement or erasure of dated or remote regional operating settings Test item Check Remark Result Send by DSC and msg 22 1 area including own position by MSG 22 (Msg: B Msg 22 Test 13.3.1 Area 1) 7 areas not overlapping, not including own position, first 3 by msg 22, last 4 by DSC Check active area. Check that EUT uses the Passed channels of area 1. a) Send a 9. msg 22 to the EUT Check that the most distant Area 8 is deleted Passed not overlapping the previous area is deleted. areas. b) step 1: Set own position to Passed Check channels of area 2. any of the 7 areas. Check channels of area 3. Passed Passed Check channels of area 4. Check channels of area 5. Passed Check channels of area 6. Passed Check channels of area 7. Passed Check channels of area 8. Passed Check channels of area 9. Passed b) step 2: Send an area 10 by Check that the EUT returns to Passed DSC, overlapping the area 2 of the default operating settings step 1 not including own (the area is deleted). position. c) Step 1: Erasure by distance: Check that the EUT operates Passed with the default settings. Move own position of EUT to a distance of more than 500 miles from all regions defined by previous commands. Check area 2 = default. Passed Step 2: Check of erasure: Set own position of EUT to Check area 3 = default. Passed within all regions defined by the Passed Check area 4 = default. previous telecommands. Passed Check area 5 = default. Check area 6 = default. Passed Passed Check area 7 = default. Check area 8 = default. Passed

Check area 10 = default.

Passed

Federal Maritime and Hydrographic Agency



7.1.7 A.4.9 Test of addressed telecommand

A.4.9.1 Method of measurement

Set up a standard test environment and operate EUT in autonomous mode. Perform the following tests in the following order:

- a) send a DSC test signal number 2 with valid regional operating settings that are different from the default operating settings, to the EUT with a regional operating area, which contains the current position of own station;
- b) send an addressed DSC channel management command to the EUT with different regional operating settings than the previous command;
- c) move the EUT out of the regional operating area defined by the previous addressed telecommand into an area without regional operating settings.

A.4.9.2 Required results

Check that

- a) the EUT uses the regional operating settings commanded to it in a),
- b) the EUT uses the regional operating settings commanded to it in b),
- c) the EUT reverts to default.

2016-07-05	Tester: Ba	Test details: Test of addressed telecommand								
Test item		Check	Remark	Result						
All areas are e	rased by the pre	vious test.								
a) Send a DS0 area, position	C call with a new inside.	Check that the EUT uses the regional operating settings.		Passed						
b) Send an addressed DSC call to the EUT with different regional operating settings.		Check that the EUT uses the settings of the new message.		Passed						
c) Move the position out of the area.		Check that the EUT uses the default channels.		Passed						

Federal Maritime and Hydrographic Agency



7.1.8 A.4.10 Invalid regional operating areas

A.4.10.1 General

Test for invalid regional operating areas (three regional operating areas with same corner).

A.4.10.2 Method of measurement

Set up standard test environment and operate EUT in autonomous mode. Perform the following tests in the following order after completion of all other tests related to change of regional operating settings:

- a) send three different valid regional operating settings with adjacent regional operating areas, their corners within eight miles of each other, to the EUT by DSC test signal number 2. The current own position of the EUT shall be within the regional operating area of the third regional operating setting;
- b) move current own position of the EUT consecutively to the regional operating areas of the first two valid regional operating settings.

A.4.10.3 Required results

Check that

- a) the EUT uses the operating settings that were in use prior to receiving the third regional operating setting,
- b) the EUT consecutively uses the regional operating settings of the first two received regional operating areas.

2016-07-05	Tester: Ba	Test details: Test for in	nvalid regional operating areas	
Test item		Check	Remark	Result
a) Send three different valid regional with adjacent corners by DSC area call, Position inside 3 rd area.		Check that the default channels are used.	UTC 09:01	Passed
b) Move own position to the first area.		Check that the EUT uses the operational settings of the first area.		Passed
second area.		Check that the EUT uses the operational settings of the second area.		Passed

Federal Maritime and Hydrographic Agency



Annex A Test equipment

A.1 Test equipment summary

#	description	type	identification
1	VDL Analyser / Generator	AIS Test unit MKII	S/N AA08PN
			Bund BSH/2012, 7200002112
			BSH PC10745 AISLog
2	Target simulator software	Furuno Navintra	BSH PC 14731
3	Presentation Interface Monitor	BSH	BSH PC 10756
			BSH VC 13416
			SW NewMoni V3.2
4	GMDSS-AIS-Testbox (DSC)	Futronic I/S	200 30 405
5	16 Port Serial Device Server	Moxa NPort 5610	S/N 756
		RS232	
6	16 Port Serial Device Server	Moxa NPort 5630	S/N 9440
		RS485/RS422	
7	Active retransmitting GPS antenna	RA - 48	4800199
8	Trimble GPS reference receiver	4000RS,	S/N 3428A06700
		Part number 21000-	
		76	
	Auxiliaries:		
9	True RMS Multimeter DMM 916	Tektronix	S/N 138531
11	Unbalanced Standard Attenuator	Rhode & Schwarz	BUND KK 11201
		DPR BN 18024/50	
12	2 fixed voltage power supply	SITOP	BUND 102452, 102453
	(24 V/10A)		
14	2 adjustable power supplies	PS 405 D	S/N 2737, 2768
	(30 V/5 A)		

A.1.1 VDL Analyser / Generator

The VDL analyser/generator:

- <u>receives</u> the radio data telegrams transmitted by the AIS under test, slot wise evaluates their radio parameters (field strength, SNR, etc.) and provides a transparent display of the decoded radio data telegrams (VDL messages).
- <u>transmits</u> radio data telegrams which have been entered/edited via a control panel. The AIS under test receives these messages and either passes the received data to it's presentation interface and/or responds as appropriate.
- <u>records</u> all data contained in the received radio telegrams and radio parameters in a data base for offline evaluation and documentation purposes.
- <u>simulates</u> AIS targets by transmitting position reports of virtual targets up to the maximum channel capacity of 100% channel load on both channels (4500 messages / minute). The data are provided via serial interface to the VDL analyser/ Generator.

The VDL analyser is controlled by a user interface software running on a standard PC. This user interface software composes the transmission messages and decodes and displays the

Federal Maritime and Hydrographic Agency



received messages.

A.1.2 Target simulator

The target simulator consists of a standard PC with special AIS Target Simulator software.

For tests of AIS transponders the data of up to 75 moving targets defined in text file in plain language are transferred to the "TS" input of the VDL Analyser/ Generator as VDM sentences and transmitted on the VHF data link (VDL) . Thus the AIS VHF data link is loaded with simulated AIS targets in fixed slots or in slots selected by the VDL Analyser/ Generator.

A.1.3 Presentation Interface Monitor

The Presentation Interface Monitor is a PC software running on four standard PCs. It is used to

- analyse the AIS high speed input / output
- analyse the AIS long range function
- generate DSC calls for the DSC test box and to display, log and evaluate the received DSC calls from EUT.

For that purpose it includes the functions:

- coding / decoding of NMEA 6-bit data fields
- online AIS message filtering
- online AIS message editing
- load and transmit predefined sequences
- online modification of transmitted sequences

A.1.4 Sensor Data Simulator

The Sensor Data Simulator provides simulated sensor data to the serial sensor data inputs of the EUT. The sensor data are provided in text files to the Sensor Data Simulator which modifies the sensor data sentences e.g. adding the actual UTC time, modify some time-varying data and by adding a checksum.

The Sensor Data Simulator is basically the same software as the Presentation Interface Monitor using a special part of the functionality of the software.

A.1.5 DSC Test box

The DSC test box is a standard GMDSS-AIS Test box used for the survey of ship stations.

For the DSC testing of AIS equipment in includes a software extension that provides a remote control input/output facility

- to transmit DSC calls according to ITU 825-3 generated in an external PC on DSC channel 70 and
- to output received DSC calls from the EUT to the external PC.

Federal Maritime and Hydrographic Agency



Special PC software is used to generate the DSC calls and to display, log and evaluate received DSC calls. It communicates via the serial remote control interface to the DSC Test box.

A.1.6 Serial Interface Server

The Serial Interface Server consists on two Serial Interface boxes which provides 16 serial lines each which can be connected in a flexible way to the EUT and to equipment of the test environment like the DSC Test box.

The Serial Interface Server is connected to the controlling PCs via Ethernet Network. It includes:

- One interface box with 16 serial lines according to RS-422 and IEC 61162-1/2
- One interface box with 16 serial lines according to RS-232

A.1.7 Laboratory Network

A special laboratory network connects controlling PCs with equipment of the test environment (VDL Generator/ analyser) and with EUT if equipped with an Ethernet interface.

A.1.8 GPS Re-transmitter


All AIS equipment includes a GPS receiver for the exact timing and for getting position and speed information.

To avoid the need to connect all AIS equipment to GPS antennas outside the laboratory a retransmitting GPS antenna is installed in the lab. It amplifies and radiates a GPS signal in the laboratory which is received by active GPS antenna on the roof.

Federal Maritime and Hydrographic Agency



A.2 Test environment overview



BSH Network for exchange evaluation data

Federal Maritime and Hydrographic Agency



Annex B Test sentences

B.1 IEC 61162 Test Sentences

Many of the test sentences are modified manually during the test according to the requirements of the actual test items.

Mainly the MMSI in all addressed sentences are adapted to the actual MMSI of the EUT or of the unit the EUT communicates with.

In addition the files containing these sentences contain also some control information used by the monitor program like:

<UTC> is replaced by the actual UTC time at time of output

<WAIT EVENT> waiting for user action before next output

<WAIT xxxx> waiting xxx ms before next output

This control information is not shown in the following sentence examples because it is not sent to the EUT.

B.1.1 Messages (ABM, BBM)

The addressed messages include a MMSI number which is changed according to the actual MMSI number of the EUT

Messages (ABM, BBM)						
File name	Description					
Sentences						
AIABM_bin.sst	Standard addressed binary message					
!AIABM,1,1,2,211001028,1,6,07i@E=@,2						
AIABM_safety.sst	Standard addressed safety related message					
!AIABM,1,1,2,211001028,1,12,D5CD,0						
AIABM_4_bin.sst	Set of 4 addressed binary messages					
!AIABM,1,1,3,211001028,1,6,07i@E=B34,2						
!AIABM,1,1,0,211001028,2,6,07i@E=B38,2						
!AIABM,1,1,1,211001028,1,6,07i@E=B3<,2						
!AIABM,1,1,2,211001028,2,6,07i@E=B3@,2						
AIBBM_bin.sst	Standard binary broadcast message					
!AIBBM,1,1,6,1,8,07i@E=@,2						
AIBBM_safety.sst	Standard safety related broadcast message					
!AIBBM,1,1,6,1,14,D5CD,0						

Federal Maritime and Hydrographic Agency



AIABM_BBM_msg25_26.sst

Collecton of addressed and broadcast message 25/26

<WAIT_EVENT>

!AIABM,1,1,0,211001028,1,70,upGd45L22B2J2B2H,0

<WAIT, 10000>

!AIABM,1,1,1,211001028,2,25,upGd45L22B2J2B2H,0

<WAIT,10000>

!AIABM,1,1,2,211001028,1,71,ur3d45L0h`S0,0

<WAIT,10000>

!AIABM,1,1,3,211001028,2,26,ur3d45L0h`S0,0

<WAIT,10000>

!AIBBM,1,1,4,1,70,up?d45L2N`UKPF1>o8?`00,4

<WAIT,5000>

!AIBBM,1,1,5,2,25,up?d45L2N`UKPFl>o8?`00,4

<WAIT,5000>

!AIBBM,1,1,6,1,71,upkd45L1E9PR200JGP,4

<WAIT,5000>

!AIBBM,1,1,7,2,26,upkd45L1E9PR200JGP,4

AIBBM multi bin 3 slot.sst

Long 3 slot binary broadcast message

 $! \verb|AIBBM|, 3, 1, 6, 2, 8, 07i@456789012345678901234567890123456789, 0$

!AIBBM,3,2,6,2,8,0123456789012345678901234567890123456789,0

!AIBBM,3,3,6,2,8,01234567890,2


Federal Maritime and Hydrographic Agency





Annex C Test Diagrams

C.1 10.2.1.5 Receiving in adjacent slots

2016-07-01 - AMEC B600 - Test 10.2.1.5 Receive in adjacent slots








Federal Maritime and Hydrographic Agency




C.2 10.2.1.6 High VDL loading reception test

2016-06-29 - AMEC B600 - Test 10.2.1.6 High VDL load reception




2016-06-29 - AMEC B600 - Test 10.2.1.6 High VDL load reception




Federal Maritime and Hydrographic Agency



C.3 10.2.2.6 Single ITDMA and RATDMA transmissions








Federal Maritime and Hydrographic Agency




C.4 10.5.2.1 Autonomous reporting interval


C.4.1 30s - 5 s interval



















Federal Maritime and Hydrographic Agency








2016-05-20 Ba - AMEC B600 - Test 10.5.2.1 Selection interval at 30 s reporting interval





Federal Maritime and Hydrographic Agency




2016-05-20 Ba - AMEC B600 - Test 10.5.2.1 Selection interval at 15 s reporting interval






















Federal Maritime and Hydrographic Agency




C.4.2 3 min - 30 s interval



























Federal Maritime and Hydrographic Agency







-■- Slots -◆- Channel

2016-05-20 - AMEC B600 - Test 10.5.2.1 Reporting interval 3 min



UTC time


Federal Maritime and Hydrographic Agency




C.5 10.5.2.3 Static data reporting interval

C.5.1 Slot allocation at 30 s interval

2016-11-30 - AMEC B600 - Test 10.5.2.3 Slot allocation of static data reports









Federal Maritime and Hydrographic Agency



C.5.2 Slot allocation at 15 s interval








Federal Maritime and Hydrographic Agency



C.5.3 Slot allocation at 5 s interval

2016-11-30 - AMEC B600 - Test 10.5.2.3 Slot allocation of static data reports

	Frame 1		Frame :	2	Frame	e_3	3		Frame		ļ	Frame	e 5	j
2016-11-30 14:00:00			2016-11-30	14:01:00	2016-11-30 14:02:00		2016-11-30 14:03:00		2016-11-3	30 1	4:04:00			
	Channel A Channel B		Channel A	Channel B	Channel A	П	Channel B		Channel A	\Box	Channel B	Channel A		Channel B




Generated by BSH AISlog Version 3.52

Federal Maritime and Hydrographic Agency



2016-11-30 - AMEC B600 - Test 10.5.2.3 Slot allocation of static data reports

	Frame 6 2016-11-30 14:05:00				Frame 7			Frame 8 2016-11-30 14:07:00				Frame 9 2016-11-30 14:08:00				Frame 10 2016-11-30 14:09:00		0
				2016-11-30 14:06:00														4:09:00
	Channel A		Channel B		Channel A	Channel B		Channel A		Channel B		Channel A	Г	Channel B		Channel A	П	Channel B




Generated by BSH AlSlog Version 3.52

Federal Maritime and Hydrographic Agency




C.5.4 Transmission schedule of Message 24

2016-05-19 - AMEC B600 - Test 10.5.2.3 Static data reporting interval



2016-05-19 - AMEC B600 - Test 10.5.2.3 Static data reporting interval




Federal Maritime and Hydrographic Agency



C.6 12.3 Synchronisation jitter


C.6.1 UTC direct synchronisation

2016-06-16 - AMEC B600 - 12.3 - Sync jitter deviation mode 0



UTC time

2016-06-16 - AMEC B600 - 12.3 - Sync jitter deviation mode 0




Federal Maritime and Hydrographic Agency




C.6.2 UTC indirect synchronisation

2016-06-16 - AMEC B600 - 12.3 Sync jitter deviation vs. time in sync mode 1



2016-06-16 - AMEC B600 - 12.3 Sync jitter deviation vs. time in sync mode 1




Federal Maritime and Hydrographic Agency




C.7 12.6 Slot allocation

C.7.1 12.6.1 Network entry








Federal Maritime and Hydrographic Agency




C.7.2 12.6.2 Autonomous scheduled tx (SOTDMA)



Federal Maritime and Hydrographic Agency



2016-05-26 - Class B SO - AMEC B600 - Test 12.6.1 Network entry, 5s interval




Bundesamt für Seeschifffahrt und Hydrographie Federal Maritime and Hydrographic Agency




C.7.3 12.6.2b Use of free slots at 50% VDL load

2016-05-27 - AMEC B600 - Test 12.6.2b Use of free slots at 50% VDL load.



2016-05-27 - AMEC B600 - Test 12.6.2b Use of free slots at 50% VDL load.




Federal Maritime and Hydrographic Agency




C.7.4 12.6.5 Assigned operation


C.7.4.1 12.6.5.1 Message 16 with slot assignment












Federal Maritime and Hydrographic Agency




C.7.4.2 12.6.5.2 Message 16 with rate assignment

C.7.5 Rate assignment 5 s



Generated by BSH AlSlog Version 3.46







Federal Maritime and Hydrographic Agency




C.7.6 Rate assignment 10 s

















Federal Maritime and Hydrographic Agency



C.7.7 12.6.6 Group assignment


C.7.7.1 12.6.6.1 Entering group assignment




Federal Maritime and Hydrographic Agency




C.7.7.2 12.6.6.6 Reverting from group assignment










Federal Maritime and Hydrographic Agency




C.7.8 12.6.7 Base station reservations

2016-05-30 - AMEC B600 - 12.6.7 Base station reservation, distance < 120 NM




2016-05-30 - AMEC B600 - 12.6.7 Base station reservation, distance < 120 NM






2016-05-30 - AMEC B600 - 12.6.7 Base station reservation, distance > 120 NM



2016-05-30 - AMEC B600 - 12.6.7 Base station reservation, distance > 120 NM




Federal Maritime and Hydrographic Agency




C.8 13.1 Regional area designation by VDL Message

C.8.1 a) Area border transition









Federal Maritime and Hydrographic Agency




C.8.2 c) Tx/Rx mode 1

















Federal Maritime and Hydrographic Agency




C.9 13.5 Slot reuse and FATDMA reservations

2016-09-19 - AMEC B600 - 13.5b Slot reuse




2016-09-19 - AMEC B600 - 13.5b Slot reuse




Federal Maritime and Hydrographic Agency



2016-09-19 - AMEC B600 - 13.5b Slot reuse




2016-09-19 - AMEC B600 - 13.5b Slot reuse




Federal Maritime and Hydrographic Agency



2016-09-19 - AMEC B600 - 13.5c Slot reuse




2016-09-19 - AMEC B600 - 13.5c Slot reuse




Federal Maritime and Hydrographic Agency



2016-08-26 Ba - AMEC B600- 13.5d Slots selection with reservations on channel A.



2016-08-26 Ba - AMEC B600- 13.5d Slots selection with reservations on channel A.




Federal Maritime and Hydrographic Agency




C.10 13.6 Long range broadcast


2017-02-16- Me - AMEC B600 - Test 13.6.1 Reporting interval of message 27





2017-02-16- Me - AMEC B600 - Test 13.6.1 Reporting interval of message 27



















2017-03-09 - AMEC B600 - Test 13.6.1 Use of free slots at 50% VDL load for Message 27





Federal Maritime and Hydrographic Agency




Annex D Photos of equipment under test

D.1 Transponder unit







Bundesamt für Seeschifffahrt und Hydrographie Federal Maritime and Hydrographic Agency





Bundesamt für Seeschifffahrt und Hydrographie Federal Maritime and Hydrographic Agency



D.2 GPS antenna



