

# CDMA M2M Router



## NWL-11 USER GUIDE

#### Copyright

Copyright© 2013 NetComm Wireless Limited. All rights reserved.

The information contained herein is proprietary to NetComm Wireless. No part of this document may be translated, transcribed, reproduced, in any form, or by any means without prior written consent of NetComm Wireless.



**Note:** This document is subject to change without notice.

#### Save our environment

When this equipment has reached the end of its useful life, it must be taken to a recycling centre and processed separately from domestic waste.

The cardboard box, the plastic contained in the packaging, and the parts that make up this device can be recycled in accordance with regionally established regulations. Never dispose of this electronic equipment along with your household waste. You may be subject to penalties or sanctions under the law. Instead, ask for disposal instructions from your municipal government.

Please be responsible and protect our environment.

This manual covers the following products:

NetComm Wireless NWL-11 CDMA M2M Router

DOCUMENT VERSION	DATE
Initial document release	

*Table 1 - Document Revision History*

# Table of contents

Table of contents .....	3
Overview .....	4
Introduction.....	4
Target audience.....	4
Prerequisites .....	4
Notation .....	4
Product introduction .....	5
Product overview .....	5
Package contents .....	5
Product features .....	6
Physical dimensions and indicators .....	7
Physical dimensions .....	7
LED indicators .....	8
Interfaces.....	10
Placement of the router .....	11
Mounting options .....	11
Installation and configuration of the CDMA M2M router.....	18
Powering the router .....	16
Power consumption .....	17
Installing the router .....	18
Advanced configuration.....	20
Status .....	20
Internet .....	22
Data connection.....	22
Dial on Demand.....	27
LAN .....	30
Routing.....	35
VPN.....	43
Services .....	56
Dynamic DNS.....	56
Network time (NTP).....	57
System Monitor.....	<b>Error! Bookmark not defined.</b>
SNMP.....	60
TR-069 .....	62
HTTPS .....	63
SMS Diagnostics and Commands .....	66
Diagnostics.....	72
Sending an SMS diagnostic command .....	75
System .....	82
Log.....	82
System configuration .....	85
Appendix A: Tables.....	94
Appendix B: Device Mounting Dimensions .....	95
Appendix C: Mounting Bracket .....	96
Appendix D: Default Settings .....	97
Restoring factory default settings.....	98
Recovery mode .....	99
Appendix E: HTTPS - Uploading a self-signed certificate .....	100
Appendix F: RJ-45 connector .....	102
Safety and product care .....	103

# Overview

## Introduction




This document provides you all the information you need to set up, configure and use the NetComm Wireless NWL-11 CDMA M2M Router.

## Target audience

This document is intended for system integrators or experienced hardware installers who understand telecommunications terminology and concepts.

## Prerequisites

Before continuing with the installation of your CDMA M2M Router, please confirm that have the following:

-  A device with a working Ethernet network adapter.
-  A web browser such as Internet Explorer, Mozilla Firefox or Google Chrome.
-  A flathead screwdriver (No. 3) if field terminated power is required.

## Notation

The following symbols are used in this user guide:



The following note requires attention.



The following note provides a warning.



The following note provides useful information.

# Product introduction

## Product overview

- Dual-band CDMA (BC0/BC1), 800/1900MHz
- CDMA data speeds up to 3.1 Mbps DL
- Ethernet port with full passive Power over Ethernet (PoE) support (802.3af)
- Internal diversity antennas with option for external main antenna (autosensing)
- Intelligent, Tri-Colour LED display for clear, easy to read modem status information
- Extensive device management with support for TR-069, Web GUI and full feature management with SMS
- Optimized web configuration UI
- Flexible mounting suitable for in-home use or industrial applications with built-in wall mount, DIN and C-Rail mounting options

## Package contents

The NetComm Wireless CDMA M2M Router package consists of:

- 1 x CDMA M2M Router
- 1 x 1.5m yellow Ethernet cable 8P8C
- 1 x DIN rail mounting bracket
- 1 x Quick Start Guide and Safety Manual

If any of these items are missing or damaged, please contact NetComm Wireless Support immediately. The NetComm Wireless Support website can be found at: <http://support.netcommwireless.com>.

## Product features

The NetComm Wireless NWL-11 CDMA M2M Router is an M2M device designed by NetComm Wireless to address the rapid growth in M2M deployments. It has been designed to provide state-of-the-art features and versatility at an affordable price. Compatible with North American CDMA networks, the NWL-11 can be managed remotely even when the router does not have an Internet connection via the use of SMS commands and diagnostics.

The NWL-11 includes many features such as Dial on Demand which provides a means to seamlessly connect or disconnect the mobile broadband connection to conserve usage; TR-069 support for easy management of a group of NWL-11 routers; and the ability to function as an SSH server to secure communications. Additionally, the open management system allows you to expand the feature set by producing your own custom software applications.

The NetComm Wireless CDMA M2M Router meets the North American demand for a reliable and cost-effective M2M device that successfully caters to mass deployment across businesses.

# Physical dimensions and indicators

## Physical dimensions

Below is a list of the physical dimensions of the CDMA M2M Router.




Figure 1 - CDMA M2M Router Dimensions

CDMA M2M ROUTER (WITHOUT EXTERNAL ANTENNA ATTACHED)	
Length	140 mm
Depth	103 mm
Height	30 mm
Weight	180g

Table 2 - Device Dimensions

## LED indicators

The CDMA M2M Router uses 7 LEDs to display the current system and connection status.




Figure 2 - CDMA M2M Router LED Indicators

















LED ICON	NAME	COLOR	STATE	DESCRIPTION
	Power		Off	Power off
			Double flash	Powering up
			On	Power on
			On	Power on in recovery mode
			Slow flashing	Hardware error
	Network		On	Connected via WWAN
			Blinking <sup>1</sup>	Traffic via WWAN
			Slow flashing	Connecting data session
			On	Registered network
			Slow flashing	Registering network
			On	Can't connect
	Signal strength		On	EVDO coverage
			On	CDMA 1x coverage

Table 3 - LED Indicators

<sup>1</sup> The term "blinking" means that the LED may pulse, with the intervals that the LED is on and off not being equal. The term "flashing" means that the LED turns on and off at equal intervals.



## Signal strength LEDs

The following table lists the signal strength range corresponding with the number of lit signal strength LEDs.

NUMBER OF LIT LEDS	SIGNAL STRENGTH
All LEDs unlit	< -109 dBm
1	-109 dBm to -101dBm
2	-101 dBm to -91 dBm
3	-91 dBm to -85 dBm
4	-85 dBm to -77 dBm
5	> -77 dBm

*Table 4 - Signal strength LED descriptions*

## LED update interval

The signal strength LEDs update within a few seconds with a rolling average signal strength reading. When selecting a location for the router or connected or positioning an external antenna, please allow up to 20 seconds for the signal strength LEDs to update before repositioning.

## Interfaces

The following interfaces are available on the CDMA M2M Router:




Figure 3 - Interfaces

ITEM	DESCRIPTION
Main antenna socket	SMA female connector for an optional external antenna (not supplied). The main internal antenna is disabled when an external antenna is connected but the auxiliary antenna remains active to provide (where possible) diversity assistance.
Power LED	Indicates the power status of the device and whether the device is in recovery mode.
Network LED	Indicates the network status.
Signal strength LEDs	Indicates the signal strength and network type.
RJ45 PoE Ethernet port	Connect one or several devices via a network switch here. This port can also optionally receive Power over Ethernet (802.3af PoE) in which case the DC power supply can serve as backup power source if required.
Reset button	Press and hold for less than 5 seconds to reboot to normal mode. Press and hold for 5 to 15 seconds to reboot to recovery mode. Press and hold for 15 to 20 seconds to reset the router to factory default settings.
Two-way captive power	Connect power source here. Power wires may be terminated on optional terminal block and connected to DC input jack. Operates in the 8-35V DC range.

Table 5 - Interfaces

# Placement of the router

When selecting a location to mount the CDMA M2M router, keep in mind that it houses two high performance internal antennas designed to provide optimum signal strength in a wide range of environments. If you find the signal strength is weak, try moving the router to a different place or mounting it differently. If signal strength doesn't improve, you may need to attach an external antenna (not included) to the router's female SMA connector.



Note: If you connect an external antenna to the female SMA connector, the main internal antenna disables automatically but the auxiliary internal antenna remains connected to provide (where possible) diversity assistance.




Note: When selecting a location for the router, allow at least 20 seconds for the signal strength LEDs to update before trying a different location or connecting an external antenna.

## Mounting options

The CDMA M2M router can be quickly and easily mounted in a variety of locations.

### Mounted flat against the wall

When mounted flat against the wall, the CDMA M2M router has a slimline form factor. Use appropriately sized screws in the mounting holes provided on the base of the unit.



*Figure 4 - Wall mount - Flat against the wall*

### Perpendicular to the wall

If a large surface area is not available, there is the option of mounting the router perpendicular to the wall. This gives the router a small wall footprint while remaining securely attached. Use appropriately sized screws in the mounting holes provided on the back of the unit.




Figure 5 - Wall mount - Perpendicular to the wall

### C Section DIN Rail mount

The CDMA M2M router easily slides onto a C Section DIN rail so that it is horizontally mounted. The DIN Rail mounting bracket is not required for C Section DIN rail mounting.




Figure 6 - C Section DIN rail mount

To mount the unit on a C-Section DIN rail, slide it on as illustrated below:




Figure 7 - Mounting the unit on a DIN rail


### Mounting bracket

The provided mounting bracket provides additional methods of mounting the CDMA M2M router. To attach the mounting bracket, slide it onto the rear of the router as shown in the diagram below:



*Figure 8 - Sliding on the mounting bracket*

To remove the bracket, press the **PUSH** button and slide the router off the bracket:



*Figure 9 - Removing the mounting bracket*

### Using the mounting bracket for wall mounting

By first attaching the DIN rail bracket to the wall, the CDMA M2M router can be easily attached and removed from the bracket.




Figure 10 - Wall mount - Mounted via DIN rail bracket

### Using the mounting bracket for Top hat DIN rail mounting

The CDMA M2M router may be vertically mounted to the wall with the bracket by sliding the bracket onto a top hat DIN rail




Figure 11 - Top hat DIN rail mount

Alternatively, you can attach it to the DIN Rail by using the V bend in the bracket as illustrated below:





Figure 12 - Attaching the mounting bracket to the DIN rail using the V bend

## Desk mount

In situations where wall mounts and DIN rails are not required, you can simply place the CDMA M2M router on a desk using its rubber feet to prevent it from slipping.



*Figure 13 - Desk mount*

# Powering the router

The CDMA M2M router can be powered in one of three ways:

1. Power over Ethernet (802.3af PoE)
2. DC power input via 2-pin connector (8-35V DC)
3. DC power input via field terminated power source (8-35V DC)

The green power LED on the router lights up when a power source is connected.

## Power over Ethernet (802.3af PoE)

Power over Ethernet (PoE) is a method of connecting network devices through Ethernet cable where power and data are passed along a single cable. This may be a desirable method of powering the device if PoE is available, or if it's most convenient in the desired installation environment to only have a single cable running to the CDMA M2M router.

There are 5 power classes defined in the IEEE 802.3-2005 standard, of which the CDMA M2M router is a class 3 device.

CLASS	CLASSIFICATION CURRENT	POWER RANGE	CLASS DESCRIPTION
3	26-30 mA	6.49 – 12.95 W	Mid power

*Table 6 - PoE power classes*

To use PoE to power the CDMA M2M router, simply connect your router to a PoE injector or PoE network switch using the bundled yellow Ethernet cable 8P8C.

## DC power via 2-pin connector

The DC input jack can accept power from a separately sold DC power supply. Both a standard temperature range DC power supply and an extended temperature range DC power supply are available to purchase as accessories.

To power the device via DC Power via the 2-pin connector, remove the attached green terminal block from your router and connect the external DC power supply to the router's green DC power jack.

## DC power via field terminated power source

If an existing 8-35V DC power supply is available, you can insert the wires into the supplied terminal block to power your router. Use a No. 3 flathead screwdriver to tighten the terminal block screws and secure the power wires, making sure the polarity of the wires are correctly matched, as illustrated below.



*Figure 14 - Locking Power Terminal Block*

PIN	SIGNAL	DESCRIPTION
+	V+	Voltage +
-	V-	Ground

*Table 7 - Locking power block pin outs*



## Failover power support

The CDMA M2M router includes support for connection of two power sources at the same time. When a PoE Ethernet cable is connected and DC power is also supplied to the DC input jack of the router, the router will source power exclusively from the PoE source. In the event that power from the PoE cable is lost, the router will automatically switch to source power from the DC input jack, without affecting the router's operation. When PoE power is restored, the router automatically switches back to receive power from the PoE input source.

## Viewing power source information

You can view the current power input mode in the **Advanced status** section of the device's web user interface. This is useful for remotely monitoring the device. You can also use the Software Development Kit to access this information for advanced purposes (e.g. configuring SMS alerts to inform you of the power status of the router).

To view the router's power source information, log in to the router and expand the **Advanced status** box on the status page. See the [Status](#) section of this manual for more information on the status page.

## Power consumption

To assist with power consumption planning, the following table summarises average power consumption during the various states of the CDMA M2M router under normal usage conditions. It's important to note that this table serves as an indication only as the power consumed by the device is affected by many variables including signal strength, network type, and network activity.

### Average power consumption figures

STATE	POWER CONSUMPTION
Powered on, idle and connected to packet data	1.2W
Powered on, connected to packet data with average load	2.0W
Powered on, connected to packet data with heavy traffic	4.0W
Peak power draw at maximum 3G module transmission power	5.0W

*Table 8 - Average power consumption figures*

# Installation and activation of the CDMA M2M router

## Installing the router

After you have mounted the router and connected a power source, follow these steps to complete the installation process.

1. Connect equipment that requires network access to the Ethernet port of your router. This may be your computer for advanced configuration purposes, or your end equipment which requires data access via the CDMA M2M router. You can connect one device directly, or several devices using a network switch.  
If you're using PoE as the power source, you need to connect any devices via an available data Ethernet port on your PoE power source (be it a PoE network switch or PoE power injector).
2. Ensure the external power source is switched on and wait 2 minutes for your CDMA M2M router to start up. To check the status of your router, compare the LED indicators on the device with those listed on page 8 of this guide.
3. Open a web browser (e.g. Internet Explorer, Firefox, Safari), type <http://192.168.1.1> into the address bar and press **Enter**. The web-based user interface log in screen is displayed.




Figure 15 – Log in prompt for the web-based user interface

4. Enter the login username and password. If this is the first time you are logging in or you have not previously configured the password for the “root” or “admin” accounts, you can use one of the default account details to log in.

ADMIN MANAGER ACCOUNT		ROOT MANAGER ACCOUNT	
Username:	admin	Username:	root
Password:	admin	Password:	admin

Table 9 - Management account login details



Note: To access all features of the router, you must use the root manager account.

For security reasons, we highly recommend that you change the passwords for the root and admin accounts upon initial installation. You can do so by navigating via the menu to the System and then Administration page.


The Status page is displayed when you log in successfully.

## Activating the router

The CDMA M2M Router requires activation on the network before it can be used. The router is not activated until you perform the activation process.

To perform the activation process:

1. Log in to the router as described above. The Status page is displayed and the router prompts you to activate it by displaying the following pop-up window:



2. Click the **OK** button on the pop-up window. The router displays "Programming In Progress". Wait approximately 2 minutes for the activation process to complete.




Figure 16: Activation - Programming In Progress

3. When the activation process is complete, the router displays "Programming successful!"






Figure 17: Activation - Programming successful


Your router is now activated and ready for use. The CDMA M2M Router comes with preconfigured settings that should suit most customers. For advanced configuration, see the following section.

# Advanced configuration

The CDMA M2M Router comes with preconfigured settings that should suit most customers. For advanced configuration, log in to the web-based user interface of the router as described in the previous section. The following sections detail the advanced configuration options available on the CDMA M2M Router.

## Status

The status page of the web interface provides system related information and is displayed when you log in to the CDMA M2M router management console. The status page shows System information, LAN details, Cellular connection status, Packet data connection status and Advanced status details. You can toggle the sections from view by clicking the  or  buttons to show or hide them. Extra status boxes will appear as additional software features are enabled (e.g. VPN connectivity).



The screenshot shows the 'Status' page of the NetComm Wireless web interface. The page has a dark blue header with the NetComm Wireless logo and navigation tabs: Status, Internet, Services, System, and Help. A user profile 'root' is visible in the top right. The main content area is divided into several expandable sections:

- System Information:**
  - System Up Time:** 07:32:28
  - Router Version:** Board version D, Router Serial Number 163011125100022, Software VX.X.X
  - Phone Module:** Model PVS8, Firmware REVISION 02.893, MDN 9199036207
- LAN:**
  - IP:** 192.168.1.1 / 255.255.255.0
  - MAC Address:** 00:60:64:9F:14:0B
  - Ethernet Port Status:** Up / 100.0 Mbps
- Cellular connection status:**
  - Activation Status:** Activated
  - Roaming Status:** Not Roaming
  - MEID:** 0x00A1000021D00393
  - Coverage:** CDMA 1xEVDO Release A
  - SID / NID:** 48 / 4
  - Frequency:** CH:384 PCS-B Band
  - Signal Strength (dBm):** -81 dBm (Medium)
  - MIP IP Address:** 166.149.197.32
  - Network registration status:** Registered, home network
- WWAN:**
  - Profile Name:** Profile1
  - Status:** Connected
  - IP Type:** mip/sip
  - WWAN IP:** 166.149.197.32
  - DNS server:** 198.224.172.135, 198.224.175.135
  - Connection uptime:** 07:31:06
- Advanced Status:**
  - Mobile Country Code:** 310
  - Mobile Network Code:** 0
  - Power input mode:** DCJack
  - DC input voltage:** 11.88V
  - PN (1x) Index:** 12
  - PN (1x EVDO) Index:** 12
  - Channel (1x):** 384
  - Channel (1x EVDO):** 770
  - Cell ID:** 424
  - Signal Quality (Ec/Io):** Carrier 0: 11, Carrier 1: N/A
  - Received Signal Code Power (RSCP):** N/A

Figure 18 - The Status page

ITEM	DEFINITION
<b>System information</b>	
System up time	The current uptime of the router.
Board version	The hardware version of the router.
Router Serial Number	The serial number of the router.
Software	The software version number running on the router.
Model	The type of phone module and the firmware version of the module.
Firmware	The firmware revision of the phone module.
MDN	The Mobile Directory Number of the router on the network.
<b>LAN</b>	
IP	The IP address and subnet mask of the router.
MAC Address	The MAC address of the router.
Ethernet Port Status	Displays the current status of the Ethernet port and its operating speed.
<b>Cellular connection status</b>	
Activation Status	Displays the activation status of the router on the carrier network.
Coverage	Indicates the type of coverage being received by the router's antennas.
Signal strength (dBm)	The current signal strength measured in dBm
Roaming status	The roaming status of the router.
SID / NID	The System ID and Network ID of the router.
MIP IP Address	The Mobile IP Address.
MEID	The mobile equipment identifier (MEID) of the router, a unique code for identifying devices on a CDMA network.
Frequency	The channel that the router is using on the mobile network.
Network registration status	The status of the router's registration for the current network.
<b>Packet data connection status</b>	
Profile name	The name of the active profile.
Status	The connection status of the active profile.
IP Type	The type of IP in use. SIP is a Simple IP connection and when moving between cell sectors, the PPP session is torn down. MIP is a Mobile IP connection which creates an address which is persistent between across cell sectors allowing the mobile connection to remain connected even when moving between cell sectors.
WWAN IP	The IP address assigned by the mobile broadband carrier network.
DNS server	The primary and secondary DNS servers for the WWAN connection.
Connection uptime	The length of time of the current mobile connection session.
<b>Advanced status</b>	
Mobile Country Code	The Mobile Country Code (MCC) of the router.
Mobile Network Code	The Mobile Network Code (MNC) of the router.
Power input mode	Displays whether power is currently being sourced from the PoE Ethernet port or from the DC input jack.
DC input voltage	Displays the current voltage of the power input source provided via the DC Input jack
PN (1x) Index	The pseudo-random number index used in encrypting the mobile connection for RTT connections.
PN (1x EVDO) Index	The pseudo-random number index used in encrypting the mobile connection for EVDO connections.
Channel (1x)	The 1x (RTT) channel number in use.
Channel (1x EVDO)	The 1x (EVDO) channel number in use.
Cell ID	A unique code that identifies the base station from within the location area of the current mobile network signal.
Signal quality (Ec/Io)	A measurement of the portion of the received signal that is usable. This is the signal strength minus the signal noise level.
Received signal code power (RSCP)	The power level of the signal on the current connection's particular channel.


Table 10 - Status page item details

# Internet

The Internet section provides configuration options for Wireless WAN, LAN, Routing and VPN connectivity.

## Data connection

The data connection page allows you to configure and enable/disable the connection profile.



**NetCommWireless** | Status | Internet | Services | System | Help

root

**WWAN (3G)**

- Data Connection
- Dial on Demand
- Band Settings

**LAN**

**Routing**

**VPN**

### WWAN (3G) Profile Settings

Activation Status: Activated

MEID: 0x00A1000021D00393

Profile:  ON  OFF

Phone number:

User:

Password:

Authentication Type:  CHAP  PAP

Reconnect Delay:  (30-65535) secs

Reconnect Retries:  (0-65535, 0=Unlimited)

Metric:  (0-65535)

MTU:  (1-1500)

NAT Masquerading:  ON  OFF

IP Type:

#### Profile routing settings

You may route only particular traffic via this connection profile by specifying the network address and mask below of the destination network. Blank values will route all traffic via this profile. Please leave these settings blank if you are unsure.

Network Address:

Network Mask:

Figure 19 - Data connection settings

ITEM	DEFINITION
<b>WWAN (3G) Profile Settings</b>	
Activation Status	Shows whether the router has been activated on the network.
MEID	The mobile equipment identifier (MEID) of the router, a unique code for identifying devices on a CDMA network.
Profile	Toggles the WWAN connection on and off.
Phone number	
User	The CDMA username provided for the router by your carrier.
Password	The CDMA password provided for the router by your carrier.
Authentication Type	The protocol used for authenticating the user on the network.
Reconnect Delay	The time to wait between connection attempts when a connection has been dropped or connection failed.
Reconnect Retries	The number of times to retry to establish a connection when a connection has been dropped or connection failed.
Metric	The metric value is used by the router to prioritise routes. The lower the value, the higher the priority. To give the route the highest priority, set it to 0.
MTU	The maximum transmission uni (MTU) size. The default value is 1460. You should not change this value unless instructed to by your network provider.
NAT Masquerading	NAT masquerading, also known simply as NAT is a common routing feature which allows multiple LAN devices to appear as a single WAN IP via network address translation. In this mode, the router modifies network traffic sent and received to inform remote computers on the internet that packets originating from a machine behind the router actually originated from the WAN IP address of the router's internal NAT IP address.
IP Type	The type of IP in use. SIP is a Simple IP connection and when moving between cell sectors, the PPP session is torn down. MIP is a Mobile IP connection which creates an address which is persistent between across cell sectors allowing the mobile connection to remain connected even when moving between cell sectors.
<b>Profile routing settings</b>	
Network Address	The network address of the remote network. Entering the remote network address enables the router to route traffic to that network via this particular connection profile.
Network Mask	The network mask of the remote network.

Table 11 - Data connection item details

If your device has not yet been activated on the carrier network, the activation status and MEID are displayed.




Figure 20 - Device not activated

Refer to the [Activating the router](#) section to activate your router on the network.


Connecting to the mobile broadband network



## Manually configuring a connection profile

To manually configure a connection profile:

1. Click the **Profile** toggle key to turn the profile **ON**. Additional settings appear.



**WWAN (3G) Profile Settings**

Activation Status: Activated

MEID: 0x00A1000021D00393

Profile:  ON  OFF

Phone number:

User:

Password:

Authentication Type:  CHAP  PAP

Reconnect Delay:   
(30-65535) secs

Reconnect Retries:   
(0-65535, 0=Unlimited)

Metric:   
(0-65535)

MTU:   
(1-1500)

NAT Masquerading:  ON  OFF

IP Type:

**Profile routing settings**

You may route only particular traffic via this connection profile by specifying the network address and mask below of the destination network. Blank values will route all traffic via this profile. Please leave these settings blank if you are unsure.

Network Address:

Network Mask:

Figure 21 - Data connection settings - Profile turned on

2. In the **Phone number** field, enter the phone number assigned to the device.
3. In the **User** and **Password** fields, enter the username and passwords assigned to your account by the carrier.
4. Next to **Authentication** type, select CHAP or PAP depending on the type of authentication used by your provider.
5. The **Reconnect delay** field specifies the number of seconds to wait between connection attempts. The default setting of 30 seconds is sufficient in most cases but you may modify it to wait up to 65535 seconds if you wish.
6. The **Reconnect retries** field specifies the number of times to attempt to connect to the network if the router fails to establish a connection. It is set to 0 by default which causes the router to attempt to reconnect indefinitely.
7. The **Metric** value is used by router to prioritise routes (if multiple are available) and is set to 20 by default. This value is sufficient in most cases but you may modify it if you are aware of the effect your changes will have on the service.
8. The **MTU** field specifies the maximum transmission unit which is the largest packet or frame that can be sent in a packet or frame-based network such as the internet. The default value is 1460. This value should only be modified under instruction from your carrier.

9. Use the **NAT Masquerading** toggle key to turn NAT Masquerading on or off. NAT masquerading, also known simply as NAT is a common routing feature which allows multiple LAN devices to appear as a single WAN IP via network address translation. In this mode, the router modifies network traffic sent and received to inform remote computers on the internet that packets originating from a machine behind the router actually originated from the WAN IP address of the router's internal NAT IP address. This may be disabled if a framed route configuration is required and local devices require WAN IP addresses.
10. Use the **IP Type** drop down list to select the type of IP that you want the router to create. **SIP Only** creates a Simple IP via Point-to-Point Protocol and if the router moves between cell sectors, the packet data link is lost. **MIP Only** establishes a Mobile IP connection using an address which is persistent across cell sectors, allowing the router to move between sectors without losing the packet data link. **MIP Preferred** sets the router to use a Mobile IP where possible, but allowing a Simple IP connection if MIP is not available.
11. For advanced networking such as using dual simultaneous PDP contexts, you may wish to configure a particular profile to route only certain traffic via that profile by configuring a custom address and mask of traffic to send via that profile. To do this, in the Profile routing settings section, enter the **Network address** and **Network mask** of the remote network. If you do not want to use this feature, or are unsure, please leave these fields blank, which will not designate any particular traffic to be routed via this profile. For more information on configuring Profile routing settings, see the [Setting a default gateway with two active connection profiles](#) example.
12. Click the **Save** button when you have finished entering the profile details.

### Confirming a successful connection

After configuring the packet data session, and ensuring that it is enabled, click on the Status menu item at the top of the page to return to the Status page. When there is a mobile broadband connection, the **WWAN** section is expanded showing the details of the connection and the Status field displays **Connected**. To see details on the connected session, you can click the **Show data usage** button.




Figure 22 - Packet data connection status section

## Dial on Demand

The dial on demand feature keeps the Packet Data Protocol (PDP) context deactivated by default while making it appear to locally connected devices that the router has a permanent connection to the mobile broadband network. When a packet of interest arrives or an SMS wake-up command is received, the router attempts to establish a mobile broadband data connection. When the data connection is established, the router monitors traffic and terminates the link when it is idle.



Note: When interesting packets arrive, the recovery time for the wireless WAN connection is approximately 20-30 seconds.

### Configuring Dial on Demand

To configure Connect on demand:

1. Click the **Internet** menu item from the top menu bar.
2. On the **Dial on Demand** page, click the **Dial on Demand** toggle key so that it is **ON**.




Figure 23 - Connect on demand configuration options

3. If you have more than one active connection profile, use the **Select profile** drop down list to select the profile for which you want to configure the Connect on demand feature.

### Setting the router to dial a connection when traffic is detected on specific ports

In some situations, you may wish to have the internet connection disabled except at times when outbound traffic to a particular external host's port or range of ports is sent to the router. To use this feature, click **Enable dial port filter** and enter the port number or list of port numbers separated by commas. When you select this option, all outbound ICMP/TCP/UDP packets to any remote host on the specified port(s) will trigger the connection to dial. Note that when this feature is enabled, the options to ignore specific packet types are not available.



Figure 24 - Dial on demand - Data activity triggered connection

You can allow Microsoft network awareness (NCSI) traffic through but if you prefer that they do not trigger the connection, click the **Ignore Microsoft network awareness (NCSI) traffic** toggle key to set it to **ON**.




Figure 25 - Dial on demand - Ignore NCSI traffic

## Excluding certain packet types from triggering the connection to dial

Depending on your environment, you might prefer to exclude certain types of traffic passing through the router from triggering the data connection. You can tell the router to ignore outbound TCP, UDP or ICMP packets. When any of these options are checked the router will not dial a connection when that type of outbound destined data packet reaches the router from a locally connected device.

WWAN connection except the following types of IP protocol

Ignore ICMP  ON  OFF

Ignore TCP  ON  OFF

Ignore UDP  ON  OFF

Figure 26 - Dial on demand - Excluding IP protocols

## Excluding certain application types from triggering the connection to dial

Some devices may generate general traffic as a part of normal operation which you may not want to trigger the data connection. You can set the router to ignore Domain Name System (DNS), Network Time Protocol (NTP) or Microsoft network awareness (NCSI) traffic from devices behind the router. When you check the box for these options, it tells the router to ignore the request from that application type and will not dial a connection when this data type is received.

WWAN connection except the following applications

Ignore DNS  ON  OFF

Ignore NTP  ON  OFF

Ignore Microsoft network awareness (NCSI) traffic  ON  OFF

Figure 27 - Dial on demand - Excluding application types

## Setting timers for dial-up and disconnection

The router has a number of timer settings which let you determine when a connection is dialled and when it is disconnected.

Dial-up / Hang-up Timers	Periodic Dial Schedule
Keep online for this period of time after a triggered dial	20 minutes
Do not attempt to hang up for this period of time after dial	20 minutes
Do not attempt to dial for this period of time after hang-up	Immediate
Force to hang up after this period of time regardless of traffic	never
Dial every this period of time	never
Randomize dial starting time	30 minutes

Figure 28 - Dial on demand - Connect and disconnect timers

OPTION	DESCRIPTION
Keep online for this period of time after a triggered dial	When traffic as per the configured settings above appear, the router will either continue to stay online, or dial a connection and will not disconnect it for the specified time period (min. 1 minute, max. 1 hour). This timer is continuously reset throughout the duration of a dial-up session, whenever data activity is detected matching the rules above.
Do not attempt to hang up for this period of time after dial	This timer configures the router to not hang-up the connection for the specified time period after initially dialling the connection. This setting cannot be less than the keep online period above. This timer affects the connection only once per dial up session, at the beginning of the session.
Do not attempt to dial for this period of time after hang-up	After a connection has been disconnected, you can tell the router to rest for a period of time before re-dialling.
Force to hang up after this period of time regardless of traffic	Forces the router to disconnect the connection regardless of the traffic passing through it. The default setting is <i>never</i> .
Dial every this period of time / Randomize dial starting time	<p>If you want to have the router dial a connection at regular intervals, use <b>Connect regularly, every</b> to specify the interval between dials. Setting this to <i>never</i> effectively disables this option.</p> <p>The router also features the ability to randomise the time at which the first dial action is performed. This is useful in situations such as where you have numerous routers in an area where a power outage has occurred. Setting a random dial time helps to reduce network congestion when all the routers are powered on so they do not all try to connect simultaneously.</p> <p>When it is set to at least 2 minutes, you are able to configure the router to randomize the time it begins to dial. The randomized dial timer only affects the initial dial after the unit powers on or after the settings are saved. For example, if you configure the router to dial every 2 minutes with a randomized dial time of 1 minute, the router will dial the initial connection at a time greater than 2 minutes, but less than 3 minutes. After the first dial, the router will dial the connection exactly every 2 minutes.</p>

Table 12 - Connect on demand - Connect and disconnect timers descriptions

## Verbose mode

The router provides the option of logging all the data activity which matches the settings for the Dial on demand feature for advanced troubleshooting purposes. To enable the logging of the Dial on demand feature, click the **Enable verbose mode** toggle key to switch it **ON**. See the System log section for more information.




Figure 29 - Dial on demand - Verbose logging configuration

## Manually connecting/disconnecting

There may be times when you need to either force a connection to be made or force a disconnection manually. You can use the **Dial** and **Hangup** buttons to do this whenever necessary. The online status of the connection is displayed above the buttons.





Figure 30 - Dial on demand - Online/Offline control

When you have finished configuring the options for the Dial on demand feature, click the **Save** button at the bottom to save your changes.

## Band Settings

The band settings page lets you configure the roaming preference and mode of the radio.



## LAN

### LAN configuration

The LAN configuration page is used to configure the LAN settings of the router and to enable or disable DNS Masquerading.



Figure 31 - LAN configuration settings

The default IP of the Ethernet port is 192.168.1.1 with subnet mask 255.255.255.0. To change the IP address or Subnet mask, enter the new IP Address and/or Subnet mask and click the **Save** button.



Note: If you change the IP address, remember to reboot the router and enter the new IP address into your browser address bar.

#### Local DNS Server (DNS masq)

DNS masquerading allows the router to proxy DNS requests from LAN clients to dynamically assigned DNS servers. When enabled, clients on the router's LAN can then use the router as a DNS server without needing to know the dynamically assigned cellular network DNS servers.

With DNS masquerading **ON**, the DHCP server embedded in the CDMA M2M router hands out its own IP address (e.g. 192.168.1.1) as the DNS server address to LAN clients. The downstream clients then send DNS requests to the CDMA M2M router which proxies them to the upstream DNS servers.

With DNS masquerading **OFF**, the DHCP server hands out the upstream DNS server IP addresses to downstream clients directly, so that downstream clients send DNS requests directly to the upstream DNS servers without being proxied by the CDMA M2M router.

You may also override the DNS Masquerading option by specifying custom DNS Server IP addresses in the DHCP Server configuration mentioned in the next section of this guide. In this case the DHCP server assigns downstream devices the manually configured addresses and the DNS Masquerading option is ignored.

In most cases, it is not necessary to disable DNS masquerading but if you need to, click the **Local DNS Server (DNS masq)** toggle key to turn it **OFF** and then click the **Save** button.

## Automatic IP address assignment (DHCP)

The DHCP page is used to adjust the settings used by the router's built in DHCP Server which assigns IP addresses to locally connected devices.

### DHCP relay configuration

In advanced networks configurations where the CDMA M2M router should not be responsible for DHCP assignment, but instead an existing DHCP server is located on the Wireless WAN connection, the clients behind the CDMA M2M router are able to communicate with the DHCP server when DHCP relay is enabled. This enables the CDMA M2M router to accept client broadcast messages and to forward them onto another subnet.

To configure the router to act as a DHCP relay agent click the **DHCP Relay** toggle key to turn it **ON** and enter the DHCP server address into the **DHCP Server Address** field. DHCP relay is disabled by default.



**DHCP Relay Configuration**

DHCP Relay  ON  OFF


DHCP Server Address  .  .  .

Save

Figure 32 - DHCP relay configuration

### DHCP configuration

You can manually set the start and end address range to be used to automatically assign addresses within, the lease time of the assigned address, the default domain name suffix, primary and secondary DNS server, the primary and secondary WINS server, as well as the advanced DHCP settings such as NTP, TFTP and Option 150/Option 160 (VoIP options).



**DHCP Configuration**

DHCP  ON  OFF

DHCP Start Range  192  168  1  100

DHCP End Range  192  168  1  199

DHCP Lease Time(seconds)  86400

Default Domain Name Suffix

DNS Server 1 IP Address  .  .  .

DNS Server 2 IP Address  .  .  .

WINS Server 1 IP Address  .  .  .

WINS Server 2 IP Address  .  .  .

NTP Server (Option 42)  .  .  .

TFTP Server (Option 66)

Option 150

Option 160

Save

Figure 33 - DHCP configuration




OPTION	DESCRIPTION
DHCP Start Range	Sets the first IP address of the DHCP range
DHCP End Range	Sets the last IP address of the DHCP range
DHCP Lease Time (seconds)	The length of time in seconds that DHCP allocated IP addresses are valid
Default Domain Name Suffix	Specifies the default domain name suffix for the DHCP clients. A domain name suffix enables users to access a local server, for example, server1, without typing the full domain name server1.domain.com
DNS Server 1 IP Address	Specifies the primary DNS (Domain Name System) server's IP address.
DNS Server 2 IP Address	Specifies the secondary DNS (Domain Name System) server's IP address.
WINS Server 1 IP Address	Specifies the primary WINS (Windows Internet Name Service) server IP address
WINS Server 2 IP Address	Specifies the secondary WINS (Windows Internet Name Service) server IP address
NTP Server (Option 42)	Specifies the IP address of the NTP (Network Time Protocol) server
TFTP Server (Option 66)	Specifies the TFTP (Trivial File Transfer Protocol) server
DHCP Option 150	This is used to configure Cisco IP phones. When a Cisco IP phone starts, if it is not pre-configured with the IP address and TFTP address, it sends a request to the DHCP server to obtain this information. Specify the string which will be sent as a reply to the option 150 request.
DHCP Option 160	This is used to configure Polycom IP phones. When a Polycom IP phone starts, if it is not pre-configured with the IP address and TFTP address, it sends a request to the DHCP server to obtain this information. Specify the string which will be sent as a reply to the option 160 request.

Enter the desired DHCP options and click the **Save** button.

#### Address reservation list

DHCP clients are dynamically assigned an IP address as they connect, but you can reserve an address for a particular device using the address reservation list.



**Address Reservation List** + Add

Computer Name	MAC Address	IP Address	Enable
<input type="text"/>	<input type="text"/>	0 . 0 . 0 . 0	<input checked="" type="checkbox"/> ON <input type="checkbox"/> OFF <span style="float: right;">x</span>

**Save**

Figure 34 - DHCP - Address reservation list

To add a device to the address reservation list:

1. Click the **+Add** button.
2. In the **Computer Name** field enter a name for the device.
3. In the **MAC Address** field, enter the device's MAC address.
4. In the **IP Address** fields, enter the IP address that you wish to reserve for the device.
5. If the **Enable** toggle key is not set to **ON**, click it to switch it to the **ON** position.
6. Click the **Save** button to save the settings.

### Dynamic DHCP client list

The Dynamic DHCP client list displays a list of the DHCP clients. If you want to reserve the current IP address for future use, click the **Clone** button and the details will be copied to the address reservation list fields. Remember to click the **Save** button under the **Address reservation list** section to confirm the configuration.

Dynamic DHCP Client List			
Computer Name	MAC Address	IP Address	Expiry Time
computer	00:40:f4:ce:fa:1e	192.168.1.141	Friday, 29 March 2013 9:47:15 AM




Figure 35 - Dynamic DHCP client list

# Routing

## Static

Static routing is the alternative to dynamic routing used in more complex network scenarios and is used to facilitate communication between devices on different networks. Static routing involves configuring the routers in your network with all the information necessary to allow the packets to be forwarded to the correct destination. If you change the IP address of one of the devices in the static route, the route will be broken.

### Static Routing List

+ Add

Route Name	Destination IP Address	Subnet Mask	Gateway IP Address	Network Interface	Metric		
My Route	192.168.20.0	255.255.255.0	192.168.1.101	br0	0	<span style="border: 1px solid #ccc; padding: 2px 5px;">✎ Edit</span>	<span style="border: 1px solid #ccc; padding: 2px 5px;">✕</span>

### Active Routing List

Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	br0
192.168.20.0	192.168.1.101	255.255.255.0	UG	0	0	0	br0

Figure 36 - Static routing list

Some routes are added by default by the router on initialization such as the Ethernet subnet route for routing to a device on the Ethernet subnet.

### Adding Static Routes

To add a new route to the static routing list, click the **+Add** button. The Static routes page appears.

1. In the **Route name** field, type a name for the route so that it can be identified in the static routing list.
2. From the **Network interface** drop down list, select the interface for which you would like to create a static route.
3. In the **Destination IP address** field, enter the IP address of the destination of the route.
4. In the **IP subnet mask** field, enter the subnet mask of the route.
5. In the **Gateway IP address** field, enter the IP address of the gateway that will facilitate the route.
6. In the **Metric** field enter the metric for the route. The metric value is used by the router to prioritise routes. The lower the value, the higher the priority. To give the route the highest priority, set it to 0.
7. Click the **Save** button to save your settings.

### Static Routes

Route Name

Network Interface

Destination IP Address

IP Subnet Mask

Gateway IP Address

Metric  (0-65535)

Figure 37 - Adding a static route

#### Active routing list


Static routes are displayed in the Active routing list.

### Active Routing List

Destination	Gateway	Netmask	Flags	Metric	Ref	Use	Interface
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	br0
192.168.20.0	192.168.1.101	255.255.255.0	UG	0	0	0	br0

Figure 38 - Active routing list

#### Deleting static routes

From the static routing list,  click the icon to the right of the entry you wish to delete.

### Static Routing List

Route Name	Destination IP Address	Subnet Mask	Gateway IP Address	Network Interface	Metric	
My Route	192.168.20.0	255.255.255.0	192.168.1.101	br0	0	<input type="button" value="Edit"/> <input type="button" value="X"/>


Figure 39 - Deleting a static route

## RIP

RIP (Routing Information Protocol) is used for advertising routes to other routers. Thus all the routes in the router's routing table will be advertised to other nearby routers. For example, the route for the router's Ethernet subnet could be advertised to a router on the PPP interface side so that a router on this network will know how to route to a device on the router's Ethernet subnet. Static routes must be added manually according to your requirements. See [Adding Static Routes](#).



Note: Some routers will ignore RIP.



The screenshot shows the 'RIP Configuration' interface. It features a toggle switch for 'RIP' currently set to 'ON', and a dropdown menu for 'Version' set to '1'. A blue 'Save' button is located at the bottom of the configuration area.

*Figure 40 - RIP configuration*

To enable Routing Information Protocol (RIP)

1. Click the **RIP** toggle key to switch it to the **ON** position.
2. Using the **Version** drop down list, select the version of RIP that you would like to use.
3. Click the **Save** button to confirm your settings.

## Redundancy (VRRP)

Virtual Router Redundancy Protocol (VRRP) is a non-proprietary redundancy protocol designed to increase the availability of the default gateway servicing hosts on the same subnet. This increased reliability is achieved by advertising a “virtual router” (an abstract representation of master and backup routers acting as a group) as a default gateway to the host(s) instead of one physical router. Two or more physical routers are then configured to stand for the virtual router, with only one doing the actual routing at any given time. If the current physical router that is routing the data on behalf of the virtual router fails, an arrangement is made for another physical router to automatically replace it. The physical router that is currently forwarding data on behalf of the virtual router is called the master router.

Master routers have a priority of 255 and backup router(s) can have a priority between 1 and 254.

A virtual router must use 00-00-5E-00-01-XX as its (MAC) address. The last byte of the address (XX) is the Virtual Router Identifier (VRID), which is different for each virtual router in the network. This address is used by only one physical router at a time, and is the only way that other physical routers can identify the master router within a virtual router.



Figure 41 - VRRP configuration

To configure VRRP, configure multiple devices as follows and connect them all via an Ethernet network switch to downstream devices.

1. Click the **Redundancy (VRRP)** toggle key to activate VRRP.
2. In the **Virtual ID** field, enter an ID between 1 and 255. This is the VRRP ID which is different for each virtual router on the network.
3. In the **Router Priority** field, enter a value for the priority – a higher value is a higher priority.
4. The **Virtual IP Address** field is used to specify the VRRP IP address – this is the virtual IP address that both virtual routers share.
5. Click the **Save** button to save the new settings.



Note: Configuring VRRP changes the MAC address of the Ethernet port and therefore if you want to resume with the web configuration you must use the new IP address (VRRP IP) or on a command prompt type:  
`arp -d <ip address>` (i.e. `arp -d 192.168.1.1`) to clear the arp cache.(old MAC address).

## NAT

The Port forwarding list is used to configure the Network Address Translation (NAT) rules currently in effect on the router.

Port Forwarding List					+ Add
Protocol	Source IP Address	Incoming Port	Destination IP Address	Destination Port	
ALL	192.168.1.1	3389 - 3389	192.168.1.150	3389 - 3389	<input type="button" value="Edit"/> <input type="button" value="x"/>

Figure 42 - Port forwarding list

The purpose of the port forwarding feature is to allow mapping of inbound requests to a specific port on the WAN IP address to a device connected on the Ethernet interface.

### Adding a port forwarding rule

To create a new port forwarding rule:

1. Click the **+Add** button. The port forwarding settings screen is displayed.
2. Use the **Protocol** drop down list to select the type of protocol you want to use for the rule. The protocols selections available are **TCP**, **UDP** and **All**.
3. In the **Source IP Address** field, enter a “friendly” address that is allowed to access the router or a wildcard IP address (0.0.0.0) that allows all IP addresses to access the router.
4. The **Source Port Range (From)** and **(To)** fields are used to specify the port(s) on the source side that are to be forwarded. This allows you to send a range of consecutive port numbers by entering the first in the range in the **(From)** field and the last in the range in the **(To)** field. To forward a single port, enter the port in the **(From)** field and repeat it in the **(To)** field.
5. In the **Destination IP Address** field, enter the IP address of the client to which the traffic should be forwarded.
6. The **Destination Port Range (From)** and **(To)** fields are used to specify the port(s) on the destination side that are to be forwarded. If the Source port range specifies a single port then the destination port may be configured to any port. If the Source port range specifies a range of port numbers then the Destination port range must be the same as the Source port range.
7. Click the **Save** button to confirm your settings.

### Port Forwarding Settings

Protocol:

Source IP Address:

Source Port Range (From):  ( 1-65535 ) (To):  ( 1-65535 )

Destination IP Address:

Destination Port Range (From):  ( 1-65535 ) (To):  ( 1-65535 )

Figure 43 - Port forwarding settings

To delete a port forwarding rule, click the  button on the Port forwarding list for the corresponding rule that you would like to delete.

## DMZ

The Demilitarized Zone (DMZ) allows you to configure all incoming traffic on all protocols to be forwarded to a selected device behind the router. This feature can be used to avoid complex port forwarding rules, but it exposes the device to untrusted networks as there is no filtering of what traffic is allowed and what is denied.

The DMZ configuration page is used to specify the IP Address of the device to use as the DMZ host.




The screenshot shows the 'DMZ Configuration' page. At the top, there is a title 'DMZ Configuration'. Below it, there is a toggle switch for 'DMZ' which is currently set to 'ON'. Underneath, there is a field for 'DMZ IP Address' with four input boxes, each containing the digit '0'. At the bottom of the form, there is a blue 'Save' button.

Figure 44 - DMZ configuration

1. Click the DMZ toggle key to turn the DMZ function **ON**.
2. Enter the IP Address of the device to be the DMZ host into the **DMZ IP Address** field.
3. Click the **Save** button to save your settings.

## MAC / IP / Port filtering

The MAC/IP/Port filter feature allows you apply a policy to the traffic that passes through the router, both inbound and outbound, so that network access can be controlled. When the filter is enabled with a default rule of "Accepted", all connections will be allowed except those listed in the "Current MAC / IP / Port filtering rules in effect" list. Conversely, when the default rule is set to "Dropped", all connections are denied except for those listed in the filtering rules list.



The screenshot shows the 'MAC / IP / Port Filtering' page. At the top, there is a title 'MAC / IP / Port Filtering'. Below it, there is a toggle switch for 'MAC / IP / Port Filtering' which is currently set to 'ON'. Underneath, there is a dropdown menu for 'Default Rule (inbound/forward)' which is currently set to 'Accepted'. At the bottom of the form, there are two buttons: a blue 'Save' button and a grey 'Reset' button.

Figure 45 - MAC / IP / Port filtering



Note: When enabling MAC / IP / Port filtering and setting the default rule to "Dropped", you should ensure that you have first added a filtering rule which allows at least one known MAC/IP to access the router, otherwise you will not be able to access the user interface of the router without resetting the router to factory default settings.

## Creating a MAC / IP / Port filtering rule

To create a filtering rule:

1. Click the **MAC / IP / Port filtering** toggle key to switch it to the **ON** position.
2. Using the **Default Rule (inbound/forward)** drop down list, select the default action for the router to take when traffic reaches it. By default, this is configured to **Accepted**. If you change this to **Dropped**, you should first configure a filter rule that allows at least one device access to the router, otherwise you will effectively be locked out of the router.
3. Click the **Save** button to confirm the default rule.
4. In the Current MAC / IP / Port filtering rules in effect section, click the **+Add** button.



**Current MAC/IP/Port filtering rules in system**

Up   Down   + Add

No	Bound	Action	Comment
1	Forward	Drop	Demonstration rule

Edit   X

Figure 46 - Current MAC / IP / Port filtering rules in effect

- Enter the details of the rule in the section that is displayed and click the **Save** button.

**MAC / IP / Port Filtering**

**MAC / IP / Port Filter Settings**

Bound: Forward

Protocol: TCP

Source MAC Address: 00:40:F4:CE:FA:1E

Source IP Address: 192 . 168 . 1 . 1 / 24

Source Port Range (From): 5000 (1-65535) (To): 5000 (1-65535)

Destination IP Address: 192 . 168 . 1 . 150 / 24

Destination Port Range (From): 5000 (1-65535) (To): 5000 (1-65535)

Action: Drop



Comment: Demonstration rule

Save   Cancel

Figure 47 - MAC / IP / Port filtering settings

OPTION	DESCRIPTION
Bound	Use the drop down list to select the direction of the traffic for which you want to apply to the rule. <b>Inbound</b> refers to all traffic that is entering the router including data entering from the WAN and the LAN. <b>Outbound</b> refers to all traffic exiting the router including traffic leaving in the direction of the WAN and traffic leaving in the direction of the LAN. <b>Forward</b> specifies traffic that enters on the LAN or WAN side and is forwarded to the opposite end.
Protocol	Use the drop down list to select the protocol for the rule. You can have the rule apply to <b>All</b> protocols, <b>TCP</b> , <b>UDP</b> , <b>UDP/TCP</b> or <b>ICMP</b> .
MAC Address	Enter the MAC address in six groups of two hexadecimal digits separated by colons (:). e.g. 00:40:F4:CE:FA:1E
Source IP Address	Enter the IPv4 address that the traffic originates from and the subnet mask using CIDR notation.
Source Port Range (From) – (To)	Only appears for TCP, UDP and UDP/TCP options. Use these fields to specify a port or range of ports from the source side to use for the rule. To specify a single port, repeat it in both the <b>(From)</b> and <b>(To)</b> fields.
Destination IP Address	Enter the IPv4 address that the traffic is destined for and the subnet mask using CIDR notation.
Destination Port Range (From) – (To)	Only appears for TCP, UDP and UDP/TCP options. Use these fields to specify a port or range of ports on the destination side to use for the rule. To specify a single port, repeat it in both the <b>(From)</b> and <b>(To)</b> fields.
Action	Select the action to take for traffic which meets the above criteria. You can choose to <b>Accept</b> or <b>Drop</b> packets. When the default rule is set to <b>Accept</b> , you cannot create a rule with an <b>Accept</b> action since the rule is redundant. Likewise, if the default rule is set to <b>Dropped</b> you cannot create a rule with a <b>Drop</b> action.
Comment	[Optional] Use this field to enter a comment as a meaningful description of the rule.

Table 13 - Current MAC / IP / Port filtering rules in effect

6. The new rule is displayed in the filtering rules list. You can edit the rule by clicking the  **Edit** button or delete the rule by clicking the  button.






Figure 48 - Completed filtering rule

## VPN

A Virtual Private Network (VPN) is a tunnel providing a private link between two networks or devices over a public network. Data to be sent via a VPN needs to be encapsulated and as such is generally not visible to the public network.

The advantages of a VPN connection include:

-  Data Protection
-  Access Control
-  Data Origin Authentication
-  Data Integrity

Each VPN connection has different configuration requirements. The following pages detail the configuration options available for the different VPN connection types.



Note: The following descriptions are an overview of the various VPN options available. More detailed instructions are available in separate whitepapers on the NetComm Wireless website.

## IPSec

IPSec operates on Layer 3 of the OSI model and as such can protect higher layered protocols. IPSec is used for both site to site VPN and Remote Access VPN. The CDMA M2M router supports IPSec end points and can be configured with Site to Site VPN tunnels with third party VPN routers.

### Configuring an IPSec VPN

From the menu at the top of the screen, click **Networking** and under the VPN section, click **IPSec**. A list of configured IPSec VPN connections is displayed.




Figure 49 - IPSec VPN List

Click the **+Add** button to begin configuring an IPSec VPN connection.

### IPSec Profile Edit

IPSec Profile  ON  OFF

Profile Name

Remote IPSec Server Address

Remote LAN Address

Remote LAN Subnet Mask

Local LAN Address

Local LAN Subnet Mask

Encapsulation Type

IKE Mode

PFS

IKE Encryption

IKE Hash

IPSec Encryption

IPSec Hash

DH Group

DPD Action

DPD Keep Alive Time   
secs

DPD Timeout   
secs

IKE Rekey Time   
(0-78400, 0=Unlimited) secs

SA Life Time   
(0-78400, 0=Unlimited) secs

Key Mode

Pre-shared Key

Remote ID   
(xy.sample.com or blank)

Local ID   
(xy.sample.com or blank)

Figure 50 - IPSec profile edit

The following table describes each of the fields of the IPSec VPN Connection Settings page.

ITEM	DEFINITION
IPSec Profile	Enables or disables the VPN profile.
Profile Name	A name used to identify the VPN connection profile.
Remote IPSec Server Address	The IP address of the IPSec server.
Remote LAN Address	Enter the IP address of the remote network for use on the VPN connection.
Remote LAN Subnet Mask	Enter the subnet mask in use on the remote network.
Local LAN Address	Enter the IP address of the local network for use on the VPN connection.
Local LAN Subnet Mask	Enter the subnet mask in use on the local network.
Encapsulation Type	Select the encapsulation protocol to use with the VPN connection. You can choose <b>ESP</b> , <b>AH</b> or <b>Any</b> .
IKE Mode	Select the IKE mode to use with the VPN connection. You can choose <b>Main</b> , <b>Aggressive</b> or <b>Any</b> .
PFS	Choose whether Perfect Forward Secrecy is ON or OFF for the VPN connection.
IKE Encryption	Select the cipher type to use for the Internet Key Exchange.
IKE Hash	Select the IKE Hash type to use for the VPN connection. The hash is used for authentication of packets for the key exchange.
IPSec Encryption	Select the IPSec encryption type to use with the VPN connection.
IPSec Hash	Select the IPSec hash type to use for the VPN connection. The hash is used for authentication of packets for the VPN connection.
DH Group	Select the desired Diffie-Hellman group to use. Higher groups are more secure but also require longer to generate a key.
DPD Action	Select the desired Dead Peer Detection action. This is the action to take when a dead Internet Key Exchange Peer is detected.
DPD Keep Alive Time	Enter the time in seconds for the interval between Dead Peer Detection keep alive messages.
DPD Timeout	Enter the time in seconds of no response from a peer before Dead Peer Detection times out.
IKE Rekey Time	Enter the time in seconds between changes of the encryption key. To disable changing the key, set this to 0.
SA Life Time	Enter the time in seconds for the security association lifetime.
Key Mode	Select the type of key mode in use for the VPN connection. You can select from: <ul style="list-style-type: none"> <li>• Pre Shared Key</li> <li>• RSA keys</li> <li>• Certificates</li> </ul>
Pre-shared Key	The pre-shared key is the key that peers used to authenticate each other for Internet Key Exchange.
Remote ID	Specifies the domain name of the remote network.
Local ID	Specifies the domain name of the local network.
Update Time	Displays the last time the key was updated.
Local RSA Key Upload	Select the RSA key file for the local router here by clicking the <b>Browse</b> button.
Remote RSA Key Upload	Select the RSA key file for the remote router here by clicking the <b>Browse</b> button.
Private key Passphrase	The Private key passphrase of the router is the passphrase used when generating the router's private key using OpenSSL CA.
Key / Certificate	Select the type of key or certificate to use for authentication. You can select <b>Local private key</b> , <b>Local public certificate</b> , <b>Remote public certificate</b> , <b>CA certificate</b> , <b>CRL certificate</b> .
IPSec Certificate Upload	Select the IPSec certificate to upload by clicking the <b>Browse</b> button.

Table 14 - IPSec Configuration Items

## OpenVPN

OpenVPN is an open source virtual private network (VPN) program for creating point-to-point or server-to-multi-client encrypted tunnels between host computers. It can traverse network address translation (NAT) and firewalls and allows authentication by certificate, pre-shared key or username and password. OpenVPN works well through proxy servers and can run over TCP and UDP transports. Support for OpenVPN is available on several operating systems, including Windows, Linux, Mac OS, Solaris, OpenBSD, FreeBSD, NetBSD and QNX.

### Configuring an Open VPN server

From the menu at the top of the screen, click **Networking** and from the VPN section on the left, click **OpenVPN**. A list of configured OpenVPN VPN connections is displayed.




Figure 51 - OpenVPN VPN List

Click the **+Add** button for the type of OpenVPN server/client you would like to configure.

### OpenVPN Server

To configure an OpenVPN Server:


1. Click the **OpenVPN profile** toggle key to switch it to the **ON** position.
2. Type a name for the OpenVPN server profile you are creating.
3. Use the **Server** port field to select a port number and then use the drop down list to select a packet type to use for your OpenVPN Server. The default OpenVPN port is 1194 and default packet type is UDP.
4. In the **VPN network address** and **VPN network subnet mask** fields, enter the IP address and network subnet mask to assign to your VPN. This is ideally an internal IP address which differs from your existing address scheme.
5. Next to Diffie-Hellman parameters, click the **Generate DH** button. This will create an encryption key to secure your OpenVPN connection.
6. Under Server Certificates, enter the required details. All fields must be completed. The **Country** field must consist of two characters only. When the details have been entered, click the **Generate CA certificate** button to generate the Certificate Authority (CA) certificate based on this information.
7. Under the **Server certificates** section, select the **Authentication type** that you would like to use for the OpenVPN Server.



Note: The Diffie-Hellman parameters can take up to 10 minutes to generate. Please be patient.

### Certificate Authentication

In the Certificate Management section, enter the required details to create a client certificate. All fields are required. When you have finished entering the details, click the **Generate** button.



**Certificate Management**

Certificate

Name

Country

State

City

Organization

Email

Network Address

Network Mask

Figure 52 - OpenVPN server configuration - Certificate management

When it is done, you can click the **Download** button to save the certificate file. If for some reason the integrity of your network has been compromised, you can return to this screen and use the Certificate drop down list to select the certificate and then press the **Revoke** button to disable it.

**Optional:** To inform the OpenVPN server of the network address scheme of the currently selected certificate, enter the network address and network subnet mask in the respective fields and click the **Set network information** button. If you do not enter the remote subnet here, any packet requests from the server to the client will not be received by the client network because it is not aware of the remote client's subnet.

OpenVPN Profile  ON  OFF

Profile Name

Type

Server Port

VPN Network Address  .  .  .

VPN Network Subnet Mask  .  .  .

Diffie-Hellman Parameters

### Server Certificates

Not Before: **N/A**

Not After: **N/A**

Country

State

City

Organization

Email

Authentication Type  Certificate  Username / Password

### Certificate Management

Certificate

Name

Country

State

City

Organization

Email

Network Address  .  .  .

Network Mask  .  .  .

Figure 53 - OpenVPN server profile settings



### Username / Password Authentication

In the Username/Password section, enter the username and password you would like to use for authentication on the OpenVPN Server. Click the **Download CA certificate** button to save the **ca.crt** file. This file will need to be provided to the client.



Note: If you wish to have more than one client connect to this OpenVPN server, you must use Certificate authentication mode as Username/Password only allows for a single client connection.




Figure 54 - OpenVPN Server - Username / Password section

**Optional:** To inform the OpenVPN server of the network address scheme of the currently selected certificate, enter the network address and network subnet mask in the respective fields and click the **Set network information** button. If you do not enter the remote subnet here, any packet requests from the server to the client will not be received by the client network because it is not aware of the remote client's subnet.

When you have finished entering all the required information, click **Save** to finish configuring the OpenVPN server.

## Configuring an OpenVPN Client

1. Click the **OpenVPN profile** toggle key to switch it to the **ON** position.
2. In the **Profile name** field, type a name for the OpenVPN client profile you are creating.
3. In the **Server IP** address field, type the WAN IP address of the OpenVPN server.
4. Use the **Server** port field to select a port number and then use the drop down list to select a packet type to use for the OpenVPN server. The default OpenVPN port is 1194 and default packet type is UDP.
5. If the **Default gateway** option is applied on the OpenVPN client page, the OpenVPN server will enable connections to be made to other client networks connected to it. If it is not selected, the OpenVPN connection allows for secure communication links between this router and the remote OpenVPN server only.
6. Use the **Authentication type** options to select the Authentication type that you would like to use for the OpenVPN client.

### Certificate Authentication

In the Certificate upload section at the bottom of the screen, click the **Browse** button and locate the certificate file you downloaded when you configured the OpenVPN server. When it has been selected, click the **Upload** button to send it to the router.




Figure 55 - OpenVPN client - Certificate upload

### Username / Password Authentication

Enter the username and password to authenticate with the OpenVPN server.




Figure 56 - OpenVPN Client - Username/Password section


Use the **Browse** button to locate the CA certificate file you saved from the OpenVPN Server and then press the **Upload** button to send it to the router.

Click the **Save** button to complete the OpenVPN Client configuration.

## Configuring an OpenVPN P2P Connection

To configure an OpenVPN peer-to-peer connection:

1. Set the **OpenVPN** profile toggle key to switch it to the **ON** position.
2. In the **Profile name** field, type a name for the OpenVPN P2P profile you are creating.
3. On the router designated as the master, leave the **Server IP address** field empty. On the router designated as the slave, enter the **WAN IP address** of the master.



OpenVPN Profile  ON  OFF

Profile Name

Server IP Address      
(Leave empty if it is peer-to-peer server)

Server Port

Local IP Address

Remote IP Address

**Remote Network**

Address

Subnet Mask

**Server Secret Key**

Update Time **N/A**

**Client Secret Key**

Update Time **N/A**

Client Secret Key Upload

Figure 57 - OpenVPN P2P mode settings

4. Use the **Server** port field to select a port number and then use the drop down list to select a packet type to use for the OpenVPN server. The default OpenVPN port is 1194 and default packet type is UDP.
5. In the **Local IP Address** and **Remote IP Address** fields, enter the respective local and remote IP addresses to use for the OpenVPN tunnel. The slave should have the reverse settings of the master.
6. Under the Remote network section, enter the network **Address** and network **Subnet mask**. The Network Address and Network Mask fields inform the Master node of the LAN address scheme of the slave.
7. Press the **Generate** button to create a secret key to be shared with the slave. When the timestamp appears, you can click the **Download** button to save the file to exchange with the other router.
8. When you have saved the secret key file on each router, use the **Browse** button to locate the secret key file for the master and then press the **Upload** button to send it to the slave. Perform the same for the other router, uploading the slave's secret key file to master.
9. When they are uploaded click the **Save** button to complete the peer-to-peer OpenVPN configuration.

## PPTP Client

The Point-to-Point Tunneling Protocol (PPTP) is a method for implementing virtual private networks using a TCP and GRE tunnel to encapsulate PPP packets. PPTP operates on Layer 2 of the OSI model and is included on Windows computers.

### Configuring the PPTP Client

To configure the PPTP client:

1. From the menu bar at the top of the screen, click **Networking** and then from the **VPN** section on the left side of the screen, click **PPTP client**. The PPTP client list is displayed.





Figure 58 - PPTP client list

2. Click the **+Add** button to begin configuring a new PPTP client profile. The PPTP client edit screen is displayed.



**VPN PPTP Client Edit**

Enable PPTP Client  ON  OFF

Profile Name List

Username

Password

PPTP Server Address

Authentication Type  ▼

Metric   
(0-65535)

Use peer DNS  ON  OFF

NAT Masquerading  ON  OFF

Set Default Route to PPTP  ON  OFF

MPPE  ON  OFF

Extra PPP option

Verbose logging  ON  OFF

Reconnect Delay   
(30-65535) secs

Reconnect Retries   
(0-65535, 0=Unlimited)

Figure 59 - VPN PPTP client edit

3. Click the **Enable PPTP client** toggle key to switch it to the **ON** position.
4. In the **Profile name list**, enter a profile name for the tunnel. This may be anything you like and is used to identify the tunnel on the router.
5. Use the **Username** and **Password** fields to enter the username and password for the PPTP account.
6. In the **PPTP server address** field, enter the IP address of the PPTP server.

7. From the **Authentication type** drop down list, select the Authentication type used on the server. If you do not know the authentication method used, select **any** and the router will attempt to determine the correct authentication type for you. There are 5 authentication types you can choose from:
  - CHAP – uses a three way handshake to authenticate the identity of a client.
  - MS-CHAP v1 – This is the Microsoft implementation of the Challenge Handshake Authentication Protocol for which support was dropped in Windows® Vista.
  - MS-CHAP v2 - This is the Microsoft implementation of the Challenge Handshake Authentication Protocol which was introduced in Windows® NT 4.0 and is still supported today.
  - PAP – The Password Authentication Protocol uses a password as a means of authentication and as such, is commonly supported. PAP is not recommended because it transmits passwords unencrypted and is not secure.
  - EAP – Extensible Authentication Protocol. An Authentication protocol commonly used in wireless networks.
8. The **metric** value helps the router to prioritise routes and must be a number between 0 and 65535. The default value is 30 and should not be modified unless you are aware of the effect your changes will have.
9. The **Use peer DNS** option allows you to select whether the remote clients will use the Domain Name Server of the PPTP server. Click the toggle key to set this to ON or OFF as required.
10. **NAT masquerading** allows the router to modify the packets sent and received to inform remote computers on the internet that packets originating from a machine behind the router actually originated from the WAN IP address of the router's internal NAT IP address. Click the toggle key to switch this to the ON position if you want to use this feature.
11. **Set default route to PPTP** sets all outbound data packets to go out through the PPTP tunnel. Click the toggle key to switch this to the ON position if you want to use this feature.
12. The **Verbose logging** option sets the router to output detailed logs regarding the PPTP connection in the **System Log** section of the router interface.
13. The **Reconnect delay** is the time in seconds that the router will wait before attempting to connect to the PPTP server in the event that the connection is broken. The minimum time to wait is 30 seconds so as to not flood the PPTP server with connection requests, while the maximum time to wait is 65335 seconds.
14. The **Reconnect retries** is the number of connection attempts that the router will make in the event that the PPTP connection goes down. If set to 0, the router will retry the connection indefinitely, otherwise the maximum number of times to retry cannot be greater than 65335.
15. Click the **Save** button to save the changes. The VPN will attempt to connect after your click Save. Click the **Status** button at the top left of the interface to return to the status window and monitor the VPN's connection state.

## GRE tunnelling

The Generic Route Encapsulation (GRE) protocol is used in addition to Point-to-Point Tunnelling Protocol (PPTP) to create VPNs (virtual private networks) between clients and servers or between clients only. Once a PPTP control session establishes the VPN tunnel GRE is used to securely encapsulate the data or payload.

## Configuring GRE tunnelling

To configure GRE tunnelling:

1. From the menu bar at the top of the screen, click **Networking** and then from the **VPN** section on the left side of the screen, click **PPTP client**. The PPTP client list is displayed.



Figure 60 - GRE client list

2. Click the **+Add** button to begin configuring a new GRE tunnelling client profile. The GRE client edit screen is displayed.




Figure 61 - GRE client edit

3. Click the **Enable VPN** toggle key to switch it to the **ON** position.
4. In the **Profile name**, enter a profile name for the tunnel. This may be anything you like and is used to identify the tunnel on the router.
5. In the **GRE server address** field, enter the IP address of the GRE server.
6. In the **Local tunnel address** field, enter the IP address you want to assign the tunnel locally.

7. In the **Remote tunnel address** field, enter the IP address you want to assign to the remote tunnel.
8. In the **Remote network address** field, enter the IP address scheme of the remote network.
9. In the **Remote network/mask** field, enter the subnet mask of the remote network.
10. The **TTL** (Time To Live) field is an 8-bit field used to remove an undeliverable data packet from a network to avoid unnecessary network traffic across the internet. The default value of 255 is the upper limit on the time that an IP datagram can exist. The value is reduced by at least one for each hop the data packet takes to the next router on the route to the datagram's destination. If the TTL field reaches zero before the datagram arrives at its destination the data packet is discarded and an error message is sent back to the sender.
11. The **Reconnect delay** is the time in seconds that the router will wait before attempting to connect to the GRE server in the event that the connection is broken. The minimum time to wait is 30 seconds so as to not flood the GRE server with connection requests, while the maximum time to wait is 65335 seconds.
12. The **Reconnect retries** is the number of connection attempts that the router will make in the event that the GRE connection goes down. If set to 0, the router will retry the connection indefinitely, otherwise the maximum number of times to retry cannot be greater than 65335.
13. Click the **Save** button to save the changes. The VPN will attempt to connect after your click Save. Click the **Status** button at the top left of the interface to return to the status window and monitor the VPN's connection state.

# Services

## Dynamic DNS

The DDNS page is used to configure the Dynamic DNS feature of the router. A number of Dynamic DNS hosts are available from which to select.




Figure 62 – Dynamic DNS settings

Dynamic DNS provides a method for the router to update an external name server with the current WAN IP address.

To configure dynamic DNS:


1. Click the **DDNS configuration** toggle key to switch it to the ON position.
2. From the **Dynamic DNS** drop down list, select the Dynamic DNS service that you wish to use. The available DDNS services available are:
  - [www.dhs.org](http://www.dhs.org)
  - [www.dyndns.org](http://www.dyndns.org)
  - [www.dyns.cx](http://www.dyns.cx)
  - [www.easydns.com](http://www.easydns.com)
  - [www.justlinux.com](http://www.justlinux.com)
  - [www.ods.org](http://www.ods.org)
  - [www.tzo.com](http://www.tzo.com)
  - [www.zoneedit.com](http://www.zoneedit.com)
3. In the **Username** and **Password** fields, enter the logon credentials for your DDNS account. Enter the password for the account again in the **Verify password** field.
4. Click the **Save** button to save the DDNS configuration settings.



## Network time (NTP)

The NTP (Network Time Protocol) settings page allows you to configure the CDMA M2M router to synchronize its internal clock with a global Internet Time server and specify the time zone for the location of the router. This provides an accurate timekeeping function for features such as System Log entries and Firewall settings where the current system time is displayed and recorded.

Any NTP server available publicly on the internet may be used. The default NTP server is 0.netcomm.pool.ntp.org.



**Timezone Settings**

Current Time Thu Mar 28 12:38:59 EST 2013

Time Zone (GMT+10:00) Australia (Car)

[Daylight Savings Time schedule](#)

**NTP Settings**

NTP  ON  OFF

NTP Service 0.netcomm.pool.ntp.org

Synchronization on WWAN connection  ON  OFF

Daily synchronization  ON  OFF

Save

Figure 63 - NTP settings

### Configuring Timezone settings

To configure time zone settings:

1. The **Current time** field shows the time and date configured on the router. If this is not accurate, use the **Time zone** drop down list to select the correct time zone for the router. If the selected zone observes daylight savings time, a **Daylight savings time schedule** link appears below the drop down list. Click the link to see the start and end times for daylight savings.
2. When you have selected the correct time zone, click the **Save** button to save the settings.

### Configuring NTP settings

To configure NTP settings:

1. Click the **Network time (NTP)** toggle key to switch it to the **ON** position.
2. In the **NTP service** field, enter the address of the NTP server you wish to use.
3. The **Synchronization on WWAN connection** toggle key enables or disables the router from performing a synchronization of the time each time a mobile broadband connection is established.
4. The **Daily synchronization** toggle key enables or disables the router from performing a synchronisation of the time each day.
5. When you have finished configuring NTP settings, click the **Save** button to save the settings.

## Watchdogs

Watchdogs are features which monitor the router for anomalies and restart the router if an anomaly occurs preventing its normal operation. When configured, the watchdog feature transmits controlled ping packets to 1 or 2 user specified IP addresses to confirm an active connection. If the watchdog does not receive responses to the pings after a specified number of failures, it will reboot the device in a last resort attempt to restore connectivity.

We recommend using caution when implementing this feature in situations where the device is intentionally offline for a particular reason, for example, when Dial-on-demand has been enabled. This is because the watchdog expects to be able to access the internet at all times, and will always eventually reboot the router if access isn't restored by the time the various timers expire and the fail count is reached.

It is due to the nature of the watchdog being a last resort standalone backup mechanism that it will continue to do its job and reboot the device even when the Dial-on-demand session is idle, or the mobile broadband connection is disabled by the user. Therefore, we recommended that you disable this feature if Dial-on-demand is configured or if the mobile broadband connection will be intentionally disconnected on occasion.


The watchdog works as follows:

- The router sends 3 consecutive pings to the first destination address at the interval specified in the **Periodic PING Timer** field.
- If all 3 pings to the first destination address fail, the router sends 3 consecutive pings to the second destination address at the **Periodic PING Timer** interval.
- If all 3 pings to the second destination address fail, the router sends 3 pings to the first destination address using the **Periodic PING Accelerated Timer** interval.
- If all 3 accelerated pings to the first destination address fail, the router sends 3 pings to the second destination address at the **Periodic PING Accelerated Timer** interval.
- If all 3 accelerated pings to the second destination address fail, the router registers this as a fail and returns to step C.
- When the number of failures reaches the number configured in the **Fail Count** field, the router reboots. If any ping succeeds, the router returns to step A and does not reboot.



Note: The **Periodic Ping Timer** should not be set to a value of less than 210 seconds to allow the router time to reconnect to the cellular network following a reboot.

To disable the periodic ping reset monitor, set **Fail Count** to 0.



First Destination Address

Second Destination Address

Periodic PING Timer   
(0=disable, 300-65535) secs

Periodic PING Accelerated Timer   
(0=disable, 60-65535) secs

Fail Count   
(0=disable, 1-65535) times

**Periodic Reboot**

Force reboot every   
(0=disable, 5-65535) mins

Randomize reboot time

Figure 64 - Ping watchdog settings

## Configuring Periodic PING settings

The Periodic PING settings configure the router to transmit controlled ping packets to 2 specified IP addresses. If the router does not receive responses to the pings, the router will reboot.

To configure the ping watchdog:

1. In the **First destination address** field, enter a website address or IP address to which the router should send the first round of ping requests.
2. In the **Second destination address** field, enter a website address or IP address to which the router should send the second round of ping requests.
3. In the **Periodic PING timer** field, enter an integer between 300 and 65535 for the number of seconds the router should wait between ping attempts. Setting this to 0 disables the ping watchdog function.
4. In the **Periodic PING accelerated timer** field, enter an integer between 60 and 65535 for the number of seconds the router should wait between accelerated ping attempts, i.e. pings to the second destination address. Setting this to 0 disables the ping watchdog function.
5. In the **Fail Count** field, enter an integer between 1 and 65535 for the number of times an accelerated ping should fail before the router reboots. Setting this to 0 disables the ping watchdog function.

## Disabling the Periodic Ping reset function

To disable the Periodic Ping reset function, set **Fail Count** to 0.



Note: The traffic generated by the periodic ping feature is usually counted as chargeable data usage. Please keep this in mind when selecting how often to ping.

## Configuring a Periodic reboot


The router can be configured to automatically reboot after a period of time specified in minutes. While this is not necessary, it does ensure that in the case of remote installations, the router will reboot if some anomaly occurs.

1. In the **Force reboot every** field, enter the time in minutes between forced reboots. The default value is 0 which disables the Periodic reboot function. The minimum period between reboots is 5 minutes while the maximum value is 65535 minutes.
2. If you have configured a forced reboot time, you can use the **Randomise reboot time** drop down list to select a random reboot timer. Randomising the reboot time is useful for preventing a large number of devices from rebooting simultaneously and flooding the network with connection attempts. The router will wait for the configured **Force reboot every** time and then randomly reboot within the configured **Randomise reboot time**.
3. Click the **Save** button to save the settings.

## SNMP

### SNMP configuration

The SNMP page is used to configure the SNMP features of the router.



The image shows a web interface for SNMP configuration. At the top, there is a title "SNMP Configuration". Below the title, there is a toggle switch for "SNMP" which is currently set to "ON". Underneath, there are two text input fields: "Read-Only Community Name" with the value "public" and "Read-Write Community Name" with the value "private". Below these fields is a "Download" button, followed by the text "(This is a brief version of the MIB file only)". At the bottom of the form is a "Save" button.

Figure 65 - SNMP configuration

SNMP (Simple Network Management Protocol) is used to remotely monitor the router for conditions that may warrant administrative attention. It can be used to retrieve information from the router such as the signal strength, the system time, the interface status, etc.

To configure SNMP:

1. Click the **SNMP** toggle key to switch it to the **ON** position.
2. Enter **Read-Only Community Name** and **Read-Write Community Name** which are used for client authentication.



Community names are used as a type of security to prevent access to reading and/or writing to the routers configuration. It is recommended that you change the Community names to something other than the default settings when using this feature.

3. Click the **Save** button to save any changes to the settings.

The **Download** button displays the Management information base (MIB) of the router. The MIB displays all the objects of the router that can have their values set or report their status. The MIB is formatted in the SNMP-related standard RFC1155.


## SNMP traps

SNMP traps are messages from the router to the Network Management System sent as UDP packets. They are often used to notify the management system of any significant events such as whether the link is up or down.

### Configuring SNMP traps

To configure SNMP traps:

1. In the **Trap destination** field, enter the IP address to which SNMP data is to be sent.
2. In the **Heartbeat interval** field, enter the number of seconds between SNMP heartbeats.
3. Use the **Trap persistence** field to specify the time in seconds that an SNMP trap persists.
4. Use the **Trap retransmission** time to specify the length of time in seconds between SNMP trap retransmissions.



The image shows a configuration panel titled "SNMP Traps". It contains four input fields, each with a label and a unit in parentheses below the field:

- Trap Destination (IP Address)**: An empty text input field with "(IP Address)" below it.
- Heartbeat Interval (seconds)**: A text input field containing the value "43200" with "(seconds)" below it.
- Trap Persistence Time (seconds)**: A text input field containing the value "500" with "(seconds)" below it.
- Trap Retransmission Time (seconds)**: A text input field containing the value "21600" with "(seconds)" below it.

Below the input fields are two buttons: a grey button labeled "Send Heartbeat Now" and a blue button labeled "Save".

*Figure 66 - SNMP traps*

To send a manual SNMP Heartbeat, click the **Send heartbeat** button.

When you have finished configuring the SNMP traps, click the **Save** button to save the settings.

## TR-069

The TR-069 (Technical Report 069) protocol is a technical specification also known as CPE WAN Management Protocol (CWMP). It is a framework for remote management and auto-configuration of end-user devices such as customer-premises equipment (CPE) and Auto Configuration Servers (ACS). It is particularly efficient in applying configuration updates across networks to multiple CPEs.

TR-069 uses a bi-directional SOAP/HTTP-based protocol based on the application layer protocol and provides several benefits for the maintenance of a field of CPEs:

- Simplifies the initial configuration of a device during installation
- Enables easy restoration of service after a factory reset or replacement of a faulty device
- Firmware and software version management
- Diagnostics and monitoring




Note: You must have your own compatible ACS infrastructure to use TR-069. In order to access and configure the TR-069 settings you must be logged into the router as the root user.

### TR-069 configuration

To configure TR-069:

1. Click the **Enable TR-069** toggle key to switch it to the **ON** position.
2. In the **ACS URL** field, enter the Auto Configuration Server's full domain name or IP address.
3. Use the **ACS username** field to specify the username for the Auto Configuration Server.
4. In the **ACS password** and **Verify ACS password** fields, enter the Auto Configuration Server password.
5. In the **Connection request username** field, enter the username to use for the connection requests.
6. In the **Connection request password** and **Verify password** fields, enter the connection request password.
7. The inform message acts as a beacon to inform the ACS of the existence of the router. Click the **Enable periodic ACS informs** toggle key to turn on the periodic ACS inform messages.
8. In the **Inform period** field, enter the number of seconds between the inform messages.
9. Click the **Save** button to save the settings.



The screenshot shows the 'TR-069 Configuration' web interface. It features a title bar at the top. Below the title, there are several configuration options: 'Enable TR-069 Service' with a toggle switch set to 'ON'; 'ACS URL' with an empty text input field; 'ACS Username' with a text input field containing 'acs'; 'ACS Password' and 'Verify ACS Password' with masked password input fields; 'Connection Request Username' with a text input field containing 'cpe'; 'Connection Request Password' and 'Verify Password' with masked password input fields; 'Enable Periodic ACS Informs' with a toggle switch set to 'ON'; and 'Inform Period' with a text input field containing '600' and a note '(30-2592000) secs' below it. At the bottom of the form is a blue 'Save' button.

Figure 67 - TR-069 configuration

# HTTPS

## What is HTTP Secure?

HTTP Secure or HTTPS is the use of the HTTP protocol over an SSL/TLS protocol. It is used primarily to protect against eavesdropping of communication between a web browser and the web site to which it is connected. This is especially important when you wish to have a secure connection over a public network such as the internet. HTTPS connections are secured through the use of certificates issued by trusted certificate authorities such as VeriSign. When a web browser makes a connection attempt to a secured web site, a digital certificate is sent to the browser so that it can verify the authenticity of the site using a built-in list of trusted certificate authorities.

There are two main differences between how HTTPS and HTTP connections work:

1. HTTPS uses port 443 while HTTP uses port 80 by default.
2. Over an HTTPS connection, all data sent and received is encrypted with SSL while over an HTTP connection, all data is sent unencrypted.

The encryption is achieved through the use of a pair of public and private keys on both sides of the connection. In cryptography, a key refers to a numerical value used by an algorithm to alter information (encrypt it), making the information secure and visible only to those who have the corresponding key to recover (decrypt) the information. The public key is used to encrypt information and can be distributed freely. The private key is used to decrypt information and must be secret by its owner.

Each CDMA M2M router contains a self-signed digital certificate which is identical on all CDMA M2M routers. For a greater level of security, the router also supports generating your own unique key. Additionally, you may use third party software to generate your own self-signed digital certificate or purchase a signed certificate from a trusted certificate authority and then upload those certificates to the router.

## Generating your own self-signed certificate

To generate your own self-signed certificate:

1. Click the **Services** item from the top menu bar, then **HTTPS** from the side menu bar.
2. Enter the certificate details using the appropriate fields. Each field must be completed in order to generate a certificate.



**Generate self signed HTTPS certificate**

Country

State

City

Organization

Email

Figure 68 - Generate self signed HTTPS certificate




Note: The **Country** field must contain a code for the desired country from the list below.

CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY	CODE	COUNTRY
AX	Åland Islands	ER	Eritrea	LS	Lesotho	SA	Saudi Arabia
AD	Andorra	ES	Spain	LT	Lithuania	SB	Solomon Islands
AE	United Arab Emirates	ET	Ethiopia	LU	Luxembourg	SC	Seychelles
AF	Afghanistan	FI	Finland	LV	Latvia	SE	Sweden
AG	Antigua and Barbuda	FJ	Fiji	LY	Libya	SG	Singapore
AI	Anguilla	FK	Falkland Islands (Malvinas)	MA	Morocco	SH	St. Helena
AL	Albania	FM	Micronesia	MC	Monaco	SI	Slovenia
AM	Armenia	FO	Faroe Islands	MD	Moldova	SJ	Svalbard and Jan Mayen
AN	Netherlands Antilles	FR	France	ME	Montenegro	SK	Slovak Republic
AO	Angola	FX	France, Metropolitan	MG	Madagascar	SL	Sierra Leone
AQ	Antarctica	GA	Gabon	MH	Marshall Islands	SM	San Marino
AR	Argentina	GB	Great Britain (UK)	MK	Macedonia	SN	Senegal
AS	American Samoa	GD	Grenada	ML	Mali	SR	Suriname
AT	Austria	GE	Georgia	MM	Myanmar	ST	Sao Tome and Principe
AU	Australia	GF	French Guiana	MN	Mongolia	SU	USSR (former)
AW	Aruba	GG	Guernsey	MO	Macau	SV	El Salvador
AZ	Azerbaijan	GH	Ghana	MP	Northern Mariana	SZ	Swaziland
BA	Bosnia and	GI	Gibraltar	MQ	Martinique	TC	Turks and Caicos Islands
BB	Barbados	GL	Greenland	MR	Mauritania	TD	Chad
BD	Bangladesh	GM	Gambia	MS	Montserrat	TF	French Southern Territories
BE	Belgium	GN	Guinea	MT	Malta	TG	Togo
BF	Burkina Faso	GP	Guadeloupe	MU	Mauritius	TH	Thailand
BG	Bulgaria	GQ	Equatorial Guinea	MV	Maldives	TJ	Tajikistan
BH	Bahrain	GR	Greece	MW	Malawi	TK	Tokelau
BI	Burundi	GS	S. Georgia and S. Sandwich	MX	Mexico	TM	Turkmenistan
BJ	Benin	GT	Guatemala	MY	Malaysia	TN	Tunisia
BM	Bermuda	GU	Guam	MZ	Mozambique	TO	Tonga
BN	Brunei Darussalam	GW	Guinea-Bissau	NA	Namibia	TP	East Timor
BO	Bolivia	GY	Guyana	NC	New Caledonia	TR	Turkey
BR	Brazil	HK	Hong Kong	NE	Niger	TT	Trinidad and Tobago
BS	Bahamas	HM	Heard and McDonald Islands	NF	Norfolk Island	TV	Tuvalu
BT	Bhutan	HN	Honduras	NG	Nigeria	TW	Taiwan
BV	Bouvet Island	HR	Croatia (Hrvatska)	NI	Nicaragua	TZ	Tanzania
BW	Botswana	HT	Haiti	NL	Netherlands	UA	Ukraine
BZ	Belize	HU	Hungary	NO	Norway	UG	Uganda
CA	Canada	ID	Indonesia	NP	Nepal	UM	US Minor Outlying Islands
CC	Cocos (Keeling) Islands	IE	Ireland	NR	Nauru	US	United States
CF	Central African Republic	IL	Israel	NT	Neutral Zone	UY	Uruguay
CH	Switzerland	IM	Isle of Man	NU	Niue	UZ	Uzbekistan
CI	Cote D'Ivoire (Ivory	IN	India	NZ	New Zealand	VA	Vatican City State (Holy See)
CK	Cook Islands	IO	British Indian Ocean	OM	Oman	VC	Saint Vincent and the
CL	Chile	IS	Iceland	PA	Panama	VE	Venezuela
CM	Cameroon	IT	Italy	PE	Peru	VG	Virgin Islands (British)
CN	China	JE	Jersey	PF	French Polynesia	VI	Virgin Islands (U.S.)
CO	Colombia	JM	Jamaica	PG	Papua New Guinea	VN	Viet Nam
CR	Costa Rica	JO	Jordan	PH	Philippines	VU	Vanuatu
CS	Czechoslovakia	JP	Japan	PK	Pakistan	WF	Wallis and Futuna Islands
CV	Cape Verde	KE	Kenya	PL	Poland	WS	Samoa
CX	Christmas Island	KG	Kyrgyzstan	PM	St. Pierre and	YE	Yemen
CY	Cyprus	KH	Cambodia	PN	Pitcairn	YT	Mayotte
CZ	Czech Republic	KI	Kiribati	PR	Puerto Rico	ZA	South Africa
DE	Germany	KM	Comoros	PS	Palestinian Territory	ZM	Zambia
DJ	Djibouti	KN	Saint Kitts and Nevis	PT	Portugal	COM	US Commercial
DK	Denmark	KR	Korea (South)	PW	Palau	EDU	US Educational
DM	Dominica	KW	Kuwait	PY	Paraguay	GOV	US Government
DO	Dominican Republic	KY	Cayman Islands	QA	Qatar	INT	International
DZ	Algeria	KZ	Kazakhstan	RE	Reunion	MIL	US Military
EC	Ecuador	LA	Laos	RO	Romania	NET	Network
EE	Estonia	LC	Saint Lucia	RS	Serbia	ORG	Non-Profit Organization
EG	Egypt	LI	Liechtenstein	RU	Russian Federation	ARPA	Old style Arpanet
EH	Western Sahara	LK	Sri Lanka	RW	Rwanda		



3. When you have entered all the required details, press the **Generate** button. The certificate takes several minutes to generate. When the certificate has been generated, you are informed that it has been successfully generated and installed. The web server on the router restarts and you are logged out of the router. Click **OK** to be taken back to the login screen.



*Figure 69 - New certificate successfully generated message*

## SSH Server Configuration

Secure Shell (SSH) is UNIX-based command interface and network protocol used to gain secure access to a remote computer, execute commands on a remote machine or to transfer files between machines. It was designed as a replacement for Telnet and other insecure remote shell protocols which send information, including passwords, as plain text.

SSH uses RSA public key cryptography for both connection and authentication. There are several ways of using SSH:

- 🔑 Use automatically generated public-private key pairs to encrypt the network connection and then use password authentication to log on.
- 🔑 Use a manually generated public-private key pair to perform the authentication and allow users or programs to log in without using a password.




Figure 70 - SSH Server Configuration

To configure SSH:

1. Select the types of authentication you want to use by clicking the **Enable password authentication** and **Enable key authentication** toggle keys on or off.
2. Click the **Save** button.
- 3.

## SMS Diagnostics and Commands

### SMS messaging

The CDMA M2M router offers an advanced SMS feature set, including sending messages, receiving messages, redirecting incoming messages to another destination, as well as supporting remote commands and diagnostics messages.

Some of the functions supported include:

- ☰ Ability to send a text message via a CDMA network and store it in permanent storage.
- ☰ Ability to receive a text message via a CDMA network and store it in permanent storage.
- ☰ Ability to forward incoming text messages via a CDMA network to another remote destination which may be a TCP/UDP server or other mobile devices.
- ☰ Ability to receive run-time variables from the device (e.g. uptime) on request via SMS
- ☰ Ability to change live configuration on the device (e.g. network username) via SMS.
- ☰ Ability to execute supported commands (e.g. reboot) via SMS
- ☰ Ability to trigger the CDMA M2M router to download and install a firmware upgrade
- ☰ Ability to trigger the CDMA M2M router to download and apply a configuration file

To access the SMS messaging functions of the CDMA M2M router, click on the **Services** menu item from the top menu bar, and then select one of the options under the **SMS messaging** section on the left hand menu.

### Setup

The Setup page provides the options to enable or disable the SMS messaging functionality and SMS forwarding functionalities of the router. SMS messaging is enabled by default.

#### General SMS Configuration

SMS  ON  OFF

Messages Per Page (10-50)

Encoding Scheme  GSM 7 Bit  UCS2

SMSC Address

Routing Option  Packet-switched  
 Circuit-switched  
 Packet-switched preferred  
 Circuit-switched preferred

---

#### SMS Forwarding Setup

Forwarding  ON  OFF

Redirect to Mobile

TCP server IP address

TCP Port

UDP server IP address

UDP Port

Figure 71 - General SMS Configuration

OPTION	DEFINITION
<b>General SMS configuration</b>	
SMS messaging	Toggles the SMS functionality of the router on and off.
Messages per page (10-50)	The number of SMS messages to display per page. Must be a value between 10 and 50.
Encoding scheme	The encoding method used for outbound SMS messages. GSM 7-bit mode permits up to 160 characters per message but drops to 50 characters if the message includes special characters. UCS-2 mode allows the sending of Unicode characters and permits a message to be up to 50 characters in length.
SMSC address	The short message service centre (SMSC) address is the number of your mobile broadband SMS provider. The SMSC address is used when sending text messages and is stored on the SIM card. If the SMSC address field is blank, the router will not be able to send any SMS messages.
Routing Option	<p>Allows you to configure the method used to route SMS messages.</p> <p>Packet-switched: Uses the switched IP packet network to deliver messages. Messages are broken up into packets and transmitted through the network independently, then re-assembled when they reach the destination. In packet switched networks, network links are shared by packets from multiple competing communication sessions. Packet switching generally results in a lower quality of service compared with circuit switched networks because the packets may take different routes to the destination and cause delay in their re-assembly.</p> <p>Circuit-switched: Creates a route with reserved bandwidth from the source to the destination, emulating a physical connection with an electrical circuit. Data transmitted in a circuit switched network is delivered in order and has a constant bit delay meaning the service is predictable and reliable.</p> <p>Packet-switched preferred: Attempts to use the packet-switched network for SMS delivery but fails over to the circuit-switched network if messages are undeliverable.</p> <p>Circuit-switched preferred: Attempts to use the circuit-switched network for SMS delivery but fails over to the packet-switched network if messages are undeliverable.</p>
<b>SMS forwarding configuration</b>	
Forwarding	Toggles the SMS forwarding function of the router on and off.
Redirect to mobile	Enter a mobile number as the destination for forwarded SMS messages.
TCP address	Enter an IP address or domain name as the destination for forwarded SMS messages using TCP.
TCP port	The TCP port on which to connect to the remote destination.
UDP address	Enter an IP address or domain name as the destination for forwarded SMS messages using UDP.
UDP port	The UDP port on which to connect to the remote destination.

Table 15 - SMS Setup Settings

## SMS forwarding configuration

Incoming text messages can be redirected to another mobile device and/or a TCP/UDP message server.

### Redirect to mobile

You can forward incoming text messages to a different destination number. This destination number can be another mobile phone or a 3G router phone number.

For Example:

If someone sends a text message and **Redirect to mobile** is set to “+61412345678”, the text message is stored on the router and forwarded to “+61412345678” at the same time.

To disable redirection to a mobile, clear the **Redirect to mobile** field and click the **Save** button.

### Redirect to TCP / UDP address

You can also forward incoming text messages to a TCP/UDP based destination. The TCP or UDP server can be any kind of public or private server if the server accepts incoming text-based message.

The TCP/UDP address can be an IP address or domain name. The port number range is from 1 to 65535. Please refer to your TCP/UDP based SMS server configuration for which port to use.



For Example:


If someone sends a text message and **TCP address** is set to “192.168.20.3” and **TCP port** is set to “2002”, this text message is stored in the router and forwarded to “192.168.20.3” on port “2002” at the same time.

To disable redirection to a TCP or UDP address, clear the **TCP address** and **UDP address** fields and click the **Save** button.

## New message



The New message page can be used to send SMS text messages to a single or multiple recipients.

A new SMS message can be sent to a maximum of 100 recipients at the same time. After sending the message, the result is displayed next to the destination number as “Success” or “Failure” if the message failed to send. By default, only one destination number field is displayed. Additional destination numbers may be added one at a time after entering a valid number for the current destination number field. To add a destination number, click the  button and to remove the last destination in the list, click the  button.



**New Message**

Please prefix a '+' to all international numbers or the message may be incorrectly processed and/or discarded by the network.

Destination Number 01   

New Message



 

Figure 72 - SMS - New Message

Destination numbers should begin with the “+” symbol followed by the country calling code. To send a message to a destination number, enter the “+” symbol followed by the country calling code and then the destination number.

For example:

To send a message to the mobile destination number 0412345678 in Australia (country calling code 61), enter “+61412345678”.

After entering the required recipient numbers, type your SMS message in the **New message** field. As you type your message, a counter shows how many characters you have entered out of the total number available for your chosen encoding scheme. When you have finished typing your message and you are ready to send it, click the **Send** button.

## Inbox / Outbox

The Inbox displays all received messages that are stored on the router while the Outbox displays all sent messages.




Figure 73 - SMS Inbox



Figure 74 - SMS Outbox







ICON	DESCRIPTION
	Forward button. Click this button to open a new message window where you can forward the corresponding message to another recipient.
	Reply button. Click this button to open a new message window where you can reply to the sender.
	Add to White list. Click this button to add the sender's mobile number to the white list on the router.
	Delete button. Click this button to delete the corresponding message.
	Refresh button. Click this button to refresh the inbox or outbox to see new messages.

Table 16 - Inbox/Outbox icons

## Diagnostics

The Diagnostics page is used to configure the SMS diagnostics and command execution configuration. This enables you to change the configuration, perform functions remotely and check on the status of the router via SMS commands.

### SMS diagnostics and command execution configuration



**SMS Diagnostics & Command Execution Configuration**

Enable Remote Diagnostics  ON  OFF

Authentication  ON  OFF

Send Ack. SMS for Set Command  ON  OFF

Send Ack. SMS to  Fixed Number  SMS Sender Number

Send Error SMS for Get/Set/Exec Command  ON  OFF

Send Error SMS to  Fixed Number  SMS Sender Number

Max. Diag. SMS Tx Limit  messages per

0 / 100 messages sent

Limit the maximum number of diagnostic text messages to be sent within a certain time period. The current "messages sent" count automatically resets at the beginning of the designated time unit. For example, the counter will reset to 0 at 1:00, 2:00... for "HOUR", 00:00 for "DAY", 00:00 Monday for "WEEK" and the 1st day of the month for "MONTH".

Figure 75 - SMS diagnostics and command execution configuration

The options on this page are described below.

### Enable remote diagnostics and command execution

Enables or disables the remote diagnostics feature. If this setting is enabled all incoming text messages are parsed and tested for remote diagnostics commands.

If remote diagnostics commands are found, the router executes those commands. This feature is enabled by default. All remote diagnostic commands that are received are stored in the Inbox.



Note: It is possible to adjust settings and prevent your router from functioning correctly using remote diagnostics. If this occurs, you will need to perform a factory reset in order to restore normal operation.



We highly recommended that you use the white list and a password when utilising this feature to prevent unauthorised access. See the [White list](#) description for more information.

### Only accept authenticated SMS messages

Enables or disables checking the sender's phone number against the allowed sender white list for incoming diagnostics and command execution SMS messages.

If authentication is enabled, the router will check if the sender's number exists in the white list. If it exists, the router then checks the password (if configured) in the incoming message against the password in the white list for the corresponding sending number. If they match, the diagnostic or command is executed.

If the number does not exist in the white list or the password does not match, the router does not execute the incoming diagnostic or command in the SMS message.

This is enabled by default and it is strongly advised that you leave this feature enabled to maintain security.



### Send Set command acknowledgment replies

The CDMA M2M router will automatically reply to certain types of commands received, such as *get* commands, or *execute* commands. However replies from the CDMA M2M router are optional with *set* commands and the *Wakeup* command. This option Enables or disables sending an acknowledgment message after execution of a *set* command or SMS Wakeup command. If disabled, the router does not send any acknowledgement after execution of a *set* command or SMS Wakeup command. All acknowledgment replies are stored in the Outbox after they have been sent.

This can be useful to determine if a command was received and executed by the router. This option is disabled by default.

### Send acknowledgment replies to

This option allows you to specify where to send acknowledgment messages after the execution of a *set*, or *exec* command.

If a **fixed number** is selected, the acknowledgement message will be sent to the number defined in the **Fixed number to send replies to** field. If **the sender's number** is selected, the acknowledgement message will be sent to the number that the SMS diagnostic or command message originated from. The default setting is to use **the sender's number**.

### Fixed number to send replies to

This field defines the destination number to which acknowledgement messages are sent after the execution of a *set*, or *exec* command.

### Send command error replies

Enables or disables the sending of an error message resulting from the execution of a *get*, *set*, or *exec* command. All error replies are stored in the Outbox after they have been sent.

If disabled, the router does not send any error notifications after the execution of a *get*, *set*, or *exec* command. This function is enabled by default.

### Send error replies to

This option allows you to specify where to send error messages from the execution of a *get*, *set*, or *exec* command.

If a **fixed number** is selected, any error messages will be sent to the number defined in the **fixed number to send error replies to** field. If **the sender's number** is selected, any error messages will be sent to the number that the SMS diagnostic or command message originated from. The default setting is to use **the sender's number**.

### Fixed number to send error replies to

This field defines the destination number to which error messages are sent after the execution of a *get*, *set*, or *exec* command.


### Send a maximum of \_\_\_ replies per \_\_\_

You can set the maximum number of acknowledgement and error messages sent when an SMS diagnostic or command is executed. The maximum limit can be set per hour, day, week or month. The router will send a maximum of 100 replies by default.

The number of messages sent is shown below the options. The total transmitted message count resets after a reboot or at the beginning of the time frame specified.

## White list for diagnostic or execution SMS

The white list is a list of mobile numbers that you can create which are considered “friendly” to the router. If **Only accept authenticated SMS messages** is enabled in the diagnostics section, the router will compare the mobile number of all incoming diagnostic and command messages against this white list to determine whether the diagnostic or command should be executed. You may optionally configure a password for each number to give an additional level of security. When a password is specified for a number, the SMS diagnostic or command message is parsed for the password and will only be executed if the number and password match.



**White List for Diagnostic or Execution SMS Messages**

Incoming diagnostic or execution SMS messages are first checked with this White List. If the sender and password of the message do not match any of the destination numbers and passwords in the list, the message is ignored and an error message is sent either to the sender, or a predefined destination. Destination numbers can be easily added from SMS Inbox/Outbox pages using the "Add White List" button, up to a maximum of 20 entries.

[+ Add](#)

#	Destination Number	Password
01	<input type="text"/>	<input type="text"/>

Figure 76 - White list for diagnostic or execution SMS

A maximum of 20 numbers can be stored on the router in the white list.

One blank entry is shown by default and you can add a number by clicking the “**+Add**” button. The White List numbers and passwords can be cleared by pressing the  button to the right of each entry. To add a number to the white list, enter it in the **Destination number** field and optionally define a password in the **Password** field. When you have finished adding numbers click the **Save** button to save the entries.


## Sending an SMS diagnostic command

Follow the steps below to configure the router to optionally accept SMS diagnostic commands only from authenticated senders and learn how to send SMS diagnostic commands to the router.

1. Navigate to the **Services > SMS messaging > Diagnostics** page
2. Confirm that the **Enable remote diagnostics and command execution** toggle key is set to the **ON** position. If it is set to **OFF** click the toggle key to switch it to the **ON** position.
3. If you wish to have the router only accept commands from authenticated senders, ensure that **Only accept authenticated SMS messages** is set to the **ON** position. This is the default setting. In the **White list for diagnostic or execution SMS** section, click the **+Add** button and enter the sender's number in international format into the **Destination number** field that appears. If you wish to also configure a password, enter the password in the **Password** field corresponding to the destination number.
4. If you would prefer to accept SMS diagnostic commands from any sender, set the **Only accept authenticated SMS messages** toggle key to the **OFF** position.

Note: An alternative method of adding a number to the white list is to send an SMS message to the router, navigate to **Services**



> **SMS messaging > Inbox** and then click the  button next to the message which corresponds to the sender's number.

5. Click the **Save** button.

### Types of SMS diagnostic commands

There are three types of commands that can be sent; **execute**, **get** and **set**. The basic syntax is as follows:

- execute COMMAND
- get VARIABLE
- set VARIABLE=VALUE

If authentication is enabled, each command must be preceded by the password:

- PASSWORD execute COMMAND
- PASSWORD get VARIABLE
- PASSWORD set VARIABLE=VALUE

The following are some examples of SMS diagnostic commands:

- password6657 execute reboot
- get rssi
- set apn1=testAPNvalue

### SMS Acknowledgment replies

The router automatically replies to **get** commands with a value and **execute** commands with either a success or error response. **Set** commands will only be responded to if the **Send Set command acknowledgement replies** toggle key is set to **ON**. If the **Send command error replies** toggle key is set to **ON**, the router will send a reply if the command is correct but a variable or value is incorrect, for example, due to misspelling.

#### SMS Command format

Generic Format for reading variables:

get VARIABLE

PASSWORD get VARIABLE

Generic Format for writing to variables:

set VARIABLE=VALUE

PASSWORD set VARIABLE=VALUE

Generic Format for executing a command:

Execute COMMAND

PASSWORD execute COMMAND

#### Replies

Upon receipt of a successfully formatted, authenticated (if required) command, the gateway will reply to the SMS in the following format:

TYPE	SMS CONTENTS	NOTES
get command	"VARIABLE=VALUE"	
set command	"Successfully set VARIABLE to VALUE"	Only sent if the acknowledgment message function is enabled
execute command	"Successfully executed command COMMAND"	

*Table 17 - SMS Diagnostic Command Syntax*

Where "VARIABLE" is the name of the value to be read

Where "VARIABLE (x)" is the name of another value to be read

Where "VALUE" is the content to be written to the "VARIABLE"

Where "COMMAND" is a supported command to be executed by the device (e.g. reboot)

Where "PASSWORD" is the password (if configured) for the corresponding sender number specified in the White List

Multiple commands can be sent in the same message, if separated by a semicolon.

For Example:

get VARIABLE1; get VARIABLE2; get VARIABLE3

PASSWORD get VARIABLE1; get VARIABLE2

set VARIABLE=VALUE1 ; set VARIABLE2=VALUE2

PASSWORD set VARIABLE1=VALUE1; set VARIABLE2=VALUE2; set VARIABLE3=VALUE3

If required, values can also be bound by an apostrophe, double apostrophe or back tick.

For Example:

"set VARIABLE='VALUE'"

"set VARIABLE=""VALUE""

"set VARIABLE=`VALUE`"

"get VARIABLE"

A password (if required), only needs to be specified once per SMS, but can be prefixed to each command if desired.

“PASSWORD get Variable1”; “get VARIABLE2”

“PASSWORD set VARIABLE1=VALUE1”; “set VARIABLE2=VALUE2”

If the command sent includes the “reboot” command and has already passed the white list password check, the device keeps this password and executes the remaining command line after the reboot with this same password.

For Example:

“PASSWORD execute reboot; getVariable1”; “get VARIABLE2”

“PASSWORD execute reboot; PASSWORD get Variable1”; “get VARIABLE2”



Note: Commands, variables and values are case sensitive.

### List of valid commands

A list of valid commands which can be used in conjunction with the execute command are listed below:

“pdpcycle”, “pdpdown” and “pdpup” commands can have a profile number suffix ‘x’ added. Without the suffix specified, the command operates against the default profile configured on the profile list page of the Web-UI.

#	COMMAND NAME	DESCRIPTION
1	reboot	Immediately performs a soft reboot.
2	pdpcycle or pdpcyclex	Disconnects (if connected) and reconnects the 3G connection. If a profile number is selected in the command, try to disconnect/reconnect the specified profile in case the profile is active. If no profile number is selected, try to disconnect/reconnect the current active profile. Reports an error if no profile number is selected and there is no currently activated profile.
3	pdpdown or pdpdownx	Disconnects the PDP. If a profile number is selected in the command, the router tries to disconnect the specified profile in case the profile is active. If no profile number is selected, try to disconnect the current active profile. Reports an error if no profile number is selected and there is no currently activated profile.
4	pdpup or pdpupx	Reconnects the PDP. If a profile number is selected in the command, the router tries to connect with the specified profile. If no profile number is selected, the router tries to connect to the last active profile. The gateway will check the currently activated profile and disconnect this profile before executing the command. The router reports an error if no profile number is selected and there is no stored last active profile number.
5	factorydefaults	Performs a factory reset on the router.
6	download	<p>Performs a download and install of a Firmware Upgrade (.cdi), Config File (.tar.gz) or a help document (.pdf) file.</p> <p>If the file is a firmware image as in the case of a .cdi file, the router will apply the recovery image first and then the main firmware image. The download location is specified immediately after the command and may be from an HTTP or FTP source URL.</p> <p>If the file is a .tar.gz file, the router will apply the file as a configuration file update for the device and reboot afterwards.</p> <p>If the file is a .pdf, the router will assume this is a user guide document and save it to the router and make the file available for viewing via the help menu on the Web-UI.</p> <p>Note: If your download URL includes any space characters, please encode these prior to transmission according to RFC1738, for example:</p> <p><code>ftp://username:password@serveraddress/directory%20with%20spaces/filename.cdi</code></p> <p>Note: Authenticated FTP addresses may be used following the format as defined in RFC1738, for example:</p> <p><a href="ftp://username:password@serveraddress/directory/filename.cdi">ftp://username:password@serveraddress/directory/filename.cdi</a></p>

Table 18 - List of Valid SMS diagnostic commands

The following table lists valid variables where “x” is a profile number (1-6). If no profile is specified, variables are read from or written to for the current active profile. If a profile is specified, variables are read from or written to for the specified profile number (‘x’).

#	RDB VARIABLE NAME	SMS VARIABLE NAME	READ/ WRITE	DESCRIPTION	EXAMPLE VALUE
0	link.profile.x.enable link.profile.x.apn link.profile.x.user link.profile.x.pass link.profile.x.auth_type link.profile.x.iplocal link.profile.x.status	profile or profilex	RW	Profile	Read: (profile no,apn,user,pass,auth,iplocal,status)  1,internet,username,password, chap,202.44.185.111,up  Write: (apn, user, pass,auth) internet,username,password
1	link.profile.x.apn	apn or apnx	RW	APN	internet
2	link.profile.x.user	username or usernamex	RW	3G username	Guest, could also return “null”
3	link.profile.x.pass	password or passwordx	RW	3G password	Guest, could also return “null”
4	link.profile.x.auth_type	authtype or authtypex	RW	3G Authentication type	“pap” or “chap”
5	link.profile.x.iplocal	wanip or wanipx	R	WAN IP address	202.44.185.111
6	wwan.0.radio.information.signal_strength	rsi	R	3G signal strength	65 dBm
7	wwan.0.imei	imei	R	IMEI number	359102128941027512
8	statistics.usage_current	usage	R	3G data usage of current session	“Rx 500 bytes, Tx 1024 bytes, Total 1524 bytes” or “Rx 0 byte, Tx 0 byte, Total 0 byte” when wwan down
9	statistics.usage_current	wanuptime	R	Up time of current 3G session	1 days 02:30:12 or 0 days 00:00:00 when wwan down
10	/proc/uptime	deviceuptime	R	Device up time	1 days 02:30:12
11	wwan.0.system_network_status.current_b and	band	R	Current 3G frequency	WCDMA 850

Table 19 - List of SMS diagnostics variables

## Network scan and manual network selection by SMS

### Performing a network scan

The **get plmnscan** SMS command enables you to perform a scan of the cellular networks available at the time of the scan.

It returns the following semi-colon separated information for each network in range:

- 📶 MCC
- 📶 MNC
- 📶 Network Type (3G, 2G)
- 📶 Provider's Name
- 📶 Operator Status (available, forbidden, current)

The following is an example of a response from the **get plmnscan** SMS command:

```
plmnscan:505,3,7,vodafone AU,4;505,3,1,vodafone AU,1;505,2,7,YES OPTUS,1;505,2,1,YES OPTUS,1;505,1,1,Telstra  
Mobile,1;505,1,7,Telstra Mobile,1
```

NETWORK TYPE	DESCRIPTION
7	Indicates a 3G network
1	Indicates a 2G network

Table 20 - Network types returned by get plmnscan SMS command

OPERATOR STATUS	DESCRIPTION
1	Indicates an available operator which may be selected.
2	Indicates a forbidden operator which may not be selected (applies only to generic SIM cards).
4	Indicates the currently selected operator.

Table 21 - Operator status codes returned by get plmnscan SMS command



Notes about the network connection status when using the **get plmnscan** command:

If the connection status is **Up** and connection mode is **Always on**, the **get plmnscan** SMS will cause the connection to disconnect, perform the scan, send the result through SMS and then bring the connection back up again. If the connection status is **Down**, the router will perform the PLMN scan, send the result and keep the connection status down.

If the connection status is **Waiting** and connection mode is **Connect on demand**, the **get plmnscan** SMS will change the connection status to **Down**, perform the scan, send the result through SMS and then restore the connection status to the **Waiting** state.

If the connection status is **Up** and connection mode is **Connect on demand**, the **get plmnscan** SMS will cause the connection to disconnect, perform the scan, send the result through SMS, and then restore the connection status to the **Waiting** state unless there is a traffic which triggers a connection in which case the connection status will be set to **Up**.

#### Setting the router to connect to a network

The router can be instructed by SMS to connect to one of the networks returned by the **get plmnscan** command. The **set forceplmn** command forces the router to connect to a specified operator network (if available) while the **get forceplmn** command retrieves the currently configured network on the router.

Command format:

 `set forceplmn=0|MCC,MNC| MCC,MNC,Network Type`

For example:

`set forceplmn=0`

Sets the selection of operator and network type to automatic mode.

`set forceplmn=505,3`

Sets the operator to a manual selection made by the user where “505” is the Mobile Country Code for Australia and “3” is the Mobile Network Code for Vodafone. As no network type (i.e. 3G or 2G) is specified, it is selected automatically.

`set forceplmn=505,3,7`

Sets the operator and network type to a manual selection made by the user where “505” is the Mobile Country Code for Australia, “3” is the Mobile Network Code for Vodafone and “7” is the 3G network type.



Notes about the **set forceplmn** command:

If the manual selection fails, the device will fall back to the previous 'good' network.

When enabled, the SMS acknowledgement reply reflects the success or failure of the manual selection with respect to the **set** command and includes the final MNC/MCC that was configured.

Confirming the currently configured operator and network type

You can retrieve the currently configured operator and network type using the **get forceplmn** command.

The **get forceplmn** command returns the operator and network type selection mode (Automatic/Manual), in addition to the MCC and MNC values, for example:

Automatic,505,3

This response indicates that the operator/network selection mode is Automatic, and the network used is Vodafone AU.

## SMS diagnostics examples

The examples below demonstrate various combinations of supported commands. This is not an exhaustive list and serves as an example of possibilities only.

DESCRIPTION	AUTHENTICATION	INPUT EXAMPLE
Send SMS to change APN	Not required	set apn1=internet set apn2="access"
	Required	PASSWORD set apn1=internet PASSWORD set apn2=access
Send SMS to change the 3G username	Not required	set username='NetComm'
	Required	PASSWORD set username= "NetComm"
Send SMS to change the 3G password	Not required	set password= `NetComm`
	Required	PASSWORD set password= `NetComm`
Send SMS to change the 3G authentication	Not required	set authtype= 'pap'
	Required	PASSWORD set authtype = pap
Send SMS to reboot	Not required	execute reboot
	Required	PASSWORD execute reboot
Send SMS to check the WAN IP address	Not required	get wanip
	Required	PASSWORD get wanip
Send SMS to check the 3G signal strength	Not required	get rssi
	Required	PASSWORD get rssi
Send SMS to check the IMEI number	Not required	get imei
	Required	PASSWORD get imei
Send SMS to check the current band	Not required	get band
	Required	PASSWORD get band
Send SMS to Disconnect (if connected) and reconnect the 3G connection	Not required	execute pdpcycle
	Required	PASSWORD execute "pdpcycle1"
Send SMS to disconnect the 3G connection	Not required	execute pdpdown1
	Required	PASSWORD execute "pdpdown1"
Send SMS to connect the 3G connection	Not required	execute pdpup
	Required	PASSWORD execute pdpup1
Send multiple get command	Not required	get wanip; get rssi
	Required	PASSWORD get wanip; get rssi
Send multiple set command	Not required	set apn1="3netaccecss"; set password1='NetComm'
	Required	PASSWORD set APN="3netaccecss"; set password=NetComm
Send SMS to reset to factory	Not required	execute factorydefaults



default settings	Required	PASSWORD execute factorydefaults
Send SMS to retrieve status of router	Not required	get status
	Required	PASSWORD get status
Send SMS to retrieve the history of the session, including start time, end time and total data usage	Not required	get sessionhistory
	Required	PASSWORD get sessionhistory
Send SMS to configure the router to send syslog to a remote syslog server	Not required	set syslogserver
	Required	PASSWORD set syslogserver
Send SMS to wake up the router, turn on the default gateway and trigger the 'connect on demand' profile if in waiting state.	Not required	A zero byte class 1 flash SMS
Send SMS to retrieve MCC, MNC, network type, provider's name and operator status	Not required	get plmnscan
	Required	PASSWORD get plmnscan
Send SMS to retrieve current network type selection mode, MNC and MCC values.	Not required	get forceplmn
	Required	PASSWORD get forceplmn
Send SMS to force connection to a specific operator and network type	Not required	set forceplmn=505,1,7
	Required	PASSWORD set forceplmn=505,1,7
Send SMS to perform firmware upgrade when firmware is located on HTTP server	Not required	execute download <a href="http://download.com:8080/firmware_image.cdi">http://download.com:8080/firmware_image.cdi</a> execute download <a href="http://download.com:8080/firmware_image_r.cdi">http://download.com:8080/firmware_image_r.cdi</a>
	Required	PASSWORD execute download <a href="http://download.com:8080/firmware_image.cdi">http://download.com:8080/firmware_image.cdi</a> PASSWORD execute download <a href="http://download.com:8080/firmware_image_r.cdi">http://download.com:8080/firmware_image_r.cdi</a>
Send SMS to perform firmware upgrade when firmware is located on FTP server	Not required	execute download ftp://username:password@download.com:8080/firmware_image.cdi execute download ftp://username:password@download.com:8080/firmware_image_r.cdi
	Required	PASSWORD execute download ftp://username:password@download.com:8080/firmware_image.cdi PASSWORD execute download ftp://username:password@download.com:8080/firmware_image_r.cdi
Send SMS to turn off PPPoE	Not required	set pppoe=0
	Required	PASSWORD set pppoe=0
Send SMS to turn on PPPoE and set APN and service name	Not required	set pppoe=1,internet, Vodafone
	Required	PASSWORD set pppoe=1,internet, Vodafone
Send SMS to retrieve the PPPoE status, currently configured APN and service name	Not required	get pppoe
	Required	PASSWORD get pppoe
Send SMS to set the default data connection profile	Not required	set defaultprofile=1
	Required	PASSWORD set defaultprofile=1
Send SMS to retrieve the currently configured default data connection profile	Not required	get defaultprofile
	Required	PASSWORD get defaultprofile
Send SMS to set the LED mode timeout to 10 minutes	Not required	set ledmode=10
	Required	PASSWORD set ledmode=10
Send SMS to retrieve the current LED mode	Not required	get ledmode
	Required	PASSWORD get ledmode

Table 22 - SMS diagnostics example commands

# System

## Log

The Log pages are used to display or download the System log and IPSec logs on the router.

### System log

The System Log enables you to troubleshoot any issues you may be experiencing with your CDMA M2M router.

Log data is stored in RAM and therefore, when the unit loses power or is rebooted it will lose any log information stored in RAM. To ensure that log information is accessible between reboots of the router there are two options:

1. Enable the Log to non-volatile memory option
2. Use a remote syslog server

#### Enable log to non-volatile memory

When the router is configured to log to non-volatile memory, the log data is stored in flash memory, making it accessible after a reboot of the router. Up to 512kb of log data will be stored before it is overwritten by new log data. Flash memory has a finite number of program-erase operations that it may perform to the blocks of memory. While this number of program-erase operations is quite large, we recommend that you do not enable this option for anything other than debugging to avoid excessive wear on the memory.

#### Use a remote syslog server

The router can be configured to output log data to a remote syslog server. This is an application running on a remote computer which accepts and displays the log data. Most syslog servers can also save the log data to a file on the computer on which it is running allowing you to ensure that no log data is lost between reboots.

To configure the CDMA M2M Router to output log data to a remote syslog server:

1. Click on the **System** menu from the top menu bar. The System log item is displayed.
2. Click on the **Administration settings** item from the menu on the left.
3. Under the **Remote syslog server** section, enter the IP address or hostname of the syslog server in the **IP / Hostname [ :PORT ]** field. You can also specify the port number after the IP or hostname by entering a semi-colon and then the port number e.g. 192.168.1.102:514. If you do not specify a port number, the router will use the default UDP port 514.
4. Click the **Save** button to save the configuration.

#### Log file

The **Log to non-volatile memory** option, when enabled, stores the log data in a file in flash memory making it available after a reboot.

Use the **Display level** drop-down list to select a message level to be displayed. The message levels are described in the table below.

To download the System log for offline viewing, right-click the **Download** button and choose **Save as..** to save the file. To clear the System log, click the **Clear** button. The downloaded log file is in Linux text format with carriage return (CR) only at the end of a line, therefore in order to be displayed correctly with new lines shown, it is recommended to use a text file viewer which displays this format correctly (e.g. Notepad++).

### Log File

Display Level

Date & Time	Machine	Level	Process	Message
Mar 28 16:15:15	ntc_nwl11	daemon.info	dnsmasq[702]	exiting on receipt of SIGTERM
Mar 28 16:15:15	ntc_nwl11	daemon.info	dhcp_lease_update[9883]	updating lease expiry
Mar 28 16:15:15	ntc_nwl11	daemon.info	dhcp_lease_update[9883]	event = old, mac = 00:40:f4:ce:fa:1e, ip = 192.168.1.141, host = pdg26, expiry = 1364529920
Mar 28 16:15:15	ntc_nwl11	user.notice	interface.template	done
Mar 28 16:15:15	ntc_nwl11	daemon.info	dnsmasq-dhcp[702]	read /tmp/hostfiles
Mar 28 16:15:15	ntc_nwl11	daemon.info	dnsmasq[702]	read /etc/hosts - 2 addresses
Mar 28 16:15:15	ntc_nwl11	user.notice	interface.template	192.168.1.1 my.router # from link.profile.0.hostname (created by interfaces.template)
Mar 28 16:15:15	ntc_nwl11	user.notice	interface.template	127.0.0.1 localhost
Mar 28 16:15:14	ntc_nwl11	user.notice	interface.template	## /etc/hosts - HOSTNAME=my.router,ADDRESS_IP=192.168.1.1
Mar 28 16:15:14	ntc_nwl11	user.notice	interface.template	apply router host name
Mar 28 16:15:14	ntc_nwl11	user.notice	interface.template	dod disabled
Mar 28 16:15:14	ntc_nwl11	user.notice	interface.template	Captive portal interface disabled
Mar 28 16:15:14	ntc_nwl11	user.notice	interface.template	IP address changed to 192.168.1.1:255.255.255.0

Log to file

Figure 77 - System log

ITEM	DEFINITION
All	Display all system log messages.
Debug	Show extended system log messages with full debugging level details.
Info	Show informational messages only.
Notice	Show normal system logging information.
Warning	Show warning messages only.
Error	Show error condition messages only.


Table 23 - System log detail levels

## IPSec log

The IPSec log section provides the ability for you to download the log for the IPSec VPN function. This can assist in troubleshooting any problems you may have with the IPSec VPN.

Use the **Log level** drop down list to specify the type of detail you want to capture in the log and then click the **Save** button. When you change the logging level, any active IPSec VPN tunnels will be disconnected as a change in logging level requires the IPSec service to be restarted.

To download the IPSec log, click the **IPSec log download** button and you will be prompted to save the file.




*Figure 78 - IPSec log*

## System configuration

### Settings backup and restore

The settings backup and restore page is used to backup or restore the router's configuration or to reset it to factory defaults. In order to view the settings page you must be logged into the web user interface as `root` using the password `admin`. The backup and restore functions can be used to easily configure a large number of CDMA M2M router by configuring one router with your desired settings, backing them up to a file and then restoring that file to multiple CDMA M2M routers.



**Save a copy of current settings**

Password

Confirm Password

Save

**Restore saved settings**

File  Browse...

Restore

**RESTORE FACTORY DEFAULTS**

Restore Defaults

Figure 79 – Settings backup and restore

#### Back up your router's configuration

Log in to the web configuration interface, click on the **System** menu and select **Settings backup and restore**.

If you want to password protect your backup configuration files, enter your password in the fields under **Save a copy of current settings** and click on **Save**. If you don't want to password protect your files, just click on **Save**. The router will then prompt you to select a location to save the settings file.



Note: The following conditions apply:-

- It is NOT possible to edit the contents of the file downloaded; if you modify the contents of the configuration file in any way you will not be able to restore it later.
- You may change the name of the file if you wish but the filename extension must remain as “.cfg”

#### Restore your backup configuration

1. In the web configuration interface click on the **System System** menu and select **Settings backup and restore**.
2. From the **Restore saved settings** section, click on **Browse** and select the backup configuration file on your computer.
3. Click **Restore** to copy the settings to the new CDMA M2M router. The router will apply these settings and inform you it will reboot - click on **OK**.

#### Restoring the router's factory default configuration

Click the **Restore defaults** button to restore the factory default configuration. The router asks you to confirm that you wish to restore factory default settings. If you wish to continue with the restoring of factory defaults, click **OK**.




Note: All current settings on the router will be lost when performing a restore of factory default settings. The device IP address will change to 192.168.1.1 and the default username `root` and default password `admin` will be configured.

## Upload

The Upload page allows you to upload firmware files, HTTPS certificates or user created application packages to the CDMA M2M router. When firmware files have been uploaded, they can also be installed from this page. PDF files, such as this user guide may also be uploaded for access on the router's help page.

For more information on application development, contact NetComm Wireless about our Software Development Kit.



**File Uploads**

File

Uploaded Files ( Free Space: 99.0 M )

File Name	Date	Size	Action	
ntc_nwl11_trunk.42060.cdi	Mar 28 2013	24.8M	<a href="#">Install</a>	<a href="#">Delete</a>
ntc_nwl11_trunk.42060_r.cdi	Mar 28 2013	11.3M	<a href="#">Install</a>	<a href="#">Delete</a>

Figure 80 - Upload page

## Updating the Firmware

The firmware update process involves first updating the recovery image firmware, rebooting into the recovery mode of the router and then updating the main firmware image.



Note: In order to perform an update, you must be logged into the router with the root manager account (see the [Advanced configuration](#) section for more details).

To update the CDMA M2M router firmware:

1. Under the **File uploads** section, click the **Browse** button. Locate the recovery firmware image file on your computer and click **Open**.
2. Click the **Upload** button. The recovery firmware image is uploaded to the storage on the router.




Figure 81 - File upload

The recovery firmware image is listed in the **Uploaded files** section. Click the **Install** link to begin installing the recovery firmware image and then click **OK** on the confirmation window that appears.




Figure 82 - Uploaded files

- The recovery firmware image is flashed and when it is complete, the router displays “The firmware update was successful” and returns to the main Upload screen.




Figure 83 - Recovery firmware flash process

- Press and hold the reset button on the interface panel of the router for between 5 and 15 seconds until the all LEDs on the front of the router start to flash on and off then release it. The router boots into the system recovery mode.
- When the router has finished booting, navigate to <http://192.168.1.1/> in your web browser. The router recovery console is displayed.




Figure 84 - NWL Series Router Recovery Console banner

- Click the **Application installer** link from the menu bar at the top then click the **Browse** button. Locate the main firmware image file on your computer and click **Open**. Click the **Upload** button to begin the firmware upload.




Figure 85 - Recovery console - Upload main firmware image

- When the upload has completed, the screen refreshes to display the list of files on the router's storage. Click the **Install** link to the right of the main firmware image you uploaded and then click **OK** to confirm that you want to continue with the installation.
- The installation is complete when you see the words "Done" as per the screenshot below.




Figure 86 - Recovery console - installing main firmware image


- Click the **Reboot** menu item from the top menu bar then click the **Reboot** button. Click **OK** to confirm the reboot of the router. The CDMA M2M router boots up with the updated firmware.



## Software applications manager

The Software applications manager page is used to provide details of any user installed packages on the router and allow them to be uninstalled.

For more information on application development, contact NetComm Wireless about our Software Development Kit.



Package Name	Version	Architecture	Installed Time		
sshd	1.0	arm	Thursday, 28 March 2013 4:43:13 PM	<a href="#">Package details</a>	<a href="#">Uninstall</a>

Figure 87 – Software applications manager

The Application name, Version number of the application, the architecture type and time of installation are all displayed. Clicking the [Package details](#) link will display a pop-up window with further details of the package.

To uninstall any software applications, click the [Uninstall](#) link.

## Administration settings

The Administration settings page is used to enable or disable the firewall, remote access control, telnet access, ping responses and logging to a remote syslog server.

### Router Firewall

Enable Router Firewall  ON  OFF

### Remote Router Access Control

Enable HTTP  ON  OFF

Enable HTTPS  ON  OFF

Enable Telnet  ON  OFF

Enable Ping  ON  OFF

### Web User Interface Account

Username

Password

Confirm Password

### Telnet Account

Username **root**

Password

Confirm Password

### Remote Syslog Server

IP / Hostname [ :PORT ]

### LED Operation Mode

Mode

Figure 88 - Administration page

OPTION	DEFINITION
Router firewall	
Enable router firewall	<p>Enable or disable the in-built firewall on the router. When enabled, the firewall performs stateful packet inspection on inbound traffic from the wireless WAN and blocks all unknown services, that is, all services not listed on the Services configuration page of the router.</p> <p>With respect to the other Routing options on the Networking page, the firewall takes a low priority. The priority of the firewall can be described as: DMZ &gt; MAC/IP/Port filtering rules &gt; MAC/IP/Port filtering default rule &gt; Router firewall rules</p> <p>In other words, the firewall is of the lowest priority when compared to other manual routing configurations. Therefore, a MAC/IP/Port filtering rule takes priority in the event that there is a conflict of rules. When DMZ is enabled, MAC/IP/Port filtering rules and the router firewall are ignored but the router will still honour the configuration of the Remote router access control settings described below.</p>
Remote router access control	
Enable HTTP	Enable or disable remote HTTP access to the router. You can also set the port you would like remote HTTP access to be available on.
HTTP management port	Enter a port number between 1 and 65534 to use when accessing the router remotely.
Enable HTTPS	Enable or disable remote HTTPS access to the router using a secure connection.
Remote HTTPS access port	Enter a port number between 1 and 65534 to use when accessing the router remotely over an HTTPS connection.
Enable Telnet	Enable or disable remote telnet (command line) access to the router.
Enable Ping	Enable or disable remote ping responses on the WWAN connection.
Web User Interface account	
Username	Use the drop down list to select the <b>root</b> or <b>admin</b> account to change its web user interface password.
Password	Enter the desired web user interface password.
Confirm Password	Re-enter the desired web user interface password.
Telnet account	
Username	Always displays <b>root</b> as this is the only account that can be used to access the router using telnet.
Password	Enter the desired telnet access password.
Confirm Password	Re-enter the desired telnet access password.
Remote syslog server	
IP / Hostname [[:PORT]]	Enter the IP address or hostname of the syslog server. You can also specify the port number after the IP or hostname by entering a semi-colon and then the port number e.g. 192.168.1.102:514. If you do not specify a port number, the router will use the default UDP port 514.
LED operation mode	
Mode	Sets the operation mode of the LEDs on the front panel of the router. To set the lights to operate at all times, set this to <b>Always on</b> . To set the lights to turn off after a specified period, select <b>Turn off after timeout</b> .

Table 24 - Administration configuration options

To access the router's configuration pages remotely:

1. Open a new browser window and navigate to the WAN IP address and assigned port number of the router, for example <http://123.209.130.249:8080>



Note: You can find the router's WAN IP address by clicking on the "Status" menu. The Local field in the WWAN section shows the router's WAN IP address.

2. Enter the username and password to login to the router and click **Log in**.



Note: To perform functions like Firmware upgrade, device configuration backup and to restore and reset the router to factory defaults, you must be logged in with the root manager account.

## Reboot

The reboot option in the System section performs a soft reboot of the router. This can be useful if you have made configuration changes you want to implement.

To reboot the router:

1. Click the **System** menu item from the top menu bar.
2. Click the **Reboot** button from the menu on the left side of the screen.




Figure 89 - Reboot menu option

3. The router displays a warning that you are about to perform a reboot. If you wish to proceed, click the **Reboot** button then click **OK** on the confirmation window which appears.




Figure 90 - Reboot confirmation



Note: It can take up to 2 minutes for the router to reboot.

## Logging out

To log out of the router, click the  icon at the top right corner of the web user interface.

# Appendix A: Tables

Table 1 - Document Revision History .....	2
Table 2 - Device Dimensions .....	7
Table 3 - LED Indicators .....	8
Table 4 - Signal strength LED descriptions.....	9
Table 5 – Interfaces .....	10
Table 6 - PoE power classes .....	16
Table 7 - Locking power block pin outs.....	16
Table 8 - Average power consumption figures.....	17
Table 9 - Management account login details .....	18
Table 10 - Status page item details .....	21
Table 11 - Data connection item details.....	23
Table 12 - Connect on demand - Connect and disconnect timers descriptions .....	29
Table 13 - Current MAC / IP / Port filtering rules in effect .....	42
Table 14 - IPSec Configuration Items .....	45
Table 15 - SMS Setup Settings.....	68
Table 16 - Inbox/Outbox icons.....	71
Table 17 - SMS Diagnostic Command Syntax.....	76
Table 18 - List of Valid SMS diagnostic commands.....	77
Table 19 - List of SMS diagnostics variables .....	78
Table 20 - Network types returned by get plmnscan SMS command .....	79
Table 21 - Operator status codes returned by get plmnscan SMS command.....	79
Table 22 - SMS diagnostics example commands .....	81
Table 23 - System log detail levels .....	83
Table 24 - Administration configuration options .....	91
Table 25 - LAN Management Default Settings.....	97
Table 26 - Web Interface Default Settings .....	97
Table 27 - Telnet Access .....	97
Table 28 - RJ-45 connector pin outs.....	102

# Appendix B: Device Mounting Dimensions

The image below is at 100% scale and may be used as a template for mounting the device. All dimensions shown are in millimetres.




Figure 91 - Device mounting dimensions

# Appendix C: Mounting Bracket

The image below is at 100% scale and may be used as a template for mounting the bracket. All dimensions shown are in millimetres.




Figure 92 - Mounting bracket



# Appendix D: Default Settings

The following tables list the default settings for the CDMA M2M router.

LAN (MANAGEMENT)	
Static IP Address:	192.168.1.1
Subnet Mask:	255.255.255.0
Default Gateway:	192.168.1.1

*Table 25 - LAN Management Default Settings*

ADMIN MANAGER ACCOUNT		ROOT MANAGER ACCOUNT	
Username:	admin	Username:	root
Password:	admin	Password:	admin

*Table 26 - Web Interface Default Settings*



Note: The admin manager account allows you to manage all settings of the router except functions such as firmware upgrade, device configuration backup and restore and reset to factory default settings, which are privileged only to the root manager account.

CDMA M2M ROUTER TELNET ACCESS	
Username:	root
Password:	admin

*Table 27 - Telnet Access*

## Restoring factory default settings

Restoring factory defaults will reset the CDMA M2M router to its factory default configuration. You may encounter a situation where you need to restore the factory defaults on your CDMA M2M router such as:

- You have lost your username and password and are unable to login to the web configuration page;
- You are asked to perform a factory reset by support staff.

There are two methods you can use to restore factory default settings on your CDMA M2M router:

- Using the web-based user interface
- Using the reset button on the interface panel of the router

### Using the web-based user interface

To restore your router to its factory default settings, please follow these steps:

1. Open a browser window and navigate to the IP address of the router (default address is <http://192.168.1.1>). Login to the router using `root` as the User Name and `admin` as the password.
2. Click the **System** item from the top menu bar, then **System configuration** on the left menu and then click **Settings backup and restore**.
3. Under the **Restore factory defaults** section, click the **Restore defaults** button. The router asks you to confirm that you wish to restore factory defaults. Click **OK** to continue. The router sets all settings to default. Click **OK** again to reboot the router.
4. When the Power light returns to a steady red, the reset is complete. The default settings are now restored.

### Using the reset button on the interface panel of the router

Use a pen to depress the Reset button on the device for 15-20 seconds. The router will restore the factory default settings and reboot.

When you have reset your CDMA M2M router to its default settings you will be able to access the device's configuration web interface using <http://192.168.1.1> with username `admin` or `root` and password `admin`.

## Recovery mode

The CDMA M2M router features two independent operating systems, each with its own file systems. These two systems are referred to as 'Main' and 'Recovery'. It is always possible to use one in order to restore the other in the event that one system becomes damaged or corrupted (such as during a firmware upgrade failure).

Both systems have Web interfaces that can be used to manipulate the other inactive system. The CDMA M2M router starts up by default in the Main system mode, however the router may be triggered to start in recovery mode if desired.

To start the router in recovery mode:

1. Press and hold the physical reset button on the interface panel of the router for 5 to 15 seconds. When the LEDs on the front panel change to amber and countdown in a sequence, release the reset button. The router then boots into recovery mode.
2. In your browser, navigate to <http://192.168.1.1>. The router's recovery mode is hardcoded to use this address regardless of the IP address that was configured in the main system. The router's recovery console is displayed.




Figure 93 - Recovery console

The recovery console provides limited functionality. Basic status information is available, as well as access to the System log for troubleshooting. The Application Installer can be used to upload and install different firmware, allowing you to roll back to a previous firmware in the event that an upgrade fails. The Settings menu provides the ability to reset the router to factory default settings and the Reboot tab allows you to perform a soft reboot of the router.

# Appendix E: HTTPS - Uploading a self-signed certificate

If you have your own self-signed certificate or one purchased elsewhere and signed by a Certificate Authority, you can upload it to the CDMA M2M Router using the [Upload](#) page.



Note: Your key and certificate files must be named **server.key** and **server.crt** respectively otherwise they will not work.

To upload your certificate:

1. Click on the **System** item from the top menu bar. From the side menu bar, select **System configuration** and then **Upload**. The file upload screen is displayed.




Figure 94 - Upload page

2. Click the **Browse** button and locate your server certificate file and click **Open**.




Figure 95 - Browse for server.crt

- Click the **Upload** button to begin uploading it to the router. The file appears in the list of files stored on the router.




Figure 96 - Server certificate file uploaded

- Repeat steps 2 and 3 for the server key file.
- Click the **Install** link next to the server.crt file then click **OK** on the prompt that is displayed. The certificate file is installed. Repeat this for the key file. When each file is installed it is removed from the list of stored files.




Figure 97 - Installing the server.crt file

# Appendix F: RJ-45 connector

The RJ-45 connector provides an interface for a data connection and for device input power using the pin layout shown below.



Pin: 8 1

*Figure 98 - The RJ-45 connector*

PIN	COLOUR	SIGNAL (802.3AF MODE A)	SIGNAL (802.3AF MODE B)
1	White/Orange stripe	Rx +	Rx + DC +
2	Orange Solid	Rx -	Rx - DC +
3	White/Green stripe	Tx +	Tx + DC -
4	Blue solid	DC +	unused
5	White/Blue stripe	DC +	unused
6	Green solid	Tx -	Tx - DC -
7	White/Brown stripe	DC -	unused
8	Brown solid	DC -	unused

*Table 28 - RJ-45 connector pin outs*

# Safety and product care

## RF Exposure

Your device contains a transmitter and a receiver. When it is on, it receives and transmits RF energy. When you communicate with your device, the system handling your connection controls the power level at which your device transmits.

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. To ensure compliance with RF exposure guidelines the device must be used with a minimum of 20cm separation from the body. Failure to observe these instructions could result in your RF exposure exceeding the relevant guideline limits.

## External antenna

Any optional external antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operated in conjunction with any other antenna or transmitter. Please consult the health and safety guide of the chosen antenna for specific body separation guidelines as a greater distance of separation may be required for high-gain antennas.

Any external antenna gain must meet RF exposure and maximum radiated output power limits of the applicable rule section. The maximum external antenna gain including cable loss in a mobile-only exposure condition must not exceed 9.4 dBi (850MHz) and 8.4 dBi (1900MHz).

## FCC Statement

### FCC compliance

Federal Communications Commission Notice (United States): Before a wireless device model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure.

### FCC regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorientate or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



## Electrical safety

### Accessories

Only use approved accessories.

Do not connect with incompatible products or accessories.

### Connection to a car

Seek professional advice when connecting a device interface to the vehicle electrical system.

## Distraction

### Operating machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

## Product handling

You alone are responsible for how you use your device and any consequences of its use.

You must always switch off your device wherever the use of a mobile phone is prohibited. Do not use the device without the clip-on covers attached, and do not remove or change the covers while using the device. Use of your device is subject to safety measures designed to protect users and their environment.

Always treat your device and its accessories with care and keep it in a clean and dust-free place.

Do not expose your device or its accessories to open flames or lit tobacco products.

Do not expose your device or its accessories to liquid, moisture or high humidity.

Do not drop, throw or try to bend your device or its accessories.

Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.

Do not paint your device or its accessories.

Do not attempt to disassemble your device or its accessories, only authorised personnel must do so.

Do not use or install this product in extremely hot or cold areas. Ensure that the device is installed in an area where the temperature is within the supported operating temperature range (-20°C to 65°C)

Do not use your device in an enclosed environment or where heat dissipation is poor. Prolonged use in such space may cause excessive heat and raise ambient temperature, which will lead to automatic shutdown of your device or the disconnection of the mobile network connection for your safety. To use your device normally again after such shutdown, cool it in a well-ventilated place before turning it on.

Please check local regulations for disposal of electronic products.

Do not operate the device where ventilation is restricted

Installation and configuration should be performed by trained personnel only.

Do not use or install this product near water to avoid fire or shock hazard. Avoid exposing the equipment to rain or damp areas.

Arrange power and Ethernet cables in a manner such that they are not likely to be stepped on or have items placed on them.

Ensure that the voltage and rated current of the power source match the requirements of the device. Do not connect the device to an inappropriate power source.

## Small children

Do not leave your device and its accessories within the reach of small children or allow them to play with it.

They could hurt themselves or others, or could accidentally damage the device.

Your device contains small parts with sharp edges that may cause an injury or which could become detached and create a choking hazard.

## Emergency situations

This device, like any wireless device, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless device for emergency communications.

## Device heating

Your device may become warm during normal use.

# Faulty and damaged products

Do not attempt to disassemble the device or its accessories.

Only qualified personnel must service or repair the device or its accessories.

If your device or its accessories have been submerged in water punctured or subjected to a severe fall, do not use until they have been checked at an authorised service centre.

## Interference

Care must be taken when using the device in close proximity to personal medical devices, such as pacemakers and hearing aids.

### Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15cm be maintained between a device and a pacemaker to avoid potential interference with the pacemaker.

### Hearing aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby.

The level of interference will depend on the type of hearing device and the distance from the interference source, increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

### Medical devices

Please consult your doctor and the device manufacturer to determine if operation of your device may interfere with the operation of your medical device.

### Hospitals

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

### Interference in cars

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of devices in their vehicles unless an external antenna is included in the installation.

## Explosive environments

### Petrol stations and explosive atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your device or other radio equipment.

Areas with potentially explosive atmospheres include fuelling areas, below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders.

### Blasting caps and areas

Turn off your device or wireless device when in a blasting area or in areas posted turn off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.