


NTNV-N77-3700-3980-PC2-30-90-L-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-90-L-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-L-DFT-QPSK-Edge_1RB_


Right-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-90-L-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-M-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-M-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-PI2BPSK-Edge_1R
B_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS





NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-90-H-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1

RB_Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1

RB_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1


RB_Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1


RB_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1
RB_Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1
RB_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1
RB_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1
RB_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1

RB_Right-Ant1-PASS


NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1

RB_Right-Ant1-PASS





NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1

RB_Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-L-DFT-PI2BPSK-Edge_1

RB_Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_

Left-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_

Right-Ant1-PASS




NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS





NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS





NTNV-N77-3700-3980-PC2-30-100-L-DFT-QPSK-Edge_1RB_ Right-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-M-DFT-PI2BPSK-Edge_1
RB_Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-100-M-DFT-PI2BPSK-Edge_1
RB_Left-Ant1-PASS



NTNV-N77-3700-3980-PC2-30-100-M-DFT-PI2BPSK-Edge_1
RB_Left-Ant1-PASS

NTNV-N77-3700-3980-PC2-30-100-M-DFT-PI2BPSK-Edge_1
RB_Left-Ant1-PASS