





## 43" LED FHD TV

# USER MANUAL



Model No.: KC4325AO



### **IMPORTANT**

Please read this manual carefully before installing and operating the TV.

Keep this manual handy for further reference

# Table of Contents

|                                                 |    |
|-------------------------------------------------|----|
| <b>Safety warning</b> .....                     | 1  |
| <b>Important Safety Instructions</b> .....      | 2  |
| <b>Preparation for Your New TV</b> .....        | 3  |
| Check Accessories .....                         | 3  |
| Stand Installation Guide .....                  | 3  |
| <b>Wall mount specification</b> .....           | 4  |
| <b>TV Jacks Explanation</b> .....               | 5  |
| <b>External Device Connection Diagram</b> ..... | 6  |
| <b>Side Keypad and Front Panel</b> .....        | 7  |
| Keypad Buttons .....                            | 7  |
| Front Panel .....                               | 7  |
| <b>Remote Control Instructions</b> .....        | 8  |
| Inserting Batteries in the Remote .....         | 8  |
| Remote Control Reception Angle .....            | 8  |
| <b>Learning about Remote Control</b> .....      | 9  |
| Remote Control Buttons .....                    | 9  |
| <b>Basic Operations</b> .....                   | 10 |
| Turning On and Off .....                        | 10 |
| Select input source .....                       | 10 |
| Adjust the OSD Screen .....                     | 10 |
| <b>OSD Menu Operations</b> .....                | 11 |
| Menu Setting .....                              | 11 |
| Smart TV Operation .....                        | 12 |
| Media Operation .....                           | 12 |
| <b>Troubleshooting</b> .....                    | 13 |
| Identifying Problems .....                      | 13 |
| <b>Specification</b> .....                      | 14 |

---

*\* The pictures, functions and other information provided in the manual are for reference only.  
If it does not match the actual object, please refer to the actual product.*

---

# Safety warning



## CAUTION

**RISK OF ELECTRIC SHOCK  
DO NOT OPEN**



Caution: To reduce the risk of electric shock, do not remove cover or back. No user-serviceable parts inside. Refer servicing to qualified service personnel.



The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the TV.

**WARNING:** TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

**CAUTION:** CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE WITH THE FCC RULES COULD AVOID THE USERS AUTHORITY TO OPERATE THIS EQUIPMENT.

## Safety Warning

Before operating the unit, please read through this manual.

### PLACEMENT

- Do not place the unit on an unstable cart, stand, tripod, bracket, table, or shelf.
- Do not expose the unit to direct sunlight and other sources of heat.
- Do not handle liquids near or on the unit.
- Never spill liquid of any kind into the unit
- Do not put the unit near appliances that create magnetic fields.
- Do not put heavy objects on top of the unit.

### TEMPERATURE

- Do not place the unit near or over a radiator or a heater register.
- If your unit is suddenly moved from a cold to a warm place, unplug the power cord for at least two hours so that moisture that may have formed inside the unit can dry completely.

### HUMIDITY

- Do not expose machine in rain, damp or place near water.
- Ensure the indoor drying, cool.

### VENTILATION

- Keep the ventilation openings clear.

### WARNING(Only applicable to models over 7kg)

Never place a television set in an unstable location. A television set may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- Using cabinets or stands recommended by the manufacturer of the television set.
  - Only using furniture that can safely support the television set.
  - Ensuring the television set is not overhanging the edge of the supporting furniture.
  - Not placing the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television set to a suitable support.
  - Not placing the television set on cloth or other materials that may be located between the television set and supporting furniture.
  - Educating children about the dangers of climbing on furniture to reach the television set or its controls.
- If your existing television set is being retained and relocated, the same considerations as above should be applied.

# Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water. For example, do not use near a laundry tub, in a wet basement, or near a swimming pool, and the like.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet back or bottom are provided for ventilation, to ensure reliable operation of the TV and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the TV on a bed, sofa, rug, or other similar surface.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over. A TV and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the TV and cart combination to overturn.
13. Unplug this apparatus during lightning storms or when unused for long periods of time. For added protection for this TV receiver during a lightning storm, or when it is left unused for long periods of time, unplug it from the wall outlet and disconnect antenna or cable system. This will prevent damage to the TV due to lightning and power line surges.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. This TV should be operated only from the type of power supply indicated on the rating label. If customer is not sure the type of power supply in your home, consult your appliance dealer or local power company. For TV remote control battery power, refer to the operating instructions.
16. The TV set shall not be exposed to dripping or splashing. No objects filled with liquids, such as vases, shall be placed on the TV set.
17. Never push objects of any kind into this TV through openings as they may touch dangerous voltage or other electrical parts that could result in fire or electric shock. Never spill liquid of any kind into the TV.
18. Unplug the TV from the wall outlet before cleaning. Do not use liquid or aero cleaners. Use a damp cloth for cleaning.
19. This TV should never be placed near or over a radiator or heat resource. This TV should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
20. Do not place this TV on an unstable cart, stand, tripod, bracket, or table. The TV may fall, causing serious injury to someone, and serious damage to the appliance.
21. Do not attempt to service this TV by yourself because opening or removing covers may expose you to dangerous high voltage or other hazards. Refer all servicing to qualified service personnel.
22. Please do the static electricity prevention and panel protect measures before overhaul, avert damage the panel and main board sensitive element, ex. IC etc.
23. **WARNING:** To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.




# Preparation for Your New TV

## Check Accessories


Check the accessories that are packed with your TV.




LED TV



Remote Control & Batteries



TV Stand Base  
+  
4 x Screws




User's manual  
+  
Warranty Card


## Stand Installation Guide

The TV is packaged with the TV stand separated from the cabinet. To setup the TV table stand, please carry out the installation according to the instructions below.

1. The panel can be scratched easily, so please:  
Place a soft cloth on the table and place the TV face down on the cloth.  
Note: Always unplug the AC cord first when installing/removing the stand.
2. Take the base. Please align the screw holes of the base and the TV, and then insert the screws into the holes on the base and tighten them.  
Note: To ensure that the TV is stable, please lock all screws.



Please take note of the base direction:




The bottom view of the TV  
(Front cabinet faces down)

(The illustration is for reference only, Please prevail in kind)

## Wall Mounting(if available)

| Unit Dimension (unit:mm) | Screws       |
|--------------------------|--------------|
| VESA 200x200             | M4x8mm, 4pcs |


**Note:** The length of the screw specified is only a recommendation; actual length required can vary depending on the type of wall mount used.



### Warnings:

1. Do not set up the wall mount by yourself. Please contact qualified professionals for installation.
2. The TV should not be mounted on walls or surfaces which have an angle more than 10 degrees with vertical direction. Otherwise the TV set may fall.
3. The walls for mounting must have enough strength to hold the whole weight of TV set. For example, concrete wall and brickwork are eligible. Do not place the mount on soft walls such as earth walls and plasterboard.
4. If spare parts of different specifications (such as screws) are used during mounting, consult with qualified professionals to make sure these parts are safe and effective.
5. Before attaching the base to wall, ensure the holes for anchors are in keeping with the installing rules. Otherwise there may exist some potential problems.
6. Do not place any heating source under your television. Or else, it can cause fire.
7. Do not place the TV near anything dripping. Transducers and high voltage wires should be kept far away from the apparatus too. Or else, it may cause creepage, electric shock or bad resonance.
8. Do not place TV in a location where collision or vibration is liable to happen.
9. In order to avoid unexpected falling of the TV set, do not put any strong force on TV or wall mount after installing.
10. Be sure to unplug the TV before installing. Keep anything hard or sharp away from the screen panel to prevent the scuffing.
11. After installing, if there is any need to move the cabinet, please contact the qualified professionals.

# TV Jacks Explanation



①

HDMI1/ARC

HDMI2

CVBS

L

R

USB1

USB2

②

OPTICAL

Earphone

RJ45

RF

**HDMI:** (High-Definition Multimedia Interface) Provides an uncompressed digital connection.

**CVBS :** Connect an AV device that has composite video jacks, such as a VCR or DVD Player.

**L:** Left audio channel connection. The left audio connector is usually white.

**R:** Right audio channel connection. The right audio connector is usually red.

**USB:** Connect the USB device such as the flash disk to access the TV media function.


**OPTICAL:** Digital TV sound output.

**EARPHONE:** Connect a 3.5mm headset for personal audio.

**RJ45:** Connect the internet.

**RF:** Connect to receive the signal from your antenna or cable through a coaxial cable.


# External Device Connection Diagram



# Side Keypad and Front Panel

## Keypad Buttons

If you cannot locate your remote, you can use the side keypad buttons on your TV to operate many TV features.




\*The OSD menu image is subject to the actual display.

- POWER(⏻):**
1. When the TV is on, press this button once to open the menu bar.
  2. Press the button again to move the cursor from left to right, step by step. You can adjust it as needed.
  3. Press and hold the button to select the desired option. The screen will pop up with the relevant menu. short press to select  $\wedge/\vee$  or  $+/-$  icon, then long press to select options in the pop-up menu.
  4. After selecting the menu you want to adjust, you need to move the cursor to the source (  ) icon and long press button to enter the menu.
  5. Press and hold button to exit setting.
  6. Repeat 2-5 for other options.
  7. Please note: The setting menu will automatically turn off if there is no operation within 10 seconds.

## Front Panel

**Power/Standby Indicator:** White and indicator off. It shows White when the TV is standby and indicator off when turned on.

**Remote Control Sensor:** Remote control IR sensor, which receives infrared ray sent by remote control.



**NOTE:** If there is a protective film around the screen, remove the protective film before using the TV.

# Remote Control Instructions

## Inserting Batteries in the Remote

1. Remove the battery compartment cover from the back of the remote control by lifting the cover.
2. Insert 2AAA batteries ,making sure the polarities(+and-) are aligned correctly.
3. Replace the cover.

### If the remote control does not work, check these points:

- Are the polarities (+, -) correct?
- Are the batteries worn out?
- Is there an AC power failure?
- Is the power cord plugged in?
- Is there any interference or block near the remote control sensor?


### CAUTION:

- Used batteries should be recycled.
- Keep out of children's reach.
- DO NOT use new and old batteries together.
- Change both the batteries at the same time.
- When not using the remote control for a long time, remove the batteries from the unit.


**Warning:** All batteries (packed or in use) must not be exposed to high temperature like sun heat or fire.

## Remote Control Reception Angle

Use your remote control within the distance and angle range shown below.



# Learning about Remote Control



## Remote Control Buttons

**POWER**(): Turns the TV on or off.

**MUTE**(): Reduces the TV volume to its minimum level. Press again to restore the volume.

**NUMBER BUTTONS**: Press 0-9 select a TV channel directly when you are watching TV.

“” : To switch the channel digit.

**Recall**(): Returns to the previous channel.

**SLEEP**: Selects the sleep timer, after which the TV will shut off automatically.

**AUDIO**: Switch the audio channel in DVD or multimedia mode.

**FAV**: Show favorite channel list.

**HOME**: Press to open Android home page.

**MOUSE**: Switches to the mouse mode.

**NETFLIX**: Press this key to access the netflix site.

**YouTube**: Press this key to access the YouTube site..

**INPUT**: To select input source menu.

**INFO**: To display the current program information on the screen.

**Arrows**(///): Uses the four arrows to highlight different items in the TV menu or change the value.

**OK**: Enter and confirm button.

**MENU**: Accesses the Main Menu, or return to the upper level of a sub-menu.

**EXIT**: Exits the current menu or function.

**VOL+ or VOL-**: Increases or decreases the TV volume.

**ASPECT**: Switches between the preset screen size mode.

**P.MODE**: Switches between the preset picture mode.

**S.MODE**: Switches between the preset sound mode.

**CH ^ or CH v** :Scans up or down through the current channel list

**RED/GREEN/YELLOW/BLUE**: Use add-on functions in OSD menu.

 : Stop the media files.

 : play or pause media files.

  : Fast review and fast forward.

  : Select the previous or the next media file.

**CC/SUB-T**: Selects the closed caption.

Press to select sub-title of media video file.

**EPG**: Shows Electronic Program Guide.

**PRTSC**: Print Screen.

## NOTE:


- ◆ All pictures in this manual are examples, only for reference, actual product may differ from the pictures.
- ◆ The buttons not mentioned here are not used.

# Basic Operations

## Turning On and Off

Connect the AC cord to power the TV. At this time the TV will enter standby mode and power indicator will turn white. Use Power button(  ) on the TV or on the remote control to turn on the TV. After switching off the TV for 5 seconds, you can turn on TV again.

## Select input source



Press **INPUT** button to display the input source list;

Press **▲/▼** button to select the input source you want to watch;

Press **OK** button to enter the input source;

## Adjust the OSD Screen


- Press **MENU** button to display the MAIN OSD MENU;
- Press **▲/▼** button to select the **MENU** you want;
- Press **OK** button to enter the sub menu, and press **EXIT** button to return back to the previous menu.
- Press **▲/▼** button to select the option and then press **OK** or **▶** button to enter the submenu, press **◀/▶** button to adjust the value or press **◀/▶** button to select in the sub-menu;

You can press **MENU** button to save and return back to the previous menu, and press **EXIT** button to exit the entire menu.

# OSD Menu Operations

## Menu Setting

Press **MENU** button to display the MAIN OSD MENU:



**Picture:** Used for TV picture effect adjusting.  
For example: Picture mode, Color Temp and so on.

**Sound:** Used for TV sound effect adjusting.  
For example: Sound Mode, Balance and so on.

**Channel:** Used for channel searching and edit, it's only available in TV input.  
You can choose to automatically search, or choose to manually search according to your needs.

**Lock:** Used for TV Lock effect adjusting.  
For example: System Lock, Change Password and so on.

**Note:** If the System Lock is on, please input the password to unlock, default password is **0000**.

**Settings:** Used for TV settings.  
For example: HDMI CEC, Time, Blue Screen and so on.

*For more settings, please refer to the menu settings.*