

## QUICK START GUIDE

### Ceiling Mount Wireless Access Point

#### Packing List

- 1 x AP
- 1 x Power Adapter
- 1 x PoE Module (Optional)
- 1 x Quick Start Guide
- 1 x Warranty Card
- 1 x Accessories Kit

SN: 0902-0001-005

## 1 Product Overview

Thank you for choosing the UTT Ceiling Mount Wireless Access Point (hereinafter as "Device").

The UTT WA Series Ceiling Mount AP is a best-in-class indoor Access Point specifically designed for business-class wireless network such as hotel, cafe, lounge, shopping mall, restaurant and school. The available models are WA1700N, WA1900N, WA2200N, WA2500N and etc.

With a standard install design and stylish appearance, the Device can be installed on wall or ceiling without hassle. Powered with integrated 802.3af Power over Ethernet standard (passive PoE for WA1700N), it allows installation in areas where power outlets are not readily available.

The Device can also be managed by UTT WX Series WiFi Controller when working in FIT Mode. The WX Series WiFi Controller User Guides are available for download at [www.uttglobal.com/download/](http://www.uttglobal.com/download/).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and 2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

## 2 Hardware Overview




LED/Button/Interface	Description
WLAN	After the Device is powered on and wireless enabled, the WLAN LED indicator will blink when transmitting/receiving wireless data.
Link/Act	When a device is connected to a port properly, the port's corresponding LED indicator will be on. The indicator will blink when there's traffic on that port.
SYS	The LED indicator blinks twice per second when the system is operating properly, and it will blink slower if the system is under heavy load.
Reset	With the Device powered on, press the Reset button with a bent paperclip for 5 seconds until the WLAN LED indicator goes off, and then release the button. After that, the AP will restart itself and reset the device to factory default settings.
LAN	The LAN interfaces provide a LAN connection to network devices, such as PCs or switches.
PoE	You may use this Ethernet interface to power the Device. Power can be provided by an UTT PoE Switch or a 802.3af PoE injector.
Power	The Power interface is where you connect the provided power adapter.
2.4G	The 2.4G LED indicator is on when 2.4GHz Wireless is enabled. The LED indicator blinks when transmitting/receiving 2.4G wireless data.
5G	The 5G LED indicator is on when 5GHz Wireless is enabled. The LED indicator blinks when transmitting/receiving 5G wireless data.




Address: 3F, Building 9, No.518 Xinzhuang Road, Caohejing  
Songjiang Hi-Tech Park, Shanghai 201612, P. R. China  
Phone: +86 21-67766519, 67766527  
Global Sales Office Number: +1(626)722-5032  
Fax: +86 21-67766518  
Email: [uttglobal@utt.com.cn](mailto:uttglobal@utt.com.cn)  
Skype Support: uttglobal  
Official Website: [www.uttglobal.com](http://www.uttglobal.com)  
©2016 UTT Technologies Co., Ltd. All rights reserved.

## 3 Hardware Installation


- Place the mounting bracket in the center of the ceiling tile. Mark the mounting screw holes and 25 mm hole for the Ethernet cable. Use a drill bit to drill the screw holes, and cut or drill the 25 mm hole for the Ethernet cable feed.
- Secure the Mounting Bracket to the ceiling tile by using the Expansion Bolts. Then feed the Ethernet cable through the 25 mm hole.
- Connect the Ethernet cable to the Ethernet port of the Device.



- Align the notch on the Device with the notch on the mounting bracket.



- Turn the Device clockwise until it locks into place.




## 4 Configuring the Device

### NOTE:

- Please assign your computer a static IP address within the same range as the Device's IP address (192.168.1.253 by default). See more on Appendix: Computer Configuration.
- If there is DHCP server on the local area network, the Device will obtain an IP address automatically.

- Launch a web browser, such as Internet Explorer or Mozilla Firefox. In the Address field enter the Device's IP Address (192.168.1.253) and press the Enter key.

- Enter the default user name of admin and password of admin in the User Name and Password fields. Click "OK" to access the Device's Web GUI.







**NOTE:** The Device works in FIT AP Mode by default. You can go to "Start→Device Mode" to change the Device Mode to FAT AP Mode.

## Appendix: Computer Configuration




### Windows XP

- Click "My Network Places", choose "Properties".
- Click "Local Area Connection", choose "Properties".
- Double click "Internet Protocol (TCP/IP)".
- Select "Use the following IP address", enter the static IP address ( a free IP address in 192.168.1.0/24) in IP address field, 255.255.255.0 in Subnet mask field, and enter the IP address of your default gateway in Default Gateway field. Click "OK" to finish the configuration.



### Windows 7

- Click "Start→ Control Panel→ Network and Internet→ Network and Sharing Center→ Change Adapter Settings". Right click "Local Area Connection" and select "Properties".
- Double click "Internet Protocol Version 4 (TCP/IPv4)" to open the Internet Protocol Version 4(TCP/IPv4) Properties window.
- Select "Use the following IP address", enter the static IP address (a free IP address in 192.168.1.0/24) in IP address field, 255.255.255.0 in Subnet mask field, and enter the IP address of your default gateway in Default Gateway field. Click "OK" to finish the configuration.



Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

**FCC Radiation Exposure Statement**

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.