

# COMMSCOPE<sup>®</sup>

## ION<sup>®</sup>-U

H 7P/80-85P/17(E)P/19P  
Remote Unit



Manual  
MF0200A8D

**DISCLAIMER:**

This document has been developed by CommScope, and is intended for the use of its customers and customer support personnel. The information in this document is subject to change without notice. While every effort has been made to eliminate errors, CommScope disclaims liability for any difficulties arising from the interpretation of the information contained herein. The information contained herein does not claim to cover all details or variations in equipment, nor to provide for every possible incident to be met in connection with installation, operation, or maintenance. This document describes the performance of the product under the defined operational conditions and does not cover the performance under adverse or disturbed conditions. Should further information be desired, or should particular problems arise which are not covered sufficiently for the purchaser's purposes, contact CommScope.

CommScope reserves the right to change all hardware and software characteristics without notice.

**COPYRIGHT:**

© Copyright 2016 CommScope Inc. All Rights Reserved.

This document is protected by copyright. No part of this document may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical photocopying, recording, or otherwise without the prior written permission of CommScope.

**TRADEMARKS**

All trademarks identified by ® or ™ are registered trademarks or trademarks, respectively, of CommScope. Names of products mentioned herein are used for identification purposes only and may be trademarks and / or registered trademarks of their respective companies.

Andrew Wireless Systems GmbH, 20-January-2017

**TABLE OF CONTENTS**

<b>1. GENERAL</b>	<b>6</b>
1.1. USED ABBREVIATIONS	6
1.2. HEALTH AND SAFETY	7
1.3. PROPERTY DAMAGE WARNINGS	7
1.4. COMPLIANCE	8
1.5. ABOUT COMMSCOPE	12
1.6. INTERNATIONAL CONTACT ADDRESSES FOR CUSTOMER SUPPORT	13
<b>2. INTRODUCTION</b>	<b>15</b>
2.1. PURPOSE	15
2.2. ION-U HIGH POWER REMOTE UNITS	15
<b>3. FUNCTIONAL DESCRIPTION</b>	<b>16</b>
<b>4. COMMISSIONING</b>	<b>17</b>
4.1. GENERAL	17
<b>4.2. HIGH POWER RU MECHANICAL INSTALLATION</b>	<b>17</b>
4.2.1. Health and Safety for mechanical installation	17
4.2.2. Property Damage Warnings for mechanical installation	17
4.2.3. Wall mounting procedure	19
4.2.4. Pole mounting procedure with screw bands	20
4.2.5. Pole mounting procedure with brackets	21
<b>4.3. ELECTRICAL INSTALLATION</b>	<b>23</b>
4.3.1. Health and Safety for electrical installation	23
4.3.2. Property Damage Warnings for electrical installation	23
4.3.3. Connections	24
4.3.4. Grounding (Earthing)	27
4.3.5. Connection of the antenna cable	28
4.3.6. Cleaning procedure for RF cable connectors	29
4.3.7. Antenna cable connector assembly	32
4.3.8. Mains power connection	33
4.3.8.1. Mains power connection AC	33
4.3.8.2. Mains power connection DC	35
4.3.9. Extension Unit port connection	37
4.3.10. External alarm In / Out port	38
4.3.11. RS 485 /+28 V port	38
4.3.12. Local interface port	39
4.3.13. Coupling probe	39
4.3.14. Optical-fiber cable connection	40
4.3.15. Assembly instructions for optical LC patch cables	42
4.3.15.1. Assemble optical Opus short plug components	43

---

4.3.15.2.	Connect Opus short plug to RU	45
4.3.15.3.	Disconnect Opus short plug from RU	46
4.3.16.	Optional equipment for optical fiber connection	46
<b>4.4.</b>	<b>COMMISSIONING FLOW-CHART</b>	<b>47</b>
<b>5.</b>	<b>ALARMS</b>	<b>49</b>
<b>5.1.</b>	<b>BITE AND ALARMS</b>	<b>49</b>
<b>5.2.</b>	<b>TROUBLESHOOTING</b>	<b>49</b>
<b>5.3.</b>	<b>STATUS LED ALARMS</b>	<b>49</b>
<b>5.4.</b>	<b>EXTERNAL ALARM INPUTS AND OUTPUTS</b>	<b>50</b>
<b>6.</b>	<b>MAINTENANCE</b>	<b>51</b>
<b>6.1.</b>	<b>GENERAL</b>	<b>51</b>
<b>6.2.</b>	<b>REPLACING THE FAN UNIT</b>	<b>52</b>
<b>6.3.</b>	<b>CLEANING THE HEAT SINK</b>	<b>53</b>
<b>7.</b>	<b>APPENDIX</b>	<b>54</b>
<b>7.1.</b>	<b>ILLUSTRATIONS</b>	<b>54</b>
<b>7.2.</b>	<b>SPECIFICATIONS</b>	<b>55</b>
<b>7.3.</b>	<b>SPARE PARTS</b>	<b>55</b>
<b>7.4.</b>	<b>LIST OF CHANGES</b>	<b>55</b>
<b>8.</b>	<b>INDEX</b>	<b>56</b>

**FIGURES AND TABLES**

figure 3-1 ION-U High Power RU block diagram..... 16

figure 4-1 Wall mounting - pitches..... 19

figure 4-2 Pole mounting - pitches..... 20

figure 4-3 Pole mounting - screw bands..... 20

figure 4-4 Pole mounting - fasten RU..... 20

figure 4-5 Pole mounting – max. diameter ..... 21

figure 4-6 Pole mounting – with brackets ..... 21

figure 4-7 Pole mounting - pitches..... 22

figure 4-8 Pole mounting - brackets ..... 22

figure 4-9 Pole mounting - fasten RU..... 22

figure 4-10 ION-U H 7P/80-85P/17(E)P/19P AC version connector flange..... 24

figure 4-11 ION-U H 7P/80-85P/17(E)P/19P DC version connector flange..... 26

figure 4-12 Grounding bolts..... 27

figure 4-13 Grounding bolt, schematic view ..... 27

figure 4-14 Mains power connector..... 34

figure 4-15 Mains power cable - AC..... 34

figure 4-16 EU connector and cable bridge..... 37

figure 4-17 Mounting the EU cable bridge..... 37

figure 4-18 Alarm connector..... 38

figure 4-19 RS485 /+28 VDC connector..... 38

figure 4-20 Local interface connector..... 39

figure 4-21 Contents of the Opus short plug kit..... 42

figure 4-22 LC/APC patch cable requirements..... 42

figure 4-23 Opus short plug clamp and nut..... 43

figure 4-24 Simplex split gasket ..... 43

figure 4-25 Duplex split gasket ..... 43

figure 4-26 Simplex cavity A..... 44

figure 4-27 Duplex cavity A & B..... 44

figure 4-28 Assemble Opus short plug..... 44

figure 4-29 Insert LC connector plug into plug body ..... 44

figure 4-30 Tighten Opus short plug adapter nut..... 45

figure 4-31 Remove Opus short plug protective cap..... 45

figure 4-32 Insert Opus short plug into RU receptacle..... 45

figure 4-33 Disconnect Opus short plug from RU..... 46

figure 4-34 Optional pigtail kit..... 46

figure 5-1 Alarm inputs and outputs ..... 50

figure 7-1 ION-U H 7P/80-85P/17(E)P/19P required space..... 54

table 4-1 Specified torques..... 18

table 4-2 ION-U H RU connectors..... 25

table 4-3 AC power cable pinning ..... 34

table 4-4 Alarm connector pinning..... 38

table 4-5 RS485/+28V pinning ..... 38

table 4-6 Local interface connector pinning..... 39

# 1. General

## 1.1. Used Abbreviations

AC/DC	Alternating current / Direct Current	NF	Noise Figure
AIMOS	Andrew Integrated Management and Operating System	OMC	Operations and Maintenance Center
ALC	Automatic Level Control	OTRx	Optical Transceiver
BITE	Built-In Test Equipment	PIM	Passive Intermodulation
BTS	Base Transceiver Station	P <sub>in</sub>	Input power
		P <sub>out</sub>	Output power
CDMA	Code Division Multiple Access	Rev	Revision
CE	"Conformité Européenne" ("European Conformity")	RF	Radio Frequency
CFR	Code of Federal Regulations	RU	Remote Unit
		RX	Receiver
DL	Downlink	SISO	Single Input Single Output
DoC	Declaration of Conformity	SNMP	Simple Network Management Protocol
EP	Extension Port		
ESD	Electrostatic Discharge	TX	Transmitter
EU	Extension Unit		
		UL	Uplink
GSM	Global System for Mobile Communication	UMTS	Universal Mobile Telecommunication System
GND	Ground (Earth)	UPS	Uninterruptible Power Supply
GUI	Graphical User Interface		
		VSWR	Voltage Standing Wave Ratio
ICP3	Intercept Point 3 <sup>rd</sup> order	WCDMA	Wideband Code Division Multiple Access
ID No	Identification Number	WDM	Wavelength Division Multiplex
ION	Intelligent Optical Network	XML	Extensible Markup Language
LED	Light Emitting Diode		
LMT	Local Maintenance Terminal		
LTE	Long Term Evolution		
MIMO	Multiple Input Multiple Output		
MS	Mobile Station		
MU	Main Unit		

## 1.2. Health and Safety



1. **Danger:** Electrical hazard. Danger of death or fatal injury from electrical current. Obey all general and regional installation and safety regulations relating to work on high voltage installations, as well as regulations covering correct use of tools and personal protective equipment.



2. **Danger:** Electrical hazard. Danger of death or fatal injury from electrical current inside the unit in operation. Before opening the unit, disconnect mains power.



3. **Caution:** Laser radiation. Risk of eye injury in operation. Do not stare into the beam; do not view it directly or with optical instruments.



4. **Caution:** High frequency radiation in operation. Risk of health hazards associated with radiation from the unit's inner conductor of the antenna port(s). Disconnect mains before connecting or replacing antenna cables.



5. **Caution:** High frequency radiation in operation. Risk of health hazards associated with radiation from the antenna(s) connected to the unit. Implement prevention measures to avoid the possibility of close proximity to the antenna(s) while in operation.

## 1.3. Property Damage Warnings

1. **Attention:** Due to power dissipation, the Remote Unit may reach a very high temperature. Do not operate this equipment on or close to flammable materials. Use caution when servicing the unit.

2. **Attention:** Only authorized and trained personnel are allowed to open the unit and get access to the inside.

3. **Notice:** Although the Remote Unit is internally protected against overvoltage, it is strongly recommended to ground (earth) the antenna cables close to the antenna connectors of the Remote Unit for protection against atmospheric discharge. In areas with strong lightning, it is strongly recommended to install additional lightning protection.



4. **Notice:** ESD precautions must be observed. Before commencing maintenance work, use the available grounding (earthing) system to connect ESD protection measures.

5. **Notice:** Only suitably qualified personnel are allowed to work on this unit and only after becoming familiar with all safety notices, installation, operation and maintenance procedures contained in this manual.

6. **Notice:** Keep operating instructions within easy reach and make them available to all users.

7. **Notice:** Read and obey all the warning labels attached to the unit. Make sure that all warning labels are kept in a legible condition. Replace any missing or damaged labels.
8. **Notice:** Only license holders for the respective frequency range are allowed to operate this unit.
9. **Notice:** Make sure the repeater settings are correct for the intended use (refer to the manufacturer product information) and regulatory requirements are met. Do not carry out any modifications or fit any spare parts, which are not sold or recommended by the manufacturer.

## 1.4. Compliance

1. **Notice:** For installations which have to comply with European EN50385 exposure compliance requirements, the following Power Density limits/guidelines (mW/cm<sup>2</sup>) according to ICNIRP are valid:
  - 0.2 for frequencies from 10 MHz to 400 MHz
  - $F \text{ (MHz)} / 2000$  for frequencies from 400 MHz to 2 GHz
  - 1 for frequencies from 2 GHz to 300 GHz
2. **Notice:** For installations, which have to comply with FCC RF exposure requirements, the antenna selection and installation must be completed in a way to ensure compliance with those FCC requirements. Depending on the RF frequency, rated output power, antenna gain, and the loss between the repeater and antenna, the minimum distance D to be maintained between the antenna location and human beings is calculated according to this formula:

$$D_{[cm]} = \sqrt{\frac{P_{[mW]}}{4 * \pi * PD_{[mW/cm^2]}}}$$

where

- P (mW) is the radiated power at the antenna, i.e. the max. rated repeater output power in addition to the antenna gain minus the loss between the repeater and the antenna.
- PD (mW/cm<sup>2</sup>) is the allowed Power Density limit acc. to 47 CFR 1.1310 (B) for general population / uncontrolled exposures which is
  - $F \text{ (MHz)} / 1500$  for frequencies from 300MHz to 1500MHz
  - 1 for frequencies from 1500MHz to 100,000MHz

RF exposure compliance may need to be addressed at the time of licensing, as required by the responsible FCC Bureau(s), including antenna co-location requirements of 1.1307(b)(3).



- 3. Notice:** Installation of this equipment is in full responsibility of the installer, who has also the responsibility, that cables and couplers are calculated into the maximum gain of the antennas, so that this value, which is filed in the FCC Grant and can be requested from the FCC data base, is not exceeded. The industrial boosters are shipped only as a naked booster without any installation devices or antennas as it needs for professional installation.
- 4. Notice:** For installations which have to comply with FCC/Industry Canada requirements:
- English:**  
This device complies with FCC Part 15 and Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
- This device complies with Health Canada's Safety Code. The installer of this device should ensure that RF radiation is not emitted in excess of the Health Canada's requirement. Information can be obtained at [http://www.hc-sc.gc.ca/ewh-semt/pubs/radiation/radio\\_guide-lignes\\_direct-eng.php](http://www.hc-sc.gc.ca/ewh-semt/pubs/radiation/radio_guide-lignes_direct-eng.php).
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- French:**  
Cet appareil est conforme à FCC Partie 15 d'Industrie Canada RSS standard exempts de licence (s). Son utilisation est soumise à Les deux conditions suivantes: (1) cet appareil ne peut pas provoquer d'interférences et (2) cet appareil doit accepter Toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement du dispositif.
- Cet appareil est conforme avec Santé Canada Code de sécurité 6. Le programme d'installation de cet appareil doit s'assurer que les rayonnements RF n'est pas émis au-delà de l'exigence de Santé Canada. Les informations peuvent être obtenues: [http://www.hc-sc.gc.ca/ewh-semt/pubs/radiation/radio\\_guide-lignes\\_direct-fra.php](http://www.hc-sc.gc.ca/ewh-semt/pubs/radiation/radio_guide-lignes_direct-fra.php)
- Les changements ou modifications non expressément approuvés par la partie responsable de la conformité pourraient annuler l'autorité de l'utilisateur à utiliser cet équipement.
- 5. Notice:** Corresponding local particularities and regulations must be observed. For national deviations, please refer to the respective documents included in the manual CD that is delivered with the unit.

- 6. Notice:** The unit complies with Overvoltage Category II. It also complies with the surge requirement according to EN 61000-4-5 (fine protection); however, installation of an additional medium (via local supply connection) and/or coarse protection (external surge protection) is recommended depending on the individual application in order to avoid damage caused by overcurrent.

For Canada and US, components used to reduce the Overvoltage Category shall comply with the requirements of IEC 61643-series. As an alternative, components used to reduce the Overvoltage Category may comply with ANSI/IEEE C62.11, CSA Certification Notice No. 516, CSA C22.2 No. 1, or UL 1449. Suitability of the component for the application shall be determined for the intended installation.

- 7. Note:** For a Class A digital device or peripheral:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

- 8. Note:** For a Class B digital device or peripheral:


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference.

- 9. Note:** This unit complies with European standard EN60950.

- 10. Note:** The Manufacturer's rated output power of this equipment is for single carrier operation. For situations when multiple carrier signals are present, the rating would have to be reduced by 3.5 dB, especially where the output signal is reradiated and can cause interference to adjacent band users. This power reduction is to be by means of input power or gain reduction and not by an attenuator at the output of the device.

**Equipment Symbols Used / Compliance**

Please observe the meanings of the following symbols used in our equipment and the compliance warnings:

<b>Symbol</b>	<b>Compliance</b>	<b>Meaning / Warning</b>
---	<b>FCC</b>	Unit is for FCC Part 20 purposes - COMMERCIAL MOBILE SERVICES – only. WARNING: This is NOT a CONSUMER device. It is designed for installation by FCC LICENSEES and QUALIFIED INSTALLERS. You MUST have an FCC LICENSE or express consent of an FCC Licensee to operate this device. Unauthorized use may result in significant forfeiture penalties, including penalties in excess of \$100,000 for each continuing violation.
	<b>CE</b>	Alert sign to R&TTE To be sold exclusively to mobile operators or authorized installers – no harmonized frequency bands, operation requires license. Intended use: EU and EFTA countries
<b>CE 0700</b>		Indicates conformity with the R&TTE directive 1999/5/EC certified by the notified body no. 0700.

## 1.5. About CommScope

*CommScope* is the foremost supplier of one-stop, end-to-end radio frequency (RF) solutions. Part of the *CommScope* portfolio are complete solutions for wireless infrastructure from top-of-the-tower base station antennas to cable systems and cabinets, RF site solutions, signal distribution, and network optimization. For patents see [www.cs-pat.com](http://www.cs-pat.com).

*CommScope* has global engineering and manufacturing facilities. In addition, it maintains field engineering offices throughout the world.

*Andrew Wireless Systems GmbH* based in Buchdorf/ Germany, which is part of *CommScope*, is a leading manufacturer of coverage equipment for mobile radio networks, specializing in high performance, RF and optical repeaters. Our optical distributed networks and RF repeater systems provide coverage and capacity solution for wireless networks in both indoor installations and outdoor environments, e.g. tunnels, subways, in-trains, airport buildings, stadiums, skyscrapers, shopping malls, hotels and conference rooms.

*Andrew Wireless Systems GmbH* operates a quality management system in compliance with the requirements of ISO 9001 and TL 9000. All equipment is manufactured using highly reliable material. To maintain highest quality of the products, comprehensive quality monitoring is conducted at all fabrication stages. Finished products leave the factory only after a thorough final acceptance test, accompanied by a test certificate guaranteeing optimal operation.

This product meets the requirements of the R&TTE directive and the Declaration of Conformity (DoC) itself. A current version of the CE DoC is included in this manual CD delivered \*. Any updated version of the DoC is available upon request from the local sales offices or directly from *CommScope* via the local Customer Support at one of the addresses listed in the following chapter.

**According to the DoC, our "CE"-marked equipment can be used in all member states of the European Union.**

**Note: Exceptions of and national deviations from this intended use may be possible. To observe corresponding local particularities and regulations, please refer to the respective documents (also in national language) which are included in the manual CD delivered.**

\* In case the Declaration of Conformity (DoC) for the product was not included in the manual CD delivered, it is available upon request from the local sales offices or directly from *CommScope* at one of the addresses listed in the following chapter.

To make the most of this product, we recommend you carefully read the instructions in this manual and commission the system only according to these instructions.

For technical assistance and support, please also contact the local office or *CommScope* directly at one of the addresses listed in the following chapter.

## 1.6. International Contact Addresses for Customer Support

<p style="text-align: center;"><b>Canada</b></p> <p style="text-align: center;"><b>CommScope Canada</b></p> <p>Mail 505 Consumers Road, Suite 803 Toronto M2J 4V8, Canada</p> <p>Phone +1-905-878-3457 (Office) +1-416-721-5058 (Cell)</p> <p>Fax +1-905-878-3297</p> <p>E-mail wisupport@commscope.com</p>	<p style="text-align: center;"><b>United States</b></p> <p style="text-align: center;"><b>Andrew LLC, A CommScope Company</b></p> <p>Mail 620 North Greenfield Parkway Garner, NC 27529, U.S.A.</p> <p>Phone +1-888-297-6433</p> <p>Fax +1-919-329-8950</p> <p>E-mail wisupport@commscope.com</p>
<p style="text-align: center;"><b>Caribbean &amp; South American Region</b></p> <p style="text-align: center;"><b>CommScope Cabos do Brasil Ltda.</b></p> <p>Mail CALA Tech Support for <i>Distributed Coverage &amp; Capacity Solutions (DCCS) products:</i> Rua Guaporanga, 49 Praça Seca – Rio de Janeiro – RJ ZIP: 21320-180, Brazil</p> <p>Phone +1-815-546-7154 (Cell) +55-15-9104-7722 (Office)</p> <p>Fax + 55-15-2102-4001</p> <p>E-mail wisupport@commscope.com</p>	<p style="text-align: center;"><b>Caribbean &amp; Central American Region</b></p> <p style="text-align: center;"><b>CommScope Mexico S.A. de C.V.</b></p> <p>Mail CALA Tech Support for <i>Distributed Coverage &amp; Capacity Solutions (DCCS) products:</i> Av. Insurgentes Sur 688, Piso 6 Col. Del Valle, CP: 03100 Mexico City, Mexico</p> <p>Phone +52-55-1346-1900 (Office)</p> <p>Fax +52-55-1346-1901</p> <p>E-mail wisupport@commscope.com</p>
<p style="text-align: center;"><b>China, India and Rest of Asia</b></p> <p style="text-align: center;"><b>Andrew International Corporation</b></p> <p>Mail Room 915, 9/F Chevalier Commercial Centre 8 Wang Hoi Rd Kowloon Bay, Hong Kong</p> <p>Phone +852-3106-6100</p> <p>Fax +852-2751-7800</p> <p>E-mail wisupport.China@commscope.com</p>	<p style="text-align: center;"><b>Australia &amp; New Zealand</b></p> <p style="text-align: center;"><b>Andrew Corporation (Australia) Pty Ltd.</b></p> <p>Mail Unit 1 153 Barry Road Campbellfield VIC 3061, Australia</p> <p>Phone +613-9300-7969</p> <p>Fax +613-9357-9110</p> <p>E-mail wisupport.Australia@commscope.com</p>
<p style="text-align: center;"><b>Middle East &amp; North Africa</b></p> <p style="text-align: center;"><b>CommScope Solutions International Inc. (Branch)</b></p> <p>Mail PO Box 48 78 22 Unit 3206, Floor 32, Jumeirah Business Center 5, Jumeirah Lakes Towers, Dubai, United Arab Emirates</p> <p>Phone +971 4 390 09 80</p> <p>Fax +971 4 390 86 23</p> <p>E-mail wisupport@commscope.com</p>	<p style="text-align: center;"><b>South Africa</b></p> <p style="text-align: center;"><b>Andrew Wireless Solutions Africa (PTY) LTD</b></p> <p>Mail 11 Commerce Crescent West Eastgate, Sandton PO Box 786117 Sandton 2146 South Africa</p> <p>Phone + 27 11-719-6000</p> <p>Fax + 27 11-444-5393</p> <p>E-mail wisupport@commscope.com</p>

**A  
M  
E  
R  
I  
C  
A  
  
A  
P  
I  
A  
C  
  
A  
f  
r  
i  
c  
a  
&  
M  
i  
d  
d  
l  
e  
E  
a  
s  
t**

<b>United Kingdom</b>		<b>Scandinavia</b>
<p><b>Andrew Wireless Systems UK Ltd</b></p> <p>Unit 15, Ilex Building Mulberry Business Park Mail Fishponds Road Wokingham Berkshire RG41 2GY, England</p> <p>Phone +44-1189-366-792 Fax +44-1189-366-773 E-mail wisupport.uk@commscope.com</p>		<p><b>Andrew Norway (AMNW)</b></p> <p>P.O. Box 3066 Osloveien 10 Mail Hoenefoss 3501 Norway</p> <p>Phone + 47 32-12-3530 Fax + 47 32-12-3531 E-mail wisupport@commscope.com</p>
<b>Germany</b>		<b>France</b>
<p><b>Andrew Wireless Systems GmbH</b></p> <p>Industriering 10 Mail 86675 Buchdorf Germany</p> <p>Phone +49-9099-69-0 Fax +49-9099-69-930 E-mail wisupport@commscope.com</p>	<b>EUROPE</b>	<p><b>CommScope France</b></p> <p>Immeuble Le Lavoisier Mail 4, Place des Vosges 92052 Courbevoie, France</p> <p>Phone +33-1 82 97 04 00 Fax +33-1 47 89 45 25 E-mail wisupport@commscope.com</p>
<b>Austria</b>		<b>Switzerland</b>
<p><b>Andrew Wireless Systems (Austria) GmbH</b></p> <p>Weglgasse 10 Mail 2320 Wien-Schwechat Austria</p> <p>Phone +43-1706-39-99-10 Fax +43-1706-39-99-9 E-mail wisupport.austria@commscope.com</p>		<p><b>CommScope Wireless Systems AG</b></p> <p>Tiergartenweg 1 Mail CH-4710 Balsthal Switzerland</p> <p>Phone +41-62-386-1260 Fax +41-62-386-1261 E-mail wisupport.ch@commscope.com</p>
<b>Italy</b>		<b>Iberia Region - Spain &amp; Portugal</b>
<p><b>CommScope Italy S.r.l., Faenza, Italy</b></p> <p>Via Mengolina, 20 Mail 48018 Faenza (RA) Italy</p> <p>Phone +39-0546-697111 Fax +39-0546-682768 E-mail wisupport.italia@commscope.com</p>		<p><b>Andrew España S.A. A CommScope Company</b></p> <p>Avda. de Europa, 4 - 2ª pta. Mail Parque Empresarial de la Moraleja Alcobendas, Madrid 28108, Spain</p> <p>Phone +34-91-745-20 40 Fax +34-91-661-87 02 E-mail wisupport.iberia@commscope.com</p>
<b>Czech Republic</b>		
<p><b>CommScope Solutions Czech Republic C-Com, spol. s r.o</b></p> <p>U Moruší 888 Mail 53006 Pardubice, Czech Republic</p> <p>Phone +49 871 9659171 (Office) +49 171 4001166 (Mobile) Fax +49 871 9659172 E-mail wisupport@commscope.com</p>		

## 2. Introduction

### 2.1. Purpose

Mobile telephone systems transmit signals in two directions between base transceiver station (BTS) and mobile stations (MS) within the signal coverage area to carry voice and data traffic.

If weak signal transmissions occur within the coverage area because of indoor applications, topological conditions or distance from the transmitter, extension of the transmission range can be achieved by means of an optical distributed antenna system (DAS).

Office buildings, sports arenas, college campuses, industrial parks, and other areas of high demand require the specialized capacity boost that an optical DAS can provide to meet increasing customer demands for voice and data.

An optical DAS contains optical Master Units and a sufficient number of Remote Units to provide the necessary coverage. The number of the Remote Units depends on the coverage requirements of the DAS. The Remote Units are connected to the Master Unit with optical links.

The Master Unit is the connection to the Base Transceiver Stations. The configuration of a Master Unit depends on the number of the Remote Units and the frequency range.

RF signals are transported to and from the Remote Units via optical fibers.

### 2.2. ION-U High Power Remote Units

The ION-U is an optical fiber based DAS system that efficiently takes the outputs of multiple Base Transceiver Stations (BTS) sectors and converts those RF signals to optical to send them over fiber optic cables to Remote Units to provide coverage in indoor and outdoor locations. The system supports both low power and high power remotes units and SISO and MIMO operation.

The ION-U H 7P/80-85P/17(E)P/19P is a multi-band, multi-operator Remote Unit used in conjunction with a Master Unit in the ION optical distribution system. This system transports up to five frequency bands simultaneously (700 MHz, 800/850 MHz, 1700/2100 MHz, and 1900 MHz), providing a cost-effective solution for distributing capacity from one or more base stations.

It has been specifically tested and optimized for GSM, EDGE, CDMA, UMTS, HSPA+, LTE, and other OFDM modulations. Furthermore it is provisioned for future modulation scheme evolutions.

These Remote Units feature independent downlink and uplink gain adjustments and an integrated channel power detector for in-band spectrum and PIM analysis and end-to-end auto leveling.



The unit utilizes a single fiber to support multiple bands in both the uplink and downlink directions. WDM (Wave Division Multiplex) filters are integrated in the optical modules. For the UL, a wavelength within 1546 nm – 1550 nm is used. For the DL, a wavelength of 1310  $\pm$ 10 nm is used. The maximum optical output power for the UL and DL is 6.7 mW.

### 3. Functional Description




figure 3-1 ION-U High Power RU block diagram

In the Downlink (DL) path, the Remote Unit provides:

- Optical to RF conversion of the input optical signal
- Automatic Gain Control (AGC) of each converted signal to compensate for optical losses
- RF amplification of the converted RF signal for transmission while maintaining an excellent signal-to-noise ratio
- RF filtering to reject spurious emissions

In the Uplink (UL) path, the Remote Unit provides:

- RF amplification to boost the signals received by the antennas to maintain an excellent signal-to-noise ratio
- RF filtering to reject spurious emissions
- Automatic Level Control (ALC) to adjust the RF signal level to meet blocking requirements
- RF-to-optical conversion of the signal, which is conveyed to the optical port

The Remote Unit can be paired with further EUs (Extension Unit) to provide additional bands.



## 4. Commissioning

### 4.1. General

Read and observe chapter 1.2 Health and Safety as well as the description carefully to avoid mistakes and proceed step by step as described.

- Do not operate the Remote Unit without terminating the antenna connectors. The antenna connectors may be terminated by connecting them to their respective antennas or to a dummy load.
- Only qualified personnel should carry out the electrical, mechanical, commissioning, and maintenance activities that require the unit to be powered on when open.
- When opening the Remote Unit do not damage the warranty labels on the internal devices. The warranty is void if the seals are broken.
- One of the three mounting kits has to be ordered separately. They are not contained within the standard equipment. See chapter 7.3 Spare Parts.

Unless otherwise agreed to in writing by CommScope, CommScope's general limited product warranty (<http://www.commscope.com/Resources/Warranties/>) shall be the warranty governing the Remote Units, including the installation, maintenance, usage and operation of the Remote Units.

### 4.2. High Power RU Mechanical Installation

#### 4.2.1. Health and Safety for mechanical installation

Read and observe chapter 1.2 Health and Safety.



1. **Caution:** Risk of injury by the considerable weight of the unit falling. Ensure there is adequate manpower to handle the weight of the system.




2. **Caution:** Risk of serious personal injury by equipment falling due to improper installation. The installer must verify that the supporting surface will safely support the combined load of the electronic equipment and all attached hardware and components. The screws and dowels (wall anchors) used should also be appropriate for the structure of the supporting wall.

#### 4.2.2. Property Damage Warnings for mechanical installation

1. **Attention:** Do not install the unit in a way or at a place where the specifications outlined in the Environmental and Safety Specifications leaflet of the supplier are not met.
2. **Attention:** Due to power dissipation, the Remote Unit may reach a very high temperature. Ensure sufficient airflow for ventilation.
3. **Notice:** Exceeding the specified load limits may cause the loss of warranty.
4. **Notice:** When connecting and mounting the cables (RF, optical, mains, ...) ensure that no water can penetrate into the unit through these cables.

5. **Notice:** Ensure that there is free access to the electrical connections as well as to the cabinet. The approved bending radius of the connected cables must not be exceeded. See chapter 7.1 for more details.
6. **Notice:** If any different or additional mounting material is used, ensure that the mounting remains as safe as the mounting designed by the manufacturer. The specifications for stationary use of the Remote Unit must not be exceeded. Ensure that the static and dynamic strengths are adequate for the environmental conditions of the site. The mounting itself must not vibrate, swing or move in any way that might cause damage to the Remote Unit.
7. **Notice:** Observe all additional rules or restrictions regarding mounting that apply to specific Remote Unit types. For details refer to the mechanical specifications in the data sheet for the unit. Install the unit vertically with the fan unit at the top. A maximum tilt angle of 25° from a vertical position must be maintained, as shown in the following illustrations:



8. **Notice:** A spacing of 50 mm (1.97 inch) around the unit is required.
9. **Notice:** To ensure sufficient airflow when mounting the unit in enclosed spaces, two lid openings (one for the air inlet and the other for the air outlet) must be provided. Do not block these air inlets and outlets when mounting the Remote Unit. The size of each opening must equal at least 18 x 18 cm (> 300 cm<sup>2</sup>). Ensure that there is no thermal short circuit between the air inlet and air outlet. Make sure free airflow is not deflected or otherwise obstructed.

Specified torques must be observed for certain mounting procedures according to the following table:

Type	Tallow-drop screws	Hex nuts	Screw band lock	Spacing bolts		PG (plastic)	PG (alum.)
Thread	M 4	M 8		M 4	M 8	PG 13.5	PG 29
Specified torques	3.3 N-m	27 N-m	6 N-m	2.3 N-m	27 N-m	3.75 N-m	10 N-m

table 4-1 Specified torques

### 4.2.3. Wall mounting procedure

**Notice:** It is the responsibility of the installer to verify that the supporting surface will safely support the combined load of the electronic equipment and all attached hardware and components and to ensure that the RU is safely and securely mounted.

1. Mark the position of the drilling holes (for pitches refer to figure 4-1 Wall mounting). Drill four holes at the marked positions and insert dowels\*.
2. Mount the brackets (A) to the wall using the M8x80 screws (B), split lock washers (C), and washers (D).





figure 4-1 Wall mounting - pitches

3. Hang the Remote Unit into the upper bracket, insert it to the lower bracket, and fasten it to the lower bracket with the M8x25 screws (E), split lock washers (F), and washers (G).

\* The dowels are not included with the delivery because the suitable type depends on the on-site conditions (material of wall).

### 4.2.4. Pole mounting procedure with screw bands

Standard mounting hardware cannot be used to mount the Remote Unit to a pole, a column, or other similar structures. Additional hardware must be used for this type of installation. The pole-mounting kit includes

- two mounting brackets with screw bands, (worm gear) clamps to mount the brackets to the pole
- and two M8x25 screws, flat washers, and split lock washers per bracket to attach the Remote Unit to the bracket.




figure 4-2 Pole mounting - pitches




figure 4-3 Pole mounting - screw bands




figure 4-4 Pole mounting - fasten RU

1. Use two screw bands (B) for the upper and one for the lower bracket to fasten the two brackets (A) to the pole.
2. Place the bands around the pole or post and feed the loose end into the lock and tighten the slotted screw securely. When the screw is turned clockwise, it acts as a worm drive pulling the threads of the band causing the band to tighten around the pole.

**Note:** When fastening the brackets make sure that they are installed congruently and not at an angle to each other. To determine the distance between the clamps refer to figure 4-2 Pole mounting - pitches.

3. Hang the Remote Unit into the upper bracket, insert it into the lower bracket, and fasten it to the lower bracket with the M8x25 screws (C), split lock washers (D) and washers (E), see chapter 4.2.3.

The maximum diameter of the pole or column must not exceed 120 mm (4.7 inch).




figure 4-5 Pole mounting – max. diameter

#### 4.2.5. Pole mounting procedure with brackets

The pole-mounting kit with brackets includes

- two mounting brackets (A), two counter brackets (B), four threaded bolts (C), flat (F) and split lock (G) washers, hexagon (E) and locking (D) nuts to mount the brackets to the pole
- and two M8x25 screws (H), flat (F) and split lock (G) washers to attach the Remote Unit to the bracket.




figure 4-6 Pole mounting – with brackets




figure 4-7 Pole mounting - pitches




figure 4-8 Pole mounting - brackets




figure 4-9 Pole mounting - fasten RU

1. Apply this procedure to both mounting brackets on both sides:  
Screw a hexagon nut (E) to the threaded bolt and place a flat washer (F) on it. Insert this side of the bolt into the mounting bracket (A). Then, fasten the mounting bracket with a flat washer (F), split lock washer (G), and the locking nut (D). See figure 4-6 Pole mounting – with brackets.
  2. Place the pre-mounted brackets with threaded bolts to the pole or post, slide the counter bracket (B) on the threaded bolts and fasten the kit with a flat washer (F), split lock washer (G), and the locking nut (D).
- Note:** When fastening the brackets make sure that they are installed congruently and not at an angle to each other. To determine the distance between the clamps refer to figure 4-7 Pole mounting - pitches.
3. Hang the Remote Unit into the upper bracket, insert it into the lower bracket (see chapter 4.2.3), and fasten it to the lower bracket with the M8x25 screws (H), split lock washers (G), and flat washers (F).

The diameter of the pole or column must be in the range from 65 to 120 mm (2.6 to 4.7 inch).

## 4.3. Electrical Installation

### 4.3.1. Health and Safety for electrical installation

Read and observe the notices in chapter 1.2 Health and Safety.



1. **Danger: Electrical hazard. Danger of death or fatal injury from electrical current. Obey all general and regional installation and safety regulations relating to work on high voltage installations, as well as regulations covering correct use of tools and personal protective equipment.**

### 4.3.2. Property Damage Warnings for electrical installation

1. **Attention:** It is compulsory to ground (earth) the unit before connecting the power supply. Grounding bolts are provided on the cabinet to connect the ground-bonding cable.
2. **Attention:** If the mains connector of the Remote Unit is not easily accessible, a disconnect device in the mains power circuit must be provided within easy reach.
3. **Attention:** A connection of the mains supply to a power socket requires the power socket to be nearby the Remote Unit.
4. **Attention:** Before connecting or disconnecting the mains connector at the Remote Unit, ensure that mains power supply is disconnected.
5. **Attention:** Make sure that an appropriate circuit breaker acting as a disconnect device (as required by IEC/EN60950-1) and an overcurrent limiting device are connected between mains power and the Remote Unit.
6. **Attention:** Incorrectly wired connections can destroy electrical and electronic components.
7. **Notice:** To avoid corrosion at the connectors caused by electrochemical processes, the material of the cable connectors must not cause a higher potential difference than 0.6 V (see electrochemical contact series).
8. **Notice:** Use an appropriate torque wrench for the coupling torques:
  - for 7/16 DIN-type (25 N-m / 19 ft lb) with 1 ¼ in opening, e. g. item no. 244377 available from the CommScope e-catalog
  - for 4.3-10 type connectors (5 N-m, 44 in lb) with 22mm (7/8) in opening, e.g. item no. TW-4310

Do NOT use your hands or any other tool (e.g. a pair of pliers). This might cause damage to the connector and lead to a malfunction of the Remote Unit.

9. **Notice:** For unstabilized electric networks, which frequently generate spikes, the use of a voltage limiting device is advised.
10. **Notice:** Observe the labels on the front panels before connecting or disconnecting any cables.
11. **Notice:** Unused connectors must be closed with their protective covers to ensure water tightness.



**4.3.3. Connections**

The ION-U RU ports and connectors shown in the following are located at the base of the RU.




figure 4-10 ION-U H 7P/80-85P/17(E)P/19P AC version connector flange



ION-U High Power RU Connectors/Indicators			
	Port/Conn	Purpose	Type
(A)	EXPANSION	This connector is used to interconnect to an Extension Unit to provide additional bands of coverage.	Radiall Opus M424400-003
(B)	EXTERNAL ALARM IN/OUT	This connector provides two alarm contact inputs and two alarm contact outputs.	Binder 712 series 8-pin
(C)	RS 485 / +28V	This connector provides RS 485 communications and +28 VDC power (500 mA)	Binder 712 series 5-pin
(D)	LOCAL INTERFACE	This port is used for a local connection to a laptop PC.	RJ45
(E)	ANT	This connector is used for transmitting and receiving signals to and from an antenna, antenna splitter, or cross-band coupler.	4.3-10 type female
(F)	STATUS	This LED provides a visual warning of an alarm condition. The color of the LED indicates the severity of the alarm.	LED
(G)	OPTICAL	This connector is used to connect an optical fiber cable to receive downlink signals from and to send uplink signals back to the OTRx module of the ION-U Master Unit.	LC/APC8°
(H)	PROBE	This connector is used as measurement probe to antenna port.	QMA
(I)	Grounding Bolts	Ground (earth) bolts for connecting the mandatory ground cable to the RU	M6 bolts, hex nut, & washers
(J)	MAINS	This connector provides the power to RU models that use standard AC (100 to 240 Vac) power.	Coninvers M17 –Series P20, 4-Pin

table 4-2 ION-U H RU connectors



figure 4-11 ION-U H 7P/80-85P/17(E)P/19P DC version connector flange

ION-U High Power RU Connectors/Indicators			
	Port/Conn	Purpose	Type
	All, except MAINS	The connectors and indicators for the AC and the DC version are identical except for the MAINS connector.	
(J)	MAINS	This connector provides the power to RU models that use standard DC (-60 to -48 Vdc) power.	M6 bolts, hex nut, & washers

#### 4.3.4. Grounding (Earthing)

The RU must be grounded (earthed).

When double grounding lugs are used they must support M6 studs with a stud hole spacing of 15.88 mm (5/8").

1. Connect an earth-bonding cable to one or both of the grounding bolt connections provided on the connector flange of the Remote Unit. Do not use the grounding connection to connect external devices.



figure 4-12 Grounding bolts




figure 4-13 Grounding bolt, schematic view

2. After loosening the hex nut(s), connect the earth-bonding cable between the two washers as illustrated in the figures above.
3. Then, fasten all parts again by tightening the hex nut(s).
4. Connect the other end of the ground wire to a suitable permanent ground.

**Note:** Ground of a second unit (for example RU + EU) has to be connected to the same equipotential bonding terminal as the Remote Unit. Use bonding cables of the same length, as short as possible, and with a large wire cross section. Follow local electrical code practices.

### 4.3.5. Connection of the antenna cable

The Remote Unit has one 4.3-10 type antenna connector labeled “ANT”.

When attaching the antenna cable connector, it is recommended to refer to the corresponding documentation of the connector manufacturer. The bending radius of the antenna cable must remain within the given specifications.

The selection of cable and antenna is an important consideration. On the one hand, a cable with higher loss is less expensive but, on the other hand, it impairs performance.

**Notice:** Use an appropriate torque wrench for the coupling torques:

- for 7/16 DIN-type (25 N-m / 19 ft lb) with 1 ¼ in opening, e. g. item no. 244377 available from the *CommScope e-catalog*
- for 4.3-10 type connectors (5 N-m, 44 in lb) with 22 mm (7/8) in opening, e.g. item no. TW-4310

Do NOT use your hands or any other tool (e.g. a pair of pliers). This might cause damage to the connector and lead to a malfunction of the Remote Unit.

**Attention:** To minimize passive inter-modulation (PIM) distortion, attention has to be paid to the physical condition of the connector junctions:

- Do not use connectors that show signs of corrosion on the metal surface.
- Prevent the ingress of water or dirt into the connector.
- Use protective caps for the connectors when not mounted.
- Before mounting clean the connectors with dry compressed air.
- Before mounting clean the mating surfaces of the connector with a lint-free alcohol-drenched cloth on a wooden or non-metallic item.
- Attach and torque the connectors properly.
- Avoid metallic abrasion when mounting the connectors by only screwing the connecting nut, but not turning the whole connector.
- Use a torque wrench to fasten the connector, see above.
- Clean the protective caps before mounting for antenna cable replacement.


### 4.3.6. Cleaning procedure for RF cable connectors


The figures in this chapter illustrate the cleaning procedure and do not show the actual RU.

1. What is needed for the cleaning?
  - a. Isopropyl alcohol
  - b. Compressed air
  - c. Lint-free wipe
  - d. Cotton buds





2. Remove protective cap from the RF connector.




 **Caution:** Risk of injury by flying particles when compressed air is used. Wear protective clothing, especially protective glasses.


3. Remove metal chips and small particles from the mating and inner surfaces of the connector using compressed air.



 **Warning:** Flammable material. Risk of fire. Keep away from sources of ignition.

 **Caution:** Eye irritant product. Risk of eye irritation. Avoid contact with eyes and skin. Wear protective clothing, especially protective glasses.

4. Clean the connector winding with lint-free wipe drenched with isopropyl alcohol.







5. Clean the lip of the inner ring with a cotton bud drenched with isopropyl alcohol.




6. Clean the inside surface of the inner ring with a cotton bud drenched with isopropyl alcohol.



7. Clean the inside of the center conductor spring tines with a cotton bud drenched with isopropyl alcohol.



8. Clean in the similar way the connector of the connected cable. Remove protective caps from the unit connector first.



9. Remove metal chips and small particles from the mating and inner surfaces of the connector using compressed air.




10. Continue with the winding area using lint-free wipe drenched with isopropyl alcohol.



11. Continue with the inside mating surface of the inner ring.



12. Clean the outside surface of the center pin.



### 4.3.7. Antenna cable connector assembly

1. What is needed for the connector assembly?
  - a. Torque wrench.
  - b. (Adjustable) counter wrench



B0409ACA

2. Join the connectors and turn the coupling nut until the thread grips.



B0409ADA

3. Push in the connector until it clicks.



B0409AFA



4. Fasten the coupling nut hand-tight. Do not turn the connector but the coupling nut only.



B0409AGA



5. Retain the cable connector with the counter wrench and fasten the coupling nut with the torque wrench until the torque is applied (torque wrench clicks).



For angled antenna connectors use your hand to retain the cable connector and fasten the coupling nut with the torque wrench. Make sure only the coupling nut is turned, not the cable connector.

### 4.3.8. Mains power connection

Before connecting electrical power to the unit, the system must be grounded as described in the previous chapter.

Mains power must be connected at the mains connector of the unit.

#### 4.3.8.1. Mains power connection AC

1. Take the Mains power cable that was delivered with the RU.
2. Locate or install a suitable power junction box or receptacle near the RU and route the power cable from the power source to the RU. Do not connect the cable to the RU's Mains connector at this time. The power source must be interruptible.
3. The Mains cable must be properly secured observing local regulations and electrical codes. Be sure to allow enough slack in the cable at the RU to plug or unplug the cable into the Mains connector of the RU.
4. Wire the power cable to the junction box or receptacle. Refer to the color code and pin numbers shown in figure 4-15 (AC cable), and table 4-3.
5. With the cable's Mains plug disconnected from the RU, turn the circuit breaker on, unscrew the plug's protective cover, and carefully test the plug with a voltmeter to ensure that the voltage and polarity are correct.
6. Once the testing has been completed, turn off the circuit breaker.
7. Unscrew the protective cover from the Mains connector of the RU (figure 4-14).
8. Insert the plug into the Mains connector and tighten the clamping ring until it is hand tight. Do not over-tighten the clamping ring.




figure 4-14 Mains power connector





figure 4-15 Mains power cable - AC

The Mains cable is part of the delivery. It's available in two wiring configurations:



Wiring 1		
Pin	Name	Color
1	Phase	Black
2	Neutral	White
3	n.c.	n.c
PE	Ground	Green

Wiring 2		
Pin	Name	Color
1	Phase	Brown
2	Neutral	Blue
3	n.c.	n.c
PE	Ground	Green/Yellow

table 4-3 AC power cable pinning

**For the AC power supply connection, a minimum cross section of 1.5 mm<sup>2</sup> is required. Each wire must observe the applicable national regulations regarding loop impedance, voltage drop, and methods of installation. Make sure to connect the correct voltage to the unit.**

**Note:** Do not connect or disconnect the power cord at the mains connector while power is on. Turn off mains\* power before connecting the power cord at the Remote Unit, then, engage mains again.

\* Mains power must be interrupted with an external mains breaker. For the mains breaker, observe the following recommendation:

120 Volt / 20 Amp max. or 240 Volt / 16 Amp, single-phase, 50 / 60 Hz AC service is needed, i.e. the external AC breaker should be 20 Amps max. for 120-Volt service or 13 - 16 Amps for 240-Volt service.

## 4.3.8.2. Mains power connection DC



**Caution:** Danger of electrical hazard by high current. Disconnect mains power before opening the DC connector housing.


**Note:** The Mains cable must be properly secured observing local regulations and electrical codes. Be sure to allow enough slack in the cable at the RU to mount or dismount the cable into the DC Mains connector of the RU.

Unscrew the two M3 x 12 captive screws and take off the cover from the DC Mains connector housing. At the RU housing the cover is inserted into a recess, so first lift the cover at the front and carefully pull it out from the recess.


Then remove the rubber plug.



Double lug DC cable connectors need to be M6 with a stud hold spacing of 15.88 mm (5/8").



First, install a conduit fitting (not contained in scope of delivery) to the 34.52 mm hole. This must be a suitable fitting for a 1 Inch conduit with lock nut. Inside, the clearance around the hole is 5 mm, the maximum space for the nut is 8 mm. Then, insert your wiring through the opening and mount it to the M6 mains terminals. Observe the correct polarity. Close the conduit fitting to ensure water tightness. For strain release, two M5 threaded holes are provided; the distance between the threaded holes is 34.5 mm.



Mount the housing cover by inserting it into the recess at the repeater cabinet and fastening the two M3 x 12 captive screws.

**Attention:** For the DC power supply connection, a minimum cross section of  $6.6 \text{ mm}^2$  ( $\leq$  AWG 9) per potential is required. Each wire must observe the applicable national regulations regarding loop impedance, voltage drop, and methods of installation. Make sure to connect the correct voltage to the unit. To ensure water-tightness of the unit, use the correct size of cable gland.


**Note:** Do not connect or disconnect the power cord at the mains connector while power is on. Turn off mains\* power before connecting the power cord at the Remote Unit, then, engage mains again.

\* Mains power must be interruptible with an external mains breaker (40 A). For the mains breaker, observe the local regulations of the DC provider.

### 4.3.9. Extension Unit port connection

The Expansion connector is used to connect a cable bridge to an optional Extension Unit to provide additional bands of coverage. This port provides control and RF signaling to and from the Extension Unit.

**Attention:** The cable bridge connector is a push-pull connector. Ensure not to insert it at an angle into the EU connector. The connector coupler has to be inserted before the Pin-holder is pushed in. Otherwise the connectors might be damaged.



The cable bridge connector provides two notches, the EU connector two noses.



figure 4-16 EU connector and cable bridge




figure 4-17 Mounting the EU cable bridge

Take the cable bridge connector at the connector coupler and insert it carefully to the EU connector. Use the green markings to align the connector, turn it without pressure until the noses catch the notches and carefully push it at right angle into the connector.

Then take the cable bridge connector (Pin-holder) and push it into the EU connector until the lock clicks. The red 'UNLOCK' marking must be completely covered by the connector coupler.

### 4.3.10. External alarm In / Out port

The Alarm port provides external alarm contacts (two inputs and two outputs) that are used to monitor and report alarms generated by other equipment or to provide contact closures for RU alarms. The connector is an 8-pin Binder 712 series connector.



B0405AEA  
Front View


figure 4-18 Alarm connector

8-Pin Binder 712 Series	
Pin	Assignment
1	EXT_IN_1
2	GND_Isolated
3	EXT_IN_2
4	EXT_Out_1_normally closed
5	EXT_Out_1_common
6	EXT_Out_2_normally open
7	EXT_Out_2_common
8	EXT_Out_2_normally closed

table 4-4 Alarm connector pinning

### 4.3.11. RS 485 /+28 V port

This 5 pin connector provides RS 485 communications and +28 VDC power.



B0405AFA  
Front View

figure 4-19 RS485 /+28 VDC connector

5-Pin Binder 712 Series	
Pin	Assignment
1	+28V/500 mA
2	GND
3	RS485_RD-
4	RS485_RD+
5	GND

table 4-5 RS485/+28V pinning

### 4.3.12. Local interface port

The Local Interface port is a RJ45 network port, which can be used for a local connection to a laptop PC. This interface is used by factory for the initial setup of the RU.




figure 4-20 Local interface connector

RJ45	
Pin	Assignment
1	TXD+
2	TXD-
3	RXD+
4	
5	
6	RXD-
7	
8	

table 4-6 Local interface connector pinning

### 4.3.13. Coupling probe

The coupling probe is a QMA measurement probe that allows the measurement of the antenna output without disconnecting the antenna. The coupling is as follows:

Port	Coupling dB typ.
700 MHz	57
800/850 MHz	56
1900 MHz	50
1700 MHz	48



### 4.3.14. Optical-fiber cable connection

#### **Main optical system parameters:**

Fiber:

- Single mode fiber, type is E9/125  $\mu\text{m}$
  - Attenuation:  $<0.36 \text{ dB / km @ } 1310 \text{ nm}$  /  $<0.26 \text{ dB / km @ } 1550 \text{ nm}$
  - Dispersion:  $<3.5 \text{ ps / nm km @ } 1310 \text{ nm}$  /  $<18.0 \text{ ps / nm km @ } 1550 \text{ nm}$
  - Fiber-cable connectors LC/APC8°
- 
- The pigtails for the connection between Master Unit and Remote Unit must have a sufficient length. Protection for the optical fibers must be provided where the fibers feed into the units.
  - The system attenuation of the optical fibers, including the connectors, must not exceed 10 dB for optimal performance. Up to 20 dB optical loss can be compensated by the system, but with impact on the performance.

System attenuation and attenuation of optical components must be determined. This can be achieved by measuring attenuation and reflection with an appropriate measuring instrument. For pigtails, a total value of  $<0.4 \text{ dB}$  (measured to a reference plug) can be assumed due to the dead zone of the reflectometer. These measurements must be made with a sufficient length of optical fiber, at the input and output of the device which has to be measured.

#### **Fiber-System Installation:**

Fiber-cable connectors have to be of the same type (LC/APC8°) as the connectors used for the unit. The fiber-optic cables are connected to the optical transceiver.

**Notice:** Angled connectors are not compatible with straight optical connectors; non-compatibility of connectors will result in permanent damage to both connectors.

Before connecting the fiber cables, follow the procedure below to ensure optimized performance. It is important for these procedures to be carried out with care:

- Remove fiber-optic protective caps.
- Do not bend the fiber-optic cable in a tight radius ( $<4 \text{ cm}$ ) as this may cause cable damage and interrupt transmission.
- Using high-grade alcohol and lint-free cotton cleaning swabs, clean the end of the fiber-optic cable that will be inserted in the optical connectors on the donor interface box. Use a fiber end-face inspection tool to scan both, the class fiber and its surrounding area.
- Check for dirt on the cladding, chips/pits, dirt on the ferrule, and scratches.



- Connect the fiber-optic cables by inserting the cable end into the laser receptacle and aligning the key (on the cable end) with the keyed slot.
- Do not use any index-matching gels or fluids of any kind in these connectors. Gels are intended for laboratory use and attract dirt in the field.

**Notice:** Care should be taken when connecting and disconnecting fiber-optic cables - use the connector housing to plug or unplug a fiber. Scratches and dust significantly affect system performance and may permanently damage the connector. Always use protective caps on fiber-optic connectors not in use.

### **Cleaning Procedure for Fiber-Optical Components:**

Any contamination in the fiber connection results in additional optical transmission loss which could cause whole system failure. It is thus recommended that every fiber connector be inspected and cleaned prior to mating.

The goal is to eliminate any dust or contamination and to provide a clean environment for the fiber-optic connection.

When you clean fiber components, always complete the following steps carefully:



**Caution:** Laser radiation. Risk of eye injury in operation. Do not stare into the beam; do not view it directly or with optical instruments.

1. Turn off the ION system (laser sources) before you inspect fiber connectors.
2. Check the connectors or adapters with a fiberscope before cleaning.
3. If the connector is dirty, clean it with a lint-free wipe (dry cleaning).
4. Inspect the connector.
5. If the connector is still dirty, repeat the dry cleaning technique.
6. Inspect the connector.
7. If the connector is still dirty, clean it with 99% isopropyl alcohol (wet cleaning) followed immediately with a dry clean in order to ensure no residue is left on the end face.
8. Repeat steps 5 through 7 until end face is clean.

Note: For a more detailed description, please refer to:

[http://www.cisco.com/en/US/tech/tk482/tk876/technologies\\_white\\_paper09186a0080254eba.shtml](http://www.cisco.com/en/US/tech/tk482/tk876/technologies_white_paper09186a0080254eba.shtml)

**4.3.15. Assembly instructions for optical LC patch cables**

The ION-U H 7P/80-85P/17(E)P/19P utilizes a single fiber cable for both uplink and downlink. The RU optical connector (Opus short plug kit) supports both simplex (one fiber cable) and duplex (two fiber cables) operation.

The Opus short plug kit, which is included with the delivery of the RU, has the following components.




figure 4-21 Contents of the Opus short plug kit

The LC/APC patch cables must meet the following requirements shown in figure 4-22 for use with the RU and the Opus short plug kit.




figure 4-22 LC/APC patch cable requirements

**Note:** You must pay close attention to the integrity of the fiber during the assembly process.

### 4.3.15.1. Assemble optical Opus short plug components

The following instructions cover both simplex and duplex fiber cables. Steps that apply only to duplex cables have “b” following the step number.

- 1 Unscrew the nut and take out the plug clamp. Slide the adaptor nut ① and the clamp ② onto and along the fiber patch cable as shown.




figure 4-23 Opus short plug clamp and nut

#### Simplex Cable

- 2 Place the simplex split gasket ③ on the cable using the split on the side of the gasket with the larger diameter of the gasket toward the front.




figure 4-24 Simplex split gasket

#### Duplex Cable

- 2b Place the duplex split gasket ④ on the cables using the split on both sides of the gasket with the larger diameter of the gasket toward the front. Ensure that the channel positioning is correct as shown.




figure 4-25 Duplex split gasket

**Note:** The LC latch must be pressed down in order to slide it into the cavity of the LC support.

**3** Insert the LC connector by its side into Cavity A of LC support ⑤ until it clicks into place.




figure 4-26 Simplex cavity A

**3b** Insert the LC connectors by their sides into the LC support ⑤ until they click into place. Ensure that the channel positioning is correct as shown.




figure 4-27 Duplex cavity A & B

**4** Align and assemble LC support ⑤ with split gasket ③ or ④ and clamp ②. Insert this assembly into the plug body ⑥ as shown. The inside pin of the clamp must be aligned with the groove in the split gasket.




figure 4-28 Assemble Opus short plug





figure 4-29 Insert LC connector plug into plug body

- 5** Screw the adapter nut ① onto the body (2 N-m maximum torque).




B0405AUA

figure 4-30 Tighten Opus short plug adapter nut

#### 4.3.15.2. Connect Opus short plug to RU


- 1** Pull on the plug's collar to remove the protection cap.



B0405AVA

figure 4-31 Remove Opus short plug protective cap

- 2** Push the plug body into the receptacle until the collar is in the locked position. The "UNLOCKED" label on the connector body will no longer be visible when the connector is properly locked into the receptacle on the RU.



B0405AWA

figure 4-32 Insert Opus short plug into RU receptacle

### 4.3.15.3. Disconnect Opus short plug from RU

- 1 To disconnect the Opus short plug, pull on the collar to release the plug.




figure 4-33 Disconnect Opus short plug from RU

### 4.3.16. Optional equipment for optical fiber connection

To ease the optical connection additional equipment is available as an option:

- optical LC/APC pigtail, 5000 mm
- ready-made optical pigtail kit with Opus connector and protective tube, 5000 mm






figure 4-34 Optional pigtail kit

For connecting/disconnecting the Opus plug of the optical pigtail kit see chapters 4.3.15.2 and 4.3.15.3.

### 4.4. Commissioning Flow-Chart







## 5. Alarms

### 5.1. Bite and Alarms

The Built-In Test concept comprises the monitoring of the power supplies, the power amplifiers, fan units and the optical interface.

All occurring alarms can be checked via software at the Master Unit.

As soon as the software acknowledges a valid alarm, a message is transmitted to the Master Unit.

If the reason for the alarm has been cleared or if the alarm should continue, a new alarm message will not be repeated. If there was an interruption of at least five seconds after acknowledgement, a new alarm message will be generated.

### 5.2. Troubleshooting

The status of the Remote Unit can be checked via the Master Unit (for details please refer to the ION-U Site Manager software manual). Locally, the status can be checked at the LED.

### 5.3. Status LED Alarms

For local supervision, a status LED on the connector flange of the Remote Unit provides a visual indication of possible reasons for alarms. The color of the LED indicates the severity of the alarm. Detailed alarm information is available through the ION-U software interface.

<b>Status LED Indication</b>	<b>Alarms</b>	<b>Possible on-site measures</b>
Green	No alarm → Status ok	
Orange	Optical alarm Rx	Check fiber loss of optical link. Check optical connectors. Clean optical connectors. <i>(MU: Check optical output power of corresponding OTRx at MU).</i>
Red	Hardware failure	Reboot the RU via SM software or reboot the RU by shortly interrupting mains supply.
Status LED off	Mains	Check mains cabling. Check mains power.

### 5.4. External Alarm Inputs and Outputs

The eight-pin EXT ALARM IN/OUT connector supports two external alarm inputs and two external alarm outputs. Chapter 4.3.10 External alarm In / Out port includes the connector's pin-out information and chapter 4.3.3 Connections identifies the connector's location.

The alarm outputs are realized with relays (switching capacity max. 60 VDC, max. 2 A, max 60 W). They can be used to monitor alarms with an external alarm indicator.

**Note:** The manufacturer / supplier of this system accepts no liability for damage caused by equipment connected to external outputs or by effects from such equipment.

With the external alarm inputs, it is possible to monitor the status of connected devices, e.g. a UPS, via software. All alarm inputs are normally high (5 V) without connection. The polarity (high/ low) can be set via the software at the Master Unit (for details please see the appropriate ION-U software manual).

The device to be monitored must be connected so that the alarm contacts will be closed in case of an alarm (I max = 5 mA). The alarm inputs are potential-free with common ground (earth).

Subminiature circular connectors series 712 with eight contacts, which are included in the alarm kit, can be ordered directly from the Binder Connector Group, the manufacturer, or indirectly from CommScope.




figure 5-1 Alarm inputs and outputs

## 6. Maintenance

### 6.1. General

Read and observe the notices in chapter 1.2 Health and Safety.



**Caution:** Rotating fans. Risk of injury in operation. Wear tight-fitting clothes and disconnect mains before connecting or replacing or cleaning the fan unit.



**Caution:** The unit reaches high temperature in operation. Risk of burns by hot surface. Do not touch the unit before it has sufficiently cooled down.

**Note:** The Remote Unit does not require preventative maintenance measures.

**Note:** We recommend checking the cleanliness of the unit and in particular of the heat sink / fan(s) at appropriate intervals depending on the degree of dust and dirt at the installation site. If necessary, any dusty or dirty areas / parts should be cleaned at regular intervals, which also depend on the degree of dust and dirt at the installation site.

Maintenance of the ION-U High Power RUs should be performed by replacing only components that are described in this chapter. In order to maintain the warranty, avoid unintentional damage to the seals on the modules.

**Note:** When sending back the unit, use appropriate packaging. Use of the original packaging for shipping the unit is strongly recommended.

**Note:** Defective parts should only be replaced by original parts from the supplier. All service work performed inside the housing is performed at the users own risk.

**Note:** Ensure the Remote Unit has been disconnected from mains power during maintenance.

**Note:** Label any unlabelled cables before disconnecting them to ensure correct reconnection.

Unless otherwise agreed to in writing by CommScope, CommScope's general limited product warranty (<http://www.commscope.com/Resources/Warranties/>) shall be the warranty governing the Remote Units, including the installation, maintenance, usage and operation of the Remote Units.

For most maintenance procedures, appropriate tools are required to ensure correct handling. All of these tools can be ordered from the supplier.

**Note:** All Remote Unit screws have a right-hand thread, and are tightened by turning the screws clockwise and loosened by turning them counter-clockwise with an appropriate tool.

Due to the design of the Remote Unit, the fan unit is the only component that should be replaced in the field. Please contact the supplier for replacement of any other components.

## 6.2. Replacing the Fan Unit

Replacement of the fan unit is not required as a preventative measure. Only when an alarm indicates a malfunctioning of a fan, must the unit be exchanged.

**Note:** Please observe that the fan unit can only be replaced as a whole. Do not remove the fans separately.


Read and observe chapter 1.2 Health and Safety as well as the instructions in chapter 6.1 General before starting with the replacement.

1. Switch off the Remote Unit. Make sure that mains power is disconnected for the following replacement procedure. Then, proceed as follows:

2. Unscrew the four Pan-head screws (two at each side of the cabinet) and remove the fan cover.



3. Unscrew and disconnect the fan connector and unscrew the four Pan-head screws the fan plate is fastened to the cabinet. Take out the fan unit, replace it by the new one, fasten the four Pan-head screws for the fan unit, re-connect the fan connector and mount the cover to the cabinet.



Fan connector

### 6.3. Cleaning the Heat Sink

**Note:** Read and observe chapter 1.2 Health and Safety as well as the instructions in chapter 6.1 General before starting with the replacement procedure. Then, proceed as follows:

1. Switch off the Remote Unit. Make sure that mains power is disconnected for the following procedure.
2. Remove the fan cover and fan unit from the Remote Unit as described in chapter 6.2 Replacing the Fan Unit.



**Caution:** Risk of injury by flying particles when compressed air is used. Wear protective clothing, especially protective glasses.

3. Use compressed air (max. 5 bars) to blow out any dust, dirt, or other debris in the heat sink from back to front.
4. If the dirt cannot be blown out completely and parts of it stick to the ribs of the heat sink, clean the parts concerned carefully from the front using e.g. a brush. Take care that the heat sink material is not scratched or damaged.
5. After cleaning the heat sink, remount the fan unit according to chapter 6.2 Replacing the Fan Unit. Then, switch the Remote Unit back on.

# 7. Appendix

## 7.1. Illustrations




figure 7-1 ION-U H 7P/80-85P/17(E)P/19P required space



## 7.2. Specifications

This manual is valid for the following Remote Units:

ID No	Denomination
7698400-xxxx*	ION-U H 7P/80-85P/17P/19P
7698400-0001	ION-U H 7P/80-85P/17P/19P VAC
7698400-0002	ION-U H 7P/80-85P/17P/19P VDC
7698400-0003	ION-U H 7P/80-85P/17EP/19P VAC
7698400-0004	ION-U H 7P/80-85P/17EP/19P VDC

\* The xxxx suffix is the identifier for the specific configuration of the Remote Unit.

Please refer to the *ION-U H 7P/80-85P/17EP/19P* data sheet for the ION-U HP RU specifications.

## 7.3. Spare Parts

Maintenance of the RU should be performed on an FRU (Field Replaceable Unit) basis only. If any FRU not contained in the following list needs to be replaced, please contact customer service for additional instructions.

Designation:	ID No
Fan Unit M2-Cabinet	7661556-xx
Optical pigtail, 5 m	7704220
Optical pigtail kit, 5 m	7704209-xx
Pole-mounting kit M2-cab*	7661538
Pole-mounting kit M2-cab* with brackets	7690784
Wall-mounting kit M2-cab*	7661581

\* One of the three mounting kits has to be ordered separately. They are not contained within the standard equipment.

The manufacturer reserves the right to replace the spare parts listed above by equivalent substitutes.

**Note:** Only the spare parts listed above are FRUs and can be replaced by the user. For replacement of any other parts, please send the entire Remote Unit back to the manufacturer.

## 7.4. List of Changes

Version	Changes	Release Date
M0200A8B		30-June-2015
M0200A8C	<ul style="list-style-type: none"> <li>- chapters 1.3 and 4.3.2 updated, duplicate property damage warning removed</li> <li>- chapter 1.4 updated, single carrier and Class B</li> <li>- chapters 4.1 and 6.1 updated, warranty and mounting kits</li> <li>- chapter 4.2.2 updated, 50 mm distance</li> <li>- chapters 4.3.2 and 4.3.5 updated, 4.3-10 torque wrench</li> <li>- chapter 6.3 updated, warning</li> <li>- chapter 7.3 updated, RU IDs added</li> <li>- chapter 7.3 updated, mounting kits</li> </ul>	17-December-2015
M0200A8D	- added ION-U H 7P/80-85P/17EP/19P, AWS-3 RU	Not yet released

# 8. Index

<b>A</b>		<b>H</b>	
Alarm In/Out port.....	38	Health and Safety .....	7
Alarm port.....	25	<b>I</b>	
Alarms		Illustrations.....	54
External Inputs .....	50	Installation	
Handling of Alarms .....	49	Electrical .....	23
List .....	49	Mechanical.....	17
Outputs .....	50	<b>L</b>	
RU.....	49	LC/APC Patch Cable Requirements .....	42
Status LED .....	49	Local Interface Port .....	39
<b>B</b>		<b>M</b>	
Block Diagram ION-U H 7P/80-85P/17(E)P/19P... 16		Mains Connector.....	33
<b>C</b>		Mains Power Connection.....	33
CE Declaration of Conformity (DoC).....	12	Maintenance .....	51
Cleaning the Heat Sink .....	53	Mounting	
Commissioning.....	17	Pole with brackets.....	21
CommScope.....	12	Pole with screw bands.....	20
Compliance .....	8	Wall .....	19
Connections		<b>O</b>	
Antenna .....	28	Optical-Fiber Connection	
Connector Panel.....	24	Optional pigtail .....	46
Optical-Fiber Cable .....	40	Opus Short Plug .....	42
Connectors		Opus Short Plug kit.....	42
AC Mains .....	25	<b>P</b>	
Alarm In/out .....	25	Pole Mounting.....	20, 21
ANT RF.....	25	Property Damage Warnings .....	7
DC Mains.....	26	<b>R</b>	
Extension Unit Connector .....	25	Replacement of Fan Unit.....	52
Grounding Bolt .....	25	RS 485/+28V port.....	38
Local Interface.....	25	<b>S</b>	
Optical .....	25	Spare Parts .....	55
Probe .....	25	Status LED.....	25
RS 485/28V .....	25	<b>T</b>	
Contact Addresses, Customer Support .....	13, 14	Troubleshooting .....	49
Coupling Port.....	39	<b>W</b>	
<b>D</b>		Wall Mounting.....	19
DC Mains Connector.....	35		
Declaration of Conformity (DoC).....	12		
<b>E</b>			
Extension Unit Port .....	37		
<b>F</b>			
Fiber-Optical Components			
Cleaning Procedure .....	41		
System Installation .....	40		
<b>G</b>			
Grounding (Earthing).....	27		

COMMScope®