

**A120**

# **User Manual**

# Content

<b>1</b>	<b>Welcome .....</b>	<b>3</b>
<b>2</b>	<b>Your phone.....</b>	<b>4</b>
2.1	Phone overview.....	4
2.2	Functions of Keys .....	5
<b>3</b>	<b>Getting started.....</b>	<b>6</b>
3.1	Installing the SIM Cards and the Battery .....	6
3.2	Linking to the Network.....	6
<b>4</b>	<b>Input method .....</b>	<b>6</b>
4.1	Icons for Input Methods.....	6
4.2	To Shift Entry Methods.....	6
4.3	Inserting a Symbol .....	7
<b>5</b>	<b>Using the Menus.....</b>	<b>7</b>
5.1	Contacts.....	7
5.2	Message.....	7

5.3	Call logs .....	7
5.4	Multimedia.....	8
5.5	Settings.....	9
5.6	Web .....	10
5.7	Audio player.....	11
5.8	Organizer.....	11

## **1 Welcome**

Thank you for purchasing this cellular phone.

To guarantee your cellular phone works properly, please follow the instructions in this manual to prevent any possible incidents or malfunctions.

Follow all safety warnings to avoid injury or property damage.

Screen displays and illustrations in this user’s manual are designed to help you operate your phone to its optimum performance.

We continuously strive to improve our products. Therefore, we reserve the rights to revise this user manual

or withdraw it at any time without prior notice.

## 2 Your phone

### 2.1 Phone overview



## 2.2 Functions of Keys

<b>1</b>	<b>Earpiece</b>	<b>9</b>	<b>Ending/Power key</b>
<b>2</b>	<b>Display</b>	<b>10</b>	<b># key</b>
<b>3</b>	<b>Left soft key</b>	<b>11</b>	<b>Camera</b>
<b>4</b>	<b>Dial/Answer key</b>	<b>12</b>	<b>Speaker</b>
<b>5</b>	<b>Keypad</b>	<b>13</b>	<b>The battery cover</b>
<b>6</b>	<b>* key</b>		
<b>7</b>	<b>Navigation key</b>		
<b>8</b>	<b>Right soft key</b>		

### Number keys, \* key and # key

Press number keys 0 through 9 to input or edit state to input numbers and characters;

The # key and the \* key represent different functions in different states or different function menus.

Hold the # key up to 2s in standby state to activate or deactivate the silent mode.

Press the # key in edit state to switch between input methods.

Pressing the \* key in edit status to select a symbol.

Press \* key twice can input "+" in standby interface. When the symbol "+" appears, press the \* key quickly to input "P" or "W". "P" and "W" are used for calling the extension; "+" are used for dialing an

international call.

## **3 Getting started**

### **3.1 Installing the SIM Cards and the Battery**

An SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PIN2, PUK (PIN Unlocking Key), PUK2 (PIN2 Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short messages data.

### **3.2 Linking to the Network**

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network. After finding a network, the mobile phone enters the standby state. When the mobile phone is registered in the network, the name of the network operator is displayed on the screen. Then you can dial or receive a call.

## **4 Input method**

This mobile phone provides multiple input methods, including English input and numeric input. You can use these input methods when editing the phonebook, short messages, files and so on.

### **4.1 Icons for Input Methods**

After you enter an edit window such as a window for editing the phonebook, short messages or the memorandum, an icon is displayed to indicate the current input method:

### **4.2 To Shift Entry Methods**

Press the # key to switch between input methods.

### 4.3 Inserting a Symbol

Press the \* key to enter the **Select symbol** interface, use direction keys to select a symbol you want.

## 5 Using the Menus

### 5.1 Contacts

You can store the name and telephone number in the phone memory or the SIM card.

Up to 1000 pairs of numbers and names can be stored in the phone memory. The storage capacity of the SIM card is determined by the type of the card.

### 5.2 Message

Send SMS or MMS to the selected item.

### 5.3 Call logs

Through this function, you can view a list of missed calls, dialed calls and received calls etc.

#### **Delete all**

You can delete the latest call records. Choose **Delete call logs** and then select to delete all the numbers in the call history, or delete only the numbers in the missed calls list, the dialed calls list or the received calls list.

#### **Call timers**

Choose **call timers** to view the last call time, the total time of all dialed calls and the total time of all received calls, and/or to reset all the time.

## **GPRS counter**

Access this menu to view the sent or received GPRS volume or to reset counter.

## **5.4 Multimedia**

### **Camera**

The phone is provided with a camera, which supports the photographing functions. Roll the phone to align the camera to the picture and then press OK key to capture photos. Pictures will be saved in the file system of the phone or the memory card. In the capture interface, you can press up or down direction key to zoom in and zoom out; left or right direction key to settings.

### **Image browser**

You can view the pictures or images through this function.

### **Video player**

Use this function to play video files. By pressing the direction key can you control the playing process of video player: play/pause (ok key), fast forward (press right direction key) and rewind (press left direction key). In video player interface, you can press up or down key to tune volume.

### **FM radio**

You can use the application as a traditional FM radio with automatic tuning and saved channels. In FM radio interface, you can press up or down key to tune volume, press ok key to play/pause the playing process of the current channel, press left or right key to switch last/next channel.



## **Sound recorder**

You can record MP3, AMR & WAV format audio files through this function. The AMR takes the compression algorithm. So in the same memory condition, it has longer recording time than WAV. Press **OK** key to start Recording.

## **5.5 Settings**

### **Date & time**

Set the date format, the time format, and detail time of the location.

### **Language settings**

Users can access this item to choose the language.

### **Display**

Users can access this item to set wallpaper, screen saver, contrast, power on/off display, keypad backlight time, auto keypad lock etc.

### **Call settings**

**Dual-SIM:** Dual-SIM refers to two SIM card slots, and the two cards can standby at the same time or set one of them to display on the idle screen.

### **Security**

This function provides you with related settings about safety use.

## **Connections**

Contact the network operator to obtain the following network services:

**Network selection:** Set Network selection mode to Automatic or Manual. Automatic is recommended. When Network selection mode is set to Automatic, the mobile phone will prefer the network where the SIM card is registered. When Network selection mode is set to Manual, you need to select the network operator's network where the SIM card is registered.

## **Profiles**

The mobile phone provides multiple user profiles, so that you can customize some settings to adapt to the specific events and environments.

Customize the user profiles according to your preference and then activate the user profiles. The user profiles fall into four scenarios: Normal, Silent, Meeting, Indoor and Outdoor. When you insert an earpiece to the mobile phone, the mobile phone automatically enters the Headset mode.

## **Auto power on/off**

Users can access this item to set the auto power on/off schedule.

## **Restore factory settings**

Use this function to restore factory settings. The preset password is 1122.

## **5.6 Web**

This function enables you to view the internet. Your phone will ask you with existed way. You can start to view only by starting corresponding way.

## **5.7 Audio player**

Use this function to play audio files. By pressing the direction key can you control the playing process of audio player: play/pause (ok key), switch to last song/next song (press left or right direction key). In audio player interface, you can press up or down key to tune volume.

## **5.8 Organizer**

### **File manager**

The phone supports the Memory card. The capacity of the Memory card is selectable. You can use the file manager to conveniently manage various directories and files on the Memory card.

### **Calendar**

Once you enter this menu, there is a monthly-view calendar for you to keep track of important appointments, etc. Days with events entered will be marked.

### **Alarm**

Five alarm clocks are set but deactivated by default. You can activate one, multiple or all of them as needed. For each alarm clock, the ringing date and the ringing time can be set.

### **Calculator**

The calculator can add, subtract, multiply and divide to use the calculator.

### **Stopwatch**

You can specifies a timer that can be started and stopped.

## **Bluetooth**

With Bluetooth, you can make a wireless connection to other compatible devices, such as mobile phones, computers, headsets and car kits. You can use the Bluetooth to send images, video clips, music, sound clips and notes, and transfer files from your compatible pc.

## **FCC Caution.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **Information to user.**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Information to the user.**

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **Specific Absorption Rate (SAR) information:**

This A120 meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Feature Phone (FCC ID:YHLBLUA120) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 1.18 W/kg and when properly worn on the body is 1.04 W/kg. This device was tested for typical body-worn operations with the back of the handset kept 15mm from the body. To maintain compliance with FCC RF

exposure requirements, use accessories that maintain a 15mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

### **Body-worn Operation**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.5cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.