



GV600WG User Manual

GSM/GPRS/WCDMA/GNSS Tracker

QSZTRACGV600WGUM0102

Version: 1.02

International Telematics Solutions Innovator

www.queclink.com

Document Title	GV600WG User Manual
Version	1.01
Date	2019-02-14
Status	Released
Document Control ID	QSZTRACGV600WGUM0101

General Notes

Queclink offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Queclink. The information provided is based upon requirements specifically provided to Queclink by the customers. Queclink has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Queclink within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of Queclink. Copying of this document, distribution to others or using or communication of the contents thereof is forbidden without express authority. Offenders are liable to the payment of damages. All rights are reserved in the event of a patent grant or registration of a utility model or design. All specifications supplied herein are subject to change without notice at any time.

Copyright © Queclink Wireless Solutions Co., Ltd. 2020

Contents

0. Revision History.....	1
1. Introduction	2
1.1. Reference.....	2
1.2. Terms and Abbreviations	2
2. Product Overview.....	3
2.1. GV600WG Products.....	3
2.2. Parts List	3
2.3. Interface Definition	3
2.4. GV600WG Standard Cable Color	4
3. Getting Started	6
3.1. Open and Close the Case.....	6
3.2. Install a SIM Card.....	7
3.3. Install the Internal Backup Battery and Close the Case.....	7
3.4. Power Supply Connection	7
3.5. Ignition Detection.....	8
3.6. Digital Inputs	9
3.7. Analogue Inputs	9
3.8. Digital Outputs	10
3.9. Device Status and LED	12
3.10. Temperature Sensor Interface.....	12
3.11. Serial Port/UART Interface	13
4. Supported Peripheral List.....	13

Table Index

Table 1. GV600WG Protocol Reference	2
Table 2. Terms and Abbreviations	2
Table 3. Product Model	3
Table 4. Parts List.....	3
Table 5. Description of 18-pin Connections	3
Table 6. GV600WG Standard Cable Color Definition.....	4
Table 7. Electrical Characteristics of Ignition Detection	8
Table 8. Electrical Characteristics of the Digital Inputs	9
Table 9. Electrical Characteristics of Digital Outputs.....	10
Table 10. Definition of Device Status and LED	12

Figure Index

Figure 1. The 18-pin Connector on the GV600WG.....	3
Figure 2. Open the Case	6
Figure 3. SIM Card Installation	7
Figure 4. Backup Battery Installation	7
Figure 5. External Power Supply Connection	8
Figure 6. Typical Ignition Detection.....	8
Figure 7. Typical Digital Input Connection.....	9
Figure 8. Typical Analogue Input Connection.....	9
Figure 9. Digital Output Internal Drive Circuit.....	10
Figure 10. Typical Connection with a Relay	10
Figure 11. Typical Connection with a LED	11
Figure 12. Typical Connection with a Buzzer.....	11
Figure 13. Typical Connection with Other Devices.....	11
Figure 14. GV600WG LEDs on the Case	12
Figure 15. Typical Connection with a Temperature Sensor	13
Figure 16. Typical Connection with USB to TTL Serial Port	13

0. Revision History

Version	Date	Author	Description of Change
1.00	2019-01-09	Arry Wang	Initial
1.01	2019-02-14	Arry Wang	Modified contents
1.02	2020-06-29	Neal.lin	Modify LEDs description

1. Introduction

The GV600WG is a compact waterproof GPS trackers designed for a wide variety of vehicle tracking applications. They have multiple I/O interfaces that can be used for monitoring or controlling external devices, including a 1-wire interface used for temperature monitoring. Bluetooth 4.2 is supported. Virtual ignition detection and iButton function are both supported. Their built-in GPS receiver has superior sensitivity and fast initial positioning. Different models allow the GV600WG's location to be monitored in real time or periodically tracked by a backend server or mobile devices. System integration is straightforward as complete documentation is provided for the full featured @Track protocol. The @Track protocol supports a wide variety of reports such as emergency, geo-fence boundary crossings, and external power supply monitoring and scheduled GPS position reports.

1.1. Reference

Table 1. GV600WG Protocol Reference

SN	Document Name	Remark
[1]	GV600WG @Track Air Interface Protocol	The air protocol interface between GV600WG and backend server.

1.2. Terms and Abbreviations

Table 2. Terms and Abbreviations

Abbreviation	Description
AGND	Analogue Ground
AIN	Analogue Input
DIN	Digital Input
DOUT	Digital Output
GND	Ground
RXD	Receive Data
TXD	Transmit Data

2. Product Overview

2.1. GV600WG Products

Table 3. Product Model

Model No.	Region	Technology	Operating Band (MHz)
GV600WG	Worldwide	HSPA/UMTS/GSM	GSM/GPRS: 850/900/1800/1900 HSPA/UMTS: 850(B5)/900(B8)/1900(B2)/2100(B1)

2.2. Parts List

Table 4. Parts List

Name	Description
GV600WG Locator	135*62*38 mm
User Cable	GV600WG standard cable [Optional accessory]
USB Configure Cable	USB to TTL serial port [Optional accessory]
Power & GND Cable	GV600WG Power &GND Cable [Optional accessory]

2.3. Interface Definition

The GV600WG Tracker has an 18-pin interface connector which contains the connections for power, I/O, TTL, etc. The sequence and definition of the 18-pin connector are shown in the following figure:




Figure 1. The 18-pin Connector on the GV600WG


Table 5. Description of 18-pin Connections

Index	Description	Comment
1	PWR1	Primary Power 8-32V
2	PWR2	Secondary Power 8-32V
3	AGND	Primary Analogue Ground
4	AGND	Secondary Analogue Ground
5	IGN	Ignition Detection Input, Positive Trigger
6	ADIN1	Analogue Input 0-32V
7	OUT_3V3	External Accessory Power 400mA Max
8	GND	External Accessory Ground

9	1_WIRE	Temperature Sensor Input
10	NC	NC
11	OUT/IN1	Negative trigger input1 for normal use or Open drain output1 150mA max drive current
12	OUT/IN2	Negative trigger input2 for normal use or Open drain output2 150mA max drive current
13	OUT/IN3	Negative trigger input3 for normal use or Open drain output3 150mA max drive current
14	OUT/IN4	Negative trigger input4 for normal use or Open drain output4 150mA max drive current
15	EX_RX	RS232 RX
16	EX_TX	RS232 TX
17	RXD	UART RXD TTL
18	TXD	UART TXD TTL

2.4. GV600WG Standard Cable Color

Table 6. GV600WG Standard Cable Color Definition

Definition	Color	Pin No.	Connector	Pin No.	Color	Definition
PWR1	Red	1		2	Red/Green	RWR2
AGNG	Black	3		4	Black	AGNG
IGN	White	5		6	Green	ADIN1
OUT-3V3	Red/White	7		8	Black/White	GND
1-WIRE	Gray	9		10	NC	NC
OUT/IN1	Blue	11		12	Yellow	OUT/IN2
OUT/IN3	Brown	13		14	Orange	OUT/IN4
EX_RX	Purple	15		16	Purple/White	EX_TX
RXD	Pink	17		18	White/Black	TXD

Note:

The main color of the dual color cable is the first color, for example, Black/White means black is the main color, and white is the secondary color.

3. Getting Started

3.1. Open and Close the Case




Figure 2. Open the Case


To open: Use a cross screwdriver to loosen the four screws and then lift the top case gently.

To close: Align the top case with the bottom case and then tighten the four screws.


Note:

Pay attention to the following details to close the case. Otherwise, the waterproof capability of the device may be deteriorated.

1. The positioning poles (total 11) on the top cover must be inserted into the holes of the rubber ring as shown below.



2. Tighten the screws sufficiently until the rubber ring is squeezed out as shown in the following figure 1.



3.2. Install a SIM Card

Open the case and ensure the unit is powered off (unplug the 18-pin cable and switch the internal battery to the OFF position). Insert the SIM card into the holder. Take care to align the cut mark and ensure the SIM card is pushed into the SIM holder completely. Close the case.




Figure 3. SIM Card Installation

3.3. Install the Internal Backup Battery and Close the Case

GV600WG has an internal backup Li-ion battery (5200mAh).



Figure 4. Backup Battery Installation

3.4. Power Supply Connection

PWR (pin 1 or pin 2)/GND (pin 3 or pin 4) are the power input pins. The input voltage range is from 8V to 32V. The device is designed to be installed in vehicles that operate on 12V or 24V systems without the need of external transformers.




Figure 5. External Power Supply Connection

3.5. Ignition Detection

Table 7. Electrical Characteristics of Ignition Detection

Logical Status	Electrical Characteristics
Active	5V to 32V
Inactive	0V to 3V or open loop




Figure 6. Typical Ignition Detection

IGN (pin 5) is used for ignition detection. It is recommended to connect this pin to the “RUN” position of the vehicle ignition switch as shown above.

An alternative to connect to the ignition switch is to find a non-permanent power source that is only available when the vehicle is running, for example, the power source for the FM radio.

IGN signal can be configured to transmit information to the backend server when ignition is on and enter the power saving mode when ignition is off.

3.6. Digital Inputs

There are four general purpose digital inputs on GV600. They all are negative triggers.

Table 8. Electrical Characteristics of the Digital Inputs

Logical Status	Electrical Characteristics
Active	0V to 0.8V
Inactive	Open loop

The following picture shows the recommended connection of a digital input.




Figure 7. Typical Digital Input Connection

3.7. Analogue Inputs

There is one analogue input on GV600WG, and the analogue input voltage range is from 0 to 32V. The following picture shows the recommended connection.




Figure 8. Typical Analogue Input Connection

Note:

Pin 6 is a multifunction pin: it can be configured as an analogue input.

3.8. Digital Outputs

There are four digital outputs on GV600WG. All are of open drain type and the maximum drain current is 150 mA. Each output has a built-in over current PTC resettable fuse.




Figure 9. Digital Output Internal Drive Circuit

Table 9. Electrical Characteristics of Digital Outputs

Logical Status	Electrical Characteristics
Enable	<1.5V @150 mA
Disable	Open drain




Figure 10. Typical Connection with a Relay




Figure 11. Typical Connection with a LED




Figure 12. Typical Connection with a Buzzer




Figure 13. Typical Connection with Other Devices

Note:

Pay attention to the polarity of the relay if it is pre-installed with an internal flyback diode during connection. Install an additional diode externally if there is no pre-installed internal diode. A common diode such as a 1N4004 one will work in most circumstances.

3.9. Device Status and LED

Table 10. Definition of Device Status and LED

LED	Device Status	LED Status
CELL (Note 1)	Device is searching CELL network.	Fast flashing (Note 3)
	Device has registered to CELL network.	Slow flashing(Note 4)
	Device goes into sleep mode.	OFF
	SIM card needs pin code to unlock.	ON
GPS (Note 2)	GPS chip is powered off.	OFF
	GPS sends no data or data format error occurs.	Slow flashing
	GPS chip is searching GPS info.	Fast flashing
	GPS chip has gotten GPS info.	ON
PWR (Note 2)	No external power and internal battery voltage is lower than 3.46V.	OFF
	No external power and internal battery voltage is below 3.6V.	Slow flashing
	External power in and internal battery is charging.	Fast flashing
	External power in and internal battery is fully charged.	ON



Figure 14. GV600WG LEDs on the Case

Note:

4. 1. LED cannot be configured.
5. 2. Fast flashing: about 100ms ON/200ms OFF
6. 3. Slow flashing: about 200ms ON/1000ms OFF

6.1. Temperature Sensor Interface




Figure 15. Typical Connection with a Temperature Sensor

6.2. Serial Port/UART Interface

There are two lines dedicated to the Serial Port/UART interface (TXD and RXD). TXD and RXD are standard TTL signal.




Figure 16. Typical Connection with USB to TTL Serial Port

4. Supported Peripheral List

Name	Description
Temperature Sensor	1-Wire temperature sensor DS18B20
Fuel level Sensor	Digital RS232 (DUT-E COM Protocol) Ultrasonic fuel level sensor UFS300
Bluetooth Sensor	BLE 4.2 protocol supported
iButton	Supported (should be used with iButton reader)

5. CE Declaration

Hereby, Queclink Wireless Solutions Co., Ltd. declares that the radio equipment type GPS tracker is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

<http://www.queclink.com/>



FCC Statement:

This device complies with part 15 of the FCC rules . Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user ' s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help
- This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

RF Exposure Information:

This equipment complies with FCC exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.