



Please read carefully before use

# Table of Contents

# Thank You

Congratulations on your purchase of the Tablet. This guide is provided to help you get started quickly with your player; please read it carefully and save it for future reference.

## Package Contents

Please make sure that the items shown below are included in the package. Should an item be missing, please contact the local retailer from which you purchased this product.

- ◆ Tablet
- ◆ USB cable
- ◆ USB host/keyboard adapter
- ◆ Professional stereo Earphones
- ◆ DC charger
- ◆ User manual

This package may contain plastic bags or other materials that pose a hazard to children. Be sure to safely dispose of all packing materials after opening.

# Features

- ◆ Browse the Web.  
Visit your favorite websites
- ◆ Check your e-mail  
Keep in touch with friends and family
- ◆ Read your favorite books  
Download thousands of books with the included E-book reader \*
- ◆ Discover thousands of apps for Android™  
Games, applications, and more with the installed marketplace
- ◆ HDMI™ output to your TV \*\*  
Enjoy videos, photos and more in the comfort of your living room
- ◆ Connect to the Internet wirelessly  
High-speed Wi-Fi 802.11 b/g/n networking
- ◆ Enjoy your media library anywhere  
Portable powerhouse plays popular music, video, and photo formats
- ◆ Micro SD memory card reader  
Increase your storage capacity (up to 32 GB supported)
- ◆ Built-in camera  
Convenient front-facing camera
- ◆ Automatic orientation detection  
Read any way you want; the display adjusts automatically!

\* Reading books in the ePub format requires the included E-book reader application.

\*\* Requires optional HDMI cable (Type A-to-Type C). 2160p HD video playback requires a video file encoded at 2160p. Streaming video quality will be affected by the source, and the quality and condition of your network connection.

# Getting to Know the Internet Tablet

## Unit at a Glance



Name	Description	
1	Camera	Front-facing camera
2	Back key	Press to return to the previous screen. Long press around 4 seconds to turn the screen off
3	Power	Long Press around 5 seconds to turn the unit on /off. Double Click to turn the screen on. If screen on, Press to go to options.

4	Home	Short press the key to return to main menu interface
5	Power jack (DC input)	Charge and power the tablet with the included power adapter.
6	USB 2.0 Hi-speed port	Connect to a computer to transfer data (e.g., music, videos, photos, files).
7	Micro SD card slot	Load external micro SD memory cards here.
8	Headphone jack	Audio output connection for head-phones. <div>Note: Speaker output is automatically disabled when</div>
9	HDMI jack (mini Type C)	Connect to a TV or other display.
10	Touch Screen	Display and control screen. Touch controls are displayed on the screen. Touch (or touch and hold) icons with your finger to control the player.

## About the Touch screen

Your tablet comes equipped with an easy-to-use touch screen.

Our capacitive multi-touch screen requires gentle fingertip touch on the glass screen to activate tablet's functions. Multiple fingers may be used to perform gestures (e.g. 2-finger picture zoom).

Please note: Your finger tips must not be covered. A stylus may be used. Make sure it is for capacitive touch screens.

*To avoid damaging the screen, do not touch it with excessive force or with any object other than your finger. For best response, make sure your hands are clean before using the touchscreen controls.*

### *Protective Film*

A thin film has been applied to the touch screen to protect it during shipping. The protective film should be removed before use. To remove it, simply take a corner of the film and peel it away from the screen.

### *Touchscreen Actions*

You can control the functions of the tablet by using the touch screen in combination with the three touch keys located on the bezel. To control the tablet with the touch screen, use your fingertip to manipulate icons, buttons, menu items, the


on-screen keyboard, and other items displayed on the screen.

You can perform the following actions on the touch screen using your fingertip or appropriate stylus.

<b>Touch:</b>	To activate an on-screen item (e.g., application icons, buttons, menu items, and the letter/symbols of the on-screen keyboard), simply touch them with your fingertip.
<b>Touch and Hold:</b>	Some on-screen items have an alternate action if you touch and hold it (e.g., opening an alternate menu, or to activate the drag function). To touch and hold an item, touch the item and do not lift your fingertip until the action occurs.
<b>Drag:</b>	Drag an on-screen item to change its position (e.g., an application icon on the home screen). To drag an item, touch and hold it for a moment, then without lifting your fingertip, move your fingertip on the screen until the item reaches its target destination.
<b>Swipe:</b>	<p>Swipe up/down on the screen to scroll through a list. On some screens, you may be able to swipe left/right to change the view.</p> <p>To swipe, touch the screen and then quickly move your fingertip across the screen without lifting your fingertip. Do not pause on the screen with your fingertip at the initial point of contact or you may accidentally drag an item instead.</p>
<b>Double-tap:</b>	Quickly tap the screen twice on a webpage or other application screen to zoom (the application must support the double-tap/zoom function). Within the browser, double-tapping a webpage section will cause the browser to zoom and fit that section to the width of the screen.

## About the Orientation Sensor

The tablet contains a sensor that will automatically change the orientation of most screens as you rotate the tablet. The sensor works best when the tablet is rotated perpendicular to the ground (i.e., when the tablet is held upright and not flat on its back).



The orientation sensor can be turned on and off in the **Display** settings menu.

## Charging the Tablet

The tablet comes with a built-in rechargeable lithium-polymer battery.

Before using the tablet, the battery should be charged fully. The Status Indicator will light blue when the battery is charged fully.

To charge the battery:

Plug one end of the included power adapter into an AC 100-240V outlet.

Plug the other end of the included power adapter into the Power jack on the tablet.

Disconnect the power adapter when the tablet is fully charged.

*The battery used in this device may present a fire or chemical burn if mistreated. Do not disassemble, incinerate, or heat the device. Do not leave the device in a place subject to direct sunlight, or in a car with its windows closed. Do not connect the device to a power source other than that which is indicated here or on the label as this may result in the risk of fire or electric shock.*

## Inserting a Memory Card

The tablet accepts micro SD memory cards. Insert a memory card into the micro SD card slot to:

Increase the memory capacity of your tablet

Play media files stored on the memory card (e.g., music, video, or photo files).

### **To insert a memory card:**

Align the memory card with the card slot. The metal contacts of the memory card should face down away from the LCD screen.

Slide the card into the spring-loaded slot. Push the card in until it clicks into place.

*Do not attempt to insert objects other than a micro SD memory card into the card slot. A compatible memory card should fit easily into the card slot; if you encounter resistance, check the alignment of the card. Do not attempt to force the card in.*


*Avoid touching the gold contacts of the memory card.*

### **To release and remove a memory card:**



## UNMOUNT the memory card.

- a. From the home screen, tap the **Launcher Tab**, and then touch **Settings** to show the settings menu.
- b. Touch **Storage** to show the storage settings.
- c. Touch **Unmount SD card** to prepare the memory card for safe removal.



Push the card further into the slot until you hear a click. The card will spring out of the slot.

Grasp the card by its edge to remove it.

*To avoid damage and data corruption, do not remove a memory card while data is being written to or read from the card. For example, do not remove a card while playing a music file stored on the card.*

## Resetting the Tablet

Reset the tablet if it should freeze and not respond or otherwise malfunction.

1. Disconnect your tablet if it is connected to a computer.
2. Press and hold the POWER key for about 8 seconds to turn off the tablet, and then press and hold the POWER key about 3 seconds to turn on the tablet.

# Getting Started


## Turning the Tablet on and off

To turn the tablet on:

- ◆ Press and hold the **Power** key until the LCD screen turns on. Wait until the Home screen appears; the tablet is now ready for use.

To turn the tablet off:

1. Press and hold the **Power** key until the confirmation message appears.



2. Touch **OK** to turn off the tablet.

### *Turning the Screen On and Off (Standby)*

When the tablet is on, you can turn off the screen to conserve battery power. Simply press the **Power** key once to turn the screen off. Press the **Power** key again to turn the screen back on.

### *Unlocking the Screen*


When the screen turns off, you will have to unlock the screen when you turn it back on.

Long press around 4 seconds to unlock the screen

*To conserve battery power, the screen can be set to turn off automatically when the tablet is not in use (between 15 seconds and 30 minutes). This **Sleep** option can be found in the **Display** menu.*



If a password has been set, enter the password to finish unlocking the screen. The Screen Unlock password can be set in the **Security** settings menu.



*WARNING: Please write down your password lock pattern/PIN/Password. Misplacing or forgetting this method will lock the user out. Recovering the unit will reset the device back to factory defaults. **ALL YOUR DATA & PROGRAMS WILL BE LOST.***

## Home Screen at a Glance

The home screen is the starting point for all of the features of your tablet.



Name		Description
1	<b>Google Search</b>	Touch to search with Google browser.
2	<b>Home icon</b>	Touch to back to the central Home Screen.
3	<b>Back icon</b>	Touch to back to the previous screen.
4	Recent Apps	Touch to display the list of thumbnail images of apps you have worked recently. Touch an App to open it.
5	Launcher Tab	Open the Launcher to view the list of all Applications and Widgets installed on the tablet. Touch the Launcher tab to open the Launcher.
6	Widgets	Widgets are small applications that you can use directly from the home screen. For more information, refer to the "Widgets" section on page <b>xx</b> .
7	Icons	Touch an icon to open an application or folder.
8	Notification bar	Shows notification icons such as time, battery level, and the network signal strength; touch the bar to open the full Notifications panel. Touch a Notification icon to display more detail.

## About Applications

To open an application, touch the application icon on the home screen or in the Launcher.




Launcher screen:
















The screen shown above is for illustrative purposes only. We reserves the right to modify and improve the final list of applications available on the tablet.

Preinstalled Applications

Some applications have been installed on your tablet for your convenience. These applications include:

	Browse the web.
	Display the calendar or record events and appointments to manage your schedule.
	Perform simple mathematical operations.

 Camera	Take pictures or videos with the front-facing camera.
 Clock	View the current time, or set an alarm.
 Dev Tools	Debugging tool
 Email	Check your e-mail.
 File Manager	View and manage files stored on the tablet.
 Super-HD Player	View photos and videos, plus edit photos.
 Downloads	view the files (Pictures ect) which download from website
 Music	Play music.
 Settings	Access the Settings menu to adjust the tablet's options.

 Maps	View map with wifi
 Latitude	With Wifi ,can make your location
 Market	Installed applications
 Sound Recorder	Record the sound & voice

## Installing Applications

You can also download and install additional applications from the device's applications marketplace, the web browser, or other sources.

The tablet must be set to allow installation of applications from non-Market sources. The Unknown sources option can be set in the **Application settings** menu.

*Your Mobile Internet Device may include access to, or information on, content, products, applications and services from third parties. Your use of such third party content, products, applications and services is at the discretion of such third party and expressly governed by such third party's terms of use, including any such third party's privacy policies, for such content, products, applications and services. We are not responsible for and expressly disclaims all warranties of any kind with respect to all such third party content, products, applications and services. We will not be responsible for any loss, costs, or damages incurred due to your access to or use of third party content, products, applications or services.*

## About Widgets

Widgets are self-contained applications that you can place on the Home screens to access your favorite features.

### Adding Widgets to a Home Screen


Navigate to the Home screen which you want to place the Widget on.

Touch the **Launcher Tab**.

Touch **WIDGETS** to show all widgets, and then hold on a widget icon to add it to the Home screen.

### *Removing Widgets*

Touch and hold the Widget until Remove icon appears at the top side of the screen, then drag the Widget to the Remove icon to remove it.



## About Notifications


The icons that appear in the Notification bar at the bottom right corner of the screen alerts you when new messages arrive or alarms or other application events occur.

View and respond to the notifications by opening the full Notifications panel.

Touch the **Notification** bar to open the Notifications panel.

### **To respond to a notification:**

- ◆ Touch a notification in the list; the Notifications panel will close and the application associated with the notification will launch.



### **To close the Notifications panel:**

- ◆ Touch any other area of screen except the Notifications panel , or;
- ◆ Touch the Back icon.



# Connecting to the Internet

This tablet can utilize Wi-Fi data networks to connect to the Internet.

- ◆ Wireless Wi-Fi technology can provide Internet access at distances of over 300 feet; however, this distance can be affected by your surrounding environment and Wi-Fi router.

## Requirements

In order to connect to the Internet, you will need either of the following:

### **A wireless router or access point with a broadband Internet connection**

The wireless router must support Wi-Fi 802.11b/g connections. If the router supports 802.11n, make sure that it has been configured to accept 802.11b/g connections as well.

*A minimum connection speed of 64 Kbps is recommended. Faster speeds will enable a better Internet experience.*


You will need to know the name of your network (SSID), as well as the password or other credentials if your network is secured. These settings can usually be found on the administration webpage of your wireless router.

Please refer to your wireless router's documentation for help, or ask your network administrator for details.

*You may encounter open Wi-Fi networks, or "hot spots." These networks are usually configured so that you can simply connect to them without needing to know its settings; the tablet will obtain all the information it needs from the router automatically.*

## Connect to a Wi-Fi network

The Notification bar displays icons that indicate your tablet's Wi-Fi status.

	Connected to a Wi-Fi network (waves indicate connection strength).
[no icon]	There are no Wi-Fi networks in range, or the Wi-Fi radio is off.

### **1. Turn on the Wi-Fi radio if it is not already on. To turn on Wi-Fi:**

- Go to the Home screen:  
Touch the **Home** icon.
- Open the Launcher screen:  
Touch the **Launcher Tab**, then touch **Settings**.

c. Open the Wireless & networks menu:

Touch **WIRELESS & NETWORKS**.

d. Open the Wi-Fi settings menu:

Touch **WiFi**.

e. Make sure that the Wi-Fi option box is set to ON: Touch and slide the block right to enable the **Wi-Fi** connection.



When Wi-Fi is on, the tablet will look for and display a list of available Wi-Fi networks.

*If a network that you have connected to previously is found, the tablet will connect to it.*

*If you don't see your network in the list, you can force the tablet to re-scan. To scan for networks, tap the **SCAN** icon that located on the top right corner of the screen.*

## 2. Select an available Wi-Fi network to connect to:

In the same Wi-Fi settings menu above, touch a network in the list.

If the network is open, the tablet will prompt you to confirm connection to the network. Touch **Connect** to confirm.

If the network is secured (as indicated by a Lock icon), the tablet will prompt you to enter a password or other credentials. Touch the Wireless password box to show the on-screen keyboard and then use it to enter the password. Touch **Connect** to confirm.



When you have successfully connected to a Wi-Fi network, the Notifications bar at the bottom of the screen will show a Wi-Fi signal indicator.

*To learn about how to add a Wi-Fi network when it is not in range or when the router is set to obscure the network name (SSID); or to configure advanced Wi-Fi options, please refer to the manual.*

# Browsing the Web

The Browser application lets you visit webpages and find information on the web. Keep up with the news, your friends, or enjoy video from YouTube™, the world's most popular video-sharing community.

To use Browser, the tablet must be connected to the Internet. Read the section “Connecting to the Internet” to learn how to connect to the Internet.





To open Browser, touch the Browser icon on the Home screen or in the Launcher.

Name		Description
1	Address bar	Displays the address (URL) of the current page. Touch the bar to enter a new address or to search the web.
2	<b>Goto Bookmarks</b> icon	Touch to view bookmarks, to view your most visited sites, or to view your browser history.
3	<b>Search</b> icon	Touch to search with Google browser.
4	<b>Add Bookmark</b> icon	Touch to add bookmarks.
5	New Window (+)	Creates new browser window.



Some common Browser actions are described below.


## To go to a webpage.

<p>1. Touch the <b>Address bar</b> at the top of the Browser screen. The keyboard will open automatically. (If the Address bar is not visible, drag the page down to return to the top of the Browser screen.)</p>	
<p>2. Use the keyboard to enter the address (URL) of the webpage</p>	
<p>3. Touch <b>Enter</b> key to open the webpage.</p>	



## ◆ To bookmark a webpage.

Bookmark your favorite webpages in order to visit them quickly without entering a URL.

<p>1. Go to the webpage that you want to bookmark</p>	
<p>2. Touch the <b>Add Bookmark</b> icon.</p>	



<p>3. If desired, you can modify the name of the bookmark or its location (URL address). Otherwise, touch <b>OK</b> to finish adding the book-mark.</p>	
---	--

◆ **To go to a bookmarked webpage.**

<p>1. Touch the <b>Goto Bookmark</b> icon.</p>	
<p>2. Touch a bookmark tile to open it.</p>	

◆ **To delete a bookmarked webpage.**

<p>1. Touch the <b>Goto Bookmark</b> icon.</p>	
--	---

<p>2. Touch and hold a bookmark tile to open the option menu.</p>	
<p>3. Touch "Delete bookmark".</p>	
<p>4. Touch "OK" to confirm.</p>	

## Browser menu

While viewing a webpage, touch the icon show as right to open the Browser Menu, the icon is locate on the top right corner of the screen, the options are:



- ◆ Refresh: Refresh the current webpage.
- ◆ Forward: Go to the next webpage.
- ◆ New tab: Open the webpage in a new window, under a new tab.
- ◆ New incognito tab: Open the webpage in a new window, under a new tab, and the pages you view in the new window will not appear in your browser history or search history. See the on-screen explanation of going incognito.
- ◆ Share page: Use Email to send the webpage URL.
- ◆ Find on page: Search for content on the current page.
- ◆ Request desktop site:
- ◆ Save for offline reading: Save this page onto the internal memory, then you can read it when the internet connection is disable.

- ◆ Page info: View information about the current page, including the URL.
- ◆ Settings: Customize the Browser.

# Managing Applications

Downloading and installing new applications to your tablet can extend its functionality in many ways.

You can download and install applications from the included Applications store. To open the Applications store:

1. Touch the **Launcher** icon.
2. Touch the **Apps Marketplace** icon.




When installing an application, it will tell you what functions it needs to control and if it needs access to your data. Make sure you review these access requirements carefully before completing the installation.

*Be especially cautious with applications that request access to many functions or to a significant amount of your data. You are responsible for the results of applications installed on your tablet.*


## To uninstall an application:

1. From the Home screen, touch the **Launcher Tab**.
2. Touch Settings to open the **Settings** menu.
3. Touch **Apps**, a list of all applications installed on the tablet will display on screen.




4. Touch the name of the application you want to uninstall; the Application Info screen will open.






5. Touch **Uninstall**. The tablet will prompt you to confirm.



6. Touch **OK** to uninstall the application.

*Or you can uninstall an application from the Launcher screen directly. Touch and hold an application icon until the **Uninstall** icon  appears, drag the application icon to the **Uninstall** icon to uninstall the application.*

# Optional Connections

## Connecting to a Computer

Connect the tablet to a computer to transfer files.

### 1. Connect your tablet to the computer.

With the included USB cable:


Plug the small end of the cable into the USB 2.0 Hi-speed connector of the tablet.

Plug the large end of the cable into an available USB 2.0 Hi-speed port on the computer.

**When your tablet is connected, a USB icon will appear in the Notification bar.**



Touch the Notification bar to open the notifications panel.



*The Tablet's "mass storage mode" is compatible with many operating systems including: Microsoft® Windows® XP, Vista, 7 or higher and Mac OS or Linux.*

### 2. Mount the storage drive.

- ◆ Touch **USB connected** to mount the tablet's built-in storage, then touch "Turn on USB storage" and "OK" when prompted to confirm. When mounted, you can copy files to/from your computer to it.

Your tablet will be recognized by the computer as a Removable Storage drive. Drag and drop files between your tablet and the computer. To learn more about copying files, please refer to the documentation included with your computer or

operating system.

## Connecting to a TV

Connect to a TV to enjoy your tablet from the comfort of your living room. An HDMI cable (Type A-to-Type C) is required to connect the tablet to a TV.

The tablet will recognize and match the capabilities of the TV automatically.

### **To connect the tablet to the TV:**

1. Plug the small end of the HDMI cable into the mini HDMI connector of the tablet.
2. Plug the large end of the HDMI cable into the HDMI port on the TV.
3. Turn on the TV, and set its display mode to the HDMI port that the tablet is connected to.

The tablet's display will be output to the TV screen.

*If you need help setting the display mode of the TV, please refer to the documentation provided by the TV manufacturer.*

## Connecting Headphones

Connect a pair of headphones (or earphones) to the tablet to enjoy media in private.

Lower the volume level of the tablet before connecting headphones, and then slowly raise the volume to a comfortable listening level.

- ◆ The headphones must have a 3.5 mm (1/8 in) plug.
- ◆ When headphones are connected, speaker output will be disabled automatically.

*Hearing experts advise against the constant use of personal stereos played at high volume. Constant exposure to high volumes can lead to hearing loss. If you should experience ringing in the ears or hearing loss, discontinue use and seek medical advice.*

*Hearing experts advise against the constant use of personal stereos played at high volume. Constant exposure to high volumes can lead to hearing loss. If you should experience ringing in the ears or hearing loss, discontinue use and seek medical advice.*

## Using the USB Full-Size Adapter


The USB full-size adapter can be used to connect and use USB devices with the tablet. The adapter converts the mini USB port on the tablet into a USB On-the-Go (OTG) connector.

### *Connecting a Keyboard*

For times when you want to type for an extended period of time, you may want to connect a full-size keyboard to the tablet.

Use the included USB full-size (Type A) adapter to connect a keyboard to the tablet.

*You may also use this connection to add a mouse to the tablet.*



*The adapter supports one connection at a time. To use a keyboard and mouse simultaneously, you will need to add an external USB hub.*

### *Connecting a Storage Device*

Use the included USB full-size (Type A) adapter to connect a storage device to the tablet (e.g., a USB flash memory drive).

*This connection supports a maximum storage size of 16 GB. For additional storage capacity, a microSD card can be added to the tablet.*

# Setting the System Options

Open the system settings menu to adjust how the tablet looks and functions.

*Many applications will have their own settings; refer to the documentation provided by the application developer to learn more.*

To open the Settings menu:

1. From the Home screen, touch the **Launcher Tab**.
2. Touch **Settings** to open the Settings menu.

The settings are grouped by category. Touch a category to open and adjust its settings on the right side.

*Please refer to the manual for a description of the items in the Settings menu.*

# Specifications

Processor	Cortex A8 (1.2 GHz)
RAM	512M
Storage	4GB flash built-in Micro SD card slot (max. 32GB supported)
Display	7.0" TFT LCD (800 x 600), capacitive touchscreen
Networking	Wi-Fi IEEE 802.11 b/g/n
Video Output	Mini HDMI, type C (1080p and 2160p supported)
Audio Output	3.5 mm headphone
PC Interface	USB 2.0 Hi-speed
Additional Features	Front camera Built-in microphone Stereo speaker
Operating System	Android 4.0
Power	Rechargeable Li-poly battery Power Adapter (DC 5V)
Playback Time (hours) *	Up to 10 hours music, 5.5 hours video, 4 hours web browsing

\* Music was tested with a 128 kbps MP3 file; video was tested with a 1920 x 1080 MPEG-4/AVC file; browsing was tested with the screen brightness set to default. Actual playback results may vary.

#### FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

#### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device and its antenna( s) must not be co-located or operation in conjunction with any other antenna or transmitter.