

ATW User Manual

Revision: 1.00

Document Title	<i>ATW User manual</i>
Version	<i>1.00</i>
Finale Date	<i>2018-03-29</i>
Status	<i>Released</i>
Document Control ID	<i>TRACKER ATW</i>

Contents

1 Introduction	3
2 Product Overview	3
2.1 Appearance.....	3
2.2 Buttons/12PIN Interface Description	3
2.3 LED Description	4
3 Getting Started	5
3.1 Parts List	5
3.2 Battery Charging	5
3.3 ATW Data Cable	5
3.4 Power on/Power off.....	6
4 Frequency.....	6
5 Trouble shooting and Safety info	7
5.1 Trouble shooting	7
5.2 Safety info	7

1 Introduction

ATW is a powerful GPS locator which is designed for vehicle and assets tracking. With superior receiving sensitivity, fast WCDMA frequencies 850/1900. Its location can be real time or schedule tracked by backend server or specified terminals. Based on the embedded wireless tracking protocol, ATW can communicate with the backend server through WCDMA and GSM network, and transfer reports of emergency, Geo-fencing, device status and scheduled GPS position etc... Service provider is easy to setup their tracking platform based on the functional wireless tracking protocol.

2 Product Overview

2.1 Appearance



Figure 1-1

2.2 Buttons/12PIN Interface Description

Button /12PIN Interface Description	
KEY/interface	Description
Power Key	Power on ATW Power off ATW (If power key is enabled)
Function Key	Geo-Fence mode Long press the key to enable/disable Geo-Fence ID0 Geo-Fence in current position mode Long press the key to enable/disable Geo-Fence ID0. If enable Geo-Fence ID0, using the current position as the centre of Geo-Fence 0. SOS mode (default) Long press the key to active SOS alarm

12PIN interface	Connect a 3.7V Li-ion or Li-Polymer battery can power on ATW Backend server developer or administrator can use the data cable to configure ATW (by RD or engineer not by end user).
Reset Key	Click the key will turn off internal VBAT when OS is abnormal, and then press Power Key to restart ATW.

2.3 LED Description





Figure 1-2

There are four LED lights in ATW device, the description as following.

Light	Event	State
Power LED	Power on and normal	Dark
	Fully charged	Solid
	In charging	Slow flash
WCDMA LED	Power on and normal	Slow flash
	Power off	Dark
WIFI LED	WIFI on	Slow flash
	WIFI off	Dark
GPS LED	GPS fixed	Fast flash
	GPS has been turned off	Dark

3 Getting Started

3.1 Parts List

Name	Picture	Remark
ATW Locater	 A black, rectangular ATW Locater device with a circular speaker at the bottom and a small display area at the top showing icons for signal strength, call, Wi-Fi, and battery.	The WCDMA/GPS locator.
ATW Data and charger Cable	 A blue data and charger cable with a 12-pin connector on one end and a standard USB-A connector on the other.	It the data cable which can be used for firmware upgrading and configuration (by RD or engineer not by end user). It also includes the charger interface on the ATW.

3.2 Battery Charging

The following items are suggestion for battery charge, please pay more attention.

- ◆ During the charging process, the Power LED light will slow flash. When the battery is fully charged, the Power LED light will be Ever-light.
- ◆ You can charge the battery using charging cable which connects ATW device with the Adapter.
- ◆ Charging will last about 5 hours.

Note: If the ATW device is firstly used, please make sure the battery is fully charged, which will make the life of battery much longer.

3.3 ATW Data Cable

ATW Data Cable is a cable with a 12PIN connector.

The data cable is used for data download, which will be used for firmware update or configuration and can be used for charging at the same time (by RD or engineer not by end user).



Figure 2-1

3.4 Power on/Power off



Figure 2-2

Power on:

- ◆ Press the Power key at least 3 seconds and release it to power on ATW device.
Note that, the Power LED light will light for a moment and then turn off.

Power off:

- ◆ Press the power key about 3 seconds; Power LED light will light for a moment and then turn off, which indicates that ATW device has been powered off.

Note: the user can not power off ATW if the power key is disabled by protocol.

4 Frequency

GSM850:824-849MHz (TX), 869-894MHz (RX);

PCS1900:1850-1910MHz (TX), 1930-1990MHz (RX);

WCDMA B5:824-849MHz (TX), 869-894MHz (RX);

WCDMA B2:1850-1910MHz (TX), 1930-1990MHz (RX);

GPS:1575.42MHz

5 Trouble shooting and Safety info

5.1 Trouble shooting

Trouble	Possible Reason	Solution
Messages can't be reported to the backend server by Mobile network.	APN is wrong. Some APN can not visit the internet directly.	Ask the network operator for the right APN.
	The IP address or port of the backend server is wrong.	Make sure the IP address for the backend server is an identified address in the internet.
Unable to power off ATW.	The function of power key was disabled by AT+GTFKS.	Enable the function of power key by AT+GTFKS.
Battery can not be charged	The battery has not been used for too long time and has been locked.	Using a external power source with 3.6V to 4.2V DC power supply to active the battery or apply for after sale help.
ATW can't fix GPS successfully.	The GPS signal is weak.	Please move ATW to a place with open sky.
		It is better to let the top surface face to the sky. (The same surface with indication LED)

5.2 Safety info

The following items are suggestion for safety use, please pay more attention.

- ◆ Please do not disassemble the device by yourself.
- ◆ Please do not put the device on the overheating or too humid place, avoid exposure to direct sunlight. Too high temperature will damage the device or even cause the battery explosion.
- ◆ Please do not use ATW on the airplane or near medical equipment.

FCC Caution.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ISED RSS Warning/ISED RF Exposure Statement

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ISED RF exposure statement:

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Le rayonnement de la classe b respecte ISED fixaient un environnement non contrôlés. Installation et mise en œuvre de ce matériel devrait avec échangeur distance minimale entre 20 cm ton corps. Lanceurs ou ne peuvent pas coexister cette antenne ou capteurs avec d'autres.