Go to the Settings icon on your iPad® iPhone® or iPod® touch and select Wi-Fi, Confirm that Wi-Fi is ON, Select "Kingston Wi-Drive" under "Choose a Network" and click on it to connect to it.

Once connected, open the Kingston Wi-Drive app on your iPad, iPhone, or iPod touch and enjoy your new expanded storage.

Share your content with as many as three users by having them follow steps 3 to 6.

TURKISH

Step 1 - Charge your Wi-Drive Device

charge, connect the included USB cable to your Wi-Drive's mini-USB port and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

Step 2 – Add Content to your Wi-Drive

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explore one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVF" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device

Mac users: By default when connecting your Wi-Drive to your computer, two drives will appear on your desktop one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device

(It is recommended that you organize your content by creating folders, e.g., "Videos, Music, Pictures and Documents")

Step 3 – Download Kingston's Free Wi-Drive App from the

Visit Apple's App Store and search for "Kingston Wi-Drive".

Power on the Wi-Drive by pressing the On/Off button (see Figure 2).*

*Note: After you power on, wait for Blue Wi-Fi Activity Light to start flashing before proceeding to the next step.

Go to the Settings icon on your iPad®, iPhone®, or iPod® touch

and select Wi-Fi, Confirm that Wi-Fi is ON, Select "Kingston Before using, make sure your Wi-Drive™ is fully charged. To Wi-Drive" under "Choose a Network" and click on it to

Once connected, open the Kingston Wi-Drive app on your iPad, iPhone, or iPod touch and enjoy your new expanded

Share your content with as many as three users by having them follow steps 3 to 6.

RUSSIAN

Step 1 – Charge your Wi-Drive Device

Before using, make sure your Wi-Drive™ is fully charged. To charge, connect the included USB cable to your Wi-Drive's mini-USB port and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

Step 2 – Add Content to your Wi-Drive

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explorer one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVF" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device

Mac users: By default when connecting your Wi-Drive to your computer, two drives will appear on your desktop one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled

"WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device. (It is recommended that you organize your content

by creating folders, e.g., "Videos, Music, Pictures and Documents") Step 3 - Download Kingston's Free Wi-Drive App from the

App Store Visit Apple's App Store and search for "Kingston Wi-Drive".

Power on the Wi-Drive by pressing the On/Off button (see Figure 2).*

*Note: After you power on, wait for Blue Wi-Fi Activity Light to start flashing before proceeding to the next step.

Go to the Settings icon on your iPad®, iPhone®, or iPod® touch and select Wi-Fi, Confirm that Wi-Fi is ON, Select "Kingston Wi-Drive" under "Choose a Network" and click on it to connect to it.

Once connected, open the Kingston Wi-Drive app on your iPad, iPhone, or iPod touch and enjoy your new expanded

Share your content with as many as three users by having them follow steps 3 to 6.

SIMPLIFIED CHINESE

Step 1 - Charge your Wi-Drive Device

Before using, make sure your Wi-Drive™ is fully charged. To charge, connect the included USB cable to your Wi-Drive's mini-USB port and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

Step 2 - Add Content to your Wi-Drive Windows users: When connecting your Wi-Drive to your

computer, two drive letters will appear in Windows Explorer - one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device

Mac users: By default when connecting your Wi-Drive to vour computer, two drives will appear on your desktop one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVF" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive: drag or copy files from your computer to your Wi-Drive device.

(It is recommended that you organize your content by creating folders, e.g., "Videos, Music, Pictures and Documents")

Step 3 – Download Kingston's Free Wi-Drive App from the

Visit Apple's App Store and search for "Kingston Wi-Drive". computer to your Wi-Drive device

Power on the Wi-Drive by pressing the On/Off button (see Figure 2) *

*Note: After you power on, wait for Blue Wi-Fi Activity Light to start flashing before proceeding to the next step.

Go to the Settings icon on your iPad®, iPhone®, or iPod® touch and select Wi-Fi. Confirm that Wi-Fi is ON. Select "Kingston Wi-Drive" under "Choose a Network" and click on it to

Once connected, open the Kingston Wi-Drive app on your iPad, iPhone, or iPod touch and enjoy your new expanded

Share your content with as many as three users by having them follow steps 3 to 6.

TRADITIONAL CHINESE

Step 1 – Charge your Wi-Drive Device

Before using, make sure your Wi-Drive™ is fully charged. To charge, connect the included USB cable to your Wi-Drive's mini-USB port and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

Step 2 – Add Content to your Wi-Drive

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explorer — one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVF" Double-click on the drive labeled

"WI-DRIVE" to add vour content. Transfer your files the same as you would for any USB drive; drag or copy files from your

Mac users: By default when connecting your Wi-Drive to your computer, two drives will appear on your desktop one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your

computer to your Wi-Drive device. (It is recommended that you organize your content by creating folders, e.g., "Videos, Music, Pictures and Documents")

Step 3 - Download Kingston's Free Wi-Drive App from the App Store

Visit Apple's App Store and search for "Kingston Wi-Drive".

Power on the Wi-Drive by pressing the On/Off button

(see Figure 2).* *Note: After you power on, wait for Blue Wi-Fi Activity

Light to start flashing before proceeding to the next step.

Go to the Settings icon on your iPad®, iPhone®, or iPod® touch and select Wi-Fi. Confirm that Wi-Fi is ON. Select "Kingston Wi-Drive" under "Choose a Network" and click on it to connect to it

Once connected, open the Kingston Wi-Drive app on your iPad, iPhone, or iPod touch and enjoy your new expanded storage.

Share your content with as many as three users by having them

follow steps 3 to 6.

JAPANESE

Step 1 – Charge your Wi-Drive Device

Before using, make sure your Wi-Drive™ is fully charged. To charge, connect the included USB cable to your Wi-Drive's mini-USB port and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

Step 2 - Add Content to your Wi-Drive

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explore — one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device

your computer, two drives will appear on your desktop one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device.

by creating folders, e.g., "Videos, Music, Pictures and Documents")

Power on the Wi-Drive by pressing the On/Off button

Go to the Settings icon on your iPad®, iPhone®, or iPod® touch

connect to it.

and select Wi-Fi, Confirm that Wi-Fi is ON, Select "Kingston

Once connected, open the Kingston Wi-Drive app on your iPad, iPhone, or iPod touch and enjoy your new expanded

Share your content with as many as three users by having them follow steps 3 to 6

Mac users: By default when connecting your Wi-Drive to

(It is recommended that you organize your content

Step 3 – Download Kingston's Free Wi-Drive App from the Visit Apple's App Store and search for "Kingston Wi-Drive".

(see Figure 2) *

*Note: After you power on, wait for Blue Wi-Fi Activity Light to start flashing before proceeding to the next step.

Wi-Drive" under "Choose a Network" and click on it to Kingston Wi-Drive[™]

Getting Started

online at www.kingston.com/support/widrive. 4402103-001.A00

Getting Started

Step 1 - Charge your Wi-Drive Device

Before using, make sure your Wi-Drive™ is fully charged. To charge, connect the included USB cable to your Wi-Drive's mini USB port (1) and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

Step 2 - Add Content to your Wi-Drive

computer to your Wi-Drive device

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explorer — one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your

Mac users: By default when connecting your Wi-Drive to your computer, two drives will appear on your desktop one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device.

(It is recommended that you organize your content by creating folders, e.g., "Videos, Music, Pictures and Documents")

Step 3 – Download Kingston's Free Wi-Drive App from the Visit Apple's App Store and search for "Kingston Wi-Drive".



Figure 1 - Kingston's Wi-Drive App Icon

Power on the Wi-Drive by pressing the On/Off button

*Note: After you power on, wait for Blue Wi-Fi Activity Light to start flashing before proceeding to the next

Go to the Settings icon on your iPad®, iPhone®, or iPod® touch and select Wi-Fi. Confirm that Wi-Fi is ON. Select "Kingston Wi-Drive" under "Choose a Network" and click on it to connect to it.

Once connected, open the Kingston Wi-Drive app on your iPad, iPhone, or iPod touch and enjoy your new expanded

Share your content with as many as three users by having



Figure 2 – Kingston's Wi-Drive

FRENCH

Step 1 – Charge your Wi-Drive Device Before using, make sure your Wi-Drive™ is fully charged. To charge, connect the included USB cable to your Wi-Drive's mini-USB port and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

Step 2 - Add Content to your Wi-Drive

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explorer — one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device

Mac users: By default when connecting your Wi-Drive to vour computer, two drives will appear on your desktop – one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device.

(It is recommended that you organize your content by creating folders, e.g., "Videos, Music, Pictures and Documents")

Step 3 - Download Kingston's Free Wi-Drive App from the Visit Apple's App Store and search for "Kingston Wi-Drive

*Note: After you power on, wait for Blue Wi-Fi Activity Light to start flashing before proceeding to the next step.

(see Figure 2).*

Power on the Wi-Drive by pressing the On/Off button

Go to the Settings icon on your iPad®, iPhone®, or iPod® touch and select Wi-Fi Confirm that Wi-Fi is ON Select "Kingston Wi-Drive" under "Choose a Network" and click on it to

iPad, iPhone, or iPod touch and enjoy your new expanded

GERMAN

Before using, make sure your Wi-Drive™ is fully charged. To charge connect the included LISB cable to your Wi-Drive's mini-USB port and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

Step 2 – Add Content to your Wi-Drive

Once connected, open the Kingston Wi-Drive app on your

Share your content with as many as three users by having them

follow steps 3 to 6.

Step 1 – Charge your Wi-Drive Device

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explorer — one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device

Mac users: By default when connecting your Wi-Drive to

vour computer, two drives will appear on your desktop —

labeled "WI-DRIVE" Double-click on the drive labeled

one Read-Only labeled "CDROM" and one Removable Disk

"WI-DRIVE" to add your content. Transfer your files the same

as you would for any USB drive; drag or copy files from your

(It is recommended that you organize your content

App Store

Power on the Wi-Drive by pressing the On/Off button

Light to start flashing before proceeding to the next step.

computer to your Wi-Drive device.

by creating folders, e.g., "Videos, Music, Pictures and Documents") Step 3 – Download Kingston's Free Wi-Drive App from the

Visit Apple's App Store and search for "Kingston Wi-Drive".

(see Figure 2) *

*Note: After you power on, wait for Blue Wi-Fi Activity

Go to the Settings icon on your iPad®, iPhone®, or iPod® touch and select Wi-Fi. Confirm that Wi-Fi is ON. Select "Kingston Wi-Drive" under "Choose a Network" and click on it to

Once connected, open the Kingston Wi-Drive app on your

ITALIAN

light will stop flashing when Wi-Drive is fully charged.

iPad, iPhone, or iPod touch and enjoy your new expanded

Share your content with as many as three users by having them follow steps 3 to 6.

Step 1 – Charge your Wi-Drive Device Refore using make sure your Wi-Drive™ is fully charged To charge, connect the included USB cable to your Wi-Drive's connect to it. mini-LISR port and the other end into an available LISR port on your computer or to a USB wall adapter. The green power

Step 2 - Add Content to your Wi-Drive

computer to your Wi-Drive device

computer to your Wi-Drive device.

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explorer — one Read-Only Jaheled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content Transfer your files the same as you would for any USB drive; drag or copy files from your follow steps 3 to 6.

Mac users: By default when connecting your Wi-Drive to your computer, two drives will appear on your desktop one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your

(It is recommended that you organize your content by creating folders, e.g., "Videos, Music, Pictures and Documents")

Step 3 - Download Kingston's Free Wi-Drive App from the Visit Apple's App Store and search for "Kingston Wi-Drive".

Power on the Wi-Drive by pressing the On/Off button (see Figure 2).* *Note: After you power on, wait for Blue Wi-Fi Activity

Light to start flashing before proceeding to the next step.

Step 5

Go to the Settings icon on your iPad® iPhone®, or iPod® touch and select Wi-Fi, Confirm that Wi-Fi is ON, Select "Kingston Wi-Drive" under "Choose a Network" and click on it to

Share your content with as many as three users by having them

Before using, make sure your Wi-Drive™ is fully charged. To charge, connect the included USB cable to your Wi-Drive's mini-LISB port and the other end into an available LISB port on your computer or to a USB wall adapter. The green power

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explorer - one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVF" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from you computer to your Wi-Drive device

Mac users: By default when connecting your Wi-Drive to your computer, two drives will appear on your desktop labeled "WI-DRIVE" Double-click on the drive labeled computer to your Wi-Drive device.

Once connected, open the Kingston Wi-Drive app on your

iPad, iPhone, or iPod touch and enjoy your new expanded

POLISH

Step 1 – Charge your Wi-Drive Device and select Wi-Fi. Confirm that Wi-Fi is ON. Select "Kingston light will stop flashing when Wi-Drive is fully charged.

Step 2 - Add Content to your Wi-Drive

one Read-Only labeled "CDROM" and one Removable Disk "WI-DRIVF" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your (It is recommended that you organize your content

by creating folders, e.g., "Videos, Music, Pictures

and Documents")

Step 3 – Download Kingston's Free Wi-Drive App from the App Store

Visit Apple's App Store and search for "Kingston Wi-Drive". Step 4

Power on the Wi-Drive by pressing the On/Off button (see Figure 2).* *Note: After you power on, wait for Blue Wi-Fi Activity Light to start flashing before proceeding to the next step.

Go to the Settings icon on your iPad® iPhone® or iPod® touch

Wi-Drive" under "Choose a Network" and click on it to Once connected, open the Kingston Wi-Drive app on your

Share your content with as many as three users by having them follow steps 3 to 6.

iPad, iPhone, or iPod touch and enjoy your new expanded

SPANISH/CASTILLIAN Step 1 - Charge your Wi-Drive Device

Before using, make sure your Wi-Drive™ is fully charged. To charge, connect the included USB cable to your Wi-Drive's mini-USB port and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

Step 2 – Add Content to your Wi-Drive

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explorer - one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled

"WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your computer to your Wi-Drive device

©2011 Kingston Technology Corporation. All rights reserved. All registered trademarks

and trademarks are the property of their respective owners Printed in the U.S.A

Mac users: By default when connecting your Wi-Drive to your computer, two drives will appear on your desktop one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your

computer to your Wi-Drive device. (It is recommended that you organize your content

and Documents") Step 3 - Download Kingston's Free Wi-Drive App from the Visit Apple's App Store and search for "Kingston Wi-Drive".

by creating folders, e.g., "Videos, Music, Pictures

Power on the Wi-Drive by pressing the On/Off button

*Note: After you power on, wait for Blue Wi-Fi Activity

Light to start flashing before proceeding to the next step.

(see Figure 2).*

Go to the Settings icon on your iPad®, iPhone®, or iPod® touch and select Wi-Fi. Confirm that Wi-Fi is ON. Select "Kingston Wi-Drive" under "Choose a Network" and click on it to

Once connected, open the Kingston Wi-Drive app on your

iPad, iPhone, or iPod touch and enjoy your new expanded

Share your content with as many as three users by having them follow steps 3 to 6

For the complete User Manual and list of FAQs, please visit us

PORTUGUESE

Step 1 – Charge your Wi-Drive Device

Before using, make sure your Wi-Drive™ is fully charged. To charge, connect the included USB cable to your Wi-Drive's mini-USB port and the other end into an available USB port on your computer or to a USB wall adapter. The green power light will stop flashing when Wi-Drive is fully charged.

computer to your Wi-Drive device

computer to your Wi-Drive device.

Windows users: When connecting your Wi-Drive to your computer, two drive letters will appear in Windows Explorer — one Read-Only labeled "CDROM" and one Removable Disk labeled "WI-DRIVE" Double-click on the drive labeled "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your

labeled "WI-DRIVE" Double-click on the drive labeled

(It is recommended that you organize your content by creating folders, e.g., "Videos, Music, Pictures

Step 3 - Download Kingston's Free Wi-Drive App from the

Power on the Wi-Drive by pressing the On/Off button

Light to start flashing before proceeding to the next step.

Step 2 – Add Content to your Wi-Drive

Mac users: By default when connecting your Wi-Drive to your computer, two drives will appear on your desktop one Read-Only labeled "CDROM" and one Removable Disk "WI-DRIVE" to add your content. Transfer your files the same as you would for any USB drive; drag or copy files from your

and Documents")

Visit Apple's App Store and search for "Kingston Wi-Drive".

*Note: After you power on, wait for Blue Wi-Fi Activity

FCC Compliance and Advisory Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device,

according to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- 1. Reorient the receiving antenna.
- 2.Increase the separation between the equipment and receiver.
- 3. Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.

Any special accessories needed for compliance must be specified in the instruction manual.

Warning: A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used. Use only shielded cables to connect I/O devices to this equipment.

CAUSION: Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.