

PRINTING COLOURS:	CMYK
NON PR COLOURS:	DIELINE
	WHITE SUBSTRATE

ALTHOUGH EVERY POSSIBLE EFFORT HAS BEEN MADE TO ENSURE ACCURACY, ERRORS CAN OCCUR. PLEASE CHECK THIS PROOF/PDF FILE CAREFULLY. THIS PROOF/PDF FILE IS FOR COLOUR BREAK ONLY AND MAY NOT ACCURATELY REFLECT FINAL PRINTED INKS.

33,6 mm  
167 mm

42,8 mm

**MIGHTY TRUCK**



**MIGHTY TRUCK**

Vehicle de acción teledirigida

**MIGHTY TRUCK**

**KID'SN PLAY**

**WARNING**  
CHEN/AVERTENCIA

**MIGHTY TRUCK**

Scale 1:18

Wireless RC Action! Actación del CR inalámbrico

Multi-Directional Operation Funcionamiento multidireccional

Bright LED Headlights Faros delanteros brillantes en LED

Available in 2 Frequencies Disponible en 2 Frecuencias 27 MHz/49 MHz

**MIGHTY TRUCK**



**ADVERTENCIA:**  
RIESGO DE NAUFRIO - Precaución, No nadar.  
Colours and details may vary slightly. Los colores y detalles pueden variar.

**MIGHTY TRUCK**



**MIGHTY TRUCK**

Radio Controlled Action Vehicle

**Operating Instructions / Instrucciones de uso:**


**WIRELESS RC ACTION! / ACTACIÓN DEL CR ALÁMBRICO**

1. Check the battery level. The battery level is indicated by the LED lights on the front of the truck. If the battery is low, the LED lights will be dim.
2. Turn on the truck. Press the power button on the back of the truck. The truck will start moving forward.
3. Control the truck. Use the remote control to move the truck in the direction you want. The remote control has a directional pad and a power button.
4. Stop the truck. Press the power button on the back of the truck. The truck will stop.
5. Recharge the battery. When the battery is low, you will need to recharge it. The battery is located on the bottom of the truck.
6. Troubleshooting. If the truck is not moving, check the battery level and the remote control. If the truck is not responding to the remote control, check the frequency selection.

**WIRELESS RC ACTION! / ACTACIÓN DEL CR ALÁMBRICO**

1. Compruebe el nivel de la batería. El nivel de la batería se indica por las luces LED en la parte delantera del camión. Si la batería está baja, las luces LED serán débiles.
2. Encienda el camión. Presione el botón de encendido en la parte posterior del camión. El camión comenzará a moverse hacia adelante.
3. Controle el camión. Use el control remoto para mover el camión en la dirección que desea. El control remoto tiene un panel direccional y un botón de encendido.
4. Detenga el camión. Presione el botón de encendido en la parte posterior del camión. El camión se detendrá.
5. Recargue la batería. Cuando la batería esté baja, necesitará recargarla. La batería se encuentra en la parte inferior del camión.
6. Solución de problemas. Si el camión no se mueve, compruebe el nivel de la batería y el control remoto. Si el camión no responde al control remoto, compruebe la selección de frecuencia.

INSERT COLOR



STICKER

