Operation method

Ready to boot

1. insert TF card of burned program

2, use 5 V2A of power to charge the machine, about 5 hours 2,. If it's a 5 V1A power charge, it' II be longer

Switchgear operation

1. boot - press power button for 2 seconds

2. Shutdown - Press Power Key to Shutdown or Press SELECT" to Select Shutdown and Restart

Press "Power" for 7 seconds - Force shutdown

Game operation

When entering the desktop, the direction key is left and right - select the simulator press the A key to enter the game directory, the direction key up and down select the game program, press the L1R2 to change the simulator, press the A key to start the game

Press the SELECT START to exit the game. SELECT up and down = volume adjustment

Functional operations

Luminance Adjustment - Press "START" Select" System Settings "-" BRIGHTNESS* to adjust

Audio Adjustment - Press START" Select - Sound Settings - System

If technical and system updates may lead to operational changes. without prior notice!

RGB 10 MAX II 説明書

機能の説明 - A Button Left Stick Right Stick

コンビネーションキー操作説明

WFIを同時に関くとマシンの机能時間が減ります。

SELECT-START-Y-L4-97 L4-4 / SELECT-UP/DOWN-IF-913980 SELECT-L1/R1-ゲームストア/ゲームの研算込候 SELECT-LEFT/RICHT-ゲーム格輪ローカル SELECTIVAL DIRECTOR AND A STATE OF THE SELECTION OF THE S

WIFI-正常に機能停止状態にあります。使用が必要なら、手動で開く必要があります。

オンノナフ操作

電時間が長くなります

電源投入前の準備

2.シャットダウン-電源キーを押してシャットダウンするか、SELECT を押して シャットダウンと再起動を選択 電源キーを7秒間長押しします (強制的にシャットダウンします)。

1.電源を入れ、電源キーを 2.秒間長押しするとシステムに入る

操作方法

2.5V2A の電源を使用して自机を充電して、約 2.5 時間。5V1A の電源の場合充

1 修み上がったプログラムを組入した 耳 カード

ゲーム操作

進入机面後、方向鍵左右-選択シミエレータ、押 A 鍵進入游戯目録、方向鍵上 下選択游戯者組、押 L1 R2 支援シミュレータ、押 A 練開始游戯 同時に SELECT START を押すとゲームを終了し、SELECT 方向上下=ポリュームサ 2 T 10 83

明るさの開整-START キーを押してシステム設定を選択-BRIGHTNESS キーを押

サウンド調整。CTART カーを押して提択、サウンド時間、システムボリューム

技術やシステムのアップデートがあった場合、予告なしに動作が変更されるこ

Operation method

1, insert TF card of burned program

2, use 5 V2A of power to charge the machine, about 5 hours 2,. If it's a 5 V1A power charge, it' II be longer

Switchgear operation

1. boot - press power button for 2 seconds

2. Shutdown - Press Power Key to Shutdown or Press SELECT" to Select Shutdown and Restart Press "Power" for 7 seconds - Force shutdown

Game operation

When entering the desktop, the direction key is left and right - select the simulator, press the A key to enter the game directory, the direction key up and down select the game program, press the L1R2 to change the simulator, press the A key to start the game


Press the SELECT START to exit the game SELECT up and down a volume adjustment

Luminance Adjustment - Press "START" Select" System Settings "-" BRIGHTNESS* to adjust

Audio Adjustment - Press START" Select - Sound Settings - System

If technical and system updates may lead to operational changes without prior notice!

RGB 10 MAX II 説明書



コンピネーションキー操作説明

機能の説明

SELECT-START-Y-LIFET/LIFET/SELECT-UP TOWN-IF REDER SELECT-L1/R1-ゲームストア/ゲームの記録込製 SELECT-LEFT/RIGHT-ゲーム格納ローカル SELECT-X-L3-R3-RAVXFLICX&/SELECT-B-ゲームリセット

WFI-正常に機能停止状態にあります。使用が必要なら、手動で何く必要があります。 WF市同時に関くとマシンの机械時間が減ります。

操作方法

電源投入前の準備

1値まとがったプログラムを組入した 頂カード 2.5V2A の電源を使用して白机を充電して、約 2.5 時間。5V1A の電源の場合充 電時間が長くなります

オン/オフ操作

1 雷艇を入れ、雷艇キーを2 時間長押しするとシステムに入る 2.シャットダウン-電腦キーを押してシャットダウンするか、SELECT を押して シャットダウンと再起動を選択 電源キーを7秒間長押しします (強制的にシャットダウンします)。

進入机面後、方向鍵左右-選択シミエレータ、押 A 鍵進入游戯目録、方向鍵上 下選択游戯香組、押 L1 R2 支換シミュレータ、押 A 腱関始游戯 同時に SELECT START を押すとゲームを終了し、SELECT 方向上下=ポリュームサ × ± 100.00

明るさの測整-START キーを押してシステム設定を選択-BRIGHTNESS + ーを押

セウンド調整-START ターを押して開創しセウンド語信してそんボリュール

技術やシステムのアップデートがあった場合、予告なしに動作が変更されるこ

. . .

RGB 10 MAX II 说明书

按键操作说明

SLECT-SIMT-組合的成 / SLECT-十字架上/下-音樂等等 SLECT-SLL/在80-他也保存/指数 / SLLCT-LET-NOT-多地存储 HERTOLING-BARRER / HERTO-BREET WWF-正常处于天地状态测量的中枢/GUEFF/FG MIN. HOWEVER, MERCHANISTS AND IN-

操作方法

开机前准备 1.插入您好的程序的 TF 卡

2.使用 5V2A 的电源对本机进行充电 , 大约 2.5 小时. 如果是 5V1A 的电源充电时间会延长

开学机操作

1.开机-长按"电源键"2 秒可进系统

2.关机-按"电源键"可关机 也可以按"SELECT" 选择关机和重启 长按"电源键"7秒。强制关机

讲卓面后 方向键左右-洗择模扣器 核 Δ 键讲入游戏目录 方向键 上下选择游戏节目,按 L1 R2 变换模拟器,按 A 键开始游戏 同时按 SELECT+START 可退出游戏, SELECT+方向上下=音量大小

调节 功能操作

亮度调节--按"START" 选择"系统设置"---"BRIGHTNESS" 进行调节 声音调节--按"START"选择- 声音设置--系统音量

如有技术和系统更新可能导至操作有变,想不另行通知!

RGB10 MAX II Instruction




Combination Key Description

SELECT-STORT-QUIT THE GOVE / SELECT-SPORT-VIOL-V-SELECT-LL/ST-GOVE SWELLOAD / SELECT-LEFT-STORT-VIOL LOXIDIN SELECT-0-CA-43-EVER BY DISTRY / SELECT-0-GARE RESET

SIFI-Normally shot does ,it will be turned on when no

RGB 10 MAX II 说明书



按键操作说明 SUSCINITIONS / SUSCI-1-981-/T-088T

SEECT-ELL/640-砂食長谷/抽取 / SEECT-EPT-E SEECT-G-C+O-世入担係性 / SEECT-G-EPG-EE **WWF-示范处于天州状态调查的时候可以打行所以** API, 开口winter(ARRIVING 有形成力。

操作方法

开机前准备

1.插入您好的程序的 TF卡 2.使用 5V2A 的电源对本机进行充电 , 大约 2.5 小时. 如果是

5V1A 的电源充电时间会延长

1.开机-长按"电源键"2 秒可进系统

2.关机-按"电源键"可关机 也可以按"SELECT" 选择关机和重启 长按"电源键"7 秒。强制关机

开关机操作


讲卓丽后 方向键左右-洗择模拟器 按 ▲ 镍进入游戏目录 方向键 上下选择游戏节目,按 L1 R2 变换模报器,按 A 键开始游戏 同时按 SELECT+START 可退出游戏, SELECT+方向上下=音量大小

调节 功能操作

亮度调节--按"START" 选择"系统设置" --- "BRIGHTNESS" 进行调节 声音调节--按"START"选择- 声音设置--系统音量

如有技术和系统更新可能导至操作有变,想不另行通知!

RGB10 MAX II Instruction



Combination Key Description

SERVING OF THE COST / SERVINGSON, VI SELECT-LATE-GOME SWEATON / SELECT-LEFT RESERVANCE LOCKTON-SELECT-0-C3-90-DYTER BA SYSTEM / SELECT-0-GAME RESET

the power communition of the machine and the lattery duration will be increased.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be u sed in portable exposure condition without restriction