C57

WIRELESS HANDSFREE CAR KIT

With FM Transmitter

and QC3.0 fast charging

5.0 version

▶▶ User Guide

Package contents

- FM transmitter *1
- User Guide *1

Specifications

- Wireless version: V5.0
- Support agreement: A2DP,AVRCP,HFP,HSP
- Frequency range: 87.5~108.0MHz
- FM transmission distance: about 3M
- Product Input: DC12-24V
- Output: QC3.0 Fast charging
- Music format: MP3,WMA,WAV
- USB: (Max capacity): 64GB
- product weight: 37g
- Low power alert: flashing under 12V
- Material: ABS+High-end Anodic Aluminum Oxide(AAO) Sand-blasting Technology

Features

- Transmitter phone call from mobile phone to car FM Stereo system
- Switch from music playing mode to Hands-free mode automatically when receiving call

---

- Built-in Microphone
- LED screen display
- Car Battery voltage display
- Full 206 channels from 87.5-108.0MHz
- Caller number announcer
- Redialing last call

Cautions

- keep the product away from extreme heat or cold,as well as any flammable materials or damp places
- **DO NOT** use under direct sunshine
- **DO NOT** disassemble the product without professional instruction. it will void warranty coverage

Diagram

Charging 5V/1A & USB flash drives

QC3.0 Fast Charging

87.5

LED Screen

Microphone

USB charger

USB socket with music logo printed on it supports up to 64GB FAT format U disk to play music, and supports 5V/1A current output charging.

The socket marked with QC3.0 on the USB port is a fast-charge socket and supports QUALCOMM QC3.0 protocol, DC3.5-6.5V/3A, 6.5-9V/2A, and 9-12V/1.5A.

---

1. Answer / Hang up
2. paly/pause
3. Long press one second to find FM mode

▶▶ 1. Next song
2. Listen to music mode, press once to increase volume
3. Increase frequency in frequency modulation mode

▶▶ 1. Previous song
2. Listen to music mode, press once to decrease the volume
3. In frequency modulation mode, press once to decrease frequency

Instruction manual

Plug the FM transmitter into your vehicle's cigarette lighter port. The LED display will indicate the voltage of car battery for 5 seconds.Then the device turns into Wireless pairing mode.LED screen displays "bt". Please follow the FM frequency tuning instruction and the wireless pairing instruction.After setting FM frequency and pairing wireless, you can answer phone calls and play music through the transmitter.

FM Frequency Tuning

Tune your car radio to a blank FM frequency. Press and hold the " "button till the LED screen starts flashing the frequency.Press the previous/next button tune the transmitter to the same blank frequency.

Wireless Pairing

At the first time,you will need to pair your mobile phone with the transmitter.Activate Wireless on your mobile phone,then search the transmitter(named as "C57").Choose the transmitter and pair it with your phone.Normally the connection will pair automatically but sometimes it will require you to enter the password.Please use the the password"0000".

Answering Phone Call

- Please press the " "to answer the incoming call.
- Please press the" "to hang off a call.
- Please press the" "twice to dial the last Number.
- When making a call,you can only dial the phone number by your mobile phone.
- Reject phone calls: when there is any calls coming under wireless hands-free mode,you can long click" "button to reject it if you are not convenient to answer.

Playing Music

- Turn on the music APP on your phone or insert USB flash drive which contains mp3 files into the slot(it will play music automaticlly if using USB flash drive)
- Press   button to play the music.
- Press   while playing music to pause
- Press ▶▶ to play the previous song
- Press ◀◀ to play the next song
- Long Press ◀◀ to raise Volume
- Long Press ▶▶ to lower Volume
In the music playing mode,when there is an incoming call, this unit will automatically switch to hands free mode.

Changing for playing source

- Changing U-disk mode into phone wireless playing mode: when it's playing under U-disk mode,you can search for device named"C57" in wireless page of your phone.When it connect successfully, you can open music app and click play button,now it has changed into playing via wireless mode.

- Changing phone wireless playing mode into U-disk mode: when it's playing under phone wireless mode,you can click the play button to pause music and wait for 3 seconds. "usb" will be displayed in the screen of this device.Now you can insert U-disk and it has changed into playing from U-disk.

☺ **Friendly Tips**：

After receiving the product, do not hurry to insert the product into the cigarette light hole of the car. After starting your car, firstly an idle FM channel with no local radio station program patiently on the car radio, and the standard is a slight rustling sound. Then insert the product into the cigarette hole, and adjust same FM frequency of the product as the FM frequency of the car. At this time, the car radio will be very quiet and there is no static interference. (If it's still not quiet, try to find new ones again. The free channel), and finally connect your phone with the product via wireless.When they are pairing successfully,you can enjoy the song from your phone.

Quick Guide

Operation Guide	On FM transmitter
Answer / hang up the call,redial	Press : answer the call Press : hang off the call Press the twice to redial the last caller
Play and Pause the music	Press Button:Play the music Press again:Pause the music
Adjust the Volume	Long Press ◀◀ or ▶▶ to adjust the Volume
Frequency tuning	Press and hold till Frequency keep flashing Press ◀◀ to increase the frequency Press ▶▶ to decrease the frequency
Choose music	Press ▶▶ to play the previous song press ◀◀ to play the next song

CE FC ♻ ✓RoHS

MADE IN CHINA