

Naporon

User Manual
取扱説明書

WIRELESS EARBUDS | ワイヤレスイヤホン

Naporon E10の製品を使って頂き誠にありがとうございます。説明書をちゃんと読んで、そして保管してお願いいたします。

カタログ

1. 梱包リスト 1
2. ボタン示す 2
3. パラメータ 2
4. ペアリング説明 3
5. 通話コントロール 4
6. 音楽操作 4
7. 操作シート一覧 5
8. 充電説明 6
9. 注意事項 7
10. 安全指示 7
11. アフターサービス 7

1. 梱包リスト

- ① Naporon E10イヤリング 1pc
- ② シリコンイヤピース 10pcs
- ③ イヤーパッド 6pcs
- ④ コードスライド 1個
- ⑤ USB充電ケーブル 1本
- ⑥ 取り扱い説明書 1枚

2. ボタン示す

3. パラメータ

バージョン	4.1	チップ	CSR8645
サイズ	570x23.4x29mm	重量	15g
範囲	10M/33Ft	動き時間	音量が60%にて8時間再生できます
待機時間	100時間	充電時間	1.5時間
電池	3.7V 55mAh*2	周波数	20Hz-20KHz
拡声器抵抗	32Ω±15% at 1KHz	拡声器直径	2 X Φ6mm

製品パラメータ、規格が変更する場合は、別途お知らせいたしません。

4. ペアリング説明

- 1) 電源入れず: MFBボタン 3秒長押し、青ランプは点滅す。電源を切る: MFBボタンを3秒長押し、赤ランプを一回点滅する。
- 2) ペアリング: A. 電源をOFF状態で、青いランプを点灯まで(3秒くらい) MFBを長押しすること。 B. イヤリングとペアリングしたい設備のBluetoothをONにして、「Naporon E10」と言うペアリング名を繋がります。繋がりが成功してから青ランプ点灯します。
- 3) ペアリングし直し: 一回繋がった記録がありましたら、次回同じ設備と繋がりたい場合、設備とイヤリングの電源をONすれば、自動で繋がります。
- 4) ペアリングを切る: 携帯と繋がっている状態で、「+」と「-」を同時に長押しすると繋がっているモードを切り替えます。
*長い時間繋がれないと、電源を切つて以上の操作方法を繰り返す。

5. 通話コントロール

- 1) 電話をかける: 電話が入る時、MFB「▲」を一回押す。
- 2) 電話を切る: 電話が入る時、MFB「▲」を1秒押す。
- 3) 通話を切る: 通話中にMFB「▲」を一回押す。

6. 音楽操作

- 1) 音楽を放送する: MFB「▲」を一回押すor携帯に操作する。青ランプは6秒毎で一回点滅する。
- 2) 一回停止: 放送しているうちにMFB「▲」を一回押しor携帯に操作する
- 3) 曲送り: 音楽を放送しているうちに、「+」ボタンを長押し
- 4) 曲戻り: 音楽を放送しているうちに、「-」ボタンを長押し
- 5) ポリウム+: 音楽を放送しているうちに、「+」ボタンを一回押し
- 6) ポリウム-: 音楽を放送しているうちに、「-」ボタンを一回押し

7. 操作シート一覧

順番	機能	操作	知らせ音
1	電源ON	MFBボタン3秒長押し	Di Di Di
2	電源OFF	MFBボタン3秒長押し	Di Di Di
3	音楽放送	MFBボタン一回押す	N/A
4	音楽一時停止	MFBボタン一回押す	N/A
5	ボリューム+	「+」ボタンを一回押し	音量大のなった時音デュー、デュー発生する
6	ボリューム-	「-」ボタンを一回押し	N/A
7	電話出る	MFB「▲」を一回押す	N/A
8	電話終了	通話中にMFB「▲」を一回押す	N/A
9	電話を切る	電話が入る時、MFB「▲」を2秒押し	N/A
10	電話中にイヤリングと携帯切り替え	MFB「▲」を2秒長押し	N/A
11	リセット設置	充電の時MFB「▲」を3秒長押し	N/A

8. 充電説明

- 1) 付属しているUSBケーブルで充電してください、初めて使う時電量満杯にしてください。
- 2) 電池の寿命を長くなるため、30日に一回満杯まで充電してください。
- 3) 電量が低下した時LEDランプ点滅する。
- 4) 充電中に赤ランプ点灯。
- 5) 電量が満杯になった時青ランプ点灯する。

リセット: 充電している状態でMFBボタンを3秒押し、両方青ランプ点滅する。

- 9. 注意事項**
- 1) 落とさないように注意すること。
 - 2) 分解しないでください。
 - 3) 赤やんに遊ばないでください。小さい部品が入っていますので、赤やんに危ないです。
 - 4) 水に浸さないでください。
 - 5) 直接太陽の下、高温環境に放置しないでください。
 - 6) 磨食剤で洗浄しないでください。
- 10. 安全指示**
- 1) ヒヤリングを壊さないように、高温で長く聞かないようにしてください。
 - 2) 周りの音を聴けるように音量を過ぎないようにしてください。
 - 3) 運転やバイクにする時使わないでください。
 - 4) 危険性が存在する時慎重や使用停止してください。
- 11. アフターサービス**
- 1) 12ヶ月保証期間: 発注日から人の原因で破損したのは12ヶ月修理保証があります。使用者が有効な購買インボイスや保証カードを提供する必要があります。
 - 2) 以下の場合修理保証できません:
 - A. 中古イヤリングや認証していない店に購入したもの。
 - B. 操作ミスで破損した場合。
 - C. 化学剤、火災、放射性物質、有害物、液体で破損した場合。
 - D. 自分で分解や別の修理所で破損した場合。
 - E. 自然災害で破損した場合。

FCC statement:
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Mailadi Trading Co., Ltd.

List

1. Packing List 1
2. Buttons Illustration 2
3. Specifications 2
4. Operation Guide 3
5. Calling Operation 4
6. Music Operation 4
7. Quick Information Table 5
8. Charging 6
9. Safety Instructions 7
10. Hearing Safety 7
11. Warranty 7

1. Packing List

- ① Naporon E10 Earbuds 1pc
- ② Silicone Ear Tips 10pcs
- ③ Secure Fit Wingtips 6pcs
- ④ Slide Line Buckle 1pc
- ⑤ USB Charging Cable 1pc
- ⑥ User Manual 1pc

2. Buttons Illustration

3. Specifications

Version	4.1	Chip	CSR8645
Dimension	570x23.4x29mm	Weight	15g
Range	10M/33Ft	Working Time	8 hours when the volume at 60%
Standby Time	up to 100 hours	Charging Time	1.5 hours
Battery	3.7V 55mAh*2	Frequency Response	20Hz-20KHz
Impedance	32Ω±15% at 1KHz	Diameter	2 X Φ6mm

Specification are subject to change without notice.

4. Operation Guide

- 1) Turning on: Press and hold multifunction button for 3 seconds. The LED light breathes blue quickly. Turning off: Press and hold multifunction button for 3 seconds. The LED light flashes red once quickly.
- 2) Pairing and Connecting: A. Press and hold multifunction button for about 3 Seconds under powering off mode until the blue indicator breathes quickly to enter pairing mode. B. Active the Paring function on device and search for the earbuds name "Naporon E10" to connect. If successful connection, the indicator light is solid blue.
- 3) Re-connecting: If you have previously paired the earbuds with a device, simply turn on your earbuds and the device, they will automatically connect within 10 seconds without going into pairing mode.
- 4) Disconnecting: Simultaneously press and hold "+" and "-" buttons to disconnect. Remarks: If the earbuds and device cannot connect for a long time, please repeat the Pairing and Connecting instructions.

5. Calling Operation

- 1) Answer an incoming call: Short press multifunction button.
- 2) Reject an incoming call: Press and hold multifunction button.
- 3) End an active call: Short press multifunction button in an active call.

6. Music Operation

- 1) Play Music: Short press multifunction button or play on device when connected.
- 2) Pause Music: Short press multifunction button or pause on device.
- 3) Next Track: Press and hold "+" button when playing music.
- 4) Previous Track: Press and hold "-" button when playing music.
- 5) Volume "+": Short press "+" button when playing music.
- 6) Volume "-": Short press "-" button when playing music.

7. Quick Information Table

Item	Function	Operation	Voice Prompts
1	Power On	Press and hold Multifunction button for about 3 seconds	Di Di Di
2	Power Off	Press and hold Multifunction button for about 3 second	Di Di Di
3	Play Music	Short press Multifunction button	N/A
4	Pause Music	Short press Multifunction button	N/A
5	Volume+	Short press Volume+	"D" when volume reaches the highest level
6	Volume-	Short press Volume-	N/A
7	Answer a Incoming Call	Short press Multifunction button	N/A
8	Hang Up	Short press Multifunction button as an active call	N/A
9	Reject a Incoming Call	Press and hold Multifunction button for about 2 seconds	N/A
10	Transfre between earbuds and Phone in a Call	Press and hold Multifunction button for about 2 seconds	N/A
11	Reset	Press and hold Multifunction button for about 3 seconds when charging	N/A

8. Charging

- 1) Use the included USB cable to charge your earbuds. Make sure it is fully charged before first use.
- 2) To preserve battery lifespan, fully charge at least once every 30 days.
- 3) The Led indicator flashes red when low battery
- 4) The Led indicator turns solid red when charging.
- 5) The Led indicator turns solid blue when fully charged. Reset: Press and hold multifunction button for 3 seconds when charging with Led light flashing blue twice quickly.

- 9. Safety Instructions**
- 1) Do not drop or knock the earbuds on hard surfaces
 - 2) Do not take the earbuds apart
 - 3) Keep out of reach of children. It contains small parts which may be a choking hazard.
 - 4) Do not submerge in water.
 - 5) Do not expose the earbud under direct sunlight or hot areas.
 - 6) Do not use any chemicals or detergents to clean the earbuds.
- 10. Hearing Safety**
- 1) To avoid hearing damage, do not use the earbuds at high volume for extended periods.
 - 2) Do not turn the volume too high to hear your surroundings.
 - 3) Do not use earbuds while driving
 - 4) In potentially hazardous situations, you should use carefully or temporarily stop using the earbuds.
- 11. Warranty**
- 1) We warrant the earbuds 12 months from the date of the original purchase for manufacturer defects. Please provide the valid invoice and warranty card.
 - 2) The following are excluded from warranty cover:
 - A. Purchased as second hand or from unauthorized seller.
 - B. Damage caused by misuse and abusive action.
 - C. Damage caused by chemical, fire, radioactive substance, poison, liquid.
 - D. Damage caused by private disassembling by user or unauthorized maintenance stations.
 - E. Damage caused by natural disaster.