

SYLVANIA

KARAOKE BLUETOOTH PORTABLE

MICROPHONE

SP-041



User Manual

SYLVANIA is a registered trademark of OSRAM Sylvania Inc. used under license

Please read the precautions carefully before using this karaoke bluetooth portable microphone for proper and safe operation, to optimize its performance and extend its life.

- 1.This product works with max voltage 5.25V, and electric current 2A for charging,and it will be damaged if charging is done beyond this max voltage and current.
- 2.Do not expose the karaoke bluetooth portable microphone to direct sunlight; otherwise, the product may be damaged.
- 3.Take good care of the karaoke bluetooth portable microphone and prevent water or sand particles from entering the karaoke bluetooth portable microphone when it is used on the beach or water, because water, sand partides or component containing salt may damage the product.
- 4.Keep the product free of dust and chemical materials. Keep it in a cool, dry and well ventilated environment. Do not keep the product in a high temperature, moist or dusty environment.
5. Place it under high temperature or moist environment or expose to sunshine directly.

How to sing by wireless:

1. Power on: Press the power button once, the blue LED illume on and flashing quickly.
2. Bluetooth connection: Turning on your cell phone's Bluetooth function and scanning, searching pairing name "Sylvania SPMC100-B-GOLD" and click it paired, there will have a tone when successful paired.
3. Play music load on your music website, download your favorite music or accompaniment. will start to play, can adjust accompaniment volume on your cell phone.
4. Turning the VOL up and down can adjust the microphone level.
5. Turning the ECH up and down can adjust the echo level.

Note:

After connection with your cellphone once, which will connect automatically next time, it can connect last device when power on. If you want to disconnect bluetooth, please turn your bluetooth off. if only listen to music, advise to adjust the VOL level to the lowest.

How to play recorder by mobile phone

Connect with recording cable, pick up recording cable (accessory included) insert USB port side to unit's micro USB jack, insert the 3.5mm of the other end of recording cable to the mobile phone's earphone jack.

Note: When inserting the recording cable, the Bluetooth function will be disconnected automatically.

Turn on your mobile phone's APP "Recorder" to sing by unit, it will record your sing as the same time. and you can save it in your phone or singing again.

How to record music by mobile phone


Connect to mobile phone s Bluetooth then turning on your mobile phone s APP Sing or other recording song's'APP, choose your favorite songs to sing by unit, after finish, singing your can save it or singing again.

Note: All playing function depends on mobile phone APP.

How to charge

1. When the battery's voltage is too low, the microphone will be off automatically.
2. Charging by USB cable, connect USB cable to standard adapter to charge if red light under switch is on, means on charging.
3. Normally 2 hours fully charged, if charge completed, red light will be off Automatically.
4. Working time is 3-5 hours after fully charged.

- 9: Sensitivity: -46 db
- 10: Battery: polymer lithium ion battery
- 11: Battery capacity: 1000mAh
- 12: Charging power: DCSV
13. Playing time: about 3~5 hours
14. Charging time: 2 hours normally
15. Bluetooth distance: 10 meters(free space)



Specification:

- | | |
|-----------------------------------|-----------------------------|
| 1: The main material: plastic | 5: Speaker : 50mm*1/4 4Ω |
| 2: Microphone: capacitance | 6: Output power: 3W |
| 3: Frequency response: 80Hz~16kHz | 7: SNR: 85dB (THD+N=1%) |
| 4: Product size: 22*6.8*6.8CM | 8. MIC ECHO time: 120-196ms |

For service assistance and product information, please call: 1-800-968-9853.
Curtis International Ltd.
7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON, L5S 2A3 www.curtisint.com

SYLVANIA

KARAOKE BLUETOOTH PORTABLE MICROPHONE SP-041



Manuel Utilisateur

SYLVANIA est une marque déposée d'OSRAM Sylvania Inc, utilisée sous licence

— 1 —

Veillez lire attentivement les précautions avant d'utiliser ce microphone portable karaoké Bluetooth pour un fonctionnement correct et sûr, pour optimiser ses performances et prolonger sa durée de vie.

1. Ce produit fonctionne avec une tension maximale de 5,25 V et un courant électrique de 2 A pour la charge, et il sera endommagé si le chargement est fait au-delà de cette tension et de ce courant maximum.
2. N'exposez pas le microphone portable karaoké bluetooth à la lumière directe du soleil; sinon, le produit pourrait être endommagé.
3. Prenez bon soin du microphone portable karaoké bluetooth et empêcher l'eau ou les particules de sable de pénétrer dans le microphone portable karaoké bluetooth lorsqu'il est utilisé sur la plage ou dans l'eau, car l'eau, les particules de sable ou les composants contenant du sel peuvent endommager le produit.
4. Gardez le produit exempt de poussière et de produits chimiques. Conservez le produit dans un environnement frais, sec et bien ventilé. Ne conservez pas le produit dans un environnement chaud, humide ou poussiéreux.
5. Placez-le à température élevée ou dans un environnement humide ou exposez-le directement au soleil.

Comment chanter en sans fil :

1. Allumer: Appuyez une fois sur le bouton d'alimentation, le LED bleu s'allume et clignote rapidement.
2. Connexion de bluetooth: Activez la fonction de Bluetooth et du balayage de votre téléphone, en recherchant le nom d'appariement "Sylvania SPMC100-B-GOLD" et en cliquant dessus, il y aura une tonalité lorsque la connexion aura terminé.
3. Jouez de la musique qui charge sur votre site Web de musique, téléchargez votre musique préférée ou l'accompagnement. Il va commencer à jouer et vous pouvez régler le volume de l'accompagnement sur votre téléphone portable.
4. En tournant le volume vers le haut ou vers le bas, vous pouvez régler le niveau du volume du microphone.
5. En tournant le bouton ECH vers le haut et vers le bas, vous pouvez régler le niveau de l'écho.

Remarque:

Après la connexion avec votre téléphone portable une fois, le produit se connectera automatiquement la prochaine fois, et il peut connecter le dernier appareil à la mise sous tension. Si vous souhaitez déconnecter le Bluetooth, désactivez la fonction de bluetooth SVP. Et si vous souhaitez seulement écouter de la musique, il est mieux d'ajuster le niveau de VOL au plus bas.

— 2 —

Comment jouer enregistreur par téléphone portable:

Connecter avec le câble d'enregistrement, relier le câble d'enregistrement (accessoire inclus) à la prise de micro USB de l'unité, et insérer le câble 3,5 mm de l'autre extrémité du câble d'enregistrement dans la prise d'écouteurs du téléphone portable.

Remarque: Lors de l'insertion du câble d'enregistrement, la fonction Bluetooth sera automatiquement déconnectée.

Allumez l'application "Recorder" de votre téléphone portable pour chanter à l'unité, il enregistrera votre chant en même temps. Et vous pouvez l'enregistrer sur votre téléphone ou chanter à nouveau.

Comment enregistrer de la musique sur un téléphone portable

Connectez-vous au téléphone portable Bluetooth, puis allumez l'APP de «Chanter» de votre téléphone ou l'autre APP d'enregistrement de la chanson, choisissez vos chansons préférées à chanter par l'unité, après avoir fini de chanter, vous pouvez l'enregistrer ou chanter à nouveau.

Remarque: Toute la fonction de lecture est dépendue du APP de téléphone portable.

Comment le charger

1. Lorsque la tension de la batterie est trop basse, le microphone s'éteint automatiquement.
2. Charge par le câble USB, branchez le câble USB à l'adaptateur standard pour charger le produit, si le voyant rouge sous le commutateur est allumé, cela signifie lors du chargement.
3. Normalement, la charge sera terminée complètement dans 2 heures, si la charge est terminée, le voyant rouge s'éteint automatiquement.
4. Le produit travaillera pour 3-5 heures après une complète charge.



Spécification:

- 1: Le matériau principal: plastique
- 2: Microphone: capacitance
- 3: Fréquence de réponse: 80Hz-16kHz
- 4: Taille du produit: 22*6.8*6.8CM
- 5: Speaker: 50mm*1/4 4Ω
- 6: Puissance de sortie: 3W

— 3 —

- 7: SNR: 85dB (THD+N=1%)
- 8: Temps de MIC ECHO: 120-196ms
- 9: Sensibilité: -46 db
- 10: Batterie: batterie lithium ion polymère
- 11: Capacité de la batterie: 1000mAh
- 12: Puissance de charge: DC5V
- 13: Temps de jouer: vers 3-5 heures
- 14: Temps de la charge: normalement 2 heures
- 15: Distance de Bluetooth: 10 mètres (espace ouvert)

Pour obtenir assistance et information appelez: 1-800-968-9853.
Curtis International Ltd.
7045 BECKETT DRIVE, UNIT 15, MISSISSAUGA, ON, L5S 2A3 www.curtisint.com

— 4 —

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.